

MaxiDas_AlfaRemeo_V3.00 Function List (Note:For reference only)

NOTES:

- This function is supported. X This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported. rianlge This function is the new feature in this version.

As for special function please refer to the special function table.

| lode1 | Version | Group | System | ECU info. | Read Codes | Erase Codes | Live Data | Active Test | Specil Function |
|----------|----------------|--------|----------------------|-----------|---------------|----------------|--------------|----------------|-----------------|
| 45 | 1. 4 TS 16V | Safety | ICIT/TRW VAS95 alarm | • | 00000 | • | • | • | 0 |
| 45 | 1. 6 TS 16V | Safety | ICIT/TRW VAS95 alarm | • | • | • | • | • | 0 |
| 45 | 1. 8 TS 16V | Safety | ICIT/TRW VAS95 alarm | • | • | • | • | • | 0 |
| 15 15 | 2. 0 TS 16V | Safety | ICIT/TRW VAS95 alarm | • | • | • | • | • | 0 |
| 15 | '98 1.4 TS 16V | Safety | ICIT/TRW VAS95 alarm | • | • | • | • | • | 0 |
| 5 | '98 1.6 TS 16V | Safety | ICIT/TRW VAS95 alarm | • | • | • | • | • | 0 |
| 5 | '98 1.8 TS 16V | Safety | ICIT/TRW VAS95 alarm | • | • | • | • | • | 0 |
| 5 | '98 2.0 TS 16V | Safety | ICIT/TRW VAS95 alarm | • | • | • | • | • | 0 |
| :5 | '99 1.9 JTD | Safety | ICIT/TRW VAS95 alarm | • | • | • | • | • | 0 |
| 6 | 1. 4 TS 16V | Safety | ICIT/TRW VAS95 alarm | • | • | • | | • | 0 |
| 6 | 1. 6 TS 16V | Safety | ICIT/TRW VAS95 alarm | • | • | • | • | • | 0 |
| 6 | 1. 8 TS 16V | Safety | ICIT/TRW VAS95 alarm | • | • | • | • | • | 0 |
| 6 | 2. 0 TS 16V | Safety | ICIT/TRW VAS95 alarm | • | • | • | • | • | 0 |
| 6 | '98 1.4 TS 16V | Safety | ICIT/TRW VAS95 alarm | • | • | • | • | • | 0 |
| 6 | '98 1.6 TS 16V | Safety | ICIT/TRW VAS95 alarm | • | • | • | • | • | 0 |
| 6 | '98 1.8 TS 16V | Safety | ICIT/TRW VAS95 alarm | • | • | • | • | • | 0 |
| 6 | '98 2.0 TS 16V | Safety | ICIT/TRW VAS95 alarm | • | • | • | • | • | 0 |
| 6 | '99 1.9 JTD | Safety | ICIT/TRW VAS95 alarm | • | • | • | | • | 0 |
| 5 | 1. 6 TS 16V | Safety | ICIT/TRW VAS95 alarm | • | • | • | | • | 0 |
| 55 | 1.8 TS 16V | Safety | ICIT/TRW VAS95 alarm | • | • | • | • | • | 0 |
| 55 | 2.0 TS 16V | Safety | ICIT/TRW VAS95 alarm | • | • | • | • | • | 0 |
| 5 | 2.5 TD | Safety | ICIT/TRW VAS95 alarm | • | • | • | • | • | 0 |
| 5 | TD | Safety | ICIT/TRW VAS95 alarm | • | • | • | • | • | 0 |
| V | '03 2.0 JTS | Safety | ICIT/TRW VAS95 alarm | • | • | • | • | • | 0 |
| `V | '03 2.0 TS 16V | Safety | ICIT/TRW VAS95 alarm | • | • | • | • | • | 0 |
| `V | '03 3.2 V6 24V | Safety | ICIT/TRW VAS95 alarm | • | • | • | • | • | 0 |
| V | 2.0 TS 16V | Safety | ICIT/TRW VAS95 alarm | • | • | • | • | • | 0 |
| V | 2.0 V6 TB | Safety | ICIT/TRW VAS95 alarm | • | • | • | • | • | 0 |
| V | 3.0 V6 24V | Safety | ICIT/TRW VAS95 alarm | • | • | • | • | • | 0 |
| V | '98 1.8 TS 16V | Safety | ICIT/TRW VAS95 alarm | • | • | • | • | • | 0 |
| V | '98 2.0 TS 16V | Safety | ICIT/TRW VAS95 alarm | • | • | • | • | • | 0 |
| V | '98 2.0 V6 TB | Safety | ICIT/TRW VAS95 alarm | • | • | • | • | • | 0 |
| V | '98 3.0 V6 24V | Safety | ICIT/TRW VAS95 alarm | • | • | • | • | • | 0 |
| IDER | '03 2.0 JTS | Safety | ICIT/TRW VAS95 alarm | • | • | • | • | • | 0 |
| IDER | '03 2.0 TS 16V | Safety | ICIT/TRW VAS95 alarm | • | • | • | • | • | 0 |
| IDER | '03 3.2 V6 24V | Safety | ICIT/TRW VAS95 alarm | • | • | • | • | • | 0 |
| IDER | 2.0 TS 16V | Safety | ICIT/TRW VAS95 alarm | • | • | • | • | • | 0 |
| IDER | 3. 0 V6 | Safety | ICIT/TRW VAS95 alarm | • | • | • | • | • | 0 |
| IDER | '98 1.8 TS 16V | Safety | ICIT/TRW VAS95 alarm | • | • | • | • | • | 0 |
| IDER | '98 2.0 TS 16V | Safety | ICIT/TRW VAS95 alarm | • | • | • | • | • | 0 |

| Mode1 | Version | Group | System | ECU info. | Read Codes | Erase Codes | Live Data | Active Test | Specil Function |
|--------|----------------|--------|----------------------|--------------|---------------|----------------|--------------|----------------|-----------------|
| SPIDER | '98 2.0 V6 TB | Safety | ICIT/TRW VAS95 alarm | • | • | • | • | • | 0 |
| SPIDER | '98 3.0 V6 | Safety | ICIT/TRW VAS95 alarm | • | • | • | • | • | 0 |
| 145 | 1. 3 | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 145 | 1.4 TS 16V | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 145 | 1.6 | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 145 | 1.6 TS 16V | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 145 | 1.7 16V | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 145 | 1.8 TS 16V | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 145 | 2.0 TS 16V | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 145 | '98 1.4 TS 16V | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 145 | '98 1.6 TS 16V | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 145 | '98 1.8 TS 16V | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 145 | '98 2.0 TS 16V | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 145 | '99 1.9 JTD | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 145 | TD | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 146 | 1. 3 | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 146 | 1.4 TS 16V | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 146 | 1. 6 | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 146 | 1.6 TS 16V | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 146 | 1.7 16V | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 146 | 1.8 TS 16V | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 146 | 2.0 TS 16V | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 146 | '98 1.4 TS 16V | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 146 | '98 1.6 TS 16V | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 146 | '98 1.8 TS 16V | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 146 | '98 2.0 TS 16V | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 146 | '99 1.9 JTD | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 146 | TD | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 155 | 1.6 TS 16V | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 155 | 1.7 TS | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 155 | 1.8 TS | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 155 | 1.8 TS 16V | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 155 | 2.0 TS | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 155 | 2.0 TS 16V | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 155 | 2.5 TD | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 155 | TD | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 155 | V6 | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 156 | 1.6 TS 16V | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 156 | 1.8 TS 16V | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 156 | 1.9 JTD | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 156 | 2.0 TS 16V | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 156 | 2.4 JTD | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 156 | 2.5 V6 24V | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 156 | SELESPEED | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 164 | 2.0 TS ECO | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 164 | QV 24V | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 164 | SUPER 2.0 TS | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 164 | SUPER TD | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |

| | Version | Group | System | ECU info. | Read Codes | Erase Codes | Live Data | Active Test | Specil Function |
|----------|---------------------|------------------|----------------------------------------------|--------------|---------------|----------------|--------------|----------------|-----------------|
| 164 | SUPER V6 24V | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 164 | SUPER V6 24V C.A.E. | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 164 | SUPER V6 TB | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 164 | V6 ECO | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 164 | V6 ECO C.A. | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 166 | 2.0 TS 16V | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 166 | 2.4 JTD | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 166 | 2.5 V6 24V | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| 166 | 3.0 V6 24V | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| GTV | '03 2.0 TS 16V | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| GTV : | 2.0 TS 16V | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| GTV : | 2.0 V6 TB | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| GTV : | 3.0 V6 24V | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| GTV | '98 1.8 TS 16V | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| GTV | '98 2.0 TS 16V | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| GTV | | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| GTV | | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| SPIDER ' | '03 2.0 TS 16V | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| SPIDER : | 2. 0 TS 16V | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| | 3. 0 V6 | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| SPIDER ' | '98 1.8 TS 16V | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| SPIDER ' | '98 2.0 TS 16V | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| SPIDER ' | '98 2.0 V6 TB | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| SPIDER ' | '98 3.0 V6 | Safety | Bosch 5.3 ABS | • | • | • | • | • | 0 |
| | 1. 3 | Engine - Gearbox | Magneti Marelli IAW 18F Injection | • | 0 | 0 | • | • | 0 |
| | 1. 3 | Engine - Gearbox | Magneti Marelli IAW 18F Injection | • | 0 | 0 | • | • | 0 |
| | 1. 3 | Engine - Gearbox | Magneti Marelli IAW O8F Injection | • | 0 | 0 | • | • | 0 |
| 146 | 1. 3 | Engine - Gearbox | Magneti Marelli IAW 08F Injection | • | 0 | 0 | • | • | 0 |
| 33 | 1. 3 I. E. ECO | Engine - Gearbox | Magneti Marelli IAW 08.68 Injection | • | 0 | 0 | • | • | 0 |
| | 1. 4 I. E. ECO | Engine - Gearbox | Magneti Marelli IAW 08.68 Injection | • | 0 | 0 | • | • | 0 |
| | 2. 0 TS 16V | Engine - Gearbox | Bosch Motronic M2.10.3 Injection (2.0 TS 16v | • | • | • | • | • | 0 |
| | | Engine - Gearbox | Bosch Motronic M2.10.3 Injection (2.0 TS 16v | • | • | • | • | • | 0 |
| | 2.0 TS 16V | Engine - Gearbox | Bosch Motronic M2.10.3 Injection (2.0 TS 16v | • | • | • | • | • | 0 |
| | 2.0 TS 16V | Engine - Gearbox | Bosch Motronic M2.10.3 Injection (2.0 TS 16v | • | • | • | • | • | 0 |
| | 2.0 TS 16V | Engine - Gearbox | Bosch Motronic M2.10.3 Injection (2.0 TS 16v | • | • | • | • | • | 0 |
| | 1. 3 | Comfort | Borletti MCC55F climate control | • | • | • | • | • | 0 |
| | 1.4 TS 16V | Comfort | Borletti MCC55F climate control | • | • | • | • | • | 0 |
| | 1.6 | Comfort | Borletti MCC55F climate control | • | • | • | • | • | 0 |
| | 1.6 TS 16V | Comfort | Borletti MCC55F climate control | • | • | • | • | • | 0 |
| | | Comfort | Borletti MCC55F climate control | • | • | • | • | • | 0 |
| | | Comfort | Borletti MCC55F climate control | • | • | • | • | • | 0 |
| | 2. 0 TS 16V | Comfort | Borletti MCC55F climate control | • | • | • | • | • | 0 |
| 145 | '98 1.4 TS 16V | Comfort | Borletti MCC55F climate control | • | • | • | • | • | 0 |
| 145 | '98 1.6 TS 16V | Comfort | Borletti MCC55F climate control | • | • | • | • | • | 0 |
| 145 | '98 1.8 TS 16V | Comfort | Borletti MCC55F climate control | • | • | • | • | • | 0 |
| 145 | '98 2.0 TS 16V | Comfort | Borletti MCC55F climate control | • | • | • | • | • | 0 |
| 145 | '99 1.9 JTD | Comfort | Borletti MCC55F climate control | • | • | • | • | • | 0 |
| | | Comfort | Borletti MCC55F climate control | • | • | • | • | • | 0 |

| Model | Version | Group | System | ECU | Read | Erase | Live | Active | Specil Function |
|--------|----------------|------------------|------------------------------------------------|-------|-------|-------|------|--------|-----------------|
| | 1 0 | | | info. | Codes | Codes | Data | Test | |
| 146 | 1. 3 | Comfort | Borletti MCC55F climate control | • | • | • | • | • | 0 |
| 146 | 1. 4 TS 16V | Comfort | Borletti MCC55F climate control | • | • | • | • | • | 0 |
| 146 | 1. 6 | Comfort | Borletti MCC55F climate control | • | • | • | • | • | 0 |
| 146 | 1. 6 TS 16V | Comfort | Borletti MCC55F climate control | • | • | • | • | • | 0 |
| 146 | 1. 7 16V | Comfort | Borletti MCC55F climate control | • | • | • | • | • | 0 |
| 146 | 1. 8 TS 16V | Comfort | Borletti MCC55F climate control | • | • | • | • | • | 0 |
| 146 | 2. 0 TS 16V | Comfort | Borletti MCC55F climate control | • | • | • | • | • | 0 |
| 146 | '98 1.4 TS 16V | Comfort | Borletti MCC55F climate control | • | • | • | • | • | 0 |
| 146 | '98 1.6 TS 16V | Comfort | Borletti MCC55F climate control | • | • | • | • | • | 0 |
| 146 | '98 1.8 TS 16V | Comfort | Borletti MCC55F climate control | • | • | • | • | • | 0 |
| 146 | '98 2.0 TS 16V | Comfort | Borletti MCC55F climate control | • | • | • | • | • | 0 |
| 146 | '99 1.9 JTD | Comfort | Borletti MCC55F climate control | • | • | • | • | • | 0 |
| 146 | TD | Comfort | Borletti MCC55F climate control | • | • | • | • | • | 0 |
| 145 | 1.4 TS 16V | Engine - Gearbox | Bosch Motronic M2.10.4 Injection (TS 16v eng.) | • | • | • | • | • | 0 |
| 145 | 1.6 TS 16V | Engine - Gearbox | Bosch Motronic M2.10.4 Injection (TS 16v eng.) | • | • | • | • | • | 0 |
| 145 | 1.8 TS 16V | Engine - Gearbox | Bosch Motronic M2.10.4 Injection (TS 16v eng.) | • | • | • | • | • | 0 |
| 145 | 2.0 TS 16V | Engine - Gearbox | Bosch Motronic M2.10.4 Injection (TS 16v eng.) | • | • | • | • | • | 0 |
| 146 | 1.4 TS 16V | Engine - Gearbox | Bosch Motronic M2.10.4 Injection (TS 16v eng.) | • | • | • | • | • | 0 |
| 146 | 1.6 TS 16V | Engine - Gearbox | Bosch Motronic M2.10.4 Injection (TS 16v eng.) | • | • | • | • | • | 0 |
| 146 | 1.8 TS 16V | Engine - Gearbox | Bosch Motronic M2.10.4 Injection (TS 16v eng.) | • | • | • | • | • | 0 |
| 146 | 2.0 TS 16V | Engine - Gearbox | Bosch Motronic M2.10.4 Injection (TS 16v eng.) | • | • | • | • | • | 0 |
| 155 | 1.6 TS 16V | Engine - Gearbox | Bosch Motronic M2.10.4 Injection (TS 16v eng.) | • | • | • | • | • | 0 |
| 155 | 1.8 TS 16V | Engine - Gearbox | Bosch Motronic M2.10.4 Injection (TS 16v eng.) | • | • | • | • | • | 0 |
| 155 | 2.0 TS 16V | Engine - Gearbox | Bosch Motronic M2.10.4 Injection (TS 16v eng.) | • | • | • | • | • | 0 |
| 156 | 1.6 TS 16V | Engine - Gearbox | Bosch Motronic M2.10.4 Injection (TS 16v eng.) | • | • | • | • | • | 0 |
| GTV | 2. 0 TS 16V | Engine - Gearbox | Bosch Motronic M2.10.4 Injection (TS 16v eng.) | • | • | • | • | • | 0 |
| SPIDER | 2. 0 TS 16V | Engine - Gearbox | Bosch Motronic M2.10.4 Injection (TS 16v eng.) | • | • | • | • | • | 0 |
| 145 | 1. 3 | Safety | ICIT VAS 93 anti-theft device | • | • | • | • | • | 0 |
| 145 | 1. 4 TS 16V | Safety | ICIT VAS 93 anti-theft device | • | • | • | • | • | 0 |
| 145 | 1.6 | Safety | ICIT VAS 93 anti-theft device | • | • | • | • | • | 0 |
| 145 | 1. 6 TS 16V | Safety | ICIT VAS 93 anti-theft device | • | • | • | • | • | 0 |
| 145 | 1. 7 16V | Safety | ICIT VAS 93 anti-theft device | • | • | • | • | • | 0 |
| 145 | 1. 8 TS 16V | Safety | ICIT VAS 93 anti-theft device | | • | • | • | | 0 |
| 145 | 2. 0 TS 16V | Safety | ICIT VAS 93 anti-theft device | • | | • | • | • | 0 |
| 145 | TD | Safety | ICIT VAS 93 anti-theft device | • | | • | • | | 0 |
| 146 | 1. 3 | Safety | ICIT VAS 93 anti-theft device | | | • | | | 0 |
| 146 | 1. 4 TS 16V | Safety | ICIT VAS 93 anti-theft device | | | | | | 0 |
| 146 | 1. 6 | Safety | ICIT VAS 93 anti-theft device | • | • | • | • | • | 0 |
| 146 | 1. 6 TS 16V | Safety | ICIT VAS 93 anti-theft device | - | • | | - | | 0 |
| 146 | 1. 7 16V | Safety | ICIT VAS 93 anti-theft device | • | • | • | • | • | 0 |
| 146 | 1. 8 TS 16V | Safety | ICIT VAS 93 anti-theft device | • | | | • | | 0 |
| 146 | 2. 0 TS 16V | Safety | ICIT VAS 93 anti-theft device | • | | | • | | 0 |
| 146 | TD | | | • | • | | • | • | 0 |
| 155 | 1. 6 TS 16V | Safety | ICIT VAS 93 anti-theft device | | • | • | | | 0 |
| | | Safety | ICIT VAS 93 anti-theft device | • | | • | • | • | |
| 155 | 1. 7 TS | Safety | ICIT VAS 93 anti-theft device | • | • | • | • | | 0 |
| 155 | 1. 8 TS | Safety | ICIT VAS 93 anti-theft device | | • | • | • | • | 0 |
| 155 | 1. 8 TS 16V | Safety | ICIT VAS 93 anti-theft device | • | • | • | • | • | 0 |
| 155 | 2.0 TS | Safety | ICIT VAS 93 anti-theft device | • | • | • | • | | 0 |

| Model | Version | Group | System | ECU info. | Read Codes | Erase Codes | Live Data | Active Test | Specil Function |
|--------|---------------------|------------------|-------------------------------------------------------------|--------------|---------------|----------------|--------------|----------------|-----------------|
| 155 | 2.0 TS 16V | Safety | ICIT VAS 93 anti-theft device | • | • | • | • | • | 0 |
| 155 | 2.5 TD | Safety | ICIT VAS 93 anti-theft device | • | • | • | • | • | 0 |
| 155 | TD | Safety | ICIT VAS 93 anti-theft device | • | • | • | • | • | 0 |
| 155 | V6 | Safety | ICIT VAS 93 anti-theft device | • | • | • | • | • | 0 |
| GTV | 2.0 TS 16V | Safety | ICIT VAS 93 anti-theft device | • | • | • | • | • | 0 |
| GTV | 2. 0 V6 TB | Safety | ICIT VAS 93 anti-theft device | • | • | • | • | • | 0 |
| SPIDER | 2.0 TS 16V | Safety | ICIT VAS 93 anti-theft device | • | • | • | • | • | 0 |
| SPIDER | 3. 0 V6 | Safety | ICIT VAS 93 anti-theft device | • | • | • | • | • | 0 |
| 155 | 1.7 TS | Engine - Gearbox | Bosch Motronic M1.7 Injection (TS eng. El. | • | • | • | • | • | 0 |
| 155 | 1.8 TS | Engine - Gearbox | Bosch Motronic M1.7 Injection (TS eng. El. | • | • | • | • | • | 0 |
| 155 | 2. 0 TS | Engine - Gearbox | Bosch Motronic M1.7 Injection (TS eng. El. | • | • | • | • | • | 0 |
| 164 | 2. 0 TS ECO | Engine - Gearbox | Bosch Motronic M1.7 Injection (TS eng. El. | • | • | • | • | • | 0 |
| 164 | SUPER 2.0 TS | Engine - Gearbox | Bosch Motronic M1.7 Injection (TS eng. El. | • | • | • | • | • | 0 |
| 164 | QV 24V | Engine - Gearbox | Bosch Motronic M1.7 Injection (V6 3.0 eng. El. | • | • | • | • | • | 0 |
| 164 | SUPER V6 24V | Engine - Gearbox | Bosch Motronic M1.7 Injection (V6 3.0 eng. El. | • | • | • | • | • | 0 |
| 164 | SUPER V6 24V C.A.E. | Engine - Gearbox | Bosch Motronic M1.7 Injection (V6 3.0 eng. El. | • | • | • | • | • | 0 |
| 164 | V6 ECO | Engine - Gearbox | Bosch Motronic M1.7 Injection (V6 3.0 eng. E1. | • | | • | • | • | 0 |
| 164 | V6 ECO C. A. | Engine - Gearbox | Bosch Motronic M1.7 Injection (V6 3.0 eng. El. | • | | • | • | | 0 |
| 155 | 1. 7 TS | Engine - Gearbox | Bosch Motronic M1.7 Injection (Vol. 9 eng.) | | | • | • | • | 0 |
| 155 | 1. 8 TS | Engine - Gearbox | Bosch Motronic M1.7 Injection (15 eng.) | | | • | • | | 0 |
| 155 | 2. 0 TS | Engine - Gearbox | Bosch Motronic M1.7 Injection (15 eng.) | | | • | • | | 0 |
| 164 | 2. 0 TS ECO | Engine - Gearbox | Bosch Motronic M1.7 Injection (TS eng.) | | | • | • | | 0 |
| 164 | SUPER 2.0 TS | Engine - Gearbox | Bosch Motronic M1.7 Injection (TS eng.) | | | • | • | | 0 |
| 145 | 1. 7 16V | Engine - Gearbox | Bosch Motronic M2.10.3 Injection (1.7 16v eng. El. key) | • | • | • | • | • | 0 |
| 146 | 1.7 16V | Engine - Gearbox | Bosch Motronic M2.10.3 Injection (1.7 16v eng. El. key) | • | • | • | • | • | 0 |
| GTV | 3.0 V6 24V | Engine - Gearbox | Bosch Motronic M3.7.1 Injection (3.0 12/24v eng. El. key) | • | • | • | • | • | 0 |
| GTV | '98 3.0 V6 24V | Engine - Gearbox | Bosch Motronic M3.7.1 Injection (3.0 12/24v eng. El. key) | • | • | • | • | • | 0 |
| SPIDER | 3.0 V6 | Engine - Gearbox | Bosch Motronic M3.7.1 Injection (3.0 12/24v eng. El. key) | • | • | • | • | • | 0 |
| SPIDER | '98 3.0 V6 | Engine - Gearbox | Bosch Motronic M3.7.1 Injection (3.0 12/24v eng. El. key) | • | • | • | • | • | 0 |
| 164 | Q4 | Engine - Gearbox | Bosch Motronic M3.7.1 injection (3.0 24v 4X4 | • | — | • | <u> </u> | • | 0 |
| 164 | SUPER V6 TB | Engine - Gearbox | Bosch Motronic ML4.1 injection (V6 T.Petr. El. Key eng.) | • | • | • | • | • | 0 |
| GTV | 2. 0 V6 TB | Engine - Gearbox | Bosch Motronic ML4.1 injection (V6 T.Petr. El. Key eng.) | • | • | • | • | • | 0 |
| GTV | '98 2.0 V6 TB | Engine - Gearbox | Bosch Motronic ML4.1 injection (V6 T.Petr. El. Key eng.) | • | • | • | • | • | 0 |
| SPIDER | '98 2.0 V6 TB | Engine - Gearbox | Bosch Motronic ML4.1 injection (V6 T.Petr. El. Key eng.) | • | • | • | • | • | 0 |
| 164 | QV 24V | Engine - Gearbox | Bosch Motronic M1.7 injection (V6 3.0 eng.) | • | • | • | • | • | 0 |
| 164 | SUPER V6 24V | Engine - Gearbox | Bosch Motronic M1.7 injection (V6 3.0 eng.) | • | • | • | • | • | 0 |
| 164 | SUPER V6 24V C.A.E. | | Bosch Motronic M1.7 injection (V6 3.0 eng.) | • | • | • | • | • | 0 |
| 164 | V6 ECO | Engine - Gearbox | Bosch Motronic M1.7 injection (V6 3.0 eng.) | • | • | • | • | • | 0 |

| Model | Version | Group | System | ECU info. | Read Codes | Erase Codes | Live Data | Active Test | Specil Function |
|------------|----------------|--------------------------------------|-----------------------------------------------|--------------|---------------|----------------|--------------|----------------|-----------------|
| 164 | V6 ECO C. A. | Engine - Gearbox | Bosch Motronic M1.7 injection (V6 3.0 eng.) | • | • | • | Data | 1050 | 0 |
| 155 | V6 | Engine - Gearbox | Bosch Motronic M1.7 injection (V6 2.5 El. Key | • | | • | | • | 0 |
| 155 | V6 | Engine - Gearbox | Bosch Motronic M1.7 injection (V6 2.5 eng.) | • | | • | | | 0 |
| 164 | SUPER V6 TB | Engine - Gearbox | Bosch Motronic ML4.1 injection (V6 T/Petr. | | | | | | 0 |
| 164 | V6 TURBO ECO | Engine - Gearbox | Bosch Motronic ML4.1 injection (V6 T/Petr. | | | • | | | 0 |
| 145 | 1. 7 16V | Engine - Gearbox | Bosch Motronic M2. 10. 3 injection (1.7 16v | • | | • | | | 0 |
| 146 | 1. 7 16V | Engine Gearbox Engine - Gearbox | Bosch Motronic M2.10.3 injection (1.7 16v | • | | • | | | 0 |
| 156 | 2. 4 JTD | Engine - Gearbox Engine - Gearbox | Bosch EDC15 Diesel Injection (2.4 TD d.i. | | | • | - | | 0 |
| 166 | 2. 4 JTD | | Bosch EDC15 Diesel Injection (2.4 TD d.i. | • | | • | | | 0 |
| | 1. 6 TS 16V | Engine - Gearbox | | | | | | 0 | 0 |
| 156 | | Safety | Allied MY97 Airbag (2F-2P-I-S) | | | | • | | |
| 156 156 | 1. 8 TS 16V | Safety | Allied MY97 Airbag (2F-2P-I-S) | • | • | • | | 0 | 0 |
| 156 | 1. 9 JTD | Safety | Allied MY97 Airbag (2F-2P-I-S) | | • | • | | 0 | 0 |
| 156 | 2. 0 TS 16V | Safety | Allied MY97 Airbag (2F-2P-I-S) | • | • | • | • | 0 | 0 |
| 156 | 2. 4 JTD | Safety | Allied MY97 Airbag (2F-2P-I-S) | • | • | • | • | 0 | 0 |
| 156 | 2. 5 V6 24V | Safety | Allied MY97 Airbag (2F-2P-I-S) | • | • | • | • | 0 | 0 |
| 156 | SELESPEED | Safety | Allied MY97 Airbag (2F-2P-I-S) | • | • | • | • | 0 | 0 |
| 156 | 1.6 TS 16V | Comfort | Harrison climate control | • | • | • | • | 0 | 0 |
| 156 | 1.8 TS 16V | Comfort | Harrison climate control | • | • | • | • | 0 | 0 |
| 156 | 1.9 JTD | Comfort | Harrison climate control | • | • | • | • | 0 | 0 |
| 156 | 2.0 TS 16V | Comfort | Harrison climate control | • | • | • | • | 0 | 0 |
| 156 | 2.4 JTD | Comfort | Harrison climate control | • | • | • | • | 0 | 0 |
| 156 | 2.5 V6 24V | Comfort | Harrison climate control | • | • | • | • | 0 | 0 |
| 156 | SELESPEED | Comfort | Harrison climate control | • | • | • | • | 0 | 0 |
| GTV | '03 2.0 JTS | Comfort | Harrison climate control | • | • | • | • | 0 | 0 |
| GTV | '03 2.0 TS 16V | Comfort | Harrison climate control | • | • | • | • | 0 | 0 |
| GTV | '03 3.2 V6 24V | Comfort | Harrison climate control | • | • | • | • | 0 | 0 |
| GTV | '98 1.8 TS 16V | Comfort | Harrison climate control | • | • | • | • | 0 | 0 |
| GTV | '98 2.0 TS 16V | Comfort | Harrison climate control | • | • | • | • | 0 | 0 |
| GTV | '98 2.0 V6 TB | Comfort | Harrison climate control | • | • | • | • | 0 | 0 |
| GTV | '98 3.0 V6 24V | Comfort | Harrison climate control | • | • | • | • | 0 | 0 |
| SPIDER | '03 2.0 JTS | Comfort | Harrison climate control | • | • | • | • | 0 | 0 |
| SPIDER | '03 2.0 TS 16V | Comfort | Harrison climate control | • | • | • | • | 0 | 0 |
| SPIDER | '03 3.2 V6 24V | Comfort | Harrison climate control | • | • | • | • | 0 | 0 |
| SPIDER | '98 1.8 TS 16V | Comfort | Harrison climate control | • | • | • | • | 0 | 0 |
| SPIDER | '98 2.0 TS 16V | Comfort | Harrison climate control | • | • | • | • | 0 | 0 |
| SPIDER | '98 2.0 V6 TB | Comfort | Harrison climate control | • | • | • | • | 0 | 0 |
| SPIDER | '98 3.0 V6 | Comfort | Harrison climate control | • | • | • | • | 0 | 0 |
| 164 | QV | Engine - Gearbox | Bosch Motronic ML4.1 Injection (3.0 V6 eng.) | • | • | • | • | • | 0 |
| 164 | V6 | Engine - Gearbox | Bosch Motronic ML4.1 Injection (3.0 V6 eng.) | • | • | • | • | • | 0 |
| 164 | V6 ECO | Engine - Gearbox | Bosch Motronic ML4.1 Injection (3.0 V6 eng.) | • | • | • | • | • | 0 |
| 164 | V6 ECO C. A. | Engine - Gearbox | Bosch Motronic ML4.1 Injection (3.0 V6 eng.) | • | • | • | • | | 0 |
| 156 | 1. 8 TS 16V | Engine - Gearbox | Bosch Motronic Ml. 5. 5 injection | • | • | • | • | • | 0 |
| 156 | 2. 0 TS 16V | Engine - Gearbox Engine - Gearbox | Bosch Motronic M1.5.5 injection | | • | • | - | | 0 |
| 156 | 2. 5 V6 24V | Engine - Gearbox Engine - Gearbox | Bosch Motronic ME2.1 injection (2.5 V6 eng.) | • | • | • | • | | 0 |
| 145 | '99 1.9 JTD | | Bosch Diesel EDC15 injection (2.5 vo eng.) | | • | • | | | 0 |
| 146 | '99 1.9 JTD | Engine - Gearbox Engine - Gearbox | Bosch Diesel EDC15 injection (1.9 TD d.i. | | | • | • | | 0 |
| | | 1 | | | | • | • | | 0 |
| 156 145 | 1.9 JTD | Engine - Gearbox | Bosch Diesel EDC15 injection (1.9 TD d.i. | | • | _ | • | | |
| 145 | 1. 3 | Safety | TRW MY 97 Airbag (2F) | | | • | | 0 | 0 |

| Model | Version | Group | System | ECU info. | Read Codes | Erase Codes | Live Data | Active Test | Specil Function |
|--------|-----------------------|------------------|-----------------------------------------------|--------------|---------------|----------------|--------------|----------------|-----------------|
| 145 | 1. 4 TS 16V | Safety | TRW MY 97 Airbag (2F) | • | • | • | • | 0 | 0 |
| 145 | 1. 6 | Safety | TRW MY 97 Airbag (2F) | • | • | • | • | 0 | 0 |
| 145 | 1. 6 TS 16V | Safety | TRW MY 97 Airbag (2F) | • | • | • | • | 0 | 0 |
| 145 | 1. 7 16V | Safety | TRW MY 97 Airbag (2F) | • | • | • | • | 0 | 0 |
| 145 | 1. 8 TS 16V | Safety | TRW MY 97 Airbag (2F) | • | • | • | • | 0 | 0 |
| 145 | 2. 0 TS 16V | Safety | TRW MY 97 Airbag (2F) | • | • | • | • | 0 | 0 |
| 145 | '98 1.4 TS 16V | Safety | TRW MY 97 Airbag (2F) | • | | • | • | 0 | 0 |
| 145 | '98 1.6 TS 16V | Safety | TRW MY 97 Airbag (2F) | • | | • | • | 0 | 0 |
| 145 | '98 1.8 TS 16V | Safety | TRW MY 97 Airbag (2F) | • | | • | • | 0 | 0 |
| 145 | '98 2.0 TS 16V | Safety | TRW MY 97 Airbag (2F) | | | • | • | 0 | 0 |
| 145 | '99 1.9 JTD | Safety | TRW MY 97 Airbag (2F) | | | • | • | 0 | 0 |
| 145 | TD | Safety | TRW MY 97 Airbag (2F) | | | | | 0 | 0 |
| 146 | 1. 3 | Safety | TRW MY 97 Airbag (2F) | | | | - | 0 | 0 |
| 146 | 1. 4 TS 16V | Safety | TRW MY 97 Airbag (2F) | - | | | | 0 | 0 |
| 146 | 1. 4 13 10 | Safety | TRW MY 97 Airbag (2F) | | | | - | 0 | 0 |
| 146 | 1. 6 TS 16V | Safety | TRW MY 97 Airbag (2F) | | | | - | 0 | 0 |
| 146 | 1. 7 16V | | | | | | - | | 0 |
| 146 | | Safety | TRW MY 97 Airbag (2F) | | | • | • | 0 | 0 |
| | 1. 8 TS 16V | Safety | TRW MY 97 Airbag (2F) | | - | | | 0 | |
| 146 | 2. 0 TS 16V | Safety | TRW MY 97 Airbag (2F) | | - | • | • | 0 | 0 |
| 146 | '98 1.4 TS 16V | Safety | TRW MY 97 Airbag (2F) | | • | • | • | 0 | 0 |
| 146 | '98 1.6 TS 16V | Safety | TRW MY 97 Airbag (2F) | • | • | • | • | 0 | 0 |
| 146 | '98 1.8 TS 16V | Safety | TRW MY 97 Airbag (2F) | | • | • | • | 0 | 0 |
| 146 | '98 2.0 TS 16V | Safety | TRW MY 97 Airbag (2F) | | • | • | • | 0 | 0 |
| 146 | '99 1.9 JTD | Safety | TRW MY 97 Airbag (2F) | | • | • | • | 0 | 0 |
| 146 | TD | Safety | TRW MY 97 Airbag (2F) | | • | • | • | 0 | 0 |
| 164 | SUPER V6 24V C. A. E. | Engine - Gearbox | ZF 4HP18 K Automatic Transmission | • | • | • | • | • | 0 |
| 166 | 2. 0 TS 16V | Safety | TRW MY 97 Air Bag (2F-2P-2L-I-S) | • | • | • | • | 0 | 0 |
| 166 | 2. 0 V6 TB | Safety | TRW MY 97 Air Bag (2F-2P-2L-I-S) | • | • | • | • | 0 | 0 |
| 166 | 2.4 JTD | Safety | TRW MY 97 Air Bag (2F-2P-2L-I-S) | <u> </u> | • | • | • | 0 | 0 |
| 166 | 2. 5 V6 24V | Safety | TRW MY 97 Air Bag (2F-2P-2L-I-S) | • | • | • | • | 0 | 0 |
| 166 | 3.0 V6 24V | Safety | TRW MY 97 Air Bag (2F-2P-2L-I-S) | • | • | • | • | 0 | 0 |
| 145 | '98 1.4 TS 16V | Engine - Gearbox | Bosch Motronic M1.5.5 injection (eng. TS '98) | • | • | • | • | • | 0 |
| 145 | '98 1.6 TS 16V | Engine - Gearbox | Bosch Motronic M1.5.5 injection (eng. TS'98) | • | • | • | • | • | 0 |
| 145 | '98 1.8 TS 16V | Engine - Gearbox | Bosch Motronic M1.5.5 injection (eng. TS '98) | • | • | • | • | • | 0 |
| 145 | '98 2.0 TS 16V | Engine - Gearbox | Bosch Motronic M1.5.5 injection (eng. TS '98) | • | • | • | • | • | 0 |
| 146 | '98 1.4 TS 16V | Engine - Gearbox | Bosch Motronic M1.5.5 injection (eng. TS'98) | • | • | • | • | • | 0 |
| 146 | '98 1.6 TS 16V | Engine - Gearbox | Bosch Motronic M1.5.5 injection (eng. TS '98) | • | • | • | • | • | 0 |
| 146 | '98 1.8 TS 16V | Engine - Gearbox | Bosch Motronic M1.5.5 injection (eng. TS '98) | • | • | • | • | | 0 |
| 146 | '98 2.0 TS 16V | Engine - Gearbox | Bosch Motronic M1.5.5 injection (eng. TS '98) | • | • | • | • | • | 0 |
| 156 | 1.6 TS 16V | Engine - Gearbox | Bosch Motronic M1.5.5 injection (eng. TS '98) | • | • | • | • | • | 0 |
| 156 | 1.8 TS 16V | Engine - Gearbox | Bosch Motronic M1.5.5 injection (eng. TS '98) | • | • | • | • | • | 0 |
| 156 | 2. 0 TS 16V | Engine - Gearbox | Bosch Motronic M1.5.5 injection (eng. TS '98) | • | • | • | • | • | 0 |
| 166 | 2.0 TS 16V | Engine - Gearbox | Bosch Motronic M1.5.5 injection (eng. TS '98) | • | • | • | • | • | 0 |
| GTV | '98 1.8 TS 16V | Engine - Gearbox | Bosch Motronic M1.5.5 injection (eng. TS '98) | • | • | • | • | • | 0 |
| GTV | '98 2.0 TS 16V | Engine - Gearbox | Bosch Motronic M1.5.5 injection (eng. TS '98) | • | • | • | • | • | 0 |
| SPIDER | '98 1.8 TS 16V | Engine - Gearbox | Bosch Motronic M1.5.5 injection (eng. TS '98) | • | • | • | • | • | 0 |
| SPIDER | '98 2.0 TS 16V | Engine - Gearbox | Bosch Motronic M1.5.5 injection (eng. TS '98) | • | • | • | • | • | 0 |
| GTV | '03 2.0 JTS | Safety | TRW MY 97 Air Bag (2F-2P) | • | • | • | • | 0 | 0 |

| Model | Version | Group | System | ECU info. | Read Codes | Erase Codes | Live Data | Active Test | Specil Function |
|--------|-----------------|--------|-----------------------------------------------------|--------------------------------------------------|--------------------------------------------------|----------------|---------------|----------------|-----------------|
| GTV | '03 2.0 TS 16V | Safety | TRW MY 97 Air Bag (2F-2P) | • | Codes | Codes | • Data | 0 | 0 |
| GTV | '03 3. 2 V6 24V | Safety | TRW MY 97 Air Bag (2F-2P) | | | • | • | 0 | 0 |
| GTV | 2. 0 TS 16V | Safety | TRW MY 97 Air Bag (2F-2P) | | | • | • | 0 | 0 |
| GTV | 2. 0 V6 TB | Safety | TRW MY 97 Air Bag (2F-2P) | | | | | 0 | 0 |
| GTV | 3. 0 V6 24V | Safety | TRW MY 97 Air Bag (2F-2P) | | | | | 0 | 0 |
| GTV | '98 1.8 TS 16V | Safety | TRW MY 97 Air Bag (2F-2P) | | | • | | 0 | 0 |
| GTV | '98 2.0 TS 16V | Safety | TRW MY 97 Air Bag (2F-2P) | | | • | | 0 | 0 |
| GTV | '98 2.0 V6 TB | Safety | TRW MY 97 Air Bag (2F-2P) | | | • | | 0 | 0 |
| GTV | '98 3.0 V6 24V | Safety | TRW MY 97 Air Bag (2F-2F) | | | • | | 0 | 0 |
| SPIDER | '03 2.0 JTS | Safety | TRW MY 97 Air Bag (2F-2P) | | | • | • | 0 | 0 |
| SPIDER | '03 2.0 TS 16V | Safety | TRW MY 97 Air Bag (2F-2F) | | | • | • | 0 | 0 |
| SPIDER | '03 3. 2 V6 24V | Safety | TRW MY 97 Air Bag (2F-2F) | | | | | 0 | 0 |
| SPIDER | 2. 0 TS 16V | Safety | TRW MY 97 Air Bag (2F-2F) | | | • | | 0 | 0 |
| SPIDER | 3. 0 V6 | Safety | TRW MY 97 Air Bag (2F-2F) | | | • | | 0 | 0 |
| SPIDER | '98 1.8 TS 16V | Safety | TRW MY 97 Air Bag (2F-2F) | | | • | | 0 | 0 |
| SPIDER | '98 2.0 TS 16V | Safety | TRW MY 97 Air Bag (2F-2F) | | | | $\overline{}$ | 0 | 0 |
| SPIDER | '98 2.0 V6 TB | Safety | TRW MY 97 Air Bag (2F-2F) TRW MY 97 Air Bag (2F-2P) | | | | - | 0 | 0 |
| | | | TRW MY 97 Air Bag (2F-2F) | | — | | - | | 0 |
| SPIDER | '98 3.0 V6 | Safety | | • | | _ | | 0 | 0 |
| 145 | '98 1.4 TS 16V | Safety | TRW MY 97 Air Bag (2F-S) | + - | | • | • | 0 | |
| 145 | '98 1.6 TS 16V | Safety | TRW MY 97 Air Bag (2F-S) | - | | • | • | 0 | 0 |
| 145 | '98 1.8 TS 16V | Safety | TRW MY 97 Air Bag (2F-S) | • | • | • | • | 0 | 0 |
| 145 | '98 2.0 TS 16V | Safety | TRW MY 97 Air Bag (2F-S) | • | • | • | • | 0 | 0 |
| 145 | '99 1.9 JTD | Safety | TRW MY 97 Air Bag (2F-S) | • | • | • | • | 0 | 0 |
| 146 | '98 1.4 TS 16V | Safety | TRW MY 97 Air Bag (2F-S) | • | • | • | • | 0 | 0 |
| 146 | '98 1.6 TS 16V | Safety | TRW MY 97 Air Bag (2F-S) | • | • | • | • | 0 | 0 |
| 146 | '98 1.8 TS 16V | Safety | TRW MY 97 Air Bag (2F-S) | • | • | • | • | 0 | 0 |
| 146 | '98 2.0 TS 16V | Safety | TRW MY 97 Air Bag (2F-S) | • | • | • | | 0 | 0 |
| 146 | '99 1.9 JTD | Safety | TRW MY 97 Air Bag (2F-S) | • | • | • | | 0 | 0 |
| 166 | 2. 0 TS 16V | Safety | TRW MY 97 Air Bag (2F-2P-I) | • | • | • | • | 0 | 0 |
| 166 | 2. 0 V6 TB | Safety | TRW MY 97 Air Bag (2F-2P-I) | • | • | • | • | 0 | 0 |
| 166 | 2. 4 JTD | Safety | TRW MY 97 Air Bag (2F-2P-I) | • | • | • | • | 0 | 0 |
| 166 | 2.5 V6 24V | Safety | TRW MY 97 Air Bag (2F-2P-I) | • | • | • | • | 0 | 0 |
| 166 | 3. 0 V6 24V | Safety | TRW MY 97 Air Bag (2F-2P-I) | • | • | • | • | 0 | 0 |
| GTV | '03 2.0 JTS | Safety | TRW MY 97 Air Bag (2F-2P-I) | • | • | • | • | 0 | 0 |
| GTV | '03 2.0 TS 16V | Safety | TRW MY 97 Air Bag (2F-2P-I) | • | • | • | • | 0 | 0 |
| GTV | '03 3.2 V6 24V | Safety | TRW MY 97 Air Bag (2F-2P-I) | • | • | • | • | 0 | 0 |
| GTV | '98 1.8 TS 16V | Safety | TRW MY 97 Air Bag (2F-2P-I) | • | • | • | • | 0 | 0 |
| GTV | '98 2.0 TS 16V | Safety | TRW MY 97 Air Bag (2F-2P-I) | • | • | • | • | | 0 |
| GTV | '98 2.0 V6 TB | Safety | TRW MY 97 Air Bag (2F-2P-I) | • | • | • | • | 0 | 0 |
| GTV | '98 3.0 V6 24V | Safety | TRW MY 97 Air Bag (2F-2P-I) | • | • | • | • | 0 | 0 |
| SPIDER | '03 2.0 JTS | Safety | TRW MY 97 Air Bag (2F-2P-I) | • | • | • | • | 0 | 0 |
| SPIDER | '03 2.0 TS 16V | Safety | TRW MY 97 Air Bag (2F-2P-I) | • | • | • | • | 0 | 0 |
| SPIDER | '03 3.2 V6 24V | Safety | TRW MY 97 Air Bag (2F-2P-I) | • | • | • | • | 0 | 0 |
| SPIDER | '98 1.8 TS 16V | Safety | TRW MY 97 Air Bag (2F-2P-I) | • | • | • | • | 0 | 0 |
| SPIDER | '98 2.0 TS 16V | Safety | TRW MY 97 Air Bag (2F-2P-I) | • | • | • | • | 0 | 0 |
| SPIDER | '98 2.0 V6 TB | Safety | TRW MY 97 Air Bag (2F-2P-I) | • | • | • | • | 0 | 0 |
| SPIDER | '98 3.0 V6 | Safety | TRW MY 97 Air Bag (2F-2P-I) | • | • | • | • | 0 | 0 |
| 145 | '98 1.4 TS 16V | Safety | TRW MY 97 Air Bag (2F-2L-S) | • | • | • | • | 0 | 0 |

| W - 4 - 1 | V : | C | Ct | ECU | Read | Erase | Live | Active | Constitution |
|-----------|-----------------|------------------|-----------------------------------------------|-------|-------|-------|------|--------|-----------------|
| Mode1 | Version | Group | System | info. | Codes | Codes | Data | Test | Specil Function |
| 145 | '98 1.6 TS 16V | Safety | TRW MY 97 Air Bag (2F-2L-S) | • | • | • | • | 0 | 0 |
| 145 | '98 1.8 TS 16V | Safety | TRW MY 97 Air Bag (2F-2L-S) | • | • | • | • | 0 | 0 |
| 145 | '98 2.0 TS 16V | Safety | TRW MY 97 Air Bag (2F-2L-S) | • | • | • | • | 0 | 0 |
| 145 | '99 1.9 JTD | Safety | TRW MY 97 Air Bag (2F-2L-S) | • | • | • | • | 0 | 0 |
| 146 | '98 1.4 TS 16V | Safety | TRW MY 97 Air Bag (2F-2L-S) | • | • | • | • | 0 | 0 |
| 146 | '98 1.6 TS 16V | Safety | TRW MY 97 Air Bag (2F-2L-S) | • | • | • | • | 0 | 0 |
| 146 | '98 1.8 TS 16V | Safety | TRW MY 97 Air Bag (2F-2L-S) | • | • | • | • | 0 | 0 |
| 146 | '98 2.0 TS 16V | Safety | TRW MY 97 Air Bag (2F-2L-S) | • | • | • | • | 0 | 0 |
| 146 | '99 1.9 JTD | Safety | TRW MY 97 Air Bag (2F-2L-S) | • | • | • | • | 0 | 0 |
| 166 | 2.0 TS 16V | Safety | TRW MY 97 Air Bag (2F-2P-I-S) | • | • | • | • | 0 | 0 |
| 166 | 2. 0 V6 TB | Safety | TRW MY 97 Air Bag (2F-2P-I-S) | • | • | • | • | 0 | 0 |
| 166 | 2.4 JTD | Safety | TRW MY 97 Air Bag (2F-2P-I-S) | • | • | • | • | 0 | 0 |
| 166 | 2.5 V6 24V | Safety | TRW MY 97 Air Bag (2F-2P-I-S) | • | • | • | • | 0 | 0 |
| 166 | 3.0 V6 24V | Safety | TRW MY 97 Air Bag (2F-2P-I-S) | • | • | • | • | 0 | 0 |
| 156 | 1.6 TS 16V | Safety | Allied MY 97 Airbag (2F-2P) | • | • | • | • | 0 | 0 |
| 156 | 1.8 TS 16V | Safety | Allied MY 97 Airbag (2F-2P) | • | • | • | • | 0 | 0 |
| 156 | 1.9 JTD | Safety | Allied MY 97 Airbag (2F-2P) | • | • | • | • | 0 | 0 |
| 156 | 2.0 TS 16V | Safety | Allied MY 97 Airbag (2F-2P) | • | • | • | • | 0 | 0 |
| 156 | 2.4 JTD | Safety | Allied MY 97 Airbag (2F-2P) | • | • | • | • | 0 | 0 |
| 156 | 2.5 V6 24V | Safety | Allied MY 97 Airbag (2F-2P) | • | • | • | • | 0 | 0 |
| 156 | SELESPEED | Safety | Allied MY 97 Airbag (2F-2P) | • | • | • | • | 0 | 0 |
| 156 | 1.6 TS 16V | Safety | Allied MY 97 Air Bag (2F-2P-2L-I-S) | • | • | • | • | 0 | 0 |
| 156 | 1.8 TS 16V | Safety | Allied MY 97 Air Bag (2F-2P-2L-I-S) | • | • | • | • | 0 | 0 |
| 156 | 1.9 JTD | Safety | Allied MY 97 Air Bag (2F-2P-2L-I-S) | • | • | • | • | 0 | 0 |
| 156 | 2.0 TS 16V | Safety | Allied MY 97 Air Bag (2F-2P-2L-I-S) | • | • | • | • | 0 | 0 |
| 156 | 2.4 JTD | Safety | Allied MY 97 Air Bag (2F-2P-2L-I-S) | • | • | • | • | 0 | 0 |
| 156 | 2.5 V6 24V | Safety | Allied MY 97 Air Bag (2F-2P-2L-I-S) | • | • | • | • | 0 | 0 |
| 156 | SELESPEED | Safety | Allied MY 97 Air Bag (2F-2P-2L-I-S) | • | • | • | • | 0 | 0 |
| 166 | 2.5 V6 24V | Engine - Gearbox | Bosch Motronic ME2.1 injection (eng. V6 2.5 / | • | • | • | • | • | 0 |
| 166 | 3.0 V6 24V | Engine - Gearbox | Bosch Motronic ME2.1 injection (eng. V6 2.5 / | • | • | • | • | • | 0 |
| GTV | '98 3.0 V6 24V | Engine - Gearbox | Bosch Motronic ME2.1 injection (eng. V6 2.5 / | • | • | • | • | • | 0 |
| SPIDER | '98 3.0 V6 | Engine - Gearbox | Bosch Motronic ME2.1 injection (eng. V6 2.5 / | • | • | • | • | • | 0 |
| 166 | 2.0 TS 16V | Safety | Bosch 5.3 TC ABS | • | • | • | • | • | 0 |
| 166 | 2.0 V6 TB | Safety | Bosch 5.3 TC ABS | • | • | • | • | • | 0 |
| 166 | 2.4 JTD | Safety | Bosch 5.3 TC ABS | • | • | • | • | • | 0 |
| 156 MY | GTA 3.2 V6 | Safety | Bosch 5.3 ASR ABS | • | • | • | • | • | 0 |
| 166 | 2.5 V6 24V | Safety | Bosch 5.3 ASR ABS | • | • | • | • | • | 0 |
| 166 | 3. 0 V6 24V | Safety | Bosch 5.3 ASR ABS | • | • | • | • | • | 0 |
| GTV | '03 2.0 JTS | Safety | Bosch 5.3 ASR ABS | • | • | • | • | • | 0 |
| GTV | '03 3.2 V6 24V | Safety | Bosch 5.3 ASR ABS | • | • | • | • | • | 0 |
| SPIDER | '03 2.0 JTS | Safety | Bosch 5.3 ASR ABS | • | • | • | • | • | 0 |
| SPIDER | '03 3.2 V6 24V | Safety | Bosch 5.3 ASR ABS | • | • | • | • | • | 0 |
| 166 | 2. 0 V6 TB | Engine - Gearbox | Bosch Motronic ME2.1 injection (eng. V6 2.0 | • | • | • | • | • | 0 |
| 166 | '03 2.0 TS 16V | Instrumentation | Navigator/Siemens ICS instrument | • | • | • | • | 0 | 0 |
| 166 | '03 2.4 JTD 20V | Instrumentation | Navigator/Siemens ICS instrument | • | • | • | • | 0 | 0 |
| 166 | '03 2.5 V6 24V | Instrumentation | Navigator/Siemens ICS instrument | • | • | • | • | 0 | 0 |
| 166 | '03 3.0 V6 24V | Instrumentation | Navigator/Siemens ICS instrument | • | • | • | • | 0 | 0 |
| 166 | '03 3.2 V6 24V | Instrumentation | Navigator/Siemens ICS instrument | • | • | • | • | 0 | 0 |

| Model | Version | Group | System | ECU info. | Read Codes | Erase Codes | Live Data | Active Test | Specil Function |
|--------|------------------|------------------|--------------------------------------------|--------------|---------------|----------------|--------------|----------------|-----------------|
| 166 | 2. 0 TS 16V | Instrumentation | Navigator/Siemens ICS instrument | • | • | • | • | 0 | 0 |
| 166 | 2. 0 V6 TB | Instrumentation | Navigator/Siemens ICS instrument | • | • | • | • | 0 | 0 |
| 166 | 2. 4 JTD | Instrumentation | Navigator/Siemens ICS instrument | • | • | • | • | 0 | 0 |
| 166 | 2. 5 V6 24V | Instrumentation | Navigator/Siemens ICS instrument | • | • | • | • | 0 | 0 |
| 166 | 3. 0 V6 24V | Instrumentation | Navigator/Siemens ICS instrument | • | • | • | • | 0 | 0 |
| 166 | '03 2.5 V6 24V | Engine - Gearbox | ZF 4HP20 Automatic Transmission | • | • | • | • | • | 0 |
| 166 | '03 3.0 V6 24V | Engine - Gearbox | ZF 4HP20 Automatic Transmission | • | • | • | • | • | 0 |
| 166 | 2.5 V6 24V | Engine - Gearbox | ZF 4HP20 Automatic Transmission | • | • | • | • | • | 0 |
| 166 | 3.0 V6 24V | Engine - Gearbox | ZF 4HP20 Automatic Transmission | • | • | • | • | • | 0 |
| 156 | 2.5 V6 24V | Engine - Gearbox | AISIN Q-SYSTEM Automatic Gearbox | • | • | • | • | • | 0 |
| 156 MY | 2.5 V6 24V | Engine - Gearbox | AISIN Q-SYSTEM Automatic Gearbox | • | • | • | • | • | 0 |
| 156 | SELESPEED | Engine - Gearbox | Marelli SELESPEED Automatic Gearbox | • | • | • | • | • | 0 |
| 156 | SELESPEED | Engine - Gearbox | Bosch Motronic ME3.1 injection (Selespeed) | • | • | • | • | • | 0 |
| 145 | '98 1.4 TS 16V | Safety | Trw MY 97 airbag (2F-2L) | • | • | • | • | 0 | 0 |
| 145 | '98 1.6 TS 16V | Safety | Trw MY 97 airbag (2F-2L) | • | • | • | • | 0 | 0 |
| 145 | '98 1.8 TS 16V | Safety | Trw MY 97 airbag (2F-2L) | • | • | • | • | 0 | 0 |
| 145 | '98 2.0 TS 16V | Safety | Trw MY 97 airbag (2F-2L) | • | • | • | • | 0 | 0 |
| 145 | '99 1.9 JTD | Safety | Trw MY 97 airbag (2F-2L) | • | • | • | • | 0 | 0 |
| 146 | '98 1.4 TS 16V | Safety | Trw MY 97 airbag (2F-2L) | • | • | • | • | 0 | 0 |
| 146 | '98 1.6 TS 16V | Safety | Trw MY 97 airbag (2F-2L) | • | • | • | • | 0 | 0 |
| 146 | '98 1.8 TS 16V | Safety | Trw MY 97 airbag (2F-2L) | • | • | • | • | 0 | 0 |
| 146 | '98 2.0 TS 16V | Safety | Trw MY 97 airbag (2F-2L) | • | • | • | • | 0 | 0 |
| 146 | '99 1.9 JTD | Safety | Trw MY 97 airbag (2F-2L) | • | • | • | • | 0 | 0 |
| 166 | 2.0 TS 16V | Safety | TRW MY 97 airbag (2F-2P-2L-I) | • | • | • | • | 0 | 0 |
| 166 | 2. 0 V6 TB | Safety | TRW MY 97 airbag (2F-2P-2L-I) | • | • | • | • | 0 | 0 |
| 166 | 2.4 JTD | Safety | TRW MY 97 airbag (2F-2P-2L-I) | • | • | • | • | 0 | 0 |
| 166 | 2.5 V6 24V | Safety | TRW MY 97 airbag (2F-2P-2L-I) | • | • | • | • | 0 | 0 |
| 166 | 3.0 V6 24V | Safety | TRW MY 97 airbag (2F-2P-2L-I) | • | • | • | • | 0 | 0 |
| 166 | 3.0 V6 24V | Safety | Bosch 5.7 VDC ABS | • | • | • | • | • | 0 |
| 156 | 1.6 TS 16V | Safety | Allied MY 97 Airbag (2F-2P-I) | • | • | • | • | 0 | 0 |
| 156 | 1.8 TS 16V | Safety | Allied MY 97 Airbag (2F-2P-I) | • | • | • | • | 0 | 0 |
| 156 | 1.9 JTD | Safety | Allied MY 97 Airbag (2F-2P-I) | • | • | • | • | 0 | 0 |
| 156 | 2.0 TS 16V | Safety | Allied MY 97 Airbag (2F-2P-I) | • | • | • | • | 0 | 0 |
| 156 | 2.4 JTD | Safety | Allied MY 97 Airbag (2F-2P-I) | • | • | • | • | 0 | 0 |
| 156 | 2.5 V6 24V | Safety | Allied MY 97 Airbag (2F-2P-I) | • | • | • | • | 0 | 0 |
| 156 | SELESPEED | Safety | Allied MY 97 Airbag (2F-2P-I) | • | • | • | • | 0 | 0 |
| 156 | 1.6 TS 16V | Safety | Allied MY 97 Airbag (2F-2P-2L-I) | • | • | • | • | 0 | 0 |
| 156 | 1.8 TS 16V | Safety | Allied MY 97 Airbag (2F-2P-2L-I) | • | • | • | • | 0 | 0 |
| 156 | 1.9 JTD | Safety | Allied MY 97 Airbag (2F-2P-2L-I) | • | • | • | • | 0 | 0 |
| 156 | 2.0 TS 16V | Safety | Allied MY 97 Airbag (2F-2P-2L-I) | • | • | • | • | 0 | 0 |
| 156 | 2.4 JTD | Safety | Allied MY 97 Airbag (2F-2P-2L-I) | • | • | • | • | 0 | 0 |
| 156 | 2.5 V6 24V | Safety | Allied MY 97 Airbag (2F-2P-2L-I) | • | • | • | • | 0 | 0 |
| 156 | SELESPEED | Safety | Allied MY 97 Airbag (2F-2P-2L-I) | • | • | • | • | 0 | 0 |
| 147 | 1.6 TS 16V 105CV | Safety | Allied Airbag MY 97 (2F-2P-2L-2T-I) | • | • | • | • | 0 | 0 |
| 147 | 1.6 TS 16V 120CV | Safety | Allied Airbag MY 97 (2F-2P-2L-2T-I) | • | • | • | • | 0 | 0 |
| 147 | 1.9 JTD | Safety | Allied Airbag MY 97 (2F-2P-2L-2T-I) | • | • | • | • | 0 | 0 |
| 147 | 1.9 JTD 16V | Safety | Allied Airbag MY 97 (2F-2P-2L-2T-I) | • | • | • | • | | 0 |
| 147 | 2.0 TS 16V | Safety | Allied Airbag MY 97 (2F-2P-2L-2T-I) | • | • | • | • | 0 | 0 |

| | | Group | System | ECU info. | Read Codes | Erase Codes | Live Data | Active Test | Specil Function |
|--------|----------------------------|------------------|-------------------------------------------------------------------------|-----------|--------------------------------------------------|----------------|--------------|----------------|-----------------|
| | GTA 3.2 V6 | Safety | Allied Airbag MY 97 (2F-2P-2L-2T-I) | 11110. | Codes | • Codes | | O | 0 |
| 147 | GTA SELESPEED | Safety | Allied Airbag MY 97 (2F-2P-2L-2T-I) | | | • | • | 0 | 0 |
| | SELESPEED | Safety | Allied Airbag MY 97 (2F-2P-2L-2T-I) | | | | • | 0 | 0 |
| | 1. 6 TS 16V | Safety | Allied Airbag MY 97 (2F-2P-2L-2T-I) | | | | | 0 | 0 |
| | 1. 8 TS 16V | Safety | Allied Airbag MY 97 (2F-2P-2L-2T-I) | | | | | 0 | 0 |
| | 1. 9 JTD | Safety | Allied Airbag MY 97 (2F-2P-2L-2T-I) | | | | | 0 | 0 |
| | 2. 0 TS 16V | Safety | Allied Airbag MY 97 (2F-2F-2L-2T-I) Allied Airbag MY 97 (2F-2P-2L-2T-I) | | | | - | 0 | 0 |
| | 2. 4 JTD | Safety | Allied Airbag MY 97 (2F-2F-2L-2T-I) | | | | - | 0 | 0 |
| | · · | Safety | | | | | - | 0 | 0 |
| | 2. 5 V6 24V SELESPEED | Safety | Allied Airbag MY 97 (2F-2P-2L-2T-I) Allied Airbag MY 97 (2F-2P-2L-2T-I) | | | | - | 0 | 0 |
| | | | | | | | • | | 0 |
| | SELESPEED TTC CELECPEED | Engine - Gearbox | Marelli CFC208F SELESPEED Automatic Gearbox | | | • | • | | 0 |
| | JTS SELESPEED | Engine - Gearbox | Marelli CFC208F SELESPEED Automatic Gearbox | | | | • | | |
| | SELESPEED | Engine - Gearbox | Marelli CFC208F SELESPEED Automatic Gearbox | <u> </u> | | • | | • | 0 |
| | GTA SELESPEED | Engine - Gearbox | Marelli SELESPEED CFC218F Automatic Gearbox | • | • | • | • | • | 0 |
| | 1. 6 TS 16V 105CV | Safety | SIEMENS MY 99 Airbag (2F-2P-2L-2T-I) | • | • | • | • | • | 0 |
| | 1.6 TS 16V 120CV | Safety | SIEMENS MY 99 Airbag (2F-2P-2L-2T-I) | • | • | • | • | • | 0 |
| | 1.9 JTD | Safety | SIEMENS MY 99 Airbag (2F-2P-2L-2T-I) | • | • | • | • | • | 0 |
| | 1.9 JTD 16V | Safety | SIEMENS MY 99 Airbag (2F-2P-2L-2T-I) | • | • | • | • | • | 0 |
| | 2.0 TS 16V | Safety | SIEMENS MY 99 Airbag (2F-2P-2L-2T-I) | • | • | • | • | • | 0 |
| | GTA 3.2 V6 | Safety | SIEMENS MY 99 Airbag (2F-2P-2L-2T-I) | • | • | • | • | • | 0 |
| | GTA SELESPEED | Safety | SIEMENS MY 99 Airbag (2F-2P-2L-2T-I) | • | • | • | • | • | 0 |
| | SELESPEED | Safety | SIEMENS MY 99 Airbag (2F-2P-2L-2T-I) | • | • | • | • | • | 0 |
| | 1.6 TS 16V | Safety | SIEMENS MY 99 Airbag (2F-2P-2L-2T-I) | • | • | • | • | • | 0 |
| | 1.8 TS 16V | Safety | SIEMENS MY 99 Airbag (2F-2P-2L-2T-I) | • | • | • | • | • | 0 |
| 156 MY | 1.9 JTD | Safety | SIEMENS MY 99 Airbag (2F-2P-2L-2T-I) | • | • | • | • | • | 0 |
| 156 MY | 1.9 JTD 16V | Safety | SIEMENS MY 99 Airbag (2F-2P-2L-2T-I) | • | • | • | • | • | 0 |
| 156 MY | 2.0 TS 16V | Safety | SIEMENS MY 99 Airbag (2F-2P-2L-2T-I) | • | • | • | • | • | 0 |
| 156 MY | 2.4 JTD 10V | Safety | SIEMENS MY 99 Airbag (2F-2P-2L-2T-I) | • | • | • | • | • | 0 |
| 156 MY | 2.4 JTD 20V | Safety | SIEMENS MY 99 Airbag (2F-2P-2L-2T-I) | • | • | • | • | • | 0 |
| 156 MY | 2.5 V6 24V | Safety | SIEMENS MY 99 Airbag (2F-2P-2L-2T-I) | • | • | • | • | • | 0 |
| 156 MY | GTA 3.2 V6 | Safety | SIEMENS MY 99 Airbag (2F-2P-2L-2T-I) | • | • | • | • | • | 0 |
| 156 MY | GTA SELESPEED | Safety | SIEMENS MY 99 Airbag (2F-2P-2L-2T-I) | • | • | • | • | • | 0 |
| 156 MY | JTS 2.0 | Safety | SIEMENS MY 99 Airbag (2F-2P-2L-2T-I) | • | • | • | • | • | 0 |
| 156 MY | JTS SELESPEED | Safety | SIEMENS MY 99 Airbag (2F-2P-2L-2T-I) | • | • | • | • | • | 0 |
| 156 MY | SELESPEED | Safety | SIEMENS MY 99 Airbag (2F-2P-2L-2T-I) | • | • | • | • | • | 0 |
| GT | 1.8 TS 16V | Safety | SIEMENS MY 99 Airbag (2F-2P-2L-2T-I) | • | • | • | • | • | 0 |
| GT | 1.9 JTD 16V | Safety | SIEMENS MY 99 Airbag (2F-2P-2L-2T-I) | • | • | • | • | • | 0 |
| GT | 3. 2 V6 24V | Safety | SIEMENS MY 99 Airbag (2F-2P-2L-2T-I) | • | • | • | • | • | 0 |
| | JTS 2.0 | Safety | SIEMENS MY 99 Airbag (2F-2P-2L-2T-I) | • | • | • | • | • | 0 |
| | '03 2.0 TS 16V | Safety | TRW MY 99 Airbag (2F-2P-2L-I) | • | • | • | • | • | 0 |
| 166 | '03 2.4 JTD 20V | Safety | TRW MY 99 Airbag (2F-2P-2L-I) | • | • | • | • | • | 0 |
| 166 | '03 2.5 V6 24V | Safety | TRW MY 99 Airbag (2F-2P-2L-I) | • | • | • | • | • | 0 |
| 166 | '03 3.0 V6 24V | Safety | TRW MY 99 Airbag (2F-2P-2L-I) | • | • | • | • | • | 0 |
| | '03 3.2 V6 24V | Safety | TRW MY 99 Airbag (2F-2P-2L-I) | • | • | • | • | • | 0 |
| | 2. 0 TS 16V | Safety | TRW MY 99 Airbag (2F-2P-2L-I) | | | • | • | • | 0 |
| | 2. 0 V6 TB | Safety | TRW MY 99 Airbag (2F-2P-2L-I) | • | • | • | • | • | 0 |
| | 2. 4 JTD | Safety | TRW MY 99 Airbag (2F-2P-2L-I) | | | • | • | | 0 |
| | 2. 5 V6 24V | Safety | TRW MY 99 Airbag (2F-2P-2L-I) | | • | • | • | | 0 |

| Model | Version | Group | System | ECU info. | Read Codes | Erase Codes | Live Data | Active Test | Specil Function |
|--------|-----------------------------|--------|----------------------------------|--------------|---------------|----------------|--------------|----------------|-----------------|
| 166 | 3.0 V6 24V | Safety | TRW MY 99 Airbag (2F-2P-2L-I) | • | • | • | • | • | 0 |
| 166 | '03 2.0 TS 16V | Safety | TRW MY 99 Airbag (2F-2P-2L-2T-I) | • | • | • | • | • | 0 |
| 166 | '03 2.4 JTD 20V | Safety | TRW MY 99 Airbag (2F-2P-2L-2T-I) | • | • | • | • | • | 0 |
| 166 | '03 2.5 V6 24V | Safety | TRW MY 99 Airbag (2F-2P-2L-2T-I) | • | • | • | • | • | 0 |
| 166 | '03 3.0 V6 24V | Safety | TRW MY 99 Airbag (2F-2P-2L-2T-I) | • | • | • | • | • | 0 |
| 166 | '03 3.2 V6 24V | Safety | TRW MY 99 Airbag (2F-2P-2L-2T-I) | • | • | • | • | • | 0 |
| 147 | 1.6 TS 16V 105CV | Safety | Bosch ABS 5.7 | • | • | • | • | • | 0 |
| 147 | 1.6 TS 16V 120CV | Safety | Bosch ABS 5.7 | • | • | • | • | • | 0 |
| 147 | 1.9 JTD | Safety | Bosch ABS 5.7 | • | • | • | • | • | 0 |
| 147 | 1. 9 JTD 16V | Safety | Bosch ABS 5.7 | • | • | • | • | • | 0 |
| 147 | 2. 0 TS 16V | Safety | Bosch ABS 5.7 | • | • | • | • | • | 0 |
| 147 | GTA 3.2 V6 | Safety | Bosch ABS 5.7 | • | • | • | • | • | 0 |
| 147 | GTA SELESPEED | Safety | Bosch ABS 5.7 | • | • | • | • | • | 0 |
| 147 | SELESPEED | Safety | Bosch ABS 5.7 | • | • | • | | • | 0 |
| 156 MY | 1. 6 TS 16V | Safety | Bosch ABS 5.7 | | | • | • | • | 0 |
| 156 MY | 1. 8 TS 16V | Safety | Bosch ABS 5.7 | | | • | | | 0 |
| 156 MY | 1. 9 JTD | Safety | Bosch ABS 5.7 | | | • | | | 0 |
| 156 MY | 1. 9 JTD 16V | Safety | Bosch ABS 5.7 | | | • | | | 0 |
| 156 MY | 2. 0 TS 16V | Safety | Bosch ABS 5.7 | | | • | - | | 0 |
| | 2. 4 JTD 10V | Safety | | | | | - | | 0 |
| 156 MY | 2. 4 JTD 20V | Safety | Bosch ABS 5.7 | | | • | - | | 0 |
| 156 MY | 2. 4 J1D 20V 2. 5 V6 24V | | Bosch ABS 5.7 | | | • | - | | 0 |
| 156 MY | | Safety | Bosch ABS 5.7 | | | • | • | | |
| 156 MY | GTA SELESPEED | Safety | Bosch ABS 5.7 | • | | | | | 0 |
| 156 MY | JTS 2.0 | Safety | Bosch ABS 5.7 | • | _ | • | • | • | 0 |
| 156 MY | JTS SELESPEED | Safety | Bosch ABS 5.7 | • | • | • | • | • | 0 |
| 156 MY | SELESPEED | Safety | Bosch ABS 5.7 | • | • | • | | • | 0 |
| GT | 1. 8 TS 16V | Safety | Bosch ABS 5.7 | • | • | • | | • | 0 |
| GT | 1. 9 JTD 16V | Safety | Bosch ABS 5.7 | • | • | • | • | • | 0 |
| GT | 3. 2 V6 24V | Safety | Bosch ABS 5.7 | • | • | • | • | • | 0 |
| GT | JTS 2.0 | Safety | Bosch ABS 5.7 | • | • | • | • | • | 0 |
| 147 | 1.6 TS 16V 120CV | Safety | Bosch ABS 5.7 VDC | • | • | • | • | • | 0 |
| 147 | 1.9 JTD | Safety | Bosch ABS 5.7 VDC | • | • | • | • | • | 0 |
| 147 | 1.9 JTD 16V | Safety | Bosch ABS 5.7 VDC | • | • | • | • | • | 0 |
| 147 | 2.0 TS 16V | Safety | Bosch ABS 5.7 VDC | • | • | • | • | • | 0 |
| 147 | GTA 3.2 V6 | Safety | Bosch ABS 5.7 VDC | • | • | • | • | • | 0 |
| 147 | GTA SELESPEED | Safety | Bosch ABS 5.7 VDC | • | • | • | • | • | 0 |
| 147 | SELESPEED | Safety | Bosch ABS 5.7 VDC | • | • | • | • | • | 0 |
| 156 MY | 1.6 TS 16V | Safety | Bosch ABS 5.7 VDC | • | • | • | • | • | 0 |
| 156 MY | 1.8 TS 16V | Safety | Bosch ABS 5.7 VDC | • | • | • | • | • | 0 |
| 156 MY | 1.9 JTD | Safety | Bosch ABS 5.7 VDC | • | • | • | • | • | 0 |
| 156 MY | 1.9 JTD 16V | Safety | Bosch ABS 5.7 VDC | • | • | • | • | • | 0 |
| 156 MY | 2.0 TS 16V | Safety | Bosch ABS 5.7 VDC | • | • | • | • | • | 0 |
| 156 MY | 2.4 JTD 10V | Safety | Bosch ABS 5.7 VDC | • | • | • | • | • | 0 |
| 156 MY | 2.4 JTD 20V | Safety | Bosch ABS 5.7 VDC | • | • | • | • | • | 0 |
| 156 MY | 2.5 V6 24V | Safety | Bosch ABS 5.7 VDC | • | • | • | • | • | 0 |
| 156 MY | GTA SELESPEED | Safety | Bosch ABS 5.7 VDC | • | • | • | • | • | 0 |
| 156 MY | JTS 2.0 | Safety | Bosch ABS 5.7 VDC | • | • | • | • | • | 0 |
| 156 MY | JTS SELESPEED | Safety | Bosch ABS 5.7 VDC | • | • | • | • | • | 0 |

| • O O O O O |
|-------------|
| • 0 |
| • 0 |
| |
| • 0 |
| |
| • 0 |
| • 0 |
| • 0 |
| • 0 |
| • 0 |
| • 0 |
| • 0 |
| • 0 |
| • 0 |
| • 0 |
| • 0 |
| • 0 |
| • 0 |
| • 0 |
| • 0 |
| • 0 |
| • 0 |
| • 0 |
| • 0 |
| • 0 |
| • 0 |
| • 0 |
| • 0 |
| • 0 |
| • 0 |
| • 0 |
| • 0 |
| • 0 |
| • 0 |
| • 0 |
| • 0 |
| • 0 |
| • 0 |
| • 0 |
| • 0 |
| • 0 |
| • 0 |
| |
| |

| Model | Version | Group | System | ECU | Read | Erase | Live | Active | Specil Function |
|------------|---------------------|------------------------------------|----------------------------------------------------------|-------|-------|-------|------|--------|---------------------|
| 1.47 | 1.9 JTD 16V | Othersene | TDW decision, and a second | info. | Codes | Codes | Data | Test | |
| 147 | · · | Other systems | TRW driver's door | | | • | _ | | 0 |
| 147 | 2. 0 TS 16V | Other systems | TRW driver's door | • | • | • | • | • | 0 |
| 147 | GTA 3.2 V6 | Other systems | TRW driver's door | | | | | | |
| 147 | GTA SELESPEED | Other systems | TRW driver's door | | | • | • | • | 0 |
| 147 | SELESPEED | Other systems | TRW driver's door | • | • | • | • | • | 0 |
| 147 | 1. 6 TS 16V 105CV | Other systems | TRW Boot | • | • | • | • | • | 0 |
| 147 | 1. 6 TS 16V 120CV | Other systems | TRW Boot | • | • | • | • | • | 0 |
| 147 | 1. 9 JTD | Other systems | TRW Boot | • | • | • | • | • | 0 |
| 147 | 1. 9 JTD 16V | Other systems | TRW Boot | • | • | • | • | • | 0 |
| 147 | 2. 0 TS 16V | Other systems | TRW Boot | • | • | • | • | • | 0 |
| 147 | GTA 3.2 V6 | Other systems | TRW Boot | • | • | • | • | • | 0 |
| 147 | GTA SELESPEED | Other systems | TRW Boot | • | • | • | • | • | 0 |
| 147 | SELESPEED | Other systems | TRW Boot | • | • | • | • | • | 0 |
| 147 | 1.6 TS 16V 105CV | Safety | Marelli Body Computer | • | • | • | • | • | 0 |
| 147 | 1.6 TS 16V 120CV | Safety | Marelli Body Computer | • | • | • | • | • | 0 |
| 147 | 1.9 JTD | Safety | Marelli Body Computer | • | • | • | • | • | 0 |
| 147 | 1.9 JTD 16V | Safety | Marelli Body Computer | • | • | • | • | • | 0 |
| 147 | 2.0 TS 16V | Safety | Marelli Body Computer | • | • | • | • | • | 0 |
| 147 | GTA 3.2 V6 | Safety | Marelli Body Computer | • | • | • | • | • | 0 |
| 147 | GTA SELESPEED | Safety | Marelli Body Computer | • | • | • | • | • | 0 |
| 147 | SELESPEED | Safety | Marelli Body Computer | • | • | • | • | • | 0 |
| GT | 1.8 TS 16V | Safety | Marelli Body Computer | • | • | • | • | • | 0 |
| GT | 1.9 JTD 16V | Safety | Marelli Body Computer | • | • | • | • | • | 0 |
| GT | 3. 2 V6 24V | Safety | Marelli Body Computer | • | • | • | • | • | 0 |
| GT | JTS 2.0 | Safety | Marelli Body Computer | • | • | • | • | • | 0 |
| 147 | 1.6 TS 16V 105CV | Instrumentation | Mannesman VDO instrument panel | • | • | • | • | • | 0064 0032 0042 0034 |
| 147 | 1.6 TS 16V 120CV | Instrumentation | Mannesman VDO instrument panel | • | • | • | • | • | 0064 0032 0042 0034 |
| 147 | 1.9 JTD | Instrumentation | Mannesman VDO instrument panel | • | • | • | • | • | 0064 0032 0042 0034 |
| 147 | 1.9 JTD 16V | Instrumentation | Mannesman VDO instrument panel | • | • | • | • | • | 0064 0032 0042 0034 |
| 147 | 2. 0 TS 16V | Instrumentation | Mannesman VDO instrument panel | • | • | • | • | • | 0064 0032 0042 0034 |
| 147 | GTA 3.2 V6 | Instrumentation | Mannesman VDO instrument panel | • | • | • | • | • | 0064 0032 0042 0034 |
| 147 | GTA SELESPEED | Instrumentation | Mannesman VDO instrument panel | • | • | • | • | • | 0064 0032 0042 0034 |
| 147 | SELESPEED | Instrumentation | Mannesman VDO instrument panel | • | • | • | • | • | 0064 0032 0042 0034 |
| GT | 1. 8 TS 16V | Instrumentation | Mannesman VDO instrument panel | • | • | • | • | • | 0064 0032 0042 0034 |
| GT | 1. 9 JTD 16V | Instrumentation | Mannesman VDO instrument panel | • | • | • | • | • | 0064 0032 0042 0034 |
| GT | 3. 2 V6 24V | Instrumentation | Mannesman VDO instrument panel | • | • | • | • | • | 0064 0032 0042 0034 |
| GT | JTS 2.0 | Instrumentation | Mannesman VDO instrument panel | • | • | • | • | • | 0064 0032 0042 0034 |
| 147 | 1. 6 TS 16V 105CV | Engine - Gearbox | Bosch Motronic Me7.3.1 EOBD injection (2 lambda sensors) | • | • | • | • | • | 0 |
| 147 | 1.6 TS 16V 120CV | Engine - Gearbox | Bosch Motronic Me7.3.1 EOBD injection | • | • | • | • | • | 0 |
| 147 | 2. 0 TS 16V | Engine - Gearbox Engine - Gearbox | Bosch Motronic Me7.3.1 EOBD injection | + + | • | • | • | | 0 |
| 147 | GTA 3. 2 V6 | Engine - Gearbox Engine - Gearbox | Bosch Motronic Me7.3.1 EODD injection | | • | • | | • | 0 |
| 147 | GTA SELESPEED | Engine - Gearbox Engine - Gearbox | Bosch Motronic Me7.3.1 EOBD injection | | • | • | | | 0 |
| 147 | SELESPEED SELESPEED | | | | • | | - | • | 0 |
| 147 156 | | Engine - Gearbox | Bosch Motronic Me7. 3.1 EOBD injection | | • | • | • | | 0 |
| | 1. 6 TS 16V | Engine - Gearbox | Bosch Motronic Me7. 3.1 EOBD injection | | • | _ | • | • | 0 |
| 156 | 1. 8 TS 16V | Engine - Gearbox | Bosch Motronic Me7.3.1 EOBD injection | | | • | | | |
| 156 | 2. 0 TS 16V | Engine - Gearbox | Bosch Motronic Me7. 3. 1 EOBD injection | • | • | • | • | • | 0 |
| 156 | SELESPEED | Engine - Gearbox | Bosch Motronic Me7.3.1 EOBD injection | • | • | • | • | | 0 |

| Mode1 | Voncion | Croun | Creat on | ECU | Read | Erase | Live | Active | Crasil Eurotion |
|--------|---------------------|------------------|-----------------------------------------------------------------------|-------|-------|-------|------|--------|-----------------|
| Model | Version | Group | System | info. | Codes | Codes | Data | Test | Specil Function |
| 156 MY | 1.6 TS 16V | Engine - Gearbox | Bosch Motronic Me7.3.1 EOBD injection | • | • | • | • | • | 0 |
| 156 MY | 1.8 TS 16V | Engine - Gearbox | Bosch Motronic Me7.3.1 EOBD injection | • | • | • | • | • | 0 |
| 156 MY | GTA 3.2 V6 | Engine - Gearbox | Bosch Motronic Me7.3.1 EOBD injection | • | • | • | • | • | 0 |
| 156 MY | GTA SELESPEED | Engine - Gearbox | Bosch Motronic Me7.3.1 EOBD injection | • | • | • | • | • | 0 |
| 156 MY | SELESPEED | Engine - Gearbox | Bosch Motronic Me7.3.1 EOBD injection | • | • | • | • | • | 0 |
| 166 | '03 2.0 TS 16V | Engine - Gearbox | Bosch Motronic Me7.3.1 EOBD injection | • | • | • | • | • | 0 |
| 166 | '03 3.2 V6 24V | Engine - Gearbox | Bosch Motronic Me7.3.1 EOBD injection | • | • | • | • | • | 0 |
| 166 | 2.0 TS 16V | Engine - Gearbox | Bosch Motronic Me7.3.1 EOBD injection | • | • | • | • | • | 0 |
| GT | 1.8 TS 16V | Engine - Gearbox | Bosch Motronic Me7.3.1 EOBD injection | • | • | • | • | • | 0 |
| GT | 3. 2 V6 24V | Engine - Gearbox | Bosch Motronic Me7.3.1 EOBD injection | • | • | • | • | • | 0 |
| GTV | '03 2.0 TS 16V | Engine - Gearbox | Bosch Motronic Me7.3.1 EOBD injection | • | • | • | • | • | 0 |
| GTV | '03 3.2 V6 24V | Engine - Gearbox | Bosch Motronic Me7.3.1 EOBD injection | • | • | • | • | • | 0 |
| GTV | '98 2.0 TS 16V | Engine - Gearbox | Bosch Motronic Me7.3.1 EOBD injection | • | • | • | • | • | 0 |
| SPIDER | '03 2.0 TS 16V | Engine - Gearbox | Bosch Motronic Me7.3.1 EOBD injection | • | • | • | • | • | 0 |
| SPIDER | '03 3.2 V6 24V | Engine - Gearbox | Bosch Motronic Me7.3.1 EOBD injection | • | • | • | • | • | 0 |
| SPIDER | '98 2.0 TS 16V | Engine - Gearbox | Bosch Motronic Me7.3.1 EOBD injection | • | • | • | • | • | 0 |
| 147 | 1. 6 TS 16V 105CV | Comfort | Delphi Climate control (Dual zone) | • | • | • | • | • | 0 |
| 147 | 1. 6 TS 16V 120CV | Comfort | Delphi Climate control (Dual zone) | • | • | • | • | • | 0 |
| 147 | 1. 9 JTD | Comfort | Delphi Climate control (Dual zone) | | • | • | • | • | 0 |
| 147 | 1. 9 JTD 16V | Comfort | Delphi Climate control (Dual zone) | | | • | • | | 0 |
| 147 | 2. 0 TS 16V | Comfort | Delphi Climate control (Dual zone) | | | • | • | | 0 |
| 147 | GTA 3. 2 V6 | Comfort | Delphi Climate control (Dual zone) | | | • | | | 0 |
| 147 | GTA SELESPEED | Comfort | Delphi Climate control (Dual zone) | • | • | • | | | 0 |
| 147 | SELESPEED SELESPEED | Comfort | Delphi Climate control (Dual zone) | | | • | - | | 0 |
| GT GT | 1.8 TS 16V | Comfort | Delphi Climate control (Dual zone) | | | • | • | | 0 |
| GT | 1. 9 JTD 16V | Comfort | | | | • | - | | 0 |
| | 3. 2 V6 24V | Comfort | Delphi Climate control (Dual zone) Delphi Climate control (Dual zone) | | | | • | | 0 |
| GT | | | | | | | • | | 0 |
| GT | JTS 2.0 | Comfort | Delphi Climate control (Dual zone) | | | • | | _ | 0 |
| 147 | 1. 6 TS 16V 105CV | Comfort | Delphi Climate control (Single zone) | | | | • | • | |
| 147 | 1. 6 TS 16V 120CV | Comfort | Delphi Climate control (Single zone) | • | | • | | • | 0 |
| 147 | 1.9 JTD | Comfort | Delphi Climate control (Single zone) | • | • | • | • | • | 0 |
| 147 | 1. 9 JTD 16V | Comfort | Delphi Climate control (Single zone) | • | • | • | • | • | 0 |
| 147 | 2. 0 TS 16V | Comfort | Delphi Climate control (Single zone) | • | • | • | • | • | 0 |
| 147 | GTA 3.2 V6 | Comfort | Delphi Climate control (Single zone) | • | • | • | • | • | 0 |
| 147 | GTA SELESPEED | Comfort | Delphi Climate control (Single zone) | • | • | • | • | • | 0 |
| 147 | SELESPEED | Comfort | Delphi Climate control (Single zone) | • | • | • | • | • | 0 |
| GT | 1. 8 TS 16V | Comfort | Delphi Climate control (Single zone) | • | • | • | • | • | 0 |
| GT | 1. 9 JTD 16V | Comfort | Delphi Climate control (Single zone) | • | • | • | • | • | 0 |
| | 3. 2 V6 24V | Comfort | Delphi Climate control (Single zone) | • | • | • | • | • | 0 |
| GT | JTS 2.0 | Comfort | Delphi Climate control (Single zone) | • | • | • | • | • | 0 |
| 156 | 2.5 V6 24V | Engine - Gearbox | Bosch Motronic EOBD ME3.1 Injection (eng. V6) | • | • | • | • | • | 0 |
| 156 MY | 2. 5 V6 24V | Engine - Gearbox | Bosch Motronic EOBD ME3.1 Injection (eng. V6) | • | • | • | • | • | 0 |
| 166 | '03 2.5 V6 24V | Engine - Gearbox | Bosch Motronic EOBD ME3.1 Injection (eng. V6) | • | • | • | • | • | 0 |
| 166 | '03 3.0 V6 24V | Engine - Gearbox | Bosch Motronic EOBD ME3.1 Injection (eng. V6) | • | • | • | • | • | 0 |
| 166 | 2.5 V6 24V | Engine - Gearbox | Bosch Motronic EOBD ME3.1 Injection (eng. V6) | • | • | • | • | • | 0 |
| 166 | 3.0 V6 24V | Engine - Gearbox | Bosch Motronic EOBD ME3.1 Injection (eng. V6) | • | • | • | • | • | 0 |
| GTV | '98 3.0 V6 24V | Engine - Gearbox | Bosch Motronic EOBD ME3.1 Injection (eng. V6) | • | • | • | • | • | 0 |
| SPIDER | '98 3.0 V6 | Engine - Gearbox | Bosch Motronic EOBD ME3.1 Injection (eng. V6) | • | • | • | • | • | 0 |

| Model | Version | Group | System | ECU info. | Read Codes | Erase Codes | Live Data | Active Test | Specil Function |
|--------|---------------------|---------------|----------------------------------|--------------|---------------|----------------|--------------|----------------|-----------------|
| 147 | 1. 6 TS 16V 105CV | Other systems | Bosch discharge headlamp (left) | • | 00000 | Oddes | Data | 1050 | 0 |
| 147 | 1. 6 TS 16V 120CV | Other systems | Bosch discharge headlamp (left) | | | • | • | • | 0 |
| 147 | 1. 9 JTD | Other systems | Bosch discharge headlamp (left) | | | • | • | | 0 |
| 147 | 1. 9 JTD 16V | Other systems | Bosch discharge headlamp (left) | | | • | • | | 0 |
| 147 | 2. 0 TS 16V | Other systems | Bosch discharge headlamp (left) | | | | • | | 0 |
| 147 | GTA 3. 2 V6 | Other systems | Bosch discharge headlamp (left) | • | | • | | | 0 |
| 147 | GTA SELESPEED | Other systems | Bosch discharge headlamp (left) | | | • | • | | 0 |
| 147 | SELESPEED | Other systems | Bosch discharge headlamp (left) | | | | | | 0 |
| 156 MY | 1. 6 TS 16V | Other systems | Bosch discharge headlamp (left) | | | • | - | | 0 |
| 156 MY | 1. 8 TS 16V | Other systems | Bosch discharge headlamp (left) | | | | • | | 0 |
| 156 MY | 1. 9 JTD | | 1 \ / | | | | - | | 0 |
| | 1. 9 JTD 16V | Other systems | Bosch discharge headlamp (left) | | | | - | | 0 |
| 156 MY | 2. 0 TS 16V | Other systems | Bosch discharge headlamp (left) | | | | • | | 0 |
| 156 MY | | Other systems | Bosch discharge headlamp (left) | | | | • | | 0 |
| 156 MY | 2. 4 JTD 10V | Other systems | Bosch discharge headlamp (left) | • | | <u> </u> | | | |
| 156 MY | 2. 4 JTD 20V | Other systems | Bosch discharge headlamp (left) | • | | • | • | | 0 |
| 156 MY | 2. 5 V6 24V | Other systems | Bosch discharge headlamp (left) | • | • | • | • | • | 0 |
| 156 MY | GTA 3.2 V6 | Other systems | Bosch discharge headlamp (left) | • | • | • | • | • | 0 |
| 156 MY | GTA SELESPEED | Other systems | Bosch discharge headlamp (left) | • | • | • | • | • | 0 |
| 156 MY | JTS 2.0 | Other systems | Bosch discharge headlamp (left) | • | • | • | • | • | 0 |
| 156 MY | JTS SELESPEED | Other systems | Bosch discharge headlamp (left) | • | • | • | • | • | 0 |
| 156 MY | SELESPEED | Other systems | Bosch discharge headlamp (left) | • | • | • | • | • | 0 |
| GT | 1.8 TS 16V | Other systems | Bosch discharge headlamp (left) | • | • | • | • | • | 0 |
| GT | 1.9 JTD 16V | Other systems | Bosch discharge headlamp (left) | • | • | • | • | • | 0 |
| GT | 3. 2 V6 24V | Other systems | Bosch discharge headlamp (left) | • | • | • | • | • | 0 |
| GT | JTS 2.0 | Other systems | Bosch discharge headlamp (left) | • | • | • | • | • | 0 |
| 147 | 1.6 TS 16V 105CV | Other systems | Bosch discharge headlamp (right) | • | • | • | • | 0 | 0 |
| 147 | 1.6 TS 16V 120CV | Other systems | Bosch discharge headlamp (right) | • | • | • | • | 0 | 0 |
| 147 | 1.9 JTD | Other systems | Bosch discharge headlamp (right) | • | • | • | • | 0 | 0 |
| 147 | 1.9 JTD 16V | Other systems | Bosch discharge headlamp (right) | • | • | • | • | 0 | 0 |
| 147 | 2.0 TS 16V | Other systems | Bosch discharge headlamp (right) | • | • | • | • | 0 | 0 |
| 147 | GTA 3.2 V6 | Other systems | Bosch discharge headlamp (right) | • | • | • | • | 0 | 0 |
| 147 | GTA SELESPEED | Other systems | Bosch discharge headlamp (right) | • | • | • | • | 0 | 0 |
| 147 | SELESPEED | Other systems | Bosch discharge headlamp (right) | • | • | • | • | 0 | 0 |
| 156 MY | 1.6 TS 16V | Other systems | Bosch discharge headlamp (right) | • | • | • | • | 0 | 0 |
| 156 MY | 1.8 TS 16V | Other systems | Bosch discharge headlamp (right) | • | • | • | • | 0 | 0 |
| 156 MY | 1.9 JTD | Other systems | Bosch discharge headlamp (right) | • | • | • | • | 0 | 0 |
| 156 MY | 1.9 JTD 16V | Other systems | Bosch discharge headlamp (right) | • | • | • | • | 0 | 0 |
| 156 MY | 2.0 TS 16V | Other systems | Bosch discharge headlamp (right) | • | • | • | • | 0 | 0 |
| 156 MY | 2.4 JTD 10V | Other systems | Bosch discharge headlamp (right) | • | • | • | • | 0 | 0 |
| 156 MY | 2. 4 JTD 20V | Other systems | Bosch discharge headlamp (right) | • | • | • | • | 0 | 0 |
| 156 MY | 2. 5 V6 24V | Other systems | Bosch discharge headlamp (right) | • | • | • | • | 0 | 0 |
| 156 MY | GTA 3.2 V6 | Other systems | Bosch discharge headlamp (right) | • | • | • | • | 0 | 0 |
| 156 MY | GTA SELESPEED | Other systems | Bosch discharge headlamp (right) | • | • | • | • | 0 | 0 |
| 156 MY | JTS 2.0 | Other systems | Bosch discharge headlamp (right) | • | • | • | • | 0 | 0 |
| 156 MY | JTS SELESPEED | Other systems | Bosch discharge headlamp (right) | • | • | • | • | 0 | 0 |
| 156 MY | SELESPEED SELESPEED | Other systems | Bosch discharge headlamp (right) | • | • | • | • | 0 | 0 |
| GT | 1. 8 TS 16V | Other systems | Bosch discharge headlamp (right) | • | • | • | • | 0 | 0 |
| GT | 1. 9 JTD 16V | Other systems | Bosch discharge headlamp (right) | • | • | • | • | | 0 |

| Mode1 | Version | Group | System | ECU info. | Read Codes | Erase Codes | Live Data | Active Test | Specil Function |
|--------|------------------|------------------|------------------------------------------------------------|--------------|---------------|----------------|--------------|----------------|-----------------|
| GT | 3. 2 V6 24V | Other systems | Bosch discharge headlamp (right) | • | • | • | • | 0 | 0 |
| GT | JTS 2.0 | Other systems | Bosch discharge headlamp (right) | • | • | • | • | 0 | 0 |
| 147 | 1.9 JTD | Engine - Gearbox | Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4) | • | • | • | • | • | 0 |
| 156 | 1.9 JTD | Engine - Gearbox | Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4) | • | • | • | • | • | 0 |
| 156 | 2. 4 JTD | Engine - Gearbox | Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4) | • | • | • | • | • | 0 |
| 156 MY | 1.9 JTD | Engine - Gearbox | Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4) | • | • | • | • | • | 0 |
| 156 MY | 2.4 JTD 10V | Engine - Gearbox | Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4) | • | • | • | • | • | 0 |
| 166 | 2.4 JTD | Engine - Gearbox | Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4) | • | • | • | • | • | 0 |
| 159 | 1.8 16V | Safety | ESP TRW Lucas ABS | • | • | • | • | • | 0 |
| 159 | 1.8 JTS TB 16V | Safety | ESP TRW Lucas ABS | • | • | • | • | • | 0 |
| 159 | 1.9 JTS 16V | Safety | ESP TRW Lucas ABS | • | • | • | • | • | 0 |
| 159 | 1.9 MJET 16V | Safety | ESP TRW Lucas ABS | • | • | • | • | • | 0 |
| 159 | 1.9 MJET 8V | Safety | ESP TRW Lucas ABS | • | • | • | • | • | 0 |
| 159 | 2.0 JTD 16V | Safety | ESP TRW Lucas ABS | • | • | • | • | • | 0 |
| 159 | 2. 2 JTS 16V | Safety | ESP TRW Lucas ABS | • | • | • | • | • | 0 |
| 159 | 2.4 MJET 20V | Safety | ESP TRW Lucas ABS | • | • | • | • | • | 0 |
| 159 | 3. 2 V6 24V | Safety | ESP TRW Lucas ABS | • | • | • | • | • | 0 |
| BRERA | 1.8 JTS TB 16V | Safety | ESP TRW Lucas ABS | • | • | • | • | • | 0 |
| BRERA | 2.0 JTD 16V | Safety | ESP TRW Lucas ABS | • | • | • | • | • | 0 |
| BRERA | 2. 2 JTS 16V | Safety | ESP TRW Lucas ABS | • | • | • | • | • | 0 |
| BRERA | 2.4 MJET 20V | Safety | ESP TRW Lucas ABS | • | • | • | • | • | 0 |
| BRERA | 3. 2 V6 24V | Safety | ESP TRW Lucas ABS | • | • | • | • | • | 0 |
| 147 | 1.6 TS 16V 120CV | Engine - Gearbox | Injection - Bosch Motronic Me7.3.1 Outside EEC | • | • | • | • | • | 0 |
| 147 | 2.0 TS 16V | Engine - Gearbox | Injection - Bosch Motronic Me7.3.1 Outside EEC | • | • | • | • | • | 0 |
| 147 | SELESPEED | Engine - Gearbox | Injection - Bosch Motronic Me7.3.1 Outside EEC | • | • | • | • | • | 0 |
| 156 | 1.6 TS 16V | Engine - Gearbox | Injection - Bosch Motronic Me7.3.1 Outside EEC | • | • | • | • | • | 0 |
| 156 | 2.0 TS 16V | Engine - Gearbox | Injection - Bosch Motronic Me7.3.1 Outside EEC | • | • | • | • | • | 0 |
| 156 | SELESPEED | Engine - Gearbox | Injection - Bosch Motronic Me7.3.1 Outside EEC | • | • | • | • | • | 0 |
| 156 MY | 2.0 TS 16V | Engine - Gearbox | Injection - Bosch Motronic Me7.3.1 Outside EEC | • | • | • | • | • | 0 |
| 156 MY | GTA 3.2 V6 | Engine - Gearbox | Injection - Bosch Motronic Me7.3.1 Outside EEC | • | • | • | • | • | 0 |
| 156 MY | SELESPEED | Engine - Gearbox | Injection - Bosch Motronic Me7.3.1 Outside EEC | • | • | • | • | • | 0 |
| GTV | '03 2.0 TS 16V | Engine - Gearbox | Injection - Bosch Motronic Me7.3.1 Outside EEC | • | • | • | • | • | 0 |
| GTV | '98 2.0 TS 16V | Engine - Gearbox | Injection - Bosch Motronic Me7.3.1 Outside EEC | • | • | • | • | • | 0 |
| SPIDER | '03 2.0 TS 16V | Engine - Gearbox | Injection - Bosch Motronic Me7.3.1 Outside EEC | • | • | • | • | • | 0 |
| SPIDER | '98 2.0 TS 16V | Engine - Gearbox | Injection - Bosch Motronic Me7.3.1 Outside EEC | • | • | • | • | • | 0 |
| 147 | 1.6 TS 16V 105CV | Engine - Gearbox | Injection - Bosch Motronic Me7.3.1 Outside EEC (2 lambdas) | • | • | • | • | • | 0 |
| 156 | 2.5 V6 24V | Engine - Gearbox | Injection - Bosch Motronic Me3.1 (eng. V6) Outside EEC | • | • | • | • | • | 0 |
| 166 | '03 2.5 V6 24V | Engine - Gearbox | Injection - Bosch Motronic Me3.1 (eng. V6) Outside EEC | • | • | • | • | • | 0 |

| Model | Version | Group | System | ECU info. | Read Codes | Erase Codes | Live Data | Active Test | Specil Function |
|--------|----------------|------------------|-----------------------------------------------------------|--------------|---------------|----------------|--------------|----------------|-----------------|
| 166 | '03 3.0 V6 24V | Engine - Gearbox | Injection - Bosch Motronic Me3.1 (eng. V6) Outside EEC | • | • | • | • | • | 0 |
| 166 | 2. 5 V6 24V | Engine - Gearbox | Injection - Bosch Motronic Me3.1 (eng. V6) Outside EEC | • | • | • | • | • | 0 |
| 166 | 3. 0 V6 24V | Engine - Gearbox | Injection - Bosch Motronic Me3.1 (eng. V6) Outside EEC | • | • | • | • | • | 0 |
| GTV | '98 3.0 V6 24V | Engine - Gearbox | Injection - Bosch Motronic Me3.1 (eng. V6) Outside EEC | • | • | • | • | • | 0 |
| SPIDER | '98 3.0 V6 | Engine - Gearbox | Injection - Bosch Motronic Me3.1 (eng. V6) Outside EEC | • | • | • | • | • | 0 |
| 159 | 1.8 16V | Comfort | Valeo Parking control unit | • | • | • | • | 0 | 0 |
| 159 | 1.8 JTS TB 16V | Comfort | Valeo Parking control unit | • | • | • | • | 0 | 0 |
| 159 | 1.9 JTS 16V | Comfort | Valeo Parking control unit | • | • | • | • | 0 | 0 |
| 159 | 1.9 MJET 16V | Comfort | Valeo Parking control unit | • | • | • | • | 0 | 0 |
| 159 | 1.9 MJET 8V | Comfort | Valeo Parking control unit | • | • | • | • | 0 | 0 |
| 159 | 2.0 JTD 16V | Comfort | Valeo Parking control unit | • | • | • | • | 0 | 0 |
| 159 | 2. 2 JTS 16V | Comfort | Valeo Parking control unit | • | • | • | • | 0 | 0 |
| 159 | 2.4 MJET 20V | Comfort | Valeo Parking control unit | • | • | • | • | 0 | 0 |
| 159 | 3. 2 V6 24V | Comfort | Valeo Parking control unit | • | • | • | • | 0 | 0 |
| BRERA | 1.8 JTS TB 16V | Comfort | Valeo Parking control unit | • | • | • | • | 0 | 0 |
| BRERA | 2.0 JTD 16V | Comfort | Valeo Parking control unit | • | • | • | • | 0 | 0 |
| BRERA | 2. 2 JTS 16V | Comfort | Valeo Parking control unit | • | • | • | • | 0 | 0 |
| BRERA | 2.4 MJET 20V | Comfort | Valeo Parking control unit | • | • | • | • | 0 | 0 |
| BRERA | 3. 2 V6 24V | Comfort | Valeo Parking control unit | • | • | • | • | 0 | 0 |
| 156 MY | JTS 2.0 | Engine - Gearbox | Bosch Motronic MeD7.11 EOBD injection | • | • | • | • | • | 0 |
| 156 MY | JTS SELESPEED | Engine - Gearbox | Bosch Motronic MeD7.11 EOBD injection | • | • | • | • | • | 0 |
| GT | JTS 2.0 | Engine - Gearbox | Bosch Motronic MeD7.11 EOBD injection | • | • | • | • | • | 0 |
| GTV | '03 2.0 JTS | Engine - Gearbox | Bosch Motronic MeD7.11 EOBD injection | • | • | • | • | • | 0 |
| SPIDER | '03 2.0 JTS | Engine - Gearbox | Bosch Motronic MeD7.11 EOBD injection | • | • | • | • | • | 0 |
| 156 MY | 1.6 TS 16V | Comfort | Delphi Climate Control | • | • | • | • | • | 0 |
| 156 MY | 1.8 TS 16V | Comfort | Delphi Climate Control | • | • | • | • | • | 0 |
| 156 MY | 1.9 JTD | Comfort | Delphi Climate Control | • | • | • | • | • | 0 |
| 156 MY | 1.9 JTD 16V | Comfort | Delphi Climate Control | • | • | • | • | • | 0 |
| 156 MY | 2. 0 TS 16V | Comfort | Delphi Climate Control | • | • | • | • | • | 0 |
| 156 MY | 2.4 JTD 10V | Comfort | Delphi Climate Control | • | • | • | • | • | 0 |
| 156 MY | 2.4 JTD 20V | Comfort | Delphi Climate Control | • | • | • | • | • | 0 |
| 156 MY | 2.5 V6 24V | Comfort | Delphi Climate Control | • | • | • | • | • | 0 |
| 156 MY | GTA 3.2 V6 | Comfort | Delphi Climate Control | • | • | • | • | • | 0 |
| 156 MY | GTA SELESPEED | Comfort | Delphi Climate Control | • | • | • | • | • | 0 |
| 156 MY | JTS 2.0 | Comfort | Delphi Climate Control | • | • | • | • | • | 0 |
| 156 MY | JTS SELESPEED | Comfort | Delphi Climate Control | • | • | • | • | • | 0 |
| 156 MY | SELESPEED | Comfort | Delphi Climate Control | • | • | • | • | • | 0 |
| 147 | 1.9 JTD 16V | Engine - Gearbox | Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.) | • | • | • | • | • | 0 |
| 156 MY | 1.9 JTD 16V | Engine - Gearbox | Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.) | • | • | • | • | • | 0 |
| 156 MY | 2. 4 JTD 20V | Engine - Gearbox | Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.) | • | • | • | • | • | 0 |

| Model | Version | Group | System | ECU info. | Read Codes | Erase Codes | Live Data | Active Test | Specil Function |
|--------|-------------------|------------------|------------------------------------------------------|--------------|---------------|----------------|--------------|----------------|-----------------|
| 166 | '03 2.4 JTD 20V | Engine - Gearbox | Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.) | • | • | • | • | • | 0 |
| GT | 1.9 JTD 16V | Engine - Gearbox | Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.) | • | • | • | • | • | 0 |
| 156 MY | JTS 2.0 | Engine - Gearbox | Bosch Motronic MeD7.11 Extra EEC Injection | • | • | • | • | • | 0 |
| 147 | 1.6 TS 16V 105CV | Safety | Bosch 8 ABS | • | • | • | • | • | 0 |
| 147 | 1.6 TS 16V 120CV | Safety | Bosch 8 ABS | • | • | • | • | • | 0 |
| 147 | 1.9 JTD | Safety | Bosch 8 ABS | • | • | • | • | • | 0 |
| 147 | 1.9 JTD 16V | Safety | Bosch 8 ABS | • | • | • | • | • | 0 |
| 147 | 2.0 TS 16V | Safety | Bosch 8 ABS | • | • | • | • | • | 0 |
| 147 | GTA 3.2 V6 | Safety | Bosch 8 ABS | • | • | • | • | • | 0 |
| 147 | GTA SELESPEED | Safety | Bosch 8 ABS | • | • | • | • | • | 0 |
| 147 | SELESPEED | Safety | Bosch 8 ABS | • | • | • | • | • | 0 |
| GT | 1.8 TS 16V | Safety | Bosch 8 ABS | • | • | • | • | • | 0 |
| GT | 1.9 JTD 16V | Safety | Bosch 8 ABS | • | • | • | • | • | 0 |
| GT | 3. 2 V6 24V | Safety | Bosch 8 ABS | • | • | • | • | • | 0 |
| GT | JTS 2.0 | Safety | Bosch 8 ABS | • | • | • | • | • | 0 |
| 147 | 1.6 TS 16V 105CV | Other systems | Valeo discharge headlamp (left) | • | • | • | • | • | 0 |
| 147 | 1.6 TS 16V 120CV | Other systems | Valeo discharge headlamp (left) | • | • | • | • | • | 0 |
| 147 | 1. 9 JTD | Other systems | Valeo discharge headlamp (left) | • | • | • | • | • | 0 |
| 147 | 1.9 JTD 16V | Other systems | Valeo discharge headlamp (left) | • | • | • | • | • | 0 |
| 147 | 2. 0 TS 16V | Other systems | Valeo discharge headlamp (left) | • | • | • | • | • | 0 |
| 147 | GTA 3.2 V6 | Other systems | Valeo discharge headlamp (left) | • | • | • | • | • | 0 |
| 147 | GTA SELESPEED | Other systems | Valeo discharge headlamp (left) | • | • | • | • | • | 0 |
| 147 | SELESPEED | Other systems | Valeo discharge headlamp (left) | • | • | • | • | • | 0 |
| 166 | '03 2.0 TS 16V | Other systems | Valeo discharge headlamp (left) | • | • | • | • | • | 0 |
| 166 | '03 2.4 JTD 20V | Other systems | Valeo discharge headlamp (left) | • | • | • | • | • | 0 |
| 166 | '03 2.5 V6 24V | Other systems | Valeo discharge headlamp (left) | • | • | • | • | • | 0 |
| 166 | '03 3.0 V6 24V | Other systems | Valeo discharge headlamp (left) | • | • | • | • | • | 0 |
| 166 | '03 3.2 V6 24V | Other systems | Valeo discharge headlamp (left) | • | • | • | • | • | 0 |
| MITO | 1. 3 MJET 16V | Other systems | Valeo discharge headlamp (left) | • | • | • | • | • | 0 |
| MITO | 1. 4 16V | Other systems | Valeo discharge headlamp (left) | • | • | • | • | • | 0 |
| MITO | 1. 4 TURBO 16V | Other systems | Valeo discharge headlamp (left) | • | • | • | • | • | 0 |
| MITO | 1.6 MJET 16V | Other systems | Valeo discharge headlamp (left) | • | • | • | • | • | 0 |
| 147 | 1. 6 TS 16V 105CV | Safety | Bosch 8 VDC ABS | • | • | • | • | • | 0 |
| 147 | 1.6 TS 16V 120CV | Safety | Bosch 8 VDC ABS | • | • | • | • | • | 0 |
| 147 | 1.9 JTD | Safety | Bosch 8 VDC ABS | • | • | • | • | • | 0 |
| 147 | 1. 9 JTD 16V | Safety | Bosch 8 VDC ABS | • | • | • | • | • | 0 |
| 147 | 2. 0 TS 16V | Safety | Bosch 8 VDC ABS | • | • | • | • | • | 0 |
| 147 | GTA 3.2 V6 | Safety | Bosch 8 VDC ABS | • | • | • | • | • | 0 |
| 147 | GTA SELESPEED | Safety | Bosch 8 VDC ABS | • | • | • | • | • | 0 |
| 147 | SELESPEED | Safety | Bosch 8 VDC ABS | • | • | • | • | • | 0 |
| GT | 1. 8 TS 16V | Safety | Bosch 8 VDC ABS | • | • | • | • | • | 0 |
| GT | 1. 9 JTD 16V | Safety | Bosch 8 VDC ABS | • | • | • | • | • | 0 |
| GT | 3. 2 V6 24V | Safety | Bosch 8 VDC ABS | • | • | • | • | • | 0 |
| GT | JTS 2.0 | Safety | Bosch 8 VDC ABS | • | • | • | • | • | 0 |
| 156 MY | 1. 6 TS 16V | Comfort | Delphi Climate Control MY 03 (Single-zone) | • | • | • | • | • | 0 |
| 156 MY | 1. 8 TS 16V | Comfort | Delphi Climate Control MY 03 (Single-zone) | • | • | • | • | • | 0 |

| Model | Version | Group | System | ECU info. | Read Codes | Erase Codes | Live Data | Active Test | Specil Function |
|--------|---------------------|------------------|---------------------------------------------|--------------------------------------------------|---------------|----------------|--------------|----------------|-----------------|
| 156 MY | 1.9 JTD | Comfort | Delphi Climate Control MY 03 (Single-zone) | 11110. | Codes | Codes | Data | Test | 0 |
| 156 MY | 1. 9 JTD 16V | Comfort | Delphi Climate Control MY 03 (Single-zone) | | | | | | 0 |
| 156 MY | 2. 0 TS 16V | Comfort | Delphi Climate Control MY 03 (Single-zone) | | | | | | 0 |
| 156 MY | 2. 4 JTD 10V | Comfort | Delphi Climate Control MY 03 (Single-zone) | | • | • | | | 0 |
| 156 MY | 2. 4 JTD 20V | Comfort | Delphi Climate Control MY 03 (Single-zone) | | | • | | | 0 |
| 156 MY | 2. 5 V6 24V | Comfort | Delphi Climate Control MY 03 (Single-zone) | — | | | | | 0 |
| 156 MY | GTA 3.2 V6 | Comfort | Delphi Climate Control MY 03 (Single-zone) | — | | | | | 0 |
| 156 MY | GTA SELESPEED | Comfort | Delphi Climate Control MY 03 (Single-zone) | • | | • | • | | 0 |
| 156 MY | JTS 2.0 | Comfort | Delphi Climate Control MY 03 (Single-zone) | | • | | | | 0 |
| 156 MY | JTS SELESPEED | Comfort | Delphi Climate Control MY 03 (Single-zone) | | • | • | • | | 0 |
| 156 MY | SELESPEED SELESPEED | Comfort | Delphi Climate Control MY 03 (Single-zone) | | • | • | • | | 0 |
| 147 | 1. 6 TS 16V 105CV | Other systems | Valeo discharge headlamp (right) | • | • | • | • | | 0 |
| 147 | 1. 6 TS 16V 120CV | Other systems | Valeo discharge headlamp (right) | | • | • | • | | 0 |
| 147 | 1. 9 JTD | Other systems | Valeo discharge headlamp (right) | | | | | | 0 |
| 147 | 1. 9 JTD 16V | Other systems | Valeo discharge headlamp (right) | | • | • | • | | 0 |
| 147 | 2. 0 TS 16V | Other systems | Valeo discharge headlamp (right) | — | | | | | 0 |
| 147 | GTA 3.2 V6 | Other systems | Valeo discharge headlamp (right) | • | • | • | • | • | 0 |
| 147 | GTA SELESPEED | Other systems | Valeo discharge headlamp (right) | | | | | | 0 |
| 147 | SELESPEED SELESPEED | Other systems | Valeo discharge headlamp (right) | | • | | • | | 0 |
| 166 | '03 2.0 TS 16V | Other systems | Valeo discharge headlamp (right) | | | • | | | 0 |
| 166 | '03 2.4 JTD 20V | Other systems | Valeo discharge headlamp (right) | | | • | | | 0 |
| 166 | '03 2. 4 J1D 20V | Other systems | Valeo discharge headlamp (right) | | | • | | | 0 |
| 166 | '03 3.0 V6 24V | Other systems | Valeo discharge headlamp (right) | | • | • | | | 0 |
| 166 | '03 3. 2 V6 24V | Other systems | Valeo discharge headlamp (right) | | | • | | | 0 |
| MITO | 1. 3 MJET 16V | Other systems | Valeo discharge headlamp (right) | — | | • | | | 0 |
| MITO | 1. 4 16V | Other systems | Valeo discharge headlamp (right) | | • | • | • | | 0 |
| MITO | 1. 4 TURBO 16V | Other systems | Valeo discharge headlamp (right) | | • | • | • | • | 0 |
| MITO | 1. 6 MJET 16V | Other systems | Valeo discharge headlamp (right) | | • | • | • | | 0 |
| 166 | '03 2.4 JTD 20V | Engine - Gearbox | AISIN YLII 5 Automatic Gearbox (1) | • | • | • | • | | 0 |
| GT | 1. 8 TS 16V | Other systems | TRW Driver's Door (1) | • | • | • | • | • | 0 |
| GT | 1. 9 JTD 16V | Other systems | TRW Driver's Door (1) | | • | | • | | 0 |
| GT | 3. 2 V6 24V | Other systems | TRW Driver's Door (1) | • | • | • | • | • | 0 |
| GT | JTS 2.0 | Other systems | TRW Driver's Door (1) | • | • | • | • | • | 0 |
| 159 | 1.8 16V | Safety | TRW Lucas ABS | • | • | • | • | • | 0 |
| 159 | 1. 8 JTS TB 16V | Safety | TRW Lucas ABS | • | • | • | • | • | 0 |
| 159 | 1. 9 JTS 16V | Safety | TRW Lucas ABS | • | • | • | • | • | 0 |
| 159 | 1. 9 MJET 16V | Safety | TRW Lucas ABS | • | • | • | • | • | 0 |
| 159 | 1.9 MJET 8V | Safety | TRW Lucas ABS | • | • | • | • | • | 0 |
| 159 | 2. 0 JTD 16V | Safety | TRW Lucas ABS | • | • | • | • | • | 0 |
| 159 | 2. 2 JTS 16V | Safety | TRW Lucas ABS | • | • | • | • | • | 0 |
| 159 | 2. 4 MJET 20V | Safety | TRW Lucas ABS | • | • | • | • | • | 0 |
| 159 | 3. 2 V6 24V | Safety | TRW Lucas ABS | • | • | • | • | • | 0 |
| BRERA | 1. 8 JTS TB 16V | Safety | TRW Lucas ABS | • | • | • | • | • | 0 |
| BRERA | 2. 0 JTD 16V | Safety | TRW Lucas ABS | • | • | • | • | • | 0 |
| BRERA | 2. 2 JTS 16V | Safety | TRW Lucas ABS | • | • | • | • | • | 0 |
| BRERA | 2. 4 MJET 20V | Safety | TRW Lucas ABS | • | • | • | • | • | 0 |
| BRERA | 3. 2 V6 24V | Safety | TRW Lucas ABS | • | • | • | • | • | 0 |
| | | | | • | • | • | • | • | |
| 147 | GTA SELESPEED | Engine - Gearbox | Marelli Automatic Gearbox SELESPEED CFC218F | | | | · | | 0118 |

| Model | Version | Group | System | ECU info. | Read Codes | Erase Codes | Live Data | Active Test | Specil Function |
|--------|-----------------|------------------|---------------------------------------------------------|--------------|---------------|----------------|--------------|----------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 147 | SELESPEED | Engine - Gearbox | Marelli Automatic Gearbox SELESPEED CFC208F | • | 00000 | • | • | | 0118 |
| GT | JTS 2.0 | Engine - Gearbox | Marelli Automatic Gearbox SELESPEED CFC208F | • | | | • | | 0118 |
| 166 | '03 2.0 TS 16V | Comfort | Valeo Parking control unit (1) | • | | | • | 0 | 0 |
| 166 | '03 2.4 JTD 20V | Comfort | Valeo Parking control unit (1) | • | | | • | 0 | 0 |
| 166 | '03 2.5 V6 24V | Comfort | Valeo Parking control unit (1) | • | | | • | 0 | 0 |
| 166 | '03 3.0 V6 24V | Comfort | Valeo Parking control unit (1) | • | • | • | • | Ö | 0 |
| 166 | '03 3.2 V6 24V | Comfort | Valeo Parking control unit (1) | • | • | • | • | 0 | 0 |
| 147 | 1.9 JTD | Engine - Gearbox | Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4) | • | • | • | • | | 0029 0058 0059 0060 0061 0055 0030 0043 0014 0063 0054 0053 0037 0002 0020 0052 0047 0046 |
| 147 | 1.9 JTD 16V | Engine - Gearbox | Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4) | • | • | • | • | • | 0029 0058 0059 0060 0061 0055 0030 0043 0014 0063 0054 0053 0037 0002 0020 0052 0047 0046 |
| 156 MY | 1.9 JTD 16V | Engine - Gearbox | Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4) | • | • | • | • | • | 0029 0058 0059 0060 0061 0055 0030 0043 0014 0063 0054 0053 0037 0002 0020 0052 0047 0046 |
| 159 | 1.9 MJET 16V | Engine - Gearbox | Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4) | • | • | • | • | • | 0029 0058 0059 0060 0061 0055 0030 0043 0014 0063 0054 0053 0037 0002 0020 0052 0047 0046 |
| 159 | 1.9 MJET 8V | Engine - Gearbox | Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4) | • | • | • | • | • | 0029 0058 0059 0060 0061 0055 0030 0043 0014 0063 0054 0053 0037 0002 0020 0052 0047 0046 |
| 159 | 2.4 MJET 20V | Engine - Gearbox | Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4) | • | • | • | • | • | 0029 0058 0059 0060 0061 0055 0030 0043 0014 0063 0054 0053 0037 0002 0020 0052 0047 0046 |
| 166 | '03 2.4 JTD 20V | Engine - Gearbox | Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4) | • | • | • | • | • | 0029 0058 0059 0060 0061 0055 0030 0043 0014 0063 0054 0053 0037 0002 0020 0052 0047 0046 |
| BRERA | 2.4 MJET 20V | Engine - Gearbox | Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4) | • | • | • | • | • | 0029 0058 0059 0060 0061 0055 0030 0043 0014 0063 0054 0053 0037 0002 0020 0052 0047 0046 |
| GT | 1.9 JTD 16V | Engine - Gearbox | Bosch Diesel Injection EDC16C39 CF4/EOBD (eng. 1.9/2.4) | • | • | • | • | • | 0029 0058 0059 0060 0061 0055 0030 0043 0014 0063 0054 0053 0037 0002 0020 0052 0047 0046 |
| 159 | 1.8 16V | Comfort | Driver's seat Lear 2 | • | • | • | • | • | 0 |
| 159 | 1.8 JTS TB 16V | Comfort | Driver's seat Lear 2 | • | • | • | • | • | 0 |
| 159 | 1.9 JTS 16V | Comfort | Driver's seat Lear 2 | • | • | • | • | • | 0 |
| 159 | 1.9 MJET 16V | Comfort | Driver's seat Lear 2 | • | • | • | • | | 0 |
| 159 | 1.9 MJET 8V | Comfort | Driver's seat Lear 2 | • | • | • | • | • | 0 |
| 159 | 2.0 JTD 16V | Comfort | Driver's seat Lear 2 | • | • | • | • | • | 0 |
| 159 | 2. 2 JTS 16V | Comfort | Driver's seat Lear 2 | • | • | • | • | • | 0 |
| 159 | 2.4 MJET 20V | Comfort | Driver's seat Lear 2 | • | • | • | • | • | 0 |
| 159 | 3. 2 V6 24V | Comfort | Driver's seat Lear 2 | • | • | • | • | • | 0 |
| BRERA | 1.8 JTS TB 16V | Comfort | Driver's seat Lear 2 | • | • | • | • | • | 0 |
| BRERA | 2. 0 JTD 16V | Comfort | Driver's seat Lear 2 | • | • | • | • | • | 0 |
| BRERA | 2. 2 JTS 16V | Comfort | Driver's seat Lear 2 | • | • | • | • | • | 0 |
| BRERA | 2. 4 MJET 20V | Comfort | Driver's seat Lear 2 | • | • | • | • | • | 0 |
| BRERA | 3. 2 V6 24V | Comfort | Driver's seat Lear 2 | • | • | • | • | | 0 |

| Model | Version | Group | System | ECU info. | Read Codes | Erase Codes | Live Data | Active Test | Specil Function |
|-------|-----------------|-----------------|--------------------------------|--------------|---------------|----------------|--------------|----------------|-------------------------------|
| 159 | 1.8 16V | Comfort | Passenger seat Lear 2 | • | • | • | • | • | 0 |
| 159 | 1.8 JTS TB 16V | Comfort | Passenger seat Lear 2 | • | • | • | • | • | 0 |
| 159 | 1.9 JTS 16V | Comfort | Passenger seat Lear 2 | • | • | • | • | • | 0 |
| 159 | 1.9 MJET 16V | Comfort | Passenger seat Lear 2 | • | • | • | • | • | 0 |
| 159 | 1.9 MJET 8V | Comfort | Passenger seat Lear 2 | • | • | • | • | • | 0 |
| 159 | 2.0 JTD 16V | Comfort | Passenger seat Lear 2 | • | • | • | • | • | 0 |
| 159 | 2.2 JTS 16V | Comfort | Passenger seat Lear 2 | • | • | • | • | • | 0 |
| 159 | 2.4 MJET 20V | Comfort | Passenger seat Lear 2 | • | • | • | • | • | 0 |
| 159 | 3. 2 V6 24V | Comfort | Passenger seat Lear 2 | • | • | • | • | • | 0 |
| BRERA | 1.8 JTS TB 16V | Comfort | Passenger seat Lear 2 | • | • | • | • | • | 0 |
| BRERA | 2.0 JTD 16V | Comfort | Passenger seat Lear 2 | • | • | • | • | • | 0 |
| BRERA | 2. 2 JTS 16V | Comfort | Passenger seat Lear 2 | • | • | • | • | • | 0 |
| BRERA | 2.4 MJET 20V | Comfort | Passenger seat Lear 2 | • | • | • | • | • | 0 |
| BRERA | 3. 2 V6 24V | Comfort | Passenger seat Lear 2 | • | • | • | • | • | 0 |
| 159 | 1.8 16V | Other systems | Front Door G. E. PROCOND | • | • | • | • | • | 0 |
| 159 | 1.8 JTS TB 16V | Other systems | Front Door G.E. PROCOND | • | • | • | • | • | 0 |
| 159 | 1.9 JTS 16V | Other systems | Front Door G.E. PROCOND | • | • | • | • | • | 0 |
| 159 | 1.9 MJET 16V | Other systems | Front Door G.E. PROCOND | • | • | • | • | • | 0 |
| 159 | 1.9 MJET 8V | Other systems | Front Door G.E. PROCOND | • | • | • | • | • | 0 |
| 159 | 2. 0 JTD 16V | Other systems | Front Door G.E. PROCOND | • | • | • | • | • | 0 |
| 159 | 2. 2 JTS 16V | Other systems | Front Door G.E. PROCOND | • | • | • | • | • | 0 |
| 159 | 2. 4 MJET 20V | Other systems | Front Door G.E. PROCOND | • | • | • | • | • | 0 |
| 159 | 3. 2 V6 24V | Other systems | Front Door G.E. PROCOND | • | • | • | • | • | 0 |
| 159 | 1. 8 16V | Other systems | Driver's Door G.E. PROCOND 2 | • | • | • | • | • | 0 |
| 159 | 1.8 JTS TB 16V | Other systems | Driver's Door G.E. PROCOND 2 | • | • | • | • | • | 0 |
| 159 | 1.9 JTS 16V | Other systems | Driver's Door G.E. PROCOND 2 | • | • | • | • | • | 0 |
| 159 | 1.9 MJET 16V | Other systems | Driver's Door G.E. PROCOND 2 | • | • | • | • | • | 0 |
| 159 | 1.9 MJET 8V | Other systems | Driver's Door G.E. PROCOND 2 | • | • | • | • | • | 0 |
| 159 | 2. 0 JTD 16V | Other systems | Driver's Door G.E. PROCOND 2 | • | • | • | • | • | 0 |
| 159 | 2. 2 JTS 16V | Other systems | Driver's Door G.E. PROCOND 2 | • | • | • | • | • | 0 |
| 159 | 2. 4 MJET 20V | Other systems | Driver's Door G.E. PROCOND 2 | • | • | • | • | • | 0 |
| 159 | 3. 2 V6 24V | Other systems | Driver's Door G.E. PROCOND 2 | • | • | • | • | • | 0 |
| 159 | 1. 8 16V | Other systems | Passenger Door G.E. PROCOND 2 | • | • | • | • | • | 0 |
| 159 | 1.8 JTS TB 16V | Other systems | Passenger Door G.E. PROCOND 2 | • | • | • | • | • | 0 |
| 159 | 1. 9 JTS 16V | Other systems | Passenger Door G. E. PROCOND 2 | • | • | • | • | • | 0 |
| 159 | 1.9 MJET 16V | Other systems | Passenger Door G. E. PROCOND 2 | • | • | • | • | • | 0 |
| 159 | 1.9 MJET 8V | Other systems | Passenger Door G. E. PROCOND 2 | • | • | • | • | • | 0 |
| 159 | 2.0 JTD 16V | Other systems | Passenger Door G.E. PROCOND 2 | • | • | • | • | • | 0 |
| 159 | 2. 2 JTS 16V | Other systems | Passenger Door G.E. PROCOND 2 | • | • | • | • | • | 0 |
| 159 | 2.4 MJET 20V | Other systems | Passenger Door G.E. PROCOND 2 | • | • | • | • | • | 0 |
| 159 | 3. 2 V6 24V | Other systems | Passenger Door G.E. PROCOND 2 | • | • | • | • | • | 0 |
| 159 | 1. 8 16V | Instrumentation | Instrument panel Siemens 2 | • | • | • | • | • | 0070 0064 0065 0066 0034 0069 |
| 159 | 1. 8 JTS TB 16V | Instrumentation | Instrument panel Siemens 2 | • | • | • | • | • | 0070 0064 0065 0066 0034 0069 |
| 159 | 1. 9 JTS 16V | Instrumentation | Instrument panel Siemens 2 | • | • | • | • | • | 0070 0064 0065 0066 0034 0069 |
| 159 | 1. 9 MJET 16V | Instrumentation | Instrument panel Siemens 2 | • | • | • | • | • | 0070 0064 0065 0066 0034 0069 |
| 159 | 1.9 MJET 8V | Instrumentation | Instrument panel Siemens 2 | • | • | • | • | • | 0070 0064 0065 0066 0034 0069 |
| 159 | 2. 0 JTD 16V | Instrumentation | Instrument panel Siemens 2 | • | • | • | • | • | 0070 0064 0065 0066 0034 0069 |
| 159 | 2. 2 JTS 16V | Instrumentation | Instrument panel Siemens 2 | • | | • | • | | 0070 0064 0065 0066 0034 0069 |

| Model | Version | Group | System | ECU info. | Read Codes | Erase Codes | Live Data | Active Test | Specil Function |
|-------|-----------------|-----------------|-------------------------------------|-------------|---------------|----------------|--------------|----------------|-------------------------------|
| 159 | 2. 4 MJET 20V | Instrumentation | Instrument panel Siemens 2 | • | 00403 | • | Data | 1050 | 0070 0064 0065 0066 0034 0069 |
| 159 | 3. 2 V6 24V | Instrumentation | Instrument panel Siemens 2 | | | • | • | • | 0070 0064 0065 0066 0034 0069 |
| BRERA | 1. 8 JTS TB 16V | Instrumentation | Instrument panel Siemens 2 | | | • | • | • | 0070 0064 0065 0066 0034 0069 |
| BRERA | 2. 0 JTD 16V | Instrumentation | Instrument panel Siemens 2 | | | | • | • | 0070 0064 0065 0066 0034 0069 |
| BRERA | 2. 2 JTS 16V | Instrumentation | Instrument panel Siemens 2 | | | | • | | 0070 0064 0065 0066 0034 0069 |
| BRERA | 2. 4 MJET 20V | Instrumentation | Instrument panel Siemens 2 | | | | | | 0070 0064 0065 0066 0034 0069 |
| BRERA | 3. 2 V6 24V | Instrumentation | Instrument panel Siemens 2 | | | | • | | 0070 0064 0065 0066 0034 0069 |
| 159 | 1. 8 16V | Instrumentation | Marelli 3 Connect (multi-model) | | | • | | | O |
| 159 | 1. 8 JTS TB 16V | Instrumentation | Marelli 3 Connect (multi-model) | | | | • | | 0 |
| 159 | 1. 9 JTS 16V | Instrumentation | Marelli 3 Connect (multi-model) | | | | • | | 0 |
| 159 | 1. 9 MJET 16V | Instrumentation | | | | | • | | 0 |
| 159 | | | Marelli 3 Connect (multi-model) | | _ | | | | 0 |
| | 1. 9 MJET 8V | Instrumentation | Marelli 3 Connect (multi-model) | | | | | | 0 |
| 159 | 2. 0 JTD 16V | Instrumentation | Marelli 3 Connect (multi-model) | + <u> </u> | | | • | | 0 |
| 159 | 2. 2 JTS 16V | Instrumentation | Marelli 3 Connect (multi-model) | • | | | | | |
| 159 | 2. 4 MJET 20V | Instrumentation | Marelli 3 Connect (multi-model) | • | • | • | • | • | 0 |
| 159 | 3. 2 V6 24V | Instrumentation | Marelli 3 Connect (multi-model) | • | • | • | • | • | 0 |
| BRERA | 1. 8 JTS TB 16V | Instrumentation | Marelli 3 Connect (multi-model) | • | • | • | • | • | 0 |
| BRERA | 2. 0 JTD 16V | Instrumentation | Marelli 3 Connect (multi-model) | • | • | • | • | • | 0 |
| BRERA | 2. 2 JTS 16V | Instrumentation | Marelli 3 Connect (multi-model) | • | • | • | • | • | 0 |
| BRERA | 2.4 MJET 20V | Instrumentation | Marelli 3 Connect (multi-model) | • | • | • | • | • | 0 |
| BRERA | 3. 2 V6 24V | Instrumentation | Marelli 3 Connect (multi-model) | • | • | • | • | • | 0 |
| 159 | 1.8 16V | Other systems | Litronic discharge headlamp (left) | • | • | • | • | • | 0 |
| 159 | 1.8 JTS TB 16V | Other systems | Litronic discharge headlamp (left) | • | • | • | • | • | 0 |
| 159 | 1.9 JTS 16V | Other systems | Litronic discharge headlamp (left) | • | • | • | • | • | 0 |
| 159 | 1.9 MJET 16V | Other systems | Litronic discharge headlamp (left) | • | • | • | • | • | 0 |
| 159 | 1.9 MJET 8V | Other systems | Litronic discharge headlamp (left) | • | • | • | • | • | 0 |
| 159 | 2.0 JTD 16V | Other systems | Litronic discharge headlamp (left) | • | • | • | • | • | 0 |
| 159 | 2.2 JTS 16V | Other systems | Litronic discharge headlamp (left) | • | • | • | • | • | 0 |
| 159 | 2.4 MJET 20V | Other systems | Litronic discharge headlamp (left) | • | • | • | • | • | 0 |
| 159 | 3. 2 V6 24V | Other systems | Litronic discharge headlamp (left) | • | • | • | • | • | 0 |
| BRERA | 1.8 JTS TB 16V | Other systems | Litronic discharge headlamp (left) | • | • | • | • | • | 0 |
| BRERA | 2.0 JTD 16V | Other systems | Litronic discharge headlamp (left) | • | • | • | • | • | 0 |
| BRERA | 2. 2 JTS 16V | Other systems | Litronic discharge headlamp (left) | • | • | • | • | • | 0 |
| BRERA | 2.4 MJET 20V | Other systems | Litronic discharge headlamp (left) | • | • | • | • | • | 0 |
| BRERA | 3. 2 V6 24V | Other systems | Litronic discharge headlamp (left) | • | • | • | • | • | 0 |
| 159 | 1.8 16V | Other systems | Litronic discharge headlamp (right) | • | • | • | • | 0 | 0 |
| 159 | 1.8 JTS TB 16V | Other systems | Litronic discharge headlamp (right) | • | • | • | • | 0 | 0 |
| 159 | 1.9 JTS 16V | Other systems | Litronic discharge headlamp (right) | • | • | • | • | 0 | 0 |
| 159 | 1.9 MJET 16V | Other systems | Litronic discharge headlamp (right) | • | • | • | • | 0 | 0 |
| 159 | 1.9 MJET 8V | Other systems | Litronic discharge headlamp (right) | • | • | • | • | 0 | 0 |
| 159 | 2. 0 JTD 16V | Other systems | Litronic discharge headlamp (right) | • | • | • | • | 0 | 0 |
| 159 | 2. 2 JTS 16V | Other systems | Litronic discharge headlamp (right) | • | • | • | • | 0 | 0 |
| 159 | 2. 4 MJET 20V | Other systems | Litronic discharge headlamp (right) | • | • | • | • | 0 | 0 |
| 159 | 3. 2 V6 24V | Other systems | Litronic discharge headlamp (right) | | | • | • | 0 | 0 |
| BRERA | 1. 8 JTS TB 16V | Other systems | Litronic discharge headlamp (right) | | | • | • | 0 | 0 |
| BRERA | 2. 0 JTD 16V | Other systems | Litronic discharge headlamp (right) | | • | • | • | 0 | 0 |
| BRERA | 2. 2 JTS 16V | Other systems | Litronic discharge headlamp (right) | • | | • | • | 0 | 0 |
| | | | | | | | | | |
| BRERA | 2.4 MJET 20V | Other systems | Litronic discharge headlamp (right) | • | • | • | • | 0 | 0 |

| Model | Version | Group | System | ECU info. | Read Codes | Erase Codes | Live Data | Active Test | Specil Function |
|-------|-----------------|------------------|-----------------------------------------------------------|--------------|---------------|----------------|--------------|----------------|-----------------|
| BRERA | 3. 2 V6 24V | Other systems | Litronic discharge headlamp (right) | • | • | • | • | 0 | 0 |
| 159 | 1.8 16V | Comfort | Climate control Delphi 2 (Single-zone) | • | • | • | • | • | 0 |
| 159 | 1. 8 JTS TB 16V | Comfort | Climate control Delphi 2 (Single-zone) | • | • | • | • | • | 0 |
| 159 | 1. 9 JTS 16V | Comfort | Climate control Delphi 2 (Single-zone) | • | • | • | • | • | 0 |
| 159 | 1. 9 MJET 16V | Comfort | Climate control Delphi 2 (Single-zone) | • | • | • | • | • | 0 |
| 159 | 1. 9 MJET 8V | Comfort | Climate control Delphi 2 (Single-zone) | • | • | • | • | | 0 |
| 159 | 2. 0 JTD 16V | Comfort | Climate control Delphi 2 (Single-zone) | • | • | • | • | | 0 |
| 159 | 2. 2 JTS 16V | Comfort | Climate control Delphi 2 (Single-zone) | | | • | • | | 0 |
| 159 | 2. 4 MJET 20V | Comfort | Climate control Delphi 2 (Single-zone) | | | • | • | | 0 |
| 159 | 3. 2 V6 24V | Comfort | Climate control Delphi 2 (Single-zone) | | | • | | | 0 |
| BRERA | 1. 8 JTS TB 16V | Comfort | Climate control Delphi 2 (Single-zone) | | | • | • | | 0 |
| BRERA | 2. 0 JTD 16V | Comfort | Climate control Delphi 2 (Single-zone) | | | | | | 0 |
| BRERA | 2. 2 JTS 16V | Comfort | Climate control Delphi 2 (Single-zone) | | | | | | 0 |
| BRERA | 2. 4 MJET 20V | Comfort | Climate control Delphi 2 (Single-zone) | | | | | | 0 |
| BRERA | 3. 2 V6 24V | Comfort | Climate control Delphi 2 (Single-zone) | | | | | | 0 |
| 159 | 1. 8 16V | Other systems | Boot G. E. PROCOND 2 | | | | | | 0 |
| 159 | | | | | | | | | 0 |
| | 1. 8 JTS TB 16V | Other systems | Boot G. E. PROCOND 2 | - | - | | | | |
| 159 | 1. 9 JTS 16V | Other systems | Boot G. E. PROCOND 2 | - | _ | • | • | | 0 |
| 159 | 1. 9 MJET 16V | Other systems | Boot G. E. PROCOND 2 | • | • | • | • | • | 0 |
| 159 | 1. 9 MJET 8V | Other systems | Boot G. E. PROCOND 2 | • | • | • | • | • | 0 |
| 159 | 2. 0 JTD 16V | Other systems | Boot G. E. PROCOND 2 | • | • | • | • | • | 0 |
| 159 | 2. 2 JTS 16V | Other systems | Boot G. E. PROCOND 2 | • | • | • | • | • | 0 |
| 159 | 2. 4 MJET 20V | Other systems | Boot G. E. PROCOND 2 | • | • | • | • | • | 0 |
| 159 | 3. 2 V6 24V | Other systems | Boot G. E. PROCOND 2 | • | • | • | • | • | 0 |
| 159 | 1.8 16V | Comfort | Climate control Delphi (Two/Three-zone) | • | • | • | • | • | 0 |
| 159 | 1.8 JTS TB 16V | Comfort | Climate control Delphi (Two/Three-zone) | • | • | • | • | • | 0 |
| 159 | 1.9 JTS 16V | Comfort | Climate control Delphi (Two/Three-zone) | • | • | • | • | • | 0 |
| 159 | 1.9 MJET 16V | Comfort | Climate control Delphi (Two/Three-zone) | • | • | • | • | • | 0 |
| 159 | 1.9 MJET 8V | Comfort | Climate control Delphi (Two/Three-zone) | • | • | • | • | • | 0 |
| 159 | 2.0 JTD 16V | Comfort | Climate control Delphi (Two/Three-zone) | • | • | • | • | • | 0 |
| 159 | 2. 2 JTS 16V | Comfort | Climate control Delphi (Two/Three-zone) | • | • | • | • | • | 0 |
| 159 | 2.4 MJET 20V | Comfort | Climate control Delphi (Two/Three-zone) | • | • | • | • | • | 0 |
| 159 | 3.2 V6 24V | Comfort | Climate control Delphi (Two/Three-zone) | • | • | • | • | • | 0 |
| BRERA | 1.8 JTS TB 16V | Comfort | Climate control Delphi (Two/Three-zone) | • | • | • | • | • | 0 |
| BRERA | 2.0 JTD 16V | Comfort | Climate control Delphi (Two/Three-zone) | • | • | • | • | • | 0 |
| BRERA | 2. 2 JTS 16V | Comfort | Climate control Delphi (Two/Three-zone) | • | • | • | • | • | 0 |
| BRERA | 2.4 MJET 20V | Comfort | Climate control Delphi (Two/Three-zone) | • | • | • | • | • | 0 |
| BRERA | 3. 2 V6 24V | Comfort | Climate control Delphi (Two/Three-zone) | • | • | • | • | • | 0 |
| 159 | 1.9 JTS 16V | Engine - Gearbox | Bosch Motronic Injection MeD7.6.1 CF4/EOBD (eng. 1.9/2.2) | • | • | • | • | • | 0 |
| 159 | 2. 2 JTS 16V | Engine - Gearbox | Bosch Motronic Injection MeD7.6.1 CF4/EOBD (eng. 1.9/2.2) | • | • | • | • | • | 0 |
| BRERA | 2. 2 JTS 16V | Engine - Gearbox | Bosch Motronic Injection MeD7.6.1 CF4/EOBD (eng. 1.9/2.2) | • | • | • | • | • | 0 |
| 159 | 1.8 16V | Safety | Air Bag TRW MY 03 (2F-2P-2L-2T-1G-I) | • | • | • | • | • | 0 |
| 159 | 1.8 JTS TB 16V | Safety | Air Bag TRW MY 03 (2F-2P-2L-2T-1G-I) | • | • | • | • | • | 0 |
| 159 | 1. 9 JTS 16V | Safety | Air Bag TRW MY 03 (2F-2P-2L-2T-1G-I) | • | • | • | • | • | 0 |
| 159 | 1.9 MJET 16V | Safety | Air Bag TRW MY 03 (2F-2P-2L-2T-1G-I) | • | • | • | • | • | 0 |

| Model | Version | Group | System | ECU info. | Read Codes | Erase Codes | Live Data | Active Test | Specil Function |
|-------|-------------------|--------|--------------------------------------|--------------|---------------|----------------|--------------|----------------|-----------------|
| 159 | 1.9 MJET 8V | Safety | Air Bag TRW MY 03 (2F-2P-2L-2T-1G-I) | • | • | • | • | • | 0 |
| 159 | 2. 0 JTD 16V | Safety | Air Bag TRW MY 03 (2F-2P-2L-2T-1G-I) | • | • | • | • | • | 0 |
| 159 | 2. 2 JTS 16V | Safety | Air Bag TRW MY 03 (2F-2P-2L-2T-1G-I) | • | • | • | • | • | 0 |
| 159 | 2. 4 MJET 20V | Safety | Air Bag TRW MY 03 (2F-2P-2L-2T-1G-I) | • | • | • | • | • | 0 |
| 159 | 3. 2 V6 24V | Safety | Air Bag TRW MY 03 (2F-2P-2L-2T-1G-I) | • | • | • | • | • | 0 |
| BRERA | 1.8 JTS TB 16V | Safety | Air Bag TRW MY 03 (2F-2P-2L-2T-1G-I) | • | • | • | • | • | 0 |
| BRERA | 2.0 JTD 16V | Safety | Air Bag TRW MY 03 (2F-2P-2L-2T-1G-I) | • | • | • | • | • | 0 |
| BRERA | 2. 2 JTS 16V | Safety | Air Bag TRW MY 03 (2F-2P-2L-2T-1G-I) | • | • | • | • | • | 0 |
| BRERA | 2. 4 MJET 20V | Safety | Air Bag TRW MY 03 (2F-2P-2L-2T-1G-I) | • | • | • | • | • | 0 |
| BRERA | 3. 2 V6 24V | Safety | Air Bag TRW MY 03 (2F-2P-2L-2T-1G-I) | • | • | • | • | • | 0 |
| 159 | 1.8 16V | Safety | Air Bag TRW MY 03 (2F-2P-2L-2T-2G-I) | • | • | • | • | • | 0 |
| 159 | 1.8 JTS TB 16V | Safety | Air Bag TRW MY 03 (2F-2P-2L-2T-2G-I) | • | • | • | • | • | 0 |
| 159 | 1. 9 JTS 16V | Safety | Air Bag TRW MY 03 (2F-2P-2L-2T-2G-I) | • | • | • | • | • | 0 |
| 159 | 1.9 MJET 16V | Safety | Air Bag TRW MY 03 (2F-2P-2L-2T-2G-I) | • | • | • | • | • | 0 |
| 159 | 1.9 MJET 8V | Safety | Air Bag TRW MY 03 (2F-2P-2L-2T-2G-I) | • | • | • | • | • | 0 |
| 159 | 2. 0 JTD 16V | Safety | Air Bag TRW MY 03 (2F-2P-2L-2T-2G-I) | • | • | • | • | • | 0 |
| 159 | 2. 2 JTS 16V | Safety | Air Bag TRW MY 03 (2F-2P-2L-2T-2G-I) | • | • | • | • | • | 0 |
| 159 | 2. 4 MJET 20V | Safety | Air Bag TRW MY 03 (2F-2P-2L-2T-2G-I) | • | • | • | • | • | 0 |
| 159 | 3. 2 V6 24V | Safety | Air Bag TRW MY 03 (2F-2P-2L-2T-2G-I) | • | • | • | • | • | 0 |
| BRERA | 1. 8 JTS TB 16V | Safety | Air Bag TRW MY 03 (2F-2P-2L-2T-2G-I) | • | • | • | • | • | 0 |
| BRERA | 2. 0 JTD 16V | Safety | Air Bag TRW MY 03 (2F-2P-2L-2T-2G-I) | • | • | • | • | • | 0 |
| BRERA | 2. 2 JTS 16V | Safety | Air Bag TRW MY 03 (2F-2P-2L-2T-2G-I) | • | • | • | | • | 0 |
| BRERA | 2. 4 MJET 20V | Safety | Air Bag TRW MY 03 (2F-2P-2L-2T-2G-I) | • | • | • | • | • | 0 |
| BRERA | 3. 2 V6 24V | Safety | Air Bag TRW MY 03 (2F-2P-2L-2T-2G-I) | • | • | • | • | • | 0 |
| 147 | 1. 6 TS 16V 105CV | Safety | Bosch 8 ASR ABS | • | • | • | • | • | 0 |
| 147 | 1. 6 TS 16V 120CV | Safety | Bosch 8 ASR ABS | • | • | • | • | • | 0 |
| 147 | 1. 9 JTD | Safety | Bosch 8 ASR ABS | • | • | • | • | • | 0 |
| 147 | 1. 9 JTD 16V | Safety | Bosch 8 ASR ABS | • | • | • | • | • | 0 |
| 147 | 2. 0 TS 16V | Safety | Bosch 8 ASR ABS | • | • | • | • | • | 0 |
| 147 | GTA 3.2 V6 | Safety | Bosch 8 ASR ABS | • | • | • | • | • | 0 |
| 147 | GTA SELESPEED | Safety | Bosch 8 ASR ABS | • | • | • | • | • | 0 |
| 147 | SELESPEED | Safety | Bosch 8 ASR ABS | • | • | • | • | • | 0 |
| GT | 1. 8 TS 16V | Safety | Bosch 8 ASR ABS | • | • | • | • | • | 0 |
| GT | 1. 9 JTD 16V | Safety | Bosch 8 ASR ABS | • | • | • | • | • | 0 |
| GT | 3. 2 V6 24V | Safety | Bosch 8 ASR ABS | • | • | • | • | • | 0 |
| GT | JTS 2.0 | Safety | Bosch 8 ASR ABS | • | • | • | • | • | 0 |
| 159 | 1. 8 16V | Safety | Body Computer Marelli 3 | • | • | • | • | • | 0 |
| 159 | 1.8 JTS TB 16V | Safety | Body Computer Marelli 3 | • | • | • | • | • | 0 |
| 159 | 1.9 JTS 16V | Safety | Body Computer Marelli 3 | • | • | • | • | | 0 |
| 159 | 1.9 MJET 16V | Safety | Body Computer Marelli 3 | • | • | • | • | • | 0 |
| 159 | 1.9 MJET 8V | Safety | Body Computer Marelli 3 | • | • | • | • | • | 0 |
| 159 | 2. 0 JTD 16V | Safety | Body Computer Marelli 3 | • | • | • | • | • | 0 |
| 159 | 2. 2 JTS 16V | Safety | Body Computer Marelli 3 | • | • | • | • | • | 0 |
| 159 | 2.4 MJET 20V | Safety | Body Computer Marelli 3 | • | • | • | • | • | 0 |
| 159 | 3. 2 V6 24V | Safety | Body Computer Marelli 3 | • | • | • | • | • | 0 |
| 159 | 1.8 16V | Safety | Steering Lock TRW 2 | • | • | • | • | • | 0 |
| 159 | 1.8 JTS TB 16V | Safety | Steering Lock TRW 2 | • | • | • | • | • | 0 |
| 159 | 1.9 JTS 16V | Safety | Steering Lock TRW 2 | • | • | • | • | • | 0 |

| Model | Version | Group | System | ECU info. | Read Codes | Erase Codes | Live Data | Active Test | Specil Function |
|-------|----------------|--------|---------------------------------|-----------|---------------|----------------|--------------|----------------|---------------------------------------|
| 159 | 1.9 MJET 16V | Safety | Steering Lock TRW 2 | • | • | • | • | • | 0 |
| 159 | 1.9 MJET 8V | Safety | Steering Lock TRW 2 | • | • | • | • | • | 0 |
| 159 | 2.0 JTD 16V | Safety | Steering Lock TRW 2 | • | • | • | • | • | 0 |
| 159 | 2. 2 JTS 16V | Safety | Steering Lock TRW 2 | • | • | • | • | • | 0 |
| 159 | 2.4 MJET 20V | Safety | Steering Lock TRW 2 | • | • | • | • | • | 0 |
| 159 | 3. 2 V6 24V | Safety | Steering Lock TRW 2 | • | • | • | • | • | 0 |
| BRERA | 1.8 JTS TB 16V | Safety | Steering Lock TRW 2 | • | • | • | • | • | 0 |
| BRERA | 2.0 JTD 16V | Safety | Steering Lock TRW 2 | • | • | • | • | • | 0 |
| BRERA | 2. 2 JTS 16V | Safety | Steering Lock TRW 2 | • | • | • | • | • | 0 |
| BRERA | 2.4 MJET 20V | Safety | Steering Lock TRW 2 | • | • | • | • | • | 0 |
| BRERA | 3. 2 V6 24V | Safety | Steering Lock TRW 2 | • | • | • | • | • | 0 |
| 159 | 1.8 16V | Safety | Electronic Key TRW (Teg Reader) | • | • | • | • | • | 0 |
| 159 | 1.8 JTS TB 16V | Safety | Electronic Key TRW (Teg Reader) | • | • | • | • | • | 0 |
| 159 | 1.9 JTS 16V | Safety | Electronic Key TRW (Teg Reader) | • | • | • | • | • | 0 |
| 159 | 1.9 MJET 16V | Safety | Electronic Key TRW (Teg Reader) | • | • | • | • | • | 0 |
| 159 | 1.9 MJET 8V | Safety | Electronic Key TRW (Teg Reader) | • | • | • | • | • | 0 |
| 159 | 2.0 JTD 16V | Safety | Electronic Key TRW (Teg Reader) | • | • | • | • | • | 0 |
| 159 | 2. 2 JTS 16V | Safety | Electronic Key TRW (Teg Reader) | • | • | • | • | • | 0 |
| 159 | 2.4 MJET 20V | Safety | Electronic Key TRW (Teg Reader) | • | • | • | • | • | 0 |
| 159 | 3. 2 V6 24V | Safety | Electronic Key TRW (Teg Reader) | • | • | • | • | • | 0 |
| BRERA | 1.8 JTS TB 16V | Safety | Electronic Key TRW (Teg Reader) | • | • | • | • | • | 0 |
| BRERA | 2.0 JTD 16V | Safety | Electronic Key TRW (Teg Reader) | • | • | • | • | • | 0 |
| BRERA | 2. 2 JTS 16V | Safety | Electronic Key TRW (Teg Reader) | • | • | • | • | • | 0 |
| BRERA | 2.4 MJET 20V | Safety | Electronic Key TRW (Teg Reader) | • | • | • | • | • | 0 |
| BRERA | 3. 2 V6 24V | Safety | Electronic Key TRW (Teg Reader) | • | • | • | • | • | 0 |
| 159 | 1.8 16V | Safety | Tyre Pressure Control TRW 2 | • | • | • | • | • | 0007 0014 0005 0084 0012 0013 0006 |
| 159 | 1.8 JTS TB 16V | Safety | Tyre Pressure Control TRW 2 | • | • | • | • | • | 0007 0014 0005 0084 0012 0013 0006 |
| 159 | 1. 9 JTS 16V | Safety | Tyre Pressure Control TRW 2 | • | • | • | • | • | 0007 0014 0005 0084 0012 0013 0006 |
| 159 | 1.9 MJET 16V | Safety | Tyre Pressure Control TRW 2 | • | • | • | • | • | 0007 0014 0005 0084 0012 0013 0006 |
| 159 | 1.9 MJET 8V | Safety | Tyre Pressure Control TRW 2 | • | • | • | • | • | 0007 0014 0005 0084 0012 0013 0006 |
| 159 | 2.0 JTD 16V | Safety | Tyre Pressure Control TRW 2 | • | • | • | • | • | 0007 0014 0005 0084 0012 0013 0006 |
| 159 | 2. 2 JTS 16V | Safety | Tyre Pressure Control TRW 2 | • | • | • | • | • | 0007 0014 0005 0084 0012 0013 0006 |
| 159 | 2.4 MJET 20V | Safety | Tyre Pressure Control TRW 2 | • | • | • | • | • | 0007 0014 0005 0084 0012 0013 0006 |
| 159 | 3. 2 V6 24V | Safety | Tyre Pressure Control TRW 2 | • | • | • | • | • | 0007 0014 0005 0084 0012 0013 0006 |
| BRERA | 1.8 JTS TB 16V | Safety | Tyre Pressure Control TRW 2 | • | • | • | • | • | 0007 0014 0005 0084 0012 0013 0006 |
| BRERA | 2.0 JTD 16V | Safety | Tyre Pressure Control TRW 2 | • | • | • | • | • | 0007 0014 0005 0084 0012 0013 0006 |

| Model | Version | Group | System | ECU info. | Read Codes | Erase Codes | Live Data | Active Test | Specil Function |
|--------------------|------------------|------------------|------------------------------------|--------------|---------------|----------------|--------------|----------------|------------------------------------|
| BRERA | 2. 2 JTS 16V | Safety | Tyre Pressure Control TRW 2 | • | • | • | • | • | 0007 0014 0005 0084 0012 0013 0006 |
| BRERA | 2. 4 MJET 20V | Safety | Tyre Pressure Control TRW 2 | • | • | • | • | • | 0007 0014 0005 0084 0012 0013 0006 |
| BRERA | 3. 2 V6 24V | Safety | Tyre Pressure Control TRW 2 | • | • | • | • | • | 0007 0014 0005 0084 0012 0013 0006 |
| 159 | 1.9 MJET 16V | Engine - Gearbox | Automatic Gearbox AISIN AF40-6 | • | • | • | • | • | 0 |
| 159 | 1.9 MJET 8V | Engine - Gearbox | Automatic Gearbox AISIN AF40-6 | • | • | • | • | • | 0 |
| 159 | 2.4 MJET 20V | Engine - Gearbox | Automatic Gearbox AISIN AF40-6 | • | • | • | • | • | 0 |
| 159 | 3. 2 V6 24V | Engine - Gearbox | Automatic Gearbox AISIN AF40-6 | • | • | • | • | • | 0 |
| BRERA | 2.4 MJET 20V | Engine - Gearbox | Automatic Gearbox AISIN AF40-6 | • | • | • | • | • | 0 |
| BRERA | 3. 2 V6 24V | Engine - Gearbox | Automatic Gearbox AISIN AF40-6 | • | • | • | • | • | 0 |
| GIULIETTA (191) | 1.4 TURBO 16V | Instrumentation | Marelli/Microsoft Convergence (EP) | • | • | • | • | • | 0 |
| GIULIETTA (191) | 1.6 MJET 16V | Instrumentation | Marelli/Microsoft Convergence (EP) | • | • | • | • | • | 0 |
| GIULIETTA (191) | 1.8 JTS TB 16V | Instrumentation | Marelli/Microsoft Convergence (EP) | • | • | • | • | • | 0 |
| GIULIETTA (191) | 2.0 MJET 16V | Instrumentation | Marelli/Microsoft Convergence (EP) | • | • | • | • | • | 0 |
| MITO | 1.3 MJET 16V | Instrumentation | Marelli/Microsoft Convergence (EP) | • | • | • | • | • | 0 |
| MITO | 1. 4 16V | Instrumentation | Marelli/Microsoft Convergence (EP) | • | • | • | • | • | 0 |
| MITO | 1.4 TURBO 16V | Instrumentation | Marelli/Microsoft Convergence (EP) | • | • | • | • | • | 0 |
| MITO | 1.6 MJET 16V | Instrumentation | Marelli/Microsoft Convergence (EP) | • | • | • | • | • | 0 |
| 147 | 1.6 TS 16V 105CV | Instrumentation | Marelli/Microsoft Convergence | • | • | • | • | • | 0 |
| 147 | 1.6 TS 16V 120CV | Instrumentation | Marelli/Microsoft Convergence | • | • | • | • | • | 0 |
| 147 | 1.9 JTD | Instrumentation | Marelli/Microsoft Convergence | • | • | • | • | • | 0 |
| 147 | 1.9 JTD 16V | Instrumentation | Marelli/Microsoft Convergence | • | • | • | • | • | 0 |
| 147 | 2.0 TS 16V | Instrumentation | Marelli/Microsoft Convergence | • | • | • | • | • | 0 |
| 147 | GTA 3.2 V6 | Instrumentation | Marelli/Microsoft Convergence | • | • | • | • | • | 0 |
| 147 | GTA SELESPEED | Instrumentation | Marelli/Microsoft Convergence | • | • | • | • | • | 0 |
| 147 | SELESPEED | Instrumentation | Marelli/Microsoft Convergence | • | • | • | • | • | 0 |
| 159 | 1.8 16V | Instrumentation | Marelli/Microsoft Convergence | • | • | • | • | • | 0 |
| 159 | 1.8 JTS TB 16V | Instrumentation | Marelli/Microsoft Convergence | • | • | • | • | • | 0 |
| 159 | 1.9 JTS 16V | Instrumentation | Marelli/Microsoft Convergence | • | • | • | • | • | 0 |
| 159 | 1.9 MJET 16V | Instrumentation | Marelli/Microsoft Convergence | • | • | • | • | • | 0 |
| 159 | 1.9 MJET 8V | Instrumentation | Marelli/Microsoft Convergence | • | • | • | • | • | 0 |
| 159 | 2.0 JTD 16V | Instrumentation | Marelli/Microsoft Convergence | • | • | • | • | • | 0 |
| 159 | 2. 2 JTS 16V | Instrumentation | Marelli/Microsoft Convergence | • | • | • | • | • | 0 |
| 159 | 2.4 MJET 20V | Instrumentation | Marelli/Microsoft Convergence | • | • | • | • | • | 0 |
| 159 | 3. 2 V6 24V | Instrumentation | Marelli/Microsoft Convergence | • | • | • | • | • | 0 |
| BRERA | 1.8 JTS TB 16V | Instrumentation | Marelli/Microsoft Convergence | • | • | • | • | • | 0 |
| BRERA | 2.0 JTD 16V | Instrumentation | Marelli/Microsoft Convergence | • | • | • | • | • | 0 |
| BRERA | 2. 2 JTS 16V | Instrumentation | Marelli/Microsoft Convergence | • | • | • | • | • | 0 |
| BRERA | 2. 4 MJET 20V | Instrumentation | Marelli/Microsoft Convergence | • | • | • | • | • | 0 |
| BRERA | 3. 2 V6 24V | Instrumentation | Marelli/Microsoft Convergence | • | • | • | • | • | 0 |
| GT | 1. 8 TS 16V | Instrumentation | Marelli/Microsoft Convergence | • | • | • | • | • | 0 |
| GT | 1.9 JTD 16V | Instrumentation | Marelli/Microsoft Convergence | • | • | • | | • | 0 |

| Model | Version | Group | System | ECU | Read | Erase | Live | Active | Specil Function |
|-------|------------------|------------------|-------------------------------------------------------|-------|-------|-------|------|--------|--------------------------------------------|
| | | | | info. | Codes | Codes | Data | Test | • |
| GT | 3. 2 V6 24V | Instrumentation | Marelli/Microsoft Convergence | • | • | • | • | • | 0 |
| GT | JTS 2.0 | Instrumentation | Marelli/Microsoft Convergence | • | • | • | • | • | 0 |
| MITO | 1. 3 MJET 16V | Comfort | Denso Climate Control (EP) | • | • | • | • | • | 0 |
| MITO | 1. 4 16V | Comfort | Denso Climate Control (EP) | • | • | • | • | • | 0 |
| MITO | 1. 4 TURBO 16V | Comfort | Denso Climate Control (EP) | • | • | • | • | • | 0 |
| MITO | 1. 6 MJET 16V | Comfort | Denso Climate Control (EP) | • | • | • | • | • | 0 |
| MITO | 1. 3 MJET 16V | Comfort | Denso Heater (EP) | • | • | • | • | • | 0 |
| MITO | 1.6 MJET 16V | Comfort | Denso Heater (EP) | • | • | • | • | • | 0 |
| MITO | 1.3 MJET 16V | Safety | TRW Tyre Pressure Control (EP) | • | • | • | • | • | 0007 0005 0084 0012 0013 0006 0041 0014 |
| MITO | 1. 4 16V | Safety | TRW Tyre Pressure Control (EP) | • | • | • | • | • | 0007 0005 0084 0012 0013 0006 0041 0014 |
| MITO | 1.4 TURBO 16V | Safety | TRW Tyre Pressure Control (EP) | • | • | • | • | • | 0007 0005 0084 0012 0013 0006 0041 0014 |
| MITO | 1.6 MJET 16V | Safety | TRW Tyre Pressure Control (EP) | • | • | • | • | • | 0007 0005 0084 0012 0013 0006 0041 0014 |
| BRERA | 1.8 JTS TB 16V | Safety | Body Computer Marelli 4 | • | • | • | • | • | 0 |
| BRERA | 2.0 JTD 16V | Safety | Body Computer Marelli 4 | • | • | • | • | • | 0 |
| BRERA | 2. 2 JTS 16V | Safety | Body Computer Marelli 4 | • | • | • | • | • | 0 |
| BRERA | 2.4 MJET 20V | Safety | Body Computer Marelli 4 | • | • | • | • | • | 0 |
| BRERA | 3. 2 V6 24V | Safety | Body Computer Marelli 4 | • | • | • | • | • | 0 |
| 159 | 3. 2 V6 24V | Engine - Gearbox | Bosch Motronic MeD7.6.2 CF4/EOBD injection (eng. 3.2) | • | • | • | • | • | 0 |
| BRERA | 3. 2 V6 24V | Engine - Gearbox | Bosch Motronic MeD7.6.2 CF4/EOBD injection (eng. 3.2) | • | • | • | • | • | 0 |
| BRERA | 1.8 JTS TB 16V | Other systems | G.E. PROCOND 4 Driver's Door | • | • | • | • | • | 0 |
| BRERA | 2. 0 JTD 16V | Other systems | G.E. PROCOND 4 Driver's Door | • | • | • | • | • | 0 |
| BRERA | 2. 2 JTS 16V | Other systems | G.E. PROCOND 4 Driver's Door | • | • | • | • | • | 0 |
| BRERA | 2. 4 MJET 20V | Other systems | G.E. PROCOND 4 Driver's Door | • | • | • | • | • | 0 |
| BRERA | 3. 2 V6 24V | Other systems | G.E. PROCOND 4 Driver's Door | • | • | • | • | • | 0 |
| BRERA | 1.8 JTS TB 16V | Safety | WEBASTO hood/luggage compartment | • | • | • | • | • | 0 |
| BRERA | 2.0 JTD 16V | Safety | WEBASTO hood/luggage compartment | • | • | • | • | • | 0 |
| BRERA | 2. 2 JTS 16V | Safety | WEBASTO hood/luggage compartment | • | • | • | • | • | 0 |
| BRERA | 2.4 MJET 20V | Safety | WEBASTO hood/luggage compartment | • | • | • | • | • | 0 |
| BRERA | 3. 2 V6 24V | Safety | WEBASTO hood/luggage compartment | • | • | • | • | • | 0 |
| BRERA | 1.8 JTS TB 16V | Other systems | G.E. PROCOND 4 Passenger's Door | • | • | • | • | • | 0 |
| BRERA | 2.0 JTD 16V | Other systems | G.E. PROCOND 4 Passenger's Door | • | • | • | • | • | 0 |
| BRERA | 2. 2 JTS 16V | Other systems | G.E. PROCOND 4 Passenger's Door | • | • | • | • | • | 0 |
| BRERA | 2.4 MJET 20V | Other systems | G.E. PROCOND 4 Passenger's Door | • | • | • | • | • | 0 |
| BRERA | 3. 2 V6 24V | Other systems | G.E. PROCOND 4 Passenger's Door | • | • | • | • | • | 0 |
| 159 | 1.8 16V | Engine - Gearbox | Siemens VDO CF4/EOBD injection (eng. 1.8) | • | • | • | • | • | 0 |
| 147 | 1.6 TS 16V 105CV | Instrumentation | Marelli/Microsoft C3 Convergence | • | • | • | • | • | 0 |
| 147 | 1.6 TS 16V 120CV | Instrumentation | Marelli/Microsoft C3 Convergence | • | • | • | • | • | 0 |
| 147 | 1.9 JTD | Instrumentation | Marelli/Microsoft C3 Convergence | • | • | • | • | • | 0 |
| 147 | 1.9 JTD 16V | Instrumentation | Marelli/Microsoft C3 Convergence | • | • | • | • | • | 0 |
| 147 | 2.0 TS 16V | Instrumentation | Marelli/Microsoft C3 Convergence | • | • | • | • | • | 0 |
| 147 | GTA 3.2 V6 | Instrumentation | Marelli/Microsoft C3 Convergence | • | • | • | • | • | 0 |
| 147 | GTA SELESPEED | Instrumentation | Marelli/Microsoft C3 Convergence | • | • | • | • | • | 0 |

| Model | Version | Group | System | ECU info. | Read Codes | Erase Codes | Live Data | Active Test | Specil Function |
|--------------------|-----------------|---------------------------------|------------------------------------------------------------------------------|--------------|---------------|----------------|--------------|----------------|---------------------|
| 147 | SELESPEED | Instrumentation | Marelli/Microsoft C3 Convergence | • | • | • | • | • | 0 |
| 159 | 1.8 16V | Instrumentation | Marelli/Microsoft C3 Convergence | • | • | • | • | • | 0 |
| 159 | 1.8 JTS TB 16V | Instrumentation | Marelli/Microsoft C3 Convergence | • | • | • | • | • | 0 |
| 159 | 1. 9 JTS 16V | Instrumentation | Marelli/Microsoft C3 Convergence | • | • | • | • | • | 0 |
| 159 | 1.9 MJET 16V | Instrumentation | Marelli/Microsoft C3 Convergence | • | • | • | • | • | 0 |
| 159 | 1.9 MJET 8V | Instrumentation | Marelli/Microsoft C3 Convergence | • | • | • | • | • | 0 |
| | 2. 0 JTD 16V | Instrumentation | Marelli/Microsoft C3 Convergence | • | • | • | • | • | 0 |
| 159 | 2. 2 JTS 16V | Instrumentation | Marelli/Microsoft C3 Convergence | • | • | • | • | • | 0 |
| 159 | 2.4 MJET 20V | Instrumentation | Marelli/Microsoft C3 Convergence | • | • | • | • | • | 0 |
| 159 | 3. 2 V6 24V | Instrumentation | Marelli/Microsoft C3 Convergence | • | • | • | • | • | 0 |
| BRERA | 1.8 JTS TB 16V | Instrumentation | Marelli/Microsoft C3 Convergence | • | • | • | • | • | 0 |
| BRERA | 2. 0 JTD 16V | Instrumentation | Marelli/Microsoft C3 Convergence | • | • | • | • | • | 0 |
| BRERA | 2. 2 JTS 16V | Instrumentation | Marelli/Microsoft C3 Convergence | • | • | • | • | • | 0 |
| BRERA | 2. 4 MJET 20V | Instrumentation | Marelli/Microsoft C3 Convergence | • | • | • | • | | 0 |
| | 3. 2 V6 24V | Instrumentation | Marelli/Microsoft C3 Convergence | • | • | • | • | • | 0 |
| GT | 1. 8 TS 16V | Instrumentation | Marelli/Microsoft C3 Convergence | • | • | • | • | | 0 |
| GT | 1. 9 JTD 16V | Instrumentation | Marelli/Microsoft C3 Convergence | | | • | | • | 0 |
| GT | 3. 2 V6 24V | Instrumentation | Marelli/Microsoft C3 Convergence | | | • | | | 0 |
| GT | JTS 2. 0 | Instrumentation | Marelli/Microsoft C3 Convergence | | | • | - | | 0 |
| MITO | 1.3 MJET 16V | | Marelli/Microsoft C3 (EP) Convergence | - | | | - | | 0 |
| MITO | 1. 4 16V | Instrumentation Instrumentation | Marelli/Microsoft C3 (EP) Convergence Marelli/Microsoft C3 (EP) Convergence | - | | | - | | 0 |
| MITO | 1. 4 TURBO 16V | | Marelli/Microsoft C3 (EP) Convergence Marelli/Microsoft C3 (EP) Convergence | - | | | - | | 0 |
| | 1. 6 MJET 16V | Instrumentation | Marelli/Microsoft C3 (EP) Convergence Marelli/Microsoft C3 (EP) Convergence | • | • | • | • | | 0 |
| MITO BRERA | 1.8 JTS TB 16V | Instrumentation | TRW Air Bag MY 03 (2F-2P-2L-1G-I) | • | • | • | • | | 0 |
| | | Safety | | • | • | • | • | | |
| BRERA | 2. 0 JTD 16V | Safety | TRW Air Bag MY 03 (2F-2P-2L-1G-I) | | | | | _ | 0 |
| BRERA | 2. 2 JTS 16V | Safety | TRW Air Bag MY 03 (2F-2P-2L-1G-I) | • | • | • | • | • | 0 |
| BRERA | 3. 2 V6 24V | Safety | TRW Air Bag MY 03 (2F-2P-2L-1G-I) | • | • | • | • | • | 0 |
| BRERA | 1. 8 JTS TB 16V | Safety | TRW Air Bag MY 03 (2F-2P-2L-2G-I) | • | • | • | • | • | 0 |
| BRERA | 2. 0 JTD 16V | Safety | TRW Air Bag MY 03 (2F-2P-2L-2G-I) | • | • | • | • | • | 0 |
| BRERA | 2. 2 JTS 16V | Safety | TRW Air Bag MY 03 (2F-2P-2L-2G-I) | • | • | • | • | • | 0 |
| BRERA | 3. 2 V6 24V | Safety | TRW Air Bag MY 03 (2F-2P-2L-2G-I) | • | • | • | • | • | 0 |
| 159 | 2. 2 JTS 16V | Engine - Gearbox | Marelli SELESPEED CFC300 Automatic Gearbox | • | • | • | • | | 0014 0118 0164 0172 |
| BRERA | 2. 2 JTS 16V | Engine - Gearbox | Marelli SELESPEED CFC300 Automatic Gearbox | • | • | • | • | • | 0014 0118 0164 0172 |
| GIULIETTA (191) | 1.4 TURBO 16V | Engine - Gearbox | Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4) | • | • | • | • | • | 0 |
| MITO | 1. 4 16V | Engine - Gearbox | Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4) | • | • | • | • | • | 0 |
| MITO | 1.4 TURBO 16V | Engine - Gearbox | Bosch Motronic Injection Me7.9.10 CF5/EOBD (EP eng. 1.4) | • | • | • | • | • | 0 |
| GIULIETTA (191) | 1.4 TURBU 16V | Comfort | VALEO Parking Control unit (EP) 2 | • | • | • | • | 0 | 0 |
| GIULIETTA (191) | 1.6 MJET 16V | Comfort | VALEO Parking Control unit (EP) 2 | • | • | • | • | 0 | 0 |
| GIULIETTA (191) | 1.8 JTS TB 16V | Comfort | VALEO Parking Control unit (EP) 2 | • | • | • | • | 0 | 0 |
| GIULIETTA (191) | 2.0 MJEI 16V | Comfort | VALEO Parking Control unit (EP) 2 | • | • | • | • | 0 | 0 |
| MITO | 1.3 MJET 16V | Comfort | VALEO Parking Control unit (EP) 2 | • | • | • | • | 0 | 0 |

| Model | Version | Group | System | ECU info. | Read Codes | Erase Codes | Live Data | Active Test | Specil Function |
|--------------------|----------------|------------------|----------------------------------------------------------------|--------------|---------------|----------------|--------------|----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| MITO | 1.4 16V | Comfort | VALEO Parking Control unit (EP) 2 | • | • | • | • | 0 | 0 |
| MITO | 1.4 TURBO 16V | Comfort | VALEO Parking Control unit (EP) 2 | • | • | • | • | 0 | 0 |
| MITO | 1.6 MJET 16V | Comfort | VALEO Parking Control unit (EP) 2 | • | • | • | • | 0 | 0 |
| MITO | 1.3 MJET 16V | Engine - Gearbox | Marelli 6F3 EOBD CAN Diesel Injection (EP eng. 1.3 JTD) 2 | • | • | • | • | • | 0043 0014 0047 0046 |
| 159 | 2.0 JTD 16V | Engine - Gearbox | Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.) | • | • | • | • | • | 0029 0058 0059 0060 0061 0030 0043 0014 0022 0080 0054 0057 0003 0020 0052 0047 0062 0046 0198 0199 |
| BRERA | 2.0 JTD 16V | Engine - Gearbox | Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.) | • | • | • | • | • | 0029 0058 0059 0060 0061 0030 0043 0014 0022 0080 0054 0057 0003 0020 0052 0047 0062 0046 0198 0199 |
| GIULIETTA (191) | 1.4 TURBO 16V | Instrumentation | Siemens 3 instrument panel | • | • | • | • | • | 0027 0070 0064 0066 0065 0034 |
| GIULIETTA (191) | 1.6 MJEI 16V | Instrumentation | Siemens 3 instrument panel | • | • | • | • | • | 0027 0070 0064 0066 0065 0034 |
| GIULIETTA (191) | 1.8 JTS TB 16V | Instrumentation | Siemens 3 instrument panel | • | • | • | • | • | 0027 0070 0064 0066 0065 0034 |
| GIULIETTA (191) | 2.0 MJET 16V | Instrumentation | Siemens 3 instrument panel | • | • | • | • | • | 0027 0070 0064 0066 0065 0034 |
| MITO | 1.3 MJET 16V | Instrumentation | Siemens 3 instrument panel | • | • | • | • | • | 0027 0070 0064 0066 0065 0034 |
| MITO | 1.4 16V | Instrumentation | Siemens 3 instrument panel | • | • | • | • | • | 0027 0070 0064 0066 0065 0034 |
| MITO | 1.4 TURBO 16V | Instrumentation | Siemens 3 instrument panel | • | • | • | • | • | 0027 0070 0064 0066 0065 0034 |
| MITO | 1.6 MJET 16V | Instrumentation | Siemens 3 instrument panel | • | • | • | • | • | 0027 0070 0064 0066 0065 0034 |
| MITO | 1.3 MJET 16V | Safety | Delphi (EP) 3 Body computer | • | • | • | • | • | 0 |
| MITO | 1.4 16V | Safety | Delphi (EP) 3 Body computer | • | | • | • | • | 0 |
| MITO | 1.4 TURBO 16V | Safety | Delphi (EP) 3 Body computer | • | • | • | • | • | 0 |
| MITO | 1.6 MJET 16V | Safety | Delphi (EP) 3 Body computer | • | • | • | • | • | 0 |
| MITO | 1.3 MJET 16V | Safety | DELPHI (EP) 3 Electric Steering | • | • | • | • | 0 | 0051 |
| MITO | 1.4 16V | Safety | DELPHI (EP) 3 Electric Steering | • | • | • | • | 0 | 0051 |
| MITO | 1.4 TURBO 16V | Safety | DELPHI (EP) 3 Electric Steering | • | • | • | • | 0 | 0051 |
| MITO | 1.6 MJET 16V | Safety | DELPHI (EP) 3 Electric Steering | • | • | • | • | 0 | 0051 |
| GIULIETTA (191) | 1.6 MJET 16V | Engine - Gearbox | Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.) | • | • | • | • | • | 0043 0198 0199 0014 0062 0046 |
| GIULIETTA (191) | 2.0 MJET 16V | Engine - Gearbox | Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.) | • | • | • | • | • | 0043 0198 0199 0014 0062 0046 |
| MITO | 1.6 MJET 16V | Engine - Gearbox | Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 eng.) | • | • | • | • | • | 0043 0198 0199 0014 0062 0046 |
| MITO | 1.3 MJET 16V | Safety | Bosch ABS 8 ESP (EP) 2 | • | • | • | • | • | 0039 |
| MITO | 1.4 16V | Safety | Bosch ABS 8 ESP (EP) 2 | • | • | • | • | • | 0039 |
| MITO | 1.4 TURBO 16V | Safety | Bosch ABS 8 ESP (EP) 2 | • | • | • | • | • | 0039 |
| MITO | 1.6 MJET 16V | Safety | Bosch ABS 8 ESP (EP) 2 | • | • | • | • | • | 0039 |
| MITO | 1.3 MJET 16V | Safety | CONTINENTAL Airbag (EP-Proxy) 2 | • | • | • | • | • | 0 |
| MITO | 1. 4 16V | Safety | CONTINENTAL Airbag (EP-Proxy) 2 | • | • | • | • | • | 0 |
| MITO | 1.4 TURBO 16V | Safety | CONTINENTAL Airbag (EP-Proxy) 2 | • | • | • | • | • | 0 |
| MITO | 1.6 MJET 16V | Safety | CONTINENTAL Airbag (EP-Proxy) 2 | • | • | • | • | • | 0 |

| Model | Version | Group | System | ECU info. | Read Codes | Erase Codes | Live Data | Active Test | Specil Function |
|--------------------|----------------|------------------|-----------------------------------------------------------|-----------|---------------|----------------|--------------|----------------|-----------------|
| 159 | 1.8 JTS TB 16V | Engine - Gearbox | Bosch Injection Motronic MeD17.3.1 CF5/EOBD (eng. 1.8) | • | • | • | • | • | 0102 0014 |
| BRERA | 1.8 JTS TB 16V | Engine - Gearbox | Bosch Injection Motronic MeD17.3.1 CF5/EOBD (eng. 1.8) | • | • | • | • | • | 0102 0014 |
| MITO | 1.4 TURBO 16V | Comfort | Magneti Marelli suspension (EP) | • | • | • | • | • | 0 |
| GIULIETTA (191) | 1.4 TURBO 16V | Comfort | Marelli Radio Navigator (EP) | • | • | • | • | • | 0 |
| GIULIETTA (191) | 1.6 MJET 16V | Comfort | Marelli Radio Navigator (EP) | • | • | • | • | • | 0 |
| GIULIETTA (191) | 1.8 JIS IB 16V | Comfort | Marelli Radio Navigator (EP) | • | • | • | • | • | 0 |
| GIULIETTA (191) | 2.0 MJET 16V | Comfort | Marelli Radio Navigator (EP) | • | • | • | • | • | 0 |
| MITO | 1.3 MJET 16V | Comfort | Marelli Radio Navigator (EP) | • | • | • | • | • | 0 |
| MITO | 1. 4 16V | Comfort | Marelli Radio Navigator (EP) | • | • | • | • | • | 0 |
| MITO | 1.4 TURBO 16V | Comfort | Marelli Radio Navigator (EP) | • | • | • | • | • | 0 |
| MITO | 1.6 MJET 16V | Comfort | Marelli Radio Navigator (EP) | • | • | • | • | • | 0 |
| 159 | 1.8 16V | Comfort | Marelli Radio Navigator | • | • | • | • | • | 0 |
| 159 | 1.8 JTS TB 16V | Comfort | Marelli Radio Navigator | • | • | • | • | • | 0 |
| 159 | 1.9 JTS 16V | Comfort | Marelli Radio Navigator | • | • | • | • | • | 0 |
| 159 | 1.9 MJET 16V | Comfort | Marelli Radio Navigator | • | • | • | • | • | 0 |
| 159 | 1.9 MJET 8V | Comfort | Marelli Radio Navigator | • | • | • | • | • | 0 |
| 159 | 2.0 JTD 16V | Comfort | Marelli Radio Navigator | • | • | • | • | • | 0 |
| 159 | 2.2 JTS 16V | Comfort | Marelli Radio Navigator | • | • | • | • | • | 0 |
| 159 | 2.4 MJET 20V | Comfort | Marelli Radio Navigator | • | • | • | • | • | 0 |
| 159 | 3. 2 V6 24V | Comfort | Marelli Radio Navigator | • | • | • | • | • | 0 |
| BRERA | 1.8 JTS TB 16V | Comfort | Marelli Radio Navigator | • | • | • | • | • | 0 |
| BRERA | 2.0 JTD 16V | Comfort | Marelli Radio Navigator | • | • | • | • | • | 0 |
| BRERA | 2.2 JTS 16V | Comfort | Marelli Radio Navigator | • | • | • | • | • | 0 |
| BRERA | 2.4 MJET 20V | Comfort | Marelli Radio Navigator | • | • | • | • | • | 0 |
| BRERA | 3.2 V6 24V | Comfort | Marelli Radio Navigator | • | • | • | • | • | 0 |
| MITO | 1.4 TURBO 16V | Engine - Gearbox | Injection Landi Renzo LCO2 Gas | • | • | • | • | • | 0 |
| GIULIETTA (191) | 1.4 TURBO 16V | Engine - Gearbox | Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4) | • | • | • | • | • | 0102 0207 |
| MITO | 1. 4 16V | Engine - Gearbox | Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4) | • | • | • | • | • | 0102 0207 |
| MITO | 1.4 TURBO 16V | Engine - Gearbox | Magneti Marelli Injection IAW 8GMF CF5/EOBD (EP eng. 1.4) | • | • | • | • | • | 0102 0207 |
| GIULIETTA (191) | 1.4 TURBO 16V | Instrumentation | Lauberhorn Convergence (EP) | • | • | • | • | • | 0 |
| GIULIETTA (191) | 1.6 MJET 16V | Instrumentation | Lauberhorn Convergence (EP) | • | • | • | • | • | 0 |
| GIULIETTA (191) | 1.8 JIS IB 16V | Instrumentation | Lauberhorn Convergence (EP) | • | • | • | • | • | 0 |
| GIULIETTA (191) | 2.0 MJET 16V | Instrumentation | Lauberhorn Convergence (EP) | • | • | • | • | • | 0 |
| MITO | 1.3 MJET 16V | Instrumentation | Lauberhorn Convergence (EP) | • | • | • | • | • | 0 |
| MITO | 1.4 16V | Instrumentation | Lauberhorn Convergence (EP) | • | • | • | • | • | 0 |

| Model | Version | Group | System | ECU info. | Read Codes | Erase Codes | Live Data | Active Test | Specil Function |
|--------------------|----------------|------------------|-----------------------------------------------------------|--------------|---------------|----------------|--------------|----------------|-------------------------------|
| MITO | 1.4 TURBO 16V | Instrumentation | Lauberhorn Convergence (EP) | • | • | • | • | • | 0 |
| MITO | 1.6 MJET 16V | Instrumentation | Lauberhorn Convergence (EP) | • | • | • | • | • | 0 |
| MITO | 1.3 MJET 16V | Engine - Gearbox | Marelli Diesel Injection 8DF CF5/EOBD (EP eng. 1.3 JTD) | • | • | • | • | • | 0102 0198 0199 0014 0212 0213 |
| MITO | 1.3 MJET 16V | Safety | CONTINENTAL Airbag (EP) | • | • | • | • | • | 0 |
| MITO | 1.4 16V | Safety | CONTINENTAL Airbag (EP) | • | • | • | • | • | 0 |
| MITO | 1.4 TURBO 16V | Safety | CONTINENTAL Airbag (EP) | • | • | • | • | • | 0 |
| MITO | 1.6 MJET 16V | Safety | CONTINENTAL Airbag (EP) | • | • | • | • | • | 0 |
| GIULIETTA (191) | 1.4 TURBO 16V | Safety | Continental MK60EC ABS (EP) | • | • | • | • | • | 0216 0075 0074 |
| GIULIETTA (191) | 1.6 MJET 16V | Safety | Continental MK60EC ABS (EP) | • | • | • | • | • | 0216 0075 0074 |
| GIULIETTA (191) | 1.8 JTS TB 16V | Safety | Continental MK60EC ABS (EP) | • | • | • | • | • | 0216 0075 0074 |
| GIULIETTA (191) | 2.0 MJET 16V | Safety | Continental MK60EC ABS (EP) | • | • | • | • | • | 0216 0075 0074 |
| GIULIETTA (191) | 1.4 TURBO 16V | Safety | Bosch Air bag (EP) | • | • | • | • | • | 0 |
| GIULIETTA (191) | 1.6 MJET 16V | Safety | Bosch Air bag (EP) | • | • | • | • | • | 0 |
| GIULIETTA (191) | 1.8 JTS TB 16V | Safety | Bosch Air bag (EP) | • | • | • | • | • | 0 |
| GIULIETTA (191) | 2.0 MJET 16V | Safety | Bosch Air bag (EP) | • | • | • | • | • | 0 |
| MITO | 1.4 TURBO 16V | Engine - Gearbox | Marelli DDCT CFC8TDF Automatic Gearbox (EP) | • | • | • | • | • | 0164 0014 0220 0172 |
| GIULIETTA (191) | 1.8 JTS TB 16V | Engine - Gearbox | Bosch Motronic Injection MeD17.3.1 CF5/EOBD (EP eng. 1.8) | • | • | • | • | • | 0102 0014 |
| GIULIETTA (191) | 1.4 TURBO 16V | Comfort | Marelli climate control Two-zone (EP) | • | • | • | • | • | 0 |
| GIULIETTA (191) | 1.6 MJET 16V | Comfort | Marelli climate control Two-zone (EP) | • | • | • | • | • | 0 |
| GIULIETTA (191) | 1.8 JTS TB 16V | Comfort | Marelli climate control Two-zone (EP) | • | • | • | • | • | 0 |
| GIULIETTA (191) | 2.0 MJET 16V | Comfort | Marelli climate control Two-zone (EP) | • | • | • | • | • | 0 |
| GIULIETTA (191) | 1.4 TURBU 10V | Comfort | Marelli Manual Climate control (EP) | • | • | • | • | • | 0 |
| GIULIETTA (191) | 1.6 MJET 16V | Comfort | Marelli Manual Climate control (EP) | • | • | • | • | • | 0 |
| GIULIETTA (191) | 1.8 JTS TB 16V | Comfort | Marelli Manual Climate control (EP) | • | • | • | • | • | 0 |
| GIULIETTA (191) | 2.0 MJET 16V | Comfort | Marelli Manual Climate control (EP) | • | • | • | • | • | 0 |
| GIULIETTA (191) | 1.4 TURBO 16V | Safety | Marelli 10 Body Computer | • | • | • | • | • | 0 |
| GIULIETTA (191) | 1.6 MJET 16V | Safety | Marelli 10 Body Computer | • | • | • | • | • | 0 |

| Mode1 | Version | Group | System | ECU info. | Read Codes | Erase Codes | Live Data | Active Test | Specil Function |
|--------------------|----------------|---------------|-----------------------------------------------|--------------|---------------|----------------|--------------|----------------|-----------------|
| GIULIETTA (191) | 1.8 JTS TB 16V | Safety | Marelli 10 Body Computer | • | • | • | • | • | 0 |
| CIII IETTA | 2.0 MJET 16V | Safety | Marelli 10 Body Computer | • | • | • | • | • | 0 |
| GIULIETTA (191) | 1.4 TURBO 16V | Comfort | Lear driver's seat (EP) | • | • | • | • | • | 0 |
| GIULIETTA (191) | 1.6 MJET 16V | Comfort | Lear driver's seat (EP) | • | • | • | • | • | 0 |
| GIULIETTA (191) | 1.8 JTS TB 16V | Comfort | Lear driver's seat (EP) | • | • | • | • | • | 0 |
| GIULIETTA (191) | 2.0 MJET 16V | Comfort | Lear driver's seat (EP) | • | • | • | • | • | 0 |
| GIULIETTA (191) | 1.4 TURBO 16V | Comfort | Lear passenger seat (EP) | • | • | • | • | • | 0 |
| GIULIETTA (191) | 1.6 MJET 16V | Comfort | Lear passenger seat (EP) | • | • | • | • | • | 0 |
| GIULIETTA (191) | 1.8 JTS TB 16V | Comfort | Lear passenger seat (EP) | • | • | • | • | • | 0 |
| (191) | 2.0 MJET 16V | Comfort | Lear passenger seat (EP) | • | • | • | • | • | 0 |
| GIULIETTA (191) | 1.4 TURBO 16V | Other systems | Automotive Lighting discharge headlights (EP) | • | • | • | • | • | 0 |
| GIULIETTA (191) | 1.6 MJET 16V | Other systems | Automotive Lighting discharge headlights (EP) | • | • | • | • | • | 0 |
| GIULIETTA (191) | 1.8 JTS TB 16V | Other systems | Automotive Lighting discharge headlights (EP) | • | • | • | • | • | 0 |
| (191) | 2.0 MJET 16V | Other systems | Automotive Lighting discharge headlights (EP) | • | • | • | • | • | 0 |
| 159 | 1.8 16V | Safety | Convergence Lauberhorn C1 | • | • | • | • | • | 0 |
| 159 | 1.8 JTS TB 16V | Safety | Convergence Lauberhorn C1 | • | • | • | • | • | 0 |
| 159 | 1.9 JTS 16V | Safety | Convergence Lauberhorn C1 | • | • | • | • | • | 0 |
| | 1.9 MJET 16V | Safety | Convergence Lauberhorn C1 | • | • | • | • | • | 0 |
| 159 | 1.9 MJET 8V | Safety | Convergence Lauberhorn C1 | • | • | • | • | • | 0 |
| | 2. 0 JTD 16V | Safety | Convergence Lauberhorn C1 | | • | • | | | 0 |
| | 2. 2 JTS 16V | | <u> </u> | • | | • | | | 0 |
| | | Safety | Convergence Lauberhorn C1 | | | | | _ | |
| | 2. 4 MJET 20V | Safety | Convergence Lauberhorn C1 | • | Ţ. | • | | • | 0 |
| | 3. 2 V6 24V | Safety | Convergence Lauberhorn C1 | • | • | • | • | • | 0 |
| Giulietta | | | EPS | | <u> </u> | <u> </u> | <u> </u> | 0 | |
| Giulietta | | | PAM | <u> </u> | <u> </u> | <u> </u> | <u> </u> | A | |
| Giulietta | | | TCM | <u> </u> | <u> </u> | <u> </u> | <u> </u> | 0 | |
| Giulietta | | | ETM | A | A | A | | A | |
| Giulietta | | | ORC | A | A | A | A | A | |
| Giulietta | | | ABS | A | A | A | A | A | |
| Giulietta | | | ECM | A | A | A | A | A | |
| Giulietta | | | AFLS | • | | • | | A | |
| Giulietta | | | DSTM | A | A | A | A | A | |
| Giulietta | | | BCM | A | A | A | A | A | |
| Giulietta | | | HVAC | A | A | A | A | A | |

| Model | Version | Group | System | ECU info. | Read Codes | Erase Codes | Live Data | Active Test | Specil Function |
|-----------|---------|-------|--------|--------------|---------------|----------------|--------------|----------------|-----------------|
| Giulietta | 2011 | | RMN | A | A | A | A | A | |
| Giulietta | 2011 | | CTM | A | A | A | A | A | |
| Giulietta | 2011 | | IPC | A | A | A | A | A | |
| Giulietta | 2011 | | PSTM | A | A | A | A | A | |
| 4C | 2013 | | PAM | A | A | A | A | 0 | |
| 4C | 2013 | | IPC | A | A | A | A | A | |
| 4C | 2013 | | ORC | A | A | A | A | 0 | |
| 4C | 2013 | | TPM | A | A | A | A | A | |
| 4C | 2013 | | ECM | 0 | 0 | 0 | 0 | 0 | |
| 4C | 2013 | | ABS | A | A | A | A | A | |
| 4C | 2013 | | BCM | A | A | A | A | A | |
| 4C | 2013 | | TCM | A | A | A | A | 0 | |



Special_Function

| Index | Specil Function Name | Index | Specil Function Name |
|-------|-------------------------------------------------------------------------------|-------|------------------------------------------------------------------------------------------------|
| 0001 | Air conditioner Learn | 0002 | Air flow meter replacement (only for version with |
| | | | Lambda sensor) |
| | Air flow meter sensor replacement | 0004 | Air flow sensor replacement |
| 0005 | Alarm deletion | 0006 | Alarm state check |
| | Antenna replacement | 8000 | Automatic Configuration Read |
| | Automatic Configuration Write | 0010 | Brake bleed |
| | Cam edges zeroing (VVT) | 0012 | Control unit activation |
| | Control unit deactivation | 0014 | Control unit replacement |
| | Cruise Control Learn | 0016 | Cyl. 1 injector classification |
| 0017 | Cyl. 2 injector classification | 0018 | Cyl. 3 injector classification |
| 0019 | Cyl. 4 injector classification | 0020 | Differential pressure sensor replacement (only for version with DPF) |
| 0021 | EGR valve learn | 0022 | EGR valve replacement |
| 0023 | Engine - Control Unit Group Replacement | 0024 | Engine type configuration |
| 0025 | FAP Replacement | 0026 | Fuel supply system |
| 0027 | Headlamp pos. correct. | 0028 | Injector classification (4 cyl. bank) |
| 0029 | Injector codes read | 0030 | Injector replacement (per bank) |
| 0031 | Inputs status | 0032 | Inspection service value |
| 0033 | Instrument panel lighting | 0034 | Instrument panel replacement |
| | Knock counter reset | 0036 | Lambda sensor check |
| 0037 | Lambda sensor replacement (only for version with | 0038 | LED colours configuration |
| 0039 | Lambda sensor) Longit. acc. sensor calibration | 0040 | Looks for faulty wheel transmitter |
| | | 0040 | Odometer write |
| | Manual System Configuration Oil change (only for version with DPF) | 0042 | |
| | | 0044 | Oil change servicing information delete Particulate filter regeneration (only for version |
| | Overboost counter reset Particulate filter replacement (only for version with | | |
| | | 0048 | Phase sensor learn zeroing |
| | Phonic wheel learn reset | 0050 | Phonic wheel replacement |
| | Position sensor calibration | 0052 | Pre-catalyser replacement (only for version with DPF) |
| | Rail pressure sensor and injector/s replacement | 0054 | Rail pressure sensor replacement |
| | Replacement injector cyl. 5 | 0056 | Replacement injectors (4 cyl. bank) |
| | Replacement Lambda sensor | 0058 | Replacement of injector cyl. 1 |
| 0059 | Replacement of injector cyl. 2 | 0060 | Replacement of injector cyl. 3 |
| 0061 | Replacement of injector cyl. 4 | 0062 | Replacement of particulate filter with built-in pre- catalyzer (only for versions with DPF) |
| 0063 | Replacment of control unit and injector/s | 0064 | Reset odometer |
| 0065 | Seat belts alarm Enable | 0066 | Seat belts alarm exclusion |
| 0067 | Secondary wheel identification deletion | 0068 | Self-learnt functions reset |
| 0069 | Services Interval KM message | 0070 | Servicing information delete |
| 0071 | Servo Mechanism Group Replacement | 0072 | Speed limit setting |
| 0073 | Startup with Code Card | 0074 | Steering angle calibration |
| 0075 | Steering angle reset | 0076 | System configuration |
| | Throttle learn storage | 0078 | Tow hook presence disable |
| | Tow hook presence enable | 0080 | Variable geometry turbo replacement |
| | Vehicle configuration deletion | 0082 | Vehicle type learn reset |
| | Wheel identification check | 0084 | Wheel transmitters learning |
| 0085 | Zeroing of self-adaption parameters | 0086 | Engine control unit programming |
| 0087 | System calibration | 0088 | Total additive quantity |
| 0089 | Part. Filter regeneration | 0090 | Customer mode |
| | Mounting check | 0092 | Tyre Pressure check |
| | Control Unit Replacement | 0094 | Additive type configuration |
| | RH distribution flap learn | 0096 | LH distribution flap learn |
| | LH mixing flap learn | 0098 | RH mixing flap learn |
| | United Kingdom (Thatcham std) | 0100 | Date daylight time changed |
| | Fuel level regulat. | 0102 | 0il change |
| | Self-adaptive parameters | 0102 | Phonic wheel learn |
| 0100 | DOIL GRADULING DALAMO CELD | OIUI | I nonte wheet teath |

| Index | Specil Function Name | Index | Specil Function Name |
|--------------|---------------------------------------------------------------------------|--------------|----------------------------------------------------------------------------------|
| 0105 | Injector classification | 0106 | Recognition of speed sensor type |
| 0107 | Actuator tests | 0108 | Self-adaptation Parameter erasure |
| 0109 | Sensor vibration time too long | 0110 | Dist. To Next Service Zeroing (Coupon) |
| 0111 | Maintenance Services Config. | 0112 | Call buttons configuration |
| 0113 | Clutch replacement | 0114 | KIT/Gearbox replacement |
| 0115 | Electropump replacement | 0116 | Statistical data deletion |
| 0117 | Tunnel lever replacement | 0118 | Steering wheel levers replacement |
| 0119 | KIT/Pump replacement | 0120 | Pump relay replacement |
| 0121 | AUTO switch replacement | 0122 | Key storage |
| 0123 | System Configuration Read | 0124 | System Configuration Write |
| 0125 | Reset self-adapt. param. and idle act. | 0126 | Electronic Key control unit programming |
| 0127 | Engine Control + Electronic Key control units | 0128 | Clutch bleed |
| 0129 | Accumulator depressurisation | 0130 | Clutch self-calibration enable |
| 0131 | End of line / service self-calibration | 0132 | New actuators |
| 0133 | Flap actuators learning test | 0134 | Oil Counter Write |
| 0135 | Engagement lever pin securing screw diagnosis | 0136 | Selection lever return diagnosis |
| 0137 | Memory mode write | 0138 | Control Unit Unlock |
| 0139 | Calculation of clutch degradation index | 0140 | Test limit speed disable |
| 0141 | Test limit speed restore | 0142 | VIN Code Configuration |
| 0143 | Personal data deletion | 0144 | Cyl. 5 injector classification |
| 0145 | Injector classification (5 cyl. bank) | 0146 | Deletion of statistical data relating to errors |
| 0147 | CITY switch replacement | 0148 | SPORT switch replacement |
| 0149 | Activation/Deactivation 'Auxiliary video input' | 0150 | Cruise control learn zeroing |
| 0151 | Zeroing fan mode learn | 0152 | Borg Warner sol. valves compatibility |
| 0153 | Self-adapting parameters zeroing (air) | 0154 | Self-adapting parameters zeroing (knock) |
| 0155 | Gearbox Lever Position Learn | 0156 | Deletion stored buttons |
| 0157 0159 | Audio System Test CAN Network Activation | 0158 0160 | Convergence System Restart Deletion of air temperature sensor data |
| 0161 | High pressure pump replacement | 0162 | Additional diesel circuit filling |
| 0163 | Gearbox replacement | 0164 | Gearbox oil accumulator replacement |
| 0165 | Pilot injection learn | 0166 | ECO switch replacement |
| 0167 | End of line self-calibration | 0168 | Forced trim correction |
| 0169 | Vehicle geometry height setting | 0170 | Pneumatic circuit filling |
| 0171 | Pneumatic circuit unloading | 0172 | Longitudinal acceleration signal learn |
| 0173 | JukeBox data deletion | 0174 | ECO/SPORT switch replacement |
| 0175 | 'UP Function' switch replacement | 0176 | Services Interval KM write (only 1.6 MJET 16V 105 hp |
| 0177 | Automatic gearbox replacement | 0178 | Automatic gearbox and Control unit replacement |
| 0179 | Automatic gearbox oil replacement | 0180 | Services Interval KM write (only for 1.4 TURBO 16v |
| 0181 | Static test | 0182 | 120/150 bhp eng.) C.P.H control unit programming |
| 0183 | C.P.H. control unit and engine control unit | 0184 | Remote control programming |
| 0185 | Key programming | 0186 | New vehicle preparation |
| 0187 | Reset distance till next servicing | 0188 | FAP Temperature Probe presence configuration |
| 0189 | Replacement of particulate filter and interventions | 0190 | Replacement of the additive, or the pump, or the |
| | on diesel additive circuit. | | tubes. |
| 0191 | System configuration via Examiner Web | 0192 | Performance limiting deactivation |
| 0193 | Volumetric sensors automatic diagnosis | 0194 | Neutral signal learn |
| 0195 | Hydraulic Kit replacement Selection and/or engagement clutch electrovalve | 0196 | Sensors module replacement Resetting distance travelled with Water Temp. w. lamp |
| 0197 | Resetting distance travelled with Water in diesel w. | 0198 | Resetting distance traversed with water remp. w. ramp |
| 0199 | lamp ON | 0200 | Accelerometer calibration |
| 0201 | Control unit Replacement / Reprogramming | 0202 | Motorised throttle replacement |
| 0203 | Upstream lambda sensor replacement | 0204 | MultiAir Rolling finger replacement |
| 0205 | Timing sensor and/or cam replacement | 0206 | Rpm sensor and/or distribution belt replacement |
| 0207 | Oil temperature sensor replacement | 0208 | UniAir module replacement |
| 0209 | Supercharging system components replacement | 0210 | Downstream lambda sensor and/or catalyzer and/or Injectors replacement |
| 0211 | Differential pressure sensor replacement | 0212 | Particulate filter with integrated pre-cat |
| 0213 | Particulate filter regeneration | 0214 | Mechanical waste-gate valve replacement |
| | | | |

| Index | Specil Function Name | Index | Specil Function Name |
|-------|-------------------------------------------------------------------|-------|------------------------------------------------------------------|
| 0215 | Replacement of variable geometry turbo and/or turbo posit. sensor | 0216 | Lateral and longitud. acceleration sensor calibration |
| 0217 | Pressure sensor calibration | 0218 | Load valves calibration |
| 0219 | Pilot valves calibration | 0220 | Longitudinal acceleration sensor replacement |
| 0221 | Even no. gear clutch pressure sensor replacement | 0222 | Odd no. gear clutch position sensor replacement |
| 0223 | Odd and/or even gear clutch replacement | 0224 | Electropump drive unit replacement |
| 0225 | Gearbox button panel replacement | 0226 | Replacement injectors |
| 0227 | Additive quantity volume | 0228 | Air flow meter replacement |
| 0229 | Air metering unit replacement | 0230 | Supercharg. air cooling SV replacement |
| 0231 | Replacement of Lambda sensor | 0232 | Homologation number |
| 0233 | Speed limit | 0234 | Levers on steering wheel learn |
| 0235 | Gearbox and hydraulic KIT replacement | 0236 | Parking manoeuvre status |
| 0237 | Phonic wheel and/or phase sensor and/or rev sensor replacement | 0238 | Replacement of lambda sensor and/or spark plugs and/or injectors |
| 0239 | Replacement of pressure/temperature sensor in methane | 0240 | Pre-catalyzer replacement |
| 0241 | Particulate filter replacement | 0242 | Alcohol fuel setting |
| 0243 | Petrol fuel setting | 0244 | Air/Fuel learn setting |