

## MaxiDas\_Benz\_V10. 10 Function List (Note:For reference only)

## NOTES:

- This function is supported. \* This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported. 

  A This function is the new feature in this version.

As for special function please refer to the special function table.

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
Up to 11/2005	A-Class	169	Body	AHE-Trailer recognition	•	•	•	•	•	0	•	
As of 12/2005	A-Class	169	Body	AHE-Trailer recognition	•	•	•	•	•	0	•	
Up to 11/2005	B-Class	245	Body	AHE-Trailer recognition	•	•	•	•	•	0	•	
As of 12/2005	B-Class	245	Body	AHE-Trailer recognition	•	•	•	•	•	0	•	
Up to 08/2003	C-Class	203	Body	AHE-Trailer recognition	•	•	•	•	•	0	•	
From 09/2003 to 12/2007	C-Class	203	Body	AHE-Trailer recognition	•	•	•	•	•	0	•	
As of 04/2004	CLK	209	Body	AHE-Trailer recognition	•	•	•	•	•	0	•	
As of 03/2007	G-Class	463 (16-pin diagnostic socket)		AHE-Trailer recognition	•	•	•	•	•	0	•	
Up to 08/2003	C-Class	203	Body	AHE-Trailer recognition	•	•	•		•	0	•	
From 09/2003 to 12/2007	C-Class	203	Body	AHE-Trailer recognition	•	•	•	•	•	0	•	
Up to 03/2004	CLK	209	Body	AHE-Trailer recognition	•	•	•	•	•	0	•	
As of 04/2004	CLK	209	Body	AHE-Trailer recognition	•	•	•	•	•	0	•	
Up to 03/2004	G-Class	463 (16-pin diagnostic socket)	Body	AHE-Trailer recognition	•	•	•	•	•	0	•	
From 04/2004 to 08/2006	G-Class	463 (16-pin diagnostic socket)	Body	AHE-Trailer recognition	•	•	•	•	•	0	•	
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Body	AHE-Trailer recognition	•	•	•	•	•	0	•	
As of 03/2007	G-Class	463 (16-pin diagnostic socket)		AHE-Trailer recognition	•	•	•	•	•	0	•	
Up to 05/2005	E-Class	211	Body	AHE-Trailer recognition	•	•	•	•	•	0		
From 06/2005 to 05/2006	E-Class	211	Body	AHE-Trailer recognition	•	•	•	•	•	0	•	
As of 06/2006	E-Class	211	Body	AHE-Trailer recognition	•	•	•	•	•	0	•	
Up to 08/2002	S-Class		Body	AHE-Trailer recognition	•	•	•	•	•	*	•	
As of 09/2002	S-Class		Body	AHE-Trailer recognition	•	•	•	•	•	*	•	
Up to 08/2002	CL		Body	AHE-Trailer recognition	•	•	•	•	•	*	•	
As of 09/2002	CL		Body	AHE-Trailer recognition	•	•	•	•	•	*	•	
ALL	C-Class		Body	AHE-Trailer recognition	•	•	•	•	•	•	•	
Up to 06/2009	S-Class	221	Body	AHE-Trailer recognition	•	•	•	•	•	•	•	
ALL	CL	216	Body	AHE-Trailer recognition	•				•			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	GLK		Body	AHE-Trailer recognition	•	•	•	•	•	•	•	
ALL	M-Class	163	Body	AAM-All Activity Module	•	•	0	•	•	*	•	
ALL	M-Class	163	Body	AAM-All Activity Module	•	•	0		•	*	•	
ALL	S-Class	140	Body	AirBag	•	•	0	•	0	*	0	
ALL	M-Class	163	Body	AB-Airbag	•	•	0	•		*		
Up to 08/2002	S-Class	220	Chassis	ABC-ABC active body control	•	•		•	•	*	•	0046, 0048, 0051, 0052
As of 09/2002	S-Class	220	Chassis	ABC-ABC active body control	•	•	•	•	•	*	•	0046, 0048, 0051, 0052
Up to 08/2002	CL	215	Chassis	ABC-ABC active body control	•	•	•	•	•	*	•	0046, 0048, 0051, 0052
As of 09/2002	CL	215	Chassis	ABC-ABC active body control	•	•	•	•	•	*	•	0046, 0048, 0051, 0052
Up to 08/2003	SL	230	Chassis	ABC-ABC active body control	•	•	•	•	•	*	•	0046, 0048, 0051, 0052
From 09/2003 to 05/2006	SL	230	Chassis	ABC-ABC active body control	•	•	•	•	•	*	•	0046, 0048, 0051, 0052
From 06/2006 to 02/2008	SL	230	Chassis	ABC-ABC active body control	•	•	•	•	•	*	•	0046, 0048, 0051, 0052
Up to 06/2009	S-Class	221	Chassis	ABC-ABC active body control	•	•	•	•	•	•	•	0046, 0048, 0051, 0052 , 0060, 0045
As of 07/2009	S-Class	221	Chassis	ABC-ABC active body control	•	•	•	•	•	•	•	0046, 0048, 0051, 0052 , 0060, 0045
ALL	CL	216	Chassis	ABC-ABC active body control	•	•	•	•	•	•	•	0046, 0048, 0051, 0052 , 0060, 0045
From 09/2003 to 05/2006	SL	230	Chassis	ABC-ABC active body control	•	•	•	•	•	•	*	0045, 0048, 0060
From 06/2006 to 02/2008	SL	230	Chassis	ABC-ABC active body control	•	•	•	•	•	•	*	0045, 0048, 0060
As of 03/2008	SL	230	Chassis	ABC-ABC active body control	•	•		•	•	•	*	0045, 0048, 0060
ALL	SL	231	Chassis	ABC-ABC (N51/2)		•	0	•	0	•		
As of 07/2009	S-Class	221	Chassis	ABR-Adaptive Brake		•		•	•			
ALL	CL	216	Chassis	ABR-Adaptive Brake	•	•			•			
ALL	C-Class	204	Chassis	ESP-Electronic stability program (N30/4)	•	•	0		0	•		0078
ALL	SLK	172	Chassis	ESP-Electronic stability program (N30/4)	•	•	0		0	•		0078
ALL	GLK	X204	Chassis	ESP-Electronic stability program (N30/4)	•	•	0	•	0	•		0078
As of 06/97	C-Class	202	Chassis	ABS-Antilock brake system	•	•	0	•	•	*		
ALL	CLK	208	Chassis	ABS-Antilock brake system	•	•	0	•	•	*		
As of 03/97 DAS	E-Class	210	Chassis	ABS-Antilock brake system	•	•	0	•	•	*		
ALL	SLK	170 (38-pin diagnostic socket)	Chassis	ABS-Antilock brake system	•	•	0	•	•	*		
ALL	G-Class	463 (38-pin diagnostic socket)		ABS-Antilock brake system	•	•	0	•	•	*		
ALL	G-Class	461(16-pin diagnostic socket)		Traction systems ABS	•	•	•	•	•			
Up to 03/2004	G-Class	463 (16-pin diagnostic socket)	Chassis	ABS-Antilock brake system	•	•	•	•	•	*	•	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Chassis	ABS-Antilock brake system	•	•	•	•	•	*	•	
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)		ABS-Antilock brake system	•	•	•	•	•	*	•	
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Chassis	ABS-Antilock brake system	•	•	•	•	•	*	•	
ALL	G-Class	461(16-pin diagnostic socket)		ABS-Antilock brake system	•	•	•	•	•	*	•	
ALL	SLR	199	Body	ACL [ZLB]-Air brake (spoiler) and central locking control unit	•	•	•	•	•	•	•	
ALL	SLR	199	Body	BKGS-Brake cooling and gearshift	•	•	•	•	•	•		
As of 06/97	C-Class	202	Information and communication	TELE AID-Telematic system	•	•	0	•		•		
As of 03/97 DAS	E-Class	210	Information and communication	TELE AID-Telematic system	•	•	0	•		•		
ALL	A-Class	168	Drive	ACS-Automatic clutch system	•	•	•	•	•	*		
Up to 05/2005	E-Class	211	Seats and doors	LAE [LAA]-Loading floor automatically	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	E-Class	211	Seats and doors	LAE [LAA]-Loading floor automatically extendable	•	•	•	•	•	•	•	
As of 06/2006	E-Class	211	Seats and doors	LAE [LAA]-Loading floor automatically	•	•	•	•	•	•	•	
Up to 05/2005	CLS	219	Seats and doors	LAE [LAA]-Loading floor automatically	•	•	•	•	•		•	
From 06/2005 to 05/2006	CLS	219	Seats and doors	LAE [LAA]-Loading floor automatically extendable	•	•	•	•	•	•	•	
As of 06/2006	CLS	219	Seats and doors	LAE [LAA]-Loading floor automatically	•	•	•	•	•	•	•	
As of 04/2004	CLK	209	Body	HRA-Automatic headlamp range adjustment and headlamp control	•	•	•	•	•	0	•	0005 0009
Up to 05/2005	E-Class	211	Body	HRA-Automatic headlamp range adjustment and headlamp control	•	•	•	•	•	0	•	0005 0009
From 06/2005 to 05/2006	E-Class	211	Body	HRA-Automatic headlamp range adjustment and headlamp control	•	•	•	•	•	0	•	0005 0009
Up to 05/2005	CLS	219	Body	HRA-Automatic headlamp range adjustment and headlamp control	•	•	•	•	•	0	•	0005 0009
From 06/2005 to 05/2006	CLS	219	Body	HRA-Automatic headlamp range adjustment and headlamp control	•	•	•	•	•	0	•	0005 0009
As of 06/2006	CLS	219	Body	HRA-Automatic headlamp range adjustment and headlamp control	•	•	•	•	•	0	•	0005 0009
Up to 08/2006	MayBach	240	Body	HRA-Automatic headlamp range adjustment and headlamp control	•	•	•	•	•	0	•	0005 0009
As of 09/2006	MayBach	240	Body	HRA-Automatic headlamp range adjustment and headlamp control	•	•	•	•	•	0	•	0005 0009
Up to 05/2005	SLK	171	Body	HRA-Automatic headlamp range adjustment and headlamp control	•	•	•	•	•	0	•	0005 0009
As of 06/2005	SLK	171	Body	HRA-Automatic headlamp range adjustment and headlamp control	•	•	•	•	•	0	•	0005 0009

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	M-Class	164	Body	HRA-Automatic headlamp range adjustment and headlamp control	•	•	•	•	•	0	•	0005 0009
ALL	GL-Class	X 164	Body	HRA-Automatic headlamp range adjustment and headlamp control	•	•	•	•	•	0	•	0005 0009
ALL	R-Class	251	Body	HRA-Automatic headlamp range adjustment and headlamp control	•	•	•	•	•	0	•	0005 0009
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Body	ALWR-Headlamp range adjustment	•	•	•	•	•	•	*	
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Body	ALWR-Headlamp range adjustment	•	•	•	•	•	•	*	
As of 01/2008	C-Class		Body	XALWA-L-Xenon headlamp, left	•	•	•	•	•	•	*	
ALL	C-Class		Body	XALWA-L-Xenon headlamp, left	•	•	•	•	•			
ALL	GLK		Body	XALWA-L-Xenon headlamp, left	•	•	•	•	•			
ALL	CL		Body	XALWA-L-Xenon headlamp, left	•	•	•	•	•			
As of 07/2009	S-Class		Body	XALWA-L-Xenon headlamp, left	•	•	•	•	•			
ALL	CL		Body	XALWA-L-Xenon headlamp, left	•	•	•	•	•			
ALL	CLS		Body	XALWA-L-Left xenon headlamp(E1n1)	•	•	0	•	0	•		
Up to 06/2009	S-Class		Body	XALWA-L-Xenon headlamp, left	•	•	•	•	•			
As of 07/2009	S-Class		Body	XALWA-L-Xenon headlamp, left	•	•	•	•	•			
As of 03/2008	SL		Body	XALWA-L-Xenon headlamp, left	•	•	•	•	•	•	*	
ALL	R-Class		Body	HRA-FL-Front left headlamp range control	•	•	•	•	•			
Up to 11/2005	A-Class		Body	HRA-FR-Front right headlamp range control	•	•	•	•	•	0	•	
As of 12/2005	A-Class		Body	HRA-FR-Front right headlamp range control	•	•	•	•	•	0	•	
Up to 08/2003	C-Class	203	Body	HRA-FR-Front right headlamp range control	•	•	•	•	•	0	•	
From 09/2003 to 12/2007	C-Class		Body	HRA-FR-Front right headlamp range control	•	•	•	•	•	0	•	
Up to 03/2004	CLK		Body	HRA-FR-Front right headlamp range control	•	•	•	•	•	0	•	
As of 04/2004	CLK		Body	HRA-FR-Front right headlamp range control	•	•	•	•	•	0	•	
Up to 08/2002	S-Class		Body	HRA-FR-Front right headlamp range control	•	•	•	•	•	0	•	
As of 09/2002	S-Class		Body	HRA-FR-Front right headlamp range control	•	•	•	•	•	0	•	
As of 09/2002	CL		Body	HRA-FR-Front right headlamp range control	•	•	•	•	•	0	•	
Up to 08/2003	SL	230	Body	HRA-FR-Front right headlamp range control	•	•	•	•	•	0	•	
From 09/2003 to 05/2006	SL	230	Body	HRA-FR-Front right headlamp range control	•	•	•	•	•	0	•	
From 06/2006 to 02/2008	SL	230	Body	HRA-FR-Front right headlamp range control	•	•	•	•	•	0	•	
ALL	SLR	199	Body	HRA-FR-Front right headlamp range control	•	•	•	•	•	0	•	
As of 01/2008	C-Class	203	Body	XALWA-R-Xenon headlamp, right	•	•	•	•	•		•	
ALL	C-Class	204	Body	XALWA-R-Xenon headlamp, right	•	•	•	•	•			
ALL	GLK	X204	Body	XALWA-R-Xenon headlamp, right	•	•	•	•	•			
ALL	CL		Body	XALWA-R-Xenon headlamp, right	•	•	•	•	•			
As of 07/2009	S-Class	221	Body	XALWA-R-Xenon headlamp, right	•	•	•	•	•			
ALL	CL		Body	XALWA-R-Xenon headlamp, right	•	•	•	•	•			
ALL	CLS	218	Body	XALWA-R-Right xenon headlamp(E2n1)	•	•	0	•	0	•		
Up to 06/2009	S-Class		Body	XALWA-R-Xenon headlamp, right	•	•	•	•	•			
As of 07/2009	S-Class	221	Body	XALWA-R-Xenon headlamp, right	•	•	•	•	•			

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 03/2008			Body	XALWA-R-Xenon headlamp, right	•	•	•	•	•	•		
	R-Class		Body	XALWA-R-Xenon headlamp, right	•	•	•	•	•			
Up to 11/2005	A-Class		Body	HRA-FL-Front left headlamp range control	•	•	•	•	•	0	0	
As of 12/2005	A-Class		Body	HRA-FL-Front left headlamp range control	•	•	•	•	•	0	0	
Up to 08/2003	C-Class	203	Body	HRA-FL-Front left headlamp range control	•	•	•	•	•	0	0	
From 09/2003 to 12/2007	C-Class	203	Body	HRA-FL-Front left headlamp range control	•	•	•	•	•	0	0	
Up to 03/2004	CLK	209	Body	HRA-FL-Front left headlamp range control	•	•	•	•	•	0	0	
As of 04/2004	CLK	209	Body	HRA-FL-Front left headlamp range control	•	•	•	•	•	0	0	
Up to 08/2002	S-Class	220	Body	HRA-FL-Front left headlamp range control	•	•	•	•	•	0	0	
As of 09/2002	S-Class	220	Body	HRA-FL-Front left headlamp range control	•	•	•	•	•	0	0	
As of 09/2002	CL	215	Body	HRA-FL-Front left headlamp range control	•	•	•	•	•	0	0	
Up to 08/2003	SL	230	Body	HRA-FL-Front left headlamp range control	•	•	•	•	•	0	0	
From 09/2003 to 05/2006	SL	230	Body	HRA-FL-Front left headlamp range control	•	•	•	•	•	0	0	
From 06/2006 to 02/2008	SL	230	Body	HRA-FL-Front left headlamp range control	•	•	•	•	•	0	0	
ALL	SLR	199	Body	HRA-FL-Front left headlamp range control	•	•	•	•	•	0	0	
	A-Class	169	Information and	PTS-Parktronic system	•	•	•	•	•	•		
As of 12/2005	B-Class	245	Information and	PTS-Parktronic system	•	•	•	•	•	•		
ALL	M-Class	164	Body	SG-DDW - DC/DC converter control unit	•	•	•	•	•	•		
ALL	C-Class	204	Information and communication	AMG PM-AMG Performance Media(N125/2)	•	•	0	•	0	•		
ALL	GLK	X204	Information and communication	AMG PM-AMG Performance Media(N125/2)	•	•	0	•	0	•		
ALL	SLS	197	Information and communication	AMG PM-AMG Performance Media(N125/2)	•	•	0	•	0	•		
ALL	SL	231	Information and communication	AMG PM-AMG Performance Media(N125/2)	•	•	0	•	0	•		
ALL	A-Class	168	Body	APS-Auto pilot system	•	•	0	•	•	*		
As of 06/97			Body	APS-Auto pilot system	•	•	0	•	•	*		
ALL			Body	APS-Auto pilot system	•	•	0	•	•	*		
			Body	APS-Auto pilot system	•	•	0	•	•	*		
As of 09/99	SL		Body	APS-Auto pilot system	•	•	0	•	•	*		
	G-Class	463 (38-pin diagnostic socket)	Body	APS-Auto pilot system	•	•	0	•	•	*		
As of 09/2006	MayBach		Body	AB-Airbag	•	•	•	•	•	•		0041 0003 0100 0119
ALL	M-Class		Body	AB-Airbag	•	•	•	•	•	•		0041 0003 0100 0119
			Body	AB-Airbag	•	•	•	•	•	•		0041 0003 0100 0119
			Body	AB-Airbag	•	•	•	•	•	•		0041 0003 0100 0119
			Body	AB-Airbag	•	•	•	•	•	•		0041 0003 0100 0119
			Body	AB-Airbag	•	•	•	•	•	•		0041 0003 0100 0119
ALL			Body	AB-Airbag	•	•	•	•	•	•		0041 0003 0100 0119
			Body	AB-Airbag	•		•	•	•	•	0	0003 0010 0041

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
From 09/2003 to 12/2007	C-Class	203	Body	AB-Airbag	•	•	•	•	•	•	0	0003 0010 0041
As of 01/2008	C-Class	203	Body	AB-Airbag	•	•	•	•	•		0	0003 0010 0041
As of 04/2004	CLK	209	Body	AB-Airbag	•	•	•	•	•	•	0	0003 0010 0041
Up to 05/2005	E-Class	211	Body	AB-Airbag	•	•	•	•	•	•	0	0003 0010 0041
From 06/2005 to 05/2006	E-Class	211	Body	AB-Airbag	•	•	•	•	•	•	0	0003 0010 0041
As of 06/2006	E-Class	211	Body	AB-Airbag	•	•	•	•	•	•	0	0003 0010 0041
Up to 05/2005	CLS		Body	AB-Airbag	•	•	•	•	•	•	0	0003 0010 0041
From 06/2005 to 05/2006	CLS		Body	AB-Airbag	•	•	•	•	•	•	0	0003 0010 0041
As of 06/2006	CLS	219	Body	AB-Airbag	•		•		•	•	0	0003 0010 0041
Up to 08/2006	MayBach		Body	AB-Airbag	$\overline{}$		•	•			0	0003 0010 0041
Up to 05/2005	SLK		Body	AB-Airbag	<u> </u>		•	•	•	•	0	0003 0010 0041
As of 06/2005	SLK		Body	AB-Airbag	•		•	•	•	•	0	0003 0010 0041
Up to 08/2002	S-Class		Body	AB-Airbag	<u> </u>		•	•	•	•	0	0041
As of 09/2002	S-Class		Body	AB-Airbag	<u> </u>		•	•	•	•	0	0041
As of 09/2002	CL		Body	AB-Airbag	<u> </u>	•	•	•	•	•	0	0041
Up to 08/2003	SL		Body	AB-Airbag	•	•	•	•	•	•	0	0041
From 09/2003 to 05/2006	SL		Body	AB-Airbag	•	•	•	•	•	•	0	0041
From 06/2006 to 02/2008	SL	230	Body	AB-Airbag	•	•	•	•	•	•	0	0041
As of 03/2008	SL	230	Body	AB-Airbag	•	•	•	•	•	•	0	0041
ALL	SLR		Body	AB-Airbag	•	•	•	•	•	•	0	0041
ALL	A-Class	168	Body	AB-Airbag	•	•	0	•	•	*	0	
As of 03/97 DAS	E-Class	210	Body	AB-Airbag	•	•	0	•	•	*	0	
Up to 08/2002	S-Class	220	Body	AB-Airbag	•	•	0	•	•	*	0	
Up to 08/2002	CL		Body	AB-Airbag	•	•	0	•	•	*	0	
Up to 08/2003	SL	230	Body	AB-Airbag	•	•	0	•	•	*	0	
ALL	M-Class	163	Body	AB-Airbag	•	•	0	•	•	*	0	
Up to 03/2004	G-Class	463 (16-pin diagnostic	Body	AB-Airbag	•	•	0	•	•	*	0	
From 04/2004 to 08/2006	G-Class	socket) 463(16-pin diagnostic socket)	Body	AB-Airbag	•	•	0	•	•	*	0	
From 09/2006 to 02/2007	G-Class	463 (16-pin diagnostic socket)	Body	AB-Airbag	•	•	0	•	•	*	0	
As of 03/2007	G-Class	463 (16-pin diagnostic socket)	Body	AB-Airbag	•	•	0	•	•	*	0	
ALL	G-Class	461(16-pin diagnostic socket)	Body	AB-Airbag	•	•	0	•	•	*	0	
Up to 08/2003	C-Class		Body	AB-Airbag	•	•	•	•	•	•	0	
Up to 03/2004	CLK	209	Body	AB-Airbag	•				•	•	0	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	M-Class	166	Chassis	Roll control-Roll control (N51/6)	•	•	0	•	0	•		
As of 04/2004	CLK	209	Drive	DTR-Distronic	•	•	•		•		0	0005
Up to 08/2002	S-Class	220	Drive	DTR-Distronic	•	•	•	•	•	•	0	0005
As of 09/2002	S-Class	220	Drive	DTR-Distronic	•	•	•	•	•	•	0	0005
As of 09/2002	CL	215	Drive	DTR-Distronic	•	•	•	•	•	•	0	0005
Up to 08/2006	MayBach	240	Drive	DTR-Distronic	•	•	•	•	•	•	0	0005
As of 09/2006	MayBach	240	Drive	DTR-Distronic	•	•	•	•	•	•	0	0005
Up to 05/2005	E-Class	211	Drive	DTR-Distronic	•	•	•	•	•	•	0	
From 06/2005 to 05/2006	E-Class	211	Drive	DTR-Distronic	•	•	•	•	•	•	0	
As of 06/2006	E-Class	211	Drive	DTR-Distronic	•	•	•	•	•	•	0	
Up to 05/2005	CLS	219	Drive	DTR-Distronic	•	•	•	•	•	•	0	
From 06/2005 to 05/2006	CLS	219	Drive	DTR-Distronic	•	•	•	•	•	•	0	
As of 06/2006	CLS	219	Drive	DTR-Distronic	•	•	•	•	•	•	0	
From 09/2003 to 05/2006	SL	230	Drive	DTR-Distronic	•	•	•	•	•	•	0	
From 06/2006 to 02/2008	SL	230	Drive	DTR-Distronic	•	•	•	•	•	•	0	
As of 03/2008	SL	230	Drive	DTR-Distronic	•	•	•	•	•	•	0	
ALL	M-Class	164	Drive	DTR-Distronic	•	•	•	•	•	•	0	
ALL	GL-Class	X 164	Drive	DTR-Distronic	•	•	•	•	•	•	0	
ALL	R-Class	251	Drive	DTR-Distronic	•	•	•	•	•	•	0	
Up to 06/2009	S-Class	221	Drive	DTR-Distronic	•	•	•	•	•	•	0	0058
ALL	CL	216	Drive	DTR-Distronic	•	•	•	•	•	•	0	0058
ALL	C-Class	204	Drive	DTR-Distronic	•	•	•	•	•	•		
ALL	CLS	218	Drive	DTR-Distronic	•	•	•	•	•	•		
As of 07/2009	S-Class	221	Drive	DTR-Distronic	•	•	•	•	•	•		
ALL	CL	216	Drive	DTR-Distronic	•	•	•	•	•	•		
ALL	SLK	172	Drive	DTR-Distronic	•	•	•	•	•	•		
ALL	GLK	X204	Drive	DTR-Distronic	•	•	•	•	•			
ALL	M-Class	164	Drive	DTR-Distronic	•	•	•	•	•	•		
ALL	M-Class	166	Drive	DTR-Distronic	•	•	•	•	•			
ALL	GL-Class	X 164	Drive	DTR-Distronic	•	•	•	•	•	•		
ALL	R-Class	251	Drive	DTR-Distronic	•	•	•	•	•	•		
ALL	E-Class	212	Drive	DTR-Distronic	•	•	•	•	•	•		
ALL	E-Class		Drive	DTR-Distronic	•	•	•	•	•	•		
ALL	SL	231	Drive	DTR-Distronic	•	•	•	•	•	•		
Up to 08/2003	C-Class	203	Drive	DTR-Distronic	•	•	•	•	•	*	0	0005
Up to 03/2004	CLK	209	Drive	DTR-Distronic	•	•	•	•	•	*	0	0005
Up to 05/2005	E-Class	211	Drive	DTR-Distronic	•	•	•	•	•	*	0	0005
Up to 08/2002	S-Class	220	Drive	DTR-Distronic	•	•	•	•	•	*		0005
As of 09/2002	S-Class	220	Drive	DTR-Distronic	•	•	•	•	•	*		0005
Up to 08/2002	CL	215	Drive	DTR-Distronic	•	•	•	•	•	*	0	0005
As of 09/2002	CL	215	Drive	DTR-Distronic	•	•	•	•	•	*	0	0005
Up to 08/2006	MayBach	240	Drive	DTR-Distronic	•	•	•	•	•	*	0	0005
Up to 08/2003	SL	230	Drive	DTR-Distronic	•	•	•		•	*	0	0005

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
From 09/2003 to 05/2006	SL	230	Drive	DTR-Distronic	•	•	•	•	•	*	0	0005
From 06/2006 to 02/2008	SL	230	Drive	DTR-Distronic	•	•	•	•	•	*	0	0005
From 06/2005 to 05/2006	E-Class	211	Seats and doors	ARWT-Automatic rear-end door	•	•	•	•	•	0	•	
As of 06/2006	E-Class	211	Seats and doors	ARWT-Automatic rear-end door	•	•	•	•	•	0	•	
ALL	SLK	172	Chassis	AIRSCARF-AIRSCARF system (N25/7)	•	•	•		•	•	lack	
ALL	E-Class	207	Chassis	AIRSCARF-AIRSCARF system (N25/7)	•	•	•		•	•	lack	
ALL	SLS		Chassis	AIRSCARF-AIRSCARF system (N25/7)	•	•	•	•	•	•	lack	
ALL	SL		Chassis	AIRSCARF-AIRSCARF system (N25/7)	•	•	•	•	•	•	<b>A</b>	
As of 03/2008	SL	230	Seats and doors	AIRSCARF	•	•	•	•	•	•		
ALL	M-Class	166	LIN Bus	LCP-Lower control panel (N72)	•	•	0	•	0	•		
ALL	B-Class	246	LIN Bus	UCP-Upper control panel (N72/1)	•	•	0	•	0	•		
ALL	M-Class	166	LIN Bus	UCP-Upper control panel (N72/1)	•	•	0	•	0	•		
ALL	CLA	117	LIN Bus	UCP-Upper control panel (N72/1)	•	•	0	•	0	•		
ALL	A-Class	176	LIN Bus	UCP-Upper control panel (N72/1)	•	•	0	•	0	•		
As of 06/97	C-Class	202	Chassis	ASR-Acceleration Slip Regulation	•	•	0	•	•	*		
ALL	CLK		Chassis	ASR-Acceleration Slip Regulation	•	•	0	•	•	*		
As of 03/97 DAS	E-Class	210	Chassis	ASR-Acceleration Slip Regulation	•	•	0	•	•	*		
As of 09/99	SL		Chassis	ASR-Acceleration Slip Regulation	•	•	0	•	•	*		
,		170 (38-pin										
ALL	SLK	diagnostic socket)	Chassis	ASR-Acceleration Slip Regulation	•	•	0	•	•	*		
As of 06/97	C-Class		Chassis	ASR-Acceleration Slip Regulation	•		0	•	•	*		
	E-Class	210	Chassis	ASR-Acceleration Slip Regulation			0	•		*		
As of 09/99	SL	129	Chassis	ASR-Acceleration Slip Regulation			0		<del>-</del>	*		
ALL	A-Class	168	Information and communication	AUDIO	•	•	•	•	•	•	•	
Up to 08/2003	C-Class	203	Information and communication	AUDIO	•	•	•	•	•	•	•	
As of 06/97	C-Class	202	Information and communication	AUDIO	•	•	•	•	•	•	•	
Up to 03/2004	CLK	209	Information and communication	AUDIO	•	•	•	•	•	•	•	
ALL	CLK	208	Information and communication	AUDIO	•	•	•	•	•	•	•	
As of 03/97 DAS 3	E-Class	210	Information and communication	AUDIO	•	•	•	•	•	•	•	
Up to 08/2002	S-Class	220	Information and communication	AUDIO	•	•	•	•	•	•	•	
As of 09/2002	S-Class	220	Information and communication	AUDIO	•	•	•	•	•	•	•	
Up to 08/2002	CL	215	Information and communication	AUDIO	•	•	•	•	•	•	•	
As of 09/2002	CL	215	Information and communication	AUDIO	•	•	•	•	•	•	•	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
Up to 08/2003	SL	230	Information and communication	AUDIO	•	•	•	•	•	•	•	
From 09/2003 to 05/2006	SL	230	Information and communication	AUDIO	•	•	•	•	•	•	•	
From 06/2006 to 02/2008	SL	230	Information and communication	AUDIO	•	•	•	•	•	•	•	
As of 09/99	SL	129	Information and communication	AUDIO	•	•	•	•	•	•	•	
ALL	SLR	199	Information and communication	AUDIO	•	•	•	•	•	•	•	
ALL	SLK	170(16-pin diagnostic socket)	Information and communication	AUDIO	•	•	•	•	•	•	•	
ALL	SLK	170(38-pin diagnostic socket)	Information and communication	AUDIO	•	•	•	•	•	•	•	
ALL	M-Class	163	Information and communication	AUDIO	•	•	•	•	•	•	•	
Up to 03/2004	G-Class	463 (16-pin diagnostic socket)	Information and communication	AUDIO	•	•	•	•	•	•	•	
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Information and communication	AUDIO	•	•	•	•	•	•	•	
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	AUDIO	•	•	•	•	•	•	•	
ALL	G-Class	463(38-pin diagnostic socket)	Information and communication	AUDIO	•	•	•	•	•	•	•	
Up to 08/2003	C-Class	203	Information and communication	D2B-COMAND, MCS or AUDIO	•	•	•	•	•	•		
Up to 03/2004	CLK	209	Information and communication	D2B-COMAND, MCS or AUDIO	•	•	•	•	•	•		
Up to 08/2003	SL	230	Information and	D2B-COMAND, MCS or AUDIO	•	•	•	•	•	•		
From 09/2003 to 05/2006	SL	230	Information and	D2B-COMAND, MCS or AUDIO	•	•	•	•	•	•		
From 06/2006 to 02/2008	SL	230	Information and communication	D2B-COMAND, MCS or AUDIO	•	•	•	•	•	•		
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Information and communication	D2B-COMAND, MCS or AUDIO	•	•	•	•	•	•		
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Information and communication	D2B-COMAND, MCS or AUDIO	•	•	•	•	•	•		

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	D2B-COMAND, MCS or AUDIO	•	•	•	•	•	•		
As of 06/97	C-Class	202	Chassis	BAS-Brake assist	•	•	0	•		*		
ALL	CLK	208	Chassis	BAS-Brake assist	•	•	0		•	*		
	E-Class	210	Chassis	BAS-Brake assist	•	•	0	•		*		
ALL	S-Class	140	Chassis	BAS-Brake assist	•	•	0		•	*		
As of 09/99	SL	129	Chassis	BAS-Brake assist	•	•	0			*		
ALL	SLK	170(38-pin diagnostic socket)	Chassis	BAS-Brake assist	•	•	0	•	•	*		
ALL	M-Class	163	Chassis	BAS-Brake assist	•	•	0	•	•	*		
Up to 08/2003	C-Class	203	Chassis	BAS-Brake assist	•	•	0	•	•	•	0	
As of 06/97	C-Class	202		BAS-Brake assist	•	•	0	•	•	•	0	
ALL	CLK	208	Chassis	BAS-Brake assist	•	•	0	•	•	•	0	
As of 03/97 DAS	E-Class	210		BAS-Brake assist	•	•	0	•	•	•	0	
	SLK	170(16-pin diagnostic socket)		BAS-Brake assist	•	•	0	•	•	•	0	
	MayBach	240	Body	BCG-Remote control(Rear control field)	•	•	•	•	•	0		0003
	MayBach	240	Body	BCG-Remote control(Rear control field)	•	•	•	•	•	0	•	0003
ALL	M-Class	166	Body	BMS-Battery management system (N82/2)	•	•	0	•	0	•		
ALL	E-Class	212	Body	BMS-Battery management system (N82/2)	•	•	0	•	0	•		
ALL	E-Class	207	Body	BMS-Battery management system (N82/2)	•	•	0	•	0	•		
ALL	SLS	197	Body	BMS-Battery management system	•	•	0	•	0	•		
ALL	SLS	197	Body	BMS-Battery management system	•	•	0	•	0	•		
ALL	SLS	197	Body	BMS-Battery management system	•	•	0	•	0	•		
As of 07/2009	S-Class	221	Body	SG-BMS - Battery management system control unit	•	•	•	•	•	•		
Up to 08/2003	SL	230	Body	BNS-Vehicle power supply control module	•	•	•	•	•	*	0	
From 09/2003 to 05/2006	SL	230	Body	BNS-Vehicle power supply control module	•	•	•	•	•	*	0	
From 06/2006 to 02/2008	SL	230	Body	BNS-Vehicle power supply control module	•	•	•	•	•	*	0	
	SL	230	Body	BNS-Vehicle power supply control module	•	•	•	•	•	*	0	
ALL	SLR	199	Body	BNS-Vehicle power supply control module	•	•	•	•	•	*	0	
	MayBach	240	Body	BNS-Vehicle power supply control module	•	•	•	•	•	0	0	
	MayBach	240		BNS-Vehicle power supply control module	•	•	•	•	•	0	0	
	M-Class	164	Body	SG-BMS - Battery management system control unit	•	•	•	•	•	•		
Up to 05/2005	E-Class	211	Body	BCM-Battery control module	•	•		•	•	•	•	
From 06/2005 to 05/2006	E-Class	211	Body	BCM-Battery control module	•	•	•	•	•	•	•	
Up to 05/2005	CLS	219	Body	BCM-Battery control module	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	CLS	219	Body	BCM-Battery control module	•	•	•	•	•	•	•	
	CLK	209	Body	On board electrical system(voltage supply)	•	•	•	•	•	•		
	E-Class	211	Body	On board electrical system(voltage supply)	•	•	•	•	•	•		
From 06/2005 to	E-Class	211		On board electrical system(voltage supply)	•	•	•	•	•	•		

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
Up to 05/2005	CLS	219	Body	On board electrical system(voltage supply)	•	•	•	•	•	•		
From 06/2005 to 05/2006	CLS	219	Body	On board electrical system(voltage supply)	•	•	•	•	•	•		
Up to 06/2009	S-Class		Body	BNS-Vehicle power supply control module	•	•		•	•	0	•	
As of 07/2009	S-Class		Body	BNS-Vehicle power supply control module	•	•	•	•	•	0	•	
ALL	CL		Body	BNS-Vehicle power supply control module	•	•	•		•	0	•	
Up to 05/2005	E-Class	211	Body	On board electrical system(voltage supply)	•	•	•	•	•	•	0	
From 06/2005 to 05/2006	E-Class		Body	On board electrical system(voltage supply)	•	•	•	•	•	•	0	
ALL	B-Class	246	Body	SAM-Signal acquisition and actuation module	•	•	0	•	0	•		
ALL	M-Class		Body	SAM-Signal acquisition and actuation module	•	•	0	•	0	•		
ALL	CLA	117	Body	SAM-Signal acquisition and actuation module	•	•	0		0	•		
ALL	A-Class	176	Body	SAM-Signal acquisition and actuation module	•	•	0	•	0	•		
As of 12/2005	A-Class	169	Information and communication	CTEL-Cellular telephone(JAPAN)	•	•	•	•	•	0		
As of 12/2005	B-Class	245	Information and communication	CTEL-Cellular telephone(JAPAN)	•	•	•	•	•	0		
As of 01/2008	C-Class	203	Information and communication	CTEL-Cellular telephone(JAPAN)	•	•	•	•	•	0		
Up to 05/2005	E-Class	211	Information and communication	CTEL-Cellular telephone(JAPAN)	•	•	•	•	•	0		
As of 06/2006	E-Class	211	Information and communication	CTEL-Cellular telephone(JAPAN)	•	•	•	•	•	0		
As of 06/2006	CLS	219	Information and communication	CTEL-Cellular telephone(JAPAN)	•	•	•	•	•	0		
As of 03/2008	SL	230	Information and communication	CTEL-Cellular telephone(JAPAN)	•	•	•	•	•	0		
Up to 05/2005	SLK	171	Information and communication	CTEL-Cellular telephone(JAPAN)	•	•	•	•	•	0		
As of 06/2005	SLK	171	Information and communication	CTEL-Cellular telephone(JAPAN)	•	•	•	•	•	0		
ALL	M-Class	164	Information and communication	CTEL-Cellular telephone(JAPAN)	•	•	•	•	•	0		
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	CTEL-Cellular telephone(JAPAN)	•	•	•	•	•	0		
ALL	GL-Class	X 164	Information and communication	CTEL-Cellular telephone(JAPAN)	•	•	•	•	•	0		
ALL	R-Class	251	Information and communication	CTEL-Cellular telephone(JAPAN)	•	•	•	•	•	0		
ALL	A-Class	168	Information and communication	CDC-CD changer	•	•	•	•	0	0	0	
Up to 08/2003	C-Class	203	Information and communication	CDC-CD changer	•	•	•	•	0	0	0	
As of 06/97	C-Class	202	Information and communication	CDC-CD changer	•	•	•	•	0	0	0	
Up to 03/2004	CLK	209	Information and	CDC-CD changer	•	•	•	•	0	0	0	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	CLK	208	Information and communication	CDC-CD changer	•	•	•	•	0	0	0	
As of 03/97 DAS 3	E-Class	210	Information and communication	CDC-CD changer	•	•	•	•	0	0	0	
Up to 08/2002	S-Class	220	Information and communication	CDC-CD changer	•	•	•	•	0	0	0	
As of 09/2002	S-Class	220	Information and communication	CDC-CD changer	•	•	•	•	0	0	0	
Up to 08/2002	CL	215	Information and communication	CDC-CD changer	•	•	•	•	0	0	0	
As of 09/2002	CL	215	Information and communication	CDC-CD changer	•	•	•	•	0	0	0	
Up to 08/2003	SL	230	Information and communication	CDC-CD changer	•	•	•	•	0	0	0	
From 09/2003 to 05/2006	SL	230	Information and communication	CDC-CD changer	•	•	•	•	0	0	0	
From 06/2006 to 02/2008	SL	230	Information and communication	CDC-CD changer	•	•	•	•	0	0	0	
As of 09/99	SL	129	Information and communication	CDC-CD changer	•	•	•	•	0	0	0	
ALL	SLR	199	Information and communication	CDC-CD changer	•	•	•	•	0	0	0	
ALL	SLK	170(16-pin diagnostic socket)	Information and communication	CDC-CD changer	•	•	•	•	0	0	0	
ALL	SLK	170(38-pin diagnostic socket)	Information and communication	CDC-CD changer	•	•	•	•	0	0	0	
ALL	M-Class	163	Information and communication	CDC-CD changer	•	•	•	•	0	0	0	
Up to 03/2004	G-Class	463 (16-pin diagnostic socket)	Information and communication	CDC-CD changer	•	•	•	•	0	0	0	
From 04/2004 to 08/2006	G-Class	463 (16-pin diagnostic socket)	Information and communication	CDC-CD changer	•	•	•	•	0	0	0	
From 09/2006 to 02/2007	G-Class	463 (16-pin diagnostic socket)	Information and communication	CDC-CD changer	•	•	•	•	0	0	0	
ALL	G-Class	463 (38-pin diagnostic socket)	Information and communication	CDC-CD changer	•	•	•	•	0	0	0	
ALL	B-Class		Drive	PTCU-Common powertrain controller(N127)	•	•	0	•	0	•		
ALL	C-Class	204	Drive	PTCU-Common powertrain controller(N127)	•	•	0	•	0	•		
ALL	GLK	X204	Drive	PTCU-Common powertrain controller(N127)	•	•	0	•	0	•		
ALL	CLA	117	Drive	PTCU-Common powertrain controller(N127)	•	•	0	•	0	•		
ALL	A-Class	176	Drive	PTCU-Common powertrain controller(N127)	•	•	0	•	0	•		
ALL	B-Class	246	Drive	PTCU-Common powertrain controller(N127)	•	•	0		0	•		

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	CLA	117	Drive	PTCU-Common powertrain controller(N127)	•	•	0	•	0	•		
ALL	A-Class	176	Drive	PTCU-Common powertrain controller(N127)	•	•	0	•	0	•		
ALL	C-Class	204	Body	CGW-Central gateway	•	•	•		•	•	0	
ALL	CLS	218	Body	CGW-Central gateway	•	•	•		•	•	0	
ALL	SLK	172	Body	CGW-Central gateway	•	•	•		•	•	0	
ALL	GLK	X204	Body	CGW-Central gateway	•	•	•		•	•	0	
ALL	E-Class	212	Body	CGW-Central gateway	•	•	•		•	•	0	
ALL	E-Class	207	Body	CGW-Central gateway	•	•	•		•	•	0	
ALL	SLS	197	Body	CGW-Central gateway	•	•	•		•	•	0	
ALL	SL	231	Body	CGW-Central gateway	•	•	•	•	•	•	0	
ALL	C-Class	204	Body	CGW-Central gateway	•	•	•	•	<b>A</b>	•		
ALL	CLS	218	Body	CGW-Central gateway	•	•	•	•	<b>A</b>	•		
ALL	SLK	172	Body	CGW-Central gateway	•	•	•	•	<b>A</b>	•		
ALL	GLK	X204	Body	CGW-Central gateway	•	•	•	•	<b>A</b>	•		
ALL	E-Class	212	Body	CGW-Central gateway	•	•	•	•	<b>A</b>	•		
ALL	E-Class	207	Body	CGW-Central gateway	•	•	•	•	<b>A</b>	•		
ALL	SLS	197	Body	CGW-Central gateway	•	•	•	•	<b>A</b>	•		
ALL	SL	231	Body	CGW-Central gateway	•	•	•	•	<b>A</b>	•		
ALL	C-Class	204	Body	CGW[ZGW]-Central gateway (CGW[ZGW])	•	•	0	•	0	•		
ALL	CLS	218	Body	CGW[ZGW]-Central gateway (CGW[ZGW])	•	•	0	•	0	•		
ALL	SLK	172	Body	CGW[ZGW]-Central gateway (CGW[ZGW])	•	•	0	•	0	•		
ALL	GLK	X204	Body	CGW[ZGW]-Central gateway (CGW[ZGW])	•	•	0	•	0	•		
ALL	E-Class	212	Body	CGW[ZGW]-Central gateway (CGW[ZGW])	•	•	0	•	0	•		
ALL	E-Class	207	Body	CGW[ZGW]-Central gateway (CGW[ZGW])	•	•	0	•	0	•		
ALL	SLS	197	Body	CGW[ZGW]-Central gateway (CGW[ZGW])	•	•	0	•	0	•		
ALL	SL	231	Body	CGW[ZGW]-Central gateway (CGW[ZGW])	•	•	0	•	0	•		
ALL	CLS	218	LIN Bus	AU-Analog clock (A70/1)	•	•	0	•	0	•		
ALL	SLK	172	LIN Bus	AU-Analog clock (A70/1)	•	•	0	•	0	•		
ALL	E-Class	212	LIN Bus	AU-Analog clock (A70/1)	•	•	0	•	0	•		
ALL	E-Class	207	LIN Bus	AU-Analog clock (A70/1)	•	•	0	•	0	•		
ALL	SL	231	LIN Bus	AU-Analog clock (A70/1)	•	•	0	•	0	•		
Up to 11/2005	B-Class	245	Information and communication	CM-Compass module	•	•	•	•	•	•	0	
As of 12/2005	B-Class	245	Information and communication	CM-Compass module	•	•	•	•	•	•	0	
ALL	M-Class	164	Information and communication	CM-Compass module	•	•	•	•	•	•	0	
ALL	GL-Class	X 164	Information and communication	CM-Compass module	•	•	•	•	•	•	0	
ALL	R-Class	251	Information and communication	CM-Compass module	•	•	•	•	•	•	0	
Up to 08/2003	C-Class	203	Information and communication	COMAND	•	•	0	•	•	•	•	
Up to 03/2004	CLK	209	Information and communication	COMAND	•	•	0	•	•	•	•	
ALL	CLK	208	Information and communication	COMAND	•	•	0	•	•	•	•	

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 03/97 DAS 3	E-Class	210	Information and communication	COMAND	•	•	0	•	•	•	•	
Up to 08/2002	S-Class	220	Information and communication	COMAND	•	•	0	•	•	•	•	
As of 09/2002	S-Class	220	Information and communication	COMAND	•	•	0	•	•	•	•	
Up to 08/2002	CL	215	Information and communication	COMAND	•	•	0	•	•	•	•	
As of 09/2002	CL	215	Information and communication	COMAND	•	•	0	•	•	•	•	
Up to 08/2003	SL	230	Information and communication	COMAND	•	•	0	•	•	•	•	
From 09/2003 to 05/2006	SL	230	Information and communication	COMAND	•	•	0	•	•	•	•	
From 06/2006 to 02/2008	SL	230	Information and communication	COMAND	•	•	0	•	•	•	•	
ALL	M-Class	163	Information and communication	COMAND	•	•	0	•	•	•	•	
Up to 03/2004	G-Class	463 (16-pin diagnostic socket)	Information and communication	COMAND	•	•	0	•	•	•	•	
From 04/2004 to 08/2006	G-Class	463 (16-pin diagnostic socket)	Information and communication	COMAND	•	•	0	•	•	•	•	
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	COMAND	•	•	0	•	•	•	•	
ALL	CLA	117	Information and communication	KAB-Control unit 'Camera cover' (N42)	•	•	0	•	0	•		
ALL	A-Class	168	Drive	CDI-Common Rail Diesel Injection	•	•				*	•	0003
As of 06/97	C-Class	202	Drive	CDI-Common Rail Diesel Injection	•	•	0	•		*		
As of 03/97 DAS	E-Class	210	Drive	CDI-Common Rail Diesel Injection	•	•	0	•		*		
Up to 08/2003	C-Class	203	Drive	CDI 2-Common Rail Diesel Injection	•	•	•		•	•	*	
From 09/2003 to 12/2007	C-Class	203	Drive	CDI 2-Common Rail Diesel Injection	•	•	•	•	•	•	*	
Up to 03/2004	CLK		Drive	CDI 2-Common Rail Diesel Injection	•	•	•	•	•	•	*	
As of 04/2004	CLK	209	Drive	CDI 2-Common Rail Diesel Injection	•	•	•	•	•	•	*	
	E-Class	210	Drive	CDI 2-Common Rail Diesel Injection	•	•	•		•	•	*	
Up to 08/2002	S-Class	220	Drive	CDI 2-Common Rail Diesel Injection	•	•	•	•	•	•	*	
ALL	M-Class	163	Drive	CDI 2-Common Rail Diesel Injection	•	•	•		•	•	*	
Up to 03/2004	G-Class	463(16-pin diagnostic socket)		CDI 2-Common Rail Diesel Injection	•	•	•	•	•	•	*	
From 04/2004 to 08/2006	G-Class	463 (16-pin diagnostic socket)		CDI 2-Common Rail Diesel Injection	•	•	•	•	•	•	*	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	G-Class	461(16-pin diagnostic socket)	Drive	CDI 2-Common Rail Diesel Injection	•	•	•	•	•	•	*	
Up to 08/2003	C-Class	203	Drive	CDI 2-Common Rail Diesel Injection	•	•	•	•	•	•	*	
From 09/2003 to 12/2007	C-Class	203	Drive	CDI 2-Common Rail Diesel Injection	•	•	•	•	•	•	*	
As of 04/2004	CLK	209	Drive	CDI 3-Common Rail Diesel Injection3	•	•	•	•	•	•	*	
Up to 05/2005	E-Class	211	Drive	CDI 3-Common Rail Diesel Injection3	•	•	•	•	•	•	*	
From 06/2005 to 05/2006	E-Class	211	Drive	CDI 3-Common Rail Diesel Injection3	•	•	•	•	•	•	*	
As of 09/2002	S-Class	220	Drive	CDI 3-Common Rail Diesel Injection3	•	•	•	•	•	•	*	
Up to 08/2003	C-Class	203	Drive	CDI 3-Common Rail Diesel Injection3	•	•	•	•	•	•	•	0019 0073 0074 0024
From 09/2003 to 12/2007	C-Class	203	Drive	CDI 3-Common Rail Diesel Injection3	•	•	•	•	•	•	•	0019 0073 0074 0024
As of 01/2008	C-Class	203	Drive	CDI 3-Common Rail Diesel Injection3	•	•	•	•	•	•	•	0019 0073 0074 0024
As of 04/2004	CLK	209	Drive	CDI 3-Common Rail Diesel Injection3	•	•	•	•	•	•	•	0019 0073 0074 0024
Up to 05/2005	E-Class	211	Drive	CDI 3-Common Rail Diesel Injection3	•	•	•	•	•	•	•	0019 0073 0074 0024
From 06/2005 to 05/2006	E-Class	211	Drive	CDI 3-Common Rail Diesel Injection3	•	•	•	•	•	•	•	0019 0073 0074 0024
As of 09/2002	S-Class	220	Drive	CDI 3-Common Rail Diesel Injection3	•	•	•	•	•	•	•	0019 0073 0074 0024
From 09/2003 to 12/2007	C-Class	203	Drive	CDI 4-Common Rail Diesel Injection	•	•	•	•	•	•	*	0013 0066 0064 0065 0019 0074
As of 04/2004	CLK	209	Drive	CDI 4-Common Rail Diesel Injection	•	•	•	•	•	•	*	0013 0066 0064 0065 0019 0074
From 06/2005 to 05/2006	E-Class	211	Drive	CDI 4-Common Rail Diesel Injection	•	•	•	•	•	•	*	0013 0066 0064 0065 0019 0074
As of 06/2006	E-Class	211	Drive	CDI 4-Common Rail Diesel Injection	•	•	•	•	•	•	*	0013 0066 0064 0065 0019 0074
Up to 05/2005	CLS	219	Drive	CDI 4-Common Rail Diesel Injection	•	•	•	•	•	•	*	0013 0066 0064 0065 0019 0074
From 06/2005 to 05/2006	CLS	219	Drive	CDI 4-Common Rail Diesel Injection	•	•	•	•	•	•	*	0013 0066 0064 0065 0019 0074
As of 06/2006	CLS	219	Drive	CDI 4-Common Rail Diesel Injection	•	•	•	•	•	•	*	0013 0066 0064 0065 0019 0074
ALL	M-Class	164	Drive	CDI 4-Common Rail Diesel Injection	•	•	•	•	•	•	*	0013 0066 0064 0065 0019 0074
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Drive	CDI 4-Common Rail Diesel Injection	•	•	•	•	•	•	*	0013 0066 0064 0065 0019 0074
As of 03/2007	G-Class	463(16-pin diagnostic socket)		CDI 4-Common Rail Diesel Injection	•	•	•	•	•	•	*	0013 0066 0064 0065 0019 0074
ALL	GL-Class	X 164	Drive	CDI 4-Common Rail Diesel Injection	•	•	•	•	•	•	*	0013 0066 0064 0065 0019 0074
ALL	R-Class	251	Drive	CDI 4-Common Rail Diesel Injection	•	•	•	•	•	•	*	0013 0066 0064 0065 0019 0074

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	G-Class	461(16-pin diagnostic socket)	Drive	CDI 4-Common Rail Diesel Injection	•	•	•	•	•			
As of 12/2005	A-Class	169	Drive	CDI-Common Rail Diesel Injection	•	•	•	•	•			
As of 12/2005	B-Class	245	Drive	CDI-Common Rail Diesel Injection	•	•	•	•	•			
ALL	CLS	218	Drive	CDI-Motor electronics 'CR42' for combustion engine 'OM607' (N3/9)	•	•	0	•	0	•		
ALL	E-Class	212	Drive	CDI-Motor electronics 'CR42' for combustion engine 'OM607' (N3/9)	•	•	0	•	0	•		
ALL	E-Class	207	Drive	CDI-Motor electronics 'CR42' for combustion engine 'OM607' (N3/9)	•	•	0	•	0	•		
ALL	CLS	218	Drive	CDI-Motor electronics 'CR43' for combustion engine 'OM651' (N3/9)	•	•	0	•	0	•		0080
ALL	M-Class	166	Drive	CDI-Motor electronics 'CR43' for combustion engine 'OM651' (N3/9)	•	•	0	•	0	•		0080
ALL	E-Class	212	Drive	CDI-Motor electronics 'CR43' for combustion engine 'OM651' (N3/9)	•	•	0	•	0	•		0080
ALL	E-Class	207	Drive	CDI-Motor electronics 'CR43' for combustion engine 'OM651' (N3/9)	•	•	0	•	0	•		0080
From 06/2005 to 05/2006	E-Class	211	Drive	CDI 5-Common Rail Diesel Injection	•	•	•	•	•	•		0013 0019 0022 0071 0024 0075 0076 0074
As of 06/2006	E-Class	211	Drive	CDI 5-Common Rail Diesel Injection	•	•	•	•	•	•		0013 0019 0022 0071 0024 0075 0076 0074
Up to 06/2009	S-Class	221	Drive	CDI 5-Common Rail Diesel Injection	•	•	•	•	•	•		0013 0019 0022 0071 0024 0075 0076 0074
As of 07/2009	S-Class	221	Drive	CDI 5-Common Rail Diesel Injection	•	•	•	•	•	•		0013 0019 0022 0071 0024 0075 0076 0074
ALL	M-Class	164	Drive	CDI 5-Common Rail Diesel Injection	•	•	•	•	•	•		0013 0019 0022 0071 0024 0075 0076 0074
ALL	GL-Class	X 164	Drive	CDI 5-Common Rail Diesel Injection	•	•	•	•	•	•		0013 0019 0022 0071 0024 0075 0076 0074
From 06/2005 to 05/2006	E-Class	211	Drive	CDI5-Common Rail Diesel Injection(USA)	•	•	•	•	•	•	•	0013 0019 0071 0024 0067 0062 0074
As of 06/2006	E-Class	211	Drive	CDI5-Common Rail Diesel Injection(USA)	•	•	•	•	•	•	•	0013 0019 0071 0024 0067 0062 0074
ALL	C-Class	204	Drive	CDI 6-Common Rail Diesel Injection	•	•	•	•	•	•		0013 0023 0024 0025 0026 0071 0074
ALL	GLK	X204	Drive	CDI 6-Common Rail Diesel Injection	•	•	•	•	•	•		0013 0023 0024 0025 0026 0071 0074
ALL	E-Class	212	Drive	CDI 6-Common Rail Diesel Injection	•	•	•	•	•	•		0013 0023 0024 0025 0026 0071 0074
ALL	E-Class	207	Drive	CDI 6-Common Rail Diesel Injection	•	•	•	•	•	•		0013 0023 0024 0025 0026 0071 0074
ALL	C-Class	204	Drive	CDI 60LS-Common Rail Diesel Injection	•	•	•	•	•			
ALL	CLS	218	Drive	CDI 60LS-Common Rail Diesel Injection	•	•	•	•	•			
As of 07/2009	S-Class		Drive	CDI 60LS-Common Rail Diesel Injection	•	•	•	•	•			
ALL	GLK		Drive	CDI 60LS-Common Rail Diesel Injection	•	•	•	•	•	<u> </u>	ļ	
ALL	M-Class	166	Drive	CDI 60LS-Common Rail Diesel Injection	•		•	•				

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	GL-Class	X 164	Drive	CDI 60LS-Common Rail Diesel Injection	•	•	•	•	•			
ALL	R-Class	251	Drive	CDI 60LS-Common Rail Diesel Injection	•	•	•	•	•			
ALL	E-Class	212	Drive	CDI 60LS-Common Rail Diesel Injection	•	•	•	•	•			
ALL	E-Class	207	Drive	CDI 60LS-Common Rail Diesel Injection	•		•	•	•			
ALL	CLS	218	Drive	CDI-Motor electronics 'CDI61' for combustion engine 'OM642' (N3/9)	•	•	0	•	0	•		0080
ALL	E-Class	212	Drive	CDI-Motor electronics 'CDI61' for combustion engine 'OM642' (N3/9)	•	•	0	•	0	•		0080
ALL	E-Class	207	Drive	CDI-Motor electronics 'CDI61' for combustion engine 'OM642' (N3/9)	•	•	0	•	0	•		0080
ALL	M-Class	164	Drive	CDI 6BIN5-Common Rail Diesel Injection	•	•	•	•	•	•		0013 0074 0024 0077 0023
ALL	GL-Class	X 164	Drive	CDI 6BIN5-Common Rail Diesel Injection	•	•	•	•	•	•		0013 0074 0024 0077 0023
ALL	R-Class	251	Drive	CDI 6BIN5-Common Rail Diesel Injection	•	•	•	•	•	•		0013 0074 0024 0077 0023
ALL	C-Class	204	Drive	CDI 6-Common Rail Diesel Injection	•	•	•	•	•			
ALL	GLK	X204	Drive	CDI 6-Common Rail Diesel Injection	•	•	•	•	•			
ALL	M-Class	164	Drive	CDI 6-Common Rail Diesel Injection	•	•	•	•	•			
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Drive	CDI 6-Common Rail Diesel Injection	•	•	•	•	•			
ALL	GL-Class	X 164	Drive	CDI 6-Common Rail Diesel Injection	•	•	•	•	•			
ALL	R-Class	251	Drive	CDI 6-Common Rail Diesel Injection	•	•	•	•	•			
ALL	E-Class	212	Drive	CDI 6-Common Rail Diesel Injection	•	•	•	•	•			
ALL	E-Class	207	Drive	CDI 6-Common Rail Diesel Injection	•	•	•	•	•			
ALL	C-Class	204	Drive	CDI 6-Common Rail Diesel Injection	•	•	•	•	•			
ALL	CLS	218	Drive	CDI 6-Common Rail Diesel Injection	•	•	•	•	•			
ALL	GLK	X204	Drive	CDI 6-Common Rail Diesel Injection	•	•	•	•	•			
ALL	M-Class	164	Drive	CDI 6-Common Rail Diesel Injection	•	•	•	•	•			
ALL	E-Class		Drive	CDI 6-Common Rail Diesel Injection	•	•	•	•	•			
ALL	E-Class		Drive	CDI 6-Common Rail Diesel Injection	•	•	•	•	•			
ALL	G-Class	461(16-pin diagnostic socket)	Drive	CDI 6-Common Rail Diesel Injection	•	•	•	•	•			
Up to 11/2005	A-Class		Drive	CDI-Common Rail Diesel Injection		•			•	•		0019 0074
As of 12/2005	A-Class		Drive	CDI-Common Rail Diesel Injection	•	•	•	•	•	•		0019 0074 0066
Up to 11/2005	B-Class	245	Drive	CDI-Common Rail Diesel Injection	•	•	•	•	•	•		0019 0074 0066
As of 12/2005	B-Class	245	Drive	CDI-Common Rail Diesel Injection	•	•	•	•	•	•		0019 0074 0066
ALL	E-Class	207	Information and communication	SG-FOND-Rear control unit (N22/6)	•	•	•	•	•	•	<b>A</b>	
ALL	SLK		Body	VDS-Vario roof control (N52)	•	•	0	•	0	•		
ALL	SLS		Body	VDS-Soft top control (N52)	•	•	0	•	0	•		
ALL	SL	231	Body	VDS-Vario roof control (N52)	•		0	•	0	•		
ALL	C-Class	204	Drive	CDID-Common Rail Diesel Injection	•	•	•	•	•	•		0013 0019 0020 0021 0074 0073
Up to 05/2005	E-Class	211	Drive	CDID-Common Rail Diesel Injection	•	•	•	•	•	•		0013 0019 0020 0021 0074 0073

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 06/2006	E-Class	211	Drive	CDID-Common Rail Diesel Injection	•	•	•	•	•	•		0013 0019 0020 0021 0074 0073
ALL	C-Class	204	Drive	CDID-Common Rail Diesel Injection	•	•	•	•	0	•	<b>A</b>	0074 0023 0024
ALL	GLK	X204	Drive	CDID-Common Rail Diesel Injection	•	•	•	•	0	•	<b>A</b>	0074 0023 0024
ALL	E-Class	212	Drive	CDID-Common Rail Diesel Injection	•	•	•	•	0	•	<b>A</b>	0074 0023 0024
ALL	E-Class	207	Drive	CDID-Common Rail Diesel Injection	•	•	•	•	0	•	<b>A</b>	0074 0023 0024
ALL	B-Class	246	Drive	CDI 3-Common Rail Diesel Injection3	•	•	•	•	•			
ALL	C-Class	204	Drive	CDI 3-Common Rail Diesel Injection3	•	•	•	•	•			
ALL	CLS	218	Drive	CDI 3-Common Rail Diesel Injection3	•	•	•	•	•			
As of 07/2009	S-Class	221	Drive	CDI 3-Common Rail Diesel Injection3	•	•	•	•	•			
ALL	SLK	172	Drive	CDI 3-Common Rail Diesel Injection3	•	•		•	•			
ALL	GLK	X204	Drive	CDI 3-Common Rail Diesel Injection3	•	•	•	•	•			
ALL	M-Class	166	Drive	CDI 3-Common Rail Diesel Injection3	•	•		•	•			
ALL	E-Class	212	Drive	CDI 3-Common Rail Diesel Injection3	•	•		•	•			
ALL	E-Class	207	Drive	CDI 3-Common Rail Diesel Injection3	•	•	•	•	•			
ALL	CLA	117	Drive	CDI 3-Common Rail Diesel Injection3	•	•	•	•	•			
ALL	A-Class	176	Drive	CDI 3-Common Rail Diesel Injection3	•	•	•	•	•			
ALL	B-Class	246	Drive	CDI-Motor electronics 'CRR1' for combustion engine 'OM607' (N3/9)	•	•	0	•	0	•		
ALL	CLA	117	Drive	CDI-Motor electronics 'CRR1' for combustion engine 'OM607' (N3/9)	•	•	0	•	0	•		
ALL	A-Class	176	Drive	CDI-Motor electronics 'CRR1' for combustion engine 'OM607' (N3/9)	•	•	0	•	0	•		
Up to 05/2005	E-Class	211	Drive	CDI-V-Common Rail Diesel Injection	•	•	•	•	•	•		
Up to 08/2002	S-Class	220	Drive	CDI-V-Common Rail Diesel Injection	•	•	•	•	•	•		
As of 09/2002	S-Class	220	Drive	CDI-V-Common Rail Diesel Injection	•	•	•	•	•	•		
ALL	M-Class	163	Drive	CDI-V-Common Rail Diesel Injection	•	•	•	•	•	•		
		463 (16-pin		-								
Up to 03/2004	G-Class	diagnostic socket)	Drive	CDI-V-Common Rail Diesel Injection	•	•	•	•	•	•		
From 04/2004 to		463(16-pin										
08/2006	G-Class	diagnostic	Drive	CDI-V-Common Rail Diesel Injection		•	•	•		•		
		socket)										
	S-Class		Body	COU [ZBE]-Central operating unit	•	•	•	•	•	•	•	
As of 07/2009	S-Class		Body	COU [ZBE]-Central operating unit	•	•	•	•	•	•	•	
ALL	CL		Body	COU [ZBE]-Central operating unit	•	•	•	•	•	•	•	
			Body	HBF (Rear control panel)-Rear control field	•	•	•	•	•	•	•	
As of 07/2009	S-Class	221	Body	HBF (Rear control panel)-Rear control field	•	•	•	•	•	•	•	
ALL	B-Class	246	Information and communication	COU [ZBE]-Central operating unit	•	•	•	•	•	•	•	
ALL	C-Class	204	Information and communication	COU [ZBE]-Central operating unit	•	•	•	•	•	•	•	
ALL	CLS	218	Information and communication	COU [ZBE]-Central operating unit	•	•	•	•	•	•	•	
ALL	SLK	172	Information and communication	COU [ZBE]-Central operating unit	•	•	•	•	•	•	•	
ALL	GLK	X204	Information and communication	COU [ZBE]-Central operating unit	•	•	•	•	•	•	•	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	M-Class	166	Information and communication	COU [ZBE]-Central operating unit	•	•	•	•	•	•	•	
ALL	E-Class	212	Information and communication	COU [ZBE]-Central operating unit	•	•	•	•	•	•	•	
ALL	E-Class	207	Information and communication	COU [ZBE]-Central operating unit	•	•	•	•	•	•	•	
ALL	SLS	197	Information and communication	COU [ZBE]-Central operating unit	•	•	•	•	•	•	•	
ALL	CLA	117	Information and communication	COU [ZBE]-Central operating unit	•	•	•	•	•	•	•	
ALL	A-Class	176	Information and communication	COU [ZBE]-Central operating unit	•	•	•	•	•	•	•	
ALL	SL	231	Information and communication	COU [ZBE]-Central operating unit	•	•	•	•	•	•	•	
ALL	C-Class	204	Information and communication	ZBE-Audio/COMAND operating unit(A40/9)	•	•	•	•	•	•		
ALL	GLK	X204	Information and communication	ZBE-Audio/COMAND operating unit(A40/9)	•	•	•	•	•	•		
ALL	E-Class	212	Information and communication	ZBE-Audio/COMAND operating unit(A40/9)	•	•	•	•	•	•		
ALL	E-Class	207	Information and communication	ZBE-Audio/COMAND operating unit(A40/9)	•	•	•	•	•	•		
ALL	C-Class	204	LIN Bus	LCP-Lower control panel (S77)	•	•	0	•	0	•		
ALL	CLS	218	LIN Bus	LCP-Lower control panel (S77)	•	•	0	•	0	•		
ALL	GLK	X204	LIN Bus	LCP-Lower control panel (S77)	•	•	0	•	0	•		
ALL	E-Class	212	LIN Bus	LCP-Lower control panel (S77)	•	•	0	•	0	•		
ALL	E-Class	207	LIN Bus	LCP-Lower control panel (S77)	•	•	0	•	0	•		
ALL	B-Class	246	Information and communication	DAB-Digital radio	•	•	•	•	•	•		
ALL	C-Class	204	Information and communication	DAB-Digital radio	•	•	•	•	•	•		
ALL	CLS	218	Information and communication	DAB-Digital radio	•	•	•	•	•	•		
Up to 06/2009	S-Class	221	Information and communication	DAB-Digital radio	•	•	•	•	•	•		
As of 07/2009	S-Class	221	Information and communication	DAB-Digital radio	•	•	•	•	•	•		
ALL	CL	216	Information and communication	DAB-Digital radio	•	•	•	•	•	•		
ALL	SLK	172	Information and communication	DAB-Digital radio	•	•	•	•	•	•		
ALL	GLK	X204	Information and communication	DAB-Digital radio	•	•	•	•	•	•		
ALL	M-Class	166	Information and communication	DAB-Digital radio	•	•	•	•	•	•		
ALL	E-Class	212	Information and communication	DAB-Digital radio	•	•	•	•	•	•		

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	E-Class	207	Information and communication	DAB-Digital radio	•	•	•	•	•	•		
ALL	SLS	197	Information and communication	DAB-Digital radio	•	•	•	•	•	•		
ALL	CLA	117	Information and communication	DAB-Digital radio	•	•	•	•	•	•		
ALL	A-Class	176	communication	DAB-Digital radio	•	•	•	•	•	•		
ALL	SL	231	Information and communication	DAB-Digital radio	•	•	•	•	•	•		
As of 12/2005	A-Class	169	Information and communication	DAB-Digital radio	•	•	•	•	•	0		
As of 12/2005	B-Class	245	communication	DAB-Digital radio	•	•	•	•	•	0		
As of 01/2008	C-Class	203	Information and communication	DAB-Digital radio	•	•	•	•	•	0		
Up to 05/2005	E-Class	211	Information and communication	DAB-Digital radio	•	•	•	•	•	0		
As of 06/2006	E-Class	211	Information and communication	DAB-Digital radio	•	•	•	•	•	0		
As of 06/2006	CLS	219	Information and communication	DAB-Digital radio	•	•	•	•	•	0		
As of 03/2008	SL	230	Information and communication	DAB-Digital radio	•	•	•	•	•	0		
Up to 05/2005	SLK	171	Information and communication	DAB-Digital radio	•	•	•	•	•	0		
As of 06/2005	SLK	171	Information and communication	DAB-Digital radio	•	•	•	•	•	0		
ALL	M-Class	164	Information and communication	DAB-Digital radio	•	•	•	•	•	0		
As of 03/2007	G-Class	463 (16-pin diagnostic socket)	Information and communication	DAB-Digital radio	•	•	•	•	•	0		
ALL	GL-Class	X 164	Information and communication	DAB-Digital radio	•	•	•	•	•	0		
ALL	R-Class	251	Information and communication	DAB-Digital radio	•	•	•	•	•	0		
ALL	B-Class	246	Information and communication	DAB-Digital Audio Broadcasting (N87/3)	•	•	0	•	0	•		
ALL	C-Class	204	Information and communication	DAB-Digital Audio Broadcasting (N87/3)	•	•	0	•	0	•		
ALL	CLS	218	Information and communication	DAB-Digital Audio Broadcasting (N87/3)	•	•	0	•	0	•		
ALL	SLK	172	Information and communication	DAB-Digital Audio Broadcasting (N87/3)	•	•	0	•	0	•		
ALL	GLK	X204	Information and communication	DAB-Digital Audio Broadcasting (N87/3)	•	•	0	•	0	•		

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
		peries	Information and		11110.	codes		codes	Data	1.1 аше	1650	
ALL	M-Class	166	communication	DAB-Digital Audio Broadcasting (N87/3)	•	•	0	•	0	•		
ALL	E-Class	212	Information and communication	DAB-Digital Audio Broadcasting (N87/3)	•	•	0	•	0	•		
ALL	E-Class	207	Information and communication	DAB-Digital Audio Broadcasting (N87/3)	•	•	0	•	0	•		
ALL	SLS	197	Information and communication	DAB-Digital Audio Broadcasting (N87/3)	•	•	0	•	0	•		
ALL	CLA	117	Information and communication	DAB-Digital Audio Broadcasting (N87/3)	•	•	0	•	0	•		
ALL	A-Class	176	Information and communication	DAB-Digital Audio Broadcasting (N87/3)	•	•	0	•	0	•		
ALL	SL	231	Information and communication	DAB-Digital Audio Broadcasting (N87/3)	•	•	0	•	0	•		
As of 06/97	C-Class	202	Body	OCP-Overhead control panel	•	•	0	•	•	*		
ALL	CLK	208	Body	OCP-Overhead control panel	•	•	0		•	*		
As of 03/97 DAS	E-Class	210	Body	OCP-Overhead control panel	•	•	0		•	*		
ALL	M-Class	164	Body	OCP-Overhead control panel	•	•			•	•	•	
ALL	GL-Class	X 164	Body	OCP-Overhead control panel	•	•			•	•	•	
ALL	R-Class	251	Body	OCP-Overhead control panel	•	•	•	•	•		•	
Up to 11/2005	A-Class	169	Body	OCP-Overhead control panel	•	•	•	•	•	0	•	
As of 12/2005	A-Class	169	Body	OCP-Overhead control panel	•	•	•	•	•	0	•	
Up to 11/2005	B-Class	245	Body	OCP-Overhead control panel	•	•	•	•	•	0	•	
As of 12/2005	B-Class	245	Body	OCP-Overhead control panel	•	•	•	•	•	0	•	
Up to 05/2005	SLK	171	Body	OCP-Overhead control panel	•	•	•	•	•	0	•	
As of 06/2005	SLK	171	Body	OCP-Overhead control panel	•	•	•	•	•	0	•	
Up to 08/2003	C-Class	203	Body	OCP-Overhead control panel	•	•	•	•	•	0	•	
From 09/2003 to 12/2007	C-Class	203	Body	OCP-Overhead control panel	•	•	•	•	•	0	•	
As of 01/2008	C-Class	203	Body	OCP-Overhead control panel	•	•	•	•	•	0	•	
Up to 03/2004	CLK	209	Body	OCP-Overhead control panel	•	•	•	•	•	0	•	
As of 04/2004	CLK	209	Body	OCP-Overhead control panel	•	•		•	•	0	•	
Up to 05/2005	E-Class	211	Body	OCP-Overhead control panel	•	•	•	•	•	0	•	0003 0011
From 06/2005 to 05/2006	E-Class	211	Body	OCP-Overhead control panel	•	•	•	•	•	0	•	0003 0011
	E-Class	211	Body	OCP-Overhead control panel	•	•	•	•	•	0	•	0003 0011
			Body	OCP-Overhead control panel	•	•	•	•	•	0		0003 0011
From 06/2005 to 05/2006	CLS	219		OCP-Overhead control panel	•	•	•	•	•	0		0003 0011
As of 06/2006	CLS	219	Body	OCP-Overhead control panel	•	•	•	•	•	0	•	0003 0011
Up to 08/2002	S-Class	220	Body	OCP-Overhead control panel			•		•	*	*	0009 0011
Up to 08/2002	CL CL	215	Body	OCP-Overhead control panel			•		-	*	*	
	S-Class	220	Body	OCP-Overhead control panel	-		•		•	0	•	
Up to 08/2002		220	Body				•	•	•	0	•	
As of 09/2002	S-Class			OCP-Overhead control panel	<u> </u>						_	
As of 09/2002	CL C. Classes	215	Body	OCP-Overhead control panel	•	•	•	•	•	0	• ·	
Up to 06/2009	S-Class	221	Body	OCP-Overhead control panel	•	•	•	•	•	•	*	
As of 07/2009	S-Class	221	Body	OCP-Overhead control panel	•	•	•	•	•	•	*	
ALL	CL	216	Body	OCP-Overhead control panel							*	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
Up to 08/2003	SL	230	Body	OCP-Overhead control panel	•	•	•	•	•	*	•	
From 09/2003 to 05/2006	SL	230	Body	OCP-Overhead control panel	•	•	•	•	•	*	•	
From 06/2006 to 02/2008	SL	230	Body	OCP-Overhead control panel	•	•	•	•	•	*	•	
As of 03/2008	SL		Body	OCP-Overhead control panel	•	•	•	•	•	*	•	
ALL	SLR		Body	OCP-Overhead control panel	•	•	•	•	•	*	•	
Up to 08/2006	MayBach		Body	OCP-Overhead control panel	•	•	•	•	•	0	•	
As of 09/2006	MayBach		Body	OCP-Overhead control panel	•	•	•	•	•	0	•	
Up to 03/2004	G-Class	463 (16-pin diagnostic socket)	Body	OCP-Overhead control panel	•	•	•	•	•	0	•	
From 04/2004 to 08/2006	G-Class	463 (16-pin diagnostic socket)	Body	OCP-Overhead control panel	•	•	•	•	•	0	•	
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)		OCP-Overhead control panel	•	•	•	•	•	0	•	
As of 03/2007	G-Class	463(16-pin diagnostic socket)		OCP-Overhead control panel	•	•	•	•	•	0	•	
Up to 11/2005	A-Class		Body	AB-Airbag	•	•	•	•	•	•		0041 0100 0101 0036
As of 12/2005	A-Class		Body	AB-Airbag	•	•	•	•	•	•		0041 0100 0101 0036
Up to 11/2005	B-Class	245	Body	AB-Airbag	•	•	•	•	•	•		0041 0100 0101 0036
As of 12/2005	B-Class		Body	AB-Airbag	•	•	•	•	•	•		0041 0100 0101 0036
ALL	SLS	197	Body	DDW-DC/DC converter (N83/1)	•	•	0	•	0	•		
ALL	B-Class	246	communication	DKG-Electronic transmission control for double- plate clutch transmission (N15/13)	•	•	0	•	0	•		
ALL	SLS	197	communication	DKG-Electronic transmission control for double- plate clutch transmission (N15/13)	•	•	0	•	0	•		
ALL	CLA	117	communication	DKG-Electronic transmission control for double- plate clutch transmission (N15/13)	•	•	0	•	0	•		
ALL	A-Class	176	communication	DKG-Electronic transmission control for double- plate clutch transmission (N15/13)	•	•	0	•	0	•		
ALL	C-Class	204	Information and communication	Left rear screen	•	•	•	•	•	•		
ALL	CLS	218	communication	Left rear screen	•	•	•	•	•	•		
Up to 06/2009	S-Class	221	Information and communication	Left rear screen	•	•	•	•	•	•		
As of 07/2009	S-Class	221	Information and communication	Left rear screen	•	•	•	•	•	•		
ALL	GLK	X204	Information and communication	Left rear screen	•	•	•	•	•	•		
ALL	M-Class	164	Information and communication	Left rear screen	•	•	•	•	•	•		
ALL	M-Class	166	Information and communication	Left rear screen	•	•	•	•	•	•		

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	GL-Class	X 164	Information and communication	Left rear screen	•	•	•	•	•	•		
ALL	R-Class	251	Information and communication	Left rear screen	•	•	•	•	•	•		
ALL	E-Class	212	Information and communication	Left rear screen	•	•	•	•	•	•		
ALL	E-Class	207	Information and communication	Left rear screen	•	•	•	•	•	•		
ALL	C-Class	204	Information and communication	Right rear screen	•	•	•	•	•	•		
ALL	CLS	218	Information and communication	Right rear screen	•	•	•	•	•	•		
Up to 06/2009	S-Class	221	Information and communication	Right rear screen	•	•	•	•	•	•		
As of 07/2009	S-Class	221	Information and	Right rear screen	•	•	•	•	•	•		
ALL	GLK	X204	Information and	Right rear screen	•	•	•	•	•	•		
ALL	M-Class	164	Information and communication	Right rear screen	•	•	•	•	•	•		
ALL	M-Class	166	Information and communication	Right rear screen	•	•	•	•	•	•		
ALL	GL-Class	X 164	Information and communication	Right rear screen	•	•	•	•	•	•		
ALL	R-Class	251	Information and	Right rear screen	•	•	•	•	•	•		
ALL	E-Class	212	Information and communication	Right rear screen	•	•	•	•	•	•		
ALL	E-Class	207	Information and communication	Right rear screen	•	•	•	•	•	•		
ALL	B-Class	246	Information and communication	ZAN-Central display	•	•	•	•	•	•		
ALL	C-Class	204	Information and communication	ZAN-Central display	•	•	•	•	•	•		
ALL	CLS	218	Information and communication	ZAN-Central display	•	•	•	•	•	•		
ALL	SLK	172	Information and	ZAN-Central display	•	•	•	•	•	•		
ALL	GLK	X204	Information and communication	ZAN-Central display	•	•	•	•	•	•		
ALL	M-Class	166	Information and	ZAN-Central display	•	•	•	•	•	•		
ALL	E-Class	212	Information and communication	ZAN-Central display	•	•	•	•	•	•		
ALL	E-Class	207	Information and communication	ZAN-Central display	•	•	•	•	•	•		
ALL	SLS	197	Information and communication	ZAN-Central display	•	•	•	•	•	•		

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	CLA	117	Information and communication	ZAN-Central display	•	•	•	•	•	•		
ALL	A-Class	176	Information and communication	ZAN-Central display	•	•	•	•	•	•		
ALL	SL	231	Information and communication	ZAN-Central display	•	•	•	•	•	•		
Up to 08/2006	MayBach	240	Body	CRN-Center roof node	•	•	0	•	•	•	•	
As of 09/2006	MayBach	240	Body	CRN-Center roof node	•	•	0	•	•	•	•	
ALL	C-Class	204	Seats and doors	DCM-FL-Door control module front left	•	•	•		•	•	•	
ALL	GLK	X204	Seats and doors	DCM-FL-Door control module front left	•	•	•	•	•	•	•	
ALL	C-Class	204	Seats and doors	DCU-LF-Left front door	•	•	•	•	•	•		
ALL	CLS	218	Seats and doors	DCU-LF-Left front door	•	•	•		•	•		
ALL	SLK	172	Seats and doors	DCU-LF-Left front door	•	•	•	•	•	•		
ALL	GLK	X204	Seats and doors	DCU-LF-Left front door	•	•	•	•	•	•		
ALL	E-Class	212	Seats and doors	DCU-LF-Left front door	•	•	•	•	•	•		
ALL	E-Class	207	Seats and doors	DCU-LF-Left front door	•	•	•	•	•	•		
ALL	SLS	197	Seats and doors	DCU-LF-Left front door	•	•	•	•	•	•		
ALL	B-Class	246		DCU-LF-Left front door (N69/1)	•	•	0	•	0	•		
ALL	M-Class	166		DCU-LF-Left front door (N69/1)	•	•	0		0			
ALL	CLA	117	Seats and doors	DCU-LF-Left front door (N69/1)			0		0			
ALL	A-Class	176	Seats and doors	DCU-LF-Left front door (N69/1)	•	•	0	•	0	•		
ALL	SL	231	Seats and doors	DCU-LF-Left front door (N69/1)	•	•	0	•	0			
ALL	C-Class	204		DCM-FR-Door control module front right	•	•	•	•	•	•	•	
ALL	GLK	X204	Seats and doors	DCM-FR-Door control module front right	•	•	•	•	•	•	•	
ALL	C-Class	204		DCU-RF-Right front door	•	•		•	•	Ā		
ALL	CLS	218		DCU-RF-Right front door	•	•	•	•		_		
ALL	SLK	172		DCU-RF-Right front door	•	•	•			<u> </u>		
ALL	GLK	X204		DCU-RF-Right front door	•	•	•	•		_		
ALL	E-Class	212		DCU-RF-Right front door		•						
ALL	E-Class	207		DCU-RF-Right front door	•	•	•	•	•			
ALL	SLS	197		DCU-RF-Right front door	•	•	•	•	•			
ALL	B-Class	246		DCU-RF-Right front door (N69/2)	•	•	0		0	-		
ALL	M-Class	166		DCU-RF-Right front door (N69/2)			0		0			
ALL	CLA	117		DCU-RF-Right front door (N69/2)			0	•	0			
ALL	A-Class	176		DCU-RF-Right front door (N69/2)			0		0			
ALL	SL SL	231		DCU-RF-Right front door (N69/2)			0		0			
ALL	C-Class	204		DCM-RL-Door control module rear left	•	•		•	•			
ALL	GLK	X204		DCM-RL-Door control module rear left  DCM-RL-Door control module rear left	•						•	
ALL	C-Class	204		DCU-LR-Left rear door	•						_	
ALL	CLS	218		DCU-LR-Left rear door DCU-LR-Left rear door	•							
ALL	GLK	X204		DCU-LR-Left rear door DCU-LR-Left rear door		•	•		•		<b>A</b>	
	E-Class	212		DCU-LR-Left rear door DCU-LR-Left rear door	•	•	•		•		<b>A</b>	
ALL	M-Class	166			•	•		•		_	_	
ALL				DCU-LR-Left rear door (N69/3)			0		0	•		
ALL	C-Class	204		DCM_RR-Door control module rear right	•	•	•	•	•	•	•	
ALL	GLK	X204		DCM-RR-Door control module rear right	•	•	•	•	•	•	•	
ALL	C-Class	204		DCU-RR-Right rear door	•	•	•	•	•	•	<u> </u>	
ALL	CLS	218		DCU-RR-Right rear door	•	•	•	•	•	•	<u> </u>	
ALL	GLK	X204	Seats and doors	DCU-RR-Right rear door						•		

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	E-Class	212	Seats and doors	DCU-RR-Right rear door	•	•	•	•	•	•	<b>A</b>	
ALL	M-Class	166	Seats and doors	DCU-RR-Right rear door (N69/4)	•	•	0	•	0	•		
ALL	M-Class	164	Information and communication	RFK-Backup camera	•	•	•	•	•	•	0	
ALL	GL-Class	X 164	Information and communication	RFK-Backup camera	•	•	•	•	•	•	0	
ALL	R-Class	251	Information and communication	RFK-Backup camera	•	•	•	•	•	•	0	
ALL	C-Class	204	Information and communication	RFK-Backup camera(B84/3)	•	•	•	•	•	•	0	
ALL	CLS	218	Information and communication	RFK-Backup camera(B84/3)	•	•	•	•	•	•	0	
Up to 06/2009	S-Class	221	Information and communication	RFK-Backup camera(B84/3)	•	•	•	•	•	•	0	
As of 07/2009	S-Class	221	Information and communication	RFK-Backup camera(B84/3)	•	•	•	•	•	•	0	
ALL	CL	216	Information and communication	RFK-Backup camera(B84/3)	•	•	•	•	•	•	0	
ALL	GLK	X204	Information and communication	RFK-Backup camera(B84/3)	•	•	•	•	•	•	0	
ALL	E-Class	212	Information and communication	RFK-Backup camera(B84/3)	•	•	•	•	•	•	0	
ALL	E-Class	207	Information and communication	RFK-Backup camera(B84/3)	•	•	•	•	•	•	0	
ALL	C-Class	204	Information and communication	AMG DRVU-AMG DRIVE UNIT (N145)	•	•	0	•	0	•		
ALL	CLS	218	Information and communication	AMG DRVU-AMG DRIVE UNIT (N145)	•	•	0	•	0	•		
ALL	GLK	X204	Information and communication	AMG DRVU-AMG DRIVE UNIT (N145)	•	•	0	•	0	•		
ALL	E-Class	212	Information and communication	AMG DRVU-AMG DRIVE UNIT (N145)	•	•	0	•	0	•		
ALL	E-Class	207	Information and communication	AMG DRVU-AMG DRIVE UNIT (N145)	•	•	0	•	0	•		
ALL	SLS	197	Information and communication	AMG DRVU-AMG DRIVE UNIT (N145)	•	•	0	•	0	•		
ALL	SL	231	Information and communication	AMG DRVU-AMG DRIVE UNIT (N145)	•	•	0	•	0	•		
As of 03/2008	SL	230	Body	AMG DRVU-AMG DRIVE UNIT (N145)	•	•	•	•	•	•		
ALL	CLS	218	Information and communication	DSI-DIRECT SELECT interface (N150)	•	•	0	•	0	•		
ALL	E-Class	212	Information and communication	DSI-DIRECT SELECT interface (N150)	•	•	0	•	0	•		
ALL	E-Class	207	Information and communication	DSI-DIRECT SELECT interface (N150)	•	•	0	•	0	•		
ALL	SLS	197	Information and communication	DSI-DIRECT SELECT interface (N150)	•	•	0	•	0	•		

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	CLA	117	Information and communication	DSI-DIRECT SELECT interface (N150)	•	•	0	•	0	•		
ALL	A-Class	176	Information and communication	DSI-DIRECT SELECT interface (N150)	•	•	0	•	0	•		
ALL	SL	231	Information and communication	DSI-DIRECT SELECT interface (N150)	•	•	0	•	0	•		
ALL	C-Class	204	Drive	ISM-Shift module (A80)		<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>		
ALL	CLS	218	Drive	ISM-Shift module (A80)	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>		
Up to 06/2009	S-Class	221	Drive	ISM-Shift module (A80)		•	<b>A</b>	•	<b>A</b>	<b>A</b>		
As of 07/2009	S-Class	221	Drive	ISM-Shift module (A80)		<b>A</b>	<b>A</b>	•	<b>A</b>	<b>A</b>		
ALL	CL	216	Drive	ISM-Shift module (A80)		<b>A</b>		<b>A</b>	<b>A</b>	<b>A</b>		
ALL	GLK	X204	Drive	ISM-Shift module (A80)		<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>		
ALL	M-Class	164	Drive	ISM-Shift module (A80)		•		•				
ALL	M-Class	166	Drive	ISM-Shift module (A80)		<b>A</b>	<b>A</b>	•	<b>A</b>	<b>A</b>		
ALL	GL-Class	X 164	Drive	ISM-Shift module (A80)	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>		
ALL	R-Class	251	Drive	ISM-Shift module (A80)		•		•				
ALL	E-Class	212	Drive	ISM-Shift module (A80)		•		•				
ALL	E-Class	207	Drive	ISM-Shift module (A80)		•		•				
ALL	SLS	197	Drive	ISM-Shift module (A80)		•	<b>A</b>	•	<b>A</b>	<b>A</b>		
ALL	SL	231	Drive	ISM-Shift module (A80)		<b>A</b>	<b>A</b>	•	<b>A</b>	<b>A</b>		
Up to 06/2009	S-Class	221	Information and communication	ZAN-Central display	•	•	•	•	•	•	*	
As of 07/2009	S-Class	221	Information and communication	ZAN-Central display	•	•	•	•	•	•	*	
ALL	CL	216	Information and communication	ZAN-Central display	•	•	•	•	•	•	*	
As of 12/2005	A-Class	169	Air conditioning	EKMK-Electric refrigerant compressor (A9/5)	•	•	•		•			
As of 12/2005	B-Class	245	Air conditioning	EKMK-Electric refrigerant compressor (A9/5)	•	•	•	•	•			
ALL	M-Class	164	Air conditioning	EKMK-Electric refrigerant compressor (A9/5)	•	•	•		•			
ALL	SLS	197	Air conditioning	EKMK-Electric refrigerant compressor (A9/5)	•	•	•		•			
ALL	C-Class	204	Air conditioning	EKMK-Electric refrigerant compressor (A9/5)	•	•	0	•	0	•		
ALL	GLK	X204	Air conditioning	EKMK-Electric refrigerant compressor (A9/5)	•	•	0	•	0	•		
ALL	E-Class	212	Air conditioning	EKMK-Electric refrigerant compressor (A9/5)	•	•	0	•	0	•		
ALL	E-Class	207	Air conditioning	EKMK-Electric refrigerant compressor (A9/5)		•	0		0	•		
ALL	M-Class	163	Body	EAM-Extended activity module	•	•	0	•	•	*	•	
ALL	B-Class	246	LIN Bus	AISP-Dimming inside rearview mirror (A67)	•	•	0	•	0	•		
ALL	CLS	218	LIN Bus	AISP-Dimming inside rearview mirror (A67)	•	•	0	•	0	•		
ALL	M-Class	166	LIN Bus	AISP-Dimming inside rearview mirror (A67)	•	•	0	•	0	•		
ALL	CLA	117	LIN Bus	AISP-Dimming inside rearview mirror (A67)	•	•	0	•	0	•		
ALL	A-Class	176	LIN Bus	AISP-Dimming inside rearview mirror (A67)	•	•	0	•	0	•		
As of 06/97	C-Class	202	Information and communication	TELE AID-Emergency call system	•	•	•	•	•	•		
ALL	CLK	208	Information and communication	TELE AID-Emergency call system	•	•	•	•	•	•		
As of 03/97 DAS 3	E-Class	210	Information and communication	TELE AID-Emergency call system	•	•	•	•	•	•		
Up to 08/2002	S-Class	220	Information and communication	TELE AID-Emergency call system	•	•	•	•	•	•		

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
Up to 08/2002	CL	215	Information and communication	TELE AID-Emergency call system	•	•	•	•	•	•		
As of 09/99	SL	129	Information and communication	TELE AID-Emergency call system	•	•	•	•	•	•		
Up to 08/2003	C-Class	203	Information and communication	E-call [Japan]-Emergency call system	•	•	0	•	•	•		
As of 06/97	C-Class	202	Information and communication	E-call [Japan]-Emergency call system	•	•	0	•	•	•		
ALL	CLK	208	Information and communication	E-call [Japan]-Emergency call system	•	•	0	•	•	•		
As of 03/97 DAS 3	E-Class	210	Information and communication	E-call [Japan]-Emergency call system	•	•	0	•	•	•		
Up to 08/2002	S-Class	220	Information and communication	E-call [Japan]-Emergency call system	•	•	0	•	•	•		
Up to 08/2002	CL	215	Information and communication	E-call [Japan]-Emergency call system	•	•	0	•	•	•		
As of 09/99	SL	129	Information and communication	E-call [Japan]-Emergency call system	•	•	0	•	•	•		
ALL	SLK	170(16-pin diagnostic socket)	Information and communication	E-call [Japan]-Emergency call system	•	•	Ο	•	•	•		
As of 06/97	C-Class	202	Information and communication	E-call [USA]-Emergency call system	•	•	•	•	0	0		
ALL	CLK	208	Information and communication	E-call [USA]-Emergency call system	•	•	•	•	0	0		
As of 03/97 DAS 3	E-Class	210	Information and communication	E-call [USA]-Emergency call system	•	•	•	•	0	0		
Up to 08/2002	S-Class	220	Information and communication	E-call [USA]-Emergency call system	•	•	•	•	0	0		
Up to 08/2002	CL	215	Information and communication	E-call [USA]-Emergency call system	•	•	•	•	0	0		
As of 09/99	SL	129	Information and communication	E-call [USA]-Emergency call system	•	•	•	•	0	0		
ALL	SLK	170(16-pin diagnostic socket)	Information and communication	E-call [USA]-Emergency call system	•	•	•	•	0	0		
Up to 11/2005	A-Class		Body	ATA-Anti-theft alarm system	•		•	•	•	0	•	
As of 12/2005	A-Class		Body	ATA-Anti-theft alarm system	•	•	•	•	•	0	•	
Up to 11/2005	B-Class		Body	ATA-Anti-theft alarm system	•	•	•	•	•	0	•	
As of 12/2005	B-Class		Body	ATA-Anti-theft alarm system	•	•	•	•	•	0	•	
ALL	A-Class		Body	ATA-Anti-theft alarm system	•	•	0	•	•	*		
Up to 06/2009	S-Class		Chassis	Electronic parking brake-Electric parking brake	•	•	•	•	•	•		0003 0048 0097 0122
As of 07/2009			Chassis	Electronic parking brake-Electric parking brake	•	•	•	•	•	•		0003 0048 0097 0122
ALL	CLC		Chassis	Electronic parking brake-Electric parking brake	•	•	•	•	•	•		0003 0048 0097 0122
ALL	SLS	197	Chassis	Electronic parking brake-Electric parking brake EFP, TPM, ISC-Electronic accelerator pedal, Cruise	•	•	•	•	•	•	•	0003 0048 0097 0122
ALL	S-Class	140	Drive	control, Idle speed control	•	•	0	•	0	*	0	

Model year	Model	Model	Control Unit	Contain Name	Ecu	Read	Event	Erase	Live	Freeze	Active	Carriel Europies
model year	Model	Series	Groups	System Name	Info.	Codes	Memory	Codes	Data	Frame	Test	Special Function
ALL	C-Class	204	Information and communication	Drive-side SAM-Front signal acquisition and actuation module (N10/1)	•	•	0	•	0	•		
ALL	GLK	X204		Drive-side SAM-Front signal acquisition and actuation module (N10/1)	•	•	0	•	0	•		
ALL	E-Class	212	Information and	Drive-side SAM-Front signal acquisition and	•	•	0	•	0	•		
ALL	E-Class	207		actuation module (N10/1) Drive-side SAM-Front signal acquisition and	•	•	0	•	0	•		
			communication	actuation module (N10/1)						·/		0040 0007
Up to 08/2003 As of 06/97	C-Class C-Class	203 202	Drive Drive	ETC Electronic transmission control		•	0	•	•	<u>*</u>	•	0048 0097 0048 0097
	C-Class E-Class	210	Drive	ETC-Electronic transmission control ETC-Electronic transmission control		•	0	•		<u>*</u>		0048 0097
Up to 08/2002	S-Class	220	Drive	ETC-Electronic transmission control		-	0	•		*		0048 0097
Up to 08/2002	CL	215	Drive	ETC-Electronic transmission control		-	0	•	•	*		0048 0097
up to 06/2002	CL	170 (16-pin	Drive	ETC-ETECTFORITE TRANSMISSION CONTROL						*	_	0040 0097
ALL	SLK	diagnostic socket)	Drive	ETC-Electronic transmission control	•	•	0	•	•	*	•	0048 0097
ALL	S-Class	140	Chassis	EGS, EAG-Electronic control for automatic transmission	•	•	0	•	0	*	0	
As of 06/97	C-Class	202	Drive	ETC-Electronic transmission control	•	•	0	•		*		
ALL	CLK	208	Drive	ETC-Electronic transmission control	•	•	0	•		*		
As of 03/97 DAS	E-Class	210	Drive	ETC-Electronic transmission control		•	0	•		*		
As of 09/99	SL	129	Drive	ETC-Electronic transmission control	•	•	0	•		*		
		170(38-pin										
ALL	SLK	diagnostic socket)	Drive	ETC-Electronic transmission control	•	•	0	•		*		
ALL	M-Class	163	Drive	ETC-Electronic transmission control	•	•	0	•		*		
ALL	G-Class	463 (38-pin diagnostic socket)		ETC-Electronic transmission control	•	•	0	•		*		
Up to 08/2003	C-Class	203	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	0048
From 09/2003 to 12/2007	C-Class	203	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	0048
As of 01/2008	C-Class	203	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	0048
As of 06/97	C-Class	202	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	0048
Up to 03/2004	CLK	209	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	0048
As of 04/2004	CLK	209	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	0048
ALL	CLK	208	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	)	0048
Up to 05/2005	E-Class	211	Drive	ETC-Electronic transmission control	•	•	•	•	•	•		0048
From 06/2005 to 05/2006	E-Class	211	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	0048
As of 06/2006	E-Class	211	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	0048
	E-Class	210	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	0048
Up to 05/2005	CLS	219	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	0048
From 06/2005 to 05/2006	CLS	219	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	0048
As of 06/2006	CLS	219	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	0048
Up to 06/2009	S-Class	221	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	0048
Up to 08/2002	S-Class	220	Drive	ETC-Electronic transmission control	•	•		•	•			0048

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 09/2002	S-Class	220	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	0048
Up to 08/2002	CL	215	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	0048
As of 09/2002	CL	215	Drive	ETC-Electronic transmission control	•	•		•	•	•	•	0048
Up to 08/2006	MayBach	240	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	0048
As of 09/2006	MayBach	240	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	0048
Up to 08/2003	SL	230	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	0048
From 09/2003 to 05/2006	SL	230	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	0048
From 06/2006 to 02/2008	SL	230	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	0048
As of 03/2008	SL	230	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	0048
ALL	SLR	199	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	0048
Up to 05/2005	SLK	171	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	0048
As of 06/2005	SLK	171	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	0048
ALL	SLK	170 (16-pin diagnostic socket)		ETC-Electronic transmission control	•	•	•	•	•	•	•	0048
ALL	M-Class	163	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	0048
Up to 03/2004	G-Class	463 (16-pin diagnostic socket)		ETC-Electronic transmission control	•	•	•	•	•	•	•	0048
From 04/2004 to 08/2006	G-Class	463 (16-pin diagnostic socket)	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	0048
From 09/2006 to 02/2007	G-Class	463 (16-pin diagnostic socket)		ETC-Electronic transmission control	•	•	•	•	•	•	•	0048
As of 03/2007	G-Class	463 (16-pin diagnostic socket)		ETC-Electronic transmission control	•	•	•	•	•	•	•	0048
ALL	G-Class	461(16-pin diagnostic socket)		ETC-Electronic transmission control	•	•	•	•	•	•	•	0048
ALL	C-Class	204	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	
As of 01/2008	C-Class	203	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	
	CLK	209	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	
As of 04/2004	CLK	209	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	
Up to 05/2005	E-Class	211	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	E-Class	211	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	
As of 06/2006	E-Class	211	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	
	S-Class	221	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	
	S-Class	221	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	
ALL	CL	216	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	
Up to 08/2006	MayBach	240	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	
	MayBach	240	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	
From 09/2003 to 05/2006	SL	230	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
From 06/2006 to 02/2008	SL	230	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	
As of 03/2008	SL	230	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	
As of 06/2005	SLK	171	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	
ALL	GLK	X204	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)		ETC-Electronic transmission control	•	•	•	•	•	•	•	
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)		ETC-Electronic transmission control	•	•	•	•	•	•	•	
As of 03/2007	G-Class	463 (16-pin diagnostic socket)	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	
ALL	G-Class	461 (16-pin diagnostic socket)	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	
ALL	E-Class		Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	
ALL	E-Class	207	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	•	
Up to 08/2006	MayBach	240	Chassis	SBC-Sensotronic Brake Control	•	•	•	•	•	0	0	0006 0007 0008 0123 0124 0125 0126 0127 0128 0129 0130 0131 0132 0124 0125 0133
As of 09/2006	MayBach	240	Chassis	SBC-Sensotronic Brake Control	•	•	•	•	•	0	0	0006 0007 0008 0123 0124 0125 0126 0127 0128 0129 0130 0131 0132 0124 0125 0133
Up to 08/2003	SL	230	Chassis	SBC-Sensotronic Brake Control	•	•	•	•	•	0	0	0006 0007 0008 0123 0124 0125 0126 0127 0128 0129 0130 0131 0132 0124 0125 0133
	SLR		Chassis	SBC-Sensotronic Brake Control	•	•	•	•	•	0	0	0006 0007 0008 0123 0124 0125 0126 0127 0128 0129 0130 0131 0132 0124 0125 0133
	E-Class	211	Chassis	SBC-Sensotronic Brake Control	•	•	•	•	•	•		0006 0007 0008
05/2006	E-Class	211	Chassis	SBC-Sensotronic Brake Control	•	•	•	•	•	•		0006 0007 0008
From 09/2003 to 05/2006	SL	230	Chassis	SBC-Sensotronic Brake Control	•	•	•	•	•	•		0006 0007 0008
From 06/2006 to 02/2008	SL	230	Chassis	SBC-Sensotronic Brake Control	•	•	•	•	•	•		0006 0007 0008
Up to 05/2005	E-Class	211	Chassis	SBC-Sensotronic Brake Control	•	•	•	•	•	•		0006 0007 0008 0038 0039

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
From 06/2005 to 05/2006	E-Class	211	Chassis	SBC-Sensotronic Brake Control	•	•	•	•	•	•		0006 0007 0008 0038 0039
Up to 05/2005	CLS	219	Chassis	SBC-Sensotronic Brake Control	•	•	•	•	•	•		0006 0007 0008 0038 0039
From 06/2005 to 05/2006	CLS	219	Chassis	SBC-Sensotronic Brake Control	•	•	•	•	•	•		0006 0007 0008 0038 0039
From 09/2003 to 05/2006	SL	230	Chassis	SBC-Sensotronic Brake Control	•	•	•	•	•	•		0006 0007 0008 0038 0039
From 06/2006 to 02/2008	SL	230	Chassis	SBC-Sensotronic Brake Control	•	•	•	•	•	•		0006 0007 0008 0038 0039
As of 03/2008	SL	230	Chassis	SBC-Sensotronic Brake Control	•	•	•	•	•	•		0006 0007 0008 0038 0039
Up to 08/2006	MayBach	240	Chassis	SBC-Right Sensotronic Brake Control	•	•	•	•	•	0		0006 0007 0008 0038 0039
As of 09/2006	MayBach	240	Chassis	SBC-Right Sensotronic Brake Control	•	•	•	•	•	0		0006 0007 0008 0038 0039
Up to 05/2005	E-Class	211	Chassis	ESP-Electronic stability program	•	•	•	•	•	•	•	0014
From 06/2005 to 05/2006	E-Class	211	Chassis	ESP-Electronic stability program	•	•	•	•	•	•	•	0014
Up to 08/2006	MayBach	240	Chassis	ESP-Electronic stability program	•	•	•	•	•	•	•	0014
As of 09/2006	MayBach	240	Chassis	ESP-Electronic stability program	•	•	•	•	•	•	•	0014
Up to 08/2003	SL	230	Chassis	ESP-Electronic stability program	•	•	•	•	•	•	•	0014
From 09/2003 to 05/2006	SL	230	Chassis	ESP-Electronic stability program	•	•	•	•	•	•	•	0014
From 06/2006 to 02/2008	SL	230	Chassis	ESP-Electronic stability program	•	•	•	•	•	•	•	0014
ALL	SLR	199	Chassis	ESP-Electronic stability program	•	•	•	•	•	•	•	0014
Up to 05/2005	E-Class	211	Chassis	Suspension	•	•	•	•	•	•	*	0042
From 06/2005 to 05/2006	E-Class	211	Chassis	Suspension	•	•	•	•	•	•	*	0042
As of 06/2006	E-Class	211	Chassis	Suspension	•	•	•	•	•	•	*	0042
ALL	R-Class	251	Chassis	Suspension	•	•	•	•	•	•	*	0042
ALL	M-Class	164	Chassis	EHPS-Electrohydraulic Power Steering	•	•	•	•	•			
ALL	GL-Class	X 164	Chassis	EHPS-Electrohydraulic Power Steering	•	•	•	•	•			
ALL	R-Class	251	Chassis	EHPS-Electrohydraulic Power Steering	•	•	•	•	•			
ALL	C-Class	204	Chassis	EHPS-Electrohydraulic Power Steering	•	•	•	•	•			
As of 07/2009 ALL	S-Class CL	221 216	Chassis Chassis	EHPS-Electrohydraulic Power Steering EHPS-Electrohydraulic Power Steering	•	•	•	•	•	<del>                                     </del>		
ALL	SLK	172	Chassis	EHPS-Electronydraulic Power Steering EHPS-Electrohydraulic Power Steering		•	•		•	<del>                                     </del>		
ALL	GLK	X204	Chassis	EHPS-Electrohydraulic Power Steering		•	•	•	•	<del>                                     </del>		
ALL	SLS	197	Chassis	EHPS-Electrohydraulic Power Steering	•	•	•	•				
ALL	M-Class	164	Body	EZS-Electronic ignition switch	•	•	•	•	•	•	0	
ALL	GL-Class	X 164	Body	EZS-Electronic ignition switch	•	•	•	•	•	•	0	
ALL	R-Class	251	Body	EZS-Electronic ignition switch	•	•	•	•	•	•	0	
ALL	C-Class	204	Body	EZS-Electronic ignition switch	•	•	•	•	•	•	0	
ALL	GLK	X204	Body	EZS-Electronic ignition switch	•	•	•	•	•	•	0	
ALL	E-Class	207	Body	EZS-Electronic ignition switch	•	•	•	•	•	•	0	
ALL	C-Class	204	Body	EZS-Electronic ignition lock	•	•	•	•	•	•	<b>A</b>	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	CLS	218	Body	EZS-Electronic ignition lock	•	•	•	•	•	•	<b>A</b>	
ALL	SLK	172	Body	EZS-Electronic ignition lock	•	•		•	•	•		
ALL	GLK	X204	Body	EZS-Electronic ignition lock	•	•	•	•	•	•	<b>A</b>	
ALL	E-Class	212	Body	EZS-Electronic ignition lock	•	•	•	•	•	•	<b>A</b>	
ALL	SLS	197	Body	EZS-Electronic ignition lock	•	•		•	•	•		
ALL	B-Class	246	Body	EZS-Electronic ignition switch	•	•	0		0	•		
ALL	M-Class	166	Body	EZS-Electronic ignition switch	•	•	0		0	•		
ALL	CLA	117	Body	EZS-Electronic ignition switch	•	•	0		0	•		
ALL	A-Class	176	Body	EZS-Electronic ignition switch	•	•	0	•	0	•		
Up to 06/2009	S-Class	221	Body	EZS-Electronic ignition switch	•	•		•	•			
As of 07/2009	S-Class	221	Body	EZS-Electronic ignition switch	•	•		•	•			
ALL	CL	216	Body	EZS-Electronic ignition switch	•	•		•	•			
ALL	B-Class	246	Chassis	EFB-Electronic parking break (N128)	•	•	0	•	0	•		
ALL	SLK	172	Chassis	EFB-Electronic parking break (N128)	•	•	0	•	0	•		
ALL	M-Class	166	Chassis	EFB-Electronic parking break (N128)	•	•	0	•	0	•		
ALL	SLS	197	Chassis	EFB-Electronic parking break (N128)	•	•	0	•	0	•		
ALL	CLA	117	Chassis	EFB-Electronic parking break (N128)	•	•	0	•	0	•		
ALL	A-Class	176	Chassis	EFB-Electronic parking break (N128)	•	•	0	•	0	•		
ALL	SL	231	Chassis	EFB-Electronic parking break (N128)	•	•	0	•	0	•		
Up to 11/2005	A-Class	169	Chassis	ES-Electrical power steering	•	•	•	•	•	0	0	0012
As of 12/2005	A-Class	169	Chassis	ES-Electrical power steering	•	•	•	•	•	0	0	0012
Up to 11/2005	B-Class	245	Chassis	ES-Electrical power steering	•	•	•	•	•	0	0	0012
As of 12/2005	B-Class	245	Chassis	ES-Electrical power steering	•	•	•	•	•	0	0	0012
ALL	C-Class	204	Information and communication	ES-Electrical power steering	•	•	•	•	•	0		
ALL	CLS	218	Information and communication	ES-Electrical power steering	•	•	•	•	•	0		
ALL	GLK	X204	Information and communication	ES-Electrical power steering	•	•	•	•	•	0		
ALL	E-Class	212	Information and communication	ES-Electrical power steering	•	•	•	•	•	0		
ALL	E-Class	207	Information and communication	ES-Electrical power steering	•	•	•	•	•	0		
ALL	SL	231	Information and communication	ES-Electrical power steering	•	•	•	•	•	0		
ALL	C-Class	204	Chassis	ES-Electrical power steering (N68)	•	•	0	•	0	•		
ALL	CLS	218	Chassis	ES-Electrical power steering (N68)	•	•	0	•	0	•		
ALL	GLK	X204	Chassis	ES-Electrical power steering (N68)	•	•	0	•	0	•		
ALL	M-Class	166	Chassis	ES-Electrical power steering (N68)	•	•	0	•	0	•		
ALL	E-Class	212	Chassis	ES-Electrical power steering (N68)	•	•	0	•	0	•		
ALL	E-Class	207	Chassis	ES-Electrical power steering (N68)	•	•	0	•	0	•		
ALL	B-Class	246	Chassis	ES-Electrical power steering (N68)	•	•	0	•	0	•		
ALL	CLA	117	Chassis	ES-Electrical power steering (N68)	•	•	0	•	0	•		
ALL	A-Class	176	Chassis	ES-Electrical power steering (N68)	•	•	0	•	0	•		
As of 06/97	C-Class	202	Drive	IFI-Electronic in-line injection system diesel	•	•	0	•		*		
As of 03/97 DAS		210	Drive	IFI-Electronic in-line injection system diesel	•	•	0	•		*		

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	G-Class	463(38-pin diagnostic socket)	Drive	IFI-Electronic in-line injection system diesel	•	•	0	•		*		
Up to 08/2002	S-Class	220	Chassis	ESP-Electronic stability program	•	•		•	•	*	•	
As of 09/2002	S-Class	220	Chassis	ESP-Electronic stability program	•	•	•	•	•	*	•	
Up to 08/2002	CL	215	Chassis	ESP-Electronic stability program	•	•	•	•	•	*	•	
As of 09/2002	CL	215	Chassis	ESP-Electronic stability program	•	•	•	•	•	*	•	
Up to 03/2004	G-Class	463 (16-pin diagnostic socket)	Chassis	ESP-Electronic stability program	•	•	•	•	•	*	•	
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)		ESP-Electronic stability program	•	•	•	•	•	*	•	
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Chassis	ESP-Electronic stability program	•	•	•	•	•	*	•	
As of 03/2007	G-Class	463(16-pin diagnostic socket)		ESP-Electronic stability program	•	•	•	•	•	*	•	
ALL	C-Class	204	Chassis	ABR-Adaptive Brake	•	•		•	•	•	•	0047, 0015
ALL	GLK	X204	Chassis	ABR-Adaptive Brake	•	•	•	•	•	•	•	0047, 0015
ALL	M-Class	164	Chassis	ESP-Electronic stability program	•	•	•	•	•	•		0050, 0047, 0015 0014 0093
ALL	GL-Class	X 164	Chassis	ESP-Electronic stability program	•	•		•	•	•		0005, 0047, 0015
ALL	R-Class	251	Chassis	ESP-Electronic stability program	•	•	•	•	•	•		0005, 0047, 0015
ALL	M-Class	166	Chassis	ESP-Electronic stability program (N30/4)	•	•	0	•	0	•		
Up to 11/2005	A-Class	169	Chassis	ESP-Electronic stability program	•	•	•	•	•	•		0015 0142 0014 0143 0111 0144
As of 12/2005	A-Class	169	Chassis	ESP-Electronic stability program	•	•	•	•	•	•		0015 0142 0014 0143 0111 0144
Up to 11/2005	B-Class	245	Chassis	ESP-Electronic stability program	•	•	•	•	•	•		0015 0142 0014 0143 0111 0144
As of 12/2005	B-Class	245	Chassis	ESP-Electronic stability program	•	•	•	•	•	•		0015 0142 0014 0143 0111 0144
ALL	SLS	197	Chassis	ESP-Electronic stability program (N30/4)	•	•	0	•	0	•		
ALL	SLS	197	Chassis	ESP-Electronic stability program (N30/4)	•	•	0	•	0	•		
Up to 08/2003	C-Class		Chassis	ESP-Electronic stability program	•	•	•	•	•	•	0	0047
As of 06/97	C-Class		Chassis	ESP-Electronic stability program	•	•	•	•	•	•	0	0047
ALL	CLK	208	Chassis	ESP-Electronic stability program	•	•	•	•	•	•	0	0047
	E-Class		Chassis	ESP-Electronic stability program	•	•	•	•	•	•	0	0047
Up to 08/2003	C-Class		Chassis	ESP-Electronic stability program	•	•	•	•	•	•		0047
ALL	SLK	170 (16-pin diagnostic socket)		ESP-Electronic stability program	•	•	•	•	•	•		0047
ALL	C-Class		Chassis	ESP-Electronic stability program	•	•	•	•	•	•	<b>A</b>	
ALL	CLS		Chassis	ESP-Electronic stability program	•	•	•	•	•	•	<b>A</b>	
ALL	GLK		Chassis	ESP-Electronic stability program	•	•	•	•	•	•	<b>A</b>	
ALL	E-Class	212	Chassis	ESP-Electronic stability program	•	•				•		

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	E-Class	207	Chassis	ESP-Electronic stability program	•	•	•	•	•	•		
ALL	A-Class	168	Chassis	ESP-Electronic stability program	•	•	0	•	•	*		0040
As of 06/97	C-Class	202	Chassis	ESP-Electronic stability program	•	•	0	•	•	*		0040
As of 03/97 DAS	E-Class	210	Chassis	ESP-Electronic stability program	•	•	0	•	•	*		0040
As of 09/99	SL	129	Chassis	ESP-Electronic stability program	•	•	0	•	•	*		0040
ALL	M-Class	163	Chassis	ESP-Electronic stability program	•	•	0	•	•	*		0040
ALL	A-Class	168	Chassis	ESP-Electronic stability program	•	•	0	•	•	*		
As of 06/97	C-Class	202	Chassis	ESP-Electronic stability program	•	•	0	•	•	*		
ALL	CLK	208	Chassis	ESP-Electronic stability program	•	•	0	•	•	*		
As of 03/97 DAS	E-Class	210	Chassis	ESP-Electronic stability program	•	•	0	•	•	*		
As of 09/99	SL	129	Chassis	ESP-Electronic stability program	•	•	0	•	•	*		
ALL	M-Class	163	Chassis	ESP-Electronic stability program	•	•	0	•	•	*		
As of 06/97	C-Class	202	Chassis	ESP-Electronic stability program		•	0	•	•	*		
As of 03/97 DAS	E-Class	210	Chassis	ESP-Electronic stability program		•	0	•	•	*		
ALL	S-Class	140	Chassis	ESP-Electronic stability program		•	0	•	•	*		
As of 09/99	SL	129	Chassis	ESP-Electronic stability program		•	0	•	•	*		
ALL	M-Class	163	Chassis	ESP-Electronic stability program		•	0	•	•	*		
From 09/2006 to 02/2007	G-Class	463 (16-pin diagnostic socket)	Chassis	ESP-Electronic stability program	•	•	•	•	•	•	0	
As of 03/2007	G-Class	463(16-pin diagnostic socket)		ESP-Electronic stability program	•	•	•	•	•	•	0	
ALL	CLS	218	Chassis	ESP-Electronic stability program (N30/4)	•		0	•	0	•		
ALL	E-Class	212	Chassis	ESP-Electronic stability program (N30/4)	•		0	•	0	•		
ALL	E-Class	207	Chassis	ESP-Electronic stability program (N30/4)	•	•	0	•	0	•		
ALL	B-Class	246	Chassis	ESP-Electronic stability program (N30/4)	•	•	0	•	0	•		
ALL	CLA	117	Chassis	ESP-Electronic stability program (N30/4)	•	•	0	•	0	•		
ALL	A-Class	176	Chassis	ESP-Electronic stability program (N30/4)	•	•	0	•	0	•		
ALL	SL	231	Chassis	ESP-Electronic stability program (N30/4)	•	•	0	•	0	•		
Up to 08/2003	C-Class	203	Chassis	ESP-Electronic stability program		•	•	•	•	•		0047, 0015
From 09/2003 to 12/2007	C-Class	203	Chassis	ESP-Electronic stability program	•	•	•	•	•	•		0047, 0015
As of 01/2008	C-Class	203	Chassis	ESP-Electronic stability program	•	•	•	•	•	•		0047, 0015
Up to 03/2004	CLK	209	Chassis	ESP-Electronic stability program	•	•	•	•	•	•		0047, 0015
As of 04/2004	CLK	209	Chassis	ESP-Electronic stability program	•	•	•	•	•	•		0047, 0015
	SLK	171	Chassis	ESP-Electronic stability program	•	•	•	•	•	•		0047, 0015
As of 06/2005	SLK	171	Chassis	ESP-Electronic stability program		•	•	•	•	•		0047, 0015
ALL	SLK	170(16-pin diagnostic socket)	Chassis	ESP-Electronic stability program	•	•	•	•	•	•		0047, 0015
ALL	M-Class	163	Chassis	ESP-Electronic stability program	•	•	•	•	•	•		0047, 0015
ALL	CLK	208	Seats and doors	ESA-FL-Electric seat adjustment front left	•	•	0	•	•	*		
	E-Class	210	Seats and doors	ESA-FL-Electric seat adjustment front left	•	•	0	•	•	*		
ALL	CLK	208		ESA-FR-Electric seat adjustment front right	•	•	0	•	•	*		
	E-Class	210		ESA-FR-Electric seat adjustment front right	•	•	0	•	•	*		
As of 06/97	C-Class	202	Chassis	ETS-Electronic traction system	•	•	0	•	•	*		
	E-Class	210	Chassis	ETS-Electronic traction system	•	•	0	•	•	*		

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 09/99	SL	129	Chassis	ETS-Electronic traction system	•	•	0	•	•	*		
ALL	SLK	170(38-pin diagnostic socket)	Chassis	ETS-Electronic traction system	•	•	0	•	•	*		
ALL	M-Class	163	Chassis	ETS-Electronic traction system	•	•	0	•	•	*		
As of 06/97	C-Class	202	Chassis	ETS-Electronic traction system	•	•	0		•	*		
As of 03/97 DAS	E-Class	210	Chassis	ETS-Electronic traction system	•	•	0		•	*		
ALL	M-Class	163	Chassis	ETS-Electronic traction system	•	•	0		•	*		
As of 06/97	C-Class	202	Drive	DFI-Electronic distributor injection system	•	•	0	•		*		
As of 03/97 DAS	E-Class	210	Drive	DFI-Electronic distributor injection system	•	•	0	•		*		
Up to 11/2005	A-Class	169	Drive	ESM-Electronic selector module	•	•	•	•	•	0	•	0003
As of 12/2005	A-Class	169	Drive	ESM-Electronic selector module	•	•		•	•	0	•	0003
Up to 11/2005	B-Class	245	Drive	ESM-Electronic selector module	•	•			•	0	•	0003
As of 12/2005	B-Class	245	Drive	ESM-Electronic selector module	•	•			•	0	•	0003
Up to 08/2003	C-Class	203	Drive	ESM-Electronic selector module	•	•	•	•	•	0	•	0003
From 09/2003 to 12/2007	C-Class	203	Drive	ESM-Electronic selector module	•	•	•	•	•	0	•	0003
As of 01/2008	C-Class	203	Drive	ESM-Electronic selector module	•	•	•	•	•	0	•	0003
Up to 03/2004	CLK	209	Drive	ESM-Electronic selector module	•	•	•	•	•	0	•	0003
As of 04/2004	CLK	209	Drive	ESM-Electronic selector module	•	•	•	•	•	0	•	0003
Up to 05/2005	E-Class	211	Drive	ESM-Electronic selector module	•	•	•	•	•	0	•	0003
From 06/2005 to 05/2006	E-Class	211	Drive	ESM-Electronic selector module	•	•	•	•	•	0	•	0003
As of 06/2006	E-Class	211	Drive	ESM-Electronic selector module	•	•	•	•	•	0	•	0003
Up to 05/2005	CLS	219	Drive	ESM-Electronic selector module	•	•		•	•	0	•	0003
From 06/2005 to 05/2006	CLS	219	Drive	ESM-Electronic selector module	•	•	•	•	•	0	•	0003
As of 06/2006	CLS	219	Drive	ESM-Electronic selector module	•	•	•	•	•	0	•	0003
Up to 05/2005	SLK	171	Drive	ESM-Electronic selector module	•	•	•	•	•	0	•	0003
As of 06/2005	SLK	171	Drive	ESM-Electronic selector module	•	•	•	•	•	0	•	0003
As of 06/97	C-Class	202	Drive	ESM-Electronic selector module	•	•	0	•	•	*	•	
ALL	CLK	208	Drive	ESM-Electronic selector module	•	•	0	•	•	*	•	
As of 03/97 DAS	E-Class	210	Drive	ESM-Electronic selector module	•	•	0	•	•	*	•	
ALL	SLK	170 (16-pin diagnostic socket)		ESM-Electronic selector module	•	•	0	•	•	*	•	
ALL	M-Class		Drive	ESM-Electronic selector module	•	•	0	•	•	*	•	
		463(16-pin			-							
Up to 03/2004	G-Class	diagnostic socket)	Drive	ESM-Electronic selector module	•	•	0	•	•	*	•	
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Drive	ESM-Electronic selector module	•	•	0	•	•	*	•	
From 09/2006 to 02/2007	G-Class	463 (16-pin diagnostic socket)		ESM-Electronic selector module	•	•	0	•	•	*	•	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 03/2007	G-Class	463 (16-pin diagnostic socket)	Drive	ESM-Electronic selector module	•	•	0	•	•	*	•	
ALL	G-Class	463 (38-pin diagnostic socket)	Drive	ESM-Electronic selector module	•	•	0	•	•	*	•	
ALL	G-Class	461 (16-pin diagnostic socket)	Drive	ESM-Electronic selector module	•	•	0	•	•	*	•	
Up to 08/2002	S-Class	220	Drive	ESM-Electronic selector module	•	•	•	•	•	*	•	
As of 09/2002	S-Class		Drive	ESM-Electronic selector module	•	•	•	•	•	*	•	
Up to 08/2002	CL		Drive	ESM-Electronic selector module	•	•	•	•	•	*	•	
As of 09/2002	CL		Drive	ESM-Electronic selector module	•	•	•	•	•	*	•	
Up to 08/2006	MayBach		Drive	ESM-Electronic selector module	•	•	•	•	•	*	•	
As of 09/2006	MavBach		Drive	ESM-Electronic selector module	•	•	•	•	•	*	•	
Up to 08/2003	SL	•	Drive	ESM-Electronic selector module	•	•	•	•	•	*	•	
From 09/2003 to 05/2006	SL		Drive	ESM-Electronic selector module	•	•	•	•	•	*	•	
From 06/2006 to 02/2008	SL		Drive	ESM-Electronic selector module	•	•	•	•	•	*	•	
As of 03/2008	SL	230	Drive	ESM-Electronic selector module	•	•		•	•	*	•	
ALL	SLR		Drive	ESM-Electronic selector module	•	•	•	•	•	*	•	
ALL	A-Class	168	Drive	GRM-Gear recognition module	•	•	•	•	•	*	•	
As of 06/97	C-Class	202	Body	EZS-Electronic ignition switch	•	•	0		•	*		
ALL	CLK	208	Body	EZS-Electronic ignition switch	•	•	0		•	*		
As of 03/97 DAS	E-Class	210	Body	EZS-Electronic ignition switch	•	•	0		•	*		
ALL	M-Class	164	Body	EZS-Electronic ignition switch	•		•		•	0	0	
ALL	GL-Class	X 164	Body	EZS-Electronic ignition switch	•	•	•	•	•	0	0	
ALL	R-Class	251	Body	EZS-Electronic ignition switch	•	•	•	•	•	0	0	
Up to 11/2005	A-Class	169	Body	EZS-Electronic ignition switch	•	•	•	•	•	0	0	0034
As of 12/2005	A-Class	169	Body	EZS-Electronic ignition switch	•	•	•	•	•	0	0	0034
Up to 11/2005	B-Class	245	Body	EZS-Electronic ignition switch	•	•	•	•	•	0	0	0034
As of 12/2005	B-Class	245	Body	EZS-Electronic ignition switch	•	•	•	•	•	0	0	0034
Up to 08/2003	C-Class	203	Body	EZS-Electronic ignition switch	•	•	•	•	•	0	0	0034
Up to 08/2003	C-Class	203	Body	EZS-Electronic ignition switch	•	•	•	•	•	0	0	0034
From 09/2003 to 12/2007	C-Class	203	Body	EZS-Electronic ignition switch	•	•	•	•	•	0	0	0034
As of 01/2008	C-Class	203	Body	EZS-Electronic ignition switch	•	•	•	•	•	0	0	0034
Up to 03/2004	CLK	+	Body	EZS-Electronic ignition switch	•	•	•	•	•	0	0	0034
As of 04/2004	CLK		Body	EZS-Electronic ignition switch	•	•	•	•	•	0		0034
	G-Class	463(16-pin diagnostic socket)		EZS-Electronic ignition switch	•	•	•	•	•	0		0034
From 04/2004 to 08/2006	G-Class	463 (16-pin diagnostic socket)	Body	EZS-Electronic ignition switch	•	•	•	•	•	0	0	0034

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Body	EZS-Electronic ignition switch	•	•	•	•	•	0	0	0034
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Body	EZS-Electronic ignition switch	•	•	•	•	•	0	0	0034
Up to 05/2005	E-Class	211	Body	EZS-Electronic ignition switch	•	•	•	•	•	0	*	0027 0028 0029 0030 0031 0032 0033 0034 0035 0036 0037
From 06/2005 to 05/2006	E-Class	211	Body	EZS-Electronic ignition switch	•	•	•	•	•	0	*	0027 0028 0029 0030 0031 0032 0033 0034 0035 0036 0037
As of 06/2006	E-Class	211	Body	EZS-Electronic ignition switch	•	•	•	•	•	0	*	0027 0028 0029 0030 0031 0032 0033 0034 0035 0036 0037
Up to 05/2005	CLS	219	Body	EZS-Electronic ignition switch	•	•	•	•	•	0	*	0027 0028 0029 0030 0031 0032 0033 0034 0035 0036 0037
From 06/2005 to 05/2006	CLS	219	Body	EZS-Electronic ignition switch	•	•	•	•	•	0	*	0027 0028 0029 0030 0031 0032 0033 0034 0035 0036 0037
As of 06/2006	CLS	219	Body	EZS-Electronic ignition switch	•	•	•	•	•	0	*	0027 0028 0029 0030 0031 0032 0033 0034 0035 0036 0037
Up to 05/2005	SLK	171	Body	EZS-Electronic ignition switch	•	•	•	•	•	0	*	0027 0028 0029 0030 0031 0032 0033 0034 0035 0036 0037
As of 06/2005	SLK	171	Body	EZS-Electronic ignition switch	•	•	•	•	•	0	*	0027 0028 0029 0030 0031 0032 0033 0034 0035 0036 0037
ALL	CLS	218	Body	EZS-Electronic ignition lock (N73)	•	•	0		0			
ALL	E-Class	212	Body	EZS-Electronic ignition lock (N73)	•	•	0	•	0	•		
ALL	E-Class	207	Body	EZS-Electronic ignition lock (N73)	•	•	0	•	0	•		
Up to 08/2002	S-Class	220	Body	EZS-Electronic ignition switch	•	•	•	•	•	*	0	
Up to 08/2002	CL	215	Body	EZS-Electronic ignition switch	•	•	•	•	•	*	0	
Up to 06/2009	S-Class	221	Body	EZS-Electronic ignition switch	•	•	•	•	•	•	0	
ATT	CL		Body	EZS-Electronic ignition switch	•	•	•	•	•	•	0	
Up to 08/2002	S-Class	220	Body	EZS-Electronic ignition switch	•	•	•	•	•	*	0	
Up to 08/2002	CL	215	Body	EZS-Electronic ignition switch	•	•	•	•	•	*	0	
Up to 08/2003	SL	230	Body	EZS-Electronic ignition switch	•	•	•	•	•	*	0	
ALL	SLR	199	Body	EZS-Electronic ignition switch	•	•	•	•	•	*	0	
Up to 08/2002	S-Class	220	Body	EZS-Electronic ignition switch	•	•	•	•	•	*		0034
As of 09/2002	S-Class	220	Body	EZS-Electronic ignition switch	•	•	•	•	•	*		0034
	CL	215	Body	EZS-Electronic ignition switch	•	•	•	•	•	*		0034
From 09/2003 to 05/2006	SL	230	Body	EZS-Electronic ignition switch	•	•	•	•	•	*		0034
From 06/2006 to 02/2008	SL	230	Body	EZS-Electronic ignition switch	•	•	•	•	•	*	0	0034

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 03/2008	SL	230	Body	EZS-Electronic ignition switch	•	•	•	•	•	*	0	0034
ALL	SL		Body	EZS-Electronic ignition lock (N73)	•	•	0	•	0	•		
Up to 08/2006	MayBach		Body	EZS-Electronic ignition switch	•	•	•	•	•	•		
As of 09/2006	MayBach	240	Body	EZS-Electronic ignition switch	•	•	•		•	•		
		463(16-pin										
Up to 03/2004	G-Class	diagnostic	Body	EZS-Electronic ignition switch	•	•	•	•	•	0	0	0034
		socket)										
ALL	A-Class	168	Drive	FTC-Front transmission control	•	•	•	•	•	*		
ALL	M-Class	163	Body	DAS-Drive authorization system	•	•	•	•	•	*	0	
		461(16-pin		·								
ALL	G-Class	diagnostic	Information and	WSP immobilizer	•	•	•		•	*		
	0 01000	socket)	communication		•				•	, , ,		
Up to 11/2005	A-Class	169	Drive	FCVT-Continuously variable automatic	•	•	•	•	•	•	0	0043 0044 0081 0082
As of 12/2005	A-Class		Drive	FCVT-Continuously variable automatic	•	•	•	•	•		0	0043 0044 0081 0082
Up to 11/2005	B-Class	245	Drive	FCVT-Continuously variable automatic	•	•	•	•	<u> </u>		0	0043 0044 0081 0082
As of 12/2005		245	Drive	FCVT-Continuously variable automatic	•		•	•		•	0	0043 0044 0081 0082
113 01 12/2000	D Class	2 10	DIIVC	SG-AWF-Control unit 'COLLISION PREVENTION								0010 0011 0001 0002
ALL	B-Class	246	Body	ASSIST' (A90)	•	•	0	•	0	•		
				SG-AWF-Control unit 'COLLISION PREVENTION								
ALL	CLS	218	Body	ASSIST' (A90)	•	•	0	•	0	•		
ALL	M-Class	166	Body	SG-AWF-Control unit 'COLLISION PREVENTION	•	•	0	•	0	•		
				ASSIST' (A90)								
ALL	E-Class	212	Body	SG-AWF-Control unit 'COLLISION PREVENTION	•	•	0	•	0			
1100	L Class	315	Body	ASSIST' (A90)								
ALL	E-Class	207	Body	SG-AWF-Control unit 'COLLISION PREVENTION			0	•	0			
TILL	L Class	201	Dody	ASSIST' (A90)		•	0					
ALL	CLA	117	Body	SG-AWF-Control unit 'COLLISION PREVENTION			0	•	0			
ALL	CLA	117	Dody	ASSIST' (A90)	_		0		0			
ALL	A-Class	176	Body	SG-AWF-Control unit 'COLLISION PREVENTION ASSIST' (A90)	•	•	0	•	0	•		
Up to 06/2009	S-Class	221	Seats and doors	MKL-HL-Rear left multicontour backrest	•	•	•	•	•	•		
	S-Class S-Class	221			$\overline{}$		-		<del>-</del>			
As of 07/2009			Seats and doors	MKL-HL-Rear left multicontour backrest		•		_				
Up to 06/2009	S-Class	221	Seats and doors	MKL-HR-Rear right multicontour backrest		_	•	•				
As of 07/2009	S-Class	221		MKL-HR-Rear right multicontour backrest		•	•	•		•		
Up to 05/2005	E-Class	211	Seats and doors	DS-LF-Left front dynamic seat	•	•	•	•		•	•	
From 06/2005 to 05/2006	E-Class	211	Seats and doors	DS-LF-Left front dynamic seat	•	•	•	•	•	•	•	
As of 06/2006	E-Class	211	Seats and doors	DS-LF-Left front dynamic seat	•	•	•	•	•	•	•	
Up to 05/2005		219		DS-LF-Left front dynamic seat	•	•	•	•	•	•	•	
From 06/2005 to				·				-		<b>├</b>		
05/2006	CLS	219	Seats and doors	DS-LF-Left front dynamic seat	•	•	•	•	•	•	•	
As of 06/2006	CLS	219	Seats and doors	DS-LF-Left front dynamic seat	•	•	•	•	•	•	•	
ALL	M-Class	164		DS-LF-Left front dynamic seat	<del>-</del>	•	•	•	<del>-</del>		•	
ALL	GL-Class	X 164		DS-LF-Left front dynamic seat	•	•	•		<del>-</del>		•	
ALL		251		DS-LF-Left front dynamic seat	•		•		<del>-</del>		-	
	R-Class			·				_		— -	_	
Up to 08/2002		220		DS-LF-Left front dynamic seat	•	•	•	•	•	•	•	
As of 09/2002	S-Class	220		DS-LF-Left front dynamic seat	•	•	•	•	•	•	•	
Up to 06/2009	S-Class	221	Seats and doors	DS-LF-Left front dynamic seat	•				•	•		

		Model	Control Unit		Ecu	Read	Event	Erase	Live	Freeze	Active	
Model year	Mode1	Series	Groups	System Name	Info.	Codes	Memory	Codes	Data	Frame	Test	Special Function
ALL	CL	216		DS-LF-Left front dynamic seat	•	•	•	•	•	•	•	
Up to 05/2005	E-Class	211	Seats and doors	DS-RF-Right front dynamic seat	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	E-Class	211	Seats and doors	DS-RF-Right front dynamic seat	•	•	•	•	•	•	•	
As of 06/2006	E-Class	211	Seats and doors	DS-RF-Right front dynamic seat	•	•	•	•	•	•		
Up to 05/2005	CLS	219	Seats and doors	DS-RF-Right front dynamic seat	•	•	•		•	•	•	
From 06/2005 to 05/2006	CLS	219	Seats and doors	DS-RF-Right front dynamic seat	•	•	•	•	•	•	•	
As of 06/2006	CLS	219	Seats and doors	DS-RF-Right front dynamic seat	•	•	•	•	•	•	•	
ALL	M-Class	164	Seats and doors	DS-RF-Right front dynamic seat	•	•	•	•	•	•	•	
ALL	GL-Class	X 164	Seats and doors	DS-RF-Right front dynamic seat	•	•	•	•	•	•	•	
ALL	R-Class	251	Seats and doors	DS-RF-Right front dynamic seat	•	•	•	•	•	•	•	
Up to 08/2002	S-Class	220		DS-RF-Right front dynamic seat	•	•		•	•	•		
As of 09/2002	S-Class	220		DS-RF-Right front dynamic seat	•	•	•	•	•	•	•	
Up to 06/2009	S-Class	221		DS-RF-Right front dynamic seat	•	•	•	•	•	•		
ALL	CL	216	Seats and doors	DS-RF-Right front dynamic seat	•	•	•	•	•	•		
ALL	A-Class	168	Body	RFL-Radio frequency locking/electric central locking	•	•	0	•	•	*		
ALL	S-Class	140	Body	RFL-Radio frequency locking/electric central locking	•	•	0	•	•	*		
As of 09/99	SL		Body	RFL-Radio frequency locking/electric central locking	•	•	0	•	•	*		
ALL	SLK	170 (16-pin diagnostic socket)	Body	RFL-Radio frequency locking/electric central locking	•	•	0	•	•	*		
ALL	SLK	170(38-pin diagnostic socket)		RFL-Radio frequency locking/electric central locking	•	•	0	•	•	*		
ALL	M-Class	163	Body	LCP-Lower operating panel with power window function	•	•	•	•	•	*	•	
Up to 08/2006	MayBach	240	Air conditioning	REAR AC-Rear air conditioning	•	•	•	•	•	0	•	
As of 09/2006	MayBach	240	Air conditioning	REAR AC-Rear air conditioning	•	•	•	•	•	0	•	
Up to 06/2009	S-Class	221	Drive	FSCU-Fuel pump AMG	•	•	•	•	•	•		
As of 07/2009	S-Class	221	Drive	FSCU-Fuel pump AMG	•	•			•	•		
ALL	CL	216	Drive	FSCU-Fuel pump AMG	•	•	•	•	•	•		
		220		REAR AC- Rear air conditioning	•	•	•	•	•	*	•	
As of 09/2002	S-Class			REAR AC- Rear air conditioning	•	•	•	•	•	*	•	
As of 09/2002	CL	215		REAR AC- Rear air conditioning	•	•	•	•	•	*	•	
As of 04/2004	CLK	209		FSCU Left-Control unit 'Left fuel pump'	•	•	•	•	•	•		
ALL	M-Class			FSCU Left-Control unit 'Left fuel pump'	•	•	•	•	•	•		
ALL	R-Class	251	Drive	FSCU Left-Control unit 'Left fuel pump'	•	•	•	•	•	•		
	E-Class	211	Drive	FSCU Right-Control unit 'Right fuel pump'	•	•	•	•	•	•		
Up to 05/2005	CLS	219	Drive	FSCU Right-Control unit 'Right fuel pump'	•	•	•	•	•	•		
From 06/2005 to 05/2006			Drive	FSCU Right-Control unit 'Right fuel pump'	•	•	•	•	•	•		
As of 06/2006	CLS		Drive	FSCU Right-Control unit 'Right fuel pump'	•	•	•	•	•	•		
As of 04/2004	CLK		Drive	FSCU Right-Control unit 'Right fuel pump'	•	•	•	•	•	•		
ALL	M-Class	164	Drive	FSCU Right-Control unit 'Right fuel pump'	•	•	•		•	•		

		Mode1	Control Unit		Four	Read	Event	Erase	Live	Етоопо	Astivo	
Model year	Model	Series	Groups	System Name	Ecu Info.	Codes	Event Memory	Codes	Data	Freeze Frame	Active Test	Special Function
ATT	D. C1			PCCU Pinks Control with Pinks Control							1050	
ALL	R-Class	251 211	Drive	FSCU Right-Control unit 'Right fuel pump' FSCU Left-Control unit 'Left fuel pump'	•	•	•	•	•	•		
As of 06/2006	E-Class		Drive				_					
	CLS	219	Drive	FSCU Left-Control unit 'Left fuel pump'	•	•	•	•	•	•		
From 06/2005 to 05/2006	CLS	219	Drive	FSCU Left-Control unit 'Left fuel pump'	•	•	•	•	•	•		
As of 06/2006	CLS	219	Drive	FSCU Left-Control unit 'Left fuel pump'	•	•	•		•	•		
ALL	C-Class	204	Drive	FSCU Left-Control unit 'left fuel pump'	•	•	•		0	•		
ALL	GLK	X204	Drive	FSCU Left-Control unit 'left fuel pump'	•	•	•	•	0	•		
ALL	C-Class	204	Drive	FSCU Right-Control unit 'Right fuel pump'	•	•	•	•	0	•		
ALL	GLK	X204	Drive	FSCU Right-Control unit 'Right fuel pump'	•	•	•	•	0	•		
ALL	B-Class	246	Drive	FSCU-Fuel pump	•	•	•	•	•	•		
ALL	C-Class	204	Drive	FSCU-Fuel pump	•	•	•	•	•	•		
ALL	CLS	218	Drive	FSCU-Fuel pump	•	•	•	•	•	•		
Up to 06/2009	S-Class	221	Drive	FSCU-Fuel pump	•	•	•	•	•	•		
As of 07/2009	S-Class	221	Drive	FSCU-Fuel pump	•	•	•	•	•	•		
ALL	CL	216	Drive	FSCU-Fuel pump	•	•	•		•			
ALL	SLK	172	Drive	FSCU-Fuel pump	•	•	•		•			
ALL	GLK	X204	Drive	FSCU-Fuel pump	•							
ALL	M-Class	166	Drive	FSCU-Fuel pump	•	•	•	•	•	•		
ALL	E-Class	212	Drive	FSCU-Fuel pump	•	•	•	•	•	•		
ALL	E-Class	207	Drive	FSCU-Fuel pump	•	•	•	•		•		
ALL	CLA	117	Drive	FSCU-Fuel pump	•	•	•	•				
ALL	A-Class	176	Drive	FSCU-Fuel pump	•		•			•		
ALL	SL	231	Drive	FSCU-Fuel pump	•	•	•			•		
ALL	M-Class	164	Drive	FSCU-Fuel pump	•	•	•			•		
ALL	B-Class	246	Drive	FSCU-Fuel pump	•	•	•			•		
ALL	C-Class	204	Drive	FSCU-Fuel pump			•					
ALL	CLS	218	Drive	FSCU-Fuel pump	•	•	•			•		
Up to 06/2009	S-Class	221	Drive	FSCU-Fuel pump	•	•						
As of 07/2009	S-Class	221	Drive	FSCU-Fuel pump	•	•	•			•		
	CL	216	Drive	FSCU-Fuel pump	<u> </u>					•		
ALL	SLK	172	Drive	FSCU-Fuel pump	<del>-</del>	-				•		
ALL	GLK	X204	Drive	FSCU-Fuel pump	<del>-</del>							
ALL	M-Class	164	Drive	FSCU-Fuel pump	•	-		•		•		
ALL	M-Class	166	Drive	FSCU-Fuel pump	<del>-</del>	-						
ALL	GL-Class	X 164	Drive	FSCU-Fuel pump	•	•	•	•	•			
		251	Drive	FSCU-Fuel pump	•	•	•	•	•	•		
	E-Class	212	Drive	FSCU-Fuel pump	•	•	•	•	•			
	E-Class	207	Drive	FSCU-Fuel pump	•	-	•	•	-			
	CLA	117		FSCU-Fuel pump	•	-	•	•	•			
ALL			Drive Drive									
ALL Up to 05/2005	A-Class	176 219	Drive	FSCU-Fuel pump	•	•	•	•		•		
	CLS	219	prive	FSCU-Fuel pump		_			0	_		
From 06/2005 to 05/2006	CLS	219	Drive	FSCU-Fuel pump	•	•	•	•	0	•		
As of 06/2006	CLS	219	Drive	FSCU-Fuel pump	•	•	•	•	0	•		
As of 09/2006	MayBach	240	Drive	FSCU-Fuel pump	•	•	•	•	0	•		
ALL	C-Class	204	Drive	FSCU-Fuel pump	•	•	•	•	0	•		
Up to 06/2009	S-Class	221	Drive	FSCU-Fuel pump	•	•	•	•	0	•		

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 07/2009	S-Class	221	Drive	FSCU-Fuel pump	•	•	•	•	0	•		
ALL	CL	216	Drive	FSCU-Fuel pump	•	•	•	•	0	•		
ALL	GLK	X204	Drive	FSCU-Fuel pump	•	•	•	•	0	•		
Up to 03/2004	CLK	209	Seats and doors	RCM-Rear control module	•	•	•	•	•	0		
As of 04/2004	CLK	209	Seats and doors	RCM-Rear control module	•	•	•	•	•	0		
Up to 08/2002	CL	215	Seats and doors	RCM-Rear control module	•	•	•	•	•	*		
As of 09/2002	CL	215	Seats and doors	RCM-Rear control module	•	•	•	•	•	*		
ALL	CL	216	Seats and doors	RCM-Rear control module	•	•	•	•	•	•		
Up to 08/2006	MayBach	240	Information and communication	TV-TV tuner (rear)	•	•	•	•	•	•		
As of 09/2006	MayBach	240	Information and communication	TV-TV tuner (rear)	•	•	•	•	•	•		
ALL	C-Class	204	Information and communication	AVE-H-Rear audio video unit	•	•	•	•	•	•		
ALL	CLS	218	Information and communication	AVE-H-Rear audio video unit	•	•	•	•	•	•		
Up to 06/2009	S-Class	221	Information and communication	AVE-H-Rear audio video unit	•	•	•	•	•	•		
As of 07/2009	S-Class	221	Information and communication	AVE-H-Rear audio video unit	•	•	•	•	•	•		
ALL	GLK	X204	Information and communication	AVE-H-Rear audio video unit	•	•	•	•	•	•		
ALL	M-Class	166	Information and communication	AVE-H-Rear audio video unit	•	•	•	•	•	•		
ALL	E-Class	212	Information and communication	AVE-H-Rear audio video unit	•	•	•	•	•	•		
ALL	E-Class	207	Information and communication	AVE-H-Rear audio video unit	•	•	•	•	•	•		
ALL	M-Class	164	Information and communication	AVE-H-Rear audio video unit	•	•	•	•	•	•		
ALL	GL-Class	X 164	Information and communication	AVE-H-Rear audio video unit	•	•	•	•	•	•		
ALL	R-Class	251	Information and communication	AVE-H-Rear audio video unit	•	•	•	•	•	•		
ALL	SL	231	LIN Bus	BFS LSE-Lumbar support 'Front passenger seat' (N32/24)	•	•	0	•	0	•		
ALL	B-Class	246	LIN Bus	GTO-Garage door opener (A67n2)	•	•	0	•	0	•		
ALL	C-Class	204	LIN Bus	GTO-Garage door opener (A67n2)	•	•	0	•	0	•		
ALL	CLS	218	LIN Bus	GTO-Garage door opener (A67n2)	•	•	0	•	0	•		
ALL	SLK	172	LIN Bus	GTO-Garage door opener (A67n2)	•	•	0	•	0	•		
ALL	GLK	X204	LIN Bus	GTO-Garage door opener (A67n2)	•	•	0	•	0	•		
ALL	M-Class	166	LIN Bus	GTO-Garage door opener (A67n2)	•	•	0	•	0	•		
ALL	E-Class	212	LIN Bus	GTO-Garage door opener (A67n2)	•	•	0	•	0	•		
ALL	E-Class	207	LIN Bus	GTO-Garage door opener (A67n2)	•	•	0	•	0	•		
ALL	SLS	197	LIN Bus	GTO-Garage door opener (A67n2)	•	•	0	•	0	•		
ALL	CLA	117	LIN Bus	GTO-Garage door opener (A67n2)	•	•	0	•	0	•		
ALL	A-Class	176	LIN Bus	GTO-Garage door opener (A67n2)	•	•	0	•	0	•		
ALL	SL	231	LIN Bus	GTO-Garage door opener (A67n2)			0		0			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
Up to 08/2003	C-Class	203	Information and communication	CTEL over K-wire-Telematic system	•	•	•	•	0	0	0	
Up to 03/2004	CLK	209	Information and communication	CTEL over K-wire-Telematic system	•	•	•	•	0	0	0	
ALL	CLK	208	Information and communication	CTEL over K-wire-Telematic system	•	•	•	•	0	0	0	
As of 03/97 DAS 3	E-Class	210	Information and communication	CTEL over K-wire-Telematic system	•	•	•	•	0	0	0	
Up to 08/2002	S-Class	220	Information and communication	CTEL over K-wire-Telematic system	•	•	•	•	0	0	0	
As of 09/2002	S-Class	220	Information and communication	CTEL over K-wire-Telematic system	•	•	•	•	0	0	0	
Up to 08/2002	CL	215	Information and communication	CTEL over K-wire-Telematic system	•	•	•	•	0	0	0	
As of 09/2002	CL	215	Information and communication	CTEL over K-wire-Telematic system	•	•	•	•	0	0	0	
Up to 08/2003	SL	230	Information and communication	CTEL over K-wire-Telematic system	•	•	•	•	0	0	0	
From 09/2003 to 05/2006	SL	230	Information and communication	CTEL over K-wire-Telematic system	•	•	•	•	0	0	0	
From 06/2006 to 02/2008	SL	230	Information and communication	CTEL over K-wire-Telematic system	•	•	•	•	0	0	0	
As of 03/2008	SL	230	Information and communication	CTEL over K-wire-Telematic system	•	•	•	•	0	0	0	
As of 09/99	SL	129	Information and communication	CTEL over K-wire-Telematic system	•	•	•	•	0	0	0	
ALL	SLR	199	Information and communication	CTEL over K-wire-Telematic system	•	•	•	•	0	0	0	
ALL	SLK	170(16-pin diagnostic socket)	Information and communication	CTEL over K-wire-Telematic system	•	•	•	•	0	0	0	
ALL	M-Class	163	Information and communication	CTEL over K-wire-Telematic system	•	•	•	•	0	0	0	
Up to 03/2004	G-Class	463 (16-pin diagnostic socket)	Information and communication	CTEL over K-wire-Telematic system	•	•	•	•	0	0	0	
From 04/2004 to 08/2006	G-Class	463 (16-pin diagnostic socket)		CTEL over K-wire-Telematic system	•	•	•	•	0	0	0	
From 09/2006 to 02/2007	G-Class	463 (16-pin diagnostic socket)	Information and communication	CTEL over K-wire-Telematic system	•	•	•	•	0	0	0	
ALL	M-Class	164	Drive	HAQ-Interwheel differential lock at rear axle	•	•	•	•	•	•		
ALL	GL-Class	X 164	Drive	HAQ-Interwheel differential lock at rear axle	•	•	•	•	•	•		
ALL	M-Class	164	Body	HBF (Rear control panel)-Rear control field	•	•	•	•	•	0		
ALL	GL-Class	X 164	Body	HBF (Rear control panel)-Rear control field	•	•	•	•	•	0	•	
ALL	R-Class	251	Body	HBF (Rear control panel)-Rear control field	•	•	•	•	•	0	•	
Up to 08/2006	MayBach	240	Body	HBF (Rear control panel)-Rear control field		•	•		•	0		

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
A C 00 /000C	M. D. I			UDD (Decree of the later) Decree of the later			<u> </u>					
As of 09/2006	MayBach M-Class	240 164	Body Drive	HBF (Rear control panel)-Rear control field HSG-Hybrid control unit	•	•	•	•	•	0	•	
ALL	M-Class	463 (38-pin	Drive	nsg-nybrid control unit						_		
ALL	G-Class	diagnostic socket)	Drive	HFM-SFI-Hot film engine management	•	•	0	•		*		
ALL	M-Class	164	Seats and doors	REDC-Rear-end door closing control module	•	•	•	•	•	0	•	
		X 164		REDC-Rear-end door closing control module	•	•	•	•	•	0	•	
ALL	R-Class	251		REDC-Rear-end door closing control module	•	•	•	•	•	0	•	
Up to 03/2004	CLK	209	Seats and doors	TLC-Trunk lid control	•	•	•	•	•	•	•	
As of 04/2004	CLK	209	Seats and doors	TLC-Trunk lid control	•	•	•	•	•	•	•	
Up to 05/2005	E-Class	211	Seats and doors	TLC-Trunk lid control	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	E-Class	211	Seats and doors	TLC-Trunk lid control	•	•	•	•	•	•	•	
As of 06/2006	E-Class	211	Seats and doors	TLC-Trunk lid control	•	•	•	•	•	•	•	
Up to 05/2005	CLS	219		TLC-Trunk lid control	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	CLS	219		TLC-Trunk lid control	•	•	•	•	•	•	•	
As of 06/2006	CLS	219	Seats and doors	TLC-Trunk lid control	•	•	•	•	•	•	•	
Up to 08/2006	MayBach	240	Seats and doors	TLC-Trunk lid control	•	•	•	•	•	•	•	
As of 09/2006	MayBach	240	Seats and doors	TLC-Trunk lid control	•	•	•	•	•	•	•	
Up to 06/2009	S-Class	221		TLC-Trunk lid control	•	•	•	•	•	•	•	
ALL	CL	216	Seats and doors	TLC-Trunk lid control		•	•	•	•		•	
Up to 05/2005	E-Class	211	Seats and doors	TLC-Trunk lid control	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	E-Class	211	Seats and doors	TLC-Trunk lid control	•	•	•	•	•	•	•	
As of 06/2006	E-Class	211	Seats and doors	TLC-Trunk lid control	•	•	•	•	•	•	•	
ALL	B-Class	246	Body	SG-SW-Control unit 'Headlamp' (N71/1)	•	•	0	•	0	•		
ALL	C-Class	204	Body	SG-SW-Control unit 'Headlamp' (N71/1)	•	•	0	•	0	•		
ALL	SLK	172	Body	SG-SW-Control unit 'Headlamp' (N71/1)	•	•	0	•	0	•		
ALL	GLK	X204	Body	SG-SW-Control unit 'Headlamp' (N71/1)		•	0	•	0			
ALL	M-Class	166	Body	SG-SW-Control unit 'Headlamp' (N71/1)	•	•	0	•	0	•		
ALL	CLA	117	Body	SG-SW-Control unit 'Headlamp' (N71/1)	•	•	0	•	0	•		
ALL	A-Class	176	Body	SG-SW-Control unit 'Headlamp' (N71/1)	•	•	0	•	0	•		
ALL	SL		Body	SG-SW-Control unit 'Headlamp' (N71/1)	•	•	0	•	0	•		
ALL	M-Class	164	Body	XALWA-L-Xenon headlamp, left	•	•	•	•	•			
ALL	GL-Class		Body	XALWA-L-Xenon headlamp, left	•	•	•	•	•			
ALL			Body	XALWA-L-Left xenon headlamp(E1n1)	•	•	•	•	•	•	<b>A</b>	
ALL	E-Class		Body	XALWA-L-Left xenon headlamp(E1n1)	•	•	•	•	•	•	<b>A</b>	
ALL	M-Class		Body	XALWA-R-Xenon headlamp, right	•	•	•	•	•			
	GL-Class		Body	XALWA-R-Xenon headlamp, right	•	•	•	•	•			
	E-Class		Body	XALWA-R-Right xenon headlamp(E2n1)	•	•	•	•	•	•	<u> </u>	
	E-Class		Body	XALWA-R-Right xenon headlamp(E2n1)	•	•	•	•	•	•	<b>A</b>	
ALL	C-Class		Body	XALWA-L-Xenon headlamp, left	•	•	•	•	•	•	•	
ALL	GLK		Body	XALWA-L-Xenon headlamp, left	•	•	•	•	•	•	•	
ALL	C-Class		Body	XALWA-L-Xenon headlamp, left	•	•	•	•	•	•		
ALL	GLK		Body	XALWA-L-Xenon headlamp, left	•	•	•	•	•	•		
ALL	C-Class		Body	XALWA-R-Xenon headlamp, right	•	•	•	•	•	•		
ALL	GLK	X204	Body	XALWA-R-Xenon headlamp, right		•	•		•	•		

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	C-Class	204	Body	XALWA-R-Xenon headlamp, right	•	•	•	•	•	•		
ALL	GLK	X204	Body	XALWA-R-Xenon headlamp, right	•	•	•		•	•		
ALL	CLS	218	Seats and doors	SIH-FOND-Rear passenger compartment seat heater	<b>A</b>		lack	lack	<b>A</b>	<b>A</b>		
ALL	E-Class	212	Seats and doors	SIH-FOND-Rear passenger compartment seat heater	<b>A</b>			lack	<b>A</b>			
ALL	E-Class	207	Seats and doors	SIH-FOND-Rear passenger compartment seat heater	<b>A</b>		lack	lack	<b>A</b>			
ALL	E-Class	212	Air conditioning	LRH-Steering wheel heater	•	•	•	•	0			
ALL	C-Class	204	Information and communication	COMAND or AUDIO	•	•	•	•	•	•		
ALL	CLS	218	Information and communication	COMAND or AUDIO	•	•	•	•	•	•		
ALL	GLK	X204	Information and communication	COMAND or AUDIO	•	•	•	•	•	•		
ALL	E-Class	212	Information and communication	COMAND or AUDIO	•	•	•	•	•	•		
ALL	E-Class	207	Information and communication	COMAND or AUDIO	•	•	•	•	•	•		
ALL	SLS	197	Information and communication	COMAND or AUDIO	•	•	•	•	•	•		
ALL	C-Class	204	Information and communication	COMAND or AUDIO	•	•	•	•	•	•		
ALL	GLK	X204	Information and communication	COMAND or AUDIO	•	•	•	•	•	•		
ALL	E-Class	212	Information and communication	COMAND or AUDIO	•	•	•	•	•	•		
ALL	E-Class	207	Information and communication	COMAND or AUDIO	•	•	•	•	•	•		
Up to 06/2009	S-Class	221	Information and communication	COMAND	•	•	•	•	•	•	*	
As of 07/2009	S-Class	221	Information and communication	COMAND	•	•	•	•	•	•	*	
ALL	CL	216	Information and communication	COMAND	•	•	•	•	•	•	*	
Up to 06/2009	S-Class	221	Information and communication	COMAND	•	•	•	•	•	•		
As of 07/2009	S-Class	221	Information and communication	COMAND	•	•	•	•	•	•		
ALL	CL	216	Information and communication	COMAND	•	•	•	•	•	•		
As of 12/2005	A-Class	169	Information and communication	COMAND or AUDIO	•	•	•	•	•	•		
As of 12/2005	B-Class	245	Information and communication	COMAND or AUDIO	•	•	•	•	•	•		
As of 01/2008	C-Class	203	Information and communication	COMAND or AUDIO	•	•	•	•	•	•		
Up to 05/2005	E-Class	211	Information and communication	COMAND or AUDIO	•	•	•	•	•	•		
As of 06/2006	E-Class	211	Information and communication	COMAND or AUDIO	•	•	•	•	•	•		

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 06/2006	CLS	219	Information and communication	COMAND or AUDIO	•	•	•	•	•	•		
As of 03/2008	SL	230	Information and communication	COMAND or AUDIO	•	•	•	•	•	•		
Up to 05/2005	SLK	171	Information and communication	COMAND or AUDIO	•	•	•	•	•	•		
As of 06/2005	SLK	171	Information and communication	COMAND or AUDIO	•	•	•	•	•	•		
ALL	M-Class	164	Information and communication	COMAND or AUDIO	•	•	•	•	•	•		
As of 03/2007	G-Class	463 (16-pin diagnostic socket)	Information and communication	COMAND or AUDIO	•	•	•	•	•	•		
ALL	GL-Class	X 164	Information and communication	COMAND or AUDIO	•	•	•	•	•	•		
ALL	R-Class	251	Information and communication	COMAND or AUDIO	•	•	•	•	•	•		
ALL	B-Class	246	Information and communication	Audio-Audio or COMAND (A2-A40/3)	•	•	0	•	0	•		
ALL	C-Class	204	Information and communication	Audio-Audio or COMAND (A2-A40/3)	•	•	0	•	0	•		
ALL	CLS	218	Information and communication	Audio-Audio or COMAND (A2-A40/3)	•	•	0	•	0	•		
ALL	SLK	172	Information and communication	Audio-Audio or COMAND (A2-A40/3)	•	•	0	•	0	•		
ALL	GLK	X204	Information and communication	Audio-Audio or COMAND (A2-A40/3)	•	•	0	•	0	•		
ALL	M-Class	166	Information and communication	Audio-Audio or COMAND (A2-A40/3)	•	•	0	•	0	•		
ALL	E-Class	212	Information and communication	Audio-Audio or COMAND (A2-A40/3)	•	•	0	•	0	•		
ALL	E-Class	207	Information and communication	Audio-Audio or COMAND (A2-A40/3)	•	•	0	•	0	•		
ALL	SLS	197	Information and communication	Audio-Audio or COMAND (A2-A40/3)	•	•	0	•	0	•		
ALL	CLA	117	Information and communication	Audio-Audio or COMAND (A2-A40/3)	•	•	0	•	0	•		
ALL	A-Class	176	Information and communication	Audio-Audio or COMAND (A2-A40/3)	•	•	0	•	0	•		
ALL	SL	231	Information and communication	Audio-Audio or COMAND (A2-A40/3)	•	•	0	•	0	•		
ALL	C-Class	204	Air conditioning	AAC-Air conditioning (N22/7)	•	•	•	•	•	•	•	0101 0145 0146 0147 0148 0149 0150 0151 0048 0097
ALL	CLS	218	Air conditioning	AAC-Air conditioning (N22/7)	•	•	•	•	•	•	•	0101 0145 0146 0147 0148 0149 0150 0151 0048 0097

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	GLK	X204	Air conditioning	AAC-Air conditioning (N22/7)	•	•	•	•	•	•	•	0101 0145 0146 0147 0148 0149 0150 0151 0048 0097
ALL	C-Class	204		AAC-Air conditioning (N22/7)	•	•			•	•		
ALL	GLK	X204		AAC-Air conditioning (N22/7)	•	•	•	•	•	•		
ALL	E-Class	212		AAC-Air conditioining	•	•	•	•	•	•	lack	0152
ALL	E-Class	207		AAC-Air conditioining	•	•	•	•	•	•	<b>A</b>	0152
ALL	M-Class	166		AAC-Air conditioning (N22/7)	•	•	0	•	0	•		
ALL	SLK	172		AAC-Air conditioning (N22/7)	•	•	0	•	0	•		
ALL	SLS	197	Air conditioning	AAC-Air conditioning (N22/7)	•	•	0	•	0	•		
ALL	SL	231	Air conditioning	AAC-Air conditioning (N22/7)	•	•	0	•	0	•		
ALL	B-Class	246	Air conditioning	AAC-Air conditioning (N22/7)	•	•	0	•	0	•		
ALL	CLA	117	Air conditioning	AAC-Air conditioning (N22/7)	•	•	0	•	0	•		
ALL	A-Class	176	Air conditioning	AAC-Air conditioning (N22/7)	•	•	0		0	•		
ALL	M-Class	166	Air conditioning	HBF-Rear control panel (N72/2)	•	•	0		0	•		
Up to 06/2009	S-Class	221	Air conditioning	KBE-H-Rear A/C operating unit	•	•		•	•	•	•	
As of 07/2009	S-Class	221	Air conditioning	KBE-H-Rear A/C operating unit	•	•		•	•	•	•	
As of 07/2009	S-Class	221	Body	SG-DDW - DC/DC converter control unit	•	•		•	•	•		
As of 07/2009	S-Class	221	Drive	SG-EM - Electric motor control unit	•	•		•	•	•		
ALL	B-Class	246	LIN Bus	BSN-Battery sensor (B95)	•	•	0	•	0	•		
ALL	M-Class	166	LIN Bus	BSN-Battery sensor (B95)	•	•	0	•	0	•		
ALL	SLS	197	LIN Bus	BSN-Battery sensor (B95)	•	•	0	•	0	•		
ALL	CLA	117	LIN Bus	BSN-Battery sensor (B95)	•	•	0	•	0	•		
ALL	A-Class	176	LIN Bus	BSN-Battery sensor (B95)	•	•	0	•	0	•		
ALL	M-Class	164	Drive	IRS-HRA-Outer right rear intelligent radar sensor system	•	•	•	•	•	•		
ALL	GL-Class	X 164	Drive	IRS-HRA-Outer right rear intelligent radar sensor system	•	•	•	•	•	•		
ALL	R-Class	251	Drive	IRS-HRA-Outer right rear intelligent radar sensor system	•	•	•	•	•	•		
ALL	M-Class	164	Drive	IRS-HLA - Outer left rear intelligent radar sensor system	•	•	•	•	•	•		
ALL	GL-Class	X 164	Drive	IRS-HLA - Outer left rear intelligent radar sensor system	•	•	•	•	•	•		
ALL	R-Class	251	Drive	IRS-HLA - Outer left rear intelligent radar sensor system	•	•	•	•	•	•		
ALL	B-Class	246	Body	IRS-HRA-Outer right rear intelligent radar sensor system	•	•	0	•	0	•		
ALL	C-Class	204	Body	IRS-HRA-Outer right rear intelligent radar sensor system	•	•	0	•	0	•		
ALL	CLS	218	Body	IRS-HRA-Outer right rear intelligent radar sensor system	•	•	0	•	0	•		
ALL	GLK	X204	Body	IRS-HRA-Outer right rear intelligent radar sensor system	•	•	0	•	0	•		
ALL	M-Class	166	Body	IRS-HRA-Outer right rear intelligent radar sensor system	•	•	0	•	0	•		
ALL	E-Class	212	Body	IRS-HRA-Outer right rear intelligent radar sensor system	•	•	0	•	0	•		

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	E-Class	207	Body	IRS-HRA-Outer right rear intelligent radar sensor system	•	•	0	•	0	•		
ALL	SLS	197	Body	IRS-HRA-Outer right rear intelligent radar sensor system	•	•	0	•	0	•		
ALL	CLA	117	Body	IRS-HRA-Outer right rear intelligent radar sensor system	•	•	0	•	0	•		
ALL	A-Class	176	Body	IRS-HRA-Outer right rear intelligent radar sensor system	•	•	0	•	0	•		
ALL	B-Class	246	Body	IRS-HLA-Outer left rear intelligent radar sensor system (B29/4)	•	•	0	•	0	•		
ALL	C-Class	204	Body	IRS-HLA-Outer left rear intelligent radar sensor system (B29/4)	•	•	0	•	0	•		
ALL	CLS	218	Body	IRS-HLA-Outer left rear intelligent radar sensor system (B29/4)	•	•	0	•	0	•		
ALL	GLK	X204	Body	IRS-HLA-Outer left rear intelligent radar sensor system (B29/4)	•	•	0	•	0	•		
ALL	M-Class	166	Body	IRS-HLA-Outer left rear intelligent radar sensor system (B29/4)	•	•	0	•	0	•		
ALL	E-Class	212	Body	IRS-HLA-Outer left rear intelligent radar sensor system (B29/4)	•	•	0	•	0	•		
ALL	E-Class	207	Body	IRS-HLA-Outer left rear intelligent radar sensor system (B29/4)	•	•	0	•	0	•		
ALL	SLS	197	Body	IRS-HLA-Outer left rear intelligent radar sensor system (B29/4)	•	•	0	•	0	•		
ALL	CLA	117	Body	IRS-HLA-Outer left rear intelligent radar sensor system (B29/4)	•	•	0	•	0	•		
ALL	A-Class	176	Body	IRS-HLA-Outer left rear intelligent radar sensor system (B29/4)	•	•	0	•	0	•		
ALL	B-Class	246	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	•		0002
ALL	C-Class	204	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	•		0002
ALL	CLS	218	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	•		0002
ALL	SLK	172	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	•		0002
ALL	GLK	X204	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	•		0002
ALL	M-Class	166	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	•		0002
ALL	E-Class	207	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	•		0002
ALL	SLS	197	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	•		0002
ALL	CLA	117	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	•		0002
ALL	A-Class	176	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	•		0002

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	SL	231	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	•		0002
ALL	C-Class	204	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	•	•	
ALL	GLK	X204	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	•	•	
ALL	E-Class	212	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	•	•	
ALL	E-Class	207	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	•	•	
ALL	B-Class	246	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•		
ALL	C-Class	204	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•		
ALL	CLS	218	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•		
ALL	SLK	172	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•		
ALL	GLK	X204	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•		
ALL	M-Class	166	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•		
ALL	E-Class	212	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•		
ALL	E-Class	207	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•		
ALL	SLS	197	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•		
ALL	CLA	117	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•		
ALL	A-Class	176	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•		
ALL	SL	231	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•		
ALL	B-Class	246	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•		
ALL	C-Class	204	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•		
ALL	CLS	218	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•		
ALL	SLK	172	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•		
ALL	GLK	X204	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•		
ALL	M-Class	166	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•		
ALL	E-Class	212	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•		

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	E-Class	207	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•		
ALL	SLS	197	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•		
ALL	CLA	117	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•		
ALL	A-Class	176	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•		
ALL	SL	231	Information and communication	IC-Instrument cluster (A1)	•	•	0	•	0	•		
ALL	C-Class	204	Information and communication	ICI-InCar Internet (N125/3)	•	•	0	•	0	•		
ALL	CLS	218	Information and communication	ICI-InCar Internet (N125/3)	•	•	0	•	0	•		
As of 07/2009	S-Class	221	Information and communication	ICI-InCar Internet (N125/3)	•	•	0	•	0	•		
ALL	CL	216	Information and communication	ICI-InCar Internet (N125/3)	•	•	0	•	0	•		
ALL	GLK	X204	Information and communication	ICI-InCar Internet (N125/3)	•	•	0	•	0	•		
ALL	E-Class	212	Information and	ICI-InCar Internet (N125/3)	•	•	0	•	0	•		
ALL	E-Class	207	Information and	ICI-InCar Internet (N125/3)	•	•	0	•	0	•		
As of 03/97 DAS 3	E-Class	210	Information and communication	ICS-Information and communication system	•	•	0	•		*		
ALL	CLS	218	Chassis	FWGW-Chassis gateway (N97/7)	•	•	0	•	0	•		
ALL	E-Class	212	Chassis	FWGW-Chassis gateway (N97/7)	•	•	0	•	0	•		
ALL	E-Class	207	Chassis	FWGW-Chassis gateway (N97/7)	•	•	0	•	0	•		
ALL	B-Class	246	Air conditioning	STH-Stationary heater (A6n1)	•	•	0	•	0	•		
ALL	M-Class	166	Air conditioning	STH-Stationary heater (A6n1)	•	•	0	•	0	•		
ALL	CLA	117	Air conditioning	STH-Stationary heater (A6n1)	•	•	0	•	0	•		
ALL	A-Class	176	Air conditioning	STH-Stationary heater (A6n1)	•	•	0	•	0	•		
Up to 06/2009	S-Class	221	Drive	ISM-Intelligent servo module	•	•		•	•		*	
ALL	CL	216	Drive	ISM-Intelligent servo module	•	•	•	•	•	•	*	
ALL	M-Class	164	Drive	ISM-Intelligent servo module	•	•	•	•	•	•	*	
ALL	GL-Class	X 164	Drive	ISM-Intelligent servo module	•	•	•	•	•	•	*	
ALL	R-Class	251	Drive	ISM-Intelligent servo module	•	•	•	•	•	•	*	
Up to 08/2002	S-Class	220		KG-Keyless Go	•	•	•	•	•	*		
As of 09/2002	S-Class	220	Body	KG-Keyless Go	•	•	•	•	•	*		
Up to 08/2002	CL	215	Body	KG-Keyless Go	•	•	•	•	•	*		
As of 09/2002	CL	215	Body	KG-Keyless Go	•	•	•	•	•	*		
Up to 08/2003	SL	230	Body	KG-Keyless Go	•	•	•	•	•	*		
From 09/2003 to 05/2006	SL	230	Body	KG-Keyless Go	•	•	•	•	•	*		
From 06/2006 to 02/2008	SL	230	Body	KG-Keyless Go	•	•	•	•	•	*		
ALL	S-Class	140	Body	KFB-Power windows, emergency opening, convenience closing, tilting/sliding roof	•	•	0	•	0	*	0	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	C-Class	204	Body	KG-Keyless Go	•	•	•	•	•	•	•	
ALL	CLS	218	Body	KG-Keyless Go	•	•	•	•	•	•	•	
ALL	SLK	172	Body	KG-Keyless Go	•	•	•		•	•	•	
ALL	GLK	X204	Body	KG-Keyless Go	•	•			•		•	
ALL	E-Class	212	Body	KG-Keyless Go	•	•	•		•		•	
ALL	E-Class	207	Body	KG-Keyless Go	•	•	•	•	•	•	•	
ALL	SLS	197	Body	KG-Keyless Go	•	•	•	•	•	•	•	
ALL	C-Class	204	Body	KG-KEYLESS GO(N69/5)	•	•	•	•	•	•	<b>A</b>	
ALL	GLK	X204	Body	KG-KEYLESS GO(N69/5)	•	•	•	•	•	•	<b>A</b>	
ALL	E-Class	212	Body	KG-KEYLESS GO(N69/5)	•	•	•	•	•	•		
ALL	E-Class	207	Body	KG-KEYLESS GO(N69/5)	•	•	•	•	•	•		
ALL	M-Class	164	Body	KG-Keyless Go	•	•	•	•	•	•	•	
ALL	GL-Class	X 164	Body	KG-Keyless Go	•	•	•	•	•	•	•	
ALL	R-Class	251	Body	KG-Keyless Go	•	•	•		•		•	
Up to 06/2009	S-Class	221	Body	KG-KEYLESS GO	•	•			•			
As of 07/2009	S-Class	221	Body	KG-KEYLESS GO	•	•			•			
ALL	CL	216	Body	KG-KEYLESS GO	•				•			
ALL	M-Class	166	Body	KG-KEYLESS GO	•				•			
ALL	SL	231	Body	KG-KEYLESS GO	•				•			
ALL	CLS	218	Body	KG-KEYLESS GO (N69/5)	•	•	0	•	0	•		
ALL	M-Class	166	Body	KG-KEYLESS GO (N69/5)	•	•	0	•	0			
ALL	E-Class	212	Body	KG-KEYLESS GO (N69/5)	•	•	0	•	0			
ALL	E-Class	207	Body	KG-KEYLESS GO (N69/5)	•	•	0	•	0			
ALL	SL	231	Body	KG-KEYLESS GO (N69/5)	•	•	0	•	0			
Up to 06/2009	S-Class	221	Body	KG-Keyless Go	•	•	•	•	•	•	*	
As of 07/2009	S-Class	221	Body	KG-Keyless Go	•	•	•	•	•	•	*	
ALL	CL	216	Body	KG-Keyless Go	•	•	•	•	•	•	*	
From 09/2003 to 05/2006	SL	230	Body	KG-Keyless Go	•	•	•	•	•	•		
From 06/2006 to 02/2008	SL	230	Body	KG-Keyless Go	•	•	•	•	•	•		
As of 03/2008	SL	230	Body	KG-Keyless Go	•	•	•	•	•	•		
ALL	M-Class	164	Body	KG-KEYLESS GO	•	•	•	•	•			
ALL	GL-Class	X 164	Body	KG-KEYLESS GO	•	•	•	•	•			
ALL	R-Class	251	Body	KG-KEYLESS GO	•	•	•	•	•			
ALL	M-Class	164	Information and communication	IC-Instrument cluster	•	•	•	•	•	0	•	0156 0106 0154 0107
ALL	GL-Class	X 164	Information and communication	IC-Instrument cluster	•	•	•	•	•	0	•	0156 0106 0154 0107
ALL	R-Class	251	Information and communication	IC-Instrument cluster	•	•	•	•	•	0	•	0156 0106 0154 0107
Up to 11/2005	A-Class	169	Information and communication	IC-Instrument cluster	•	•	•	•	•	0	•	0002 0102 0103 0104 0105 0106 0107 0048 0097
As of 12/2005	A-Class	169	Information and communication	IC-Instrument cluster	•	•	•	•	•	0	•	0002 0102 0103 0104 0105 0106 0107 0048 0097

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
Up to 11/2005	B-Class	245	Information and communication	IC-Instrument cluster	•	•	•	•	•	0	•	0002 0102 0103 0104 0105 0106 0107 0048 0097
As of 12/2005	B-Class	245	Information and communication	IC-Instrument cluster	•	•	•	•	•	0	•	0002 0102 0103 0104 0105 0106 0107 0048 0097
Up to 05/2005	SLK	171	Information and communication	IC-Instrument cluster	•	•	•	•	•	0	•	
As of 06/2005	SLK	171	Information and communication	IC-Instrument cluster	•	•	•	•	•	0	•	
Up to 08/2003	C-Class	203	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	0	*	0002
Up to 03/2004	G-Class	463 (16-pin diagnostic socket)	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	0	*	0002
From 04/2004 to 08/2006	G-Class	463 (16-pin diagnostic socket)	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	0	*	0002
From 09/2006 to 02/2007	G-Class	463 (16-pin diagnostic socket)	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	0	*	0002
Up to 08/2003	C-Class	203	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	0	•	0002
From 09/2003 to 12/2007	C-Class	203	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	0	•	0002
As of 01/2008	C-Class	203	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	0	•	0002
As of 03/2007	G-Class	463 (16-pin diagnostic socket)	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	0	•	0002
Up to 03/2004	CLK	209	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	0		0002
As of 04/2004	CLK	209	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	0		0002
Up to 05/2005	E-Class	211	Information and communication	IC-Instrument cluster	•	•	•	•	•	0	•	0156 0106 0154 0107 0157 0102 0103 0104 0158 0159 0160 0161 0162 0163 0164 0165 0166 0048 0097
From 06/2005 to 05/2006	E-Class	211	Information and communication	IC-Instrument cluster	•	•	•	•	•	0	•	0156 0106 0154 0107 0157 0102 0103 0104 0158 0159 0160 0161 0162 0163 0164 0165 0166 0048 0097

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 06/2006	E-Class	211	Information and communication	IC-Instrument cluster	•	•	•	•	•	0	•	0156 0106 0154 0107 0157 0102 0103 0104 0158 0159 0160 0161 0162 0163 0164 0165 0166 0048 0097
Up to 05/2005	CLS	219	Information and communication	IC-Instrument cluster	•	•	•	•	•	0	•	0156 0106 0154 0107 0157 0102 0103 0104 0158 0159 0160 0161 0162 0163 0164 0165 0166 0048 0097
From 06/2005 to 05/2006	CLS	219	Information and communication	IC-Instrument cluster	•	•	•	•	•	0	•	0156 0106 0154 0107 0157 0102 0103 0104 0158 0159 0160 0161 0162 0163 0164 0165 0166 0048 0097
As of 06/2006	CLS	219	Information and communication	IC-Instrument cluster	•	•	•	•	•	0	•	0156 0106 0154 0107 0157 0102 0103 0104 0158 0159 0160 0161 0162 0163 0164 0165 0166 0048 0097
Up to 08/2002	S-Class	220	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	*	•	0002
Up to 08/2002	CL	215	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	*	•	0002
Up to 08/2002	S-Class	220	Information and	ICM-Instrument cluster with maintenance	•	•	•	•	•	0	•	0002
As of 09/2002	S-Class	220	communication Information and communication	interval display ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	0	•	0002
Up to 08/2002	CL	215	Information and	ICM-Instrument cluster with maintenance	•	•	•	•	•	0	•	0002
As of 09/2002	CL	215	communication Information and	interval display ICM-Instrument cluster with maintenance	•	•	•	•	•	0	•	0002
Up to 06/2009	S-Class	221	communication Information and	interval display IC-Instrument cluster	•	•	•	•	•	•	•	0156 0106 0154 0155
As of 07/2009	S-Class	221	communication Information and	IC-Instrument cluster	•	•	•	•	•	•	•	0048 0097 0156 0106 0154 0155
ALL	CL	216	communication Information and	IC-Instrument cluster	•	•	•	•	•	•	•	0048 0097 0156 0106 0154 0155
Up to 08/2003	SL	230		ICM-Instrument cluster with maintenance	•	•	•	•	•	0	•	0048 0097
From 09/2003 to	SL	230	communication Information and	interval display ICM-Instrument cluster with maintenance	•	•	•	•	•	0	•	0002
05/2006 From 06/2006 to	SL	230	communication Information and	interval display ICM-Instrument cluster with maintenance	•	•	•	•	•	0	•	0002
02/2008			communication Information and	interval display ICM-Instrument cluster with maintenance								
As of 03/2008	SL	230	communication	interval display	•	•	•	•	•	0	•	0002
ALL	SLR	199	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	0	•	0002

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
From 09/2003 to 05/2006	SL	230		ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	0	•	0002
From 06/2006 to 02/2008	SL	230	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	0	•	0002
From 09/2003 to 05/2006	SL	230	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	0	•	0002
From 06/2006 to 02/2008	SL	230	communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	0	•	0002
Up to 08/2006	MayBach	240	Information and communication	ICM-Instrument cluster	•	•	•	•	•	0	•	
As of 09/2006	MayBach	240	Information and communication	ICM-Instrument cluster	•	•	•	•	•	0	•	
ALL	G-Class	461(16-pin diagnostic socket)	Information and communication	IC-Instrument cluster	•	•	•	•	•	*	•	
ALL	CLK	208	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	•		0002
As of 03/97 DAS 3	E-Class	210	communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	•		0002
As of 09/99	SL	129	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	•		0002
ALL	G-Class	463 (38-pin diagnostic socket)	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	•	•	•	•		0002
ALL	A-Class	168		ICM-Instrument cluster with maintenance interval display	•	•	0	•	•	*	•	0002
As of 06/97	C-Class	202	communication	ICM-Instrument cluster with maintenance interval display	•	•	0	•	•	*	•	0002
ALL	CLK	208	communication	ICM-Instrument cluster with maintenance interval display	•	•	0	•	•	*	•	0002
As of 03/97 DAS 3	E-Class	210	communication	ICM-Instrument cluster with maintenance interval display	•	•	0	•	•	*	•	0002
ALL	S-Class	140	communication	ICM-Instrument cluster with maintenance interval display	•	•	0	•	•	*	•	0002
As of 09/99	SL	129	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	0	•	•	*	•	0002
ALL	SLK	170(16-pin diagnostic socket)	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	0	•	•	*	•	0002
ALL	SLK	170(38-pin diagnostic socket)	communication	ICM-Instrument cluster with maintenance interval display	•	•	0	•	•	*	•	0002
ALL	M-Class	163	Information and communication	ICM-Instrument cluster with maintenance interval display	•	•	0	•	•	*	•	0002
ALL	G-Class	463 (38-pin diagnostic socket)	communication	ICM-Instrument cluster with maintenance interval display	•	•	0	•	•	*	•	0002
As of 06/97	C-Class	202	Air conditioning	AAC-Automatic air conditioning	•	•	0	•		*		

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	CLK	208	Air conditioning	AAC-Automatic air conditioning	•	•	0	•		*		
As of 03/97 DAS	E-Class	210	Air conditioning	AAC-Automatic air conditioning	•	•	0	•		*		
ALL	S-Class	140	Air conditioning	AAC-Automatic air conditioning	•	•	0	•		*		
As of 09/99	SL	129	Air conditioning	AAC-Automatic air conditioning	•	•	0	•		*		
ALL	SLK	170(16-pin diagnostic socket)	Air conditioning	AAC-Automatic air conditioning	•	•	0	•		*		
ALL	SLK	socket)	Air conditioning	AAC-Automatic air conditioning	•	•	0	•		*		
ALL	M-Class	163	Air conditioning	AAC-Automatic air conditioning	•	•	•	•	•	•	•	
ALL	M-Class	164	Air conditioning	AAC-Automatic air conditioning	•	•	•	•	•	•	*	0146 0173 0174 0100 0148 0149 0150 0151 0048
ALL	GL-Class	X 164	Air conditioning	AAC-Automatic air conditioning	•	•	•	•	•	•	*	0146 0173 0174 0100 0148 0149 0150 0151 0048
ALL	R-Class	251	Air conditioning	AAC-Automatic air conditioning	•	•	•	•	•	•		0146 0173 0174 0100 0148 0149 0150 0151 0048
Up to 11/2005	A-Class	169	Air conditioning	C-AAC-Convenience automatic air conditioning/AAC-Automatic air	•	•	•	•	•	0	•	
As of 12/2005	A-Class	169	Air conditioning	C-AAC-Convenience automatic air conditioning/AAC-Automatic air	•	•	•	•	•	0	•	
Up to 11/2005	B-Class	245	Air conditioning	C-AAC-Convenience automatic air conditioning/AAC-Automatic air	•	•	•	•	•	0	•	
As of 12/2005	B-Class	245	Air conditioning	C-AAC-Convenience automatic air conditioning/AAC-Automatic air	•	•	•	•	•	0	•	
As of 12/2005	A-Class	169	Air conditioning	C-AAC-Convenience automatic air conditioning/AAC-Automatic air	•	•	•	•	•			
Up to 05/2005	SLK	171	Air conditioning	C-AAC-Convenience automatic air conditioning/AAC-Automatic air	•	•	•	•	•	0	•	
As of 06/2005	SLK	171	Air conditioning	C-AAC-Convenience automatic air conditioning/AAC-Automatic air	•	•	•	•	•	0	•	
Up to 08/2003	C-Class	203	Air conditioning	AAC-Automatic air conditioning	•	•	•	•	•	•	•	
From 09/2003 to 12/2007	C-Class	203	Air conditioning	AAC-Automatic air conditioning	•	•	•	•	•	•	•	
As of 01/2008	C-Class	203	Air conditioning	AAC-Automatic air conditioning	•		•	•	•	•	•	
Up to 03/2004	CLK	209	Air conditioning	AAC-Automatic air conditioning	•		•	•	•	•	•	
As of 04/2004	CLK	209	Air conditioning	AAC-Automatic air conditioning	•			•	•	•	•	
Up to 03/2004	G-Class	socket)	Air conditioning	AAC-Automatic air conditioning	•	•	•	•	•	•	•	
From 04/2004 to 08/2006	G-Class	463 (16-pin diagnostic socket)	Air conditioning	AAC-Automatic air conditioning	•	•	•	•	•	•	•	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
From 09/2006 to 02/2007	G-Class	463 (16-pin diagnostic socket)	Air conditioning	AAC-Automatic air conditioning	•	•	•	•	•	•	•	
As of 03/2007	G-Class	463 (16-pin diagnostic socket)	Air conditioning	AAC-Automatic air conditioning	•	•	•	•	•	•	•	
Up to 05/2005	E-Class	211	Air conditioning	AAC-Automatic air conditioning	•	•	•	•	•	•	•	0009
From 06/2005 to 05/2006	E-Class	211	Air conditioning	AAC-Automatic air conditioning	•	•	•	•	•	•	•	0009
As of 06/2006	E-Class	211		AAC-Automatic air conditioning	•	•	•	•	•	•	•	0009
Up to 05/2005	CLS	219	Air conditioning	AAC-Automatic air conditioning	•	•	•	•	•	•	•	0009
From 06/2005 to 05/2006	CLS	219	Air conditioning	AAC-Automatic air conditioning	•	•	•	•	•	•	•	0009
As of 06/2006	CLS	219	Air conditioning	AAC-Automatic air conditioning	•	•	•	•	•	•	•	0009
Up to 08/2002	S-Class	220	Air conditioning	AAC-Automatic air conditioning	•	•	•	•	•	*	•	0175 0176 0177 0100 0048 0097 0179 0180 0181 0182 0183
As of 09/2002	S-Class	220	Air conditioning	AAC-Automatic air conditioning	•	•	•	•	•	*	•	0175 0176 0177 0100 0048 0097 0179 0180 0181 0182 0183
Up to 08/2002	CL	215	Air conditioning	AAC-Automatic air conditioning	•	•	•	•	•	*	•	0175 0176 0177 0100 0048 0097 0179 0180 0181 0182 0183
As of 09/2002	CL	215	Air conditioning	AAC-Automatic air conditioning	•	•	•	•	•	*	•	0175 0176 0177 0100 0048 0097 0179 0180 0181 0182 0183
Up to 06/2009	S-Class	221	Air conditioning	AAC-Automatic air conditioning	•	•	•	•	•	•	*	0145 0146 0184 0147 0185 0186 0100 0148 0149 0150 0151 0187 0048
As of 07/2009	S-Class	221	Air conditioning	AAC-Automatic air conditioning	•	•	•	•	•	•	*	0145 0146 0184 0147 0185 0186 0100 0148 0149 0150 0151 0187 0048
ALL	CL	216	Air conditioning	AAC-Automatic air conditioning	•	•	•	•	•	•	*	0145 0146 0184 0147 0185 0186 0100 0148 0149 0150 0151 0187 0048
Up to 08/2003	SL	230	Air conditioning	AAC-Automatic air conditioning	•	•	•	•	•	*	•	
From 09/2003 to 05/2006	SL	230	Air conditioning	AAC-Automatic air conditioning	•	•	•	•	•	*	•	
From 06/2006 to 02/2008	SL	230	9	AAC-Automatic air conditioning	•	•	•	•	•	*	•	
As of 03/2008	SL	230		AAC-Automatic air conditioning	•	•	•	•	•	*	•	
ALL	SLR	199		AAC-Automatic air conditioning	•	•	•	•	•	*	•	
Up to 08/2006	MayBach	240		AAC-Automatic air conditioning	•	•	•	•	•	0		0003
As of 09/2006	MayBach	240	Air conditioning	AAC-Automatic air conditioning					•	0	•	0003

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 12/2005	B-Class	245	Air conditioning	C-AAC-Convenience automatic air conditioning/AAC-Automatic air	•	•	•	•	•			
ALL	A-Class	168	Air conditioning	TAC-Automatic temperature control	•	•	•	•	•	*	•	
Up to 08/2003	C-Class	203	Drive	SEQ-Sequentronic automated manual transmission	•	•	•	•	•	•		
From 09/2003 to 12/2007	C-Class	203	Drive	SEQ-Sequentronic automated manual transmission	•	•	•	•	•	•		
Up to 03/2004	CLK	209	Drive	SEQ-Sequentronic automated manual transmission	•	•	•	•	•	•		
As of 04/2004	CLK	209	Drive	SEQ-Sequentronic automated manual transmission	•	•	•		•			
ALL	CLK	208	Drive	SEQ-Sequentronic automated manual transmission	•	•	•	•	•	•		
Up to 05/2005	E-Class	211	Drive	SEQ-Sequentronic automated manual transmission	•	•	•	•	•	•		
From 06/2005 to 05/2006	E-Class	211	Drive	SEQ-Sequentronic automated manual transmission	•	•	•	•	•	•		
As of 06/2006	E-Class		Drive	SEQ-Sequentronic automated manual transmission	•	•	•	•	•	•		
Up to 05/2005	CLS	219	Drive	SEQ-Sequentronic automated manual transmission	•	•	•	•	•	•		
From 06/2005 to 05/2006	CLS	219	Drive	SEQ-Sequentronic automated manual transmission	•	•	•	•	•	•		
As of 06/2006	CLS	219	Drive	SEQ-Sequentronic automated manual transmission	•	•	•	•	•	•		
Up to 08/2003	SL	230	Drive	SEQ-Sequentronic automated manual transmission	•	•	•		•	•		
From 09/2003 to 05/2006	SL	230	Drive	SEQ-Sequentronic automated manual transmission	•	•	•	•	•	•		
From 06/2006 to 02/2008	SL	230	Drive	SEQ-Sequentronic automated manual transmission	•	•	•	•	•	•		
Up to 05/2005	SLK	171	Drive	SEQ-Sequentronic automated manual transmission	•	•	•	•	•	•		
As of 06/2005	SLK	171	Drive	SEQ-Sequentronic automated manual transmission	•	•	•		•			
ALL	CLS	218	LIN Bus	AMLAB-L 2-Actuation module 2, LED exterior lighting, left front (Eln8)	•	•	0	•	0	•		
ALL	CLS	218	LIN Bus	AMLAB-R 2-Actuation module 2, LED exterior lighting, right front (E2n8)	•	•	0	•	0	•		
ALL	B-Class	246	LIN Bus	AMLAB-L 1-Actuation module 1, LED exterior lighting, left front (Eln7)	•	•	0	•	0	•		
ALL	C-Class	204	LIN Bus	AMLAB-L 1-Actuation module 1, LED exterior lighting, left front (Eln7)	•	•	0	•	0	•		
ALL	CLS	218	LIN Bus	AMLAB-L 1-Actuation module 1, LED exterior lighting, left front (Eln7)	•	•	0	•	0	•		
ALL	GLK	X204	LIN Bus	AMLAB-L 1-Actuation module 1, LED exterior lighting, left front (Eln7)	•	•	0	•	0	•		
ALL	M-Class	166	LIN Bus	AMLAB-L 1-Actuation module 1, LED exterior lighting, left front (Eln7)	•	•	0	•	0	•		
ALL	CLA	117	LIN Bus	AMLAB-L 1-Actuation module 1, LED exterior lighting, left front (Eln7)	•	•	0	•	0	•		
ALL	A-Class	176	LIN Bus	AMLAB-L 1-Actuation module 1, LED exterior lighting, left front (Eln7)	•	•	0	•	0	•		
ALL	SL	231	LIN Bus	AMLAB-L 1-Actuation module 1, LED exterior lighting, left front (Eln7)	•	•	0	•	0	•		
ALL	B-Class	246	LIN Bus	AMLAB-R 1-Actuation module 1, LED exterior lighting, right front (E2n7)	•	•	0	•	0	•		
ALL	C-Class	204	LIN Bus	AMLAB-R 1-Actuation module 1, LED exterior lighting, right front (E2n7)	•	•	0	•	0	•		

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	CLS	218	LIN Bus	AMLAB-R 1-Actuation module 1, LED exterior lighting, right front (E2n7)	•	•	0	•	0	•		
ALL	GLK	X204	LIN Bus	AMLAB-R 1-Actuation module 1, LED exterior lighting, right front (E2n7)	•	•	0	•	0	•		
ALL	M-Class	166	LIN Bus	AMLAB-R 1-Actuation module 1, LED exterior lighting, right front (E2n7)	•	•	0	•	0	•		
ALL	CLA	117	LIN Bus	AMLAB-R 1-Actuation module 1, LED exterior lighting, right front (E2n7)	•	•	0	•	0	•		
ALL	A-Class	176	LIN Bus	AMLAB-R 1-Actuation module 1, LED exterior lighting, right front (E2n7)	•	•	0	•	0	•		
ALL	SL	231	LIN Bus	AMLAB-R 1-Actuation module 1, LED exterior lighting, right front (E2n7)	•	•	0	•	0	•		
ALL	M-Class		Body	SG-EM-Power electronics (N129/1)	•	•	0	•	0	•		
ALL	E-Class		Body	SG-EM-Power electronics (N129/1)	•	•	0	•	0	•		
ALL	E-Class	207	Body	SG-EM-Power electronics (N129/1)	•	•	0	•	0	•		
ALL	M-Class	164	Chassis	Suspension	•	•	•	•	•	0	*	0048, 0049, 0056, 0057 , 0059
ALL	GL-Class	X 164	Chassis	Suspension	•	•	•	•	•	0	*	0048, 0049, 0056, 0057 , 0059
ALL	R-Class	251	Chassis	Suspension	•	•	•	•	•	0	*	0048, 0049, 0056, 0057 , 0059
Up to 06/2009	S-Class	221	Chassis	AIRmatic	•	•	•	•	•	•	•	0048, 0049, 0051, 0056 , 0057, 0059
As of 07/2009	S-Class	221	Chassis	AIRmatic	•	•	•	•	•	•	•	0048, 0049, 0051, 0056 , 0057, 0059
ALL	CL		Chassis	AIRmatic	•	•	•	•	•	•	•	0048, 0049, 0051, 0056 , 0057, 0059
Up to 05/2005	E-Class	211	Air conditioning	HSW-Heated steering wheel	•	•	•	•	•	•	•	0003 0005
From 06/2005 to 05/2006	E-Class	211	Air conditioning	HSW-Heated steering wheel	•	•	•	•	•	•	•	0003 0005
As of 06/2006	E-Class		Air conditioning	HSW-Heated steering wheel	•	•	•	•	•	•	•	0003 0005
Up to 08/2006	MayBach			HSW-Heated steering wheel	•	•	•	•	•	•	•	0003 0005
As of 09/2006	MayBach		Air conditioning	HSW-Heated steering wheel	•	•	•	•	•	•	•	0003 0005
Up to 03/2004	G-Class	socket)		HSW-Heated steering wheel	•	•	•	•	•	•	•	0003 0005
Up to 08/2002	S-Class		Air conditioning	HSW-Heated steering wheel	•	•	•	•	•	*		
As of 09/2002	S-Class	220		HSW-Heated steering wheel	•	•	•	•	•	*	•	
Up to 08/2002	CL	215		HSW-Heated steering wheel	•	•	•	•	•	*	•	
As of 09/2002	CL			HSW-Heated steering wheel	•	•	•	•	•	*	•	
Up to 08/2003	SL	230	Air conditioning	HSW-Heated steering wheel	•	•	•	•	•	*	•	
From 09/2003 to 05/2006	SL	230	Air conditioning	HSW-Heated steering wheel	•	•	•	•	•	*	•	
From 06/2006 to 02/2008	SL		_	HSW-Heated steering wheel	•	•	•	•	•	*	•	
As of 03/2008	SL			HSW-Heated steering wheel	•	•	•	•	•	*	•	
ALL	B-Class		Chassis	DTR-DISTRONIC (A89)	•	•	0	•	0	•		
ALL	CLA	117	Chassis	DTR-DISTRONIC (A89)		•	0	•	0	•		

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	A-Class	176	Chassis	DTR-DISTRONIC (A89)	•	•	0	•	0	•		
ALL	B-Class	246	Chassis	DTR-DISTRONIC (A89)	•	•	0	•	0	•		
ALL	CLA	117	Chassis	DTR-DISTRONIC (A89)	•	•	0	•	0	•		
ALL	A-Class	176	Chassis	DTR-DISTRONIC (A89)	•	•	0	•	0	•		
ALL	B-Class	246	LIN Bus	RGLS-Rain/light sensor (B38/2)	•	•	0	•	0	•		
ALL	M-Class	166	LIN Bus	RGLS-Rain/light sensor (B38/2)	•	•	0	•	0	•		
ALL	CLA	117	LIN Bus	RGLS-Rain/light sensor (B38/2)	•	•	0	•	0	•		
ALL	A-Class	176	LIN Bus	RGLS-Rain/light sensor (B38/2)	•	•	0	•	0	•		
ALL	SLK	172	Body	MSC-MAGIC SKY CONTROL (N53)	•	•	0	•	0	•		
ALL	SL	231	Body	MSC-MAGIC SKY CONTROL (N53)	•	•	0	•	0	•		
Up to 08/2002	S-Class	220	Chassis	AIRmatic	•	•	•	•	•	*		0049, 0051, 0056, 0057
As of 09/2002	S-Class	220	Chassis	AIRmatic	•	•	•	•	•	*		0049, 0051, 0056, 0057
As of 06/97	C-Class		Body	HRA-Headlamp range adjustment	•	•	0	•		*		
ALL	CLK		Body	HRA-Headlamp range adjustment	•	•	0	•		*		
	E-Class		Body	HRA-Headlamp range adjustment	•	•	0	•		*		
As of 09/99	SL		Body	HRA-Headlamp range adjustment	•	•	0	•		*		
ALL	M-Class		Body	HRA-Headlamp range adjustment	•	•	•	•	•	0	•	
ALL	SLK	170(16-pin diagnostic socket)	Body	HRA-Headlamp range adjustment	•	•	•	•	•	*	0	
ALL	CLK	208	Body	HRA-Headlamp range adjustment	•	•	0	•	•	0		
As of 03/97 DAS	E-Class	210	Body	HRA-Headlamp range adjustment	•	•	0	•	•	0		
Up to 08/2002	S-Class	220	Body	HRA-Headlamp range adjustment	•	•	•	•	•	*	•	
Up to 08/2002	CL	215	Body	HRA-Headlamp range adjustment	•	•	•	•	•	*	•	
Up to 08/2002	S-Class	220	Body	HRA-Headlamp range adjustment	•	•	•	•	•	*	•	
As of 09/2002	S-Class	220	Body	HRA-Headlamp range adjustment	•	•	•	•	•	*	•	
ALL	CLS	218	Seats and doors	AMKS-LF-Active multicontour seat(N32/19)	•	•	•	•	•	•	<b>A</b>	
ALL	E-Class	212	Seats and doors	AMKS-LF-Active multicontour seat(N32/19)	•	•	•	•	•	•	<b>A</b>	
ALL	M-Class	166		MKS-FS-Multicontour seat 'Driver' (N32/29)	•	•	0	•	0	•		
	S-Class	221		DS-LF-Left front dynamic seat	•	•	•	•	•	•		
ALL	SL	231		DS-LF-Left front dynamic seat	•	•	•	•	•	•		
ALL	CLS	218		AMKS-RF-Active multicontour seat(N32/22)	•	•	•	•	•	•	<b>A</b>	
ALL	E-Class	212		AMKS-RF-Active multicontour seat(N32/22)	•	•	•	•	•	•	<b>A</b>	
ALL	M-Class	166	Seats and doors	MKS-BFS-Multicontour seat 'Front passenger' (N32/30)	•	•	0	•	0	•		
As of 07/2009	S-Class	221	Seats and doors	DS-RF-Right front dynamic seat	•	•	•	•	•	•		
ALL	SL	231		DS-RF-Right front dynamic seat	•	•	•	•	•	•		
ALL	M-Class	163	Information and communication	MCS-Modular control system	•	•	0	•	•	•		
ALL	M-Class	163	Information and communication	MCS navigation-Navigation in MCS	•	•	0	•	•	•		
As of 09/99	SL	129	Drive	ME1-SFI-Motor electronics	•	•	0	•		*		
As of 07/2009	S-Class	221	Drive	ME-SF 17.7-Motor electronics 17.7	•	•	•	•	•			
ALL	M-Class	164	Drive	ME-SF 17.7-Motor electronics 17.7	•	•	•	•	•			
ALL	SL	231	Drive	ME-Motor electronics 'ME1778' for combustion engine 'M277' (N3/10)	•	•	0	•	0	•		
ALL	S-Class	140	Drive	ME1RE-Motor electronics 1 RE	•	•	0	•	0	*	0	
As of 06/97	C-Class	202	Drive	ME2-SFI-Motor electronics 2	•	•	0	•	•	*		

v 1.1	W 1 1	Model	Control Unit		Ecu	Read	Event	Erase	Live	Freeze	Active	g . 1 B
Model year	Mode1	Series	Groups	System Name	Info.	Codes	Memory	Codes	Data	Frame	Test	Special Function
ALL	CLK	208	Drive	ME2-SFI-Motor electronics 2	•	•	0	•	•	*		
As of 03/97 DAS	E-Class	210	Drive	ME2-SFI-Motor electronics 2	•	•	0	•	•	*		
ALL	S-Class	140	Drive	ME2-SFI-Motor electronics 2	•	•	0	•	•	*		
As of 09/99	SL	129	Drive	ME2-SFI-Motor electronics 2	•		0	•	•	*		
		170(38-pin										
ALL	SLK	diagnostic	Drive	ME2-SFI-Motor electronics 2	•	•	0	•	•	*		
		socket)										
ALL	M-Class	163	Drive	ME2-SFI-Motor electronics 2	•	•	0	•	•	*		
		463(38-pin										
ALL	G-Class	diagnostic	Drive	ME2-SFI-Motor electronics 2	•	•	0	•	•	*		
		socket)										
Up to 08/2002	S-Class	220	Drive	ME-SFI 2.0-Motor electronics 2.0	•	•	•	•	•	*	•	0003
Up to 08/2002	CL	215	Drive	ME-SFI 2.0-Motor electronics 2.0	•	•	•	•	•	*	•	0003
As of 09/2002	CL	215	Drive	ME-SFI 2.0-Motor electronics 2.0	•	•	•	•	•	*	•	0003
Up to 08/2002	S-Class	220	Drive	ME-SFI 2.0-Motor electronics 2.0	•	•	•	•	•	*	•	0003
Up to 08/2002	CL	215	Drive	ME-SFI 2.0-Motor electronics 2.0	•	•	•	•	•	*	•	0003
Up to 08/2002	S-Class		Drive	ME-SFI 2.7-Motor electronics 2.7	•	•	•	•	•	•		
Up to 08/2002	CL	215	Drive	ME-SFI 2.7-Motor electronics 2.7	•	•	•		•			
	S-Class	221	Drive	ME 2.7.2-Motor electronics 2.7.2	•	•	•		•			0004
As of 07/2009	S-Class	221	Drive	ME 2.7.2-Motor electronics 2.7.2	•	•	•		•			0004
ALL		216	Drive	ME 2.7.2-Motor electronics 2.7.2	•	•	•	•	•	•		0004
	MayBach	240	Drive	ME 2.7.2-Motor electronics 2.7.2	•	•	•	•	•	•		0004
From 09/2003 to						•						
05/2006	SL	230	Drive	ME 2.7.2-Motor electronics 2.7.2	•	•	•	•	•	•		0004
From 06/2006 to												
02/2008	SL	230	Drive	ME 2.7.2-Motor electronics 2.7.2	•	•	•	•	•	•		0004
As of 03/2008	SL	230	Drive	ME 2.7.2-Motor electronics 2.7.2	•	•		•	•	•		0004
Up to 06/2009	S-Class	221	Drive	ME 2.7.2-Motor electronics 2.7.2	•	•	•	•	•	•		0004
As of 07/2009	S-Class	221	Drive	ME 2.7.2-Motor electronics 2.7.2	•	•	•	•	•			0004
ALL	CL	216	Drive	ME 2.7.2-Motor electronics 2.7.2	•	•	•	•	•	•		0004
	MayBach	240	Drive	ME 2.7.2-Motor electronics 2.7.2	•	•	•	•	•	•		0004
From 06/2006 to						-	-					
02/2008	SL	230	Drive	ME 2.7.2-Motor electronics 2.7.2	•	•	•	•	•	•		0004
	SL	230	Drive	ME 2.7.2-Motor electronics 2.7.2	•	•	•	•	•	•		0004
Up to 08/2003	C-Class	203	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•		•	0004
From 09/2003 to												
12/2007	C-Class	203	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
As of 06/97	C-Class	202	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
Up to 03/2004	CLK	209	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
As of 04/2004	CLK	209	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
ALL	CLK	208	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
Up to 05/2005			Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
From 06/2005 to												
05/2006	E-Class	211	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
	E-Class	210	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
			Drive	ME-SFI 2.8-Motor electronics 2.8		•	•		•	•	•	0004
From 06/2005 to			DITAC			_	_	_				
05/2006	CLS	219	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
VJ/ 4000												

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 06/2006	CLS	219	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•			0004
Up to 08/2002	S-Class	220	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
As of 09/2002	S-Class	220	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
Up to 08/2002	CL	215	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•		•	•	•	•	0004
As of 09/2002	CL	215	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
Up to 08/2003	SL	230	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
From 09/2003 to 05/2006	SL	230	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
From 06/2006 to 02/2008	SL	230	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
		170(16-pin										
ALL	SLK	diagnostic socket)	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
ALL	M-Class	164	Drive	ME-SFI 2.8-Motor electronics 2.8		•	•	•	•		•	0004
ALL	M-Class	163	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•			0004
Up to 03/2004	G-Class	463 (16-pin diagnostic socket)	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
From 04/2004 to 08/2006	G-Class	463 (16-pin diagnostic socket)	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
From 09/2006 to 02/2007	G-Class	463 (16-pin diagnostic socket)	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
As of 03/2007	G-Class	463 (16-pin diagnostic socket)	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
ALL	G-Class	463 (38-pin diagnostic socket)	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
ALL	R-Class	251	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•		•	•	•	0004
Up to 08/2003	C-Class	203	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•		•	0004
From 09/2003 to 12/2007	C-Class	203	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
As of 06/97	C-Class	202	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
Up to 03/2004	CLK	209	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
	CLK	209	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
ALL	CLK		Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•		0004
Up to 05/2005	E-Class	211	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
From 06/2005 to 05/2006	E-Class	211	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
	E-Class	210	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
Up to 05/2005	CLS	219	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
From 06/2005 to 05/2006	CLS	219	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
As of 06/2006	CLS	219	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
Up to 08/2002	S-Class	220	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
	S-Class	•	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
Up to 08/2002	CL	215	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
As of 09/2002	CL	215	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•		•	0004
Up to 08/2003	SL	230	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•		•	0004
From 09/2003 to 05/2006	SL	230	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
From 06/2006 to 02/2008	SL	230	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
ALL	SLR	199	Drive	ME-SFI 2.8-Motor electronics 2.8	•				•			0004
Up to 05/2005	SLK	171	Drive	ME-SFI 2.8-Motor electronics 2.8	•		•	•	•		•	0004
As of 06/2005	SLK	171	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•			•	•	•	0004
ALL	SLK	170 (16-pin diagnostic socket)		ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
ALL	M-Class	164	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•			•		•	0004
ALL	M-Class		Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
Up to 03/2004	G-Class	463 (16-pin diagnostic socket)		ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)		ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)		ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
ALL	R-Class		Drive	ME-SFI 2.8-Motor electronics 2.8	•	•	•	•	•	•	•	0004
ALL	C-Class	204	Drive	ME 9.7-Motor electronics 9.7	•	•	•	•	•	•		0004 0205 0206 0207 0210 0189 0190 0191 0192 0217 0219 0196 0220 0221 0087 0088 0089 0090 0048
From 09/2003 to 12/2007	C-Class	203	Drive	ME 9.7-Motor electronics 9.7	•	•	•	•	•	•		0004 0205 0206 0207 0210 0189 0190 0191 0192 0217 0219 0196 0220 0221 0087 0088 0089 0090 0048
As of 01/2008	C-Class	203	Drive	ME 9.7-Motor electronics 9.7	•	•	•	•	•	•	*	0004 0205 0206 0207 0210 0189 0190 0191 0192 0217 0219 0196 0220 0221 0087 0088 0089 0090 0048
As of 04/2004	CLK	209	Drive	ME 9.7-Motor electronics 9.7	•	•	•	•	•	•	*	0004 0205 0206 0207 0210 0189 0190 0191 0192 0217 0219 0196 0220 0221 0087 0088 0089 0090 0048

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
Up to 05/2005	E-Class	211	Drive	ME 9.7-Motor electronics 9.7	•	•	•	•	•	•		0004 0205 0206 0207 0210 0189 0190 0191 0192 0217 0219 0196 0220 0221 0087 0088 0089 0090 0048
From 06/2005 to 05/2006	E-Class	211	Drive	ME 9.7-Motor electronics 9.7	•	•	•	•	•	•	*	0004 0205 0206 0207 0210 0189 0190 0191 0192 0217 0219 0196 0220 0221 0087 0088 0089 0090 0048
As of 06/2006	E-Class	211	Drive	ME 9.7-Motor electronics 9.7	•	•	•	•	•	•	*	0004 0205 0206 0207 0210 0189 0190 0191 0192 0217 0219 0196 0220 0221 0087 0088 0089 0090 0048
Up to 05/2005	CLS	219	Drive	ME 9.7-Motor electronics 9.7	•	•	•	•	•	•		0004 0205 0206 0207 0210 0189 0190 0191 0192 0217 0219 0196 0220 0221 0087 0088 0089 0090 0048
From 06/2005 to 05/2006	CLS	219	Drive	ME 9.7-Motor electronics 9.7	•	•	•	•	•	•	*	0004 0205 0206 0207 0210 0189 0190 0191 0192 0217 0219 0196 0220 0221 0087 0088 0089 0090 0048
As of 06/2006	CLS	219	Drive	ME 9.7-Motor electronics 9.7	•	•	•	•	•	•		0004 0205 0206 0207 0210 0189 0190 0191 0192 0217 0219 0196 0220 0221 0087 0088 0089 0090 0048
ALL	CLS	218	Drive	ME 9.7-Motor electronics 9.7	•	•	•	•	•	•	*	0004 0205 0206 0207 0210 0189 0190 0191 0192 0217 0219 0196 0220 0221 0087 0088 0089 0090 0048
Up to 06/2009	S-Class	221	Drive	ME 9.7-Motor electronics 9.7	•	•	•	•	•	•	*	0004 0205 0206 0207 0210 0189 0190 0191 0192 0217 0219 0196 0220 0221 0087 0088 0089 0090 0048
As of 07/2009	S-Class	221	Drive	ME 9.7-Motor electronics 9.7	•	•	•	•	•	•	*	0004 0205 0206 0207 0210 0189 0190 0191 0192 0217 0219 0196 0220 0221 0087 0088 0089 0090 0048

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	CL	216	Drive	ME 9.7-Motor electronics 9.7	•	•	•	•	•	•	*	0004     0205     0206     0207       0210     0189     0190     0191       0192     0217     0219     0196       0220     0221     0087     0088       0089     0090     0048
From 09/2003 to 05/2006	SL	230	Drive	ME 9.7-Motor electronics 9.7	•	•	•	•	•	•	*	0004 0205 0206 0207 0210 0189 0190 0191 0192 0217 0219 0196 0220 0221 0087 0088 0089 0090 0048
From 06/2006 to 02/2008	SL	230	Drive	ME 9.7-Motor electronics 9.7	•	•	•	•	•	•	*	0004 0205 0206 0207 0210 0189 0190 0191 0192 0217 0219 0196 0220 0221 0087 0088 0089 0090 0048
As of 03/2008	SL	230	Drive	ME 9.7-Motor electronics 9.7	•	•	•	•	•	•		0004 0205 0206 0207 0210 0189 0190 0191 0192 0217 0219 0196 0220 0221 0087 0088 0089 0090 0048
Up to 05/2005	SLK	171	Drive	ME 9.7-Motor electronics 9.7	•	•	•	•	•	•	*	0004 0205 0206 0207 0210 0189 0190 0191 0192 0217 0219 0196 0220 0221 0087 0088 0089 0090 0048
As of 06/2005	SLK	171	Drive	ME 9.7-Motor electronics 9.7	•	•	•	•	•	•	*	0004 0205 0206 0207 0210 0189 0190 0191 0192 0217 0219 0196 0220 0221 0087 0088 0089 0090 0048
ALL	GLK	X204	Drive	ME 9.7-Motor electronics 9.7	•	•	•	•	•	•	*	0004 0205 0206 0207 0210 0189 0190 0191 0192 0217 0219 0196 0220 0221 0087 0088 0089 0090 0048
ALL	M-Class	164	Drive	ME 9.7-Motor electronics 9.7	•	•	•	•	•	•	*	0004 0205 0206 0207 0210 0189 0190 0191 0192 0217 0219 0196 0220 0221 0087 0088 0089 0090 0048
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Drive	ME 9.7-Motor electronics 9.7	•	•	•	•	•	•	*	0004 0205 0206 0207 0210 0189 0190 0191 0192 0217 0219 0196 0220 0221 0087 0088 0089 0090 0048

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	GL-Class	X 164	Drive	ME 9.7-Motor electronics 9.7	•	•	•	•	•	•	*	0004 0205 0206 0207 0210 0189 0190 0191 0192 0217 0219 0196 0220 0221 0087 0088 0089 0090 0048
ALL	R-Class	251	Drive	ME 9.7-Motor electronics 9.7	•	•	•	•	•	•	*	0004     0205     0206     0207       0210     0189     0190     0191       0192     0217     0219     0196       0220     0221     0087     0088       0089     0090     0048
ALL	E-Class	212	Drive	ME 9.7-Motor electronics 9.7	•	•	•	•	•	•	*	0004 0205 0206 0207 0210 0189 0190 0191 0192 0217 0219 0196 0220 0221 0087 0088 0089 0090 0048
ALL	E-Class	207	Drive	ME 9.7-Motor electronics 9.7	•	•	•	•	•	•	*	0004 0205 0206 0207 0210 0189 0190 0191 0192 0217 0219 0196 0220 0221 0087 0088 0089 0090 0048
ALL	C-Class	204	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	•	•	•	•	•	•	•	0004 0013 0219 0221 0085 0088 0090 0048 0222
As of 04/2004	CLK	209	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	•	•	•	•	•	•	•	0004 0013 0219 0221 0085 0088 0090 0048 0222
As of 06/2006	E-Class	211	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	•	•	•	•	•	•	•	0004 0013 0219 0221 0085 0088 0090 0048 0222
Up to 05/2005	CLS	219	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	•	•	•	•	•	•	•	0004 0013
From 06/2005 to 05/2006	CLS	219	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	•	•	•	•	•	•	•	0004 0013
As of 06/2006	CLS	219	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	•	•	•	•	•	•	•	0004 0013
ALL	CLS	218	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	•	•	•	•	•	•	•	0004 0013
Up to 06/2009	S-Class	221	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	•	•	•	•	•	•	•	0004 0013
As of 07/2009	S-Class	221	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	•	•	•	•	•	•	•	0004 0013
ALL	CL	216	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	•		•	•	•	•	•	0004 0013
As of 03/2008	SL	230	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	•	•	•	•	•	•	•	0004 0013
ALL	GLK		Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	•	•	•	•	•	•	•	0004 0013
ALL	M-Class	164	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	•	•	•	•	•	•	•	0004 0013
ALL	R-Class		Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	•		•	•	•	•	•	0004 0013
ALL	E-Class	212	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	•		•	•	•	•	•	0004 0013
ALL	E-Class		Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	•	•	•	•	•	•	•	0004 0013
ALL	SLS		Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	•	•	•	•	•	•	•	0004 0013
ALL	C-Class		Drive	MED 17.7-Motor electronics for direct injection 17.7	•	•	•	•	•			
ALL	CLS	218	Drive	MED 17.7-Motor electronics for direct injection 17.7	•	•	•	•	•			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 07/2009	S-Class	221	Drive	MED 17.7-Motor electronics for direct injection 17.7	•	•	•	•	•			
ALL	CL	216	Drive	MED 17.7-Motor electronics for direct injection 17.7	•	•	•	•	•			
ALL	SLK	172	Drive	MED 17.7-Motor electronics for direct injection 17.7	•	•	•	•	•			
ALL	GLK	X204	Drive	MED 17.7-Motor electronics for direct injection 17.7	•	•	•	•	•			
ALL	M-Class	166	Drive	MED 17.7-Motor electronics for direct injection 17.7	•	•	•	•	•			
ALL	E-Class	212	Drive	MED 17.7-Motor electronics for direct injection 17.7	•	•	•	•	•			
ALL	E-Class	207	Drive	MED 17.7-Motor electronics for direct injection 17.7	•	•	•	•	•			
ALL	SL	231	Drive	MED 17.7-Motor electronics for direct injection 17.7	•	•	•	•	•			
ALL	SLK	172	Drive	ME-Motor electronics 'MED177AMG' for combustion engine 'M152' (N3/10)	•	•	0	•	0	•		
ALL	B-Class	246	Drive	ME-Motor electronics 'MED40' for combustion engine 'M270' (N3/10)	•	•	0	•	0	•		0080
ALL	C-Class	204	Drive	ME-Motor electronics 'MED40' for combustion engine 'M270' (N3/10)	•	•	0	•	0	•		0080
ALL	CLS	218	Drive	ME-Motor electronics 'MED40' for combustion engine 'M270' (N3/10)	•	•	0	•	0	•		0080
ALL	GLK	X204	Drive	ME-Motor electronics 'MED40' for combustion engine 'M270' (N3/10)	•	•	0	•	0	•		0080
ALL	E-Class	212	Drive	ME-Motor electronics 'MED40' for combustion engine 'M270' (N3/10)	•	•	0	•	0	•		0080
ALL	E-Class	207	Drive	ME-Motor electronics 'MED40' for combustion engine 'M270' (N3/10)	•	•	0	•	0	•		0080
ALL	CLA	117	Drive	ME-Motor electronics 'MED40' for combustion engine 'M270' (N3/10)	•	•	0	•	0	•		0080
ALL	A-Class	176	Drive	ME-Motor electronics 'MED40' for combustion engine 'M270' (N3/10)	•	•	0	•	0	•		0080
ALL	CLA	117	Drive	ME-Motor electronics 'MED40AMG' for combustion engine 'M133' (N3/10)	•	•	0	•	0	•		
ALL	A-Class	176	Drive	ME-Motor electronics 'MED40AMG' for combustion engine 'M133' (N3/10)	•	•	0	•	0	•		
ALL	B-Class	246	Drive	ME-Motor electronics 'MED40CNG' for combustion engine 'M274' (N3/10)	•	•	0	•	0	•		
ALL	E-Class	212	Drive	ME-Motor electronics 'MED40CNG' for combustion engine 'M274' (N3/10)	•	•	0	•	0	•		
ALL	E-Class	207	Drive	ME-Motor electronics 'MED40CNG' for combustion engine 'M274' (N3/10)	•	•	0	•	0	•		
ALL	C-Class	204	Drive	MED 9.7-Motor electronics for direct injection	•	•	•	•	•	•	*	0013
Up to 05/2005	CLS	219	Drive	MED 9.7-Motor electronics for direct injection	•	•	•	•	•	•	*	0013
From 06/2005 to 05/2006	CLS	219	Drive	MED 9.7-Motor electronics for direct injection 9.7	•	•	•	•	•	•	*	0013

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 06/2006	CLS	219	Drive	MED 9.7-Motor electronics for direct injection	•	•	•	•	•	•	*	0013
ALL	CLS	218	Drive	MED 9.7-Motor electronics for direct injection	•	•	•	•	•	•	*	0013
ALL	GLK	X204	Drive	MED 9.7-Motor electronics for direct injection	•	•	•		•	•	*	0013
ALL	E-Class	212	Drive	MED 9.7-Motor electronics for direct injection	•	•	•	•	•	•	*	0013
ALL	E-Class	207	Drive	MED 9.7-Motor electronics for direct injection	•	•	•		•	•	*	0013
Up to 08/2003	C-Class	203	Information and communication	TELE AID-Telematic system	•	•	•	•	•			
Up to 03/2004	CLK	209	Information and communication	TELE AID-Telematic system	•	•	•	•	•			
ALL	CLK	208	Information and communication	TELE AID-Telematic system	•	•	•	•	•			
As of 03/97 DAS 3	E-Class	210	Information and communication	TELE AID-Telematic system	•	•	•	•	•			
Up to 08/2002	S-Class	220	Information and communication	TELE AID-Telematic system	•	•	•	•	•			
As of 09/2002	S-Class	220	Information and communication	TELE AID-Telematic system	•	•	•	•	•			
Up to 08/2002	CL	215	Information and communication	TELE AID-Telematic system	•	•	•	•	•			
As of 09/2002	CL	215	Information and communication	TELE AID-Telematic system	•	•	•	•	•			
Up to 08/2003	SL	230	Information and communication	TELE AID-Telematic system	•	•	•	•	•			
From 09/2003 to 05/2006	SL	230	Information and communication	TELE AID-Telematic system	•	•	•	•	•			
From 06/2006 to 02/2008	SL	230	Information and communication	TELE AID-Telematic system	•	•	•	•	•			
As of 03/2008	SL	230	Information and communication	TELE AID-Telematic system	•	•	•	•	•			
ALL	SLR	199	Information and communication	TELE AID-Telematic system	•	•	•	•	•			
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Information and communication	TELE AID-Telematic system	•	•	•	•	•			
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Information and communication	TELE AID-Telematic system	•	•	•	•	•			
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	TELE AID-Telematic system	•	•	•	•	•			
Up to 08/2002	S-Class	220	Seats and doors	OSB-R-Multicontour backrest rear	•	•	•	•	•	*	•	
As of 09/2002	S-Class	220	Seats and doors	OSB-R-Multicontour backrest rear	•	•	•	•	•	*	•	
Up to 08/2002	CL	215		OSB-FL-Multicontour backrest front left	•	•	•	•	•	*		
As of 09/2002	CL	215		OSB-FL-Multicontour backrest front left	•	•	•	•	•	*		
Up to 08/2003	SL	230	Seats and doors	OSB-FL-Multicontour backrest front left	•	•	•	•	•	*		
From 09/2003 to 05/2006	SL	230	Seats and doors	OSB-FL-Multicontour backrest front left	•	•	•	•	•	*		

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
From 06/2006 to 02/2008	SL	230	Seats and doors	OSB-FL-Multicontour backrest front left	•	•	•	•	•	*		
As of 03/2008	SL	230	Seats and doors	OSB-FL-Multicontour backrest front left	•	•	•	•	•	*		
Up to 08/2002	S-Class	220	Seats and doors	OSB-FL-Multicontour backrest front left	•	•	•	•	•	*	•	
As of 09/2002	S-Class	220	Seats and doors	OSB-FL-Multicontour backrest front left	•	•	•	•	•	*	•	
Up to 08/2002	CL	215	Seats and doors	OSB-FR-Multicontour backrest front right	•	•	•	•	•	*		
As of 09/2002	CL	215	Seats and doors	OSB-FR-Multicontour backrest front right	•	•	•	•	•	*		
Up to 08/2003	SL	230	Seats and doors	OSB-FR-Multicontour backrest front right	•	•	•	•	•	*		
From 09/2003 to 05/2006	SL	230	Seats and doors	OSB-FR-Multicontour backrest front right	•	•	•	•	•	*		
From 06/2006 to 02/2008	SL	230	Seats and doors	OSB-FR-Multicontour backrest front right	•	•	•	•	•	*		
As of 03/2008	SL	230	Seats and doors	OSB-FR-Multicontour backrest front right	•	•	•	•	•	*		
Up to 08/2002	S-Class	220	Seats and doors	OSB-FR-Multicontour backrest front right	•	•	•	•	•	*	•	
As of 09/2002	S-Class	220		OSB-FR-Multicontour backrest front right	•	•	•	•	•	*	•	
As of 09/2002	S-Class	220	Drive	ME-SFI 2.7.1-Motor electronics 2.7.1	•	•	•	•	•	•	•	0004
As of 09/2002	CL	215	Drive	ME-SFI 2.7.1-Motor electronics 2.7.1	•	•	•	•	•	•	•	0004
Up to 08/2006	MayBach	240	Drive	ME-SFI 2.7.1-Motor electronics 2.7.1	•	•	•	•	•	•	•	0004
From 09/2003 to 05/2006	SL	230	Drive	ME-SFI 2.7.1-Motor electronics 2.7.1	•	•	•	•	•	•	•	0004
From 06/2006 to 02/2008	SL	230	Drive	ME-SFI 2.7.1-Motor electronics 2.7.1	•	•	•	•	•	•	•	0004
Up to 08/2006	MayBach	240	Seats and doors	MKL-HL-Rear left multicontour backrest	•	•	•	•	•	0	•	
As of 09/2006	MayBach	240	Seats and doors	MKL-HL-Rear left multicontour backrest	•	•	•	•	•	0	•	
Up to 08/2006	MayBach	240	Seats and doors	MKL-HR-Rear right multicontour backrest	•	•	•	•	•	0	•	
As of 09/2006	MayBach	240	Seats and doors	MKL-HR-Rear right multicontour backrest		•			•	0	•	
Up to 08/2006	MayBach	240	Seats and doors	OSB-FL-Multicontour backrest front left	•	•	•	•	•	0	•	
As of 09/2006	MayBach	240	Seats and doors	OSB-FL-Multicontour backrest front left	•	•	•	•	•	0	•	
Up to 08/2006	MayBach	240	Seats and doors	OSB-FR-Multicontour backrest front right			0		•	0	•	
As of 09/2006	MayBach	240	Seats and doors	OSB-FR-Multicontour backrest front right	•		0	•	•	0		
ALL	B-Class	246	Information and communication	MFK-Multifunction camera	•	•	•	•	•	•		
ALL	C-Class	204	Information and communication	MFK-Multifunction camera	<b>A</b>	•	<b>A</b>	<b>A</b>	<b>A</b>	•		
ALL	CLS	218	Information and communication	MFK-Multifunction camera	<b>A</b>	•	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>		
As of 07/2009	S-Class	221	Information and communication	MFK-Multifunction camera	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>		
ALL	CL	216	Information and communication	MFK-Multifunction camera	<b>A</b>	•	<b>A</b>	<b>A</b>	•	<b>A</b>		
ALL	SLK	172	Information and communication	MFK-Multifunction camera	<b>A</b>	•	<b>A</b>	<b>A</b>	•	<b>A</b>		
ALL	GLK	X204	Information and communication	MFK-Multifunction camera	<b>A</b>	<b>A</b>	<b>A</b>	•	•	<b>A</b>		
ALL	M-Class	166	Information and communication	MFK-Multifunction camera	<b>A</b>	•	<b>A</b>	<b>A</b>	<b>A</b>	•		
ALL	E-Class	212	Information and communication	MFK-Multifunction camera	<b>A</b>	•	<b>A</b>	•	<b>A</b>	•		

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	E-Class	207	Information and communication	MFK-Multifunction camera	•	•	•	•	<b>A</b>	<b>A</b>		
ALL	CLA	117	Information and communication	MFK-Multifunction camera	•	•	•	•	<b>A</b>	<b>A</b>		
ALL	A-Class	176	Information and communication	MFK-Multifunction camera	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>	<b>A</b>		
ALL	SL	231	Information and communication	MFK-Multifunction camera	•	•	•	•	<b>A</b>	•		
ALL	C-Class	204	Body	MSS-Special vehicle multifunction control	•	•	•	•	•	•	•	
ALL	GLK	X204	Body	MSS-Special vehicle multifunction control	•	•	•	•	•	•	•	
ALL	C-Class	204	Body	Multifunction control unit-Multifunction control unit (N26/14)	•	•	•	•	•	•	<b>A</b>	
ALL	GLK	X204	Body	Multifunction control unit-Multifunction control unit (N26/14)	•	•	•	•	•	•	<b>A</b>	
ALL	E-Class	212	Body	Multifunction control unit-Multifunction control unit (N26/14)	•	•	•	•	•	•	•	
Up to 06/2009	S-Class	221	Body	MSS-Special vehicle multifunction control	•	•	•	•	•	•	•	0003
As of 07/2009	S-Class	221	Body	MSS-Special vehicle multifunction control	•	•		•	•	•	•	0003
ALL	M-Class	164	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•	•	0005
ALL	GL-Class	X 164	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•	•	0005
ALL	R-Class	251	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•	•	0005
Up to 11/2005	A-Class	169	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•	•	0005
As of 12/2005	A-Class	169	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•	•	0005
Up to 11/2005	B-Class	245	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•	•	0005
As of 12/2005	B-Class	245	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•	•	0005
Up to 08/2003	C-Class	203	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•	•	0005
From 09/2003 to 12/2007	C-Class	203	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•	•	0005
As of 01/2008	C-Class	203	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•	•	0005
As of 04/2004	CLK	209	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•	•	0005
Up to 05/2005	E-Class	211	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	E-Class	211	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•	•	
As of 06/2006	E-Class	211	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•	•	
Up to 05/2005	CLS	219	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•	•	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
From 06/2005 to	CLS	219	Information and	SCM [MRM]-Steering column module	•	•	•	•	•	•	•	
05/2006 As of 06/2006	CLS	219	communication Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•	•	
Up to 05/2005	SLK	171	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•	•	
As of 06/2005	SLK	171	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•	•	
Up to 03/2004	G-Class	463 (16-pin diagnostic socket)	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•	•	
From 04/2004 to 08/2006	G-Class	463 (16-pin diagnostic socket)	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•	•	
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•	•	
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•	•	
Up to 08/2003	C-Class	203	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•		0005
Up to 03/2004	CLK	209	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•		0005
Up to 05/2005	E-Class	211	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•	•	0005
From 06/2005 to 05/2006	E-Class	211	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•	•	0005
As of 06/2006	E-Class	211	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•	•	0005
Up to 08/2006	MayBach	240	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•	•	0005
As of 09/2006	MayBach	240	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•	•	0005
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•	•	0005
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•	•	0005
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•	•	0005
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•	•	0005
Up to 08/2002	S-Class	220	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	*	•	0005

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
Up to 08/2002	CL	215	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	*	•	0005
Up to 06/2009	S-Class	221	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•	•	0005
As of 07/2009	S-Class	221	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•	•	0005
ALL	CL	216	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•	•	0005
Up to 08/2002	S-Class	220	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	*		
As of 09/2002	S-Class	220	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	*		
As of 09/2002	CL	215	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	*		
Up to 08/2003	SL	230	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	*		
From 09/2003 to 05/2006	SL	230	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	*		
From 06/2006 to 02/2008	SL	230	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	*		
As of 03/2008	SL	230	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	*		
	SLR	199	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	*		
	A-Class	168	Drive	ECM-Engine control monolith	•	•	0	•	•	*		
ALL	A-Class	168	Drive	ECM-Engine control monolith	•	•	•	•	•	<u>*</u>	•	
Up to 11/2005	A-Class	169 169	Body Body	MSS-Special vehicle multifunction control		_				0		
	A-Class B-Class	245	Body	MSS-Special vehicle multifunction control		_				0		
	B-Class	245	Body	MSS-Special vehicle multifunction control MSS-Special vehicle multifunction control						0		
As of 06/97	C-Class	202	Body	MSS-Special vehicle multifunction control			0			*		
	E-Class	210	Body	MSS-Special vehicle multifunction control			0		<del>-</del>	*		
	A-Class	169	Body	MSS-Special vehicle multifunction control			•		$\overline{}$	0	•	0003
	A-Class	169	Body	MSS-Special vehicle multifunction control						0		0003
	B-Class	245	Body	MSS-Special vehicle multifunction control					<del>-</del>	0		0003
	B-Class	245	Body	MSS-Special vehicle multifunction control					<del>-</del>	0		0003
	C-Class	203	Body	MSS-Special vehicle multifunction control						0		0003
$F_{rom} = 00/2003 + 0$				MSS-Special vehicle multifunction control								
12/2007	C-Class	203	Body	module	•	•	•	•	•	0	•	0003
	C-Class	203	Body	MSS-Special vehicle multifunction control	•	•	•	•	•	0	•	0003
	CLK	209	Body	MSS-Special vehicle multifunction control	•	•	•	•	•	0	•	0003
	CLK	209	Body	MSS-Special vehicle multifunction control	•	•	•	•	•	0		0003
	E-Class	211	Body	MSS-Special vehicle multifunction control	•	•	•	•	•	0		0003
From $06/2005$ to	E-Class	211	Body	MSS-Special vehicle multifunction control module	•	•	•	•	•	0		0003
	E-Class	211	Body	MSS-Special vehicle multifunction control	•		•	•	•	0	•	0003

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
Up to 03/2004	G-Class	463 (16-pin diagnostic socket)		MSS-Special vehicle multifunction control module	•	•	•	•	•	0	•	0003
From 04/2004 to 08/2006	G-Class	463 (16-pin diagnostic socket)		MSS-Special vehicle multifunction control module	•	•	•	•	•	0	•	0003
From 09/2006 to 02/2007	G-Class	463 (16-pin diagnostic socket)	Body	MSS-Special vehicle multifunction control module	•	•	•	•	•	0	•	0003
As of 03/2007	G-Class	463 (16-pin diagnostic socket)		MSS-Special vehicle multifunction control module	•	•	•	•	•	0	•	0003
Up to 08/2002	S-Class		Body	MSS-Special vehicle multifunction control		•	•	•	•	*	•	0003
As of 09/2002	S-Class		Body	MSS-Special vehicle multifunction control	•	•	•	•	•	*	•	0003
Up to 08/2002	CL		Body	MSS-Special vehicle multifunction control	•	•	•	•	•	*	•	0003
As of 09/2002	CL		Body	MSS-Special vehicle multifunction control	•	•	•	•	•	*	•	0003
Up to 08/2006	MayBach		Body	MSS-Special vehicle multifunction control	•	•	•	•	•	0	•	0003
As of 09/2006	MayBach	240	Body	MSS-Special vehicle multifunction control	•	•	•	•	•	0	•	0003
ALL	B-Class	246	Information and communication	NAV-Navigation module (A2/30)	•	•	0	•	0	•		
ALL	C-Class	204	Information and communication	NAV-Navigation module (A2/30)	•	•	0	•	0	•		
ALL	SLK	172	Information and communication	NAV-Navigation module (A2/30)	•	•	0	•	0	•		
ALL	GLK	X204	Information and communication	NAV-Navigation module (A2/30)	•	•	0	•	0	•		
ALL	M-Class	166	Information and communication	NAV-Navigation module (A2/30)	•	•	0	•	0	•		
ALL	E-Class	212	Information and communication	NAV-Navigation module (A2/30)	•	•	0	•	0	•		
ALL	E-Class	207	Information and communication	NAV-Navigation module (A2/30)	•	•	0	•	0	•		
ALL	CLA	117	Information and communication	NAV-Navigation module (A2/30)	•	•	0	•	0	•		
ALL	A-Class	176	Information and communication	NAV-Navigation module (A2/30)	•	•	0	•	0	•		
ALL	CLS	218	Information and communication	NSA-Night View Assist	•	•	•	•	•	0		
Up to 06/2009	S-Class	221	Information and communication	NSA-Night View Assist	•	•	•	•	•	0		
As of 07/2009	S-Class	221	Information and communication	NSA-Night View Assist	•	•	•	•	•	0		
ALL	CL	216	Information and communication	NSA-Night View Assist	•	•	•	•	•	0		
ALL	M-Class	166	Information and communication	NSA-Night View Assist	•	•	•	•	•	0		
ALL	E-Class	212	Information and communication	NSA-Night View Assist	•	•	•	•	•	0		

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	CLS	218	Information and communication	NSA-Night View Assist(N101)	•	•	0	•	0	•		
ALL	E-Class	212	Information and communication	NSA-Night View Assist(N101)	•	•	0	•	0	•		
ALL	E-Class	207	Information and communication	NSA-Night View Assist(N101)	•	•	0	•	0	•		
ALL	SL	231	Information and communication	NSA-Night View Assist(N101)	•	•	0	•	0	•		
ALL	M-Class	164	Body	UCP-Upper control panel	•	•	•	•	•	0	•	
ALL	GL-Class	X 164	Body	UCP-Upper control panel	•	•	•	•	•	0	•	
ALL	R-Class	251	Body	UCP-Upper control panel	•	•	•	•	•	0	•	
Up to 05/2005	SLK	171	Body	UCP-Upper control panel	•	•	•	•	•	0	•	
As of 06/2005	SLK	171	Body	UCP-Upper control panel	•	•	•	•	•	0	•	
Up to 08/2003	C-Class	203	Body	UCP-Upper control panel	•	•	•	•	•	0	•	
From 09/2003 to 12/2007	C-Class	203	Body	UCP-Upper control panel	•	•	•	•	•	0	•	
As of 01/2008	C-Class	203	Body	UCP-Upper control panel	•	•	•	•	•	0	•	
Up to 03/2004	CLK		Body	UCP-Upper control panel	•	•	•	•	•	0	•	
As of 04/2004	CLK		Body	UCP-Upper control panel	•	•	•	•	•	0	•	
Up to 03/2004	G-Class	463(16-pin diagnostic socket)		UCP-Upper control panel	•	•	•	•	•	0	•	
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)		UCP-Upper control panel	•	•	•	•	•	0	•	
From 09/2006 to 02/2007	G-Class	463 (16-pin diagnostic socket)	Body	UCP-Upper control panel	•	•	•	•	•	0	•	
As of 03/2007	G-Class	463 (16-pin diagnostic socket)		UCP-Upper control panel	•	•	•	•	•	0	•	
Up to 05/2005	E-Class	211	Body	UCP-Upper control panel	•	•	•	•	•	0	•	0005
From 06/2005 to 05/2006	E-Class	211	Body	UCP-Upper control panel	•	•	•	•	•	0	•	0005
As of 06/2006	E-Class	211	Body	UCP-Upper control panel	•	•		•	•	0	•	0005
Up to 05/2005	CLS	219	Body	UCP-Upper control panel	•	•	•	•	•	0	•	0005
From 06/2005 to 05/2006	CLS	219	Body	UCP-Upper control panel	•	•	•	•	•	0	•	0005
As of 06/2006	CLS	219	Body	UCP-Upper control panel	•	•	•	•	•	0	•	0005
Up to 08/2002	S-Class	220	Body	UCP-Upper control panel	•	•	•	•	•	*	•	
Up to 08/2002	CL		Body	UCP-Upper control panel	•	•	•	•	•	*	•	
Up to 08/2002	S-Class	220	Body	UCP-Upper control panel	•	•	•	•	•	0	•	
As of 09/2002	S-Class	220	Body	UCP-Upper control panel	•	•	•	•	•	0	•	
As of 09/2002	CL		Body	UCP-Upper control panel	•	•	•	•	•	0	•	
Up to 06/2009	S-Class		Body	UCP-Upper control panel	•	•	•	•	•	•	•	
As of 07/2009	S-Class		Body	UCP-Upper control panel	•	•	•	•	•	•	•	
ALL	CL		Body	UCP-Upper control panel	•	•	•	•	•	•	•	
ALL	C-Class	204	Body	WSS-Weight sensing system	•	•	•	•	•	•	0	0005

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	CLS	218	Body	WSS-Weight sensing system	•	•	•	•	•	•	0	0005
Up to 06/2009	S-Class	221	Body	WSS-Weight sensing system	•	•	•		•	•	0	0005
As of 07/2009	S-Class	221	Body	WSS-Weight sensing system	•		•	•	•	•	0	0005
ALL	CL	216	Body	WSS-Weight sensing system	•	•			•		0	0005
ALL	GLK	X204	Body	WSS-Weight sensing system	•		•	•	•		0	0005
ALL	E-Class	212	Body	WSS-Weight sensing system	•	•	•	•	•		0	0005
ALL	E-Class	207	Body	WSS-Weight sensing system	•	•	•	•	•	•	0	0005
ALL	SLS	197	Body	WSS-Weight sensing system	•			•	•	•	0	0005
ALL	M-Class	166	LIN Bus	ORBF-Off-road operating panel (N72/3)	•	•	0	•	0	•		0000
ALL	M-Class	166	LIN Bus	OCP-Control unit 'Overhead control panel' (N70)	•	•	0	•	0	•		
ALL	B-Class	246	LIN Bus	OCP-Control unit 'Overhead control panel' (N70)	•	•	0		0	•		
ALL	CLA	117	LIN Bus	OCP-Control unit 'Overhead control panel' (N70)	•		0		0	•		
ALL	A-Class	176	LIN Bus	OCP-Control unit 'Overhead control panel' (N70)	•		0		0	•		
ALL	C-Class	204	Body	SRS-Supplemental restraint system (N2/10)	•		•		<u> </u>		0	
ALL	CLS	218	Body	SRS-Supplemental restraint system (N2/10)	•				_		0	
ALL	SLK	172	Body	SRS-Supplemental restraint system (N2/10)	<del>-</del>				<u> </u>		0	
ALL	GLK	X204	Body	SRS-Supplemental restraint system (N2/10)	<del>-</del>				$\overline{}$		0	
ALL	E-Class	212	Body	SRS-Supplemental restraint system (N2/10)	<del>-</del>						0	
ALL	E-Class	207	Body	SRS-Supplemental restraint system (N2/10)	•				_		0	
ALL	SL	231	Body	SRS-Supplemental restraint system (N2/10)				•	_		0	
ALL	C-Class	204	Body	AB-Airbag	<del>-</del>		-		-			
ALL	GLK	X204	Body	AB-Airbag	<del>-</del>		-		•			
ALL	C-Class	204	Body	SRS-Supplemental restraint system	•				-		0	
		218	Body		•				-			
ALL	CLS GLK	X204	Body	SRS-Supplemental restraint system	-		•		-		0	
ALL				SRS-Supplemental restraint system	-		_					
ALL	E-Class	212 207	Body Body	SRS-Supplemental restraint system		•	•		•	•	0	
ALL	E-Class			SRS-Supplemental restraint system	•		•				0	
ALL	SLS	197	Body	SRS-Supplemental restraint system	•	•	0	•	• •	•	0	
ALL	B-Class	246	Body	SRS-Supplemental restraint system (N2/10)			0	_	0	•		
ALL	M-Class	166	Body	SRS-Supplemental restraint system (N2/10)	•	•	0	•	0	•		
ALL	CLA	117	Body	SRS-Supplemental restraint system (N2/10)	•	•	0	•	0	•		
ALL	A-Class	176	Body	SRS-Supplemental restraint system (N2/10)	•	•	0	•	0	•		
ALL	B-Class	246	Information and communication	PTS-Parktronic	•	•	0	•	0	•		
ALL	CLS	218	Information and communication	PTS-Parktronic	•	•	0	•	0	•		
ALL	E-Class	212	Information and communication	PTS-Parktronic	•	•	0	•	0	•		
ALL	E-Class	207	Information and communication	PTS-Parktronic	•	•	0	•	0	•		
ALL	CLA	117	Information and communication	PTS-Parktronic	•	•	0	•	0	•		
ALL	B-Class	246	Drive	mbrace-mbrace (N123/4)	•	•	0	•	0	•		
ALL	C-Class	204	Drive	mbrace-mbrace (N123/4)	•	•	0	•	0	•		
ALL	CLS	218	Drive	mbrace-mbrace (N123/4)	•	•	0	•	0	•		
ALL	SLK	172	Drive	mbrace-mbrace (N123/4)	•		0		0	•		
ALL	GLK	X204	Drive	mbrace-mbrace (N123/4)	•	•	0		0	•		
ALL	M-Class	166	Drive	mbrace-mbrace (N123/4)	•	•	0		0	•		
NEL	м старр	100	DIIAE	MINTAGE MINTAGE (NILLO/ T/			$\cup$		)			<u>I</u>

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	E-Class	212	Drive	mbrace-mbrace (N123/4)	•	•	0	•	0	•		
ALL	E-Class	207	Drive	mbrace-mbrace (N123/4)	•	•	0	•	0	•		
ALL	CLA	117	Drive	mbrace-mbrace (N123/4)	•	•	0		0	•		
ALL	A-Class	176	Drive	mbrace-mbrace (N123/4)	•	•	0		0	•		
ALL	SL	231	Drive	mbrace-mbrace (N123/4)	•	•	0		0	•		
Up to 05/2005	E-Class	211	Seats and doors	DSP-Pneumatic pump for dynamic seat	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	E-Class	211	Seats and doors	DSP-Pneumatic pump for dynamic seat	•	•	•	•	•	•	•	
As of 06/2006	E-Class	211	Seats and doors	DSP-Pneumatic pump for dynamic seat	•	•	•	•	•	•	•	
Up to 05/2005	CLS	219	Seats and doors	DSP-Pneumatic pump for dynamic seat	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	CLS	219	Seats and doors	DSP-Pneumatic pump for dynamic seat	•	•	•	•	•	•	•	
As of 06/2006	CLS	219	Seats and doors	DSP-Pneumatic pump for dynamic seat	•	•	•	•	•	•	•	
ALL	M-Class	164	Seats and doors	DSP-Pneumatic pump for dynamic seat	•	•	•	•	•	•	•	
ALL	GL-Class	X 164	Seats and doors	DSP-Pneumatic pump for dynamic seat	•	•	•	•	•	•	•	
ALL	R-Class	251		DSP-Pneumatic pump for dynamic seat	•	•	•	•	•	•	•	
Up to 08/2002	S-Class	220	Seats and doors	DSP-Pneumatic pump for dynamic seat	•	•	•	•	•	•	•	
As of 09/2002	S-Class	220	Seats and doors	DSP-Pneumatic pump for dynamic seat	•	•			•	•	•	
ALL	CLS	218	Seats and doors	DSP-Pneumatic pump for dynamic seat	•			•	•	•	•	
Up to 06/2009	S-Class	221	Seats and doors	DSP-Pneumatic pump for dynamic seat	•	•	•	•	•	•	•	
As of 07/2009	S-Class	221	Seats and doors	DSP-Pneumatic pump for dynamic seat	•	•	•	•	•	•	•	
ALL	CL	216	Seats and doors	DSP-Pneumatic pump for dynamic seat	•	•	•	•	•	•	•	
ALL	M-Class	166	Seats and doors	DSP-Pneumatic pump for dynamic seat	•	•	•	•	•	•	•	
ALL	E-Class	212	Seats and doors	DSP-Pneumatic pump for dynamic seat	•	•	•		•	•	•	
ALL	E-Class	207	Seats and doors	DSP-Pneumatic pump for dynamic seat	•	•	•	•	•	•	•	
ALL	SL	231	Seats and doors	DSP-Pneumatic pump for dynamic seat	•	•		•	•	•	•	
As of 03/97 DAS	E-Class	210	Chassis	SPS-Speed-sensitive power steering	•	•	0	•	•	*		
ALL	S-Class	140	Chassis	SPS-Speed-sensitive power steering	•	•	0	•	•	*		
ALL	S-Class	140	Body	PSE-Pneumatic system equipment	•	•	0	•	0	*	0	
As of 06/97	C-Class		Body	PSE-Pneumatic system equipment	•	•	0	•	•	*		
ALL	CLK		Body	PSE-Pneumatic system equipment	•	•	0	•	•	*		
	E-Class		Body	PSE-Pneumatic system equipment	•	•	0	•	•	*		
Up to 08/2002	S-Class		Body	PSE-Pneumatic system equipment	<u> </u>	•	•	•	•	*	•	
As of 09/2002	S-Class		Body	PSE-Pneumatic system equipment	•	•	•	•	•	*	•	
Up to 08/2002	CL		Body	PSE-Pneumatic system equipment	•	•	•	•	•	*	•	
As of 09/2002	CL		Body	PSE-Pneumatic system equipment	•	•	•	•	•	*	•	
Up to 08/2003	SL	230	Body	PSE-Pneumatic system equipment	•		•	•	•	*	•	
From 09/2003 to 05/2006	SL	230	Body	PSE-Pneumatic system equipment	•	•	•	•	•	*	•	
From 06/2006 to 02/2008	SL		Body	PSE-Pneumatic system equipment	•	•	•	•	•	*	•	
As of 03/2008	SL		Body	PSE-Pneumatic system equipment	•	•	•	•	•	*	•	
Up to 08/2006	MayBach		Body	PSE-Pneumatic system equipment	•	•	•	•	•	0	•	
As of 09/2006	MayBach	240	Body	PSE-Pneumatic system equipment	•	•	•	•	•	0	•	
ALL	SLK	170(16-pin diagnostic	Body	PSE-Pneumatic system equipment	•	•	0	•	•	*		
		socket)	-									

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	SLK	170(38-pin diagnostic socket)	Body	PSE-Pneumatic system equipment	•	•	0	•	•	*		
ALL	C-Class	204		HKS-Tailgate control (N121/1)	•	•	•	•	•	•	•	
ALL	CLS	218		HKS-Tailgate control (N121/1)	•	•	•	•	•	•	•	
ALL	GLK	X204		HKS-Tailgate control (N121/1)	•	•	•	•	•	•	•	
ALL	E-Class	207		HKS-Tailgate control (N121/1)	•	•	•	•	•	•	•	
Up to 06/2009	S-Class	221		TLC-Trunk lid control	•	•	•	•	•	•	•	
As of 07/2009	S-Class	221		TLC-Trunk lid control	•	•	•	•	•	•	•	
ALL	CL	216	Seats and doors	TLC-Trunk lid control	•	•	•	•	•	•	•	
ALL	E-Class	212	Seats and doors	TLC-Trunk lid control	•	•	•	•	•		•	
ALL	M-Class	164	Seats and doors	REDC-Rear-end door closing control module	•	•	•	•	•	•	•	
ALL	GL-Class	X 164	Seats and doors	REDC-Rear-end door closing control module	•	•	•		•		•	
ALL	R-Class	251	Seats and doors	REDC-Rear-end door closing control module	•		•		•	•	•	
ALL	M-Class	166	Body	HKS-Tailgate control (N121/1)	•	•	0		0	•		
ALL	C-Class	204	Information and communication	PTS-Parktronic	•	•	•	•	•	•	•	
ALL	GLK	X204	Information and communication	PTS-Parktronic	•	•	•	•	•	•	•	
ALL	C-Class	204	Information and communication	PTS-PARKTRONIC (N62)	•	•	•	•	•	•	•	
As of 07/2009	S-Class	221	Information and communication	PTS-PARKTRONIC (N62)	•	•	•	•	•	•	•	
ALL	CL	216	Information and communication	PTS-PARKTRONIC (N62)	•	•	•	•	•	•	•	
ALL	SLK	172	Information and communication	PTS-PARKTRONIC (N62)	•	•	•	•	•	•	•	
ALL	GLK	X204	Information and communication	PTS-PARKTRONIC (N62)	•	•	•	•	•	•	•	
ALL	E-Class	212	Information and communication	PTS-PARKTRONIC (N62)	•	•	•	•	•	•	•	
ALL	E-Class	207	Information and communication	PTS-PARKTRONIC (N62)	•	•	•	•	•	•	<b>A</b>	
ALL	SLS	197	Information and communication	PTS-PARKTRONIC (N62)	•	•	•	•	•	•	<b>A</b>	
ALL	S-Class	140	Body	PTS-Parktronic system	•	•	0	•	0	*	0	
ALL	A-Class	168	Information and communication	PTS-Parktronic system	•	•	•	•	•	*	•	
As of 06/97	C-Class	202	Information and communication	PTS-Parktronic system	•	•	•	•	•	*	•	
ALL	CLK	208	Information and communication	PTS-Parktronic system	•	•	•	•	•	*	•	
As of 03/97 DAS 3	E-Class	210	Information and communication	PTS-Parktronic system	•	•	•	•	•	*	•	
ALL	M-Class	163	Information and communication	PTS-Parktronic system	•	•	•	•	•	*	•	
ALL	M-Class	164	Information and communication	PTS-Parktronic system	•	•	•	•	•	0		

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	GL-Class	X 164	Information and communication	PTS-Parktronic system	•	•	•	•	•	0		
ALL	R-Class	251	Information and communication	PTS-Parktronic system	•	•	•	•	•	0		
Up to 11/2005	A-Class	169	Information and communication	PTS-Parktronic system	•	•	•	•	•	•		
As of 12/2005	A-Class	169	Information and communication	PTS-Parktronic system	•	•	•	•	•	•		
Up to 11/2005	B-Class	245	Information and communication	PTS-Parktronic system	•	•	•	•	•	•		
As of 12/2005	B-Class	245	Information and communication	PTS-Parktronic system	•	•	•	•	•	•		
Up to 08/2003	C-Class	203	Information and communication	PTS-Parktronic system	•	•	•	•	•	•	•	
From 09/2003 to 12/2007	C-Class	203	Information and communication	PTS-Parktronic system	•	•	•	•	•	•	•	
Up to 03/2004	CLK	209	Information and communication	PTS-Parktronic system	•	•	•	•	•	•	•	
As of 04/2004	CLK	209	Information and communication	PTS-Parktronic system	•	•	•	•	•	•	•	
Up to 05/2005	E-Class	211	Information and	PTS-Parktronic system	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	E-Class	211	Information and communication	PTS-Parktronic system	•	•	•	•	•	•	•	
Up to 05/2005	CLS	219	Information and communication	PTS-Parktronic system	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	CLS	219	Information and communication	PTS-Parktronic system	•	•	•	•	•	•	•	
As of 06/2006	CLS	219	Information and communication	PTS-Parktronic system	•	•	•	•	•	•	•	
Up to 08/2006	MayBach	240	Information and communication	PTS-Parktronic system	•	•	•	•	•	•	•	
As of 09/2006	MayBach	240	Information and communication	PTS-Parktronic system	•	•	•	•	•	•	•	
Up to 05/2005	SLK	171	Information and communication	PTS-Parktronic system	•	•	•	•	•	•	•	
As of 06/2005	SLK	171	Information and communication	PTS-Parktronic system	•	•	•	•	•	•	•	
As of 01/2008	C-Class	203	Information and communication	PTS-Parktronic system	•	•	•	•	•	0	•	
Up to 05/2005	E-Class	211	Information and communication	PTS-Parktronic system	•	•	•	•	•	0	•	
As of 06/2006	E-Class	211	Information and communication	PTS-Parktronic system	•	•	•	•	•	0	•	
As of 06/2006	CLS	219	Information and communication	PTS-Parktronic system	•	•	•	•	•	0	•	
As of 06/2005	SLK	171	Information and communication	PTS-Parktronic system	•	•	•	•	•	0	•	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	M-Class	164	Information and communication	PTS-Parktronic system	•	•	•	•	•	0	•	
ALL	GL-Class	X 164	Information and communication	PTS-Parktronic system	•	•	•	•	•	0	•	
ALL	R-Class	251	Information and communication	PTS-Parktronic system	•	•	•	•	•	0	•	
ALL	CLS	218	Information and communication	PTS-PARKTRONIC (N62)	•	•	0	•	0	•		
ALL	M-Class	166	Information and communication	PTS-PARKTRONIC (N62)	•	•	0	•	0	•		
Up to 08/2002	S-Class	220	Information and communication	PTS-Parktronic system	•	•	•	•	•	*		
As of 09/2002	S-Class	220	Information and communication	PTS-Parktronic system	•	•	•	•	•	*		
Up to 08/2002	CL	215	Information and communication	PTS-Parktronic system	•	•	•	•	•	*		
As of 09/2002	CL	215	Information and communication	PTS-Parktronic system	•	•	•	•	•	*		
Up to 06/2009	S-Class	221	Information and communication	PTS-Parktronic	•	•	•	•	•	•	•	
ALL	CL	216	Information and	PTS-Parktronic	•	•	•	•	•	•	•	
Up to 08/2003	SL	230	Information and	PTS-Parktronic system	•	•	•	•	•	*		
From 09/2003 to 05/2006	SL	230	Information and communication	PTS-Parktronic system	•	•	•	•	•	*		
From 06/2006 to 02/2008	SL	230	Information and communication	PTS-Parktronic system	•	•	•	•	•	*		
As of 03/2008	SL	230	Information and communication	PTS-Parktronic system	•	•	•	•	•	•		
ALL	B-Class	246	Information and communication	PTS-PARKTRONIC (N62)	•	•	0	•	0	•		
ALL	C-Class	204	Information and communication	PTS-PARKTRONIC (N62)	•	•	0	•	0	•		
ALL	GLK	X204	Information and communication	PTS-PARKTRONIC (N62)	•	•	0	•	0	•		
ALL	A-Class	176	Information and	PTS-PARKTRONIC (N62)	•	•	0	•	0	•		
ALL	SL	231	Information and communication	PTS-PARKTRONIC (N62)	•	•	0	•	0	•		
ALL	M-Class	166	Body	Rear-Rear control unit (N10/8)	•	•	0	•	0	•		
ALL	M-Class	164	Chassis	RBS-Brake system	•	•	<b>A</b>	<b>A</b>	<b>A</b>			0014 0047 0250 0251 0252 0253 0254 0141 0255
ALL	C-Class	204	Chassis	ESP-Regenerative braking system (N30/6)	•	•	0	•	0	•		0078 0116 0110 0256 0257
ALL	GLK	X204	Chassis	ESP-Regenerative braking system (N30/6)	•	•	0	•	0	•		0078 0116 0110 0256 0257

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	M-Class	166	Chassis	ESP-Regenerative braking system (N30/6)	•	•	0	•	0	•		0078 0116 0110 0256 0257
ALL	E-Class	212	Chassis	ESP-Regenerative braking system (N30/6)	•	•	0	•	0	•		0078 0116 0110 0256 0257
As of 07/2009	S-Class	221	Chassis	RBS-Brake system	<b>A</b>	<b>A</b>	_	<b>A</b>				
ALL	B-Class	246	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•	•	
ALL	C-Class	204	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•	•	
ALL	CLS	218	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•	•	
ALL	GLK	X204	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•	•	
ALL	E-Class	212	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•	•	
ALL	E-Class	207	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•	•	
ALL	CLA	117	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•	•	
ALL	A-Class	176	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•	•	
ALL	C-Class	204	Body	RevETR-LF-Left front reversible emergency tensioning retractor(A76)	•	•	•	•	•	•		
ALL	GLK	X204	Body	RevETR-LF-Left front reversible emergency tensioning retractor(A76)	•	•	•	•	•	•		
ALL	E-Class	212	Body	RevETR-LF-Left front reversible emergency tensioning retractor(A76)	•	•	•	•	•	•		
ALL	E-Class	207	Body	RevETR-LF-Left front reversible emergency tensioning retractor(A76)	•	•	•	•	•	•		
ALL	M-Class	164	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•			
ALL	GL-Class	X 164	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•			
ALL	R-Class	251	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•			
ALL	M-Class	166	Body	RevETR-LF-Left front reversible emergency tensioning retractor (A76)	•	•	0	•	0	•		
ALL	SLK	172	Body	RevETR-LF-Left front reversible emergency tensioning retractor (A76)	•	•	0	•	0	•		
As of 07/2009	S-Class	221	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•			
ALL	SL	231	Body	RevETR-LF-Left front reversible emergency tensioning retractor (A76)	•	•	0	•	0	•		
ALL	B-Class	246	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•		
ALL	C-Class	204	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•		

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	CLS	218	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•		
ALL	GLK	X204	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•		
ALL	E-Class	212	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•		
ALL	E-Class	207	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•		
ALL	CLA	117	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•		
ALL	A-Class	176	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•		
ALL	C-Class	204	Body	RevETR-RF-Right front reversible emergency tensioning retractor(A76/1)	•	•	•	•	•	•		
ALL	GLK	X204	Body	RevETR-RF-Right front reversible emergency tensioning retractor(A76/1)	•	•	•	•	•	•		
ALL	E-Class	212	Body	RevETR-RF-Right front reversible emergency tensioning retractor(A76/1)	•	•	•	•	•	•		
ALL	E-Class	207	Body	RevETR-RF-Right front reversible emergency tensioning retractor(A76/1)	•	•	•	•	•	•		
ALL	M-Class	164	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•			
ALL	GL-Class	X 164	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•			
ALL	R-Class	251	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•			
ALL	M-Class	166	Body	RevETR-RF-Right front reversible emergency tensioning retractor(A76/1)	•	•	0	•	0	•		
ALL	SLK	172	Body	RevETR-RF-Right front reversible emergency tensioning retractor(A76/1)	•	•	0	•	0	•		
As of 07/2009	S-Class	221	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•			
ALL	SL	231	Body	RevETR-RF-Right front reversible emergency tensioning retractor (A76/1)	•	•	0	•	0	•		
As of 03/97 DAS	E-Class	210	Chassis	TPM - Tire pressure monitor(N88)	•	•	•	•	•	*	•	0005 0009
	E-Class	211	Chassis	TPC-Tire pressure monitor	•	•	•	•	•	•	•	
	CLS	219	Chassis	TPC-Tire pressure monitor	•	•	•	•	•	•	•	
Up to 08/2006	MayBach	240	Chassis	TPC-Tire pressure monitor	•	•	•	•	•	•	•	
As of 09/2006	MayBach	240	Chassis	TPC-Tire pressure monitor	•	•	•	•	•	•	•	
Up to 08/2002	S-Class	220	Chassis	TPM - Tire pressure monitor(N88)	•	•	•	•	•	*	•	0005 0009
As of 09/2002	S-Class	220	Chassis	TPM - Tire pressure monitor(N88)	•	•	•	•	•	*	•	0005 0009
Up to 08/2002	CL	215	Chassis	TPM - Tire pressure monitor(N88)	•	•	•	•	•	*	•	0005 0009
As of 09/2002	CL	215	Chassis	TPM - Tire pressure monitor(N88)	•	•	•	•	•	*	•	0005 0009
Up to 08/2003	SL	230	Chassis	TPM - Tire pressure monitor(N88)	•	•	•	•	•	*	•	0005 0009
From 09/2003 to 05/2006	SL	230	Chassis	TPM - Tire pressure monitor(N88)	•	•	•	•	•	*	•	0005 0009
From 06/2006 to 02/2008	SL	230	Chassis	TPM - Tire pressure monitor(N88)	•	•	•	•	•	*	•	0005 0009

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	SLR	199	Chassis	TPM - Tire pressure monitor(N88)	•	•	•	•	•	*	•	0005 0009
ALL	C-Class	204	Body	SGR-Radar sensors control unit	<b>A</b>	<b>A</b>		<b>A</b>	<b>A</b>			
ALL	CLS	218	Body	SGR-Radar sensors control unit					•	<b>A</b>		
As of 07/2009	S-Class	221	Body	SGR-Radar sensors control unit	<b>A</b>				•			
ALL	SLK	172	Body	SGR-Radar sensors control unit								
ALL	GLK	X204	Body	SGR-Radar sensors control unit	<b>A</b>	<b>A</b>	lack	lack	<b>A</b>	<b>A</b>		
ALL	M-Class	166	Body	SGR-Radar sensors control unit	<b>A</b>							
ALL	E-Class	212	Body	SGR-Radar sensors control unit	<b>A</b>	<b>A</b>	lack	lack	<b>A</b>	<b>A</b>		
ALL	E-Class	207	Body	SGR-Radar sensors control unit	<b>A</b>	<b>A</b>	lack	lack	<b>A</b>	<b>A</b>		
ALL	SL	231	Body	SGR-Radar sensors control unit	lack			$\blacktriangle$				
Up to 06/2009	S-Class	221	Drive	SGR-Radar sensors control unit	•	•	•	•	•	0	•	
ALL	CL	216	Drive	SGR-Radar sensors control unit	•	•	•	•	•	0	•	
Up to 08/2006	MayBach	240	Drive	SGR-Radar sensors control unit	•	•		•	•	•	0	
As of 09/2006	MayBach	240	Drive	SGR-Radar sensors control unit	•	•		•	•	•	0	
Up to 08/2002	S-Class	220	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•	0	
As of 09/2002	S-Class	220	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•	0	
Up to 08/2002	S-Class	220	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•	0	
As of 09/2002	S-Class	220	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•	0	
ALL	M-Class	164	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•	•	
ALL	GL-Class	X 164	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•	•	
ALL	R-Class	251	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•	•	
Up to 05/2005	E-Class	211	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	E-Class	211	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•	•	
As of 06/2006	E-Class	211	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•	•	
Up to 05/2005	CLS	219	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	CLS	219	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•	•	
As of 06/2006	CLS	219	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•	•	
Up to 06/2009	S-Class	221	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•	•	
As of 07/2009	S-Class	221	Body	RevETR-LF-Left front reversible emergency tensioning retractor	•	•	•	•	•	•	•	
ALL	M-Class	164	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•	•	
ALL	GL-Class	X 164	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•	•	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	R-Class	251	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•	•	
Up to 05/2005	E-Class	211	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	E-Class	211	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•	•	
As of 06/2006	E-Class	211	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•	•	
Up to 05/2005	CLS	219	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	CLS	219	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•	•	
As of 06/2006	CLS	219	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•	•	
Up to 06/2009	S-Class	221	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•	•	
As of 07/2009	S-Class	221	Body	RevETR-RF-Right front reversible emergency tensioning retractor	•	•	•	•	•	•	•	
ALL	C-Class	204	Body	OCP-Overhead control panel	•	•		•	•	•		
ALL	GLK	X204	Body	OCP-Overhead control panel	•	•	•	•	•	•	•	
ALL	E-Class	207	Body	OCP-Overhead control panel	•	•	•	•	•	•	•	
ALL	E-Class	212	Body	OCP-Overhead control panel(N70)	•	•	•	•	•	•	<b>A</b>	
ALL	SLK	172	LIN Bus	OCP-Overhead control panel(N70)	•	•	0		0	•		
ALL	SL	231	LIN Bus	OCP-Overhead control panel(N70)	•	•	0	•	0	•		
As of 12/2005	B-Class	245	Drive	BSA-Belt-driven starter/alternator	•			•				
ALL	C-Class	204	Body	RFK-Backup camera (B84/3)	•	•	0	•	0	•		
ALL	CLS	218	Body	RFK-Backup camera (B84/3)	•	•	0	•	0	•		
ALL	GLK	X204	Body	RFK-Backup camera (B84/3)	•	•	0	•	0	•		
ALL	E-Class	212	Body	RFK-Backup camera (B84/3)	•	•	0	•	0	•		
ALL	E-Class	207	Body	RFK-Backup camera (B84/3)	•	•	0	•	0	•		
Up to 05/2005	E-Class	211	Seats and doors	RWT-Rear-end door control module	•	•	•	•	•	0	•	
From 06/2005 to 05/2006	E-Class	211	Seats and doors	RWT-Rear-end door control module	•	•	•	•	•	0	•	
As of 06/2006	E-Class	211	Seats and doors	RWT-Rear-end door control module	•		•	•	•	0	•	
Up to 05/2005	CLS	219		RWT-Rear-end door control module	•	•	•	•	•	0	•	
From 06/2005 to 05/2006	CLS	219	Seats and doors	RWT-Rear-end door control module	•	•	•	•	•	0	•	
As of 06/2006	CLS	219	Seats and doors	RWT-Rear-end door control module	•	•	•	•	•	0	•	
Up to 08/2006	MayBach	240	Body	Rear SAM 1-Rear signal acquisition and actuation module1	•	•	•	•	•	0	•	
As of 09/2006	MayBach	240	Body	Rear SAM 1-Rear signal acquisition and actuation module1	•	•	•	•	•	0	•	
Up to 08/2006	MayBach	240	Body	Rear SAM 2-Rear signal acquisition and actuation module2	•	•	•	•	•	0	•	
As of 09/2006	MayBach	240	Body	Rear SAM 2-Rear signal acquisition and actuation module2	•	•	•	•	•	0	•	
As of 06/97	C-Class	202	Body	SAM-Signal acquisition and actuation module	•	•	0	•	•	*		
ALL	CLK	208	Body	SAM-Signal acquisition and actuation module	•	•	0	•	•	*		

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 03/97 DAS	E-Class	210	Body	SAM-Signal acquisition and actuation module	•	•	0	•	•	*		
Up to 11/2005	A-Class	169	Body	SAM-Signal acquisition and actuation module	•	•	•	•	•	0	*	
As of 12/2005	A-Class	169	Body	SAM-Signal acquisition and actuation module	•	•	•	•	•	0	*	
Up to 11/2005	B-Class	245	Body	SAM-Signal acquisition and actuation module	•	•	•	•	•	0	*	
As of 12/2005	B-Class	245	Body	SAM-Signal acquisition and actuation module	•	•	•	•	•	0	*	
Up to 05/2005	E-Class	211	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	•	•	•	•	•	0	•	
From 06/2005 to 05/2006	E-Class	211	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	•	•	•	•	•	0	•	
As of 06/2006	E-Class	211	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	•	•	•	•	•	0	•	
Up to 05/2005	CLS	219	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	•	•	•	•	•	0	•	
From 06/2005 to 05/2006	CLS	219	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	•	•	•	•	•	0	•	
As of 06/2006	CLS	219	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	•	•	•	•	•	0	•	
Up to 08/2002	S-Class	220	Body	SAM-FR-Front right signal acquisition and actuation module	•	•	•	•	•	*	•	
As of 09/2002	S-Class	220	Body	SAM-FR-Front right signal acquisition and actuation module	•	•	•	•	•	*	•	
Up to 08/2002	CL	215	Body	SAM-FR-Front right signal acquisition and actuation module	•	•	•	•	•	*	•	
As of 09/2002	CL	215	Body	SAM-FR-Front right signal acquisition and actuation module	•	•	•	•	•	*	•	
Up to 08/2003	SL	230	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	•	•	•	•	•	*	•	
From 09/2003 to 05/2006	SL	230	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	•	•	•	•	•	*	•	
From 06/2006 to 02/2008	SL	230	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	•	•	•	•	•	*	•	
As of 03/2008	SL	230	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	•	•	•	•	•	*	•	
ALL	SLR	199	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	•	•	•	•	•	*	•	
Up to 08/2006	MayBach	240	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	•	•	•	•	•	0	•	
As of 09/2006	MayBach	240	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	•	•	•	•	•	0	•	
ALL	C-Class	204	Body	Driver-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	•	•	
ALL	CLS	218	Body	Driver-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	•	•	
ALL	SLK	172	Body	Driver-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	•	<b>A</b>	
ALL	GLK	X204	Body	Driver-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	•	•	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	E-Class	212	Body	Driver-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	•	<b>A</b>	
ALL	E-Class	207	Body	Driver-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	•	<b>A</b>	
ALL	SLS	197	Body	Driver-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	•	<b>A</b>	
ALL	SL	231	Body	Driver-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	•	•	
ALL	C-Class	204	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	•	•	
ALL	CLS	218	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	•	•	
ALL	SLK	172	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	•	•	
ALL	GLK	X204	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	•	•	
ALL	E-Class	212	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	•	•	
ALL	E-Class	207	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	•	•	
ALL	SLS	197	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	•	•	
ALL	SL	231	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	•	•	
ALL	C-Class	204	Body	Driver-side SAM-Driver signal acquisition and actuation module	•	•	•	•	<b>A</b>			
ALL	CLS	218	Body	Driver-side SAM-Driver signal acquisition and actuation module	•	•	•	•	<b>A</b>			
ALL	SLK	172	Body	Driver-side SAM-Driver signal acquisition and actuation module	•	•	•	•	<b>A</b>			
ALL	GLK	X204	Body	Driver-side SAM-Driver signal acquisition and actuation module	•	•	•	•	<b>A</b>			
ALL	E-Class	212	Body	Driver-side SAM-Driver signal acquisition and actuation module	•	•	•	•	<b>A</b>			
ALL	E-Class	207	Body	Driver-side SAM-Driver signal acquisition and actuation module	•	•	•	•	<b>A</b>			
ALL	SLS	197	Body	Driver-side SAM-Driver signal acquisition and actuation module	•	•	•	•	<b>A</b>			
ALL	SL	231	Body	Driver-side SAM-Driver signal acquisition and actuation module	•	•	•	•	<b>A</b>			
Up to 08/2002	S-Class	220	Body	SAM-FL-Front left signal acquisition and actuation module	•	•	•	•	•	*	*	0050
As of 09/2002	S-Class	220	Body	SAM-FL-Front left signal acquisition and actuation module	•	•	•	•	•	*	*	0050
Up to 08/2002	CL	215	Body	SAM-FL-Front left signal acquisition and actuation module	•	•	•	•	•	*	*	0050
As of 09/2002	CL	215	Body	SAM-FL-Front left signal acquisition and actuation module	•	•	•	•	•	*	*	0050

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
Up to 06/2009	S-Class	221	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	•	•	
As of 07/2009	S-Class	221	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	•	•	
ALL	CL	216	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	•	•	
Up to 08/2003	SL	230	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	*	•	
From 09/2003 to 05/2006	SL	230	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	*	•	
From 06/2006 to 02/2008	SL	230	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	*	•	
As of 03/2008	SL	230	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	*	•	
ALL	SLR	199	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	*	•	
Up to 08/2006	MayBach	240	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	0	•	
As of 09/2006	MayBach	240	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	0	•	
ALL	M-Class	164	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	0	*	
ALL	GL-Class	X 164	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	0	*	
ALL	R-Class	251	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	0	*	
Up to 05/2005	SLK	171	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	0	•	
As of 06/2005	SLK	171	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	0	•	
Up to 08/2003	C-Class	203	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	0	•	
From 09/2003 to 12/2007	C-Class	203	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	0	•	
As of 01/2008	C-Class	203	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	0	•	
Up to 03/2004	CLK	209	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	0	•	
As of 04/2004	CLK	209	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	0	•	
Up to 05/2005	E-Class	211	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	0	•	
From 06/2005 to 05/2006	E-Class	211	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	0	•	
As of 06/2006	E-Class	211	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	0	•	
Up to 05/2005	CLS	219	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	0	•	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
From 06/2005 to 05/2006	CLS	219	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	0	•	
As of 06/2006	CLS	219	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	0	•	
Up to 08/2002	S-Class	220	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	*	•	
As of 09/2002	S-Class	220	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	*	•	
Up to 08/2002	CL	215	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	*	•	
As of 09/2002	CL	215	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	*	•	
Up to 06/2009	S-Class	221	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	•	•	
As of 07/2009	S-Class	221	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	•	•	
ALL	CL	216	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	•	•	
Up to 08/2003	SL	230	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	*	•	
From 09/2003 to 05/2006	SL	230	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	*	•	
From 06/2006 to 02/2008	SL	230	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	*	•	
As of 03/2008	SL	230	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	*	•	
ALL	SLR	199	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	*	•	
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	0	•	
From 04/2004 to 08/2006	G-Class	463 (16-pin diagnostic socket)	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	0	•	
From 09/2006 to 02/2007	G-Class	463 (16-pin diagnostic socket)	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	0	•	
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	0	•	
ALL	C-Class	204	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	•	•	
ALL	CLS	218	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	•	•	
ALL	SLK	172	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	•	•	
ALL	GLK	X204	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	•	•	

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	E-Class	212	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	•	•	
ALL	E-Class	207	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	•	•	
ALL	SLS	197	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	•	•	
ALL	SL	231	Body	REAR SAM-Rear signal acquisition and actuation module	•	•	•	•	•	•	•	
ALL	C-Class	204	Body	Rear SAM-Rear signal acquisition and actuation module	•	•	•	•	<b>A</b>	<b>A</b>		
ALL	CLS	218	Body	Rear SAM-Rear signal acquisition and actuation module	•	•	•	•	<b>A</b>	<b>A</b>		
ALL	SLK	172	Body	Rear SAM-Rear signal acquisition and actuation module	•	•	•	•	<b>A</b>	<b>A</b>		
ALL	GLK	X204	Body	Rear SAM-Rear signal acquisition and actuation module	•	•	•	•	<b>A</b>	<b>A</b>		
ALL	E-Class	212	Body	Rear SAM-Rear signal acquisition and actuation module	•	•	•	•	<b>A</b>	<b>A</b>		
ALL	E-Class	207	Body	Rear SAM-Rear signal acquisition and actuation module	•	•	•	•	<b>A</b>	•		
ALL	SLS	197	Body	Rear SAM-Rear signal acquisition and actuation module	•	•	•	•	<b>A</b>	•		
ALL	SL	231	Body	Rear SAM-Rear signal acquisition and actuation module	•	•	•	•	•	<b>A</b>		
ALL	C-Class	204	Body	Rear SAM-Rear signal acquisition and actuation module	•	•	0	•	0	•		
ALL	CLS	218	Body	Rear SAM-Rear signal acquisition and actuation module	•	•	0	•	0	•		
ALL	SLK	172	Body	Rear SAM-Rear signal acquisition and actuation module	•	•	0	•	0	•		
ALL	GLK	X204	Body	Rear SAM-Rear signal acquisition and actuation module	•	•	0	•	0	•		
ALL	E-Class	212	Body	Rear SAM-Rear signal acquisition and actuation module	•	•	0	•	0	•		
ALL	E-Class	207	Body	Rear SAM-Rear signal acquisition and actuation module	•	•	0	•	0	•		
ALL	SLS	197	Body	Rear SAM-Rear signal acquisition and actuation module	•	•	0	•	0	•		
ALL	SL	231	Body	Rear SAM-Rear signal acquisition and actuation module	•	•	0	•	0	•		
ALL	M-Class	164	Body	SAM-F-Signal acquisition and actuation module	•	•	•	•	•	•	*	
ALL	GL-Class	X 164	Body	SAM-F-Signal acquisition and actuation module	•	•	•	•	•	•	*	
ALL	R-Class	251	Body	SAM-F-Signal acquisition and actuation module	•	•	•	•	•	•	*	
	SLK	171	Body	SAM-F-Signal acquisition and actuation module	•	•	•	•	•	0	•	
	SLK	171	Body	SAM-F-Signal acquisition and actuation module	•	•	•	•	•	0	•	
	C-Class	203	Body	SAM-F-Signal acquisition and actuation module	•	•	•	•	•	0	•	
From 09/2003 to 12/2007	C-Class	203	Body	SAM-F-Signal acquisition and actuation module front	•	•	•	•	•	0	•	

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 01/2008	C-Class	203	Body	SAM-F-Signal acquisition and actuation module	•	•	•	•	•	0	•	
Up to 03/2004	CLK	209	Body	SAM-F-Signal acquisition and actuation module	•	•	•	•	•	0	•	
As of 04/2004	CLK	209	Body	SAM-F-Signal acquisition and actuation module	•	•	•	•	•	0	•	
Up to 05/2005	E-Class	211	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	0	•	
From 06/2005 to 05/2006	E-Class	211	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	0	•	
As of 06/2006	E-Class	211	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	0	•	
Up to 05/2005	CLS	219	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	0	•	
From 06/2005 to 05/2006	CLS	219	Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	0	•	
As of 06/2006	CLS		Body	Dr-side SAM-Driver signal acquisition and actuation module	•	•	•	•	•	0	•	
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Body	SAM-F-Signal acquisition and actuation module front	•	•	•	•	•	0	*	
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)		SAM-F-Signal acquisition and actuation module front	•	•	•	•	•	0	*	
From 09/2006 to 02/2007	G-Class	463 (16-pin diagnostic socket)		SAM-F-Signal acquisition and actuation module front	•	•	•	•	•	0	*	
As of 03/2007	G-Class	463 (16-pin diagnostic socket)	Body	SAM-F-Signal acquisition and actuation module front	•	•	•	•	•	0	*	
Up to 05/2005	E-Class	211	Chassis	ESP-Electronic stability program	•		•	•	•		•	0014
From 06/2005 to 05/2006	E-Class	211	Chassis	ESP-Electronic stability program	•	•	•	•	•	•	•	0014
Up to 05/2005	CLS	219	Chassis	ESP-Electronic stability program	•	•	•	•	•	•	•	0014
From 06/2005 to 05/2006	CLS	219	Chassis	ESP-Electronic stability program	•	•	•	•	•	•	•	0014
From 09/2003 to 05/2006	SL	230	Chassis	ESP-Electronic stability program	•	•	•	•	•	•	•	0014
From 06/2006 to 02/2008	SL		Chassis	ESP-Electronic stability program	•	•	•	•	•	•	•	0014
As of 03/2008	SL		Chassis	ESP-Electronic stability program	•	•	•	•	•	•	•	0014
Up to 05/2005	E-Class	211	Chassis	ABR-Adaptive Brake	•	•	•	•	•	•	•	0014 0015
As of 06/2006	E-Class	211	Chassis	ABR-Adaptive Brake	•	•	•	•	•	•	•	0014 0015
As of 06/2006	CLS	219	Chassis	ABR-Adaptive Brake	•	•	•	•	•	•	•	0014 0015
Up to 06/2009	S-Class	221	Chassis	ABR-Adaptive Brake	•	•	•	•	•	•	•	0047, 0015
As of 07/2009	S-Class		Chassis	ABR-Adaptive Brake	•	•	•	•	•	•	•	0047, 0015
ALL	CL	216	Chassis	ABR-Adaptive Brake	•	•	•	•	•	•	•	0047, 0015
Up to 08/2003	C-Class	203	Information and communication	VCS-Voice control system	•	•	0	•		0	0	·
As of 06/97	C-Class	202	Information and communication	VCS-Voice control system	•	•	0	•		0	0	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
Up to 03/2004	CLK	209	Information and communication	VCS-Voice control system	•	•	0	•		0	0	
ALL	CLK	208	Information and communication	VCS-Voice control system	•	•	0	•		0	0	
As of 03/97 DAS 3	E-Class	210	Information and communication	VCS-Voice control system	•	•	0	•		0	0	
Up to 08/2002	S-Class	220	Information and communication	VCS-Voice control system	•	•	0	•		0	0	
As of 09/2002	S-Class	220	Information and communication	VCS-Voice control system	•	•	0	•		0	0	
Up to 08/2002	CL	215	Information and communication	VCS-Voice control system	•	•	0	•		0	0	
As of 09/2002	CL	215	Information and communication	VCS-Voice control system	•	•	0	•		0	0	
Up to 08/2003	SL	230	Information and communication	VCS-Voice control system	•	•	0	•		0	0	
From 09/2003 to 05/2006	SL	230	Information and communication	VCS-Voice control system	•	•	0	•		0	0	
From 06/2006 to 02/2008	SL	230	Information and communication	VCS-Voice control system	•	•	0	•		0	0	
As of 09/99	SL	129	Information and communication	VCS-Voice control system	•	•	0	•		0	0	
ALL	SLK	170(16-pin diagnostic socket)	Information and communication	VCS-Voice control system	•	•	0	•		0	0	
ALL	SLK	170(38-pin diagnostic socket)	Information and communication	VCS-Voice control system	•	•	0	•		0	0	
ALL	M-Class	163	Information and communication	VCS-Voice control system	•	•	0	•		0	0	
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Information and communication	VCS-Voice control system	•	•	0	•		0	0	
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Information and communication	VCS-Voice control system	•	•	0	•		0	0	
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)		VCS-Voice control system	•	•	0	•		0	0	
ALL	G-Class	463(38-pin diagnostic socket)	Information and communication	VCS-Voice control system	•	•	0	•		0	0	
ALL	C-Class	204	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•	•	
ALL	GLK	X204	Information and communication	SCM [MRM]-Steering column module	•	•	•	•	•	•	•	
ALL	SLS	197	Information and	SCM [MRM]-Steering column module	•	•	•	•	•	•	•	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	C-Class	204	Information and communication	SCCM-Steering column module(N80)	•	•	•	•	•	•	<b>A</b>	
ALL	CLS	218	Information and communication	SCCM-Steering column module(N80)	•	•	•	•	•	•	•	
ALL	SLK	172	Information and communication	SCCM-Steering column module(N80)	•	•	•	•	•	•	<b>A</b>	
ALL	GLK	X204	Information and communication	SCCM-Steering column module(N80)	•	•	•	•	•	•	<b>A</b>	
ALL	E-Class	212	Information and communication	SCCM-Steering column module(N80)	•	•	•	•	•	•	<b>A</b>	
ALL	E-Class	207	Information and communication	SCCM-Steering column module(N80)	•	•	•	•	•	•	<b>A</b>	
ALL	SLS	197	Information and communication	SCCM-Steering column module(N80)	•	•	•	•	•	•	<b>A</b>	
ALL	B-Class		Body	SCM-Steering column module(N80)	•	•	0	•	0	•		
ALL	C-Class		Body	SCM-Steering column module(N80)	•	•	0	•	0	•		
ALL	CLS		Body	SCM-Steering column module(N80)	•	•	0	•	0	•		
ALL	SLK		Body	SCM-Steering column module(N80)	•	•	0	•	0	•		
ALL	GLK		Body	SCM-Steering column module(N80)	•	•	0	•	0	•		
ALL	M-Class		Body	SCM-Steering column module(N80)	•	•	0	•	0	•		
ALL	E-Class		Body	SCM-Steering column module(N80)	•	•	0	•	0	•		
ALL	E-Class		Body	SCM-Steering column module(N80)	•	•	0	•	0	•		
ALL	CLA		Body	SCM-Steering column module(N80)	•	•	0	•	0	•		
ALL	A-Class		Body	SCM-Steering column module(N80)	•	•	0	•	0	•		
ALL	SL D. Cl		Body	SCM-Steering column module(N80)	•	•	0	•	0	•	_	
ALL	B-Class		Drive	SCR-Selective Catalytic Reduction	•	•	•	•	•	•	•	
ALL	C-Class		Drive	SCR-Selective Catalytic Reduction	•	•	•	•	•	•	•	
ALL	CLS	218 221	Drive	SCR-Selective Catalytic Reduction	•		•	•	•	•	•	
As of 07/2009	S-Class		Drive	SCR-Selective Catalytic Reduction	•		•		•		•	
ALL	GLK M-Class		Drive Drive	SCR-Selective Catalytic Reduction	•		•		•		•	
ALL ALL				SCR-Selective Catalytic Reduction	•		•	•	•		•	
ALL	M-Class	463(16-pin	Drive	SCR-Selective Catalytic Reduction		_				_		
As of 03/2007	G-Class	diagnostic socket)	Drive	SCR-Selective Catalytic Reduction	•	•	•	•	•	•	•	
ALL	GL-Class		Drive	SCR-Selective Catalytic Reduction	•	•	•	•	•	•	•	
ALL	R-Class		Drive	SCR-Selective Catalytic Reduction	•	•	•	•	•	•	•	
ALL	E-Class		Drive	SCR-Selective Catalytic Reduction	•	•	•	•	•	•	•	
ALL	E-Class		Drive	SCR-Selective Catalytic Reduction	•	•	•	•	•	•	•	
ALL	CLA		Drive	SCR-Selective Catalytic Reduction	•	•	•	•	•	•	•	
ALL	A-Class		Drive	SCR-Selective Catalytic Reduction	•	•	•	•	•	•	•	
ALL	M-Class		Body	SD-Control module 'Sliding roof (A98/1)'	•	•	0	•	0	•		
ALL	M-Class		Body	System diagnosis(CAN)	•	•	0	•	•	•		
ALL	GL-Class		Body	System diagnosis(CAN)	•	•	0	•	•	•		
ALL	R-Class		Body	System diagnosis(CAN)	•	•	0	•	•	•		
Up to 11/2005	A-Class		Body	System diagnosis(CAN)	•	•	•	•	•	•		
As of 12/2005	A-Class		Body	System diagnosis(CAN)	•	•	•	•	•	•		
Up to 11/2005	B-Class	245	Body	System diagnosis(CAN)	•		•	•	•	•		

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 12/2005	B-Class	245	Body	System diagnosis(CAN)	•	•	•	•	•	•		
Up to 08/2003	C-Class	203	Body	System diagnosis(CAN)	•	•	•	•	•	•		
From 09/2003 to 12/2007	C-Class	203	Body	System diagnosis(CAN)	•	•	•	•	•	•		
Up to 05/2005	E-Class	211	Body	System diagnosis(CAN)	•	•		•	•	•		
From 06/2005 to 05/2006	E-Class	211	Body	System diagnosis(CAN)	•	•	•	•	•	•		
As of 06/2006	E-Class	211	Body	System diagnosis(CAN)	•	•	•	•	•	•		
Up to 05/2005	CLS	219	Body	System diagnosis(CAN)	•	•	•	•	•	•		
From 06/2005 to 05/2006	CLS	219	Body	System diagnosis(CAN)	•	•	•	•	•	•		
As of 06/2006	CLS	219	Body	System diagnosis(CAN)	•	•	•	•	•	•		
ALL	SLR	199	Body	System diagnosis (CAN)	•	•	•	•	•	•		
Up to 05/2005	SLK	171	Body	System diagnosis (CAN)	•	•	•	•	•	•		
As of 06/2005	SLK	171	Body	System diagnosis (CAN)	•	•	•	•	•	•		
Up to 06/2009	S-Class	221	Body	System diagnosis(CAN)	•	•	•	•	•	0		
As of 07/2009	S-Class	221	Body	System diagnosis (CAN)	•	•	•	•	•	0		
ALL	CL	216	Body	System diagnosis(CAN)	•	•	•	•	•	0		
From 09/2003 to 05/2006	SL	230	Body	System diagnosis(CAN)	•	•	0	•	*	•		
From 06/2006 to 02/2008	SL	230	Body	System diagnosis(CAN)	•	•	0	•	*	•		
As of 03/2008	SL	230	Body	System diagnosis(CAN)	•	•	0	•	*	•		
Up to 08/2002	S-Class	220	Body	System diagnosis(CAN)	•	•	•	•	•	•		
As of 09/2002	S-Class	220	Body	System diagnosis(CAN)	•	•		•	•	•		
As of 09/2002	CL	215	Body	System diagnosis(CAN)	•	•	•	•	•	•		
Up to 08/2006	MayBach	240	Body	System diagnosis(CAN)	•	•	•	•	•	•		
As of 09/2006	MayBach	240	Body	System diagnosis(CAN)	•	•	•	•	•	•		
ALL	B-Class	246	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•		
ALL	C-Class	204	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•		
ALL	CLS	218	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•		
Up to 06/2009	S-Class	221	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•		
As of 07/2009	S-Class	221	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•		
ALL	CL	216	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•		
ALL	SLK	172	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•		
ALL	GLK	X204	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•		
ALL	M-Class	166	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•		
ALL	E-Class	212	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•		

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	E-Class	207	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•		
ALL	SLS	197	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•		
ALL	CLA	117	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•		
ALL	A-Class	176	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•		
ALL	SL	231	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•		
Up to 08/2003	C-Class	203	Information and communication	SDAR-Satellite radio	•	•	•	•	0	•		
Up to 03/2004	CLK	209	Information and communication	SDAR-Satellite radio	•	•	•	•	0	•		
Up to 08/2002	S-Class	220	Information and communication	SDAR-Satellite radio	•	•	•	•	0	•		
As of 09/2002	S-Class	220	Information and communication	SDAR-Satellite radio	•	•	•	•	0	•		
As of 09/2002	CL	215	Information and communication	SDAR-Satellite radio	•	•	•	•	0	•		
Up to 08/2003	SL	230	Information and communication	SDAR-Satellite radio	•	•	•	•	0	•		
From 09/2003 to 05/2006	SL	230	Information and communication	SDAR-Satellite radio	•	•	•	•	0	•		
From 06/2006 to 02/2008	SL	230	Information and communication	SDAR-Satellite radio	•	•	•	•	0	•		
ALL	M-Class	163	Information and communication	SDAR-Satellite radio	•	•	•	•	0	•		
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Information and communication	SDAR-Satellite radio	•	•	•	•	0	•		
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Information and communication	SDAR-Satellite radio	•	•	•	•	0	•		
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	SDAR-Satellite radio	•	•	•	•	0	•		
As of 12/2005	A-Class	169	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•		
As of 12/2005	B-Class	245	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•		
As of 01/2008	C-Class	203	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•		
Up to 05/2005	E-Class	211	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•		
As of 06/2006	E-Class	211	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•		

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 06/2006	CLS	219	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•		
As of 03/2008	SL	230	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•		
Up to 05/2005	SLK	171	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•		
As of 06/2005	SLK	171	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•		
ALL	M-Class	164	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•		
As of 03/2007	G-Class	463 (16-pin diagnostic socket)	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•		
ALL	GL-Class	X 164	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•		
ALL	R-Class	251	Information and communication	SDAR-Satellite radio(Valid for USA)	•	•	•	•	•	•		
Up to 08/2003	SL	230	Body	System diagnosis(CAN)		•			0	•	0	
From 09/2003 to 05/2006	SL	230	Body	System diagnosis(CAN)	•	•	•	•	0	•	0	
From 06/2006 to 02/2008	SL	230	Body	System diagnosis(CAN)	•	•	•	•	0	•	0	
As of 03/2008	SL	230	Body	System diagnosis(CAN)	•	•	•	•	0	•	0	
Up to 06/2009	S-Class	221	Information and communication	VCS-Voice control	•	•	•	•	•	•	•	
As of 07/2009	S-Class	221	Information and communication	VCS-Voice control	•	•	•	•	•	•	•	
ALL	CL	216	Information and communication	VCS-Voice control	•	•	•	•	•	•	•	
ALL	C-Class	204	Seats and doors	ESA driver	•	•			•	•	•	
ALL	CLS	218	Seats and doors	ESA driver	•	•		•	•	•	•	
ALL	GLK	X204		ESA driver	•	•	•	•	•	•	•	
ALL	E-Class	212		ESA driver	•	•	•	•	•	•	•	
ALL	E-Class	207		ESA driver	•	•	•	•	•	•	•	
ALL	SLS	197		ESA driver	•	•	•	•	•	•	•	
ALL	B-Class	246	Seats and doors	ESA 'Driver'-Electrical seat adjustment 'Driver' with memory function(N32/1)	•	•	0	•	0	•		
ALL	M-Class	166	Seats and doors	ESA 'Driver'-Electrical seat adjustment 'Driver' with memory function(N32/1)	•	•	0	•	0	•		
ALL	CLA	117	Seats and doors	ESA 'Driver'-Electrical seat adjustment 'Driver' with memory function(N32/1)	•	•	0	•	0	•		
ALL	A-Class	176	Seats and doors	ESA 'Driver'-Electrical seat adjustment 'Driver' with memory function(N32/1)	•	•	0	•	0	•		
ALL	SL	231	Seats and doors	ESA 'Driver'-Electrical seat adjustment 'Driver' with memory function(N32/1)	•	•	0	•	0	•		
ALL	C-Class	204	Seats and doors	ESA 'Driver'-Electric seat adjustment 'Driver' (N32/1)	•	•	0	•	0	•		

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	CLS	218	Seats and doors	ESA 'Driver'-Electric seat adjustment 'Driver'(N32/1)	•	•	0	•	0	•		
ALL	SLK	172	Seats and doors	ESA 'Driver'-Electric seat adjustment 'Driver'(N32/1)	•	•	0	•	0	•		
ALL	GLK	X204	Seats and doors	ESA 'Driver'-Electric seat adjustment 'Driver'(N32/1)	•	•	0	•	0	•		
ALL	E-Class	212	Seats and doors	ESA 'Driver'-Electric seat adjustment 'Driver'(N32/1)	•	•	0	•	0	•		
ALL	E-Class	207	Seats and doors	ESA 'Driver'-Electric seat adjustment 'Driver'(N32/1)	•	•	0	•	0	•		
ALL	SLS	197	Seats and doors	ESA 'Driver'-Electric seat adjustment 'Driver'(N32/1)	•	•	0	•	0	•		
ALL	C-Class	204	Seats and doors	ESA passenger	•	•		•	•	•	•	
ALL	CLS	218	Seats and doors	ESA passenger	•	•	•		•	•	•	
ALL	GLK	X204	Seats and doors	ESA passenger	•	•	•	•	•	•	•	
ALL	E-Class	212	Seats and doors	ESA passenger	•	•	•	•	•	•	•	
ALL	E-Class	207	Seats and doors	ESA passenger	•	•	•	•	•	•	•	
ALL	SLS	197	Seats and doors	ESA passenger	•		•		•		•	
ALL	C-Class	204	Seats and doors	ESA-Electirc seat adjustment 'Front passenger' (N32/2)	•	•	•	•	•	•		
ALL	GLK	X204	Seats and doors	ESA-Electirc seat adjustment 'Front passenger' (N32/2)	•	•	•	•	•	•		
ALL	E-Class	212	Seats and doors	ESA-Electirc seat adjustment 'Front passenger' (N32/2)	•	•	•	•	•	•		
ALL	E-Class	207	Seats and doors	ESA-Electirc seat adjustment 'Front passenger' (N32/2)	•	•	•	•	•	•		
ALL	B-Class	246	Seats and doors	ESA'Front passenger'-Electric seat adjustment 'Front passenger' with memory function(N32/2)	•	•	0	•	0	•		
ALL	M-Class	166	Seats and doors	ESA'Front passenger'-Electric seat adjustment 'Front passenger' with memory function(N32/2)	•	•	0	•	0	•		
ALL	CLA	117	Seats and doors	ESA'Front passenger'-Electric seat adjustment 'Front passenger' with memory function(N32/2)	•	•	0	•	0	•		
ALL	A-Class	176	Seats and doors	ESA'Front passenger'-Electric seat adjustment 'Front passenger' with memory function(N32/2)	•	•	0	•	0	•		
ALL	SL	231	Seats and doors	ESA'Front passenger'-Electric seat adjustment' Front passenger' with memory function (N32/2)	•	•	0	•	0	•		
ALL	C-Class	204	Seats and doors	ESA'Front passenger'-Electric seat adjustment'Front passenger' with memory function(N32/2)	•	•	0	•	0	•		
ALL	CLS	218	Seats and doors	ESA' Front passenger'—Electric seat adjustment 'Front passenger' with memory function (N32/2)	•	•	0	•	0	•		
ALL	SLK	172	Seats and doors	ESA' Front passenger' -Electric seat adjustment 'Front passenger' with memory function (N32/2)	•	•	0	•	0	•		
ALL	GLK	X204	Seats and doors	ESA'Front passenger'-Electric seat adjustment' Front passenger' with memory function (N32/2)	•	•	0	•	0	•		
ALL	E-Class	212	Seats and doors	ESA'Front passenger'-Electric seat adjustment' Front passenger' with memory function (N32/2)	•	•	0	•	0	•		
ALL	E-Class	207	Seats and doors	ESA' Front passenger' -Electric seat adjustment' Front passenger' with memory function (N32/2)	•	•	0	•	0	•		

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	SLS	197	Seats and doors	ESA'Front passenger'-Electric seat adjustment 'Front passenger' with memory function(N32/2)	•	•	0	•	0	•		
ALL	M-Class	163	Body	SEM-Security Module	•	•	0	•		*		
Up to 08/2002	S-Class	220	Air conditioning	STH-Stationary heater	•	•	•	•	•	*		
Up to 08/2002	CL	215	Air conditioning	STH-Stationary heater	•	•	•		•	*		
Up to 05/2005	E-Class	211	Seats and doors	HS-Seat heater	•	•	•		•	0	•	
From 06/2005 to 05/2006	E-Class	211	Seats and doors	HS-Seat heater	•	•	•	•	•	0	•	
As of 06/2006	E-Class	211	Seats and doors	HS-Seat heater	•	•	•	•	•	0	•	
Up to 05/2005	CLS	219		HS-Seat heater	•	•	•	•	•	0	•	
From 06/2005 to 05/2006	CLS	219	Seats and doors	HS-Seat heater	•	•	•	•	•	0	•	
As of 06/2006	CLS	219	Seats and doors	HS-Seat heater	•	•	•	•	•	0	•	
	M-Class	164		HS-Seat heater	•	•	•	•	•	0	•	
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Seats and doors	HS-Seat heater	•	•	•	•	•	0	•	
ALL	GL-Class	X 164		HS-Seat heater	•	•	•		•	0	•	
ALL	R-Class	251	Seats and doors	HS-Seat heater	•	•	•		•	0	•	
Up to 05/2005	E-Class	211	Air conditioning	HSW-Heated steering wheel	•	•	•	•	•	0	*	
From 06/2005 to 05/2006	E-Class	211	Air conditioning	HSW-Heated steering wheel	•	•	•	•	•	0	*	
As of 06/2006	E-Class	211	Air conditioning	HSW-Heated steering wheel	•	•	•	•	•	0	*	
Up to 05/2005	CLS	219	Air conditioning	HSW-Heated steering wheel	•	•	•	•	•	0	*	
From 06/2005 to 05/2006	CLS	219	Air conditioning	HSW-Heated steering wheel	•	•	•	•	•	0	*	
As of 06/2006	CLS	219	Air conditioning	HSW-Heated steering wheel	•	•	•		•	0	*	
ALL	M-Class	164	Air conditioning	HSW-Heated steering wheel	•	•	•		•	0	*	
From 04/2004 to 08/2006	G-Class	463 (16-pin diagnostic socket)		HSW-Heated steering wheel	•	•	•	•	•	0	*	
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)		HSW-Heated steering wheel	•	•	•	•	•	0	*	
As of 03/2007	G-Class	463(16-pin diagnostic socket)		HSW-Heated steering wheel	•	•	•	•	•	0	*	
ALL	GL-Class	X 164	Air conditioning	HSW-Heated steering wheel	•	•	•		•	0	*	
ALL	R-Class	251	Air conditioning	HSW-Heated steering wheel	•	•	•	•	•	0	*	
Up to 05/2005	SLK	171	Seats and doors	HS-Seat heater	•	•	•	•	•	0	•	
As of 06/2005	SLK	171	Seats and doors	HS-Seat heater	•	•	•	•	•	0	•	
Up to 05/2005	E-Class	211	Seats and doors	HS-Seat heater	•	•	•	•	0	0	0	
From 06/2005 to 05/2006	E-Class	211	Seats and doors	HS-Seat heater	•	•	•	•	0	0	0	
As of 06/2006	E-Class	211	Seats and doors	HS-Seat heater	•	•	•	•	0	0	0	
Up to 11/2005	A-Class	169		ME-SFI-Gasoline engine control	•	•	•	•	•	•	*	0013 0083 0094 0048 0097 0095 0096 0098 0261

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 12/2005	A-Class	169	Drive	ME-SFI-Gasoline engine control	•	•	•	•	•	•	*	0013 0083 0094 0048 0097 0095 0096 0098 0261
Up to 11/2005	B-Class	245	Drive	ME-SFI-Gasoline engine control	•	•	•	•	•	•	*	0013 0083 0094 0048 0097 0095 0096 0098 0261
As of 12/2005	B-Class	245	Drive	ME-SFI-Gasoline engine control	•	•	•	•	•	•	*	0013 0083 0094 0048 0097 0095 0096 0098 0261
As of 12/2005	B-Class	245	Drive	ME-SFI-CNG compressed natural gas	•	•	•	•	•	•	*	0013
As of 12/2005	B-Class	245	Drive	ME-SFI-Motor electronics	•	•	•	•	•			
ALL	C-Class	204	Drive	ME - Motor electronics 'SIM271DE20' for combustion engine 'M271EV0' (N3/10)	•	•	•	•	•	•	<b>A</b>	
ALL	GLK	X204	Drive	ME - Motor electronics 'SIM271DE20' for combustion engine 'M271EV0' (N3/10)	•	•	•	•	•	•	<b>A</b>	
ALL	E-Class	212	Drive	ME - Motor electronics 'SIM271DE20' for combustion engine 'M271EVO' (N3/10)	•	•	•	•	•	•	<b>A</b>	
ALL	E-Class	207	Drive	ME - Motor electronics 'SIM271DE20' for combustion engine 'M271EVO' (N3/10)	•	•	•	•	•	•	<b>A</b>	0010 0011 0010 0010
ALL	C-Class	204	Drive	ME-SFI-Motor electronics	•	•	•	•	•	•	*	0013 0211 0212 0213 0262 0083 0025 0263 0084 0215 0085 0087 0088 0089 0090 0094 0091 0198 0086 0048 0097
ALL	GLK	X204	Drive	ME-SFI-Motor electronics	•	•	•	•	•	•	*	0013 0211 0212 0213 0262 0083 0025 0263 0084 0215 0085 0087 0088 0089 0090 0094 0091 0198 0086 0048 0097
Up to 08/2003	C-Class	203	Drive	ME-SFI-Motor electronics	•	•	•	•	•	•	•	0013
As of 06/97	C-Class		Drive	ME-SFI-Motor electronics	•	•	•	•	•	•	•	0013
ALL	CLK		Drive	ME-SFI-Motor electronics	•	•	•	•	•	•	•	0013
As of 03/97 DAS	E-Class		Drive	ME-SFI-Motor electronics	•	•	•	•	•	•	•	0013
ALL	SLK	170(16-pin diagnostic socket)		ME-SFI-Motor electronics	•	•	•	•	•	•	•	0013
Up to 05/2005	E-Class	211	Drive	ME-SFI-Motor electronics	•	•	•	•	•	•	•	0004 0013
From 06/2005 to 05/2006	E-Class	211	Drive	ME-SFI-Motor electronics	•	•	•	•	•	•		0004 0013
As of 06/2006	E-Class		Drive	ME-SFI-Motor electronics	•	•	•	•	•	•	•	0004 0013
As of 06/2006	E-Class		Drive	ME-SFI-Motor electronics	•	•	•	•	•	•	•	0013
Up to 08/2003	C-Class	203	Drive	ME-SFI-Motor electronics	•	•	•	•	•	•	•	0013
From 09/2003 to 12/2007	C-Class		Drive	ME-SFI-Motor electronics	•	•	•	•	•	•	•	0013
Up to 03/2004	CLK	209	Drive	ME-SFI-Motor electronics	•	•	•	•	•	•	•	0013
As of 04/2004	CLK	209	Drive	ME-SFI-Motor electronics	•	•	•	•	•	•	•	0013

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
Up to 05/2005	E-Class	211	Drive	ME-SFI-Motor electronics	•	•	•		•	•	•	0013
From 06/2005 to 05/2006	E-Class	211	Drive	ME-SFI-Motor electronics	•	•	•	•	•	•	•	0013
As of 06/2006	E-Class	211	Drive	ME-SFI-Motor electronics	•	•	•		•	•	•	0013
Up to 05/2005	SLK	171	Drive	ME-SFI-Motor electronics	•	•	•		•	•	•	0013
As of 06/2005	SLK	171	Drive	ME-SFI-Motor electronics	•	•	•	•	•	•	•	0013
Up to 08/2003	C-Class	203	Drive	ME-SFI-Motor electronics	•	•	•	•	•	•	•	0013
From 09/2003 to 12/2007	C-Class	203	Drive	ME-SFI-Motor electronics	•	•	•	•	•	•	•	0013
As of 01/2008	C-Class	203	Drive	ME-SFI-Motor electronics	•	•	•	•	•	•	•	0013
Up to 03/2004	CLK	209	Drive	ME-SFI-Motor electronics	•	•	•	•	•	•	•	0013
As of 04/2004	CLK	209	Drive	ME-SFI-Motor electronics	•	•		•	•	•	•	0013
Up to 05/2005	E-Class	211	Drive	ME-SFI-Motor electronics	•	•	•	•	•	•	•	0013
From 06/2005 to 05/2006	E-Class	211	Drive	ME-SFI-Motor electronics	•	•	•	•	•	•	•	0013
As of 06/2006	E-Class	211	Drive	ME-SFI-Motor electronics	•	•	•	•	•	•	•	0013
Up to 05/2005	SLK	171	Drive	ME-SFI-Motor electronics	•	•	•	•	•	•	•	0013
As of 06/2005	SLK		Drive	ME-SFI-Motor electronics	•	•	•	•	•	•	•	0013
ALL	B-Class		LIN Bus	AS-Alarm siren(H3/1)	•	•	0	•	0	•		
ALL	M-Class	166	LIN Bus	AS-Alarm siren(H3/1)	•	•	0	•	0	•		
ALL	CLA		LIN Bus	AS-Alarm siren(H3/1)	•	•	0	•	0	•		
ALL	A-Class		LIN Bus	AS-Alarm siren(H3/1)	•	•	0	•	0	•		
ALL	SLK	170(16-pin diagnostic socket)		CCM-Multifunction control module	•	•	0	•	•	*		
ALL	SLK	170(38-pin diagnostic socket)	Body	CCM-Multifunction control module	•	•	0	•	•	*		
Up to 05/2005	E-Class	211	Chassis	AIRmatic	•	•	•	•	•	0	*	0048, 0049, 0056
From 06/2005 to 05/2006	E-Class	211	Chassis	AIRmatic	•	•	•	•	•	0	*	0048, 0049, 0056
As of 06/2006	E-Class	211	Chassis	AIRmatic	•	•	•	•	•	0	*	0048, 0049, 0056
Up to 05/2005	CLS	219	Chassis	AIRmatic	•	•	•	•	•	0	*	0048, 0049, 0056
From 06/2005 to 05/2006	CLS	219	Chassis	AIRmatic	•	•	•	•	•	0	*	0048, 0049, 0056
As of 06/2006	CLS	219	Chassis	AIRmatic	•	•	•	•	•	0		0048, 0049, 0056
Up to 08/2006	MayBach	240	Chassis	AIRmatic	•	•	•	•	•	0	*	0048, 0049, 0056
As of 09/2006	MayBach		Chassis	AIRmatic	•	•	•	•	•	0	*	0048, 0049, 0056
Up to 08/2003	C-Class	203	Information and	SOUND- Sound system	•	•	0	•	•	•	0	
Up to 03/2004	CLK	209	Information and communication	SOUND- Sound system	•	•	0	•	•	•	0	
Up to 08/2002	S-Class	220	Information and communication	SOUND- Sound system	•	•	0	•	•	•	0	
As of 09/2002	S-Class	220	Information and communication	SOUND- Sound system	•	•	0	•	•	•	0	
Up to 08/2002	CL	215	Information and communication	SOUND- Sound system	•	•	0	•	•	•	0	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 09/2002	CL	215	Information and communication	SOUND- Sound system	•	•	0	•	•	•	0	
Up to 08/2003	SL	230	Information and communication	SOUND- Sound system	•	•	0	•	•	•	0	
From 09/2003 to 05/2006	SL	230	Information and communication	SOUND- Sound system	•	•	0	•	•	•	0	
From 06/2006 to 02/2008	SL	230	Information and communication	SOUND- Sound system	•	•	0	•	•	•	0	
ALL	SLR	199	Information and communication	SOUND- Sound system	•	•	0	•	•	•	0	
ALL	M-Class	163	Information and communication	SOUND- Sound system	•	•	0	•	•	•	0	
ALL	B-Class	246	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•		
ALL	C-Class	204	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•		
ALL	CLS	218	Information and	Sound system (Main amplifier)	•	•	•	•	•	•		
ALL	SLK	172	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•		
ALL	GLK	X204	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•		
ALL	E-Class	212	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•		
ALL	E-Class	207	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•		
ALL	SLS	197	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•		
ALL	CLA	117	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•		
ALL	A-Class	176	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•		
ALL	CLS	218	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•		
As of 07/2009	S-Class	221	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•		
ALL	M-Class	166	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•		
ALL	E-Class	212	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•		
ALL	E-Class	207	Information and	Sound system (Main amplifier)	•	•	•	•	•	•		
ALL	SLS	197	Information and	Sound system (Main amplifier)	•	•	•	•	•	•		
ALL	SL	231	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•		
ALL	CLS	218	Information and communication	Sound system (Bass amplifier)	•	•	•	•	•	•		

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 07/2009	S-Class	221	Information and communication	Sound system (Bass amplifier)	•	•	•	•	•	•		
ALL	M-Class	166	Information and communication	Sound system (Bass amplifier)	•	•	•	•	•	•		
ALL	E-Class	212	Information and communication	Sound system (Bass amplifier)	•	•	•	•	•	•		
ALL	E-Class	207	Information and communication	Sound system (Bass amplifier)	•	•	•	•	•	•		
ALL	SLS	197	Information and communication	Sound system (Bass amplifier)	•	•	•	•	•	•		
ALL	SL	231	Information and communication	Sound system (Bass amplifier)	•	•	•	•	•	•		
As of 12/2005	A-Class	169	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•		
As of 12/2005	B-Class	245	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•		
As of 01/2008	C-Class	203	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•		
Up to 05/2005	E-Class	211	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•		
As of 06/2006	E-Class	211	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•		
As of 06/2006	CLS	219	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•		
As of 03/2008	SL	230	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•		
Up to 05/2005	SLK	171	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•		
As of 06/2005	SLK	171	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•		
ALL	M-Class	164	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•		
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•		
ALL	GL-Class	X 164	Information and communication	Sound system (Main amplifier)	•	•	•	•	•	•		
ALL	R-Class	251	Information and	Sound system (Main amplifier)	•	•	•	•	•	•		
ALL	M-Class	166	Information and communication	SOUND - Sound system(N40/3)	•	•	0	•	0	•		
ALL	CLA	117	Information and communication	SOUND - Sound system(N40/3)	•	•	0	•	0	•		
ALL	A-Class	176	Information and communication	SOUND - Sound system(N40/3)	•	•	0	•	0	•		
ALL	SL	231	Information and communication	SOUND - Sound system(N40/3)	•	•	0	•	0	•		

		Mode1	Control Unit		Ecu	Read	Event	Erase	Live	Freeze	Active	
Model year	Model	Series	Groups	System Name	Info.	Codes	Memory	Codes	Data	Frame	Test	Special Function
		461(16-pin	Information and									
ALL	G-Class	diagnostic	communication	AUDIO	•	•	0	•	0	•		
	0.01	socket)										00.40.00.40.00.
ALL	C-Class	204	Chassis	AIRMATIC-AIRMATIC		<b>A</b>	<b>A</b>	<u> </u>	<u> </u>	<b>A</b>	<u> </u>	0048, 0049, 0051
ALL	GLK	X204	Chassis	AIRMATIC-AIRMATIC		<b>A</b>	<b>A</b>	<u> </u>	<u> </u>	<b>A</b>	<u> </u>	0048, 0049, 0051
ALL	E-Class	212	Chassis	AIRMATIC AIRMATIC		<b>A</b>	<b>A</b>	<b>A</b>		<b>A</b>	<b>A</b>	0048, 0049, 0051
ALL ALL	E-Class	207 166	Chassis	AIRMATIC-AIRMATIC AIRMATIC - AIRMATIC (N51/3)	•		0	•	0	•	<b>A</b>	0048, 0049, 0051
Up to 08/2003	M-Class C-Class	203	Chassis Seats and doors	ESA passenger-Electric seat adjustment	-		•		•	0	•	
From 09/2003 to	C-Class	203	Seats and doors	ESA passenger-Electric seat adjustment ESA passenger-Electric seat adjustment						U		
12/2007	C-Class	203	Seats and doors	passenger brectife seat adjustment	•	•	•	•	•	0	•	
As of 01/2008	C-Class	203	Seats and doors	ESA passenger-Electric seat adjustment	•	•	•	•	•	0	•	
Up to 03/2004	CLK	209	Seats and doors	ESA passenger-Electric seat adjustment	•	•	•	•	•	0	•	
As of 04/2004	CLK	209		ESA passenger-Electric seat adjustment	•	•	•	•	•	0	•	
Up to 05/2005	E-Class	211	Seats and doors	ESA passenger-Electric seat adjustment	•	•	•	•	•	0	•	
From 06/2005 to 05/2006	E-Class	211	Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•	•	•	•	0	•	
As of 06/2006	E-Class	211	Seats and doors	ESA passenger-Electric seat adjustment	•	•	•	•	•	0	•	
Up to 05/2005	CLS	219	Seats and doors	ESA passenger-Electric seat adjustment	•	•	•	•	•	0	•	
From 06/2005 to 05/2006	CLS	219	Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•	•	•	•	0	•	
As of 06/2006	CLS	219	Seats and doors	ESA passenger-Electric seat adjustment	•	•	•	•	•	0	•	
Up to 05/2005	SLK	171		ESA passenger-Electric seat adjustment	•	•	•	•	•	0	•	
As of 06/2005	SLK	171		ESA passenger-Electric seat adjustment	•	•	•	•	•	0	•	
Up to 03/2004	G-Class	463(16-pin diagnostic	Seats and doors	ESA passenger-Electric seat adjustment	•	•	•	•	•	0	•	
		socket) 463(16-pin		passenger								
From 04/2004 to 08/2006	G-Class	I	Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•	•	•	•	0	•	
From 09/2006 to 02/2007	G-Class	463 (16-pin diagnostic socket)	Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•	•	•	•	0	•	
		463 (16-pin										
As of 03/2007	G-Class		Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•	•	•	•	0	•	
ALL	M-Class	164	Seats and doors	ESA passenger-Electric seat adjustment	•	•	•	•	•	•	•	
ALL	GL-Class	X 164	Seats and doors	ESA passenger-Electric seat adjustment	•	•	•	•	•	•	•	
ALL	R-Class	251		ESA passenger-Electric seat adjustment	•	•	•	•	•	•	•	
Up to 08/2003	C-Class	203		ESA passenger-Electric seat adjustment	•	•	•	•	•	0	•	
From 09/2003 to 12/2007	C-Class	203	Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•	•	•	•	0	•	
Up to 03/2004	G-Class	463 (16-pin diagnostic socket)	Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•	•	•	•	0	•	
From 04/2004 to 08/2006	G-Class	463(16-pin	Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•	•	•	•	0	•	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
From 09/2006 to 02/2007	G-Class	socket)	Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•	•	•	•	0	•	
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•	•	•	•	0	•	
Up to 08/2003	C-Class	203	Seats and doors	ESA passenger-Electric seat adjustment	•	•	•	•	•	0	•	
From 09/2003 to 12/2007	C-Class	203	Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•	•	•	•	0	•	
Up to 03/2004	CLK	209	Seats and doors	ESA passenger-Electric seat adjustment	•	•	•	•	•	0	•	
As of 04/2004	CLK	209	Seats and doors	ESA passenger-Electric seat adjustment	•	•	•	•	•	0	•	
Up to 05/2005	E-Class	211	Seats and doors	ESA passenger-Electric seat adjustment	•	•	•	•	•	0	•	
From 06/2005 to 05/2006	E-Class	211	Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•	•	•	•	0	•	
As of 06/2006	E-Class	211	Seats and doors	ESA passenger-Electric seat adjustment	•	•	•	•	•	0	•	
Up to 03/2004	G-Class	463 (16-pin diagnostic socket)	Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•	•	•	•	0	•	
From 04/2004 to 08/2006	G-Class	463 (16-pin diagnostic socket)	Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•	•	•	•	0	•	
From 09/2006 to 02/2007	G-Class	463 (16-pin diagnostic socket)	Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•	•	•	•	0	•	
As of 03/2007	G-Class	463 (16-pin diagnostic socket)	Seats and doors	ESA passenger-Electric seat adjustment passenger	•	•	•	•	•	0	•	
Up to 08/2003	C-Class	203	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	•	•	•	•	•	0	•	
From 09/2003 to 12/2007	C-Class	203	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	•	•	•	•	•	0	•	
As of 01/2008	C-Class	203	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	•	•	•	•	•	0	•	
Up to 03/2004	CLK	209	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	•	•	•	•	•	0	•	
As of 04/2004	CLK	209	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	•	•	•	•	•	0	•	
Up to 05/2005	E-Class	211	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	•	•	•	•	•	0	•	
From 06/2005 to 05/2006	E-Class	211	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	•	•	•	•	•	0	•	
As of 06/2006	E-Class	211	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	•	•	•	•	•	0	•	
Up to 05/2005	CLS	219	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	•	•	•	•	•	0	•	
From 06/2005 to 05/2006	CLS	219	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	•	•	•	•	•	0	•	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 06/2006	CLS	219	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	•	•	•	•	•	0	•	
Up to 05/2005	SLK	171	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	•	•	•	•	•	0	•	
As of 06/2005	SLK	171	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	•	•	•	•	•	0	•	
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	•	•	•	•	•	0	•	
From 04/2004 to 08/2006	G-Class	463 (16-pin diagnostic socket)	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	•	•	•	•	•	0	•	
From 09/2006 to 02/2007	G-Class	463 (16-pin diagnostic socket)	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	•	•	•	•	•	0	•	
As of 03/2007	G-Class	463 (16-pin diagnostic socket)	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	•	•	•	•	•	0	•	
ALL	M-Class	164	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	•	•	•	•	•	•	•	
ALL	GL-Class	X 164	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	•	•	•	•	•	•	•	
ALL	R-Class	251	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	•	•	•	•	•	•	•	
Up to 08/2003	C-Class	203	Seats and doors	ESA driver-Electric seat adjustment driver	•	•	•	•	•	0	•	
From 09/2003 to 12/2007	C-Class	203	Seats and doors	ESA driver-Electric seat adjustment driver	•	•	•	•	•	0	•	
Up to 03/2004	G-Class	463(16-pin diagnostic socket)		ESA driver-Electric seat adjustment driver	•	•	•	•	•	0	•	
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Seats and doors	ESA driver-Electric seat adjustment driver	•	•	•	•	•	0	•	
From 09/2006 to 02/2007	G-Class	socket)	Seats and doors	ESA driver-Electric seat adjustment driver	•	•	•	•	•	0	•	
As of 03/2007	G-Class	463 (16-pin diagnostic socket)		ESA driver-Electric seat adjustment driver	•	•	•	•	•	0	•	
Up to 08/2003	C-Class	203	Seats and doors	ESA driver-Electric seat adjustment driver	•	•	•	•		0	•	
From 09/2003 to 12/2007	C-Class	203	Seats and doors	ESA driver-Electric seat adjustment driver	•	•	•	•	•	0	•	
Up to 03/2004	CLK	209	Seats and doors	ESA driver-Electric seat adjustment driver	•	•	•	•	•	0	•	
As of 04/2004	CLK	209	Seats and doors	ESA driver-Electric seat adjustment driver	•	•	•	•	•	0	•	
Up to 05/2005	E-Class	211	Seats and doors	ESA driver-Electric seat adjustment driver	•	•	•	•	•	0	•	
From 06/2005 to 05/2006	E-Class	211	Seats and doors	ESA driver-Electric seat adjustment driver	•	•	•	•	•	0	•	
	E-Class	211	Seats and doors	ESA driver-Electric seat adjustment driver	•	•	•	•	•	0	•	

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Seats and doors	ESA driver-Electric seat adjustment driver	•	•	•	•	•	0	•	
From 04/2004 to 08/2006	G-Class	socket)		ESA driver-Electric seat adjustment driver	•	•	•	•	•	0	•	
From 09/2006 to 02/2007	G-Class	socket)	Seats and doors	ESA driver-Electric seat adjustment driver	•	•	•	•	•	0	•	
As of 03/2007	G-Class	463 (16-pin diagnostic socket)		ESA driver-Electric seat adjustment driver	•	•	•	•	•	0	•	
ALL	GL-Class	X 164	Seats and doors	ERA-Electric fold-down backrest system (3rd seat row)	•	•	•	•	•	•	*	
Up to 08/2002	S-Class	220	Seats and doors	ESA-R-Electric seat adjustment rear	•	•	•	•	•	*	•	
As of 09/2002	S-Class	220	Seats and doors	ESA-R-Electric seat adjustment rear	•	•	•	•	•	*	•	
Up to 06/2009	S-Class	221	Seats and doors	ESA-R-Electric seat adjustment rear	•	•	•	•	•	•	•	
As of 07/2009	S-Class	221	Seats and doors	ESA-R-Electric seat adjustment rear	•	•	•		•	•	•	
Up to 08/2006	MayBach	240	Seats and doors	ESA-LR-Left rear electrical seat adjustment	•				•	0	•	
As of 09/2006	MayBach	240	Seats and doors	ESA-LR-Left rear electrical seat adjustment	•			•	•	0	•	
Up to 08/2006	MayBach	240	Seats and doors	ESA-RR-Right rear electrical seat adjustment	•	•	0	•	•	•	•	
As of 09/2006	MayBach	240	Seats and doors	ESA-RR-Right rear electrical seat adjustment	•	•	0	•	•	•	•	
Up to 08/2002	CL	215	Seats and doors	ESA-FL-Electric seat adjustment front left	•	•	•	•	•	*	•	
As of 09/2002	CL	215	Seats and doors	ESA-FL-Electric seat adjustment front left	•	•	•	•	•	*	•	
Up to 08/2002	S-Class	220	Seats and doors	ESA-FL-Electric seat adjustment front left	•			•	•	*	•	
As of 09/2002	S-Class	220	Seats and doors	ESA-FL-Electric seat adjustment front left	•				•	*	•	
Up to 06/2009	S-Class	221	Seats and doors	ESA-FL-Electric seat adjustment front left	•			•	•	•	•	
As of 07/2009	S-Class	221	Seats and doors	ESA-FL-Electric seat adjustment front left	•			•	•	•	•	
ALL	CL	216	Seats and doors	ESA-FL-Electric seat adjustment front left	•	•	•	•	•	•	•	
Up to 08/2003	SL	230	Seats and doors	ESA-FL-Electric seat adjustment front left	•	•	•	•	•	*	•	
From 09/2003 to 05/2006	SL	230	Seats and doors	ESA-FL-Electric seat adjustment front left	•	•	•	•	•	*	•	
From 06/2006 to 02/2008	SL	230		ESA-FL-Electric seat adjustment front left	•	•	•	•	•	*	•	
As of 03/2008	SL	230	Seats and doors	ESA-FL-Electric seat adjustment front left	•	•	•	•	•	*	•	
Up to 08/2006	MayBach	240		ESA-FL-Electric seat adjustment front left	•	•	•	•	•	0	•	
,				ESA-FL-Electric seat adjustment front left	•	•	•	•	•	0	•	
Up to 08/2002	CL	215		ESA-FR-Electric seat adjustment front right	•	•	•	•	•	*	•	
As of 09/2002	CL	215		ESA-FR-Electric seat adjustment front right	•	•	•	•	•	*	•	
	S-Class	220		ESA-FR-Electric seat adjustment front right	•	•	•	•	•	*	•	
As of 09/2002	S-Class	220		ESA-FR-Electric seat adjustment front right	•	•	•	•	•	*	•	
Up to 06/2009	S-Class	221		ESA-FR-Electric seat adjustment front right	•	•	•	•	•	•	•	
As of 07/2009	S-Class	221		ESA-FR-Electric seat adjustment front right	•	•	•	•	•	•	•	
ALL	CL	216		ESA-FR-Electric seat adjustment front right	•	•	•	•	•	•	•	
Up to 08/2003	SL	230	Seats and doors	ESA-FR-Electric seat adjustment front right	•	•	•	•	•	*	•	
From 09/2003 to 05/2006	SL	230	Seats and doors	ESA-FR-Electric seat adjustment front right	•	•	•	•	•	*	•	

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
From 06/2006 to 02/2008	SL	230		ESA-FR-Electric seat adjustment front right	•	•	•	•	•	*	•	
As of 03/2008	SL	230		ESA-FR-Electric seat adjustment front right	•	•	•	•	•	*	•	
Up to 08/2006	MayBach	240	Seats and doors	ESA-FR-Electric seat adjustment front right	•	•	•	•	•	0	*	
As of 09/2006	MayBach	240	Seats and doors	ESA-FR-Electric seat adjustment front right	•	•	•	•	•	0	*	
ALL	A-Class	168	Air conditioning	STH-Stationary heater	•	•	0	•	•	*		
As of 06/97	C-Class	202	Air conditioning	STH-Stationary heater	•	•	0	•	•	*		
ALL	CLK	208		STH-Stationary heater	•	•	0	•	•	*		
As of 03/97 DAS	E-Class	210	Air conditioning	STH-Stationary heater	•	•	0	•	•	*		
As of 09/99	SL		Air conditioning	STH-Stationary heater	•	•	0	•	•	*		
ALL	SLK	170 (16-pin diagnostic socket)	Air conditioning	STH-Stationary heater	•	•	0	•	•	*		
ALL	M-Class		Air conditioning	STH-Stationary heater	•	•	0	•	•	*		
ALL	G-Class	463(38-pin diagnostic socket)	Air conditioning	STH-Stationary heater	•	•	0	•	•	*		
ALL	G-Class	socket)	Air conditioning	STH-Stationary heater	•	•	0	•	•	*		
ALL	M-Class			STH-Stationary heater with remote control	•	•	•	•	•	•	*	
ALL	GL-Class			STH-Stationary heater with remote control	•	•	•	•	•	•	*	
ALL	R-Class	251	Air conditioning	STH-Stationary heater with remote control	•	•	•	•	•	•	*	
Up to 08/2003	C-Class	203		STH-Stationary heater	•	•	•	•	•	•		
Up to 03/2004	CLK			STH-Stationary heater	•	•	•	•	•	•		
Up to 03/2004	G-Class	socket)		STH-Stationary heater	•	•	•	•	•	•		
From 04/2004 to 08/2006	G-Class	socket)		STH-Stationary heater	•	•	•	•	•	•		
From 09/2006 to 02/2007	G-Class	socket)		STH-Stationary heater	•	•	•	•	•	•		
As of 03/2007		socket)		STH-Stationary heater	•	•	•	•	•	•		
Up to 08/2003	C-Class	203	Air conditioning	STH-Stationary heater	•	•	•	•	•	•	•	
From 09/2003 to 12/2007	C-Class			STH-Stationary heater	•	•	•	•	•	•	•	
As of 01/2008	C-Class			STH-Stationary heater	•	•	•	•	•	•	•	
As of 04/2004	CLK			STH-Stationary heater	•	•	•	•	•	•	•	
Up to 05/2005	E-Class	211	Air conditioning	STH-Stationary heater	•	•	•	•	•	•	•	
03/2000		211	Air conditioning	STH-Stationary heater	•	•	•	•	•	•	•	
As of 06/2006	E-Class	211	Air conditioning	STH-Stationary heater	•	•	•	•	•	•	•	
Up to 05/2005	CLS	219	Air conditioning	STH-Stationary heater	•	•	•	•	•			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
From 06/2005 to 05/2006	CLS	219	Air conditioning	STH-Stationary heater	•	•	•	•	•	•	•	
As of 06/2006	CLS	219	Air conditioning	STH-Stationary heater	•	•	•	•	•	•	•	
Up to 08/2006	MayBach	240	Air conditioning	STH-Stationary heater	•		•	•	•	•	•	
As of 09/2006	MayBach	240	Air conditioning	STH-Stationary heater	•		•	•	•	•	•	
ALL	C-Class	204	Air conditioning	Stationary heater	•				•	•		
ALL	CLS	218	Air conditioning	Stationary heater	•				•			
ALL	GLK	X204	Air conditioning	Stationary heater	•				•	•		
ALL	E-Class	212	Air conditioning	Stationary heater	•	•			•	•		
ALL	E-Class	207		Stationary heater	•	•	•	•	•	•		
Up to 08/2002	S-Class	220	Air conditioning	STH-Stationary heater	•	•	•	•	•	•		
As of 09/2002	S-Class	220	Air conditioning	STH-Stationary heater	•	•	•	•	•	•		
As of 09/2002	CL	215	Air conditioning	STH-Stationary heater	•	•	•	•	•	•		
Up to 06/2009	S-Class	221	Air conditioning	STH-Stationary heater with remote control	•	•	•	•	•	•	•	
As of 07/2009	S-Class	221		STH-Stationary heater with remote control	•	•	•	•	•	•	•	
ALL	CL	216	Air conditioning	STH-Stationary heater with remote control	•	•	•	•	•	•	•	
Up to 08/2002	S-Class	220	Air conditioning	STH-Stationary heater	•	•		•	•	*		
Up to 08/2002	CL	215	Air conditioning	STH-Stationary heater	•	•	•	•	•	*		
Up to 08/2003	SL	230	Air conditioning	STH-Stationary heater	•	•	•	•	•	*		
From 09/2003 to 05/2006	SL	230	Air conditioning	STH-Stationary heater	•	•	•	•	•	*		
From 06/2006 to 02/2008	SL	230	Air conditioning	STH-Stationary heater	•	•	•	•	•	*		
As of 03/2008	SL	230	Air conditioning	STH-Stationary heater	•	•	•	•	•	*		
ALL	CLS	218	Information and communication	360° camera-360° camera(N148)	•	•	0	•	0	•		
ALL	M-Class	166	Information and communication	360° camera-360° camera(N148)	•	•	0	•	0	•		
ALL	E-Class	212	Information and communication	360° camera-360° camera(N148)	•	•	0	•	0	•		
ALL	E-Class	207	Information and communication	360° camera-360° camera(N148)	•	•	0	•	0	•		
ALL	C-Class	204	Information and communication	360° camera-360° camera(N148)	•	•	0	•	0	•		
ALL	GLK	X204	Information and communication	360° camera-360° camera(N148)	•	•	0	•	0	•		
ALL	E-Class	207	Information and communication	360° camera-360° camera(N148)	•	•	0	•	0	•		
Up to 08/2003	C-Class	203	Information and communication	E-call [Japan]-Telematic system	•	•	•	•	•	•		
Up to 03/2004	CLK	209	Information and communication	E-call [Japan]-Telematic system	•	•	•	•	•	•		
Up to 08/2002	S-Class	220	Information and communication	E-call [Japan]-Telematic system	•	•	•	•	•	•		
As of 09/2002	S-Class	220	Information and communication	E-call [Japan]-Telematic system	•	•	•	•	•	•		
Up to 08/2002	CL	215	Information and communication	E-call [Japan]-Telematic system	•	•	•	•	•	•		

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 09/2002	CL	215	Information and communication	E-call [Japan]-Telematic system	•	•	•	•	•	•		
Up to 08/2003	SL	230	Information and communication	E-call [Japan]-Telematic system	•	•	•	•	•	•		
From 09/2003 to 05/2006	SL	230	Information and communication	E-call [Japan]-Telematic system	•	•	•	•	•	•		
From 06/2006 to 02/2008	SL	230	Information and communication	E-call [Japan]-Telematic system	•	•	•	•	•	•		
As of 03/2008	SL	230	Information and communication	E-call [Japan]-Telematic system	•	•	•	•	•	•		
ALL	SLR	199	Information and communication	E-call [Japan]-Telematic system	•	•	•	•	•	•		
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Information and communication	E-call [Japan]-Telematic system	•	•	•	•	•	•		
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Information and communication	E-call [Japan]-Telematic system	•	•	•	•	•	•		
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	E-call [Japan]-Telematic system	•	•	•	•	•	•		
Up to 08/2003	C-Class	203	Information and communication	E-call [USA]-Telematic system	•	•	•	•	•	•	0	
Up to 03/2004	CLK	209	Information and communication	E-call [USA]-Telematic system	•	•	•	•	•	•	0	
ALL	CLK	208	Information and communication	E-call [USA]-Telematic system	•	•	•	•	•	•	0	
As of 03/97 DAS 3	E-Class	210	Information and communication	E-call [USA]-Telematic system	•	•	•	•	•	•	0	
Up to 08/2002	S-Class	220	Information and communication	E-call [USA]-Telematic system	•	•	•	•	•	•	0	
As of 09/2002	S-Class	220	Information and communication	E-call [USA]-Telematic system	•	•	•	•	•	•	0	
Up to 08/2002	CL	215	Information and communication	E-call [USA]-Telematic system	•	•	•	•	•	•	0	
As of 09/2002	CL	215	communication	E-call [USA]-Telematic system	•	•	•	•	•	•	0	
Up to 08/2003	SL	230	communication	E-call [USA]-Telematic system	•	•	•	•	•	•	0	
From 09/2003 to 05/2006	SL	230	communication	E-call [USA]-Telematic system	•	•	•	•	•	•	0	
From 06/2006 to 02/2008	SL	230	communication	E-call [USA]-Telematic system	•	•	•	•	•	•	0	
As of 03/2008	SL	230	communication	E-call [USA]-Telematic system	•	•	•	•	•	•	0	
As of 09/99	SL	129	Information and communication	E-call [USA]-Telematic system	•	•	•	•	•	•	0	

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	SLR	199	Information and communication	E-call [USA]-Telematic system	•	•	•	•	•	•	0	
ALL	SLK	170(16-pin diagnostic socket)	Information and communication	E-call [USA]-Telematic system	•	•	•	•	•	•	0	
ALL	M-Class	163	Information and communication	E-call [USA]-Telematic system	•	•	•	•	•	•	0	
Up to 03/2004	G-Class	463 (16-pin diagnostic socket)	Information and communication	E-call [USA]-Telematic system	•	•	•	•	•	•	0	
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Information and communication	E-call [USA]-Telematic system	•	•	•	•	•	•	0	
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	E-call [USA]-Telematic system	•	•	•	•	•	•	0	
As of 06/97	C-Class	202		TAC-Automatic temperature control	•	•	0	•		*	•	
ALL	CLK	208		TAC-Automatic temperature control	•	•	0	•		*	•	
As of 03/97 DAS	E-Class	210	Air conditioning	TAC-Automatic temperature control	•	•	0	•		*	•	
ALL	SLK	170(16-pin diagnostic socket)	Air conditioning	TAC-Automatic temperature control	•	•	0	•		*	•	
ALL	SLK	170(38-pin diagnostic socket)	Air conditioning	TAC-Automatic temperature control	•	•	0	•		*	•	
ALL	M-Class	166	Drive	N15/7(Transfer case control module)	•	•	0	•	0	•		
ALL	M-Class	164	Drive	ETC-Electronic transmission control	•	•	•		•			
ALL	A-Class	168	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	0	0	0	
Up to 08/2003	C-Class	203	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	0	0	0	
As of 06/97	C-Class	202	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	0	0	0	
Up to 03/2004	CLK	209	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	0	0	0	
ALL	CLK	208	communication	CTEL- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	0	0	0	
As of 03/97 DAS 3	E-Class	210		CTEL- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	0	0	0	
Up to 08/2002	S-Class	220	communication	CTEL- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	0	0	0	
As of 09/2002	S-Class	220	communication	CTEL- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	0	0	0	
Up to 08/2002	CL	215	communication	CTEL- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	0	0	0	
As of 09/2002	CL	215		CTEL- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	0	0	0	

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
Up to 08/2003	SL	230	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	•	•	•	•	0	0	0	
From 09/2003 to 05/2006	SL	230	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	•	•	•	•	0	0	0	
From 06/2006 to 02/2008	SL	230		CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	•	•	•	•	0	0	0	
As of 09/99	SL	129		CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	•	•	•	•	0	0	0	
ALL	SLR	199		CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	•	•	•	•	0	0	0	
ALL	SLK	170(16-pin diagnostic socket)		CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	•	•	•	•	0	0	0	
ALL	SLK	170(38-pin diagnostic socket)	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	•	•	•	•	0	0	0	
ALL	M-Class	163	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	•	•	•	•	0	0	0	
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	•	•	•	•	0	0	0	
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	•	•	•	•	0	0	0	
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	•	•	•	•	0	0	0	
ALL	G-Class	463 (38-pin diagnostic socket)	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	•	•	•	•	0	0	0	
As of 06/97	C-Class	202	Information and communication	DN-Dynamic navigation by means of CTEL	•	•	•	•	•	0	0	
ALL	CLK	208	Information and communication	DN-Dynamic navigation by means of CTEL	•	•	•	•	•	0	0	
As of 03/97 DAS 3	E-Class	210	Information and communication	DN-Dynamic navigation by means of CTEL	•	•	•	•	•	0	0	
Up to 08/2002	S-Class	220	Information and communication	DN-Dynamic navigation by means of CTEL	•	•	•	•	•	0	0	
Up to 08/2002	CL	215	Information and communication	DN-Dynamic navigation by means of CTEL	•	•	•	•	•	0	0	
As of 09/99	SL	129	Information and communication	DN-Dynamic navigation by means of CTEL	•	•	•	•	•	0	0	
ALL	C-Class	204	Information and communication	CTEL-Cellular telephone(JAPAN)	•	•	•	•	•	•		
ALL	CLS	218	Information and communication	CTEL-Cellular telephone(JAPAN)	•	•	•	•	•	•		
ALL	GLK	X204	Information and communication	CTEL-Cellular telephone(JAPAN)	•	•	•	•	•	•		

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	E-Class	212	Information and communication	CTEL-Cellular telephone(JAPAN)	•	•	•	•	•	•		
ALL	E-Class	207	Information and communication	CTEL-Cellular telephone(JAPAN)	•	•	•	•	•	•		
ALL	C-Class	204	Body	Trailer recognition module	•	•	•	•	•	•		
ALL	CLS	+	Body	Trailer recognition module	•	•	•	•	•	•		
As of 07/2009	S-Class		Body	Trailer recognition module	•	•	•	•	•	•		
ALL	GLK		Body	Trailer recognition module	•	•	•	•	•	•		
ALL	E-Class		Body	Trailer recognition module	•	•	•	•	•	•		
ALL	E-Class	207	Body	Trailer recognition module	•	•	•	•	•	•		
ALL	B-Class	246	Body	Trailer recognition module-Trailer recognition(N28/1)	•	•	0	•	0	•		
ALL	M-Class	166	Body	Trailer recognition module-Trailer recognition(N28/1)	•	•	0	•	0	•		
ALL	CLA	117	Body	Trailer recognition module-Trailer recognition (N28/1)	•	•	0	•	0	•		
ALL	A-Class	176	Body	Trailer recognition module-Trailer recognition(N28/1)	•	•	0	•	0	•		
ALL	M-Class	164	Chassis	TPM - Tire pressure monitor(N88)	•	•	•	•	•	•	•	
ALL	GL-Class	X 164	Chassis	TPM - Tire pressure monitor(N88)	•	•	•	•	•	•	•	
ALL	R-Class	251	Chassis	TPM - Tire pressure monitor(N88)	•	•	•	•	•	•	•	
ALL	B-Class	246	Chassis	TPM-Tire pressure monitor	•	•	0	•	0	•		0079
ALL	SLK	172	Chassis	TPM-Tire pressure monitor	•	•	0	•	0	•		0079
ALL	M-Class	166	Chassis	TPM-Tire pressure monitor	•	•	0	•	0	•		0079
ALL	CLA	117	Chassis	TPM-Tire pressure monitor	•	•	0	•	0	•		0079
ALL	A-Class	176	Chassis	TPM-Tire pressure monitor	•	•	0	•	0	•		0079
ALL	SL	231	Chassis	TPM-Tire pressure monitor	•	•	0	•	0	•		0079
ALL	C-Class	204	Chassis	TPC-Tire pressure monitor	•	•	•		•	•	•	0005
ALL	GLK	X204	Chassis	TPC-Tire pressure monitor	•	•			•	•	•	0005
ALL	E-Class	212	Chassis	TPC-Tire pressure monitor	•	•	•	•	•	•	•	0005
As of 12/2005	B-Class	245	Chassis	TPC-Tire pressure monitor	•	•	•	•	•	•	•	0005
As of 04/2004	CLK	209	Chassis	TPC-Tire pressure monitor	•	•	•	•	•	•	•	0005
As of 06/2005	SLK		Chassis	TPC-Tire pressure monitor	•	•	•	•	•	•	•	0005
As of 03/2007	G-Class	463 (16-pin diagnostic socket)		TPC-Tire pressure monitor	•	•	•	•	•	•	•	0005
ALL	C-Class		Chassis	TPM - Tire pressure monitor(N88)	•	•	•	•	•	•	•	
ALL	CLS	218	Chassis	TPM - Tire pressure monitor(N88)	•	•	•	•	•	•	•	
As of 07/2009	S-Class		Chassis	TPM - Tire pressure monitor(N88)	•	•		•	•	•	•	
ALL	CL		Chassis	TPM - Tire pressure monitor(N88)	•	•	•	•	•	•	•	
ALL	GLK	X204	Chassis	TPM - Tire pressure monitor(N88)	•	•	•	•	•	•	•	
ALL	E-Class		Chassis	TPM - Tire pressure monitor(N88)	•	•	•	•	•	•	•	
ALL	E-Class		Chassis	TPM - Tire pressure monitor(N88)	•	•	•	•	•	•	•	
ALL	SLS		Chassis	TPM - Tire pressure monitor(N88)	•	•	•	•	•	•	•	
Up to 06/2009	S-Class		Chassis	TPC-Tire pressure monitor	•	•	•	•	•	•	•	0005
ALL	CL		Chassis	TPC-Tire pressure monitor	•	•	•	•	•	•	•	0005
Up to 05/2005	E-Class	211	Chassis	TPC-Tire pressure monitor	•	•	•	•	•	•	•	0005

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
From 06/2005 to 05/2006	E-Class	211	Chassis	TPC-Tire pressure monitor	•	•	•	•	•	•	•	0005
As of 06/2006	E-Class	211	Chassis	TPC-Tire pressure monitor	•	•			•		•	0005
Up to 05/2005	CLS	219	Chassis	TPC-Tire pressure monitor	•	•			•	•	•	0005
From 06/2005 to 05/2006	CLS	219	Chassis	TPC-Tire pressure monitor	•	•	•	•	•	•	•	0005
As of 06/2006	CLS	219	Chassis	TPC-Tire pressure monitor	•	•	•	•	•	•	•	0005
From 09/2003 to 05/2006	SL	230	Chassis	TPC-Tire pressure monitor	•	•	•	•	•	•	•	0005
From 06/2006 to 02/2008	SL	230	Chassis	TPC-Tire pressure monitor	•	•	•	•	•	•	•	0005
As of 03/2008	SL	230	Chassis	TPC-Tire pressure monitor	•	•	•	•	•	•	•	0005
ALL	SLR	199	Chassis	TPC-Tire pressure monitor	•	•	•	•	•	•	•	0005
ALL	M-Class		Chassis	TPC-Tire pressure monitor	•	•	•	•	•	•	•	0005
ALL	GL-Class		Chassis	TPC-Tire pressure monitor	•	•	•	•	•	•	•	0005
ALL	R-Class	251	Chassis	TPC-Tire pressure monitor	•	•	•	•	•	•	•	0005
Up to 08/2002	S-Class	220	Information and communication	TSTH-Radio remote control of stationary heater	•	•	•	•	•	*	•	
Up to 08/2002	CL	215	Information and communication	TSTH-Radio remote control of stationary heater	•	•	•	•	•	*	•	
ALL	A-Class	168	Seats and doors	DCM-RL-Door control module rear left	•	•	0	•	•	*		
ALL	A-Class	168	Seats and doors	DCM-RR-Door control module rear right	•	•	0	•	•	*		
ALL	A-Class	168	Seats and doors	DCM-FL-Door control module front left	•	•	0	•	•	*		
ALL	A-Class	168	Seats and doors	DCM-FR-Door control module front right	•	•	0	•	•	*		
As of 06/97	C-Class	202		DCM3-Door control module rear driver side	•	•	0	•	•	*		
As of 03/97 DAS	E-Class	210	Seats and doors	DCM3-Door control module rear driver side	•	•	0	•	•	*		
Up to 11/2005	A-Class	169		DCM-RL-Door control module rear left	•	•	•	•	•	0	•	
As of 12/2005	A-Class	169	Seats and doors	DCM-RL-Door control module rear left	•	•	•	•	•	0	•	
Up to 11/2005	B-Class	245		DCM-RL-Door control module rear left	•	•	•	•	•	0	•	
As of 12/2005	B-Class	245		DCM-RL-Door control module rear left	•	•	•	•	•	0	•	
Up to 08/2003	C-Class	203		DCM-RL-Door control module rear left	•	•	•	•	•	0	•	
From 09/2003 to 12/2007	C-Class			DCM-RL-Door control module rear left	•	•	•	•	•	0	•	
Up to 03/2004	G-Class	socket)	Seats and doors	DCM-RL-Door control module rear left	•	•	•	•	•	0	•	
From 04/2004 to 08/2006	G-Class	socket)	Seats and doors	DCM-RL-Door control module rear left	•	•	•	•	•	0	•	
From 09/2006 to 02/2007	G-Class	socket)	Seats and doors	DCM-RL-Door control module rear left	•	•	•	•	•	0	•	
As of 03/2007	G-Class	socket)		DCM-RL-Door control module rear left	•	•	•	•	•	0	•	
Up to 05/2005	E-Class	211	Seats and doors	DCM-RL-Door control module rear left	•	•	•	•	•	0	•	0003
From 06/2005 to 05/2006	E-Class	211	Seats and doors	DCM-RL-Door control module rear left	•	•	•	•	•	0	•	0003

Live Freeze Frame	Active Test  • • • • • • • • • • • • • • • • • •	Special Function  0003  0003  0003  0003
• O • O • O • **	•	0003 0003
• 0 • 0 • %	•	0003
• O ×	•	
• × • ×	— <u> </u>	0003
•	•	
• •	•	
	•	
• •	•	
• 0	•	
• 0	•	
•		
• *		
• 0	•	
• 0	•	
• 0	•	
• 0	•	
• 0		
• 0	•	
• 0	•	
• 0	•	
• 0	•	
• 0	•	
• 0	•	0003
• 0	•	0003
• 0	•	0003
• 0	•	0003
• 0	•	0003
• 0	•	0003
• *	*	
• *	*	
• •	•	
• •	•	
• 0	•	
• 0	•	
•		
	<ul> <li>•</li> <li>•&lt;</li></ul>	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
		Series	droups	TOO NO. I ON THE STATE OF THE S	11110.	codes	мешот у	codes	рата	1.1 ame	lest	
As of 07/2009	S-Class	221	Seats and doors	TSG-ML-Left center door control unit (interior	•	•	•	•	•			
				Can bus)								
Up to $06/2009$	S-Class	221	Seats and doors	TSG-MR-Right center door control unit (interior Can bus)	•	•	•	•	•			
				TSG-MR-Right center door control unit (interior								
As of 07/2009	S-Class	221	Seats and doors	Can bus)	•	•	•	•	•			
As of 06/97	C-Class	202	Seats and doors	DCM1-Door control module front driver side	•	•	0	•	•	*		
ALL	CLK	208		DCM1-Door control module front driver side			0			*		
As of 03/97 DAS	E-Class	210		DCM1-Door control module front driver side	•	•	0	•	•	*		
ALL	M-Class	164		DCM-FL-Door control module front left	•	•	•	•	•	0	•	
ALL	GL-Class	X 164	Seats and doors	DCM-FL-Door control module front left	•	•	•	•	•	0	•	
ALL	R-Class	251	Seats and doors	DCM-FL-Door control module front left	•	•	•	•	•	0	•	
Up to 11/2005	A-Class	169	Seats and doors	DCM-FL-Door control module front left	•	•	•	•	•	0	•	
As of 12/2005	A-Class	169		DCM-FL-Door control module front left	•	•	•	•	•	0	•	
Up to 11/2005	B-Class	245		DCM-FL-Door control module front left	•	•	•	•	•	0	•	
As of 12/2005	B-Class	245		DCM-FL-Door control module front left	•	•	•	•	•	0	•	
Up to 05/2005	SLK	171	Seats and doors	DCM-L-Door control module left	•	•	•		•	0	•	
As of 06/2005	SLK	171	Seats and doors	DCM-L-Door control module left	•	•	•	•	•	0	•	
Up to 08/2003	C-Class	203	Seats and doors	DCM-FL-Door control module front left	•	•	•	•	•	0	•	
From 09/2003 to 12/2007	C-Class	203	Seats and doors	DCM-FL-Door control module front left	•	•	•	•	•	0	•	
As of 01/2008	C-Class	203	Seats and doors	DCM-FL-Door control module front left	•	•	•	•	•	0	•	
		463(16-pin										
Up to $03/2004$	G-Class	diagnostic socket)	Seats and doors	DCM-FL-Door control module front left	•	•	•	•	•	0	•	
From 04/2004 to 08/2006	G-Class	463(16-pin	Seats and doors	DCM-FL-Door control module front left	•	•	•	•	•	0	•	
From 09/2006 to 02/2007	G-Class	socket)		DCM-FL-Door control module front left	•	•	•	•	•	0	•	
As of 03/2007	G-Class	socket)		DCM-FL-Door control module front left	•	•	•	•	•	0	•	
Up to 03/2004	CLK	209		DCM-L-Door control module left	•	•	•	•	•	0	•	
As of 04/2004	CLK	209		DCM-L-Door control module left	•	•	•	•	•	0	•	0000
	E-Class	211	Seats and doors	DCM-FL-Door control module front left	•	•	•	•	•	0	•	0003
From 06/2005 to 05/2006	E-Class	211		DCM-FL-Door control module front left	•	•	•	•	•	0		0003
As of 06/2006	E-Class	211		DCM-FL-Door control module front left	•	•	•	•	•	0	•	0003
Up to 05/2005	CLS	219	Seats and doors	DCM-FL-Door control module front left	•	•	•	•	•	0	•	0003
From 06/2005 to 05/2006	CLS	219	Seats and doors	DCM-FL-Door control module front left	•	•	•	•	•	0	•	0003
As of 06/2006	CLS	219	Seats and doors	DCM-FL-Door control module front left	•	•	•	•	•	0	•	0003
	S-Class	220	Seats and doors	DCM-FL-Door control module front left	•	•	•	•	•	*	•	
	S-Class	220	Seats and doors	DCM-FL-Door control module front left	•	•	•	•	•	*	•	
Up to 08/2002	CL	215		DCM-FL-Door control module front left	•	•	•	•	•	*	•	
As of 09/2002	CL	215	Seats and doors	DCM-FL-Door control module front left	•				•	*		

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
Up to 06/2009	S-Class	221		DCM-FL-Door control module front left	•	•	•	•	•	•	•	
As of 07/2009	S-Class	221	Seats and doors	DCM-FL-Door control module front left	•	•	•	•	•	•	•	
ALL	CL	216	Seats and doors	DCM-FL-Door control module front left	•	•	•	•	•	•	•	
Up to 08/2003	SL	230	Seats and doors	DCM-L-Door control module left	•	•	•	•	•	*		
From 09/2003 to 05/2006	SL	230	Seats and doors	DCM-L-Door control module left	•	•	•	•	•	*		
From 06/2006 to 02/2008	SL	230	Seats and doors	DCM-L-Door control module left	•	•	•	•	•	*		
As of 03/2008	SL	230	Seats and doors	DCM-L-Door control module left	•	•	•	•	•	*		
ALL	SLR	199	Seats and doors	DCM-L-Door control module left	•	•	•	•	•	*		
Up to 08/2006	MayBach	240	Seats and doors	DCM-FL-Door control module front left	•	•	•	•	•	0	•	
As of 09/2006	MayBach	240	Seats and doors	DCM-FL-Door control module front left	•	•	•	•	•	0	•	
As of 06/97	C-Class	202	Seats and doors	DCM2-Door control module front passenger side	•	•	0	•	•	*		
ALL	CLK	208	Seats and doors	DCM2-Door control module front passenger side	•	•	0	•	•	*		
As of 03/97 DAS	E-Class	210		DCM2-Door control module front passenger side	•	•	0	•	•	*		
ALL	M-Class	164	Seats and doors	DCM-FR-Door control module front right	•	•	•	•	•	0	•	
ALL	GL-Class	X 164	Seats and doors	DCM-FR-Door control module front right	•	•	•	•	•	0	•	
ALL	R-Class	251	Seats and doors	DCM-FR-Door control module front right	•	•	•	•	•	0	•	
Up to 11/2005	A-Class	169		DCM-FR-Door control module front right	•	•	•	•	•	0	•	
As of 12/2005	A-Class	169	Seats and doors	DCM-FR-Door control module front right	•	•	•	•	•	0	•	
Up to 11/2005	B-Class	245		DCM-FR-Door control module front right	•	•	•	•	•	0	•	
As of 12/2005	B-Class	245	Seats and doors	DCM-FR-Door control module front right	•	•	•	•	•	0	•	
Up to 05/2005	SLK	171		DCM-R-Door control module right	•	•	•	•	•	0	•	
As of 06/2005	SLK	171	Seats and doors	DCM-R-Door control module right	•	•	•	•	•	0	•	
Up to 08/2003	C-Class	203	Seats and doors	DCM-FR-Door control module front right	•	•	•	•	•	0	•	
From 09/2003 to										0		
12/2007	C-Class	203	Seats and doors	DCM-FR-Door control module front right			•	•		0	•	
As of 01/2008	C-Class	203	Seats and doors	DCM-FR-Door control module front right	•	•	•	•	•	0	•	
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Seats and doors	DCM-FR-Door control module front right	•	•	•	•	•	0	•	
From 04/2004 to 08/2006	G-Class	socket)		DCM-FR-Door control module front right	•	•	•	•	•	0	•	
From 09/2006 to 02/2007	G-Class	socket)	Seats and doors	DCM-FR-Door control module front right	•	•	•	•	•	0	•	
As of 03/2007	G-Class	socket)		DCM-FR-Door control module front right	•	•	•	•	•	0	•	
Up to 03/2004	CLK	209		DCM-R-Door control module right	•	•	•	•	•	0	•	
As of 04/2004	CLK	209		DCM-R-Door control module right	•	•	•	•	•	0	•	
Up to 05/2005	E-Class	211	Seats and doors	DCM-FR-Door control module front right	•	•	•	•	•	0	•	0003
From 06/2005 to 05/2006	E-Class	211	Seats and doors	DCM-FR-Door control module front right	•	•	•	•	•	0	•	0003
As of 06/2006	E-Class	211	Seats and doors	DCM-FR-Door control module front right	•	•	•	•	•	0	•	0003
Up to 05/2005	CLS	219		DCM-FR-Door control module front right	•	•	•	•	•	0	•	0003

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
From 06/2005 to 05/2006	CLS	219	Seats and doors	DCM-FR-Door control module front right	•	•	•	•	•	0	•	0003
As of 06/2006	CLS	219	Seats and doors	DCM-FR-Door control module front right	•		•		•	0	•	0003
Up to 08/2002	S-Class	220	Seats and doors	DCM-FR-Door control module front right	•		•		•	*	•	
As of 09/2002	S-Class	220	Seats and doors	DCM-FR-Door control module front right	•	•			•	*	•	
Up to 08/2002	CL	215	Seats and doors	DCM-FR-Door control module front right	•	•			•	*	•	
As of 09/2002	CL	215	Seats and doors	DCM-FR-Door control module front right	•	•			•	*	•	
Up to 06/2009	S-Class	221	Seats and doors	DCM-FR-Door control module front right	•	•		•	•	•	•	
As of 07/2009	S-Class	221	Seats and doors	DCM-FR-Door control module front right	•	•			•	•	•	
ALL	CL	216	Seats and doors	DCM-FR-Door control module front right	•	•	•	•	•	•	•	
Up to 08/2003	SL	230	Seats and doors	DCM-R-Door control module right	•	•	•	•	•	*		
From 09/2003 to 05/2006	SL	230	Seats and doors	DCM-R-Door control module right	•	•	•	•	•	*		
From 06/2006 to 02/2008	SL	230	Seats and doors	DCM-R-Door control module right	•	•	•	•	•	*		
As of 03/2008	SL	230	Seats and doors	DCM-R-Door control module right	•	•	•	•	•	*		
ALL	SLR	199		DCM-R-Door control module right	•	•	•	•	•	*		
Up to 08/2006	MayBach	240		DCM-FR-Door control module front right	•	•		•	•	0	•	
As of 09/2006	MayBach	240		DCM-FR-Door control module front right	•	•		•	•	0	•	
ALL	C-Class	204	Drive	ESM-Electronic selector module	•	•		•	•	•	•	
ALL	CLS	218	Drive	ESM-Electronic selector module	•	•	•	•	•	•	•	
ALL	SLK	172	Drive	ESM-Electronic selector module	•	•	•	•	•	•	•	
ALL	GLK	X204	Drive	ESM-Electronic selector module	•	•	•	•	•	•	•	
ALL	E-Class	212	Drive	ESM-Electronic selector module	•	•	•	•	•	•	•	
ALL	E-Class	207	Drive	ESM-Electronic selector module	<u> </u>		•	•	•		•	
ALL	C-Class		Drive	ESM-Electronic selector module	<u> </u>		•	•	•			
ALL	GLK	X204	Drive	ESM-Electronic selector module	<u> </u>		•	•	•	•		
ALL	C-Class		Body	PSD-Control mudule 'Panoramic sliding			•	•	•	•		
ALL	GLK		Body	PSD-Control mudule 'Panoramic sliding	•		•	•	•	•		
ALL	C-Class		Body	PSD-Control mudule 'Panoramic sliding	•		•	•	•	•	<b>A</b>	
ALL	CLS		Body	PSD-Control mudule 'Panoramic sliding	•		•	•		•	<u> </u>	
ALL	GLK		Body	PSD-Control mudule 'Panoramic sliding	<u> </u>		•	•				
ALL	E-Class		Body	PSD-Control mudule 'Panoramic sliding	$\overline{}$		•	•	$\overline{}$		<u> </u>	
ALL	E-Class		Body	PSD-Control mudule 'Panoramic sliding	$\overline{}$			•	<del>-</del>		$\overline{A}$	
Up to 06/2009	S-Class		Body	PSD-Panoramic sliding roof(Interior CAN bus)	•	•	•	•	•			
As of 07/2009	S-Class		Body	PSD-Panoramic sliding roof(Interior CAN bus)	•		•		•			
ALL			Body	PSD-Control module 'Panoramic sliding			0		0			
ALL	CLA		Body	PSD-Control module 'Panoramic sliding roof	•	•	0	•	0			
ALL	A-Class	176	Body	PSD-Control module 'Panoramic sliding roof	•	•	0	•	0			
Up to 06/2009	S-Class	221	Information and	Tuner-Standard tuner	•	•	•	•	•	•	*	
ορ το ου/ 2009 ———————————————————————————————————	D 01022	221	communication	Tuner Standard tuner							~	
As of 07/2009	S-Class	221	Information and communication	Tuner-Standard tuner	•	•	•	•	•	•	*	
ALL	CL	216	Information and communication	Tuner-Standard tuner	•	•	•	•	•	•	*	
Up to 06/2009	S-Class	221	Information and communication	Tuner-Tuner sound	•	•	•	•	•	•	*	

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 07/2009	S-Class	221	Information and communication	Tuner-Tuner sound	•	•	•	•	•	•	*	
ALL	CL	216	Information and communication	Tuner-Tuner sound	•	•	•	•	•	•	*	
Up to 06/2009	S-Class	221	Information and communication	Tuner-Tuner sound	•	•	•	•	0	0		
As of 07/2009	S-Class	221	Information and communication	Tuner-Tuner sound	•	•	•	•	0	0		
ALL	CL	216	Information and communication	Tuner-Tuner sound	•	•	•	•	0	0		
Up to 08/2003	C-Class	203	Information and communication	TV-TV tuner	•	•	•	•		•	•	
Up to 03/2004	CLK	209	Information and communication	TV-TV tuner	•	•	•	•		•	•	
ALL	CLK	208	Information and communication	TV-TV tuner	•	•	•	•		•	•	
As of 03/97 DAS 3	E-Class	210	Information and communication	TV-TV tuner	•	•	•	•		•	•	
Up to 08/2002	S-Class	220	Information and communication	TV-TV tuner	•	•	•	•		•	•	
As of 09/2002	S-Class	220	Information and communication	TV-TV tuner	•	•	•	•		•	•	
Up to 08/2002	CL	215	Information and communication	TV-TV tuner	•	•	•	•		•	•	
As of 09/2002	CL	215	Information and communication	TV-TV tuner	•	•	•	•		•	•	
Up to 08/2003	SL	230	Information and communication	TV-TV tuner	•	•	•	•		•	•	
From 09/2003 to 05/2006	SL	230	Information and communication	TV-TV tuner	•	•	•	•		•	•	
From 06/2006 to 02/2008	SL	230	Information and communication	TV-TV tuner	•	•	•	•		•	•	
As of 03/2008	SL	230	Information and communication	TV-TV tuner	•	•	•	•		•	•	
Up to 03/2004	G-Class	socket)	Information and communication	TV-TV tuner	•	•	•	•		•	•	
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Information and communication	TV-TV tuner	•	•	•	•		•	•	
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	TV-TV tuner	•	•	•	•		•	•	
As of 04/2004	CLK	209	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•		
Up to 05/2005	E-Class	211	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•		

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
From 06/2005 to 05/2006	E-Class	211	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•		
As of 06/2006	E-Class	211	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•		
Up to 05/2005	CLS	219	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•		
From 06/2005 to 05/2006	CLS	219	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•		
As of 06/2006	CLS	219	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•		
Up to 08/2002	S-Class	220	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•		
As of 09/2002	S-Class	220	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•		
As of 09/2002	CL	215	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•		
Up to 08/2006	MayBach	240	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•		
As of 09/2006	MayBach	240	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•		
From 09/2003 to 05/2006	SL	230	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•		
From 06/2006 to 02/2008	SL	230	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•		
As of 03/2008	SL	230	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•		
ALL	M-Class	164	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•		
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•		
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•		
ALL	GL-Class	X 164	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•		
ALL	R-Class	251	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•		
ALL	B-Class	246	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•		
ALL	C-Class	204	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•		
ALL	CLS	218	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•		
Up to 06/2009	S-Class	221	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•		
As of 07/2009	S-Class	221	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•		

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	CL	216	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•		
ALL	SLK	172	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•		
ALL	GLK	X204	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•		
ALL	M-Class	166	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•		
ALL	E-Class	212	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•		
ALL	E-Class	207	Information and communication	TV-TV tuner (AGW)	•	•	•	•	•	•		
ALL	CLA	117	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•		
ALL	A-Class	176	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•		
ALL	SL	231	Information and communication	TV-TV tuner(AGW)	•	•	•	•	•	•		
Up to 05/2005	E-Class	211	Information and communication	TV-TV tuner	•	•	•	•	•	•		
As of 06/2006	E-Class	211	Information and communication	TV-TV tuner	•	•	•	•	•	•		
As of 06/2006	CLS	219	Information and communication	TV-TV tuner	•	•	•	•	•	•		
As of 03/2008	SL	230	Information and communication	TV-TV tuner	•	•	•	•	•	•		
Up to 05/2005	SLK	171	Information and communication	TV-TV tuner	•	•	•	•	•	•		
As of 06/2005	SLK	171	Information and communication	TV-TV tuner	•	•	•	•	•	•		
ALL	M-Class	164	Information and communication	TV-TV tuner	•	•	•	•	•	•		
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	TV-TV tuner	•	•	•	•	•	•		
ALL	GL-Class	X 164	Information and communication	TV-TV tuner	•	•	•	•	•	•		
ALL	R-Class	251	Information and	TV-TV tuner	•	•	•	•	•	•		
As of 12/2005	A-Class		Drive	TV-TV tuner	•	•	•	•	•			
As of 12/2005	B-Class		Drive	TV-TV tuner	•	•	•	•	•			
Up to 05/2005	E-Class			TV-TV tuner	•	•	•	•	•			
As of 06/2006	E-Class		Drive	TV-TV tuner	•	•	•	•	•			
As of 06/2006	CLS			TV-TV tuner	•	•	•	•	•			
As of 03/2008	SL		Drive	TV-TV tuner	•	•	•	•	•			
Up to 05/2005 As of 06/2005	SLK		Drive	TV-TV tuner	•	•	•	•	•	-		
AS 01 06/2005 ALL	SLK M-Class		Drive Drive	TV-TV tuner TV-TV tuner			•	•	-	-		

		Mode1	Control Unit		Ecu	Read	Event	Erase	Live	Freeze	Active	
Model year	Mode1	Series	Groups	System Name	Info.	Codes	Memory	Codes	Data	Frame	Test	Special Function
		463(16-pin										
As of 03/2007	G-Class	diagnostic	Drive	TV-TV tuner	•	•	•	•	•			
		socket)				_			_			
ALL	GL-Class		Drive	TV-TV tuner	•	•	•	•	•			
ALL	R-Class	251	Drive	TV-TV tuner	•	•	•	•	•			
ALL	C-Class	204	communication	TV-TV tuner	•	•	•	•	•	•		
ALL	GLK	X204	Information and communication	TV-TV tuner	•	•	•	•	•	•		
Up to 08/2006	MayBach	240	Seats and doors	PWC-Partition wall control module	•	•	•	•	•	0		
As of 09/2006	MayBach	240	Seats and doors	PWC-Partition wall control module	•	•	•	•	•	0		
Up to 08/2006	MayBach	240	Seats and doors	LDCA-Electric left door closing assist	•	•	•	•	•	•	0	
As of 09/2006	MayBach	240		LDCA-Electric left door closing assist	•	•	•	•	•	•	0	
Up to 08/2006	MayBach	240	Seats and doors	RDCA-Electric right door closing assist	•	•	•	•	•	•	0	
As of 09/2006	MayBach	240	Seats and doors	RDCA-Electric right door closing assist	•	•	•	•	•	•	0	
As of 06/97	C-Class	+	Body	LCP-Lower control panel	•	•	0	•	•	*		
ALL	CLK		Body	LCP-Lower control panel	•	•	0	•	•	*		
	E-Class		Body	LCP-Lower control panel	•	•	0	•	•	*		
ALL	A-Class	+	Body	LCP-Lower control panel	•	•	0	•	•	*		
Up to 08/2003	C-Class	203	Body	LCP-Lower control panel	•	•	•	•	•	0	•	
From 09/2003 to 12/2007	C-Class	203	Body	LCP-Lower control panel	•	•	•	•	•	0	•	
As of 01/2008	C-Class	203	Body	LCP-Lower control panel	•	•	•	•	•	0	•	
Up to 03/2004	CLK	209	Body	LCP-Lower control panel	•	•	•	•	•	0	•	
As of 04/2004	CLK	209	Body	LCP-Lower control panel	•	•	•		•	0	•	
Up to 05/2005	E-Class	211	Body	LCP-Lower control panel	•	•			•	0		
From 06/2005 to 05/2006	E-Class	211	Body	LCP-Lower control panel	•	•	•	•	•	0		
As of 06/2006	E-Class	211	Body	LCP-Lower control panel	•	•	•	•	•	0		
Up to 05/2005	CLS	219	Body	LCP-Lower control panel	•	•			•	0		
From 06/2005 to 05/2006	CLS	219	Body	LCP-Lower control panel	•	•	•	•	•	0		
As of 06/2006	CLS	219	Body	LCP-Lower control panel	•	•	•	•	•	0		
Up to 08/2003	SL	230	Body	LCP-Lower control panel	•	•	•	•	•	*	•	
From 09/2003 to 05/2006	SL	230	Body	LCP-Lower control panel	•	•	•	•	•	*	•	
From 06/2006 to 02/2008	SL	230	Body	LCP-Lower control panel	•	•	•	•	•	*	•	
As of 03/2008	SL	230	Body	LCP-Lower control panel	•	•	•	•	•	*	•	
ALL	SLR		Body	LCP-Lower control panel	•	•	•	•	•	*	•	_
ALL	B-Class	246	Information and communication	UCI-Media interface	•	•	•	•	•	•	0	
ALL	C-Class	204	Information and communication	UCI-Media interface	•	•	•	•	•	•	0	
ALL	CLS	218	Information and communication	UCI-Media interface	•	•	•	•	•	•	0	
Up to 06/2009	S-Class	221	Information and	UCI-Media interface	•	•	•	•	•	•	0	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 07/2009	S-Class	221	Information and communication	UCI-Media interface	•	•	•	•	•	•	0	
ALL	CL	216	Information and communication	UCI-Media interface	•	•	•	•	•	•	0	
ALL	SLK	172	Information and communication	UCI-Media interface	•	•	•	•	•	•	0	
ALL	GLK	X204	Information and communication	UCI-Media interface	•	•	•	•	•	•	0	
ALL	M-Class	166	Information and communication	UCI-Media interface	•	•	•	•	•	•	0	
ALL	E-Class	212	Information and communication	UCI-Media interface	•	•	•	•	•	•	0	
ALL	E-Class	207	Information and communication	UCI-Media interface	•	•	•	•	•	•	0	
ALL	SLS	197	Information and communication	UCI-Media interface	•	•	•	•	•	•	0	
ALL	CLA	117	Information and communication	UCI-Media interface	•	•	•	•	•	•	0	
ALL	A-Class	176	Information and communication	UCI-Media interface	•	•	•	•	•	•	0	
ALL	SL	231	Information and communication	UCI-Media interface	•	•	•	•	•	•	0	
As of 12/2005	A-Class	169	Information and communication	UCI-Media interface	•	•	•	•	•	•	0	
As of 12/2005	B-Class	245	Information and communication	UCI-Media interface	•	•	•	•	•	•	0	
As of 01/2008	C-Class	203	Information and communication	UCI-Media interface	•	•	•	•	•	•	0	
Up to 05/2005	E-Class	211	Information and communication	UCI-Media interface	•	•	•	•	•	•	0	
As of 06/2006	E-Class	211	Information and communication	UCI-Media interface	•	•	•	•	•	•	0	
As of 06/2006	CLS	219	Information and communication	UCI-Media interface	•	•	•	•	•	•	0	
As of 03/2008	SL	230	Information and communication	UCI-Media interface	•	•	•	•	•	•	0	
Up to 05/2005	SLK	171	Information and communication	UCI-Media interface	•	•	•	•	•	•	0	
As of 06/2005	SLK	171	Information and communication	UCI-Media interface	•	•	•	•	•	•	0	
ALL	M-Class	164	Information and communication	UCI-Media interface	•	•	•	•	•	•	0	
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	UCI-Media interface	•	•	•	•	•	•	0	
ALL	GL-Class	X 164	Information and communication	UCI-Media interface	•	•	•	•	•	•	0	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	R-Class	251	Information and communication	UCI-Media interface	•	•	•	•	•	•	0	
ALL	C-Class	204	Drive	FSCU-Fuel pump	•	•	•	•	0	•		
ALL	CLS	218	Drive	FSCU-Fuel pump	•			•	0	•		
Up to 06/2009	S-Class	221	Drive	FSCU-Fuel pump	•	•	•		0	•		
As of 07/2009	S-Class	221	Drive	FSCU-Fuel pump	•	•	•		0	•		
ALL	CL	216	Drive	FSCU-Fuel pump	•	•	•		0	•		
ALL	SLK		Drive	FSCU-Fuel pump	•	•	•		0	•		
ALL	GLK		Drive	FSCU-Fuel pump	•	•	•	•	0	•		
ALL	E-Class	212	Drive	FSCU-Fuel pump	•	•	•		0	•		
ALL	SLS	197	Drive	FSCU-Fuel pump	•	•	•	•	0	•		
Up to 08/2003	C-Class	203		UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	•	0		
As of 06/97	C-Class	202	Information and	UHI- Cellular telephone 1 (fixed installation	•	•	•	•	•	0		
Up to 03/2004	CLK	209	Information and	or portable)(D2B) UHI- Cellular telephone 1 (fixed installation	•	•	•	•	•	0		
ALL	CLK	208	Information and	or portable) (D2B) UHI- Cellular telephone 1 (fixed installation	•	•	•	•	•	0		
As of 03/97 DAS	E-Class	210	Information and	or portable)(D2B) UHI- Cellular telephone 1 (fixed installation	•	•	•	•	•	0		
Up to 08/2002	S-Class	220	Information and	or portable)(D2B) UHI- Cellular telephone 1 (fixed installation	•	•	•	•	•	0		
As of 09/2002	S-Class	220		or portable)(D2B) UHI- Cellular telephone 1 (fixed installation				•		0		
				or portable)(D2B) UHI- Cellular telephone 1 (fixed installation	_		_		-			
Up to 08/2002	CL	215	communication	or portable)(D2B)	•	•	•	•	•	0		
As of 09/2002	CL	215	communication	UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	•	0		
Up to 08/2003	SL	230		UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	•	0		
From 09/2003 to 05/2006	SL	230		UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	•	0		
From 06/2006 to 02/2008	SL	230		UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	•	0		
As of 09/99	SL	129		UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	•	0		
ALL	SLR	199		UHI- Cellular telephone 1 (fixed installation or portable) (D2B)	•	•	•	•	•	0		
ALL	SLK	170(16-pin diagnostic socket)		UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	•	0		
ALL	SLK	170 (38-pin diagnostic socket)	communication	UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	•	0		
ALL	M-Class	163		UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	•	0		

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
Up to 03/2004	G-Class	463 (16-pin diagnostic socket)	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	•	0		
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	•	0		
From 09/2006 to 02/2007	G-Class	463 (16-pin diagnostic socket)	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	•	•	•	•	•	0		
Up to 06/2009	S-Class	221	Information and communication	CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•	*	
As of 07/2009	S-Class	221	Information and communication	CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•	*	
ALL	CL	216	Information and communication	CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•	*	
ALL	C-Class	204	Information and communication	NAVI20 - Navigation(N125/2)	•	•	0	•	0	•		
ALL	CLS	218	Information and communication	NAVI20 - Navigation(N125/2)	•	•	0	•	0	•		
ALL	SLK	172	Information and communication	NAVI20 - Navigation(N125/2)	•	•	0	•	0	•		
ALL	GLK	X204	Information and communication	NAVI20 - Navigation(N125/2)	•	•	0	•	0	•		
ALL	E-Class	212	Information and communication	NAVI20 - Navigation(N125/2)	•	•	0	•	0	•		
ALL	E-Class	207	Information and communication	NAVI20 - Navigation(N125/2)	•	•	0	•	0	•		
As of 12/2005 Up to 08/2003	B-Class	245 203	Chassis	VP-Vacuum pump brake booster	•	•	•	•	•	•	•	
As of 06/97	C-Class C-Class	202	Chassis Chassis	VP-Vacuum pump brake booster VP-Vacuum pump brake booster		-	•					
ALL	CLK	208	Chassis	VP-Vacuum pump brake booster		<del>-</del>						
As of 03/97 DAS	E-Class	210	Chassis	VP-Vacuum pump brake booster		<del>-</del>	•					
ALL	SLK	170(16-pin diagnostic socket)		VP-Vacuum pump brake booster	•	•	•	•	•	•	•	
ALL	M-Class	163	Chassis	VP-Vacuum pump brake booster		•	•	•		•	•	
ALL	B-Class	246	Information and communication	Audio-Audio 5 USB(A2)	•	•	0	•	0	•		
ALL	CLA	117	Information and communication	Audio-Audio 5 USB(A2)	•	•	0	•	0	•		
ALL	A-Class	176	Information and communication	Audio-Audio 5 USB(A2)	•	•	0	•	0	•		
ALL	CLK	208	Body	RVC-Rollover bar soft top control module	•	•	0	•		*		
Up to 03/2004	CLK	209	Body	RVC-Rollover bar soft top control module	•	•	•	•		0		
As of 04/2004	CLK	209	Body	RVC-Rollover bar soft top control module	•	•	•	•	•	0		
Up to 08/2003	SL	230	Body	RVC-Rollover bar/vario roof control module	•	•	•	•		*		
From 09/2003 to 05/2006	SL	230	Body	RVC-Rollover bar/vario roof control module	•	•	•	•	•	*		

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
From 06/2006 to 02/2008	SL	230	Body	RVC-Rollover bar/vario roof control module	•	•	•	•	•	*		
From 09/2003 to 05/2006	SL	230	Body	RVC-Rollover bar/vario roof control module	•	•	•	•	•	•		
From 06/2006 to 02/2008	SL	230	Body	RVC-Rollover bar/vario roof control module	•	•	•	•	•	•		
As of 03/2008	SL	230	Body	RVC-Rollover bar/vario roof control module	•	•	•	•	•	•		
Up to 08/2006	MayBach	240	Body	VBF (Front control panel)-Front control panel		•	•	•	•	0	•	
As of 09/2006	MayBach	240	Body	VBF (Front control panel)-Front control panel		•	•	•	•	0	•	
ALL	SLK	170(16-pin diagnostic socket)	Body	VR-Vario roof	•	•	0	•	•	*	•	
ALL	SLK	170 (38-pin diagnostic socket)		VR-Vario roof	•	•	0	•	•	*	•	
ALL	M-Class	163	Drive	VG-Transfer case	•	•	0	•	•	*		
ALL	M-Class	164	Drive	VG-Transfer case	•	•	•	•	•	•	•	
ALL	GL-Class	X 164	Drive	VG-Transfer case	•	•	•	•	•	•	•	
ALL	A-Class	168	Drive	FTC2 -Front transmission control2	•	•	•	•	•	•		
Up to 03/2004	G-Class	463 (16-pin diagnostic socket)	Drive	N15/7(Transfer case control module)	•	•	•	•	•	0	•	
From 04/2004 to 08/2006	G-Class	463 (16-pin diagnostic socket)	Drive	N15/7(Transfer case control module)	•	•	•	•	•	0	•	
From 09/2006 to 02/2007	G-Class	463 (16-pin diagnostic socket)	Drive	N15/7(Transfer case control module)	•	•	•	•	•	0	•	
As of 03/2007	G-Class	463 (16-pin diagnostic socket)	Drive	N15/7(Transfer case control module)	•	•	•	•	•	0	•	
ALL	G-Class	461 (16-pin diagnostic socket)	Drive	N15/7(Transfer case control module)	•	•	•	•	•	0	•	
ALL	C-Class	204	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	0	
Up to 08/2003	C-Class	203	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	0	
From 09/2003 to 12/2007	C-Class	203	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	0	
As of 01/2008	C-Class	203	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	0	
	CLK	209	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	0	
As of 04/2004	CLK	209	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	0	
Up to 05/2005	E-Class	211	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	0	
From 06/2005 to 05/2006	E-Class	211	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	0	
As of 06/2006	E-Class	211	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	0	
	CLS	219	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	0	
From 06/2005 to 05/2006	CLS	219	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	0	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 06/2006	CLS		Drive	ETC-Electronic transmission control	•	•	•	•	•	•	0	
ALL	CLS	218	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	0	
Up to 06/2009	S-Class	221	Drive	ETC-Electronic transmission control	•	•		•	•	•	0	
As of 07/2009	S-Class	221	Drive	ETC-Electronic transmission control	•	•		•	•		0	
Up to 08/2002	S-Class	220	Drive	ETC-Electronic transmission control	•	•		•	•		0	
As of 09/2002	S-Class	220	Drive	ETC-Electronic transmission control	•	•		•	•		0	
ALL	CL	216	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	0	
As of 09/2002	CL	215	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	0	
Up to 08/2003	SL	230	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	0	
From 09/2003 to	CI	000	D!	ETC Flacture in the series in a series in								
05/2006	SL	230	Drive	ETC-Electronic transmission control	•	_	•	•	•	•	0	
From 06/2006 to 02/2008	SL	230	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	0	
As of 03/2008	SL	230	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	0	
Up to 05/2005	SLK	171	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	0	
As of 06/2005	SLK		Drive	ETC-Electronic transmission control	•	•	•	•	•	•	0	
ALL	SLK		Drive	ETC-Electronic transmission control	•	•	•	•	•	•	0	
ALL	GLK		Drive	ETC-Electronic transmission control	•	•	•	•	•	•	0	
ALL	M-Class		Drive	ETC-Electronic transmission control	•	•	•	•	•	•	0	
ALL	M-Class		Drive	ETC-Electronic transmission control	•	•	•	•	•	•	0	
From 09/2006 to		463(16-pin										
02/2007	G-Class	diagnostic socket)	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	0	
As of 03/2007	G-Class	463(16-pin diagnostic socket)		ETC-Electronic transmission control	•	•	•	•	•	•	0	
ALL	GL-Class	X 164	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	0	
ALL	R-Class	251	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	0	
ALL	E-Class	212	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	0	
ALL	E-Class	207	Drive	ETC-Electronic transmission control	•	•	•	•	•	•	0	
ALL	C-Class	204	Body	SGR-Radar sensors control unit	•	•	•	•	0	•		
ALL	CLS	218	Body	SGR-Radar sensors control unit	•	•	•	•	0	•		
As of 07/2009	S-Class	221	Body	SGR-Radar sensors control unit	•	•	•	•	0	•		
ALL	CL	216	Body	SGR-Radar sensors control unit	•	•	•	•	0	•		
ALL	SLK	172	Body	SGR-Radar sensors control unit	•	•	•	•	0	•		
ALL	GLK	X204	Body	SGR-Radar sensors control unit	•	•	•	•	0	•		
ALL	M-Class		Body	SGR-Radar sensors control unit	•	•	•	•	0	•		
ALL	E-Class	212	Body	SGR-Radar sensors control unit	•	•	•	•	0	•		
ALL	E-Class		Body	SGR-Radar sensors control unit	•	•	•	•	0	•		
ALL	SL		Body	SGR-Radar sensors control unit	•	•	•	•	0	•		
Up to 05/2005	SLK		Body	VR-Vario roof	•	•	•	•	•	0	•	
	SLK		Body	VR-Vario roof	•	•	•	•	•	0	•	
ALL	SLR		Body	RS-Roadster soft top	•	•	•	•	•	•	0	
				ATA-ATA[EDW]/tow-away protection/interior							-	
ALL	B-Class	246	Body	protection(N26/6)	•	•	0	•	0	•		
ALL	M-Class	166	Body	ATA-ATA[EDW]/tow-away protection/interior	•	•	0	•	0	•		
		ļ	<u>.</u>	protection(N26/6)	-			_	-			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	CLA	117	Body	ATA-ATA[EDW]/tow-away protection/interior protection(N26/6)	•	•	0	•	0	•		
ALL	A-Class	176	Body	ATA-ATA[EDW]/tow-away protection/interior protection(N26/6)	•	•	0	•	0	•		
ALL	M-Class	164	Information and communication	ASSYST-Active Service System	•	•	0	•	•	0	0	0001
ALL	GL-Class	X 164	Information and communication	ASSYST-Active Service System	•	•	0	•	•	0	0	0001
ALL	R-Class	251	Information and communication	ASSYST-Active Service System	•	•	0	•	•	0	0	0001
Up to 11/2005	A-Class	169	Information and communication	ASSYST-Active Service System	•	•	0	•	•	0	0	0001
As of 12/2005	A-Class	169	Information and communication	ASSYST-Active Service System	•	•	0	•	•	0	0	0001
Up to 11/2005	B-Class	245	Information and communication	ASSYST-Active Service System	•	•	0	•	•	0	0	0001
As of 12/2005	B-Class	245	Information and communication	ASSYST-Active Service System	•	•	0	•	•	0	0	0001
Up to 05/2005	SLK	171	Information and communication	ASSYST-Active Service System	•	•	0	•	•	0	0	0001
As of 06/2005	SLK	171	Information and communication	ASSYST-Active Service System	•	•	0	•	•	0	0	0001
Up to 05/2005	E-Class	211	Information and communication	ASSYST-Active Service System	•	•	0	•	•	0	0	0001
From 06/2005 to 05/2006	E-Class	211	Information and communication	ASSYST-Active Service System	•	•	0	•	•	0	0	0001
As of 06/2006	E-Class	211	Information and communication	ASSYST-Active Service System	•	•	0	•	•	0	0	0001
Up to 05/2005	CLS	219	Information and communication	ASSYST-Active Service System	•	•	0	•	•	0	0	0001
From 06/2005 to 05/2006	CLS	219	Information and communication	ASSYST-Active Service System	•	•	0	•	•	0	0	0001
As of 06/2006	CLS	219	Information and communication	ASSYST-Active Service System	•	•	0	•	•	0	0	0001
Up to 06/2009	S-Class	221	Information and communication	ASSYST-Active Service System	•	•	•	•	•	•	0	0001
As of 07/2009	S-Class	221	Information and communication	ASSYST-Active Service System	•	•	•	•	•	•	0	0001
ALL	CL	216	Information and communication	ASSYST-Active Service System	•	•	•	•	•	•	0	0001
ALL	M-Class	164	Information and communication	ASSYST PLUS-PLUS Active Service System	•	•	0	•	•	•	0	0002
ALL	GL-Class	X 164	Information and communication	ASSYST PLUS-PLUS Active Service System	•	•	0	•	•	•	0	0002
ALL	R-Class	251	Information and communication	ASSYST PLUS-PLUS Active Service System	•	•	0	•	•	•	0	0002
Up to 11/2005	A-Class	169	Information and communication	ASSYST PLUS-PLUS Active Service System	•	•	0	•	•	•	0	0002

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 12/2005	A-Class	169	Information and communication	ASSYST PLUS-PLUS Active Service System	•	•	0	•	•	•	0	0002
Up to 11/2005	B-Class	245	Information and communication	ASSYST PLUS-PLUS Active Service System	•	•	0	•	•	•	0	0002
As of 12/2005	B-Class	245	Information and communication	ASSYST PLUS-PLUS Active Service System	•	•	0	•	•	•	0	0002
Up to 05/2005	SLK	171	Information and communication	ASSYST PLUS-PLUS Active Service System	•	•	0	•	•	•	0	0002
As of 06/2005	SLK	171	Information and communication	ASSYST PLUS-PLUS Active Service System	•	•	0	•	•	•	0	0002
Up to 05/2005	E-Class	211	Information and communication	ASSYST PLUS-PLUS Active Service System	•	•	•	•	•	•	0	0002
From 06/2005 to 05/2006	E-Class	211	Information and communication	ASSYST PLUS-PLUS Active Service System	•	•	•	•	•	•	0	0002
As of 06/2006	E-Class	211	Information and communication	ASSYST PLUS-PLUS Active Service System	•	•	•	•	•	•	0	0002
Up to 05/2005	CLS	219	Information and communication	ASSYST PLUS-PLUS Active Service System	•	•	•	•	•	•	0	0002
From 06/2005 to 05/2006	CLS	219	Information and communication	ASSYST PLUS-PLUS Active Service System	•	•	•	•	•	•	0	0002
As of 06/2006	CLS	219	Information and communication	ASSYST PLUS-PLUS Active Service System	•	•	•	•	•	•	0	0002
Up to 06/2009	S-Class	221	Information and communication	ASSYST PLUS	•	•	•	•	•	•	0	0002
As of 07/2009	S-Class	221	Information and communication	ASSYST PLUS	•	•	•	•	•	•	0	0002
ALL	CL	216	Information and communication	ASSYST PLUS	•	•	•	•	•	•	0	0002
Up to 08/2003	C-Class	203	Body	WSS-Weight sensing system	•	•	•	•	•	•	0	0005
From 09/2003 to 12/2007	C-Class	203	Body	WSS-Weight sensing system	•	•	•	•	•	•	0	0005
As of 04/2004	CLK	209	Body	WSS-Weight sensing system	•	•	•	•	•	•	0	0005
Up to 05/2005	E-Class	211	Body	WSS-Weight sensing system	•	•	•	•	•	•	0	0005
From 06/2005 to 05/2006	E-Class	211	Body	WSS-Weight sensing system	•	•	•	•	•	•	0	0005
As of 06/2006	E-Class	211	Body	WSS-Weight sensing system	•	•	•	•	•	•	0	0005
	CLS	219	Body	WSS-Weight sensing system	•	•	•	•	•	•	0	0005
From 06/2005 to 05/2006	CLS	219	Body	WSS-Weight sensing system	•	•	•	•	•	•	0	0005
As of 06/2006	CLS	219	Body	WSS-Weight sensing system	•	•	•	•	•	•	0	0005
ALL	M-Class	164	Body	WSS-Weight sensing system	•	•	•	•	•	•	0	0005
ALL	GL-Class		Body	WSS-Weight sensing system	•	•	•	•	•	•	0	0005
ALL	R-Class		Body	WSS-Weight sensing system	•	•	•	•	•	•		0005
Up to 08/2006	MayBach		Body	WSS-Weight sensing system	•	•	•	•	•	0		0005
As of 09/2006	MayBach	240	Body	WSS-Weight sensing system	•	•	•	•	•	0	0	0005
From 09/2003 to 05/2006	SL	230	Body	WSS-Weight sensing system	•	•	•	•	•	0	0	0005

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
From 06/2006 to 02/2008	SL		Body	WSS-Weight sensing system	•	•	•	•	•	0	0	0005
As of 03/2008	SL	230	Body	WSS-Weight sensing system	•	•	•	•	•	0	0	0005
ALL	SLR	199	Body	WSS-Weight sensing system	•	•	•	•	•	0	0	0005
As of 06/2005	SLK	171	Body	WSS-Weight sensing system	•	•	•	•	•	0	0	0005
Up to 06/2009	S-Class	221	Body	WSS-Weight sensing system	•	•	•	•	•	0	0	0005
As of 12/2005	B-Class	245	Body	WSS-Weight sensing system	•	•	•	•	•			
Up to 11/2005	A-Class	169	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•		0003
As of 12/2005	A-Class	169	Information and	AGW-Audio gateway (MOST network management,	•	•	•	•	•	•		0003
Up to 11/2005	B-Class	245	communication Information and	diagnosis gateway, radio tuner) AGW-Audio gateway (MOST network management,			•	•		•		0003
			communication Information and	diagnosis gateway, radio tuner) AGW-Audio gateway (MOST network management,			_	_	-	_		
As of 12/2005	B-Class	245	communication	diagnosis gateway, radio tuner)	•	•	•	•	•	•		0003
Up to 08/2003	C-Class	203	communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•		0003
From 09/2003 to 12/2007	C-Class	203	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•		0003
As of 01/2008	C-Class	203		AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•		0003
As of 04/2004	CLK	209	Information and	AGW-Audio gateway (MOST network management,	•	•	•	•	•	•		0003
Up to 05/2005	E-Class	211	Information and	diagnosis gateway, radio tuner) AGW-Audio gateway (MOST network management,	•	•	•	•	•	•		0003
From 06/2005 to			communication Information and	diagnosis gateway, radio tuner) AGW-Audio gateway (MOST network management,				_				
05/2006	E-Class	211	communication Information and	diagnosis gateway, radio tuner) AGW-Audio gateway (MOST network management,			•	•	•	•		0003
As of 06/2006	E-Class	211	communication	diagnosis gateway, radio tuner)	•	•	•	•	•	•		0003
Up to 05/2005	CLS	219	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•		0003
From 06/2005 to 05/2006	CLS	219	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•		0003
As of 06/2006	CLS	219		AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•		0003
Up to 08/2006	MayBach	240	Information and	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•		0003
As of 09/2006	MayBach	240		AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•		0003
Up to 05/2005	SLK	171		AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•		0003
As of 06/2005	SLK	171	Information and	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•		0003
ALL	M-Class	164	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•		0003
From 09/2006 to 02/2007	G-Class	463 (16-pin diagnostic socket)	Information and	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•		0003

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 03/2007	G-Class	463 (16-pin diagnostic socket)		AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•		0003
ALL	GL-Class	X 164	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•		0003
ALL	R-Class	251	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•		0003
Up to 08/2002	S-Class	220	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•	0	
As of 09/2002	S-Class	220	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•	0	
As of 09/2002	CL	215	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•	0	
From 09/2003 to 05/2006	SL	230	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•	0	
From 06/2006 to 02/2008	SL	230	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•	0	
As of 03/2008	SL	230	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•	0	
Up to 05/2005	E-Class	211	Body	XALWA-L-Xenon headlamp, left	•	•			•		•	
As of 06/2006	E-Class	211	Body	XALWA-L-Xenon headlamp, left	•		•	•	•		•	
ALL	M-Class	164	Body	XALWA-L-Xenon headlamp, left	•	•	•	•	•	•	•	
ALL	GL-Class	X 164	Body	XALWA-L-Xenon headlamp, left	•	•	•	•	•		•	
Up to 05/2005	E-Class	211	Body	XALWA-R-Xenon headlamp, right	•	•	•	•	•	•	•	
As of 06/2006	E-Class	211	Body	XALWA-R-Xenon headlamp, right	•	•	•	•	•	•	•	
ALL	M-Class		Body	XALWA-R-Xenon headlamp, right	•	•	•	•	•	•	•	
ALL	GL-Class		Body	XALWA-R-Xenon headlamp, right	•	•	•	•	•	•	•	
Up to 11/2005	B-Class		Body	XALWA-L-Xenon headlamp, left	•	•	•	•	•	0	•	
As of 12/2005	B-Class		Body	XALWA-L-Xenon headlamp, left	•	•	•	•	•	0	•	
Up to 06/2009	S-Class		Body	XALWA-L-Xenon headlamp, left	•	•	•	•	•	•	*	
ALL	CL		Body	XALWA-L-Xenon headlamp, left	•	•	•	•	•	•	*	
Up to 11/2005	B-Class		Body	XALWA-R-Xenon headlamp, right	•	•	•	•	•	0	•	
As of 12/2005	B-Class		Body	XALWA-R-Xenon headlamp, right	•	•	•	•	•	0	•	
Up to 06/2009	S-Class		Body	XALWA-R-Xenon headlamp, right	•	•	•	•	•	•	*	
ALL	CL		Body	XALWA-R-Xenon headlamp, right	•	•	•	•	•	•	*	
Up to 08/2006	MayBach	240	Information and communication	AVC-Audio video controller	•	•	0	•	•	•	•	
As of 09/2006	MayBach	240	Information and communication	AVC-Audio video controller	•	•	0	•	•	•	•	
ALL	M-Class	164	Information and communication	AVE-H-Rear audio video unit	•	•	•	•	•	•	•	
ALL	GL-Class	X 164	Information and communication	AVE-H-Rear audio video unit	•	•	•	•	•	•	•	
ALL	R-Class	251	Information and communication	AVE-H-Rear audio video unit	•	•	•	•	•	•	•	
Up to 06/2009	S-Class	221	Information and communication	AVE-H-Rear audio video unit	•	•	•	•	•	•	*	

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 07/2009	S-Class	221	Information and communication	AVE-H-Rear audio video unit	•	•	•	•	•	•	*	
Up to 11/2005	A-Class	169	Information and communication	CDC-CD changer	•	•	0	•	•	•	0	
As of 12/2005	A-Class	169	Information and communication	CDC-CD changer	•	•	0	•	•	•	0	
Up to 11/2005	B-Class	245	Information and communication	CDC-CD changer	•	•	0	•	•	•	0	
As of 12/2005	B-Class	245	Information and communication	CDC-CD changer	•	•	0	•	•	•	0	
Up to 08/2003	C-Class	203	Information and communication	CDC-CD changer	•	•	0	•	•	•	0	
From 09/2003 to 12/2007	C-Class	203	Information and communication	CDC-CD changer	•	•	0	•	•	•	0	
As of 01/2008	C-Class	203	Information and	CDC-CD changer	•	•	0	•	•	•	0	
As of 04/2004	CLK	209	Information and communication	CDC-CD changer	•	•	0	•	•	•	0	
Up to 05/2005	E-Class	211	Information and communication	CDC-CD changer	•	•	0	•	•	•	0	
From 06/2005 to 05/2006	E-Class	211	Information and communication	CDC-CD changer	•	•	0	•	•	•	0	
As of 06/2006	E-Class	211	Information and communication	CDC-CD changer	•	•	0	•	•	•	0	
Up to 05/2005	CLS	219	Information and communication	CDC-CD changer	•	•	0	•	•	•	0	
From 06/2005 to 05/2006	CLS	219	Information and communication	CDC-CD changer	•	•	0	•	•	•	0	
As of 06/2006	CLS	219	Information and communication	CDC-CD changer	•	•	0	•	•	•	0	
Up to 08/2002	S-Class	220	Information and communication	CDC-CD changer	•	•	0	•	•	•	0	
As of 09/2002	S-Class	220	Information and communication	CDC-CD changer	•	•	0	•	•	•	0	
As of 09/2002	CL	215	Information and communication	CDC-CD changer	•	•	0	•	•	•	0	
From 09/2003 to 05/2006	SL	230	Information and	CDC-CD changer	•	•	0	•	•	•	0	
From 06/2006 to 02/2008	SL	230	Information and communication	CDC-CD changer	•	•	0	•	•	•	0	
As of 03/2008	SL	230	Information and communication	CDC-CD changer	•	•	0	•	•	•	0	
Up to 05/2005	SLK	171	Information and communication	CDC-CD changer	•	•	0	•	•	•	0	
As of 06/2005	SLK	171	Information and communication	CDC-CD changer	•	•	0	•	•	•	0	
ALL	M-Class	164	Information and communication	CDC-CD changer	•	•	0	•	•	•	0	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	CDC-CD changer	•	•	0	•	•	•	0	
As of 03/2007	G-Class	463 (16-pin diagnostic socket)	Information and communication	CDC-CD changer	•	•	0	•	•	•	0	
ALL	GL-Class	X 164	Information and communication	CDC-CD changer	•	•	0	•	•	•	0	
ALL	R-Class	251	Information and communication	CDC-CD changer	•	•	0	•	•	•	0	
Up to 11/2005	A-Class	169	Information and communication	AGW-Audio gateway or Audio 20 with CD drive	•	•	•	•	•	•		
As of 12/2005	A-Class	169	Information and communication	AGW-Audio gateway or Audio 20 with CD drive	•	•	•	•	•	•		
Up to 11/2005	B-Class	245	Information and communication	AGW-Audio gateway or Audio 20 with CD drive	•	•	•	•	•	•		
As of 12/2005	B-Class	245	Information and communication	AGW-Audio gateway or Audio 20 with CD drive	•	•	•	•	•	•		
Up to 05/2005	E-Class	211	Information and communication	CTEL-Telecommunication for telematics services	•	•	•	•	•	•	0	
From 06/2005 to 05/2006	E-Class	211	Information and communication	CTEL-Telecommunication for telematics services	•	•	•	•	•	•	0	
As of 06/2006	E-Class	211	Information and communication	CTEL-Telecommunication for telematics services	•	•	•	•	•	•	0	
Up to 08/2002	S-Class	220	Information and communication	CTEL-Telecommunication for telematics services	•	•	•	•	•	•	0	
As of 09/2002	S-Class	220	Information and communication	CTEL-Telecommunication for telematics services	•	•	•	•	•	•	0	
As of 09/2002	CL	215	Information and communication	CTEL-Telecommunication for telematics services	•	•	•	•	•	•	0	
Up to 08/2006	MayBach	240	Information and communication	CTEL-Telecommunication for telematics services	•	•	•	•	•	•	0	
As of 09/2006	MayBach	240	Information and communication	CTEL-Telecommunication for telematics services	•	•	•	•	•	•	0	
From 09/2003 to 05/2006	SL	230	Information and communication	CTEL-Telecommunication for telematics services	•	•	•	•	•	•	0	
From 06/2006 to 02/2008	SL	230	Information and communication	CTEL-Telecommunication for telematics services	•	•	•	•	•	•	0	
As of 03/2008	SL	230	Information and communication	CTEL-Telecommunication for telematics services	•	•	•	•	•	•	0	
Up to 05/2005	E-Class	211	Information and communication	Telephone adapter for portable CTEL- Telecommunication for telematics services	•	•	•	•	•	•		
From 06/2005 to 05/2006	E-Class	211	Information and communication	Telephone adapter for portable CTEL- Telecommunication for telematics services	•	•	•	•	•	•		
As of 06/2006	E-Class	211		Telephone adapter for portable CTEL- Telecommunication for telematics services	•	•	•	•	•	•		
Up to 08/2002	S-Class	220	Information and	Telephone adapter for portable CTEL- Telecommunication for telematics services	•	•	•	•	•	•		

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 09/2002	S-Class	220	Information and communication	Telephone adapter for portable CTEL- Telecommunication for telematics services	•	•	•	•	•	•		
As of 09/2002	CL	215	Information and communication	Telephone adapter for portable CTEL- Telecommunication for telematics services	•	•	•	•	•	•		
Up to 08/2006	MayBach	240	Information and communication	Telephone adapter for portable CTEL- Telecommunication for telematics services	•	•	•	•	•	•		
As of 09/2006	MayBach	240	Information and communication	Telephone adapter for portable CTEL- Telecommunication for telematics services	•	•	•	•	•	•		
From 09/2003 to 05/2006	SL	230	Information and communication	Telephone adapter for portable CTEL- Telecommunication for telematics services	•	•	•	•	•	•		
From 06/2006 to 02/2008	SL	230	Information and communication	Telephone adapter for portable CTEL- Telecommunication for telematics services	•	•	•	•	•	•		
As of 03/2008	SL	230	Information and communication	Telephone adapter for portable CTEL- Telecommunication for telematics services	•	•	•	•	•	•		
Up to 08/2006	MayBach	240	Information and communication	CDC-CD changer(REAR)	•	•	0	•	•	•	0	
As of 09/2006	MayBach	240	Information and communication	CDC-CD changer(REAR)	•	•	0	•	•	•	0	
Up to 08/2006	MayBach	240	Information and communication	TV-TV tuner(REAR)	•	•	0	•	•	•		
As of 09/2006	MayBach	240	Information and communication	TV-TV tuner(REAR)	•	•	0	•	•	•		
Up to 05/2005	E-Class	211	Information and communication	GPS box	•	•	0	•	•	•	0	
From 06/2005 to 05/2006	E-Class	211	Information and communication	GPS box	•	•	0	•	•	•	0	
As of 06/2006	E-Class	211	Information and communication	GPS box	•	•	0	•	•	•	0	
Up to 05/2005	CLS	219	Information and communication	GPS box	•	•	0	•	•	•	0	
From 06/2005 to 05/2006	CLS	219	Information and communication	GPS box	•	•	0	•	•	•	0	
As of 06/2006	CLS	219	Information and communication	GPS box	•	•	0	•	•	•	0	
Up to 08/2002	S-Class	220	Information and communication	GPS box	•	•	0	•	•	•	0	
As of 09/2002	S-Class	220	Information and communication	GPS box	•	•	0	•	•	•	0	
As of 09/2002	CL	215	Information and communication	GPS box	•	•	0	•	•	•	0	
Up to 08/2006	MayBach	240	Information and communication	GPS box	•	•	0	•	•	•	0	
As of 09/2006	MayBach	240	Information and communication	GPS box	•	•	0	•	•	•	0	
Up to 05/2005	SLK	171	Information and communication	GPS box	•	•	0	•	•	•	0	
As of 06/2005	SLK	171	Information and communication	GPS box	•	•	0	•	•	•	0	

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
Up to 11/2005	A-Class	169	Information and communication	AUDIO	•	•	•	•	•	•		0003
As of 12/2005	A-Class	169	Information and communication	AUDIO	•	•	•	•	•	•		0003
Up to 11/2005	B-Class	245	Information and communication	AUDIO	•	•	•	•	•	•		0003
As of 12/2005	B-Class	245	Information and communication	AUDIO	•	•	•	•	•	•		0003
Up to 08/2003	C-Class	203	Information and communication	AUDIO	•	•	•	•	•	•		0003
From 09/2003 to 12/2007	C-Class	203	Information and communication	AUDIO	•	•	•	•	•	•		0003
As of 01/2008	C-Class	203	Information and communication	AUDIO	•	•	•	•	•	•		0003
As of 04/2004	CLK	209	Information and communication	AUDIO	•	•	•	•	•	•		0003
Up to 05/2005	E-Class	211	Information and communication	AUDIO	•	•	•	•	•	•		0003
From 06/2005 to 05/2006	E-Class	211	Information and communication	AUDIO	•	•	•	•	•	•		0003
As of 06/2006	E-Class	211	Information and communication	AUDIO	•	•	•	•	•	•		0003
Up to 05/2005	CLS	219	Information and communication	AUDIO	•	•	•	•	•	•		0003
From 06/2005 to 05/2006	CLS	219	Information and communication	AUDIO	•	•	•	•	•	•		0003
As of 06/2006	CLS	219	Information and communication	AUDIO	•	•	•	•	•	•		0003
Up to 08/2002	S-Class	220	Information and communication	AUDIO	•	•	•	•	•	•		0003
As of 09/2002	S-Class	220	Information and communication	AUDIO	•	•	•	•	•	•		0003
As of 09/2002	CL	215	Information and communication	AUDIO	•	•	•	•	•	•		0003
Up to 08/2006	MayBach	240	Information and communication	AUDIO	•	•	•	•	•	•		0003
As of 09/2006	MayBach	240	Information and communication	AUDIO	•	•	•	•	•	•		0003
From 09/2003 to 05/2006	SL	230	Information and communication	AUDIO	•	•	•	•	•	•		0003
From 06/2006 to 02/2008	SL	230	Information and communication	AUDIO	•	•	•	•	•	•		0003
As of 03/2008	SL	230	Information and communication	AUDIO	•	•	•	•	•	•		0003
Up to 05/2005	SLK	171	Information and communication	AUDIO	•	•	•	•	•	•		0003
As of 06/2005	SLK	171	Information and communication	AUDIO	•	•	•	•	•	•		0003

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	M-Class	164	Information and communication	AUDIO	•	•	•	•	•	•		0003
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	AUDIO	•	•	•	•	•	•		0003
As of 03/2007	G-Class	463 (16-pin diagnostic socket)	Information and communication	AUDIO	•	•	•	•	•	•		0003
ALL	GL-Class	X 164	Information and communication	AUDIO	•	•	•	•	•	•		0003
ALL	R-Class	251	Information and communication	AUDIO	•	•	•	•	•	•		0003
Up to 11/2005	A-Class	169	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•		0003
As of 12/2005	A-Class	169	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•		0003
Up to 11/2005	B-Class	245	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•		0003
As of 12/2005	B-Class	245	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•		0003
Up to 08/2003	C-Class	203	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•		0003
From 09/2003 to 12/2007	C-Class	203	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•		0003
As of 01/2008	C-Class	203	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•		0003
As of 04/2004	CLK	209	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•		0003
Up to 05/2005	E-Class	211	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•		0003
From 06/2005 to 05/2006	E-Class	211	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•		0003
As of 06/2006	E-Class	211	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•		0003
Up to 05/2005	CLS	219	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•		0003
From 06/2005 to 05/2006	CLS	219	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•		0003
As of 06/2006	CLS	219	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•		0003
Up to 05/2005	SLK	171	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•		0003
As of 06/2005	SLK	171		AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•		0003
ALL	M-Class	164	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•		0003

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•		0003
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•		0003
ALL	GL-Class	X 164	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•		0003
ALL	R-Class	251	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	•	•	•	•	•	•		0003
Up to 11/2005	A-Class	169	Information and communication	COMAND or AUDIO	•	•	0	•	•	•		
As of 12/2005	A-Class	169	Information and communication	COMAND or AUDIO	•	•	0	•	•	•		
Up to 11/2005	B-Class	245	Information and communication	COMAND or AUDIO	•	•	0	•	•	•		
As of 12/2005	B-Class	245	Information and communication	COMAND or AUDIO	•	•	0	•	•	•		
Up to 08/2003	C-Class	203	Information and communication	COMAND or AUDIO	•	•	0	•	•	•		
From 09/2003 to 12/2007	C-Class	203	Information and communication	COMAND or AUDIO	•	•	0	•	•	•		
As of 01/2008	C-Class	203	Information and communication	COMAND or AUDIO	•	•	0	•	•	•		
As of 04/2004	CLK	209	Information and communication	COMAND or AUDIO	•	•	0	•	•	•		
Up to 05/2005	E-Class	211	Information and communication	COMAND or AUDIO	•	•	0	•	•	•		
From 06/2005 to 05/2006	E-Class	211	Information and communication	COMAND or AUDIO	•	•	0	•	•	•		
As of 06/2006	E-Class	211	Information and communication	COMAND or AUDIO	•	•	0	•	•	•		
Up to 05/2005	CLS	219	Information and communication	COMAND or AUDIO	•	•	0	•	•	•		
From 06/2005 to 05/2006	CLS	219	Information and communication	COMAND or AUDIO	•	•	0	•	•	•		
As of 06/2006	CLS	219	Information and communication	COMAND or AUDIO	•	•	0	•	•	•		
Up to 08/2002	S-Class	220	Information and communication	COMAND or AUDIO	•	•	0	•	•	•		
As of 09/2002	S-Class	220	Information and communication	COMAND or AUDIO	•	•	0	•	•	•		
As of 09/2002	CL	215	Information and communication	COMAND or AUDIO	•	•	0	•	•	•		
Up to 08/2006	MayBach	240	Information and communication	COMAND or AUDIO	•	•	0	•	•	•		
As of 09/2006	MayBach	240	Information and communication	COMAND or AUDIO	•	•	0	•	•	•		

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
Up to 05/2005	SLK	171	Information and communication	COMAND or AUDIO	•	•	0	•	•	•		
As of 06/2005	SLK	171	Information and communication	COMAND or AUDIO	•	•	0	•	•	•		
ALL	M-Class	164	Information and communication	COMAND or AUDIO	•	•	0	•	•	•		
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	COMAND or AUDIO	•	•	0	•	•	•		
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	COMAND or AUDIO	•	•	0	•	•	•		
ALL	GL-Class	X 164	Information and communication	COMAND or AUDIO	•	•	0	•	•	•		
ALL	R-Class	251	Information and communication	COMAND or AUDIO	•	•	0	•	•	•		
Up to 11/2005	B-Class	245	Information and communication	TELE AID-Control unit	•	•	•	•	•	•	0	
As of 12/2005	B-Class	245	Information and communication	TELE AID-Control unit	•	•	•	•	•	•	0	
ALL	C-Class	204	Information and communication	TELE AID-Control unit	•	•	•	•	•	•	0	
Up to 08/2003	C-Class	203	Information and communication	TELE AID-Control unit	•	•	•	•	•	•	0	
From 09/2003 to 12/2007	C-Class	203	Information and communication	TELE AID-Control unit	•	•	•	•	•	•	0	
Up to 03/2004	CLK	209	Information and communication	TELE AID-Control unit	•	•	•	•	•	•	0	
As of 04/2004	CLK	209	Information and communication	TELE AID-Control unit	•	•	•	•	•	•	0	
Up to 05/2005	E-Class	211	Information and communication	TELE AID-Control unit	•	•	•	•	•	•	0	
From 06/2005 to 05/2006	E-Class	211	Information and communication	TELE AID-Control unit	•	•	•	•	•	•	0	
As of 06/2006	E-Class	211	Information and communication	TELE AID-Control unit	•	•	•	•	•	•	0	
Up to 05/2005	CLS	219	Information and communication	TELE AID-Control unit	•	•	•	•	•	•	0	
From 06/2005 to 05/2006	CLS	219	Information and communication	TELE AID-Control unit	•	•	•	•	•	•	0	
As of 06/2006	CLS	219	Information and communication	TELE AID-Control unit	•	•	•	•	•	•	0	
ALL	CLS	218	Information and communication	TELE AID-Control unit	•	•	•	•	•	•	0	
Up to 06/2009	S-Class	221	Information and communication	TELE AID-Control unit	•	•	•	•	•	•	0	
As of 07/2009	S-Class	221	Information and communication	TELE AID-Control unit	•	•	•	•	•	•	0	

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
Up to 08/2002	S-Class	220	Information and communication	TELE AID-Control unit	•	•	•	•	•	•	0	
As of 09/2002	S-Class	220	Information and communication	TELE AID-Control unit	•	•	•	•	•	•	0	
ALL	CL	216	Information and communication	TELE AID-Control unit	•	•	•	•	•	•	0	
As of 09/2002	CL	215	Information and communication	TELE AID-Control unit	•	•	•	•	•	•	0	
Up to 08/2006	MayBach	240	Information and communication	TELE AID-Control unit	•	•	•	•	•	•	0	
As of 09/2006	MayBach	240	Information and communication	TELE AID-Control unit	•	•	•	•	•	•	0	
From 09/2003 to 05/2006	SL	230	Information and communication	TELE AID-Control unit	•	•	•	•	•	•	0	
From 06/2006 to 02/2008	SL	230	Information and communication	TELE AID-Control unit	•	•	•	•	•	•	0	
As of 03/2008	SL	230	Information and communication	TELE AID-Control unit	•	•	•	•	•	•	0	
Up to 05/2005	SLK	171	Information and communication	TELE AID-Control unit	•	•	•	•	•	•	0	
As of 06/2005	SLK	171	Information and communication	TELE AID-Control unit	•	•	•	•	•	•	0	
ALL	SLK	172	Information and communication	TELE AID-Control unit	•	•	•	•	•	•	0	
ALL	GLK	X204	Information and communication	TELE AID-Control unit	•	•	•	•	•	•	0	
ALL	M-Class	164	Information and communication	TELE AID-Control unit	•	•	•	•	•	•	0	
ALL	M-Class	166	Information and communication	TELE AID-Control unit	•	•	•	•	•	•	0	
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	TELE AID-Control unit	•	•	•	•	•	•	0	
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	TELE AID-Control unit	•	•	•	•	•	•	0	
ALL	GL-Class	X 164	Information and communication	TELE AID-Control unit	•	•	•	•	•	•	0	
ALL	R-Class	251	Information and communication	TELE AID-Control unit	•	•	•	•	•	•	0	
ALL	E-Class	212	Information and communication	TELE AID-Control unit	•	•	•	•	•	•	0	
ALL	E-Class	207	Information and communication	TELE AID-Control unit	•	•	•	•	•	•	0	
ALL	SLS	197	Information and communication	TELE AID-Control unit	•	•	•	•	•	•	0	
Up to 11/2005	B-Class	245	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•	0	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 12/2005	B-Class	245	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•	0	
ALL	C-Class	204	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•	0	
Up to 08/2003	C-Class	203	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•	0	
From 09/2003 to 12/2007	C-Class	203	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•	0	
Up to 03/2004	CLK	209	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•	0	
As of 04/2004	CLK	209	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•	0	
Up to 05/2005	E-Class	211	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•	0	
From 06/2005 to 05/2006	E-Class	211	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•	0	
As of 06/2006	E-Class	211	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•	0	
Up to 05/2005	CLS	219	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•	0	
From 06/2005 to 05/2006	CLS	219	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•	0	
As of 06/2006	CLS	219	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•	0	
ALL	CLS	218	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•	0	
Up to 06/2009	S-Class	221	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•	0	
As of 07/2009	S-Class	221	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•	0	
Up to 08/2002	S-Class	220	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•	0	
As of 09/2002	S-Class	220	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•	0	
ALL	CL	216	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•	0	
As of 09/2002	CL	215	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•	0	
Up to 08/2006	MayBach	240	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•	0	
As of 09/2006	MayBach	240	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•	0	
From 09/2003 to 05/2006	SL	230	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•	0	
From 06/2006 to 02/2008	SL	230	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•	0	
As of 03/2008	SL	230	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•	_	•	0	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
Up to 05/2005	SLK	171	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•	0	
As of 06/2005	SLK	171	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•	0	
ALL	SLK	172	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•	0	
ALL	GLK	X204	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•	0	
ALL	M-Class	164	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•	0	
ALL	M-Class	166	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•	0	
From 09/2006 to 02/2007	G-Class	463 (16-pin diagnostic socket)	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•	0	
As of 03/2007	G-Class	463 (16-pin diagnostic socket)	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•	0	
ALL	GL-Class	X 164	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•	0	
ALL	R-Class	251	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•	0	
ALL	E-Class	212	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•	0	
ALL	E-Class	207	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•	0	
ALL	SLS	197	Information and communication	TELE AID-Telematic services Emergency call	•	•	•	•		•	0	
Up to 11/2005	B-Class	245	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•	0	
As of 12/2005	B-Class	245	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•	0	
ALL	C-Class	204	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•	0	
Up to 08/2003	C-Class	203		TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•	0	
From 09/2003 to 12/2007	C-Class	203	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•	0	
Up to 03/2004	CLK	209	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•	0	
As of 04/2004	CLK	209	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•	0	
Up to 05/2005	E-Class	211	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•	0	
From 06/2005 to 05/2006	E-Class	211		TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•	0	
As of 06/2006	E-Class	211	Information and	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•	0	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
Up to 05/2005	CLS	219	Information and	TELE AID-Telematic services Remote door	•	•	•	•		•	0	
From 06/2005 to	CLS	219	communication Information and	unlocking, Remote door locking TELE AID-Telematic services Remote door	•	•	•	•		•	0	
05/2006 As of 06/2006	CLS	219	communication Information and	unlocking, Remote door locking TELE AID-Telematic services Remote door	•	•	•	•		•	0	
ALL	CLS	218	communication Information and	unlocking, Remote door locking TELE AID-Telematic services Remote door	•	•	•	•		•	0	
Up to 06/2009	S-Class	221	communication Information and	unlocking, Remote door locking TELE AID-Telematic services Remote door			•	•		•	0	
As of 07/2009	S-Class	221	communication Information and	unlocking, Remote door locking TELE AID-Telematic services Remote door	•		•	•		•	0	
Up to 08/2002	S-Class	220	communication Information and	unlocking, Remote door locking TELE AID-Telematic services Remote door			•	•		•	0	
As of 09/2002	S-Class	220	communication Information and	unlocking, Remote door locking TELE AID-Telematic services Remote door				•		•	0	
ALL	CL CL	216	communication Information and	unlocking, Remote door locking TELE AID-Telematic services Remote door				•		•	0	
As of 09/2002	CL	215	communication Information and	unlocking, Remote door locking TELE AID-Telematic services Remote door				•		•	0	
			communication Information and	unlocking, Remote door locking TELE AID-Telematic services Remote door	_			•		•	0	
Up to 08/2006	MayBach	240	communication Information and	unlocking, Remote door locking TELE AID-Telematic services Remote door		-						
As of 09/2006 From 09/2003 to	MayBach	240	communication Information and	unlocking, Remote door locking TELE AID-Telematic services Remote door	•	•	•	•		•	0	
05/2006 From 06/2006 to	SL	230	communication Information and	unlocking, Remote door locking TELE AID-Telematic services Remote door	•	•	•	•		•	0	
02/2008	SL	230	communication Information and	unlocking, Remote door locking TELE AID-Telematic services Remote door	•	•	•	•		•	0	
As of 03/2008	SL	230	communication Information and	unlocking, Remote door locking TELE AID-Telematic services Remote door	•	•	•	•		•	0	
Up to 05/2005	SLK	171	communication Information and	unlocking, Remote door locking TELE AID-Telematic services Remote door	•	•	•	•		•	0	
As of 06/2005	SLK	171	communication	unlocking, Remote door locking TELE AID-Telematic services Remote door	•	•	•	•		•	0	
ALL	SLK	172	communication	unlocking, Remote door locking TELE AID-Telematic services Remote door	•	•	•	•		•	0	
	GLK	X204	communication and Information and	unlocking, Remote door locking TELE AID-Telematic services Remote door	•	•	•	•		•	0	
ALL	M-Class	164	communication and Information and	unlocking, Remote door locking TELE AID-Telematic services Remote door	•	•	•	•		•	0	
ALL	M-Class	166 463(16-pin	communication	unlocking, Remote door locking	•	•	•	•		•	0	
From 09/2006 to 02/2007	G-Class	diagnostic socket)	Information and communication	TELE AID-Telematic services Remote door unlocking,Remote door locking	•	•	•	•		•	0	
As of 03/2007	G-Class	463 (16-pin diagnostic socket)	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•	0	

Vadal waar	Model	Model	Control Unit	Custom Name	Ecu	Read	Event	Erase	Live	Freeze	Active	Cresial Function
Model year	Model	Series	Groups	System Name	Info.	Codes	Memory	Codes	Data	Frame	Test	Special Function
ALL	GL-Class	X 164	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•	0	
ALL	R-Class	251	Information and	TELE AID-Telematic services Remote door				•		•	0	
ALL	It Class	201	communication	unlocking, Remote door locking								
ALL	E-Class	212	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	•	•	•	•		•	0	
ALL	E-Class	207	Information and	TELE AID-Telematic services Remote door	•	•	•	•		•	0	
TIDE	L Class	201	communication	unlocking, Remote door locking TELE AID-Telematic services Remote door		_						
ALL	SLS	197	Information and communication	unlocking, Remote door locking	•	•	•	•		•	0	
Up to 11/2005	B-Class	245	Information and	TELE AID-Telematic services MB Info,Roadside	•	•	•	•		•	0	
op 00 11, 2000	2 01405	- 10	communication	assistance(USA, Canada), Tele diagnosis(ECE)		<u> </u>						
As of 12/2005	B-Class	245	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•	0	
ATT	C-Class	204	Information and	TELE AID-Telematic services MB Info, Roadside				•		•	0	
ALL	C-Class	204	communication	assistance(USA, Canada),Tele diagnosis(ECE)			•				O	
Up to 08/2003	C-Class	203	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•	0	
From 09/2003 to	C C1	000	Information and	TELE AID-Telematic services MB Info, Roadside								
12/2007	C-Class	203	communication	assistance(USA, Canada),Tele diagnosis(ECE)	•	•		•		•	0	
Up to 03/2004	CLK	209		TELE AID-Telematic services MB Info, Roadside	•	•	•	•		•	0	
•			communication	assistance(USA, Canada), Tele diagnosis(ECE) TELE AID-Telematic services MB Info, Roadside								
As of $04/2004$	CLK	209	Information and communication	assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•	0	
V 05 (0005	D 01	011		TELE AID-Telematic services MB Info, Roadside		_						
Up to 05/2005	E-Class	211	communication	assistance(USA, Canada),Tele diagnosis(ECE)		•	•	•		•	0	
From 06/2005 to	E-Class	211	Information and	TELE AID-Telematic services MB Info, Roadside	•		•	•			0	
05/2006			communication	assistance(USA, Canada), Tele diagnosis(ECE)							_	
As of 06/2006	E-Class	211	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•	0	
	ar a	0.1.0		TELE AID-Telematic services MB Info, Roadside							0	
Up to 05/2005	CLS	219	communication	assistance(USA, Canada),Tele diagnosis(ECE)		•	•	•		•	0	
From $06/2005$ to	CLS	219	Information and	TELE AID-Telematic services MB Info, Roadside				•		•	0	
05/2006	OLO	213	communication	assistance(USA, Canada), Tele diagnosis(ECE)								
As of 06/2006	CLS	219	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•	0	
ALL	CLS	218		TELE AID-Telematic services MB Info, Roadside			•	•		•	0	
ALL .	CLS	210	communication	assistance(USA, Canada), Tele diagnosis(ECE)		_					0	
Up to 06/2009	S-Class	221	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•	0	
As of 07/2009	C C1	221	Information and	TELE AID-Telematic services MB Info, Roadside								
AS 01 07/2009	S-Class	221	communication	assistance(USA, Canada),Tele diagnosis(ECE)		_	•	•		•	0	
Up to 08/2002	S-Class	220	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•	0	
			Information and	TELE AID-Telematic services MB Info, Roadside								
As of 09/2002	S-Class	220		assistance(USA, Canada), Tele diagnosis(ECE)	•		•	•		•	0	
ALL	CL	216	Information and	TELE AID-Telematic services MB Info, Roadside	•	_		•		•	0	
INDL	CL	210	communication	assistance(USA, Canada), Tele diagnosis(ECE)							)	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 09/2002	CL	215	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•	0	
Up to 08/2006	MayBach	240	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•	0	
As of 09/2006	MayBach	240	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•	0	
From 09/2003 to 05/2006	SL	230		TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•	0	
From 06/2006 to 02/2008	SL	230	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•	0	
As of 03/2008	SL	230	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•	0	
Up to 05/2005	SLK	171	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•	0	
As of 06/2005	SLK	171	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•	0	
ALL	SLK	172	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	•	•	•	•		•	0	
ALL	GLK	X204	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	•	•	•	•		•	0	
ALL	M-Class	164	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	•	•	•	•		•	0	
ALL	M-Class	166	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•	0	
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	•	•	•	•		•	0	
As of 03/2007	G-Class	463 (16-pin diagnostic socket)	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•	0	
ALL	GL-Class	X 164	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•	0	
ALL	R-Class	251	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	•	•	•	•		•	0	
ALL	E-Class	212	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	•	•	•	•		•	0	
ALL	E-Class	207	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	•	•	•	•		•	0	
ALL	SLS	197	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	•	•	•	•		•	0	
Up to 11/2005	B-Class	245	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•	0	
As of 12/2005	B-Class	245	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•	0	
ALL	C-Class	204	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•	0	
Up to 08/2003	C-Class	203		TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•	0	

		Mode1	Control Unit		Ecu	Read	Event	Erase	Live	Freeze	Astivo	
Model year	Model	Series	Groups	System Name	Info.	Codes	Memory	Codes	Data	Frame	Active Test	Special Function
From 09/2003 to	C-Class	203		TELE AID-Telematic services Stolen vehicle	•	•	•	•		•	0	
12/2007	CY V	200	communication Information and	tracking TELE AID-Telematic services Stolen vehicle								
Up to 03/2004	CLK	209	communication	tracking	•	•	•	•		•	0	
As of 04/2004	CLK	209	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•	0	
Up to 05/2005	E-Class	211	Information and	TELE AID-Telematic services Stolen vehicle	•	•	•	•		•	0	
From 06/2005 to			communication Information and	tracking TELE AID-Telematic services Stolen vehicle		_	_	_		_		
05/2006	E-Class	211	communication	tracking	•	•	•	•		•	0	
As of 06/2006	E-Class	211	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•	0	
Up to 05/2005	CLS	219		TELE AID-Telematic services Stolen vehicle			•	•		•	0	
From 06/2005 to	СДО	213	communication Information and	tracking TELE AID-Telematic services Stolen vehicle								
05/2006	CLS	219	communication	tracking	•	•	•	•		•	0	
As of 06/2006	CLS	219	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•	0	
ALL	CLS	218	Information and	TELE AID-Telematic services Stolen vehicle			•	•		•	0	
	020	210	communication	tracking							0	
Up to 06/2009	S-Class	221	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•	0	
As of 07/2009	S-Class	221		TELE AID-Telematic services Stolen vehicle	•	•	•	•		•	0	
Up to 08/2002	S-Class	220	communication Information and	tracking TELE AID-Telematic services Stolen vehicle				•		•	0	
Up to 08/2002	5-Class	220	communication	tracking	_	_		•		•	0	
As of 09/2002	S-Class	220	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•	0	
ALL	CL	216	Information and	TELE AID-Telematic services Stolen vehicle	•	•	•	•		•	0	
			communication Information and	tracking TELE AID-Telematic services Stolen vehicle								
As of 09/2002	CL	215	communication	tracking	•	•	•	•		•	0	
Up to 08/2006	MayBach	240	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•	0	
As of 09/2006	MayBach	240		TELE AID-Telematic services Stolen vehicle				•		•	0	
	маурасп	240		tracking TELE AID-Telematic services Stolen vehicle						_	0	
From 09/2003 to 05/2006	SL	230	communication	tracking	•	•	•	•		•	0	
From 06/2006 to 02/2008	SL	230	Information and communication	TELE AID-Telematic services Stolen vehicle	•	•	•	•		•	0	
02/2008 As of 03/2008	SL	230	Information and	tracking TELE AID-Telematic services Stolen vehicle			•	•		•	0	
ns 01 03/2000	OL	200	communication Information and	tracking TELE AID-Telematic services Stolen vehicle							)	
Up to 05/2005	SLK	171	communication	tracking	•	•	•	•		•	0	
As of 06/2005	SLK	171	Information and	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•	0	
ATT	CIV	179	communication Information and	TELE AID-Telematic services Stolen vehicle								
ALL	SLK	172	communication	tracking			•	•		•	0	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	GLK	X204	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•	0	
ALL	M-Class	164	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•	0	
ALL	M-Class	166	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•	0	
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•	0	
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•	0	
ALL	GL-Class	X 164	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•	0	
ALL	R-Class	251	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•	0	
ALL	E-Class	212	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•	0	
ALL	E-Class	207	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•	0	
ALL	SLS	197	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	•	•	•	•		•	0	
Up to 11/2005	B-Class	245	Information and communication	NAVI-Navigation system	•	•	•	•	•	•	•	
As of 12/2005	B-Class	245	Information and communication	NAVI-Navigation system	•	•	•	•	•	•	•	
Up to 08/2003	C-Class	203	Information and communication	NAVI-Navigation system	•	•	•	•	•	•	•	
From 09/2003 to 12/2007	C-Class	203	Information and communication	NAVI-Navigation system	•	•	•	•	•	•	•	
As of 04/2004	CLK	209	Information and communication	NAVI-Navigation system	•	•	•	•	•	•	•	
ALL	M-Class	164	Information and communication	NAVI-Navigation system	•	•	•	•	•	•	•	
From 09/2006 to 02/2007	G-Class	socket)	Information and communication	NAVI-Navigation system	•	•	•	•	•	•	•	
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	NAVI-Navigation system	•	•	•	•	•	•	•	
ALL	GL-Class	X 164	Information and communication	NAVI-Navigation system	•	•	•	•	•	•	•	
ALL	R-Class	251	Information and communication	NAVI-Navigation system	•	•	•	•	•	•	•	
As of 01/2008	C-Class	203	Information and communication	NAVI-Navigation system	•	•	0	•	•	•		
Up to 05/2005	E-Class	211	Information and communication	NAVI-Navigation system	•	•	0	•	•	•		

Model year	Mode1	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
From 06/2005 to 05/2006	E-Class	211	Information and communication	NAVI-Navigation system	•	•	0	•	•	•		
As of 06/2006	E-Class	211	Information and communication	NAVI-Navigation system	•	•	0	•	•	•		
Up to 05/2005	CLS	219	Information and communication	NAVI-Navigation system	•	•	0	•	•	•		
From 06/2005 to 05/2006	CLS	219	Information and communication	NAVI-Navigation system	•	•	0	•	•	•		
As of 06/2006	CLS	219	Information and communication	NAVI-Navigation system	•	•	0	•	•	•		
Up to 08/2002	S-Class	220	Information and communication	NAVI-Navigation system	•	•	0	•	•	•		
As of 09/2002	S-Class	220	Information and communication	NAVI-Navigation system	•	•	0	•	•	•		
As of 09/2002	CL	215	Information and communication	NAVI-Navigation system	•	•	0	•	•	•		
Up to 08/2006	MayBach	240	Information and communication	NAVI-Navigation system	•	•	0	•	•	•		
As of 09/2006	MayBach	240	Information and communication	NAVI-Navigation system	•	•	0	•	•	•		
From 09/2003 to 05/2006	SL	230	Information and communication	NAVI-Navigation system	•	•	0	•	•	•		
From 06/2006 to 02/2008	SL	230	Information and communication	NAVI-Navigation system	•	•	0	•	•	•		
As of 03/2008	SL	230	Information and communication	NAVI-Navigation system	•	•	0	•	•	•		
Up to 05/2005	SLK	171	Information and communication	NAVI-Navigation system	•	•	0	•	•	•		
As of 06/2005	SLK	171	Information and communication	NAVI-Navigation system	•	•	0	•	•	•		
Up to 08/2006	MayBach	240	Information and communication	KTL-Left headphone transmitter	•	•	0	•	•	0		
As of 09/2006	MayBach	240	Information and communication	KTL-Left headphone transmitter	•	•	0	•	•	0		
Up to 08/2006	MayBach	240	Information and communication	KTR-Right headphone transmitter	•	•	0	•	•	0		
As of 09/2006	MayBach	240	Information and communication	KTR-Right headphone transmitter	•	•	0	•	•	0		
Up to 11/2005	A-Class	169	Information and communication	VCS-Voice control system	•	•	0	•		•		
As of 12/2005	A-Class	169	Information and communication	VCS-Voice control system	•	•	0	•		•		
Up to 11/2005	B-Class	245	Information and communication	VCS-Voice control system	•	•	0	•		•		
As of 12/2005	B-Class	245	Information and communication	VCS-Voice control system	•	•	0	•		•		
Up to 08/2003	C-Class	203	Information and communication	VCS-Voice control system	•	•	0	•		•		

		Mode1	Control Unit		Ecu	Read	Event	Erase	Live	Freeze	Active	a
Model year	Model	Series	Groups	System Name	Info.	Codes	Memory	Codes	Data	Frame	Test	Special Function
From 09/2003 to 12/2007	C-Class	203	Information and communication	VCS-Voice control system	•	•	0	•		•		
As of 01/2008	C-Class	203	Information and communication	VCS-Voice control system	•	•	0	•		•		
As of 04/2004	CLK	209	Information and communication	VCS-Voice control system	•	•	0	•		•		
Up to 05/2005	E-Class	211	Information and communication	VCS-Voice control system	•	•	0	•		•		
From 06/2005 to 05/2006	E-Class	211	Information and communication	VCS-Voice control system	•	•	0	•		•		
As of 06/2006	E-Class	211	Information and communication	VCS-Voice control system	•	•	0	•		•		
Up to 05/2005	CLS	219	Information and communication	VCS-Voice control system	•	•	0	•		•		
From 06/2005 to 05/2006	CLS	219	Information and communication	VCS-Voice control system	•	•	0	•		•		
As of 06/2006	CLS	219	Information and communication	VCS-Voice control system	•	•	0	•		•		
Up to 08/2002	S-Class	220	Information and communication	VCS-Voice control system	•	•	0	•		•		
As of 09/2002	S-Class	220	Information and communication	VCS-Voice control system	•	•	0	•		•		
As of 09/2002	CL	215	Information and communication	VCS-Voice control system	•	•	0	•		•		
Up to 08/2006	MayBach	240	Information and communication	VCS-Voice control system	•	•	0	•		•		
As of 09/2006	MayBach	240	Information and communication	VCS-Voice control system	•	•	0	•		•		
From 09/2003 to 05/2006	SL	230	Information and communication	VCS-Voice control system	•	•	0	•		•		
From 06/2006 to 02/2008	SL	230	Information and communication	VCS-Voice control system	•	•	0	•		•		
As of 03/2008	SL	230	Information and communication	VCS-Voice control system	•	•	0	•		•		
Up to 05/2005	SLK	171	Information and communication	VCS-Voice control system	•	•	0	•		•		
As of 06/2005	SLK	171	Information and	VCS-Voice control system	•	•	0	•		•		
ALL	M-Class	164	Information and communication	VCS-Voice control system	•	•	0	•		•		
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and	VCS-Voice control system	•	•	0	•		•		
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	VCS-Voice control system	•	•	0	•		•		
ALL	GL-Class	X 164	Information and communication	VCS-Voice control system	•	•	0	•		•		

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ALL	R-Class	251	Information and communication	VCS-Voice control system	•	•	0	•		•		
Up to 11/2005	B-Class	245	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•		
As of 12/2005	B-Class	245	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•		
Up to 08/2003	C-Class	203	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•		
From 09/2003 to 12/2007	C-Class	203	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•		
As of 01/2008	C-Class	203	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•		
As of 04/2004	CLK	209	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•		
Up to 05/2005	E-Class	211	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•		
From 06/2005 to 05/2006	E-Class	211	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•		
As of 06/2006	E-Class	211	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•		
Up to 05/2005	CLS	219	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•		
From 06/2005 to 05/2006	CLS	219	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•		
As of 06/2006	CLS	219	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•		
Up to 08/2002	S-Class	220	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•		
As of 09/2002	S-Class	220	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•		
As of 09/2002	CL	215	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•		
Up to 08/2006	MayBach	240	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•		
As of 09/2006	MayBach	240	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•		
From 09/2003 to 05/2006	SL	230	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•		
From 06/2006 to 02/2008	SL	230	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•		
As of 03/2008	SL	230	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•		
Up to 05/2005	SLK	171	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•		
As of 06/2005	SLK	171	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•		
ALL	M-Class	164	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•		

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•		
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•		
ALL	GL-Class	X 164	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•		
ALL	R-Class	251	Information and communication	SDAR-Satellite radio	•	•	0	•	•	•		
Up to 08/2002	S-Class	220	Information and communication	SOUND-Bose sound system	•	•	0	•	•	•		
As of 09/2002	S-Class	220	Information and communication	SOUND-Bose sound system	•	•	0	•	•	•		
As of 09/2002	CL	215	Information and communication	SOUND-Bose sound system	•	•	0	•	•	•		
Up to 08/2006	MayBach	240	Information and communication	SOUND-Bose sound system	•	•	0	•	•	•		
As of 09/2006	MayBach	240	Information and communication	SOUND-Bose sound system	•	•	0	•	•	•		
From 09/2003 to 05/2006	SL	230	Information and communication	SOUND-Bose sound system	•	•	0	•	•	•		
From 06/2006 to 02/2008	SL	230	Information and communication	SOUND-Bose sound system	•	•	0	•	•	•		
As of 03/2008	SL	230	Information and communication	SOUND-Bose sound system	•	•	0	•	•	•		
Up to 11/2005	A-Class	169	Information and communication	SOUND- Sound system	•	•	0	•	•	•		
As of 12/2005	A-Class	169	Information and communication	SOUND- Sound system	•	•	0	•	•	•		
Up to 11/2005	B-Class	245	Information and communication	SOUND- Sound system	•	•	0	•	•	•		
As of 12/2005	B-Class	245	Information and communication	SOUND- Sound system	•	•	0	•	•	•		
Up to 08/2003	C-Class	203	Information and communication	SOUND- Sound system	•	•	0	•	•	•		
From 09/2003 to 12/2007	C-Class	203	communication	SOUND- Sound system	•	•	0	•	•	•		
As of 01/2008	C-Class	203	Information and communication	SOUND- Sound system	•	•	0	•	•	•		
As of 04/2004	CLK	209	Information and communication	SOUND- Sound system	•	•	0	•	•	•		
ALL	M-Class	164	Information and communication	SOUND- Sound system	•	•	0	•	•	•		
From 09/2006 to 02/2007	G-Class	463 (16-pin diagnostic socket)	Information and communication	SOUND- Sound system	•	•	0	•	•	•		

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	SOUND- Sound system	•	•	0	•	•	•		
ALL	GL-Class	X 164	Information and communication	SOUND- Sound system	•	•	0	•	•	•		
ALL	R-Class	251	Information and communication	SOUND- Sound system	•	•	0	•	•	•		
Up to 11/2005	A-Class	169	Information and communication	CTEL-Cellular telephone	•	•	•	•	•	•	0	
As of 12/2005	A-Class	169	Information and communication	CTEL-Cellular telephone	•	•	•	•	•	•	0	
Up to 11/2005	B-Class	245	Information and communication	CTEL-Cellular telephone	•	•	•	•	•	•	0	
As of 12/2005	B-Class	245	Information and communication	CTEL-Cellular telephone	•	•	•	•	•	•	0	
Up to 08/2003	C-Class	203	Information and communication	CTEL-Cellular telephone	•	•	•	•	•	•	0	
From 09/2003 to 12/2007	C-Class	203	Information and communication	CTEL-Cellular telephone	•	•	•	•	•	•	0	
ALL	M-Class	164	Information and communication	CTEL-Cellular telephone	•	•	•	•	•	•	0	
ALL	GL-Class	X 164	Information and communication	CTEL-Cellular telephone	•	•	•	•	•	•	0	
ALL	R-Class	251	Information and communication	CTEL-Cellular telephone	•	•	•	•	•	•	0	
	C-Class	203	Information and communication	TV-TV tuner	•	•	0	•	•	•		
From 09/2003 to 12/2007	C-Class	203	Information and communication	TV-TV tuner	•	•	0	•	•	•		
As of 04/2004	CLK	209	Information and communication	TV-TV tuner	•	•	0	•	•	•		
Up to 05/2005	E-Class	211	Information and communication	TV-TV tuner	•	•	0	•	•	•		
From 06/2005 to 05/2006	E-Class	211	Information and communication	TV-TV tuner	•	•	0	•	•	•		
As of 06/2006	E-Class	211	Information and communication	TV-TV tuner	•	•	0	•	•	•		
Up to 05/2005	CLS	219	Information and communication	TV-TV tuner	•	•	0	•	•	•		
From 06/2005 to 05/2006	CLS	219	Information and communication	TV-TV tuner	•	•	0	•	•	•		
As of 06/2006	CLS	219	Information and communication	TV-TV tuner	•	•	0	•	•	•		
Up to 08/2002	S-Class	220	Information and communication	TV-TV tuner	•	•	0	•	•	•		
As of 09/2002	S-Class	220	Information and communication	TV-TV tuner	•	•	0	•	•	•		

Model year	Mode1	Mode1	Control Unit	Stratom Name	Ecu	Read	Event	Erase	Live	Freeze	Active	Special Function
model year	Model	Series	Groups	System Name	Info.	Codes	Memory	Codes	Data	Frame	Test	Special runction
As of 09/2002	CL	215	Information and communication	TV-TV tuner	•	•	0	•	•	•		
Up to 08/2006	MayBach	240	Information and communication	TV-TV tuner	•	•	0	•	•	•		
As of 09/2006	MayBach	240	Information and communication	TV-TV tuner	•	•	0	•	•	•		
From 09/2003 to 05/2006	SL	230	Information and communication	TV-TV tuner	•	•	0	•	•	•		
From 06/2006 to 02/2008	SL	230	Information and communication	TV-TV tuner	•	•	0	•	•	•		
As of 03/2008	SL	230	Information and communication	TV-TV tuner	•	•	0	•	•	•		
ALL	M-Class	164	Information and communication	TV-TV tuner	•	•	0	•	•	•		
ALL	GL-Class	X 164	Information and communication	TV-TV tuner	•	•	0	•	•	•		
ALL	R-Class	251	Information and communication	TV-TV tuner	•	•	0	•	•	•		
Up to 11/2005	A-Class	169		CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•	0	
As of 12/2005	A-Class	169	Information and communication	CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•	0	
Up to 11/2005	B-Class	245		CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•	0	
As of 12/2005	B-Class	245		CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•	0	
Up to 08/2003	C-Class	203		CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•	0	
From 09/2003 to 12/2007	C-Class	203		CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•	0	
As of 01/2008	C-Class	203		CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•	0	
As of 04/2004	CLK	209		CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•	0	
Up to 05/2005	E-Class	211		CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•	0	
From 06/2005 to 05/2006	E-Class	211		CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•	0	
	E-Class	211		CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•	0	
Up to 05/2005	CLS	219		CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•	0	
From 06/2005 to 05/2006	CLS	219	Information and communication	CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•	0	
As of 06/2006	CLS	219	Information and communication	CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•	0	
Up to 08/2002	S-Class	220		CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•	0	

		Mode1	Control Unit		Ecu	Read	Event	Erase	Live	Freeze	Activo	
Model year	Model	Series	Groups	System Name	Info.	Codes	Event Memory	Codes	Data	Frame	Active Test	Special Function
			Information and	CTEL-Mobile phone adapter with universal								
As of 09/2002	S-Class	220	communication	interface	•	•	•	•	•	•	0	
	O.	0.1.5	Information and	CTEL-Mobile phone adapter with universal					_			
As of 09/2002	CL	215	communication	interface	•	•			•		0	
Up to 08/2006	MayBach	240	Information and	CTEL-Mobile phone adapter with universal			•		•		0	
op to 00/2000	маурасп	240	communication	interface							)	
As of 09/2006	MayBach	240	Information and communication	CTEL-Mobile phone adapter with universal interface	•	•	•	•	•	•	0	
From 09/2003 to			Information and	CTEL-Mobile phone adapter with universal		_	_	_			_	
05/2006	SL	230	communication	interface	•	•	•	•	•	•	0	
From 06/2006 to	SL	230	Information and	CTEL-Mobile phone adapter with universal	•	•	•	•	•	•	0	
02/2008	SL	230	communication	interface							0	
As of 03/2008	SL	230	Information and	CTEL-Mobile phone adapter with universal				•	•	•	0	
115 01 00/ 2000	OL COL	200	communication	interface							0	
Up to 05/2005	SLK	171	Information and	CTEL-Mobile phone adapter with universal	•	•	•	•	•	•	0	
			communication Information and	interface CTEL-Mobile phone adapter with universal								
As of 06/2005	SLK	171	communication	interface	•	•	•	•	•	•	0	
4 7 7	W 01	104	Information and	CTEL-Mobile phone adapter with universal					_			
ALL	M-Class	164	communication	interface	•	•	•		•	•	0	
From 09/2006 to		463(16-pin	Information and	CTEL-Mobile phone adapter with universal								
02/2007	G-Class	diagnostic	communication	interface	•	•	•	•	•	•	0	
02/ 2001		socket)		Three Fuel								
4 6 00 /0007	0.01	463 (16-pin	Information and	CTEL-Mobile phone adapter with universal		١ ـ						
As of 03/2007	G-Class	diagnostic socket)	communication	interface		•	•	•	•	•	0	
			Information and	CTEL-Mobile phone adapter with universal								
ALL	GL-Class	X 164	communication	interface	•	•	•	•	•	•	0	
ATT	D 01	0.51		CTEL-Mobile phone adapter with universal							0	
ALL	R-Class	251	communication	interface		•	•		•		0	
ALL	A-Class	168	Body	AB-Airbag	•	•	0	•		*		
As of 06/97	C-Class	202	Body	AB-Airbag	•	•	0	•		*		
ALL	CLK	208	Body	AB-Airbag	•	•	0	•		*		
	E-Class	210	Body	AB-Airbag	+ •	•	0	•		*		
As of 09/99	SL	129 170(16-pin	Body	AB-Airbag		<del>                                     </del>	0			*		
ALL	SLK	diagnostic		AB-Airbag			0			*		
REE	OLK	socket)	Dody	no nii bag						<i>/</i> •\		
		170 (38-pin										
ALL	SLK	diagnostic		AB-Airbag	•	•	0	•		*		
		socket)										
		463 (38-pin			_							
ALL	G-Class	diagnostic	Body	AB-Airbag	•	•	0	•		*		
A T T	W 01	socket)	D. 1	COW C 1	+-	_						0016 0017 0010
ALL	M-Class	164	Body	CGW-Central gateway	•	•	•	•	0	0		0016 0017 0018
ALL ALL	GL-Class R-Class	X 164 251	Body Body	CGW-Central gateway CGW-Central gateway	•	•	•	•	0	0		0016 0017 0018 0016 0017 0018
	R-Class A-Class	169	Body	CGW-Central gateway CGW-Central gateway	+ -				0	0		0003
op to 11/2000	11 CTG22	100	ьоцу	oon ochulat galeway					$\cup$	$\circ$	$\overline{)}$	0000

Model year	Model	Model	Control Unit	System Name	Ecu	Read	Event	Erase	Live	Freeze	Active	Special Function
		Series	Groups		Info.	Codes	Memory	Codes	Data	Frame	Test	
As of 12/2005	A-Class	169	Body	CGW-Central gateway	•	•	•	•	0	0	0	0003
	B-Class	245	Body	CGW-Central gateway	•	•	•	•	0	0	0	0003
	B-Class	245	Body	CGW-Central gateway	•	•	•	•	0	0	0	0003
Up to 05/2005	SLK	171	Body	CGW-Central gateway	•	•	•	•	•	0	0	0016 0017 0018
As of 06/2005	SLK	171	Body	CGW-Central gateway	•	•	•	•	•	0	0	0016 0017 0018
Up to 08/2003	C-Class	203	Body	CGW-Central gateway	•	•	•	•	•	•	0	0018
From 09/2003 to 12/2007	C-Class	203	Body	CGW-Central gateway	•	•	•	•	•	•	0	0018
		461(16-pin										
ALL	G-Class	diagnostic	Body	CGW-Central gateway	•	•	•	•		•	0	0018
		socket)										
Up to 05/2005	E-Class	211	Body	CGW-Central gateway	•	•	•	•	0	0	0	0016 0017 0018
From 06/2005 to 05/2006	E-Class	211	Body	CGW-Central gateway	•	•	•	•	0	0	0	0016 0017 0018
	E-Class	211	Body	CGW-Central gateway	•	•	•	•	0	0	0	0016 0017 0018
	CLS	219	Body	CGW-Central gateway	•	•	•	•	0	0	0	0016 0017 0018
From 06/2005 to 05/2006	CLS	219	Body	CGW-Central gateway	•	•	•	•	0	0	0	0016 0017 0018
	CLS	219	Body	CGW-Central gateway	•	•	•	•	0	0	0	0016 0017 0018
	S-Class	220	Body	CGW-Central gateway	•	•	•	•	0	0	0	0016 0017 0018
	S-Class	220	Body	CGW-Central gateway	•	•	•	•	0	0	0	0016 0017 0018
As of 09/2002	CL	215	Body	CGW-Central gateway	•	•	•	•	0	0	0	0016 0017 0018
From 09/2003 to 05/2006	SL	230	Body	CGW-Central gateway	•	•	•	•	0	0	0	0016 0017 0018
From 06/2006 to 02/2008	SL	230	Body	CGW-Central gateway	•	•	•	•	0	0	0	0016 0017 0018
As of 03/2008	SL	230	Body	CGW-Central gateway	•	•	•	•	0	0	0	0016 0017 0018
ALL	SLR	199	Body	CGW-Central gateway	•	•	•	•	0	0	0	0016 0017 0018
Up to 06/2009	S-Class	221	Body	CGW-Central gateway	•	•	•	•	0	•	0	0016 0017 0018
As of 07/2009	S-Class	221	Body	CGW-Central gateway	•	•		•	0	•	0	0016 0017 0018
ALL	CL	216	Body	CGW-Central gateway	•	•	•	•	0	•	0	0016 0017 0018
1	MayBach	240	Body	CGW-Central gateway	•	•	•	•	•	0	0	0016 0017 0018
As of 09/2006	MayBach	240	Body	CGW-Central gateway	•	•	•	•	•	0	0	0016 0017 0018
As of 12/2005	A-Class	169	Drive	N93/4 (Vehicle gateway control unit)	•	•	•	•	0	0		
	B-Class	245	Drive	N93/4 (Vehicle gateway control unit)	•	•	•		0	0		
ALL	A-Class	168	Body	HB-Heater booster	•	•	0			*		
As of 06/97	C-Class	202	Body	HB-Heater booster	•	•	0	•		*		
As of 03/97 DAS	E-Class	210	Body	HB-Heater booster	•	•	0			*		



## Special\_Function

index	Specil Function Name	index	Specil Function Name
0001	ASSYST Setting	0023	Teach-in process after replacement of component Diesel particulate filter
0002	Service Reset	0024	Teaching in the diesel particulate filter after replacing the engine control unit
0003	Read coding and change if necessary.	0025	Activate fuel pump
0004	Variant coding	0026	Rapid teach-in of zero quantity calibration
0005	Initial startup	0027	Initial startup of control unit EZS
0006	Deactivate system	0028	Initial startup of control unit ESL
0007	Activate system	0029	Disable key or key track
8000	Customer complaints (without fault codes)	0030	Once again authorize key or key track.
0009	Control unit adaptations	0031	Once again authorize key or key track.
0010	Chassis number	0032	Program replacement keys
0011	Sliding/tilting roof	0033	Activate control module N73 (EIS [EZS] control unit).
0012	Calibration of the torque sensor	0034	Activate control module N26/5 (Electric steering lock control module)
0013	Learning of the throttle valve stop	0035	Key assignment or key track assignment to a memory block number
0014	Road test	0036	Writing of the VIN
0015	Tire pressure loss warner (Activating)	0037	Telematic service 'Remote door unlocking' (TELE AID)
0016	Vehicle data	0038	Brake counter update and recalculate lifetime
	Modification year or model year	0039	Replace hydraulic brake system fluid./Bleed brake system.
0018	All codes	0040	Zero point variation steering angle and lateral acceleration sensor
0019	Replace component Diesel particulate filter	0041	Steering variant
0020	Reprogram diesel particulate filter in control unit N3/9 (CDI control unit)	0042	Pneumatic tests
0021	Teach in component Y94 (Quantity control valve)	0043	Initial test/ Oil condition check/ Oil level
0022	Teaching in the diesel particulate filter after replacing the engine control unit	0044	Diagnosis routines
0045	Calibration of compnent B24/12(ABC lateral acceleration sensor)	0052	Load adjustment
0046	Calibration of the plunger travel sensors	0056	Pneumatic test of component A9/1 (AIRmatic compressor unit)
0047	Erase zero point offset error of component N49 (Steering angle sensor)	0057	Pneumatic test of component A9/1y1 (AIRmatic pressure release valve)
0048	Initial startup with automatic takeover of settings of previous control unit	0058	Replacement of control module N80(Steering column module)
0049	Initial startup with manual settings input for new control unit/Level calibration	0059	Reset compressor operating time
0050	Initializing:Rain sensor, Steering column module	0060	Reset of calibration
0051	Level calibration	0062	Prevention of diesel particulate filter regeneration
0064	Diesel particulate filter New Initializing	0071	Purge control Diesel particulate filter
0065	Diesel particulate filter Purge control	0073	Regeneration of diesel particulate filter
0066	Diesel particulate filter Used Program	0074	Regeneration of diesel particulate filter when driving
0067	Initializing Diesel particulate filter	0075	Replacement of component Diesel particulate filter on left
0077	Teach-in of diesel particulate filter after replacement of engine control unit without transfer of values	0076	Replacement of component Diesel particulate filter on right
0078	Activate function 'Tire pressure loss warning'	0079	Write identification numbers of tire pressure sensors.
0080	Teach in of throttle valve stop	0081	Switch off solenoid valve for torque converter lockup clutch
0082	Actual values of flush counter	0083	Coding according to plant data
0084	Teach in of drive authorization system	0085	Performing sensor rotor adaptation
0086	Resetting of mixture adaptation	0087	Ignition

index	Specil Function Name	index	Specil Function Name
0088	Fuel quantity	0089	Idling specified speed with selector lever in position P or N
0090	Idling specified speed with gear engaged	0091	Electric suction fan for engine or air
0092	Calibration of control unit N30/4 (Electronic Stability Program control unit)-Calibration of separation valves	0093	Read coding
0094	CO setting for vehicles without TWC	0095	Dwell time
0001	-	0000	Initial startup with manual settings input for
0096	Desensibilize shutoff threshold of smooth engine running	0097	new control unit(For example: The previous control unit can no longer be read.)
0098	Display of coding data	0099	Driver authorization
0100	Special settings	0101	Special settings /Control unit is released
0102	Configuration for key 1	0103	Configuration for key 2
0104	Configuration for key 3	0105	Set reading of main odometer
0106	Setting days since initial registration	0107	Customer-specific settings
0108	Calibration of control unit N47-5 (ESP control unit)	0109	Tire pressure loss warner (Activating)
0110	Special functions	0111	Replacement of component A7/3 (Traction system hydraulic unit) and N47-5 (ESP control unit)
0112	Replacement of component B24/15 (Yaw rate, lateral and longitudinal acceleration sebsor)	0113	Replacement of component N47-5(ESP control unit) (Initial startup with manual setting input for control unit)
0114	Bypass Zentralablauf (LIC Erstellerdaten)	0115	special function VIN
0116	Initial startup with manual adjustment of new control unit	0117	calibration of intake valves
0118	calibaration of separation valves	0119	Special settings/Control unit is released
0120	Display coded vehicle data	0121	Special settings/Check parameterization
0122	Bedding in brakes	0123	Replace brake disks
0124	Remove/install brake pads	0125	Remove/installation of parking brake shoes
0126	Replacement of the brake operating unit(BOU)	0127	Rpm sensor
0128	Exchange of hydraulic unit	0129	Exchange of brake calipers
0130	After opening or replacing one or more brake	0131	After opening or replacing one or more brake
	lines		hoses
0132	Exchange of brake disks	0133	Replace brake system pressure reservoir
0134	Special function2	0135	Erase zero point offset error of component B24/15 (Micromechanical yaw rate sensor AY pickup)
0136	Calibration of control unit N30/4 (Electronic Stability Program control unit)-Calibration of intake valves	0137	Special function1
0138	Replacement of component N30/4 (Electronic Stability Program control unit) (Initial startup with automatic takeover of settings of previous control unit)	0139	Replacement of component N30/4 (Electronic Stability Program control unit) (Initial startup with manual settings input for new control unit/Level calibration)
0140	Replacement of components A7/3 (Traction system hydraulic unit) and N30/4 (Electronic Stability Program control unit)	0141	Replacement of component B24/15 (Yaw rate, lateral and longitudinal acceleration sensor)
0142	Standstill test	0143	Hill Start Assist(Activating)
0144	Replacement of control module N47-5 (ESP and BAS control module)	0145	Alle Codierungen
0146	This setting should only be changed if requested by customer	0147	Workshop coding
0148	Normalizing of positioning motors	0149	Check of adjustment range of positioning motors
0150	Teach-in of actuator motors after actuator motor replacement	0151	Breaking-in procedure after replacement of refrigerant compressor
0152	Normalization of actuator motors	0153	Increase main odometer reading
0154	Current menu setting	0155	Resetting menu settings to manufacturer default settings
0156	Setting main odometer forward and back	0157	Factory settings
0158	National variant coding	0159	Special equipment
0160	Codings specific for instrument cluster	0161	Fuel tank version
0162	Oil level indicator	0163	Standard variant coding
0164	Correction factor of fuel consumption	0165	Setting of trip computer constants
0166	Instrument cluster settings	0167	National variant coding for vehicles with special protection GUARD"
0168	National variant coding for vehicles without special protection"GUARD"	0169	Bus system-Telematic

index	Specil Function Name	index	Specil Function Name
0170	Engine type	0171	set time
	Display coding	0173	Workshop coding1
0174	Workshop coding2	0175	MAXCOOL
0176	Temperature	0177	Suction fancontrol
0178	Special settings	0179	Ventilation of heat exchangers
0180	Test of left heating capacity	0181	Test of right heating capacity
0182		0183	Refrigerant circuit test
0184	This setting should only be change if requested by customer	0185	Workshop coding 1
0186	Engine model coding	0187	Teach-in of rotary potentiometers for the air outlets
0188	Catalytic converter	0189	Tank leak test procedure
0190	Exhaust gas recirculation	0191	Components
0192	Fuel system	0193	Display of codong data
0194	Teach in process after engine replacement	0195	Resetting of adaptaion data
0196	Resetting the cold-start adaptation values	0197	Read coding and transfer to the new control unit
0198	Default initialization	0199	Cylinder shut-off
0200	Reset lambda adaptation	0201	Right cylinder bank
0202	Left bank of cylinders	0203	Lambda control, upstream TWC
0204	Lambda control, downstream TWC	0205	02 sensor heater
0206	02 sensor	0207	Secondary air injection
0208	Sensor heating diagnosis	0209	Oxygen sensor ageing monitor
0210	Diagnosis of catalytic converter	0211	Coding
0212	SCN(Software Calibration Number)	0213	CVN(Calibration verification number)
0214	Check sensor adaptation	0215	Resetting of sensor adaptation
0216	Adaptation data	0217	Teach in ethanol portion in fuel
0218	Control module programming	0219	Resetting of adaptation data
	Resetting the reading of the counter for		
0220	ethanol teach-in processes	0221	sensor roptor adaptation
0222	Resetting of cold-start adaptation values	0223	Automatic transfer of settings from the old control unit
0224	Display of SCN	0225	Display of CVN
	Display of model check number	0227	Injector injection quantity adjustment
0228	Activation of fuel pump	0229	Teach-in of drive authorization system
		0231	B79/2 (Transmission neutral position sensor)
0232	Resetting of adaptation values	0233	Status of teach-in processes
0234	Readiness-Codes	0235	Measures for initiating the fault path tests
0236	Hard codes	0237	Notes on emissions inspection(OBD I/M check)
0238	Readiness for exhaust emissions inspection(AU)	0239	Test values of emissions test
0240	Measures for initating the fault path tests	0241	Notes on readiness
	<u> </u>		Teach—in process for component
0242	Teach-in process after engine replacement	0243	M16/45(EGR[ARE]actuator motors)
0244	Restting of adaptation data	0245	Resetting of the cold-start adaptation values
0244	Quick test of mixture adaptation	0247	Einlernen der Selbstanpassung
0248	Adjustment of injection quantities	0249	Correction programming of the CO setting(For
0240	Adjustment of injection quantities	0249	vehicles with no catalytic converter)
0250	Calibration of control unit RBS	0251	Calibration of component B37/1 (Pedal angle
0252	CVN Calibration verification number	0253	Replacement of control module N30/6 (Regenerative braking system control unit)
0254	Replacement of components A7/3 (Traction system hydraulic unit) and N30/6 (Regenerative braking system control unit)	0255	Replacement of component Brake pedal system
0256	Calibration of component 'A7/3 (Traction system	0257	Calibration of component 'B24/15 (Yaw rate sensor
	hydraulic unit)'	0250	for lateral and longitudinal acceleration)'
0258	After replacing the feed line HZ	0259	Replacement of one or more brake lines
0260	Calibration of control unit ABR	0261	Idle speed set value
0262	Type approval number	0263	Learning of the recirculated air flap stop
	Acceleration of sensor rotor adaptation	0265	Resetting of mixture adaptation(CNG compressed natural gas)
0266	CNG compressed natural gas Mode		