

# MaxiDas\_Chrysler\_V7.10 Function List (Note:For reference only)

## NOTES:

- This function is supported.      ※ This function may be supported, which depends on the actual condition of the vehicle.  
 ○ This function is not supported.    ▲ This function is the new feature in this version.  
 As for special function please refer to the special function table.

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
1996~2003	4	PCM	●	●	●	●	●	●	○	C000, C001, C002, C003, C004, C005, C006, C007, C008, C009, C00A, C00B, C00C, C00D, C00E, C00F, C010, C011, C012, C013, C014, C015, C016, C017, C018, C019
1996~2003	All Model	TCM	○	●	●	●	●	●	○	C02D, C02E, C02F, C030, C031, C032, C033
1996~2003	All Model	ABS	○	●	●	●	○	●	○	002F
1996~2003	All Model	ORC	○	●	●	●	○	○	○	
1996~2003	All Model	SKM	○	●	●	●	○	●	○	C01A, C01B, C01C, C01D, C01E, C01F, C020, C021, C022, C023, C024, C025, C026, C027, C028, C029, C02A, C02B, C02C
1996~2003	All Model	APM	○	●	●	●	○	●	○	
1996~2003	All Model	ATC	○	●	●	●	○	●	○	
1996~2003	All Model	AUD	○	●	●	●	○	○	○	
1996~2003	All Model	BCM	○	●	●	●	○	●	○	
1996~2003	All Model	CMT	○	●	●	○	○	○	○	
1996~2003	All Model	DAA	○	●	●	○	○	○	○	
1996~2003	All Model	DDM	○	●	●	●	○	●	○	
1996~2003	All Model	DSD	○	●	●	●	○	●	○	
1996~2003	All Model	FCM	○	●	●	●	○	●	○	
1996~2003	All Model	FDC	○	●	●	●	○	○	○	
1996~2003	All Model	HFM	○	●	●	●	○	●	○	
1996~2003	All Model	HVA	○	●	●	●	○	●	○	
1996~2003	All Model	LSA	○	●	●	○	○	○	○	
1996~2003	All Model	MIC	○	●	●	●	○	●	○	
1996~2003	All Model	MSM	○	●	●	●	○	●	○	
1996~2003	All Model	NAV	○	●	●	○	○	○	○	
1996~2003	All Model	OCM	○	○	○	●	○	○	○	
1996~2003	All Model	PAM	○	●	●	●	○	○	○	
1996~2003	All Model	PDM	○	●	●	●	○	●	○	
1996~2003	All Model	PLM	○	●	●	●	○	●	○	
1996~2003	All Model	PSD	○	●	●	●	○	●	○	
1996~2003	All Model	RSA	○	●	●	○	○	○	○	
1996~2003	All Model	RSM	○	●	●	○	○	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
1996~2003	All Model	SAR	○	●	●	○	○	●	○	
1996~2003	All Model	SLA	○	○	○	●	○	●	○	
1996~2003	All Model	SRM	○	○	○	●	○	●	○	
1996~2003	All Model	VIC	○	●	●	○	○	○	○	
1996~2003	All Model	VTS	○	○	○	●	○	●	○	
1996~2003	All Model	XCM	○	○	○	●	○	●	○	
2004	Durango (Pre-2011)	VES	●	●	●	●	●	●	○	
2004	Durango (Pre-2011)	ORC	●	●	●	●	●	○	●	
2004	Durango (Pre-2011)	HFM	●	●	●	●	●	●	○	
2004	Durango (Pre-2011)	AMP	●	●	●	●	●	○	●	0289, 028A, 006D, 006B, 006C, 0068, 006A
2004	Durango (Pre-2011)	MSMD	●	●	●	●	●	○	○	0117
2004	Durango (Pre-2011)	FCMCGW	●	●	●	●	●	●	●	0039, 003C, 003D, 0032, 003F, 003E, 0036, 0037, 0035, 0034, 0038, 003A, 0033, 0040
2004	Durango (Pre-2011)	TCM	●	●	●	●	○	●	●	0167, 0166, 01EE, 016A, 0169, 016C, 016B, 016E, 016D, 01F0, 0172, 0177, 0170, 0175
2004	Durango (Pre-2011)	WCM	●	●	●	●	●	○	●	01D2, 0228, 0226, 0225, 0227
2004	Durango (Pre-2011)	PCM	●	●	●	●	●	●	●	0127, 0126, 0044, 0129, 026C, 026D, 0128, 012E, 012F, 012C, 012D, 0173, 012A, 012B, 013B
2004	Durango (Pre-2011)	EOM	●	●	●	●	●	●	●	
2004	Durango (Pre-2011)	HSM	●	●	●	●	●	●	○	
2004	Durango (Pre-2011)	HVAC	●	●	●	●	●	●	○	00EA, 00E8, 0378, 00E9, 0324
2004	Durango (Pre-2011)	PDM	●	●	●	●	●	●	●	
2004	Durango (Pre-2011)	RADIO	●	●	●	●	●	○	○	
2004	Durango (Pre-2011)	DDM	●	●	●	●	●	●	●	
2004	Durango (Pre-2011)	OCM	●	●	●	●	●	○	○	011E
2004	Durango (Pre-2011)	CCN	●	●	●	●	●	●	●	008C, 008F, 008E, 0091, 008D, 0090
2004	Durango (Pre-2011)	ABS	●	●	●	●	●	●	●	0031, 002E, 002F, 0030
2004	Durango (Pre-2011)	SDAR	●	●	●	●	●	○	○	
2005	3	WCM	●	●	●	●	●	○	●	01D2, 0228, 0226, 0225, 0227
2005	Durango (Pre-2011)	HVAC	●	●	●	●	●	●	○	00EA, 00E8, 0378, 00E9, 0324
2005	Durango (Pre-2011)	ORC	●	●	●	●	●	○	●	
2005	Durango (Pre-2011)	TCM	●	●	●	●	○	●	●	0167, 0166, 01EE, 016A, 0169, 016C, 016B, 016E, 016D, 01F0, 0172, 0177, 0170, 0175
2005	Durango (Pre-2011)	RADIO	●	●	●	●	●	○	○	
2005	Durango (Pre-2011)	OCM	●	●	●	●	●	○	○	011E
2005	Durango (Pre-2011)	SDAR	●	●	●	●	●	○	○	
2005	Durango (Pre-2011)	PDM	●	●	●	●	●	●	●	
2005	Durango (Pre-2011)	HSM	●	●	●	●	●	●	○	
2005	Durango (Pre-2011)	VES	●	●	●	●	●	●	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2005	Durango (Pre-2011)	FCMCGW	●	●	●	●	●	●	●	0039, 003C, 003D, 0032, 003F, 003E, 0036, 0037, 0035, 0034, 0038, 003A, 0033, 0040
2005	Durango (Pre-2011)	HFM	●	●	●	●	●	●	○	
2005	Durango (Pre-2011)	DDM	●	●	●	●	●	●	●	
2005	Durango (Pre-2011)	CCN	●	●	●	●	●	●	●	008C, 008F, 008E, 0091, 008D, 0090
2005	Durango (Pre-2011)	AMP	●	●	●	●	●	○	●	0289, 028A, 006D, 006B, 006C, 0068, 006A
2005	Durango (Pre-2011)	EOM	●	●	●	●	●	○	●	
2005	Durango (Pre-2011)	PCM	●	●	●	●	●	●	●	0127, 0126, 0044, 0411, 0129, 026C, 026D, 0128, 012E, 012F, 013C, 012C, 012D, 0173, 012A, 012B, 013B
2005	Durango (Pre-2011)	ABS	●	●	●	●	●	●	●	002F, 002E, 0031, 0030
2005	Durango (Pre-2011)	MSMD	●	●	●	●	●	○	○	0117
2005	300 / Magnum / Charger (Pre-2011)	MSMD	●	●	●	●	●	○	○	0117
2005	300 / Magnum / Charger (Pre-2011)	PTS	●	●	●	●	●	●	○	01B4, 01B3, 01B5
2005	300 / Magnum / Charger (Pre-2011)	OCM	●	●	●	●	●	○	○	011E
2005	300 / Magnum / Charger (Pre-2011)	EOM	●	●	●	●	●	●	●	
2005	300 / Magnum / Charger (Pre-2011)	WCM	●	●	●	●	●	○	●	01D2, 0228, 0226, 0225, 0227
2005	300 / Magnum / Charger (Pre-2011)	ESM	●	●	●	●	●	●	○	
2005	300 / Magnum / Charger (Pre-2011)	ORC	●	●	●	●	●	○	●	
2005	300 / Magnum / Charger (Pre-2011)	SDAR	●	●	●	●	●	○	○	
2005	300 / Magnum / Charger (Pre-2011)	CCN	●	●	●	●	●	●	○	
2005	300 / Magnum / Charger (Pre-2011)	RADIO	●	●	●	●	●	○	○	
2005	300 / Magnum / Charger (Pre-2011)	LRSM	●	●	●	●	●	○	●	
2005	300 / Magnum / Charger (Pre-2011)	ABS	●	●	●	●	●	●	●	005A, 0058, 0059, 005E, 005C, 005D, 005F, 005B
2005	300 / Magnum / Charger (Pre-2011)	AMP	●	●	●	●	●	○	●	0289, 028A, 006D, 006B, 006C, 0068, 006A
2005	300 / Magnum / Charger (Pre-2011)	HSM	●	●	●	●	●	●	○	
2005	300 / Magnum / Charger (Pre-2011)	HVAC	●	●	●	●	●	●	○	00EA, 00E9
2005	300 / Magnum / Charger (Pre-2011)	DDM	●	●	●	●	●	●	●	
2005	300 / Magnum / Charger (Pre-2011)	SCM	●	●	●	●	○	●	●	
2005	300 / Magnum / Charger (Pre-2011)	SUNR	●	●	●	●	●	●	○	
2005	300 / Magnum / Charger (Pre-2011)	FCMCGW	●	●	●	●	●	●	●	0039, 003C, 003D, 0032, 003F, 003E, 0036, 0037, 0035, 0034, 0038, 003A, 002E, 0033
2005	300 / Magnum / Charger (Pre-2011)	TCM	●	●	●	●	●	●	●	0167, 0166, 01EE, 016A, 0169, 016C, 016B, 016E, 016D, 01F0, 0172, 01F1, 0177, 01EF, 0175, 01F4, 01F3, 01F2
2005	300 / Magnum / Charger (Pre-2011)	HFM	●	●	●	●	●	●	○	
2005	300 / Magnum / Charger (Pre-2011)	PCM	●	●	●	●	●	●	●	0127, 0126, 0044, 0129, 026C, 026D, 0128, 012E, 012F, 012C, 012D, 0173, 012A, 012B, 013B, 0411, 013C
2005	300 / Magnum / Charger (Pre-2011)	PDM	●	●	●	●	●	●	●	
2005	300 / Magnum / Charger (Pre-2011)	HIDT	●	●	●	●	●	●	○	
2005	Dakota	EOM	●	●	●	●	●	○	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2005	Dakota	RADIO	●	●	●	●	●	○	○	
2005	Dakota	OCM	●	●	●	●	●	○	○	011E
2005	Dakota	CCN	●	●	●	●	●	●	●	008C, 008F, 008E, 0091, 008D, 0090
2005	Dakota	WCM	●	●	●	●	●	○	●	01D2, 0228, 0226, 0225, 0227
2005	Dakota	HVAC	●	●	●	●	●	●	●	00EA, 00E8, 00E9
2005	Dakota	AMP	●	●	●	●	●	○	●	0289, 028A, 006D, 006B, 006C, 0068, 006A
2005	Dakota	TCM	●	●	●	●	○	●	●	0167, 0166, 01EE, 016A, 0169, 016C, 016B, 016E, 016D, 01F0, 0172, 0177, 0170, 0175
2005	Dakota	PCM	●	●	●	●	●	●	●	0127, 0126, 0044, 0411, 0129, 026C, 026D, 0128, 012E, 012F, 013C, 012C, 012D, 0173, 012A, 012B, 013B
2005	Dakota	ABS	●	●	●	●	●	●	●	005A, 0002, 005E
2005	Dakota	SDAR	●	●	●	●	●	○	○	
2005	Dakota	ORC	●	●	●	●	●	○	●	
2005	Dakota	HFM	●	●	●	●	●	●	○	
2005	Dakota	FCMCGW	●	●	●	●	●	●	●	003C, 003D, 0032, 00C4, 003F, 003E, 0036, 0037, 0034, 0038, 003A, 002E, 0033
2005	Grand Cherokee	HVAC	●	●	●	●	●	●	○	00EA, 00E9
2005	Grand Cherokee	SUNR	●	●	●	●	●	●	○	
2005	Grand Cherokee	RADIO	●	●	●	●	●	○	○	
2005	Grand Cherokee	TCM	●	●	●	●	●	●	●	0167, 0166, 01EE, 016A, 0169, 016C, 016B, 016E, 016D, 01F0, 0172, 0177, 0170, 0175, 01F4, 01F3, 01F2
2005	Grand Cherokee	WCM	●	●	●	●	●	○	●	01D2, 0228, 0226, 0225, 0232, 0230, 0231, 022F, 01DE, 022D, 0227, 0274
2005	Grand Cherokee	SDAR	●	●	●	●	●	○	○	
2005	Grand Cherokee	VES	●	●	●	●	●	●	○	
2005	Grand Cherokee	AHBM	●	●	●	●	●	●	○	0066
2005	Grand Cherokee	FDCM	●	●	●	●	●	●	●	
2005	Grand Cherokee	ESM	●	●	●	●	●	●	○	
2005	Grand Cherokee	EOM	●	●	●	●	●	○	●	
2005	Grand Cherokee	PCM	●	●	●	●	●	●	●	0127, 0126, 0044, 0411, 0129, 026C, 026D, 0128, 012E, 012F, 013C, 012C, 012D, 0173, 012A, 012B, 013B, 0042, 0149, 0142, 0145, 014B, 014A, 0148, 0049, 0146, 0147
2005	Grand Cherokee	FCMCGW	●	●	●	●	●	●	●	0039, 003C, 003D, 0032, 003F, 003E, 0036, 0037, 0035, 0034, 0038, 003A, 0373, 0374, 0033, 0040
2005	Grand Cherokee	ORC	●	●	●	●	●	○	●	
2005	Grand Cherokee	ITM	●	●	●	●	●	●	●	
2005	Grand Cherokee	ABS	●	●	●	●	●	●	●	005A, 0058, 0059, 005E, 005C, 005D, 005F, 005B
2005	Grand Cherokee	PTS	●	●	●	●	●	●	○	01B4, 01B3, 01B5
2005	Grand Cherokee	PDM	●	●	●	●	●	●	●	
2005	Grand Cherokee	SCM	●	●	●	●	●	○	●	
2005	Grand Cherokee	OCM	●	●	●	●	●	○	○	011E



YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2005	Grand Cherokee	AMP	●	●	●	●	●	○	●	0289, 028A, 006D, 006B, 006C, 0068, 006A
2005	Grand Cherokee	LRSM	●	●	●	●	●	○	○	
2005	Grand Cherokee	DDM	●	●	●	●	●	●	●	
2005	Grand Cherokee	MSMD	●	●	●	●	●	○	○	0117
2005	Grand Cherokee	CCN	●	●	●	●	●	●	●	0097, 008C, 008F, 008E, 0091, 0090
2005	Grand Cherokee	HSM	●	●	●	●	●	●	○	
2005	Grand Cherokee	HFM	●	●	●	●	●	●	○	
2006	Dodge Ram	FDCM	●	●	●	●	●	○	○	
2006	Dodge Ram	OCM	●	●	●	●	●	○	○	011E
2006	Dodge Ram	HFM	●	●	●	●	●	●	○	
2006	Dodge Ram	SUNR	●	●	●	●	●	●	○	
2006	Dodge Ram	AMP	●	●	●	●	●	○	●	028A, 028D, 006D, 006C, 027F, 0068, 006A
2006	Dodge Ram	HVAC	●	●	●	●	●	●	●	00EA, 00E8, 00E9, 00EB
2006	Dodge Ram	TIPMCGW	●	●	●	●	●	●	●	003F, 020E, 0215, 028F, 0211
2006	Dodge Ram	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2006	Dodge Ram	PCM	●	●	●	●	●	●	●	0127, 0126, 0044, 0411, 0129, 026C, 026D, 0128, 012E, 012F, 013C, 012C, 012D, 0173, 012A, 012B, 013B, 0156, 0157, 0154, 0155, 0141, 0150, 0151, 0153, 015A, 0159, 0158, 014F
2006	Dodge Ram	SDAR	●	●	●	●	●	○	○	
2006	Dodge Ram	TCM	●	●	●	●	○	●	●	0167, 0166, 01EE, 016A, 0169, 016C, 016B, 016E, 016D, 01F0, 0172, 0177, 0170, 0175
2006	Dodge Ram	VES	●	●	●	●	●	●	○	
2006	Dodge Ram	CCN	●	●	●	●	●	●	○	008C, 008F, 008E, 0090
2006	Dodge Ram	EOM	●	●	●	●	●	○	●	
2006	Dodge Ram	ORC	●	●	●	●	●	○	●	
2006	Dodge Ram	RADIO	●	●	●	●	●	○	●	
2006	Dodge Ram	WCM	●	●	●	●	●	○	●	01D2, 0228, 0226, 0225, 0232, 0230, 0231, 022F, 01DE, 0233, 022D, 023D, 023E, 0271, 0270
2006	Dodge Ram	PCI to CAN Gateway	●	●	●	●	●	○	○	
2006	Dodge Ram	JTEC Engine	●	●	●	●	○	●	○	
2006	Durango (Pre-2011)	SAS	●	●	●	●	●	○	○	
2006	Durango (Pre-2011)	HFM	●	●	●	●	●	●	○	
2006	Durango (Pre-2011)	CCN	●	●	●	●	●	●	●	008C, 008F, 008E, 0091, 008D, 0090
2006	Durango (Pre-2011)	FCMCGW	●	●	●	●	●	●	●	0039, 003C, 003D, 0032, 003F, 003E, 0036, 0037, 0035, 0034, 0038, 003A, 002E, 0033, 00C6, 0040
2006	Durango (Pre-2011)	SDAR	●	●	●	●	●	○	○	
2006	Durango (Pre-2011)	PCM	●	●	●	●	●	●	●	0127, 0126, 0044, 0411, 0129, 026C, 026D, 0128, 012E, 012F, 013C, 012C, 012D, 0173, 012A, 012B, 013B
2006	Durango (Pre-2011)	AMP	●	●	●	●	●	○	●	0069, 006D, 0079, 0068, 02F6, 0289, 028A, 006B, 006C, 006A

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2006	Durango (Pre-2011)	PDM	●	●	●	●	●	●	●	
2006	Durango (Pre-2011)	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2006	Durango (Pre-2011)	ORC	●	●	●	●	●	○	●	
2006	Durango (Pre-2011)	EOM	●	●	●	●	●	○	●	
2006	Durango (Pre-2011)	HVAC	●	●	●	●	●	●	○	00EA, 00E8, 0378, 00E9, 0324
2006	Durango (Pre-2011)	HSM	●	●	●	●	●	●	○	
2006	Durango (Pre-2011)	OCM	●	●	●	●	●	○	○	011E
2006	Durango (Pre-2011)	RADIO	●	●	●	●	●	○	●	
2006	Durango (Pre-2011)	VES	●	●	●	●	●	●	○	
2006	Durango (Pre-2011)	TCM	●	●	●	●	○	●	●	0167, 0166, 01EE, 016A, 0169, 016C, 016B, 016E, 016D, 01F0, 0172, 0177, 0170, 0175
2006	Durango (Pre-2011)	WCM	●	●	●	●	●	○	●	01D2, 0228, 0226, 0225, 0227, 0232, 0230, 0231, 022F, 01DE, 0233, 022D, 023D, 023E, 0271, 0270
2006	Durango (Pre-2011)	DDM	●	●	●	●	●	●	●	
2006	Durango (Pre-2011)	MSMD	●	●	●	●	●	○	○	0117
2006	Durango (Pre-2011)	PLGM	●	●	●	●	●	●	●	
2006	Liberty	PCM	●	●	●	●	●	●	●	0127, 0126, 0044, 0411, 0129, 026C, 026D, 0128, 012E, 012F, 013C, 012C, 012D, 0173, 012A, 012B, 013B
2006	Liberty	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2006	Liberty	SAS	●	●	●	●	●	○	○	
2006	Liberty	TCM	●	●	●	●	○	●	●	0167, 0166, 01EE, 016A, 0169, 016C, 016B, 016E, 016D, 01F0, 0172, 0177, 0170, 0175
2006	Liberty	BCM	●	●	●	●	○	●	○	0081, 8018, 8017, 8015, 8057, 8012, 003F, 002E, 8058
2006	Liberty	TCM	●	●	●	●	●	●	○	
2006	Liberty	ORC	●	●	●	●	●	●	●	
2006	Liberty	OCM	●	●	●	●	○	○	○	011E, 801A, 8023, 8024
2006	Liberty	EOM	●	●	●	○	○	○	○	
2006	Liberty	PCM	●	●	●	●	●	●	●	
2006	Liberty	SDAR	●	●	●	●	●	●	○	
2006	Liberty	SKREEM	●	●	●	●	●	○	○	8003, 8004, 8005, 8006, 8007, 01D2, 800D, 8008, 8009, 800A, 800B, 800C, 01DE, 800E, 01DA
2006	Liberty	RADIO	●	●	●	●	●	●	●	
2006	Liberty	MIC/CCN	●	●	●	●	○	●	○	008C, 804F, 8050, 8051, 8052
2006	Liberty	ITM	●	○	○	●	○	●	○	
2006	Liberty	HFM	●	●	●	●	○	●	○	
2006	300 / Magnum / Charger (Pre-2011)	PTIM	●	●	●	●	●	●	●	
2006	300 / Magnum / Charger (Pre-2011)	PTS	●	●	●	●	○	●	○	01B4, 01B3, 01B5, 01B8
2006	300 / Magnum / Charger (Pre-2011)	SDAR	●	●	●	●	●	○	○	
2006	300 / Magnum / Charger (Pre-2011)	OCM	●	●	●	●	●	○	○	011E

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2006	300 / Magnum / Charger (Pre-2011)	AMP	●	●	●	●	●	○	●	0289, 028B, 028A, 006D, 006B, 0073, 006C, 0068, 006A, 0069
2006	300 / Magnum / Charger (Pre-2011)	HIDT	●	●	●	●	●	●	○	
2006	300 / Magnum / Charger (Pre-2011)	WCM	●	●	●	●	●	○	●	01D2, 0228, 0232, 0230, 0231, 022F, 01DE, 0233, 022D, 023D, 023E, 0271, 0270, 0226, 0225, 0227
2006	300 / Magnum / Charger (Pre-2011)	HFM	●	●	●	●	●	●	○	
2006	300 / Magnum / Charger (Pre-2011)	ORC	●	●	●	●	●	●	●	
2006	300 / Magnum / Charger (Pre-2011)	VES	●	●	●	●	●	●	○	
2006	300 / Magnum / Charger (Pre-2011)	SUNR	●	●	●	●	●	●	○	
2006	300 / Magnum / Charger (Pre-2011)	RADIO	●	●	●	●	●	○	●	
2006	300 / Magnum / Charger (Pre-2011)	FCMCGW	●	●	●	●	●	●	●	0039, 003C, 003D, 0032, 003F, 003E, 0036, 0037, 0035, 00C8, 003A, 002E, 0033
2006	300 / Magnum / Charger (Pre-2011)	ITM	●	●	●	●	●	●	●	
2006	300 / Magnum / Charger (Pre-2011)	EOM	●	●	●	●	●	○	●	
2006	300 / Magnum / Charger (Pre-2011)	MSMD	●	●	●	●	●	○	○	0117
2006	300 / Magnum / Charger (Pre-2011)	ESM	●	●	●	●	●	●	○	
2006	300 / Magnum / Charger (Pre-2011)	DDM	●	●	●	●	●	●	●	
2006	300 / Magnum / Charger (Pre-2011)	TCM	●	●	●	●	●	●	●	01F3, 01F2, 0167, 0166, 01EE, 016A, 0169, 016C, 016B, 016E, 016D, 01F0, 0172, 01F1, 0177, 01EF, 0175
2006	300 / Magnum / Charger (Pre-2011)	LRSM	●	●	●	●	●	○	○	
2006	300 / Magnum / Charger (Pre-2011)	PCM	●	●	●	●	●	●	●	0127, 0126, 0044, 0411, 0129, 026C, 026D, 0128, 012E, 012F, 013C, 012C, 012D, 0173, 012A, 012B, 013B, 0042, 0149, 0142, 0145, 0045, 0046, 014B, 014A, 0049, 014D, 0146, 0147
2006	300 / Magnum / Charger (Pre-2011)	HSM	●	●	●	●	●	●	○	
2006	300 / Magnum / Charger (Pre-2011)	ABS	●	●	●	●	●	●	●	0002, 0285, 0062, 005A, 0058, 0059, 005E, 005C, 005D, 005F, 005B
2006	300 / Magnum / Charger (Pre-2011)	HVAC	●	●	●	●	●	●	○	00EA, 00E9
2006	300 / Magnum / Charger (Pre-2011)	CCN	●	●	●	●	●	●	○	
2006	300 / Magnum / Charger (Pre-2011)	AHBM	●	●	●	●	●	●	○	0066
2006	300 / Magnum / Charger (Pre-2011)	PDM	●	●	●	●	●	●	●	
2006	300 / Magnum / Charger (Pre-2011)	SCM	●	●	●	●	○	●	●	
2006	Dakota	HVAC	●	●	●	●	●	●	●	00EA, 00E8, 00E9
2006	Dakota	FCMCGW	●	●	●	●	●	●	●	0039, 003C, 003D, 0032, 00C4, 003F, 003E, 0036, 0037, 0034, 0038, 003A, 00C9, 0033, 0040
2006	Dakota	RADIO	●	●	●	●	●	○	●	
2006	Dakota	HFM	●	●	●	●	●	●	○	
2006	Dakota	AMP	●	●	●	●	●	○	●	0069, 006D, 0079, 0068, 02F6, 0289, 028A, 006B, 006C, 006A
2006	Dakota	PCM	●	●	●	●	●	●	●	0127, 0126, 0044, 0411, 0129, 026C, 026D, 0128, 012E, 012F, 013C, 012C, 012D, 0173, 012A, 012B, 013B
2006	Dakota	TCM	●	●	●	●	○	●	●	0167, 0166, 01EE, 016A, 0169, 016C, 016B, 016E, 016D, 01F0, 0172, 0177, 0170, 0175
2006	Dakota	OCM	●	●	●	●	●	○	○	011E

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2006	Dakota	SDAR	●	●	●	●	●	○	○	
2006	Dakota	WCM	●	●	●	●	●	○	●	01D2, 0228, 0226, 0225, 0227, 0232, 0230, 0231, 022F, 01DE, 0233, 022D, 023D, 023E, 0271, 0270
2006	Dakota	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2006	Dakota	EOM	●	●	●	●	●	○	●	
2006	Dakota	ORC	●	●	●	●	●	○	●	
2006	Dakota	CCN	●	●	●	●	●	●	●	008C, 008F, 008E, 0091, 008D, 0090
2006	Raider	EOM	●	●	●	●	●	○	●	
2006	Raider	OCM	●	●	●	●	●	○	○	011E
2006	Raider	ORC	●	●	●	●	●	○	●	
2006	Raider	RADIO	●	●	●	●	●	○	●	
2006	Raider	HVAC	●	●	●	●	●	●	●	00EA, 00E8, 00E9
2006	Raider	PCM	●	●	●	●	●	●	●	0127, 0126, 0044, 0411, 0129, 026C, 026D, 0128, 012E, 012F, 013C, 012C, 012D, 0173, 012A, 012B, 013B
2006	Raider	SDAR	●	●	●	●	●	○	○	
2006	Raider	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2006	Raider	AMP	●	●	●	●	●	○	●	0069, 006D, 0079, 0068, 02F6, 0289, 028A, 006B, 006C, 006A
2006	Raider	HFM	●	●	●	●	●	●	○	
2006	Raider	CCN	●	●	●	●	●	●	●	008C, 008F, 008E, 0091, 008D, 0090
2006	Raider	WCM	●	●	●	●	●	○	●	01D2, 0228, 0232, 0230, 0231, 022F, 01DE, 0233, 022D, 023D, 023E, 0271, 0270, 0226, 0225, 0227
2006	Raider	TCM	●	●	●	●	○	●	●	0167, 0166, 01EE, 016A, 0169, 016C, 016B, 016E, 016D, 01F0, 0172, 0177, 0170, 0175
2006	Raider	FCMCGW	●	●	●	●	●	●	●	0039, 003C, 003D, 0032, 00C4, 003F, 003E, 0036, 0037, 0034, 0038, 003A, 00C9, 0033, 0040
2006	PT Cruiser	TIPMCGW	●	●	●	●	●	●	●	003F, 020E, 0215, 028F, 028E, 0211
2006	PT Cruiser	ABS	●	●	●	●	●	●	●	005E, 0060, 005B
2006	PT Cruiser	AMP	●	●	●	●	●	○	●	0289, 028A, 006D, 006B, 006C, 0068, 006A
2006	PT Cruiser	SDAR	●	●	●	●	●	○	○	
2006	PT Cruiser	TCM	●	●	●	●	○	●	●	0167, 0166, 01EE, 016A, 0169, 016C, 016B, 016E, 016D, 01F0, 0172, 0177, 0170, 0175
2006	PT Cruiser	ITM	●	●	●	●	●	●	●	
2006	PT Cruiser	PDM	●	●	●	●	○	●	○	
2006	PT Cruiser	HFM	●	●	●	●	●	●	○	
2006	PT Cruiser	RADIO	●	●	●	●	●	○	●	
2006	PT Cruiser	DDM	●	●	●	●	●	●	○	
2006	PT Cruiser	ORC	●	●	●	●	●	○	●	
2006	PT Cruiser	WCM	●	●	●	●	●	○	●	01D2, 0228, 0226, 0225, 0232, 0230, 0231, 022F, 01DE, 0233, 022D, 023D, 023E, 0271, 0270
2006	PT Cruiser	CCN	●	●	●	●	●	●	●	008C, 008F, 008E, 0094, 0092, 0096

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2006	PT Cruiser	OCM	●	●	●	●	●	○	○	011E
2006	PT Cruiser	PCM	●	●	●	●	●	●	●	0042, 0149, 0142, 0044, 0145, 012D, 0173, 0049, 013B, 0127, 0126, 0411, 0129, 026C, 026D, 0128, 012E, 012F, 013C, 012C, 012A, 012B
2006	PT Cruiser	CAN GW	●	●	●	●	●	○	●	
2006	Grand Cherokee	MSMD	●	●	●	●	●	○	○	0117
2006	Grand Cherokee	TM	●	●	●	○	○	○	○	
2006	Grand Cherokee	HSM	●	●	●	●	●	●	○	
2006	Grand Cherokee	ITM	●	●	●	●	●	●	●	
2006	Grand Cherokee	SUNR	●	●	●	●	●	●	○	
2006	Grand Cherokee	PTS	●	●	●	●	●	●	○	01B4, 01B3, 01B5, 01B8
2006	Grand Cherokee	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2006	Grand Cherokee	PCM	●	●	●	●	●	●	●	0042, 0149, 0142, 0044, 0145, 012D, 014B, 0173, 014A, 0148, 0049, 0146, 0147, 013B, 0127, 0126, 0411, 0129, 026C, 026D, 0128, 012E, 012F, 013C, 012C, 012A, 012B
2006	Grand Cherokee	FCMCGW	●	●	●	●	●	●	●	0039, 003C, 003D, 0032, 003F, 003E, 0036, 0037, 0035, 0034, 0038, 003A, 002E, 0033, 0040
2006	Grand Cherokee	ESM	●	●	●	●	●	●	○	
2006	Grand Cherokee	RADIO	●	●	●	●	●	○	●	
2006	Grand Cherokee	WCM	●	●	●	●	●	○	●	01D2, 0228, 0232, 0230, 0231, 022F, 01DE, 0233, 022D, 023D, 023E, 0271, 0270
2006	Grand Cherokee	ORC	●	●	●	●	●	○	●	
2006	Grand Cherokee	CCN	●	●	●	●	●	●	●	0097, 008C, 008F, 008E, 0091, 0094, 0099, 0098, 0090
2006	Grand Cherokee	EOM	●	●	●	●	●	○	●	
2006	Grand Cherokee	DDM	●	●	●	●	●	●	●	
2006	Grand Cherokee	LRSM	●	●	●	●	●	○	○	
2006	Grand Cherokee	HVAC	●	●	●	●	●	●	○	00EA, 00E9
2006	Grand Cherokee	VES	●	●	●	●	●	●	○	
2006	Grand Cherokee	SCM	●	●	●	●	●	○	●	
2006	Grand Cherokee	HFM	●	●	●	●	●	●	○	
2006	Grand Cherokee	AHBM	●	●	●	●	●	●	○	0066
2006	Grand Cherokee	SDAR	●	●	●	●	●	○	○	
2006	Grand Cherokee	AMP	●	●	●	●	●	○	●	0289, 028A, 006D, 006B, 006C, 0068, 006A
2006	Grand Cherokee	PDM	●	●	●	●	●	●	●	
2006	Grand Cherokee	FDCM	●	●	●	●	●	●	●	
2006	Grand Cherokee	TCM	●	●	●	●	●	●	●	01F3, 01F2, 0167, 0166, 01EE, 016A, 0169, 016C, 016B, 016E, 016D, 01F0, 0172, 0177, 0170, 0175
2006	Grand Cherokee	OCM	●	●	●	●	●	○	○	011E
2006	Commander	AMP	●	●	●	●	●	○	●	0289, 028A, 006D, 006B, 006C, 0068, 006A
2006	Commander	DDM	●	●	●	●	●	●	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2006	Commander	SCM	●	●	●	●	●	○	●	
2006	Commander	FDCM	●	●	●	●	●	●	●	
2006	Commander	TM	●	●	●	○	○	○	○	
2006	Commander	PCM	●	●	●	●	●	●	●	0042, 0149, 0142, 0044, 0145, 012D, 0045, 0046, 014B, 0173, 014A, 0049, 014D, 0146, 0147, 013B, 0127, 0126, 0411, 0129, 026C, 026D, 0128, 012E, 012F, 013C, 012C, 012A, 012B
2006	Commander	SDAR	●	●	●	●	●	○	○	
2006	Commander	ITM	●	●	●	●	●	●	●	
2006	Commander	HVAC	●	●	●	●	●	●	○	00EA, 00E9
2006	Commander	PDM	●	●	●	●	●	●	●	
2006	Commander	WCM	●	●	●	●	●	○	●	01D2, 0228, 0232, 0230, 0231, 022F, 01DE, 0233, 022D, 023D, 023E, 0271, 0270
2006	Commander	LRSM	●	●	●	●	●	○	●	
2006	Commander	RADIO	●	●	●	●	●	○	●	
2006	Commander	AHBM	●	●	●	●	●	●	○	0066
2006	Commander	PTS	●	●	●	●	○	●	○	01B4, 01B3, 01B5, 01B8
2006	Commander	SUNR	●	●	●	●	●	●	○	
2006	Commander	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2006	Commander	CCN	●	●	●	●	●	●	●	0097, 008C, 008F, 008E, 0091, 0094, 0099, 0098, 0090
2006	Commander	ESM	●	●	●	●	●	●	○	
2006	Commander	VES	●	●	●	●	●	●	○	
2006	Commander	MSMD	●	●	●	●	●	○	○	0117
2006	Commander	HSM	●	●	●	●	●	●	○	
2006	Commander	TCM	●	●	●	●	●	●	●	0167, 0166, 01EE, 016A, 0169, 016C, 016B, 016E, 016D, 01F0, 0172, 0177, 0170, 0175, 01F3, 01F2
2006	Commander	HFM	●	●	●	●	●	●	○	
2006	Commander	FCMCGW	●	●	●	●	●	●	●	0039, 003C, 003D, 0032, 003F, 003E, 0036, 0037, 0035, 0034, 0038, 003A, 002E, 0033, 0040
2006	Commander	OCM	●	●	●	●	●	○	○	011E
2006	Commander	ORC	●	●	●	●	●	○	●	
2007	Pacifica	PLGM	●	●	●	●	●	●	●	
2007	Pacifica	BCMCGW	●	●	●	●	●	●	●	007E, 007D
2007	Pacifica	PCM	●	●	●	●	●	●	●	027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 0044, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 012D, 0177, 0173, 012A, 0281, 0280, 0176, 024E, 0170, 016F, 012B, 0269, 01FC, 013B
2007	Pacifica	ORC	●	●	●	●	●	○	●	
2007	Pacifica	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2007	Pacifica	SAS	●	●	●	●	○	○	○	
2007	Pacifica	AWD	●	●	●	●	●	○	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2007	Pacifica	OCM	●	●	●	●	○	○	○	011E, 802A, 802B, 8023, 8024
2007	Pacifica	SKREEM	●	●	●	●	●	○	○	8003, 8004, 8005, 8006, 8007, 01D2, 800D, 8008, 8009, 800A, 800B, 800C, 01DE, 800E, 01DA
2007	Pacifica	IPM	●	●	●	●	○	●	○	
2007	Pacifica	PDM	●	●	●	●	○	●	○	
2007	Pacifica	RADIO	●	●	●	○	○	●	○	
2007	Pacifica	MHSM	●	●	●	●	○	●	○	
2007	Pacifica	EOM	●	●	●	○	○	○	○	
2007	Pacifica	PTS	●	●	●	●	●	●	○	
2007	Pacifica	SDAR	●	●	●	●	●	●	○	
2007	Pacifica	DDM	●	●	●	●	○	●	○	
2007	Pacifica	MIC/CCN	●	●	●	●	○	●	○	
2007	Pacifica	AMP	●	●	●	○	○	○	○	
2007	Pacifica	HFM	●	●	●	●	○	●	○	
2007	Pacifica	MTC	●	●	●	●	○	●	○	
2007	Pacifica	NAV	●	●	●	○	○	○	○	
2007	Pacifica	ATC	●	●	●	●	●	●	○	
2007	Dodge Ram	HFM	●	●	●	●	●	●	○	
2007	Dodge Ram	PCM	●	●	●	●	●	●	●	027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 0044, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 012D, 0177, 0173, 012A, 0281, 0280, 0176, 024E, 0170, 016F, 012B, 0269, 01FC, 013B, 033D, 0156, 0157, 0154, 0155, 0141, 0150, 0151, 017B, 0292, 0049, 0276, 0277, 033B, 0178, 0179, 014F, 033A, 033C, 017A, 0278, 039A, 0152, 0153, 015A, 0159, 0158
2007	Dodge Ram	TIPMCGW	●	●	●	●	●	●	●	003F, 020E, 0215, 028F, 0211
2007	Dodge Ram	CCN	●	●	●	●	●	●	●	008C, 008F, 008E, 0090
2007	Dodge Ram	EOM	●	●	●	●	●	●	●	
2007	Dodge Ram	WCM	●	●	●	●	●	○	●	01D2, 0228, 0226, 0225, 0232, 0230, 0231, 022F, 01DE, 0233, 022D, 023D, 023E, 0271, 0270
2007	Dodge Ram	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2007	Dodge Ram	ORC	●	●	●	●	●	○	●	
2007	Dodge Ram	AMP	●	●	●	●	●	○	●	028A, 028D, 006D, 006C, 027F, 0068, 006A
2007	Dodge Ram	HVAC	●	●	●	●	●	●	●	00EA, 00E8, 00E9, 00EB
2007	Dodge Ram	RADIO	●	●	●	●	●	○	●	
2007	Dodge Ram	TCM	●	●	●	●	●	●	○	01F6, 027B, 0167, 0166, 01EE, 027C, 016A, 0169, 027D, 0291, 016C, 016B, 02F8, 0290, 027E, 016E, 016D, 0177, 0176, 024E, 01FB, 016F, 01FC
2007	Dodge Ram	SUNR	●	●	●	●	●	●	○	
2007	Dodge Ram	SDAR	●	●	●	●	●	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2007	Dodge Ram	SAS	●	●	●	●	○	○	○	
2007	Dodge Ram	FDCM	●	●	●	●	●	○	○	
2007	Dodge Ram	VES	●	●	●	●	●	●	○	
2007	Durango (Pre-2011)	VES	●	●	●	●	●	●	○	
2007	Durango (Pre-2011)	CCN	●	●	●	●	●	●	●	008F, 008E, 008D, 0090
2007	Durango (Pre-2011)	HSM	●	●	●	●	●	●	●	
2007	Durango (Pre-2011)	MSMD	●	●	●	●	●	○	○	0117
2007	Durango (Pre-2011)	DDM	●	●	●	●	●	●	●	
2007	Durango (Pre-2011)	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2007	Durango (Pre-2011)	PCM	●	●	●	●	●	●	●	027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 0044, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 012D, 0177, 0173, 012A, 0281, 0280, 0176, 024E, 0170, 016F, 012B, 0269, 01FC, 013B
2007	Durango (Pre-2011)	HFM	●	●	●	●	●	●	○	
2007	Durango (Pre-2011)	PLGM	●	●	●	●	●	●	●	
2007	Durango (Pre-2011)	RADIO	●	●	●	●	●	○	●	
2007	Durango (Pre-2011)	AMP	●	●	●	●	●	○	●	0069, 006D, 0079, 0068, 0303
2007	Durango (Pre-2011)	FCMCGW	●	●	●	●	●	●	●	0039, 003C, 003D, 0032, 003E, 0036, 00D5, 00D8, 0037, 0035, 0034, 00DB, 00D6, 00D9, 003A, 0033, 00C6, 0040, 00DA, 0272, 0273
2007	Durango (Pre-2011)	PDM	●	●	●	●	●	●	●	
2007	Durango (Pre-2011)	HVAC	●	●	●	●	●	●	●	00EA, 00E8, 00E9, 0324, 0323
2007	Durango (Pre-2011)	ORC	●	●	●	●	●	○	●	
2007	Durango (Pre-2011)	EOM	●	●	●	●	●	●	●	
2007	Durango (Pre-2011)	PTS	●	●	●	●	●	●	●	01B8
2007	Durango (Pre-2011)	SAS	●	●	●	●	○	○	○	
2007	Durango (Pre-2011)	PTIM	●	●	●	●	●	●	●	
2007	Durango (Pre-2011)	SDAR	●	●	●	●	●	○	○	
2007	Durango (Pre-2011)	WCM	●	●	●	●	●	○	●	01D2, 0228, 0232, 0230, 0231, 022F, 01DE, 0233, 022D, 023D, 023E, 0271, 0270
2007	Aspen	AMP	●	●	●	●	●	○	●	0069, 006D, 0079, 0068, 0303, 02F6
2007	Aspen	PDM	●	●	●	●	●	●	●	
2007	Aspen	WCM	●	●	●	●	●	○	●	01D2, 0228, 0232, 0230, 0231, 022F, 01DE, 0233, 022D, 023D, 023E, 0271, 0270
2007	Aspen	FCMCGW	●	●	●	●	●	●	●	0039, 003C, 003D, 0032, 003E, 0036, 00D5, 00D8, 0037, 0035, 0034, 00DB, 00D6, 00D9, 003A, 0033, 00C6, 0040, 00DA, 0272, 0273
2007	Aspen	ORC	●	●	●	●	●	○	●	
2007	Aspen	SAS	●	●	●	●	○	○	○	
2007	Aspen	MSMD	●	●	●	●	●	○	○	0117



YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2007	Aspen	PLGM	●	●	●	●	●	●	●	
2007	Aspen	DDM	●	●	●	●	●	●	●	
2007	Aspen	PCM	●	●	●	●	●	●	●	027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 0044, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 012D, 0177, 0173, 012A, 0281, 0280, 0176, 024E, 0170, 016F, 012B, 0269, 01FC, 013B
2007	Aspen	HSM	●	●	●	●	●	●	●	
2007	Aspen	HFM	●	●	●	●	●	○	○	
2007	Aspen	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2007	Aspen	VES	●	●	●	●	●	●	○	
2007	Aspen	CCN	●	●	●	●	●	●	●	008F, 008E, 008D, 0090
2007	Aspen	RADIO	●	●	●	●	●	○	●	
2007	Aspen	SDAR	●	●	●	●	●	○	○	
2007	Aspen	PTS	●	●	●	●	●	●	●	01B8
2007	Aspen	EOM	●	●	●	●	●	●	●	
2007	Aspen	HVAC	●	●	●	●	●	●	●	00EA, 00E8, 00E9, 0324, 0323
2007	Wrangler	RADIO	●	●	●	●	●	●	●	
2007	Wrangler	ITM	●	●	●	●	○	●	●	
2007	Wrangler	SAS	●	●	●	●	○	○	○	
2007	Wrangler	AMP	●	●	●	●	●	○	●	
2007	Wrangler	ASBS	●	●	●	●	●	○	○	0317, 0318, 031A, 031B, 0319
2007	Wrangler	TIPMCGW	●	●	●	●	●	●	●	003F, 003A, 002E, 021F
2007	Wrangler	PCM	●	●	●	●	●	●	●	027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 0044, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 012D, 0177, 0173, 012A, 0281, 0280, 0176, 024E, 0170, 016F, 012B, 0269, 01FC, 013B, 02BA, 02BF, 02BD, 0049, 031D, 02C1, 02C2
2007	Wrangler	TCM	●	●	●	●	●	●	○	0176, 024E, 01FB, 016F, 01FC
2007	Wrangler	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2007	Wrangler	CCN	●	●	●	●	●	●	●	
2007	Wrangler	WCM	●	●	●	●	●	○	●	01D2, 0228, 0226, 0225, 0232, 0230, 0231, 022F, 01DE, 0233, 022D, 0227, 0274
2007	Wrangler	ORC	●	●	●	●	●	○	●	
2007	Wrangler	OCM	●	●	●	●	●	○	○	011E
2007	Sebring / 200 / Avenger	DDM	●	●	●	●	●	●	○	
2007	Sebring / 200 / Avenger	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2007	Sebring / 200 / Avenger	SAS	●	●	●	●	○	○	○	
2007	Sebring / 200 / Avenger	ITM	●	●	●	●	●	●	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2007	Sebring / 200 / Avenger	PCM	●	●	●	●	●	●	●	0042, 0142, 012D, 0310, 0173, 03A3, 03A4, 013B, 0144, 027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 0044, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 0177, 012A, 0281, 0280, 0176, 024E, 0170, 016F, 012B, 0269, 01FC, 02E7, 013E, 0141, 012E, 0314
2007	Sebring / 200 / Avenger	PDM	●	●	●	●	●	●	○	
2007	Sebring / 200 / Avenger	TIPMCGW	●	●	●	●	●	●	●	003F, 020E, 0215, 028F, 0211
2007	Sebring / 200 / Avenger	HVAC	●	●	●	●	●	●	●	
2007	Sebring / 200 / Avenger	AWD	●	●	●	●	●	○	●	
2007	Sebring / 200 / Avenger	AMP	●	●	●	●	●	○	●	0069, 006D, 0079, 0068, 02F6
2007	Sebring / 200 / Avenger	WCM	●	●	●	●	●	○	●	01D2, 0228, 0226, 0225, 0232, 0230, 0231, 022F, 01DE, 0233, 022D, 023D, 023E, 0271, 0270
2007	Sebring / 200 / Avenger	RADIO	●	●	●	●	●	●	●	
2007	Sebring / 200 / Avenger	CCN	●	●	●	●	●	●	●	008C, 008F, 008E, 0094, 0092, 0096
2007	Sebring / 200 / Avenger	PTCM	●	●	●	●	●	○	●	
2007	Sebring / 200 / Avenger	TCM	●	●	●	●	●	●	●	0167, 0166, 01EE, 016A, 0169, 016C, 016B, 016E, 016D, 01F0, 0172, 0177, 0170, 0175, 027B, 027C, 027D, 0291, 02F8, 0290, 027E, 0176, 024E, 01FB, 016F, 01FC
2007	Sebring / 200 / Avenger	VES3	●	●	●	●	●	●	●	
2007	Sebring / 200 / Avenger	ORC	●	●	●	●	●	○	●	
2007	Sebring / 200 / Avenger	HFM	●	●	●	●	●	●	○	
2007	Nitro	ITM	●	●	●	●	●	●	●	
2007	Nitro	SAS	●	●	●	●	○	○	○	
2007	Nitro	HFM	●	●	●	●	●	●	○	
2007	Nitro	DMFR	●	●	●	●	●	●	●	
2007	Nitro	ORC	●	●	●	●	●	○	●	
2007	Nitro	CCN	●	●	●	●	●	●	●	
2007	Nitro	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2007	Nitro	WCM	●	●	●	●	●	○	●	01D2, 0228, 0226, 0225, 0232, 0230, 0231, 022F, 01DE, 0233, 022D, 0227, 0274
2007	Nitro	ESM	●	●	●	●	●	●	○	
2007	Nitro	RADIO	●	●	●	●	●	●	●	
2007	Nitro	TIPMCGW	●	●	●	●	●	●	●	003F, 003A, 021F
2007	Nitro	HVAC	●	●	●	●	●	●	●	
2007	Nitro	AMP	●	●	●	●	●	○	●	
2007	Nitro	OCM	●	●	●	●	●	○	○	011E
2007	Nitro	DMFL	●	●	●	●	●	●	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2007	Nitro	PCM	●	●	●	●	●	●	●	027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 0044, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 012D, 0177, 0173, 012A, 0281, 0280, 0176, 024E, 0170, 016F, 012B, 0269, 01FC, 013B, 02BA, 02BF, 02BD, 0049, 031D, 02C1, 02C2
2007	Nitro	TCM	●	●	●	●	●	○	○	01F3, 01F2
2007	Nitro	VES3	●	●	●	●	●	●	●	
2007	Nitro	PTS	●	●	●	●	●	●	●	01B8
2007	Liberty	SAS	●	●	●	●	●	○	○	
2007	Liberty	PCM	●	●	●	●	●	●	●	0127, 0126, 0044, 0411, 0129, 026C, 026D, 0128, 012E, 012F, 013C, 012C, 012D, 0173, 012A, 012B, 013B, 027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0140, 027E, 0266, 0265, 0145, 02FB, 0177, 0281, 0280, 0176, 024E, 0170, 016F, 0269, 01FC
2007	Liberty	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2007	Liberty	ITM	●	○	○	●	○	●	○	
2007	Liberty	RADIO	●	●	●	●	●	●	●	
2007	Liberty	MIC/CCN	●	●	●	●	○	●	○	008C, 804F, 8050, 8051, 8052
2007	Liberty	EOM	●	●	●	○	○	○	○	
2007	Liberty	SKREEM	●	●	●	●	●	○	○	8003, 8004, 8005, 8006, 8007, 01D2, 800D, 8008, 8009, 800A, 800B, 800C, 01DE, 800E, 01DA
2007	Liberty	PCM	●	●	●	●	●	●	●	
2007	Liberty	OCM	●	●	●	●	○	○	○	011E, 801A, 8023, 8024
2007	Liberty	HFM	●	●	●	●	○	●	○	
2007	Liberty	TCM	●	●	●	●	●	●	○	
2007	Liberty	ORC	●	●	●	●	●	●	●	
2007	Liberty	BCM	●	●	●	●	○	●	○	0081, 8018, 8017, 8015, 8057, 8012, 003F, 002E, 8058
2007	Liberty	SDAR	●	●	●	●	●	●	○	
2007	300 / Magnum / Charger (Pre-2011)	WCM	●	●	●	●	●	○	●	01D2, 0228, 0226, 0225, 0227, 0232, 0230, 0231, 022F, 01DE, 0233, 022D, 023D, 023E, 0271, 0270
2007	300 / Magnum / Charger (Pre-2011)	HFM	●	●	●	●	●	●	○	
2007	300 / Magnum / Charger (Pre-2011)	TCM	●	●	●	●	●	○	○	01F3, 01F2
2007	300 / Magnum / Charger (Pre-2011)	EOM	●	●	●	●	●	○	●	
2007	300 / Magnum / Charger (Pre-2011)	CCN	●	●	●	●	●	●	○	
2007	300 / Magnum / Charger (Pre-2011)	PCM	●	●	●	●	●	●	●	0042, 0149, 0142, 0044, 0145, 012D, 0045, 0046, 014B, 0173, 014A, 0049, 014D, 0146, 0147, 013B, 027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 02FB, 013C, 012C, 0177, 012A, 0281, 0280, 0176, 024E, 0170, 016F, 012B, 0269, 01FC
2007	300 / Magnum / Charger (Pre-2011)	ACC	●	●	●	●	●	○	●	0064, 0321
2007	300 / Magnum / Charger (Pre-2011)	AMP	●	●	●	●	●	○	●	0289, 028B, 028A, 006D, 006B, 0073, 006C, 0068, 006A, 0069

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2007	300 / Magnum / Charger (Pre-2011)	AHBM	●	●	●	●	●	●	○	0067, 0066
2007	300 / Magnum / Charger (Pre-2011)	MSMD	●	●	●	●	●	○	○	0117
2007	300 / Magnum / Charger (Pre-2011)	ITM	●	●	●	●	●	●	●	
2007	300 / Magnum / Charger (Pre-2011)	PDM	●	●	●	●	●	●	●	
2007	300 / Magnum / Charger (Pre-2011)	VES	●	●	●	●	●	●	○	
2007	300 / Magnum / Charger (Pre-2011)	FCMCGW	●	●	●	●	●	●	●	0039, 003C, 003D, 0032, 003F, 003E, 0036, 0037, 0035, 0034, 0038, 00C8, 003A, 002E, 0033
2007	300 / Magnum / Charger (Pre-2011)	HSM	●	●	●	●	●	●	●	
2007	300 / Magnum / Charger (Pre-2011)	PTIM	●	●	●	●	●	●	●	
2007	300 / Magnum / Charger (Pre-2011)	SUNR	●	●	●	●	●	●	○	
2007	300 / Magnum / Charger (Pre-2011)	HVAC	●	●	●	●	●	●	○	00EA, 00E9
2007	300 / Magnum / Charger (Pre-2011)	LRSM	●	●	●	●	●	○	○	
2007	300 / Magnum / Charger (Pre-2011)	ESM	●	●	●	●	●	●	○	
2007	300 / Magnum / Charger (Pre-2011)	SCM	●	●	●	●	○	●	●	
2007	300 / Magnum / Charger (Pre-2011)	SDAR	●	●	●	●	●	○	○	
2007	300 / Magnum / Charger (Pre-2011)	RADIO	●	●	●	●	●	○	●	
2007	300 / Magnum / Charger (Pre-2011)	HIDT	●	●	●	●	●	●	○	
2007	300 / Magnum / Charger (Pre-2011)	ORC	●	●	●	●	○	●	○	
2007	300 / Magnum / Charger (Pre-2011)	DDM	●	●	●	●	●	●	●	
2007	300 / Magnum / Charger (Pre-2011)	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2007	300 / Magnum / Charger (Pre-2011)	PTS	●	●	●	●	○	●	○	01B4, 01B3, 01B5, 01B8
2007	Compass	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2007	Compass	SDAR	●	●	●	●	●	○	○	
2007	Compass	ORC	●	●	●	●	●	○	●	
2007	Compass	SAS	●	●	●	●	○	○	○	
2007	Compass	OCM	●	●	●	●	●	○	○	011E
2007	Compass	CCN	●	●	●	●	●	●	●	008C, 008F, 008E, 0094, 0092, 0096
2007	Compass	RADIO	●	●	●	●	●	○	●	
2007	Compass	AMP	●	●	●	●	●	○	●	0289, 028A, 006D, 006B, 006C, 0068, 006A
2007	Compass	PCM	●	●	●	●	●	●	●	0042, 0142, 012D, 0310, 0173, 03A3, 03A4, 013B, 02E7, 0140, 013E, 0126, 0141, 0044, 0128, 012E, 0314, 012C, 012B, 0144
2007	Compass	TIPMCGW	●	●	●	●	●	●	●	003F, 020E, 0215, 028F, 0211
2007	Compass	TCM	●	●	●	●	●	●	●	
2007	Compass	HFM	●	●	●	●	●	●	○	
2007	Compass	WCM	●	●	●	●	●	○	●	01D2, 0228, 0226, 0225, 0232, 0230, 0231, 022F, 01DE, 0233, 022D, 023D, 023E, 0271, 0270
2007	Compass	AWD	●	●	●	●	●	●	●	
2007	Compass	ITM	●	●	●	●	●	●	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2007	Dakota	SDAR	●	●	●	●	●	○	○	
2007	Dakota	ORC	●	●	●	●	●	○	●	
2007	Dakota	HVAC	●	●	●	●	●	●	●	00EA, 00E8, 00E9
2007	Dakota	EOM	●	●	●	●	●	●	●	
2007	Dakota	AMP	●	●	●	●	●	○	●	0069, 006D, 0079, 0068, 02F6, 0303
2007	Dakota	FCMCGW	●	●	●	●	●	●	●	0039, 003C, 003D, 0032, 003E, 0036, 00D5, 00D8, 0037, 0035, 0034, 00DB, 00D6, 00D9, 003A, 0033, 00C6, 0040, 00DA, 0272, 0273
2007	Dakota	OCM	●	●	●	●	●	○	○	011E
2007	Dakota	RADIO	●	●	●	●	●	○	●	
2007	Dakota	CCN	●	●	●	●	●	●	●	008F, 008E, 008D, 0090
2007	Dakota	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2007	Dakota	WCM	●	●	●	●	●	○	●	01D2, 0228, 0232, 0230, 0231, 022F, 01DE, 0233, 022D, 023D, 023E, 0271, 0270
2007	Dakota	PCM	●	●	●	●	●	●	●	027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 0044, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 012D, 0177, 0173, 012A, 0281, 0280, 0176, 024E, 0170, 016F, 012B, 0269, 01FC, 013B
2007	Raider	CCN	●	●	●	●	●	●	●	008F, 008E, 008D, 0090
2007	Raider	EOM	●	●	●	●	●	●	●	
2007	Raider	FCMCGW	●	●	●	●	●	●	●	0039, 003C, 003D, 0032, 003E, 0036, 00D5, 00D8, 0037, 0035, 0034, 00DB, 00D6, 00D9, 003A, 0033, 00C6, 0040, 00DA, 0272, 0273
2007	Raider	WCM	●	●	●	●	●	○	●	01D2, 0228, 0232, 0230, 0231, 022F, 01DE, 0233, 022D, 023D, 023E, 0271, 0270
2007	Raider	HVAC	●	●	●	●	●	●	●	00EA, 00E8, 00E9
2007	Raider	SDAR	●	●	●	●	●	○	○	
2007	Raider	PCM	●	●	●	●	●	●	●	027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 0044, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 012D, 0177, 0173, 012A, 0281, 0280, 0176, 024E, 0170, 016F, 012B, 0269, 01FC, 013B
2007	Raider	OCM	●	●	●	●	●	○	○	011E
2007	Raider	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2007	Raider	RADIO	●	●	●	●	●	○	●	
2007	Raider	ORC	●	●	●	●	●	○	●	
2007	Raider	AMP	●	●	●	●	●	○	●	0069, 006D, 0079, 0068, 0303, 02F6
2007	Caliber	OCM	●	●	●	●	●	○	○	011E
2007	Caliber	WCM	●	●	●	●	●	○	●	01D2, 0228, 0226, 0225, 0232, 0230, 0231, 022F, 01DE, 0233, 022D, 023D, 023E, 0271, 0270
2007	Caliber	HFM	●	●	●	●	●	●	○	
2007	Caliber	PCM	●	●	●	●	●	●	●	0042, 0142, 012D, 0310, 0173, 03A3, 03A4, 013B, 0144, 02E7, 0140, 013E, 0126, 0141, 0044, 0128, 012E, 0314, 012C, 012B
2007	Caliber	CCN	●	●	●	●	●	●	●	008C, 008F, 008E, 0094, 0092, 0096

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2007	Caliber	ITM	●	●	●	●	●	●	●	
2007	Caliber	SAS	●	●	●	●	○	○	○	
2007	Caliber	RADIO	●	●	●	●	●	○	●	
2007	Caliber	AMP	●	●	●	●	●	○	●	0289, 028A, 006D, 006B, 006C, 0068, 006A
2007	Caliber	SDAR	●	●	●	●	●	○	○	
2007	Caliber	TCM	●	●	●	●	●	●	●	
2007	Caliber	AWD	●	●	●	●	●	●	●	
2007	Caliber	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2007	Caliber	ORC	●	●	●	●	●	○	●	
2007	Caliber	TIPMCGW	●	●	●	●	●	●	●	003F, 020E, 0215, 028F, 0211
2007	PT Cruiser	WCM	●	●	●	●	●	○	●	01D2, 0228, 0226, 0225, 0232, 0230, 0231, 022F, 01DE, 0233, 022D, 023D, 023E, 0271, 0270
2007	PT Cruiser	ITM	●	●	●	●	●	●	●	
2007	PT Cruiser	SDAR	●	●	●	●	●	○	○	
2007	PT Cruiser	TCM	●	●	●	●	○	●	●	0167, 0166, 01EE, 016A, 0169, 016C, 016B, 016E, 016D, 01F0, 0172, 0177, 0170, 0175
2007	PT Cruiser	RADIO	●	●	●	●	●	○	●	
2007	PT Cruiser	TIPMCGW	●	●	●	●	●	●	●	003F, 020E, 0215, 028F, 028E, 0211
2007	PT Cruiser	CCN	●	●	●	●	●	●	●	008C, 008F, 008E, 0094, 0092, 0096
2007	PT Cruiser	DDM	●	●	●	●	●	●	○	
2007	PT Cruiser	OCM	●	●	●	●	●	○	○	011E
2007	PT Cruiser	PCM	●	●	●	●	●	●	●	0042, 0149, 0142, 0044, 0145, 012D, 0173, 0049, 013B, 0127, 0126, 0411, 0129, 026C, 026D, 0128, 012E, 012F, 013C, 012C, 012A, 012B
2007	PT Cruiser	ORC	●	●	●	●	●	○	●	
2007	PT Cruiser	ABS	●	●	●	●	●	●	●	005E, 0060, 005B
2007	PT Cruiser	PDM	●	●	●	●	○	●	○	
2007	PT Cruiser	HFM	●	●	●	●	●	●	○	
2007	PT Cruiser	AMP	●	●	●	●	●	○	●	0289, 028A, 006D, 006B, 006C, 0068, 006A
2007	PT Cruiser	PCM	●	●	●	●	○	●	○	
2007	PT Cruiser	CAN GW	●	●	●	●	●	○	●	
2007	Sprinter	HVAC	●	●	●	●	●	●	●	0012
2007	Sprinter	BCH	●	●	●	●	●	●	○	
2007	Sprinter	AEHM	●	●	●	●	●	○	○	0004
2007	Sprinter	ECM	●	●	●	●	●	●	●	0025, 0024, 001E, 0023, 0022, 0020, 0021, 0042, 0142, 0127, 0044, 0337, 0045, 0046, 0043, 0049, 014D, 026E, 002E, 026F, 0336
2007	Sprinter	RCM	●	●	●	●	●	●	○	
2007	Sprinter	EISCGW	●	●	●	●	●	○	●	002C, 002B, 002A

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2007	Sprinter	ESM	●	●	●	●	●	●	○	
2007	Sprinter	TCM	●	●	●	●	●	○	○	02D6, 02D7, 02D4, 02D5, 0018
2007	Sprinter	TM	●	●	●	●	○	○	○	
2007	Sprinter	ABS	●	●	●	●	●	○	●	032D, 0002, 0001, 0003
2007	Sprinter	PSM	●	●	●	●	●	●	○	
2007	Sprinter	DDM	●	●	●	●	●	●	○	
2007	Sprinter	CCN	●	●	●	●	●	○	○	0007, 0008, 0005, 0334, 0006, 032F, 0330, 0331, 0332, 0333, 0009, 000A, 032E
2007	Sprinter	SBM	●	●	●	●	●	●	○	
2007	Sprinter	ACH	●	●	●	●	●	●	○	
2007	Sprinter	ORC	●	●	●	○	●	○	○	0014, 0013, 02CF
2007	Sprinter	RADIO	●	●	●	●	●	○	○	
2007	Sprinter	PTS	●	●	●	●	●	●	●	02D2, 02D3
2007	Sprinter	BCM	●	●	●	●	●	●	○	
2007	Sprinter	TPM	●	●	●	●	●	○	○	02D0, 02D1, 001A, 001B, 001C, 001D, 0247, 004E
2007	Sprinter	AHLM	●	●	●	●	●	●	○	029F
2007	Sprinter	SCM	●	●	●	●	●	●	○	
2007	Sprinter	CDC	●	●	●	●	●	○	○	
2007	Sprinter	HFM	●	●	●	●	●	○	○	
2007	Grand Cherokee	HVAC	●	●	●	●	●	●	○	00EA, 00E9
2007	Grand Cherokee	ORC	●	●	●	●	●	○	●	
2007	Grand Cherokee	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2007	Grand Cherokee	WCM	●	●	●	●	●	○	●	01D2, 0228, 0232, 0230, 0231, 022F, 01DE, 0233, 022D, 023D, 023E, 0271, 0270
2007	Grand Cherokee	VES	●	●	●	●	●	●	○	
2007	Grand Cherokee	HSM	●	●	●	●	●	●	●	
2007	Grand Cherokee	TM	●	●	●	○	○	○	○	
2007	Grand Cherokee	ITM	●	●	●	●	●	●	●	
2007	Grand Cherokee	LRSM	●	●	●	●	●	○	○	
2007	Grand Cherokee	MSMD	●	●	●	●	●	○	○	0117
2007	Grand Cherokee	PDM	●	●	●	●	●	●	●	
2007	Grand Cherokee	SCM	●	●	●	●	●	○	●	
2007	Grand Cherokee	HFM	●	●	●	●	●	●	○	
2007	Grand Cherokee	ESM	●	●	●	●	●	●	○	
2007	Grand Cherokee	RADIO	●	●	●	●	●	○	●	
2007	Grand Cherokee	TCM	●	●	●	●	●	○	○	01F3, 01F2

[illegible]



YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2007	Commander	PLGM	●	●	●	●	●	●	●	
2007	Commander	HFM	●	●	●	●	●	●	○	
2007	Commander	HVAC	●	●	●	●	●	●	○	00EA, 00E9
2007	Commander	TM	●	●	●	○	○	○	○	
2007	Commander	RADIO	●	●	●	●	●	○	●	
2007	Commander	SCM	●	●	●	●	●	○	●	
2007	Commander	SDAR	●	●	●	●	●	○	○	
2007	Commander	HSM	●	●	●	●	●	●	●	
2007	Commander	ESM	●	●	●	●	●	●	○	
2007	Commander	PTS	●	●	●	●	○	●	○	01B4, 01B3, 01B5, 01B8
2007	Commander	FDCM	●	●	●	●	●	●	●	
2007	Crossfire	OCM	●	●	●	●	○	○	○	
2007	Crossfire	ORC	●	●	●	●	○	○	○	
2007	Crossfire	BCM	●	●	●	●	○	●	○	
2007	Crossfire	SLA	●	●	●	●	○	●	○	
2007	Crossfire	SKREEM	●	●	●	●	○	●	○	
2007	Crossfire	TPM	●	●	●	●	●	○	●	8001, 8002
2007	Crossfire	HVAC	●	●	●	●	○	●	○	
2007	Crossfire	CLP	●	●	●	●	○	●	○	
2007	Crossfire	TCM	●	●	●	●	●	●	●	
2007	Crossfire	ESP	●	●	●	●	○	●	○	
2007	Crossfire	IC	●	●	●	●	○	●	○	8070, 807D
2007	Crossfire	PCM	●	●	●	●	○	●	○	
2007	Crossfire	PTCM	●	●	●	●	○	●	○	
2008	Pacifica	PCM	●	●	●	●	●	●	●	027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 0044, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 012D, 0177, 0173, 012A, 0281, 0280, 0176, 024E, 0170, 016F, 012B, 0269, 01FC, 013B
2008	Pacifica	SAS	●	●	●	●	○	○	○	
2008	Pacifica	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2008	Pacifica	AWD	●	●	●	●	●	○	●	
2008	Pacifica	BCMCGW	●	●	●	●	●	●	●	007E, 007D
2008	Pacifica	ORC	●	●	●	●	●	●	●	
2008	Pacifica	PLGM	●	●	●	●	●	●	●	
2008	Pacifica	SDAR	●	●	●	●	●	●	○	
2008	Pacifica	OCM	●	●	●	●	○	○	○	011E, 802A, 802B, 8023, 8024
2008	Pacifica	PDM	●	●	●	●	○	●	○	
2008	Pacifica	RADIO	●	●	●	○	○	●	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2008	Pacifica	PTS	●	●	●	●	●	●	○	
2008	Pacifica	IPM	●	●	●	●	○	●	○	
2008	Pacifica	SKREEM	●	●	●	●	●	○	○	8003, 8004, 8005, 8006, 8007, 01D2, 800D, 8008, 8009, 800A, 800B, 800C, 01DE, 800E, 01DA
2008	Pacifica	AMP	●	●	●	○	○	○	○	
2008	Pacifica	EOM	●	●	●	○	○	○	○	
2008	Pacifica	MTC	●	●	●	●	○	●	○	
2008	Pacifica	DDM	●	●	●	●	○	●	○	
2008	Pacifica	HFM	●	●	●	●	○	●	○	
2008	Pacifica	ATC	●	●	●	●	●	●	○	
2008	Pacifica	MIC/CCN	●	●	●	●	○	●	○	
2008	Pacifica	MHSM	●	●	●	●	○	●	○	
2008	Pacifica	NAV	●	●	●	○	○	○	○	
2008	Dodge Ram	SUNR	●	●	●	●	●	●	○	
2008	Dodge Ram	WCM	●	●	●	●	●	○	●	01D2, 0228, 0226, 0225, 0230, 0231, 0233, 033F, 023D, 023E, 0271, 0270
2008	Dodge Ram	AMP	●	●	●	●	●	○	●	028A, 028D, 006D, 006C, 027F, 0068, 006A
2008	Dodge Ram	SDAR	●	●	●	●	●	○	○	
2008	Dodge Ram	RADIO	●	●	●	●	●	○	●	
2008	Dodge Ram	TCM	●	●	●	●	●	●	○	01F6, 027B, 0167, 0166, 01EE, 027C, 016A, 0169, 027D, 0291, 016C, 016B, 02F8, 0290, 027E, 016E, 016D, 0177, 0176, 024E, 01FB, 016F, 01FC
2008	Dodge Ram	CCN	●	●	●	●	●	●	●	008C, 008F, 008E, 0090
2008	Dodge Ram	EOM	●	●	●	●	●	●	●	
2008	Dodge Ram	PCM	●	●	●	●	●	●	●	0156, 0157, 0154, 0155, 0141, 0044, 0150, 0151, 033D, 017B, 0292, 0173, 0049, 0276, 0277, 033B, 033C, 017A, 0178, 0179, 0278, 039A, 013B, 033A, 0153, 015A, 0159, 012D, 0158, 014F, 027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 0177, 012A, 0281, 0280, 0176, 024E, 0170, 016F, 012B, 0269, 01FC, 0152
2008	Dodge Ram	VES	●	●	●	●	●	●	○	
2008	Dodge Ram	TIPMCGW	●	●	●	●	●	●	●	003F, 020E, 0215, 028F, 0211
2008	Dodge Ram	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2008	Dodge Ram	HVAC	●	●	●	●	●	●	●	00EA, 00E8, 00E9, 00EB
2008	Dodge Ram	ORC	●	●	●	●	●	○	●	
2008	Dodge Ram	FDCM	●	●	●	●	●	○	○	
2008	Dodge Ram	SAS	●	●	●	●	○	○	○	
2008	Dodge Ram	HFM	●	●	●	●	●	●	○	
2008	Durango (Pre-2011)	AMP	●	●	●	●	●	○	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2008	Durango (Pre-2011)	HVAC	●	●	●	●	●	●	●	00EA, 00E9, 0323, 00E8, 0324
2008	Durango (Pre-2011)	VES3	●	●	●	●	●	●	●	
2008	Durango (Pre-2011)	EOM	●	●	●	●	●	●	●	
2008	Durango (Pre-2011)	WCM	●	●	●	●	●	○	●	01D2, 0228, 0226, 0225, 0232, 0231, 022F, 01DE, 0233, 023E, 0271
2008	Durango (Pre-2011)	HFM	●	●	●	●	●	●	○	
2008	Durango (Pre-2011)	PCM	●	●	●	●	●	●	●	027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 0044, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 012D, 0177, 0173, 012A, 0281, 0280, 0176, 024E, 0170, 016F, 012B, 0269, 01FC, 013B
2008	Durango (Pre-2011)	CCN	●	●	●	●	●	●	●	008F, 008E, 008D, 0090
2008	Durango (Pre-2011)	ORC	●	●	●	●	●	○	●	
2008	Durango (Pre-2011)	PTS	●	●	●	●	●	●	●	01B8
2008	Durango (Pre-2011)	HSM	●	●	●	●	●	●	●	
2008	Durango (Pre-2011)	RADIO	●	●	●	●	●	●	●	
2008	Durango (Pre-2011)	DDM	●	●	●	●	●	●	●	
2008	Durango (Pre-2011)	PTIM	●	●	●	●	●	●	●	
2008	Durango (Pre-2011)	PDM	●	●	●	●	●	●	●	
2008	Durango (Pre-2011)	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2008	Durango (Pre-2011)	MSMD	●	●	●	●	●	○	○	0117
2008	Durango (Pre-2011)	FCMCGW	●	●	●	●	●	●	●	02F1, 02F0, 02F3, 02EF, 0039, 003C, 003D, 02A6, 02A5, 02A4, 0032, 003E, 0036, 00D5, 00D8, 0037, 0035, 0034, 00DB, 00D6, 00D9, 003A, 0293, 0033, 00C6, 0040, 00DA, 0272, 0273
2008	Durango (Pre-2011)	SAS	●	●	●	●	○	○	○	
2008	Durango (Pre-2011)	PLGM	●	●	●	●	●	●	●	
2008	Aspen	HSM	●	●	●	●	●	●	●	
2008	Aspen	PLGM	●	●	●	●	●	●	●	
2008	Aspen	AMP	●	●	●	●	●	○	●	
2008	Aspen	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2008	Aspen	DDM	●	●	●	●	●	●	●	
2008	Aspen	HVAC	●	●	●	●	●	●	●	00EA, 00E8, 00E9, 0324, 0323
2008	Aspen	WCM	●	●	●	●	●	○	●	01D2, 0228, 0226, 0225, 0232, 0231, 022F, 01DE, 0233, 023E, 0271
2008	Aspen	SAS	●	●	●	●	○	○	○	
2008	Aspen	EOM	●	●	●	●	●	●	●	
2008	Aspen	PTIM	●	●	●	●	●	●	●	
2008	Aspen	RADIO	●	●	●	●	●	●	●	
2008	Aspen	FCMCGW	●	●	●	●	●	●	●	02F1, 02F0, 02F3, 02EF, 0039, 003C, 003D, 02A6, 02A5, 02A4, 0032, 003E, 0036, 00D5, 00D8, 0037, 0035, 0034, 00DB, 00D6, 00D9, 003A, 0293, 0033, 00C6, 0040, 00DA, 0272, 0273

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2008	Aspen	MSMD	●	●	●	●	●	○	○	0117
2008	Aspen	VES3	●	●	●	●	●	●	●	
2008	Aspen	PDM	●	●	●	●	●	●	●	
2008	Aspen	CCN	●	●	●	●	●	●	●	008F, 008E, 008D, 0090
2008	Aspen	HFM	●	●	●	●	●	●	○	
2008	Aspen	PCM	●	●	●	●	●	●	●	027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 0044, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 012D, 0177, 0173, 012A, 0281, 0280, 0176, 024E, 0170, 016F, 012B, 0269, 01FC, 013B
2008	Aspen	PTS	●	●	●	●	●	●	●	01B8
2008	Aspen	ORC	●	●	●	●	●	○	●	
2008	Wrangler (Export)	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2008	Wrangler (Export)	TIPMCGW	●	●	●	●	●	●	●	003F, 003A, 002E, 021F
2008	Wrangler (Export)	WCM	●	●	●	●	●	○	●	
2008	Wrangler (Export)	SAS	●	●	●	●	○	○	○	
2008	Wrangler (Export)	PCM	●	●	●	●	●	●	○	0145, 02BA, 02BF, 02BD, 0044, 0049, 031D, 02C1, 02C2
2008	Wrangler (Export)	CCN	●	●	●	●	○	●	●	
2008	Wrangler (Export)	RADIO	●	●	●	●	●	●	●	
2008	Wrangler (Export)	ORC	●	●	●	●	●	○	●	
2008	Wrangler (Export)	TCM	●	●	●	●	●	●	○	0176, 024E, 01FB, 016F, 01FC
2008	Journey	WCM	●	●	●	●	●	●	●	02A7, 03E6, 0232, 0230, 022F, 01D2, 0228, 0225, 0231, 01DE, 0233, 01DA
2008	Journey	TIPMCGW	●	●	●	●	●	●	●	003F, 003A, 02E3, 021F
2008	Journey	DMFR	●	●	●	●	●	●	●	
2008	Journey	HVAC	●	●	●	●	●	●	●	00EA, 00E9, 00EC
2008	Journey	ITM	●	●	●	●	●	●	●	
2008	Journey	PCM	●	●	●	●	●	●	●	027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 0044, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 012D, 0177, 0173, 012A, 0281, 0280, 0176, 024E, 0170, 016F, 012B, 0269, 01FC, 013B, 02E7, 013E, 0141, 012E, 0314, 0042, 0142, 0310, 0313, 0312, 03A3, 0311, 0144, 03A4
2008	Journey	DMFL	●	●	●	●	●	●	●	
2008	Journey	SAS	●	●	●	●	○	○	○	
2008	Journey	ORC	●	●	●	●	●	○	●	0122
2008	Journey	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2008	Journey	HFM	●	●	●	●	●	●	○	
2008	Journey	RADIO	●	●	●	●	●	●	●	
2008	Journey	AMP	●	●	●	●	●	○	●	
2008	Journey	VES3	●	●	●	●	●	●	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2008	Journey	CCN	●	●	●	●	○	●	●	008C, 0091, 0094, 0096
2008	Journey	DISP	●	●	●	●	●	○	○	
2008	Journey	AWD	●	●	●	●	●	○	●	
2008	Journey	TCM	●	●	●	●	●	●	●	0167, 0166, 01EE, 016A, 0169, 016C, 016B, 016E, 016D, 01F0, 0172, 0177, 0170, 0175
2008	Wrangler	ASBS	●	●	●	●	●	○	○	0317, 0318, 031A, 031B, 0319
2008	Wrangler	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2008	Wrangler	TIPMCGW	●	●	●	●	●	●	●	003F, 003A, 002E, 021F
2008	Wrangler	ITM	●	●	●	●	○	●	●	
2008	Wrangler	SAS	●	●	●	●	○	○	○	
2008	Wrangler	WCM	●	●	●	●	●	○	●	01D2, 0228, 0226, 0225, 0232, 0230, 0231, 022F, 01DE, 0233, 022D, 0227, 0274
2008	Wrangler	CCN	●	●	●	●	○	●	●	
2008	Wrangler	AMP	●	●	●	●	●	○	●	
2008	Wrangler	RADIO	●	●	●	●	●	●	●	
2008	Wrangler	ORC	●	●	●	●	●	○	●	
2008	Wrangler	PCM	●	●	●	●	●	●	●	0145, 02BA, 02BF, 02BD, 0044, 0049, 031D, 02C1, 02C2, 027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 02FB, 013C, 012C, 012D, 0177, 0173, 012A, 0281, 0280, 0176, 024E, 0170, 016F, 012B, 0269, 01FC, 013B
2008	Wrangler	TCM	●	●	●	●	●	●	○	0176, 024E, 01FB, 016F, 01FC
2008	Sebring / 200 / Avenger	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2008	Sebring / 200 / Avenger	AWD	●	●	●	●	●	○	●	
2008	Sebring / 200 / Avenger	ITM	●	●	●	●	●	●	●	
2008	Sebring / 200 / Avenger	TIPMCGW	●	●	●	●	●	●	●	003F, 020E, 0215, 028F, 0211
2008	Sebring / 200 / Avenger	AMP	●	●	●	●	●	○	●	0069, 006D, 0079, 0068, 02F6
2008	Sebring / 200 / Avenger	ORC	●	●	●	●	●	○	●	
2008	Sebring / 200 / Avenger	HVAC	●	●	●	●	●	●	●	
2008	Sebring / 200 / Avenger	HFM	●	●	●	●	●	●	○	
2008	Sebring / 200 / Avenger	PDM	●	●	●	●	●	●	○	
2008	Sebring / 200 / Avenger	DDM	●	●	●	●	●	●	○	
2008	Sebring / 200 / Avenger	WCM	●	●	●	●	●	○	●	01D2, 0228, 0226, 0225, 0232, 0230, 0231, 0233, 022D, 023D, 023E, 0271, 0270
2008	Sebring / 200 / Avenger	SAS	●	●	●	●	○	○	○	
2008	Sebring / 200 / Avenger	CCN	●	●	●	●	●	●	●	008C, 008F, 008E, 0094, 0092, 0096
2008	Sebring / 200 / Avenger	VES3	●	●	●	●	●	●	●	
2008	Sebring / 200 / Avenger	RADIO	●	●	●	●	●	●	●	
2008	Sebring / 200 / Avenger	PTCM	●	●	●	●	●	○	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2008	Sebring / 200 / Avenger	PCM	●	●	●	●	●	●	●	027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 0044, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 012D, 0177, 0173, 012A, 0281, 0280, 0176, 024E, 0170, 016F, 012B, 0269, 01FC, 013B, 0042, 0142, 0310, 03A3, 0144, 03A4, 02E7, 013E, 0141, 012E, 0314
2008	Sebring / 200 / Avenger	TCM	●	●	●	●	●	●	●	0167, 0166, 01EE, 016A, 0169, 016C, 016B, 016E, 016D, 01F0, 0172, 0177, 0170, 0175, 027B, 027C, 027D, 0291, 02F8, 0290, 027E, 0176, 024E, 01FB, 016F, 01FC
2008	Nitro	TCM	●	●	●	●	●	○	○	01F3, 01F2
2008	Nitro	AMP	●	●	●	●	●	○	●	
2008	Nitro	RADIO	●	●	●	●	●	●	●	
2008	Nitro	HVAC	●	●	●	●	●	●	●	
2008	Nitro	DMFL	●	●	●	●	●	●	●	
2008	Nitro	HFM	●	●	●	●	●	●	○	
2008	Nitro	ORC	●	●	●	●	●	○	●	
2008	Nitro	PTS	●	●	●	●	●	●	●	01B8
2008	Nitro	ESM	●	●	●	●	●	●	○	
2008	Nitro	TIPMCGW	●	●	●	●	●	●	●	003F, 003A, 021F, 02E2
2008	Nitro	DMFR	●	●	●	●	●	●	●	
2008	Nitro	WCM	●	●	●	●	●	○	●	01D2, 0228, 0226, 0225, 0232, 0230, 0231, 022F, 01DE, 0233, 022D, 0227, 0274
2008	Nitro	CCN	●	●	●	●	○	●	●	
2008	Nitro	SAS	●	●	●	●	○	○	○	
2008	Nitro	ITM	●	●	●	●	●	●	●	
2008	Nitro	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2008	Nitro	OCM	●	●	●	●	●	○	○	011E
2008	Nitro	VES3	●	●	●	●	●	●	●	
2008	Nitro	PCM	●	●	●	●	●	●	●	0145, 02BA, 02BF, 02BD, 0044, 0049, 031D, 02C1, 02C2, 027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 02FB, 013C, 012C, 012D, 0177, 0173, 012A, 0281, 0280, 0176, 024E, 0170, 016F, 012B, 0269, 01FC, 013B
2008	Liberty	TIPMCGW	●	●	●	●	●	●	●	003F, 003A, 021F, 02E2
2008	Liberty	MSMD	●	●	●	●	●	○	○	0117
2008	Liberty	CCN	●	●	●	●	●	●	●	
2008	Liberty	FDCM	●	●	●	●	●	●	○	
2008	Liberty	SUNR	●	●	●	●	●	○	○	
2008	Liberty	ORC	●	●	●	●	●	○	●	
2008	Liberty	SAS	●	●	●	●	○	○	○	
2008	Liberty	DMFL	●	●	●	●	●	●	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2008	Liberty	RADIO	●	●	●	●	●	●	●	
2008	Liberty	HVAC	●	●	●	●	●	●	●	
2008	Liberty	TCM	●	●	●	●	●	○	○	01F3, 01F2
2008	Liberty	ITM	●	●	●	●	●	●	●	
2008	Liberty	ESM	●	●	●	●	●	●	○	
2008	Liberty	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2008	Liberty	HFM	●	●	●	●	●	●	○	
2008	Liberty	DMFR	●	●	●	●	●	●	●	
2008	Liberty	VES3	●	●	●	●	●	●	●	
2008	Liberty	PTS	●	●	●	●	●	●	●	01B8
2008	Liberty	OCM	●	●	●	●	●	○	○	011E
2008	Liberty	PCM	●	●	●	●	●	●	●	0145, 02BA, 02BF, 02BD, 0044, 0049, 031D, 02C1, 02C2, 027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 02FB, 013C, 012C, 012D, 0177, 0173, 012A, 0281, 0280, 0176, 024E, 0170, 016F, 012B, 0269, 01FC, 013B
2008	Liberty	WCM	●	●	●	●	●	○	●	01D2, 0228, 0226, 0225, 0232, 0230, 0231, 022F, 01DE, 0233, 022D, 0227, 0274
2008	Liberty	AMP	●	●	●	●	●	○	●	
2008	Challenger	PCM	●	●	●	●	●	●	●	027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 0044, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 012D, 0177, 0173, 012A, 0281, 0280, 0176, 024E, 0170, 016F, 012B, 0269, 01FC, 013B
2008	Challenger	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2008	Challenger	ESM	●	●	●	●	●	●	○	
2008	Challenger	WCM	●	●	●	●	●	●	●	01D2, 0228, 0225, 02A7, 03E6, 0232, 0230, 022F
2008	Challenger	HSM	●	●	●	●	●	●	●	
2008	Challenger	ORC	●	●	●	●	●	○	●	
2008	Challenger	EOM	●	●	●	●	●	○	●	
2008	Challenger	PEM	●	●	●	●	●	○	●	0442
2008	Challenger	DDM	●	●	●	●	●	●	○	
2008	Challenger	TPM	●	●	●	●	○	○	●	02F7, 0232, 0230, 0231, 022F
2008	Challenger	RADIO	●	●	●	●	●	●	●	
2008	Challenger	HVAC	●	●	●	●	●	●	●	
2008	Challenger	SUNR	●	●	●	●	●	●	○	
2008	Challenger	AMP	●	●	●	●	●	○	●	
2008	Challenger	HFM	●	●	●	●	●	●	○	
2008	Challenger	TCM	●	●	●	●	●	○	○	01F3, 01F2
2008	Challenger	CCN	●	●	●	●	●	●	●	
2008	Challenger	SCM	●	●	●	●	○	●	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2008	Challenger	TIPMCGW	●	●	●	●	●	●	●	
2008	Challenger	PDM	●	●	●	●	●	●	○	
2008	300 / Magnum / Charger (Pre-2011)	AHBM	●	●	●	●	●	○	○	
2008	300 / Magnum / Charger (Pre-2011)	PCM	●	●	●	●	●	●	●	027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 0044, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 012D, 0177, 0173, 012A, 0281, 0280, 0176, 024E, 0170, 016F, 012B, 0269, 01FC, 013B, 0042, 0149, 0142, 0045, 0046, 014B, 014A, 0049, 014D, 0146, 0147
2008	300 / Magnum / Charger (Pre-2011)	SDARV	●	●	●	●	●	○	○	
2008	300 / Magnum / Charger (Pre-2011)	ITM	●	●	●	●	●	●	●	
2008	300 / Magnum / Charger (Pre-2011)	ESM	●	●	●	●	●	●	○	
2008	300 / Magnum / Charger (Pre-2011)	RADIO	●	●	●	●	●	●	●	
2008	300 / Magnum / Charger (Pre-2011)	TIPMCGW	●	●	●	●	●	●	●	
2008	300 / Magnum / Charger (Pre-2011)	ACC	●	●	●	●	●	○	●	0064, 0321
2008	300 / Magnum / Charger (Pre-2011)	HIDT	●	●	●	●	●	●	○	
2008	300 / Magnum / Charger (Pre-2011)	SUNR	●	●	●	●	●	●	○	
2008	300 / Magnum / Charger (Pre-2011)	HFM	●	●	●	●	●	●	○	
2008	300 / Magnum / Charger (Pre-2011)	VES3	●	●	●	●	●	●	●	
2008	300 / Magnum / Charger (Pre-2011)	MSMD	●	●	●	●	●	○	○	0117
2008	300 / Magnum / Charger (Pre-2011)	SCM	●	●	●	●	○	●	●	
2008	300 / Magnum / Charger (Pre-2011)	WCM	●	●	●	●	●	●	●	02A7, 03E6, 0232, 0230, 022F, 01D2, 0228, 0225, 0231, 01DE, 0233, 01DA
2008	300 / Magnum / Charger (Pre-2011)	HSM	●	●	●	●	●	●	●	
2008	300 / Magnum / Charger (Pre-2011)	EOM	●	●	●	●	●	○	●	
2008	300 / Magnum / Charger (Pre-2011)	PTIM	●	●	●	●	●	●	●	
2008	300 / Magnum / Charger (Pre-2011)	AMP	●	●	●	●	●	○	●	
2008	300 / Magnum / Charger (Pre-2011)	DDM	●	●	●	●	●	●	●	
2008	300 / Magnum / Charger (Pre-2011)	PDM	●	●	●	●	●	●	●	
2008	300 / Magnum / Charger (Pre-2011)	CCN	●	●	●	●	●	●	●	
2008	300 / Magnum / Charger (Pre-2011)	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2008	300 / Magnum / Charger (Pre-2011)	TCM	●	●	●	●	●	○	○	01F3, 01F2
2008	300 / Magnum / Charger (Pre-2011)	ORC	●	●	●	●	●	○	●	
2008	300 / Magnum / Charger (Pre-2011)	PTS	●	●	●	●	○	●	○	01B4, 01B3, 01B5, 01B8
2008	300 / Magnum / Charger (Pre-2011)	HVAC	●	●	●	●	●	●	●	00EA, 00E9
2008	300 / Magnum / Charger (Pre-2011)	LRSM	●	●	●	●	●	○	○	
2008	Compass	TCM	●	●	●	●	●	●	●	
2008	Compass	ITM	●	●	●	●	●	●	●	
2008	Compass	AWD	●	●	●	●	●	●	●	



[illegible]

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2008	Raider	ORC	●	●	●	●	●	○	●	
2008	Raider	RADIO	●	●	●	●	●	●	●	
2008	Raider	HFM	●	●	●	●	●	●	○	
2008	Raider	EOM	●	●	●	●	●	○	●	
2008	Raider	WCM	●	●	●	●	●	○	●	01D2, 0228, 0226, 0225, 0232, 0231, 022F, 01DE, 0233, 023E, 0271
2008	Caliber	ITM	●	●	●	●	●	●	●	
2008	Caliber	EBG	●	●	●	●	●	○	○	
2008	Caliber	WCM	●	●	●	●	●	○	●	01D2, 0228, 0226, 0225, 0230, 0231, 0233, 022D, 023D, 023E, 0271, 0270
2008	Caliber	HFM	●	●	●	●	●	●	○	
2008	Caliber	TCM	●	●	●	●	●	●	●	
2008	Caliber	CCN	●	●	●	●	●	●	●	008C, 008F, 008E, 0094, 0092, 0096
2008	Caliber	AWD	●	●	●	●	●	●	●	
2008	Caliber	ORC	●	●	●	●	●	○	●	
2008	Caliber	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2008	Caliber	AMP	●	●	●	●	●	○	●	0289, 028A, 006D, 006B, 006C, 0068, 006A, 0069, 0073
2008	Caliber	TIPMCGW	●	●	●	●	●	●	●	003F, 020E, 0215, 028F, 0211
2008	Caliber	RADIO	●	●	●	●	●	●	●	
2008	Caliber	SAS	●	●	●	●	○	○	○	
2008	Caliber	SDAR	●	●	●	●	●	○	○	
2008	Caliber	PCM	●	●	●	●	●	●	●	0042, 0142, 012D, 0310, 0313, 0312, 0173, 03A3, 0311, 03A4, 013B, 02E7, 0140, 013E, 0126, 0141, 0044, 0128, 012E, 0314, 012C, 012B, 0144
2008	PT Cruiser	DDM	●	●	●	●	●	●	○	
2008	PT Cruiser	SDAR	●	●	●	●	●	○	○	
2008	PT Cruiser	TIPMCGW	●	●	●	●	●	●	●	003F, 020E, 0215, 028F, 028E, 0211
2008	PT Cruiser	OCM	●	●	●	●	●	○	○	011E
2008	PT Cruiser	ITM	●	●	●	●	●	●	●	
2008	PT Cruiser	PCM	●	●	●	●	●	●	●	0127, 0126, 0044, 0411, 0129, 026C, 026D, 0128, 012E, 012F, 013C, 012C, 012D, 0173, 012A, 012B, 013B, 0042, 0149, 0142, 0145, 0049
2008	PT Cruiser	ABS	●	●	●	●	●	●	●	005E, 0060, 005B
2008	PT Cruiser	RADIO	●	●	●	●	●	○	●	
2008	PT Cruiser	AMP	●	●	●	●	●	○	●	0069, 006D, 0073, 0068, 006A, 0289, 028A, 006B, 006C
2008	PT Cruiser	PDM	●	●	●	●	○	●	○	
2008	PT Cruiser	TCM	●	●	●	●	○	●	●	0167, 0166, 01EE, 016A, 0169, 016C, 016B, 016E, 016D, 01F0, 0172, 0177, 0170, 0175
2008	PT Cruiser	HFM	●	●	●	●	●	●	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2008	PT Cruiser	WCM	●	●	●	●	●	○	●	01D2, 0228, 0226, 0225, 0230, 0231, 0233, 022D, 023D, 023E, 0271, 0270
2008	PT Cruiser	ORC	●	●	●	●	●	○	●	
2008	PT Cruiser	CCN	●	●	●	●	●	●	●	008C, 008F, 008E, 0094, 0092, 0096
2008	Mini-Van	SKREEM	●	●	●	●	●	○	○	8003, 8004, 8005, 8006, 8007, 01D2, 800D, 8008, 8009, 800A, 800B, 800C, 01DE, 800E, 01DA
2008	Mini-Van	BCM	●	●	●	●	○	●	○	
2008	Mini-Van	ABS	●	●	●	●	●	○	○	
2008	Mini-Van	IPM	●	●	●	●	○	●	○	
2008	Mini-Van	ATC	●	●	●	●	○	●	○	
2008	Mini-Van	PTS	●	●	●	●	●	●	○	
2008	Mini-Van	HFM	●	●	●	●	○	●	○	
2008	Mini-Van	PSD	●	●	●	●	○	●	○	
2008	Mini-Van	PLGM	●	●	●	●	●	●	●	
2008	Mini-Van	SDAR	●	●	●	●	●	●	○	
2008	Mini-Van	ORC	●	●	●	●	○	○	○	
2008	Mini-Van	PCM	●	●	●	●	○	●	○	
2008	Mini-Van	DSD	●	●	●	●	○	●	○	
2008	Mini-Van	OCM	●	●	●	●	○	○	○	011E, 802A, 802B, 8023, 8024
2008	Mini-Van	EOM	●	●	●	○	○	○	○	
2008	Mini-Van	MIC/CCN	●	●	●	●	○	●	○	
2008	Mini-Van	MHSM	●	●	●	●	○	●	○	
2008	Mini-Van	MTC	●	●	●	●	○	●	○	
2008	Mini-Van	TCM	●	●	●	●	●	●	●	
2008	Town & Country / Caravan	PTS	●	●	●	●	●	●	●	01B8
2008	Town & Country / Caravan	MSMD	●	●	●	●	●	○	○	0117
2008	Town & Country / Caravan	HIDT	●	●	●	●	●	●	○	
2008	Town & Country / Caravan	SAS	●	●	●	●	○	○	○	
2008	Town & Country / Caravan	TCM	●	●	●	●	●	●	○	
2008	Town & Country / Caravan	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2008	Town & Country / Caravan	VES3	●	●	●	●	●	●	●	
2008	Town & Country / Caravan	TIPMCGW	●	●	●	●	●	●	●	002E
2008	Town & Country / Caravan	DMRR	●	●	●	●	●	●	●	
2008	Town & Country / Caravan	ORC	●	●	●	●	●	○	●	0122
2008	Town & Country / Caravan	DVD	●	●	●	●	●	○	○	
2008	Town & Country / Caravan	AMP	●	●	●	●	●	○	●	
2008	Town & Country / Caravan	SDARV	●	●	●	●	●	○	○	
2008	Town & Country / Caravan	DMRL	●	●	●	●	●	●	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2008	Town & Country / Caravan	RADIO	●	●	●	●	●	●	●	
2008	Town & Country / Caravan	SUNR	●	●	●	●	●	●	○	
2008	Town & Country / Caravan	HFM	●	●	●	●	●	●	○	
2008	Town & Country / Caravan	CCN	●	●	●	●	●	●	●	
2008	Town & Country / Caravan	VES2	●	●	●	●	●	●	●	
2008	Town & Country / Caravan	FSM	●	●	●	●	●	●	○	
2008	Town & Country / Caravan	PCM	●	●	●	●	●	●	●	0145, 02BA, 02BF, 02BD, 0044, 0049, 031D, 02C1, 02C2, 027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 02FB, 013C, 012C, 012D, 0177, 0173, 012A, 0281, 0280, 0176, 024E, 0170, 016F, 012B, 0269, 01FC, 013B
2008	Town & Country / Caravan	PSDMR	●	●	●	●	●	○	●	
2008	Town & Country / Caravan	WCM	●	●	●	●	●	●	●	02A7, 03E6, 0232, 0230, 022F, 01D2, 0228, 0225, 0231, 01DE, 0233, 01DA
2008	Town & Country / Caravan	DMFL	●	●	●	●	●	●	●	
2008	Town & Country / Caravan	HVAC	●	●	●	●	●	●	●	00EA, 00E9, 00EC
2008	Town & Country / Caravan	DMFR	●	●	●	●	●	●	●	
2008	Town & Country / Caravan	PLGM	●	●	●	●	●	●	●	
2008	Town & Country / Caravan	PSDML	●	●	●	●	●	○	●	
2008	Town & Country / Caravan	ITM	●	●	●	●	●	●	●	
2008	Sprinter	ECM	●	●	●	●	●	●	●	0025, 0024, 001E, 0023, 0022, 0020, 0021, 0042, 0142, 0127, 0044, 0337, 0045, 0046, 0043, 0049, 014D, 026E, 002E, 026F, 0336
2008	Sprinter	TM	●	●	●	●	○	○	○	
2008	Sprinter	PSM	●	●	●	●	●	●	○	
2008	Sprinter	AEHM	●	●	●	●	●	○	○	0004
2008	Sprinter	ESM	●	●	●	●	●	●	○	
2008	Sprinter	PTS	●	●	●	●	●	●	●	02D2, 02D3
2008	Sprinter	DDM	●	●	●	●	●	●	○	
2008	Sprinter	BCM	●	●	●	●	●	●	○	
2008	Sprinter	SBM	●	●	●	●	●	●	○	
2008	Sprinter	PSDML	●	●	●	●	○	●	○	
2008	Sprinter	EISCGW	●	●	●	●	●	○	●	002C, 002B, 002A
2008	Sprinter	RADIO	●	●	●	●	●	○	●	
2008	Sprinter	SCM	●	●	●	●	●	●	○	
2008	Sprinter	TPM	●	●	●	●	●	○	○	02D0, 02D1, 001A, 001B, 001C, 001D, 0247, 004E
2008	Sprinter	PSDMR	●	●	●	●	○	●	○	
2008	Sprinter	HVAC	●	●	●	●	●	●	●	0012
2008	Sprinter	AHLM	●	●	●	●	●	●	○	029F

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2008	Sprinter	TCM	●	●	●	●	●	○	○	02D6, 02D7, 02D4, 02D5, 0018
2008	Sprinter	ORC	●	●	●	○	●	○	○	0014, 0013, 02CF
2008	Sprinter	ACH	●	●	●	●	●	●	○	
2008	Sprinter	BCH	●	●	●	●	●	●	○	
2008	Sprinter	RCM	●	●	●	●	●	●	○	
2008	Sprinter	CCN	●	●	●	●	●	○	○	0007, 0008, 0005, 0334, 0006, 032F, 0330, 0331, 0332, 0333, 0009, 000A
2008	Sprinter	ABS	●	●	●	●	●	○	●	032D, 0002, 0001, 0003
2008	Sprinter	HFM	●	●	●	●	●	○	○	
2008	Sprinter	CDC	●	●	●	●	●	○	○	
2008	Grand Cherokee	EOM	●	●	●	●	●	○	●	
2008	Grand Cherokee	AMP	●	●	●	●	●	○	●	
2008	Grand Cherokee	DDM	●	●	●	●	●	●	●	
2008	Grand Cherokee	TM	●	●	●	○	○	○	○	
2008	Grand Cherokee	SAS	●	●	●	●	○	○	○	
2008	Grand Cherokee	PCM	●	●	●	●	●	●	●	027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 0044, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 012D, 0177, 0173, 012A, 0281, 0280, 0176, 024E, 0170, 016F, 012B, 0269, 01FC, 013B, 0042, 0149, 0142, 0045, 0046, 014B, 014A, 0049, 014D, 0146, 0147
2008	Grand Cherokee	FDCM	●	●	●	●	●	●	●	
2008	Grand Cherokee	WCM	●	●	●	●	●	●	●	01D2, 0228, 0225, 0232, 0230, 0231, 022F, 01DE, 0233, 01DA, 02A7, 03E6
2008	Grand Cherokee	PTS	●	●	●	●	●	●	●	01B4, 01B3, 01B5, 01B8, 02ED, 03B7
2008	Grand Cherokee	ESM	●	●	●	●	●	●	○	
2008	Grand Cherokee	AHLM	●	●	●	●	●	●	○	
2008	Grand Cherokee	SDARV	●	●	●	●	●	○	○	
2008	Grand Cherokee	CCN	●	●	●	●	●	●	●	0097, 008C, 008F, 008E, 0091, 0094, 0099, 0098, 0090
2008	Grand Cherokee	PDM	●	●	●	●	●	●	●	
2008	Grand Cherokee	ITM	●	●	●	●	●	●	●	
2008	Grand Cherokee	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2008	Grand Cherokee	RADIO	●	●	●	●	●	●	●	
2008	Grand Cherokee	HSM	●	●	●	●	●	●	●	
2008	Grand Cherokee	VES3	●	●	●	●	●	●	●	
2008	Grand Cherokee	TCM	●	●	●	●	●	○	○	01F3, 01F2
2008	Grand Cherokee	AHBM	●	●	●	●	●	○	○	
2008	Grand Cherokee	MSMD	●	●	●	●	●	○	○	0117
2008	Grand Cherokee	SUNR	●	●	●	●	●	●	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2008	Grand Cherokee	LRSM	●	●	●	●	●	○	○	
2008	Grand Cherokee	HFM	●	●	●	●	●	●	○	
2008	Grand Cherokee	HVAC	●	●	●	●	●	●	●	00EA, 00E9
2008	Grand Cherokee	ORC	●	●	●	●	●	○	●	0122
2008	Grand Cherokee	FCMCGW	●	●	●	●	●	●	●	02F1, 02F0, 02F3, 02EF, 0039, 003C, 003D, 02A6, 02A5, 02A4, 0032, 003E, 0036, 00D5, 00D8, 0037, 0035, 0034, 00DB, 00D6, 00D9, 003A, 0293, 0033, 00C6, 00DA, 0272, 0273
2008	Commander	MSMD	●	●	●	●	●	○	○	0117
2008	Commander	HFM	●	●	●	●	●	●	○	
2008	Commander	RADIO	●	●	●	●	●	●	●	
2008	Commander	AMP	●	●	●	●	●	○	●	
2008	Commander	SUNR	●	●	●	●	●	●	○	
2008	Commander	TCM	●	●	●	●	●	○	○	01F3, 01F2
2008	Commander	ITM	●	●	●	●	●	●	●	
2008	Commander	PLGM	●	●	●	●	●	●	●	
2008	Commander	HVAC	●	●	●	●	●	●	●	00EA, 00E9
2008	Commander	VES3	●	●	●	●	●	●	●	
2008	Commander	PDM	●	●	●	●	●	●	●	
2008	Commander	WCM	●	●	●	●	●	●	●	02A7, 03E6, 0232, 0230, 022F, 01D2, 0228, 0225, 0231, 01DE, 0233, 01DA
2008	Commander	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2008	Commander	FDCM	●	●	●	●	●	●	●	
2008	Commander	LRSM	●	●	●	●	●	○	○	
2008	Commander	SDARV	●	●	●	●	●	○	○	
2008	Commander	HSM	●	●	●	●	●	●	●	
2008	Commander	SAS	●	●	●	●	○	○	○	
2008	Commander	FCMCGW	●	●	●	●	●	●	●	02F1, 02F0, 02F3, 02EF, 0039, 003C, 003D, 02A6, 02A5, 02A4, 0032, 003E, 0036, 00D5, 00D8, 0037, 0035, 0034, 00DB, 00D6, 00D9, 003A, 0293, 0033, 00C6, 00DA, 0272, 0273
2008	Commander	ESM	●	●	●	●	●	●	○	
2008	Commander	PTS	●	●	●	●	○	●	○	01B4, 01B3, 01B5, 01B8
2008	Commander	AHBM	●	●	●	●	●	○	○	
2008	Commander	DDM	●	●	●	●	●	●	●	
2008	Commander	CCN	●	●	●	●	●	●	●	0097, 008C, 008F, 008E, 0091, 0094, 0099, 0098, 0090
2008	Commander	ORC	●	●	●	●	●	○	●	0122
2008	Commander	TM	●	●	●	○	○	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2008	Commander	PCM	●	●	●	●	●	●	●	027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 0044, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 012D, 0177, 0173, 012A, 0281, 0280, 0176, 024E, 0170, 016F, 012B, 0269, 01FC, 013B, 0042, 0149, 0142, 0045, 0046, 014B, 014A, 0049, 014D, 0146, 0147
2008	Viper (Pre-2011)	OCM	●	●	●	●	●	○	○	02AD
2008	Viper (Pre-2011)	PCM	●	●	●	●	●	●	○	013E, 0126, 0141, 0044, 0325, 0193, 0128, 0145, 0326, 012C, 012A, 0081
2008	Viper (Pre-2011)	SDAR	●	●	●	●	●	●	○	
2008	Viper (Pre-2011)	HVAC	●	●	●	●	○	●	○	
2008	Viper (Pre-2011)	RADIO	●	●	●	○	○	●	○	
2008	Viper (Pre-2011)	ABS	●	●	●	●	○	●	○	
2008	Viper (Pre-2011)	ORC	●	●	●	●	●	●	●	
2008	Viper (Pre-2011)	BCM	●	●	●	●	○	●	○	
2008	Viper (Pre-2011)	MIC/CCN	●	●	●	●	●	○	○	801A
2008	Viper (Pre-2011)	PCI to CAN Gateway	●	●	●	●	○	○	○	
2008	Crossfire	OCM	●	●	●	●	○	○	○	
2008	Crossfire	ORC	●	●	●	●	○	○	○	
2008	Crossfire	BCM	●	●	●	●	○	●	○	
2008	Crossfire	TCM	●	●	●	●	●	●	●	
2008	Crossfire	PTCM	●	●	●	●	○	●	○	
2008	Crossfire	SLA	●	●	●	●	○	●	○	
2008	Crossfire	ESP	●	●	●	●	○	●	○	
2008	Crossfire	IC	●	●	●	●	○	●	○	8070, 807D
2008	Crossfire	PCM	●	●	●	●	○	●	○	
2008	Crossfire	CLP	●	●	●	●	○	●	○	
2008	Crossfire	SKREEM	●	●	●	●	○	●	○	
2008	Crossfire	TPM	●	●	●	●	●	○	●	8001, 8002
2008	Crossfire	HVAC	●	●	●	●	○	●	○	
2009	Dodge Ram	CCN	●	●	●	●	●	●	●	008C, 008F, 008E, 0090
2009	Dodge Ram	SDAR	●	●	●	●	●	○	○	
2009	Dodge Ram	SUNR	●	●	●	●	●	●	○	
2009	Dodge Ram	EOM	●	●	●	●	●	●	●	
2009	Dodge Ram	VES	●	●	●	●	●	●	○	
2009	Dodge Ram	AMP	●	●	●	●	●	○	●	028A, 028D, 006D, 006C, 027F, 0068, 006A
2009	Dodge Ram	SAS	●	●	●	●	○	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	BCU Configure Info.	Special Function
2009	Dodge Ram	TCM	●	●	●	●	●	●	○	027B, 0167, 0166, 01EE, 027C, 016A, 0169, 027D, 0291, 016C, 016B, 02F8, 0290, 027E, 016E, 016D, 0177, 0176, 024E, 01FB, 016F, 01FC, 01F6
2009	Dodge Ram	RADIO	●	●	●	●	●	○	●	
2009	Dodge Ram	TIPMCGW	●	●	●	●	●	●	●	003F, 020E, 0215, 028F, 0211
2009	Dodge Ram	FDCM	●	●	●	●	●	○	○	
2009	Dodge Ram	HFM	●	●	●	●	●	●	○	
2009	Dodge Ram	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2009	Dodge Ram	HVAC	●	●	●	●	●	●	●	00EB, 00E8, 00E9, 00EA
2009	Dodge Ram	PCM	●	●	●	●	●	●	●	0156, 0157, 0154, 0155, 0141, 0044, 0150, 0151, 033D, 017B, 0292, 037A, 0173, 0049, 0276, 0277, 033B, 033C, 0379, 017A, 0178, 0278, 039A, 013B, 033A, 0152, 014F, 027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 02F9, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 012D, 0177, 0304, 012A, 0281, 0280, 02FA, 0176, 024E, 0170, 016F, 012B, 0269, 01FC, 0179, 0153, 015A, 0159, 0158
2009	Dodge Ram	ORC	●	●	●	●	●	○	●	
2009	Dodge Ram	WCM	●	●	●	●	●	○	●	01D2, 0228, 0226, 0225, 0230, 0231, 0233, 033F, 023D, 023E, 0271, 0270
2009	Ram 1500	SDARV	●	●	●	●	●	○	○	
2009	Ram 1500	RADIO	●	●	●	●	●	●	●	
2009	Ram 1500	TIPMCGW	●	●	●	●	●	●	●	0214, 003F, 002E
2009	Ram 1500	PCM	●	●	●	●	●	●	●	027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 0044, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 012D, 0177, 0173, 012A, 0281, 0280, 0176, 024E, 0170, 016F, 012B, 0269, 01FC, 013B, 02F9, 0304, 02FA
2009	Ram 1500	DMFR	●	●	●	●	○	●	○	
2009	Ram 1500	CCN	●	●	●	●	●	●	●	
2009	Ram 1500	DMFL	●	●	●	●	●	●	○	
2009	Ram 1500	ABS	●	●	●	●	●	●	●	0002
2009	Ram 1500	WCM	●	●	●	●	●	●	●	02A7, 03E6, 0232, 0230, 022F, 01DE
2009	Ram 1500	DTCM	●	●	●	●	●	●	○	
2009	Ram 1500	HVAC	●	●	●	●	●	●	●	
2009	Ram 1500	PTS	●	●	●	●	●	●	●	02ED, 03B7
2009	Ram 1500	HFM	●	●	●	●	●	●	○	
2009	Ram 1500	MSMD	●	●	●	●	●	○	○	0117
2009	Ram 1500	HSM	●	●	●	●	●	●	○	
2009	Ram 1500	SAS	●	●	●	●	○	○	○	
2009	Ram 1500	AMP	●	●	●	●	●	○	●	
2009	Ram 1500	ORC	●	●	●	●	●	○	●	02A1



YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2009	Ram 1500	VES3	●	●	●	●	●	●	●	
2009	Durango (Pre-2011)	EOM	●	●	●	●	●	●	●	
2009	Durango (Pre-2011)	EAC	●	●	●	●	●	○	○	
2009	Durango (Pre-2011)	HGM	●	●	●	●	●	●	●	
2009	Durango (Pre-2011)	DDM	●	●	●	●	●	●	●	
2009	Durango (Pre-2011)	BPCM	●	○	○	●	○	○	○	
2009	Durango (Pre-2011)	HVAC	●	●	●	●	●	●	●	00EA, 034A, 00E9, 034B, 00E8, 0324
2009	Durango (Pre-2011)	SDARV	●	●	●	●	●	○	○	
2009	Durango (Pre-2011)	HSM	●	●	●	●	●	●	●	
2009	Durango (Pre-2011)	AMP	●	●	●	●	●	○	●	
2009	Durango (Pre-2011)	EPS	●	●	●	●	●	○	○	
2009	Durango (Pre-2011)	MSMD	●	●	●	●	●	○	○	0117
2009	Durango (Pre-2011)	SAS	●	●	●	●	○	○	○	
2009	Durango (Pre-2011)	FCMCGW	●	●	●	●	●	●	●	02F1, 02F0, 02F3, 02EF, 0039, 003C, 003D, 02A6, 02A5, 02A4, 0032, 003E, 0036, 00D5, 00D8, 0037, 0035, 0034, 00DB, 00D6, 00D9, 003A, 0293, 0033, 00C6, 0040, 00DA, 0272, 0273
2009	Durango (Pre-2011)	MCPA	●	○	○	●	○	○	○	
2009	Durango (Pre-2011)	RADIO	●	●	●	●	●	●	●	
2009	Durango (Pre-2011)	FDCM	●	●	●	●	●	●	○	
2009	Durango (Pre-2011)	ABS	●	●	●	●	●	●	●	03BB, 0002, 0285, 0062
2009	Durango (Pre-2011)	ORC	●	●	●	●	●	○	●	
2009	Durango (Pre-2011)	CCN	●	●	●	●	●	●	●	008F, 008E, 008D, 0090
2009	Durango (Pre-2011)	TCM	●	●	●	●	●	○	○	018D, 0360, 035B, 035C, 035D, 035E, 035F
2009	Durango (Pre-2011)	PDM	●	●	●	●	●	●	●	
2009	Durango (Pre-2011)	PTS	●	●	●	●	●	●	●	01B8
2009	Durango (Pre-2011)	PLGM	●	●	●	●	●	●	●	
2009	Durango (Pre-2011)	HCP	●	●	●	●	●	○	○	03BE
2009	Durango (Pre-2011)	WCM	●	●	●	●	●	○	●	01D2, 0228, 0226, 0225, 0232, 0231, 022F, 01DE, 0233, 023E, 0271
2009	Durango (Pre-2011)	APM	●	○	○	○	○	○	○	
2009	Durango (Pre-2011)	HFM	●	●	●	●	●	●	○	
2009	Durango (Pre-2011)	VES3	●	●	●	●	●	●	●	
2009	Durango (Pre-2011)	MCPB	●	○	○	●	○	○	○	
2009	Durango (Pre-2011)	PCM	●	●	●	●	●	●	●	027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 0044, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 012D, 0177, 0173, 012A, 0281, 0280, 0176, 024E, 0170, 016F, 012B, 0269, 01FC, 013B, 02F9, 0304, 02FA
2009	Aspen	SAS	●	●	●	●	○	○	○	



[illegible]

[illegible]

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2009	Nitro	AMP	●	●	●	●	●	○	●	
2009	Nitro	DMFL	●	●	●	●	●	●	●	
2009	Nitro	ITM	●	●	●	●	●	●	●	
2009	Nitro	VES3	●	●	●	●	●	●	●	
2009	Nitro	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2009	Nitro	OCM	●	●	●	●	●	○	○	011E
2009	Nitro	WCM	●	●	●	●	●	○	●	01D2, 0228, 0226, 0225, 0232, 0230, 0231, 022F, 01DE, 0233, 022D, 0227, 0274
2009	Nitro	TCM	●	●	●	●	●	○	○	01F3, 01F2
2009	Nitro	DMFR	●	●	●	●	●	●	●	
2009	Nitro	HVAC	●	●	●	●	●	●	●	
2009	Nitro	RADIO	●	●	●	●	●	●	●	
2009	Nitro	CCN	●	●	●	●	●	●	○	008C, 0091, 0094, 0096
2009	Nitro	ESM	●	●	●	●	●	●	○	
2009	Nitro	PCM	●	●	●	●	●	●	●	027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 0044, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 012D, 0177, 0173, 012A, 0281, 0280, 0176, 024E, 0170, 016F, 012B, 0269, 01FC, 013B, 02F9, 0304, 02FA, 02BA, 02BF, 02BD, 0049, 031D, 02C1, 02C2
2009	Liberty	HFM	●	●	●	●	●	●	○	
2009	Liberty	WCM	●	●	●	●	●	○	●	
2009	Liberty	FDCM	●	●	●	●	●	●	○	
2009	Liberty	TCM	●	●	●	●	●	○	○	01F3, 01F2
2009	Liberty	DMFL	●	●	●	●	●	●	●	
2009	Liberty	CCN	●	●	●	●	●	●	○	008C, 0091, 0094, 0096
2009	Liberty	MSMD	●	●	●	●	●	○	○	0117
2009	Liberty	SUNR	●	●	●	●	●	○	○	
2009	Liberty	VES3	●	●	●	●	●	●	●	
2009	Liberty	PCM	●	●	●	●	●	●	●	027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 02F9, 0044, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 012D, 0177, 0304, 0173, 012A, 0281, 0280, 02FA, 0176, 024E, 0170, 016F, 012B, 0269, 01FC, 013B, 02BA, 02BF, 02BD, 0049, 031D, 02C1, 02C2
2009	Liberty	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2009	Liberty	DMFR	●	●	●	●	●	●	●	
2009	Liberty	ITM	●	●	●	●	●	●	●	
2009	Liberty	ORC	●	●	●	●	●	○	●	
2009	Liberty	RADIO	●	●	●	●	●	●	●	
2009	Liberty	OCM	●	●	●	●	●	○	○	011E
2009	Liberty	ESM	●	●	●	●	●	●	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2009	Liberty	SAS	●	●	●	●	○	○	○	
2009	Liberty	AMP	●	●	●	●	●	○	●	
2009	Liberty	HVAC	●	●	●	●	●	●	●	
2009	Liberty	TIPMCGW	●	●	●	●	●	●	●	003F, 003A, 021F, 02E2
2009	Liberty	PTS	●	●	●	●	●	●	●	01B8
2009	Challenger	AMP	●	●	●	●	●	○	●	
2009	Challenger	TCM	●	●	●	●	●	○	○	01F3, 01F2
2009	Challenger	SCM	●	●	●	●	○	●	●	
2009	Challenger	HVAC	●	●	●	●	●	●	●	
2009	Challenger	CCN	●	●	●	●	●	●	●	
2009	Challenger	DDM	●	●	●	●	●	●	○	
2009	Challenger	SUNR	●	●	●	●	●	●	○	
2009	Challenger	ESM	●	●	●	●	●	●	○	
2009	Challenger	TPM	●	●	●	●	○	○	●	02F7, 0232, 0230, 0231, 022F
2009	Challenger	HSM	●	●	●	●	●	●	●	
2009	Challenger	TIPMCGW	●	●	●	●	●	●	●	
2009	Challenger	RADIO	●	●	●	●	●	●	●	
2009	Challenger	PCM	●	●	●	●	●	●	●	027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 02F9, 0044, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 012D, 0177, 0304, 0173, 012A, 0281, 0280, 02FA, 0176, 024E, 0170, 016F, 012B, 0269, 01FC, 013B
2009	Challenger	HFM	●	●	●	●	●	●	○	
2009	Challenger	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2009	Challenger	PDM	●	●	●	●	●	●	○	
2009	Challenger	EOM	●	●	●	●	●	○	●	
2009	Challenger	ORC	●	●	●	●	●	○	●	
2009	Challenger	WCM	●	●	●	●	●	●	●	01D2, 0228, 0225, 02A7, 03E6, 0232, 0230, 022F, 0231, 01DA
2009	Challenger	PEM	●	●	●	●	●	○	●	0442
2009	300 / Magnum / Charger (Pre-2011)	DDM	●	●	●	●	●	●	●	
2009	300 / Magnum / Charger (Pre-2011)	MSMD	●	●	●	●	●	○	○	0117
2009	300 / Magnum / Charger (Pre-2011)	DTCM	●	●	●	●	●	●	○	
2009	300 / Magnum / Charger (Pre-2011)	HSM	●	●	●	●	●	●	●	
2009	300 / Magnum / Charger (Pre-2011)	TIPMCGW	●	●	●	●	●	●	●	
2009	300 / Magnum / Charger (Pre-2011)	HIDT	●	●	●	●	●	●	○	
2009	300 / Magnum / Charger (Pre-2011)	PTIM	●	●	●	●	●	●	●	
2009	300 / Magnum / Charger (Pre-2011)	PEM	●	●	●	●	●	○	●	0442
2009	300 / Magnum / Charger (Pre-2011)	LRSM	●	●	●	●	●	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2009	300 / Magnum / Charger (Pre-2011)	AMP	●	●	●	●	●	○	●	
2009	300 / Magnum / Charger (Pre-2011)	TPM	●	●	●	●	○	○	●	02F7, 0232, 0230, 0231, 022F
2009	300 / Magnum / Charger (Pre-2011)	SDARV	●	●	●	●	●	○	○	
2009	300 / Magnum / Charger (Pre-2011)	PCM	●	●	●	●	●	●	●	0042, 0149, 0142, 0044, 0145, 012D, 0045, 0046, 014B, 0173, 014A, 0049, 014D, 0146, 0147, 013B, 027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 02F9, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 02FB, 013C, 012C, 0177, 0304, 012A, 0281, 0280, 02FA, 0176, 024E, 0170, 016F, 012B, 0269, 01FC
2009	300 / Magnum / Charger (Pre-2011)	SCM	●	●	●	●	○	●	●	
2009	300 / Magnum / Charger (Pre-2011)	TCM	●	●	●	●	●	○	○	01F3, 01F2
2009	300 / Magnum / Charger (Pre-2011)	PTS	●	●	●	●	●	●	●	02ED, 03B7
2009	300 / Magnum / Charger (Pre-2011)	CCN	●	●	●	●	●	●	●	
2009	300 / Magnum / Charger (Pre-2011)	PDM	●	●	●	●	●	●	●	
2009	300 / Magnum / Charger (Pre-2011)	EOM	●	●	●	●	●	○	●	
2009	300 / Magnum / Charger (Pre-2011)	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2009	300 / Magnum / Charger (Pre-2011)	SUNR	●	●	●	●	●	●	○	
2009	300 / Magnum / Charger (Pre-2011)	ACC	●	●	●	●	●	○	●	0064, 0321
2009	300 / Magnum / Charger (Pre-2011)	VES3	●	●	●	●	●	●	●	
2009	300 / Magnum / Charger (Pre-2011)	HFM	●	●	●	●	●	●	○	
2009	300 / Magnum / Charger (Pre-2011)	ORC	●	●	●	●	●	○	●	
2009	300 / Magnum / Charger (Pre-2011)	AHBM	●	●	●	●	●	○	○	
2009	300 / Magnum / Charger (Pre-2011)	WCM	●	●	●	●	●	●	●	01D2, 0228, 0225, 0232, 0230, 0231, 022F, 0233, 01DA, 02A7, 03E6
2009	300 / Magnum / Charger (Pre-2011)	RADIO	●	●	●	●	●	●	●	
2009	300 / Magnum / Charger (Pre-2011)	ITM	●	●	●	●	●	●	●	
2009	300 / Magnum / Charger (Pre-2011)	HVAC	●	●	●	●	●	●	●	00EA, 00E9
2009	300 / Magnum / Charger (Pre-2011)	ESM	●	●	●	●	●	●	○	
2009	Compass	SAS	●	●	●	●	○	○	○	
2009	Compass	RADIO	●	●	●	●	●	●	●	
2009	Compass	TCM	●	●	●	●	●	●	●	
2009	Compass	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2009	Compass	HFM	●	●	●	●	●	●	○	
2009	Compass	ORC	●	●	●	●	●	○	●	
2009	Compass	WCM	●	●	●	●	●	○	●	01D2, 0228, 0226, 0225, 0230, 0231, 0233, 022D, 023D, 023E, 0271, 0270
2009	Compass	AWD	●	●	●	●	●	●	●	
2009	Compass	TIPMCGW	●	●	●	●	●	●	●	003F, 020E, 0215, 028F, 0211
2009	Compass	CCN	●	●	●	●	●	●	●	008C, 008F, 008E, 0094, 0092, 0096

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2009	Compass	ITM	●	●	●	●	●	●	●	
2009	Compass	PCM	●	●	●	●	●	●	●	02E7, 0140, 013E, 0126, 0141, 0044, 0128, 012E, 0314, 012C, 0173, 012B, 013B, 0042, 0142, 012D, 0310, 03A3, 0144, 03A4, 0313, 0312, 0311
2009	Compass	AMP	●	●	●	●	●	○	●	
2009	Dakota	EOM	●	●	●	●	●	○	●	
2009	Dakota	CCN	●	●	●	●	●	●	●	008F, 008E, 008D, 0090
2009	Dakota	WCM	●	●	●	●	●	○	●	01D2, 0228, 0226, 0225, 0232, 0231, 022F, 01DE, 0233, 023E, 0271
2009	Dakota	HVAC	●	●	●	●	●	●	●	00EA, 00E8, 00E9
2009	Dakota	RADIO	●	●	●	●	●	●	●	
2009	Dakota	AMP	●	●	●	●	●	○	●	
2009	Dakota	FCMCGW	●	●	●	●	●	●	●	02F1, 02F0, 02F3, 02EF, 0039, 003C, 003D, 02A6, 02A5, 02A4, 0032, 003E, 0036, 00D5, 00D8, 0037, 0035, 0034, 00DB, 00D6, 00D9, 003A, 0293, 0033, 00C6, 0040, 00DA, 0272, 0273
2009	Dakota	HFM	●	●	●	●	●	●	○	
2009	Dakota	ORC	●	●	●	●	●	○	●	
2009	Dakota	PCM	●	●	●	●	●	●	●	027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 0044, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 012D, 0177, 0173, 012A, 0281, 0280, 0176, 024E, 0170, 016F, 012B, 0269, 01FC, 013B, 02F9, 0304, 02FA
2009	Dakota	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2009	Raider	FCMCGW	●	●	●	●	●	●	●	02F1, 02F0, 02F3, 02EF, 0039, 003C, 003D, 02A6, 02A5, 02A4, 0032, 003E, 0036, 00D5, 00D8, 0037, 0035, 0034, 0038, 00DB, 00D6, 00D9, 003A, 0293, 0033, 00C6, 0040, 00DA, 0272, 0273
2009	Raider	RADIO	●	●	●	●	●	●	●	
2009	Raider	ORC	●	●	●	●	●	○	●	
2009	Raider	CCN	●	●	●	●	●	●	●	008F, 008E, 008D, 0090
2009	Raider	HFM	●	●	●	●	●	●	○	
2009	Raider	WCM	●	●	●	●	●	○	●	01D2, 0228, 0226, 0225, 0232, 0231, 022F, 01DE, 0233, 023E, 0271
2009	Raider	HVAC	●	●	●	●	●	●	●	00EA, 00E8, 00E9
2009	Raider	EOM	●	●	●	●	●	○	●	
2009	Raider	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2009	Raider	AMP	●	●	●	●	●	○	●	
2009	Raider	PCM	●	●	●	●	●	●	●	027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 02F9, 0044, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 012D, 0177, 0304, 0173, 012A, 0281, 0280, 02FA, 0176, 024E, 0170, 016F, 012B, 0269, 01FC, 013B
2009	Caliber	AMP	●	●	●	●	●	○	●	



YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2009	Caliber	WCM	●	●	●	●	●	○	●	01D2, 0228, 0226, 0225, 0230, 0231, 0233, 022D, 023D, 023E, 0271, 0270
2009	Caliber	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2009	Caliber	RADIO	●	●	●	●	●	●	●	
2009	Caliber	AWD	●	●	●	●	●	●	●	
2009	Caliber	PCM	●	●	●	●	●	●	●	02E7, 0140, 013E, 0126, 0141, 0044, 0128, 012E, 0314, 012C, 0173, 012B, 013B, 0042, 0142, 012D, 0310, 03A3, 0144, 03A4, 0313, 0312, 0311
2009	Caliber	EBG	●	●	●	●	●	○	○	
2009	Caliber	ORC	●	●	●	●	●	○	●	
2009	Caliber	SAS	●	●	●	●	○	○	○	
2009	Caliber	TCM	●	●	●	●	●	●	●	
2009	Caliber	TIPMCGW	●	●	●	●	●	●	●	003F, 020E, 0215, 028F, 0211
2009	Caliber	CCN	●	●	●	●	●	●	●	008C, 008F, 008E, 0094, 0092, 0096
2009	Caliber	ITM	●	●	●	●	●	●	●	
2009	Caliber	HFM	●	●	●	●	●	●	○	
2009	PT Cruiser	SDAR	●	●	●	●	●	○	○	
2009	PT Cruiser	CCN	●	●	●	●	●	●	●	008C, 008F, 008E, 0094, 0092, 0096
2009	PT Cruiser	RADIO	●	●	●	●	●	○	●	
2009	PT Cruiser	ITM	●	●	●	●	●	●	●	
2009	PT Cruiser	ABS	●	●	●	●	●	●	●	005E, 0060, 005B
2009	PT Cruiser	WCM	●	●	●	●	●	○	●	01D2, 0228, 0226, 0225, 0230, 0231, 0233, 022D, 023D, 023E, 0271, 0270
2009	PT Cruiser	TIPMCGW	●	●	●	●	●	●	●	003F, 020E, 0215, 028F, 028E, 0211
2009	PT Cruiser	HFM	●	●	●	●	●	●	○	
2009	PT Cruiser	TCM	●	●	●	●	○	●	●	0167, 0166, 01EE, 016A, 0169, 016C, 016B, 016E, 016D, 01F0, 0172, 0177, 0170, 0175
2009	PT Cruiser	DDM	●	●	●	●	●	●	○	
2009	PT Cruiser	OCM	●	●	●	●	●	○	○	011E
2009	PT Cruiser	ORC	●	●	●	●	●	○	●	
2009	PT Cruiser	PDM	●	●	●	●	○	●	○	
2009	PT Cruiser	AMP	●	●	●	●	●	○	●	0289, 028A, 006D, 006B, 006C, 0068, 006A, 0069, 0073
2009	PT Cruiser	PCM	●	●	●	●	●	●	●	0127, 0126, 0044, 0411, 0129, 026C, 026D, 0128, 012E, 012F, 013C, 012C, 012D, 0173, 012A, 012B, 013B, 0042, 0149, 0142, 0145, 0049
2009	Mini-Van	MHSM	●	●	●	●	○	●	○	
2009	Mini-Van	PCM	●	●	●	●	○	●	○	
2009	Mini-Van	PLGM	●	●	●	●	●	●	●	
2009	Mini-Van	PSD	●	●	●	●	○	●	○	
2009	Mini-Van	BCM	●	●	●	●	○	●	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2009	Mini-Van	DSD	●	●	●	●	○	●	○	
2009	Mini-Van	MTC	●	●	●	●	○	●	○	
2009	Mini-Van	TCM	●	●	●	●	●	●	●	
2009	Mini-Van	ORC	●	●	●	●	○	○	○	
2009	Mini-Van	EOM	●	●	●	○	○	○	○	
2009	Mini-Van	HFM	●	●	●	●	○	●	○	
2009	Mini-Van	OCM	●	●	●	●	○	○	○	011E, 802A, 802B, 8023, 8024
2009	Mini-Van	PTS	●	●	●	●	●	●	○	
2009	Mini-Van	SKREEM	●	●	●	●	●	○	○	8003, 8004, 8005, 8006, 8007, 01D2, 800D, 8008, 8009, 800A, 800B, 800C, 01DE, 800E, 01DA
2009	Mini-Van	IPM	●	●	●	●	○	●	○	
2009	Mini-Van	ABS	●	●	●	●	●	○	○	
2009	Mini-Van	SDAR	●	●	●	●	●	●	○	
2009	Mini-Van	MIC/CCN	●	●	●	●	○	●	○	
2009	Mini-Van	ATC	●	●	●	●	○	●	○	
2009	Routan	RADIO	●	●	●	●	●	●	●	
2009	Routan	DMFR	●	●	●	●	●	●	●	
2009	Routan	HVAC	●	●	●	●	●	●	●	00EA, 00E9, 00EC
2009	Routan	TIPMCGW	●	●	●	●	●	●	●	003F, 002E, 021F
2009	Routan	CCN	●	●	●	●	●	●	○	008C, 0091, 0094, 0096
2009	Routan	ORC	●	●	●	●	●	○	●	0122
2009	Routan	SAS	●	●	●	●	○	○	○	
2009	Routan	DMRR	●	●	●	●	●	●	●	
2009	Routan	HFM	●	●	●	●	●	●	○	
2009	Routan	DVD	●	●	●	●	●	○	○	
2009	Routan	FSM	●	●	●	●	●	●	○	
2009	Routan	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2009	Routan	VES2	●	●	●	●	●	●	●	
2009	Routan	PSDMR	●	●	●	●	●	○	●	
2009	Routan	PLGM	●	●	●	●	●	●	●	
2009	Routan	AMP	●	●	●	●	●	○	●	
2009	Routan	DMFL	●	●	●	●	●	●	●	
2009	Routan	PSDML	●	●	●	●	●	○	●	
2009	Routan	SUNR	●	●	●	●	●	●	○	
2009	Routan	MSMD	●	●	●	●	●	○	○	0117
2009	Routan	DMRL	●	●	●	●	●	●	●	
2009	Routan	WCM	●	●	●	●	●	●	●	02A7, 03E6, 0232, 0230, 022F, 01D2, 0228, 0225, 0231, 0233, 01DA, 01DE

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2009	Routan	PTS	●	●	●	●	●	●	●	02ED, 03B7
2009	Routan	PCM	●	●	●	●	●	●	●	027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 02F9, 0044, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 012D, 0177, 0304, 0173, 012A, 0281, 0280, 02FA, 0176, 024E, 0170, 016F, 012B, 0269, 01FC, 013B
2009	Routan	VES3	●	●	●	●	●	●	●	
2009	Town & Country / Caravan	DMRL	●	●	●	●	●	●	●	
2009	Town & Country / Caravan	HIDT	●	●	●	●	●	●	○	
2009	Town & Country / Caravan	FSM	●	●	●	●	●	●	○	
2009	Town & Country / Caravan	DMFL	●	●	●	●	●	●	●	
2009	Town & Country / Caravan	TIPMCGW	●	●	●	●	●	●	●	002E
2009	Town & Country / Caravan	BSM	●	●	●	●	●	○	○	
2009	Town & Country / Caravan	HFM	●	●	●	●	●	●	○	
2009	Town & Country / Caravan	TCM	●	●	●	●	●	●	○	
2009	Town & Country / Caravan	AHBM	●	●	●	●	●	○	○	
2009	Town & Country / Caravan	ORC	●	●	●	●	●	○	●	0122
2009	Town & Country / Caravan	SDARV	●	●	●	●	●	○	○	
2009	Town & Country / Caravan	HVAC	●	●	●	●	●	●	●	00EA, 00E9, 00EC
2009	Town & Country / Caravan	VES3	●	●	●	●	●	●	●	
2009	Town & Country / Caravan	PSDMR	●	●	●	●	●	○	●	
2009	Town & Country / Caravan	PTS	●	●	●	●	●	●	●	02ED, 03B7
2009	Town & Country / Caravan	CCN	●	●	●	●	●	●	○	008C, 0091, 0094, 0096
2009	Town & Country / Caravan	SAS	●	●	●	●	○	○	○	
2009	Town & Country / Caravan	DMRR	●	●	●	●	●	●	●	
2009	Town & Country / Caravan	PLGM	●	●	●	●	●	●	●	
2009	Town & Country / Caravan	AMP	●	●	●	●	●	○	●	
2009	Town & Country / Caravan	WCM	●	●	●	●	●	●	●	01D2, 0228, 0225, 0232, 0230, 0231, 022F, 01DE, 0233, 01DA, 02A7, 03E6
2009	Town & Country / Caravan	VES2	●	●	●	●	●	●	●	
2009	Town & Country / Caravan	DMFR	●	●	●	●	●	●	●	
2009	Town & Country / Caravan	PSDML	●	●	●	●	●	○	●	
2009	Town & Country / Caravan	DVD	●	●	●	●	●	○	○	
2009	Town & Country / Caravan	ITM	●	●	●	●	●	●	●	
2009	Town & Country / Caravan	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2009	Town & Country / Caravan	PCM	●	●	●	●	●	●	●	027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 02F9, 0044, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 012D, 0177, 0304, 0173, 012A, 0281, 0280, 02FA, 0176, 024E, 0170, 016F, 012B, 0269, 01FC, 013B, 02BA, 02BF, 02BD, 0049, 031D, 02C1, 02C2

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2009	Town & Country / Caravan	SUNR	●	●	●	●	●	●	○	
2009	Town & Country / Caravan	MSMD	●	●	●	●	●	○	○	0117
2009	Town & Country / Caravan	RADIO	●	●	●	●	●	●	●	
2009	Sprinter	CCN	●	●	●	●	●	○	○	0007, 0008, 0005, 0334, 0006, 032F, 0330, 0331, 0332, 0333, 0009, 000A
2009	Sprinter	SCM	●	●	●	●	●	●	○	
2009	Sprinter	ABS	●	●	●	●	●	○	●	032D, 0002, 0001, 0003
2009	Sprinter	PTS	●	●	●	●	●	●	●	02D2, 02D3
2009	Sprinter	TM	●	●	●	●	○	○	○	
2009	Sprinter	BCH	●	●	●	●	●	●	○	
2009	Sprinter	ECM	●	●	●	●	●	●	●	0042, 0142, 0127, 0044, 0337, 001E, 0045, 0046, 0023, 0043, 0049, 014D, 026E, 002E, 026F, 0336, 0025, 0024, 0022, 0020, 0021
2009	Sprinter	BCM	●	●	●	●	●	●	○	
2009	Sprinter	AHLM	●	●	●	●	●	●	○	029F
2009	Sprinter	PSM	●	●	●	●	●	●	○	
2009	Sprinter	PSDMR	●	●	●	●	○	●	○	
2009	Sprinter	TPM	●	●	●	●	●	○	○	02D0, 02D1, 001A, 001B, 001C, 001D, 0247, 004E
2009	Sprinter	TCM	●	●	●	●	●	○	○	02D6, 02D7, 02D4, 02D5, 0018
2009	Sprinter	AEHM	●	●	●	●	●	○	○	0004
2009	Sprinter	HVAC	●	●	●	●	●	●	●	0012
2009	Sprinter	PSDML	●	●	●	●	○	●	○	
2009	Sprinter	DDM	●	●	●	●	●	●	○	
2009	Sprinter	RCM	●	●	●	●	●	●	○	
2009	Sprinter	ESM	●	●	●	●	●	●	○	
2009	Sprinter	EISCGW	●	●	●	●	●	○	●	002C, 002B, 002A
2009	Sprinter	ACH	●	●	●	●	●	●	○	
2009	Sprinter	SBM	●	●	●	●	●	●	○	
2009	Sprinter	ORC	●	●	●	○	●	○	○	0014, 0013, 02CF
2009	Sprinter	RADIO	●	●	●	●	●	○	●	
2009	Sprinter	HFM	●	●	●	●	●	○	○	
2009	Sprinter	CDC	●	●	●	●	●	○	○	
2009	Grand Cherokee	EOM	●	●	●	●	●	○	●	
2009	Grand Cherokee	PCM	●	●	●	●	●	●	●	027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 02F9, 0044, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 012D, 0177, 0304, 0173, 012A, 0281, 0280, 02FA, 0176, 024E, 0170, 016F, 012B, 0269, 01FC, 013B, 0042, 0149, 0142, 0045, 0046, 014B, 014A, 0049, 014D, 0146, 0147
2009	Grand Cherokee	HFM	●	●	●	●	●	●	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2009	Grand Cherokee	PDM	●	●	●	●	●	●	●	
2009	Grand Cherokee	MSMD	●	●	●	●	●	○	○	0117
2009	Grand Cherokee	LRSM	●	●	●	●	●	○	○	
2009	Grand Cherokee	RADIO	●	●	●	●	●	●	●	
2009	Grand Cherokee	CCN	●	●	●	●	●	●	●	0097, 008C, 008F, 008E, 0091, 0094, 0099, 0098, 0090
2009	Grand Cherokee	PTS	●	●	●	●	●	●	●	02ED, 03B7
2009	Grand Cherokee	ORC	●	●	●	●	●	○	●	0122
2009	Grand Cherokee	SAS	●	●	●	●	○	○	○	
2009	Grand Cherokee	HVAC	●	●	●	●	●	●	●	00EA, 00E9
2009	Grand Cherokee	DDM	●	●	●	●	●	●	●	
2009	Grand Cherokee	AHBM	●	●	●	●	●	○	○	
2009	Grand Cherokee	ITM	●	●	●	●	●	●	●	
2009	Grand Cherokee	SUNR	●	●	●	●	●	●	○	
2009	Grand Cherokee	ESM	●	●	●	●	●	●	○	
2009	Grand Cherokee	FDCM	●	●	●	●	●	●	●	
2009	Grand Cherokee	AHLM	●	●	●	●	●	●	○	
2009	Grand Cherokee	SDARV	●	●	●	●	●	○	○	
2009	Grand Cherokee	AMP	●	●	●	●	●	○	●	
2009	Grand Cherokee	HSM	●	●	●	●	●	●	●	
2009	Grand Cherokee	TM	●	●	●	○	○	○	○	
2009	Grand Cherokee	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2009	Grand Cherokee	TCM	●	●	●	●	●	○	○	01F3, 01F2
2009	Grand Cherokee	WCM	●	●	●	●	●	●	●	01D2, 0228, 0225, 0232, 0230, 0231, 022F, 01DE, 0233, 01DA, 02A7, 03E6
2009	Grand Cherokee	VES3	●	●	●	●	●	●	●	
2009	Grand Cherokee	FCMCGW	●	●	●	●	●	●	●	02F1, 02F0, 02F3, 02EF, 0039, 003C, 003D, 02A6, 02A5, 02A4, 0032, 003E, 0036, 00D5, 00D8, 0037, 0035, 0034, 00DB, 00D6, 00D9, 003A, 002E, 0293, 0033, 00C6, 00DA, 0272, 0273
2009	Commander	AHBM	●	●	●	●	●	○	○	
2009	Commander	TCM	●	●	●	●	●	○	○	01F3, 01F2
2009	Commander	HVAC	●	●	●	●	●	●	●	00EA, 00E9
2009	Commander	SUNR	●	●	●	●	●	●	○	
2009	Commander	TM	●	●	●	○	○	○	○	
2009	Commander	HSM	●	●	●	●	●	●	●	
2009	Commander	PCM	●	●	●	●	●	●	●	027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 0044, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 012D, 0177, 0173, 012A, 0281, 0280, 0176, 024E, 0170, 016F, 012B, 0269, 01FC, 013B, 02F9, 0304, 02FA, 0042, 0149, 0142, 0045, 0046, 014B, 014A, 0049, 014D, 0146, 0147

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2009	Commander	WCM	●	●	●	●	●	●	●	01D2, 0228, 0225, 0232, 0230, 0231, 022F, 01DE, 0233, 01DA, 02A7, 03E6
2009	Commander	PTS	●	●	●	●	●	●	●	02ED, 03B7
2009	Commander	FCMCGW	●	●	●	●	●	●	●	02F1, 02F0, 02F3, 02EF, 0039, 003C, 003D, 02A6, 02A5, 02A4, 0032, 003E, 0036, 00D5, 00D8, 0037, 0035, 0034, 00DB, 00D6, 00D9, 003A, 002E, 0293, 0033, 00C6, 00DA, 0272, 0273
2009	Commander	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2009	Commander	MSMD	●	●	●	●	●	○	○	0117
2009	Commander	DDM	●	●	●	●	●	●	●	
2009	Commander	AMP	●	●	●	●	●	○	●	
2009	Commander	SDARV	●	●	●	●	●	○	○	
2009	Commander	ORC	●	●	●	●	●	○	●	0122
2009	Commander	LRSM	●	●	●	●	●	○	○	
2009	Commander	HFM	●	●	●	●	●	●	○	
2009	Commander	VES3	●	●	●	●	●	●	●	
2009	Commander	ESM	●	●	●	●	●	●	○	
2009	Commander	RADIO	●	●	●	●	●	●	●	
2009	Commander	SAS	●	●	●	●	○	○	○	
2009	Commander	FDCM	●	●	●	●	●	●	●	
2009	Commander	AHLM	●	●	●	●	●	●	○	
2009	Commander	ITM	●	●	●	●	●	●	●	
2009	Commander	PDM	●	●	●	●	●	●	●	
2009	Commander	PLGM	●	●	●	●	●	●	●	
2009	Commander	CCN	●	●	●	●	●	●	●	0097, 008C, 008F, 008E, 0091, 0094, 0099, 0098, 0090
2009	Viper (Pre-2011)	OCM	●	●	●	●	●	○	○	02AD
2009	Viper (Pre-2011)	PCM	●	●	●	●	●	●	○	013E, 0126, 0141, 0044, 0325, 0193, 0128, 0145, 0326, 012C, 012A, 0081
2009	Viper (Pre-2011)	ABS	●	●	●	●	○	●	○	
2009	Viper (Pre-2011)	ORC	●	●	●	●	●	●	●	
2009	Viper (Pre-2011)	BCM	●	●	●	●	○	●	○	
2009	Viper (Pre-2011)	MIC/CCN	●	●	●	●	●	○	○	801A
2009	Viper (Pre-2011)	RADIO	●	●	●	○	○	●	○	
2009	Viper (Pre-2011)	PCI to CAN Gateway	●	●	●	●	○	○	○	
2009	Viper (Pre-2011)	SDAR	●	●	●	●	●	●	○	
2009	Viper (Pre-2011)	HVAC	●	●	●	●	○	●	○	
2010	Ram 3500 Pickup	VES3	●	●	●	●	●	●	●	
2010	Ram 3500 Pickup	ITBM	●	●	●	●	○	○	○	
2010	Ram 3500 Pickup	HVAC	●	●	●	●	●	●	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2010	Ram 3500 Pickup	PTS	●	●	●	●	●	●	●	02ED, 03B7
2010	Ram 3500 Pickup	RADIO	●	●	●	●	●	●	●	
2010	Ram 3500 Pickup	DMFL	●	●	●	●	●	●	●	
2010	Ram 3500 Pickup	ABS	●	●	●	●	●	●	●	0002
2010	Ram 3500 Pickup	AMP	●	●	●	●	●	○	●	
2010	Ram 3500 Pickup	DTCM	●	●	●	●	●	●	○	
2010	Ram 3500 Pickup	TIPMCGW	●	●	●	●	●	●	●	0214, 003F, 002E
2010	Ram 3500 Pickup	HSM	●	●	●	●	●	●	○	
2010	Ram 3500 Pickup	SAS	●	●	●	●	○	○	○	
2010	Ram 3500 Pickup	DMFR	●	●	●	●	●	●	●	
2010	Ram 3500 Pickup	ORC	●	●	●	●	●	○	●	
2010	Ram 3500 Pickup	PCM	●	●	●	●	●	●	●	025E, 0260, 0261, 0263, 0154, 0155, 0044, 0265, 017B, 0049, 0280, 03C8, 024E, 0179, 027B, 025F, 027C, 0262, 027D, 0264, 02F8, 0127, 0140, 0126, 02F9, 0411, 026C, 026D, 0128, 027E, 0266, 0145, 02FB, 013C, 012C, 0177, 0304, 0173, 0281, 0176, 0170, 016F, 012B, 0269, 01FC, 013B, 02FA
2010	Ram 3500 Pickup	WCM	●	●	●	●	●	●	●	02A7, 03E6, 0232, 0230, 022F
2010	Ram 3500 Pickup	MSMD	●	●	●	●	●	○	○	0117
2010	Ram 3500 Pickup	CCN	●	●	●	●	●	●	●	
2010	Ram 3500 Pickup	HFM	●	●	●	●	●	●	○	
2010	Ram 3500 Pickup	SDARV	●	●	●	●	●	○	○	
2010	Ram 2500	FDCM	●	●	●	●	●	○	○	
2010	Ram 2500	ORC	●	●	●	●	●	○	●	
2010	Ram 2500	DMFR	●	●	●	●	●	●	●	
2010	Ram 2500	DMFL	●	●	●	●	●	●	●	
2010	Ram 2500	CCN	●	●	●	●	●	●	●	
2010	Ram 2500	AMP	●	●	●	●	●	○	●	
2010	Ram 2500	SAS	●	●	●	●	○	○	○	
2010	Ram 2500	HFM	●	●	●	●	●	●	○	
2010	Ram 2500	PCM	●	●	●	●	●	●	●	027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 02F9, 0044, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 0177, 0304, 0173, 0281, 0280, 0176, 024E, 0170, 016F, 012B, 0269, 01FC, 013B, 0154, 0155, 017B, 0049, 03C8, 0179, 02FA
2010	Ram 2500	DTCM	●	●	●	●	●	●	○	
2010	Ram 2500	VES3	●	●	●	●	●	●	●	
2010	Ram 2500	ABS	●	●	●	●	●	●	●	0002
2010	Ram 2500	HSM	●	●	●	●	●	●	○	
2010	Ram 2500	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2010	Ram 2500	SDARV	●	●	●	●	●	○	○	
2010	Ram 2500	RADIO	●	●	●	●	●	●	●	
2010	Ram 2500	HVAC	●	●	●	●	●	●	●	
2010	Ram 2500	MSMD	●	●	●	●	●	○	○	0117
2010	Ram 2500	PTS	●	●	●	●	●	●	●	02ED, 03B7
2010	Ram 2500	ITBM	●	●	●	●	○	○	○	
2010	Ram 2500	TIPMCGW	●	●	●	●	●	●	●	0214, 003F, 002E
2010	Ram 2500	WCM	●	●	●	●	●	●	●	02A7, 03E6, 0232, 0230, 022F
2010	Dodge Ram	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2010	Dodge Ram	SDAR	●	●	●	●	●	○	○	
2010	Dodge Ram	RADIO	●	●	●	●	●	○	●	
2010	Dodge Ram	CCN	●	●	●	●	●	●	●	008C, 008F, 008E, 0090
2010	Dodge Ram	TIPMCGW	●	●	●	●	●	●	●	003F, 020E, 0215, 028F, 0211
2010	Dodge Ram	SUNR	●	●	●	●	●	●	○	
2010	Dodge Ram	TCM	●	●	●	●	●	●	○	027B, 0167, 0166, 01EE, 027C, 016A, 0169, 027D, 0291, 016C, 016B, 02F8, 0290, 027E, 016E, 016D, 0177, 0176, 024E, 01FB, 016F, 01FC, 01F6
2010	Dodge Ram	EOM	●	●	●	●	●	●	●	
2010	Dodge Ram	WCM	●	●	●	●	●	○	●	01D2, 0228, 0226, 0225, 0230, 0231, 0233, 033F, 023D, 023E, 0271, 0270
2010	Dodge Ram	HFM	●	●	●	●	●	●	○	
2010	Dodge Ram	PCM	●	●	●	●	●	●	●	0156, 0157, 0154, 0155, 0141, 0044, 0150, 0151, 033D, 017B, 0292, 037A, 0173, 0049, 0276, 0277, 033B, 033C, 0379, 017A, 0178, 0278, 039A, 013B, 033A, 0152, 027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 02F9, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 0177, 0304, 0281, 0280, 02FA, 0176, 024E, 0170, 012B, 0269, 01FC, 0153, 015A, 0159, 012D, 0158, 014F, 0179, 016F
2010	Dodge Ram	VES	●	●	●	●	●	●	○	
2010	Dodge Ram	FDCM	●	●	●	●	●	○	○	
2010	Dodge Ram	SAS	●	●	●	●	○	○	○	
2010	Dodge Ram	ORC	●	●	●	●	●	○	●	
2010	Dodge Ram	HVAC	●	●	●	●	●	●	●	00EA, 00E8, 00E9, 00EB
2010	Dodge Ram	AMP	●	●	●	●	●	○	●	028A, 028D, 006D, 006C, 027F, 0068, 006A
2010	Ram 1500	ITBM	●	●	●	●	○	○	○	
2010	Ram 1500	CCN	●	●	●	●	●	●	●	
2010	Ram 1500	HFM	●	●	●	●	●	●	○	



YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2010	Ram 1500	PCM	●	●	●	●	●	●	●	027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 02F9, 0044, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 0177, 0304, 0173, 0281, 0280, 0176, 024E, 0170, 016F, 012B, 0269, 01FC, 013B, 02FA
2010	Ram 1500	HSM	●	●	●	●	●	●	○	
2010	Ram 1500	SDARV	●	●	●	●	●	○	○	
2010	Ram 1500	ORC	●	●	●	●	●	○	●	
2010	Ram 1500	VES3	●	●	●	●	●	●	●	
2010	Ram 1500	SAS	●	●	●	●	○	○	○	
2010	Ram 1500	PTS	●	●	●	●	●	●	●	02ED, 03B7
2010	Ram 1500	TIPMCGW	●	●	●	●	●	●	●	0214, 003F, 002E
2010	Ram 1500	ABS	●	●	●	●	●	●	●	0002
2010	Ram 1500	MSMD	●	●	●	●	●	○	○	0117
2010	Ram 1500	WCM	●	●	●	●	●	●	●	02A7, 03E6, 0232, 0230, 0231, 022F, 01DE, 01DA
2010	Ram 1500	DMFL	●	●	●	●	●	●	●	
2010	Ram 1500	DTCM	●	●	●	●	●	●	○	
2010	Ram 1500	AMP	●	●	●	●	●	○	●	
2010	Ram 1500	RADIO	●	●	●	●	●	●	●	
2010	Ram 1500	HVAC	●	●	●	●	●	●	●	
2010	Ram 1500	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2010	Ram 1500	DMFR	●	●	●	●	●	●	●	
2010	Ram (Mexico)	HFM	●	●	●	●	●	●	○	
2010	Ram (Mexico)	ABS	●	●	●	●	●	●	●	0002
2010	Ram (Mexico)	WCM	●	●	●	●	●	●	●	02A7, 03E6, 0232, 0230, 022F, 0231, 01DE, 01DA
2010	Ram (Mexico)	MSMD	●	●	●	●	●	○	○	0117
2010	Ram (Mexico)	PCM	●	●	●	●	●	●	●	027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 02F9, 0044, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 0177, 0173, 0281, 0280, 02FA, 0176, 024E, 0170, 012B, 0269, 01FC, 013B, 016F, 0154, 0155, 017B, 0049, 03C8, 0179
2010	Ram (Mexico)	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2010	Ram (Mexico)	DMFL	●	●	●	●	●	●	●	
2010	Ram (Mexico)	HVAC	●	●	●	●	●	●	●	
2010	Ram (Mexico)	TIPMCGW	●	●	●	●	●	●	●	0214, 003F, 002E
2010	Ram (Mexico)	DMFR	●	●	●	●	●	●	●	
2010	Ram (Mexico)	AMP	●	●	●	●	●	○	●	
2010	Ram (Mexico)	ORC	●	●	●	●	●	○	●	
2010	Ram (Mexico)	SAS	●	●	●	●	○	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2010	Ram (Mexico)	SDARV	●	●	●	●	●	○	○	
2010	Ram (Mexico)	HSM	●	●	●	●	●	●	○	
2010	Ram (Mexico)	PTS	●	●	●	●	●	●	●	02ED, 03B7
2010	Ram (Mexico)	ITBM	●	●	●	●	○	○	○	
2010	Ram (Mexico)	DTCM	●	●	●	●	●	●	○	
2010	Ram (Mexico)	VES3	●	●	●	●	●	●	●	
2010	Ram (Mexico)	CCN	●	●	●	●	●	●	●	
2010	Ram (Mexico)	RADIO	●	●	●	●	●	●	●	
2010	Wrangler (Export)	TCM	●	●	●	●	●	●	○	0176, 024E, 01FB, 016F, 01FC
2010	Wrangler (Export)	ORC	●	●	●	●	●	○	●	0122
2010	Wrangler (Export)	RADIO	●	●	●	●	●	●	●	
2010	Wrangler (Export)	PCM	●	●	●	●	●	●	○	0145, 02BA, 02BF, 02BD, 0044, 0049, 031D, 02C1, 02C2
2010	Wrangler (Export)	CCN	●	●	●	●	●	●	○	008C, 0091, 0094, 0096
2010	Wrangler (Export)	SAS	●	●	●	●	○	○	○	
2010	Wrangler (Export)	WCM	●	●	●	●	●	○	●	
2010	Wrangler (Export)	TIPMCGW	●	●	●	●	●	●	●	003F, 003A, 002E, 021F
2010	Wrangler (Export)	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2010	Journey	WCM	●	●	●	●	●	●	●	02A7, 01D2, 0228, 0225, 0232, 0230, 022F, 0233, 01DA, 03E6, 01DE
2010	Journey	HFM	●	●	●	●	●	●	○	
2010	Journey	CCN	●	●	●	●	○	●	●	008C, 0091, 0094, 0096
2010	Journey	TIPMCGW	●	●	●	●	●	●	●	003F, 003A, 02E3, 021F
2010	Journey	SAS	●	●	●	●	○	○	○	
2010	Journey	DISP	●	●	●	●	●	○	○	
2010	Journey	DMFL	●	●	●	●	●	●	●	
2010	Journey	AMP	●	●	●	●	●	○	●	
2010	Journey	SDARV	●	●	●	●	●	○	○	
2010	Journey	ORC	●	●	●	●	●	○	●	0122
2010	Journey	TCM	●	●	●	●	●	●	●	
2010	Journey	VES3	●	●	●	●	●	●	●	
2010	Journey	HVAC	●	●	●	●	●	●	●	00EA, 00E9, 00EC
2010	Journey	RADIO	●	●	●	●	●	●	●	
2010	Journey	AWD	●	●	●	●	●	○	●	
2010	Journey	ITM	●	●	●	●	●	●	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2010	Journey	PCM	●	●	●	●	●	●	●	0042, 0142, 012D, 0310, 0313, 0312, 0173, 03A3, 0311, 0144, 03A4, 013B, 02E7, 0140, 013E, 0126, 0141, 0044, 0128, 012E, 0314, 012C, 012B, 027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 02F9, 0411, 026C, 026D, 027E, 0266, 0265, 0145, 02FB, 013C, 0177, 0304, 0281, 0280, 02FA, 0176, 024E, 0170, 0269, 01FC, 016F
2010	Journey	DMFR	●	●	●	●	●	●	●	
2010	Journey	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2010	Wrangler	CCN	●	●	●	●	●	●	○	008C, 0091, 0094, 0096
2010	Wrangler	WCM	●	●	●	●	●	○	●	
2010	Wrangler	AMP	●	●	●	●	●	○	●	
2010	Wrangler	ORC	●	●	●	●	●	○	●	0122
2010	Wrangler	TCM	●	●	●	●	●	●	○	0176, 024E, 01FB, 016F, 01FC
2010	Wrangler	HFM	●	●	●	●	●	●	○	
2010	Wrangler	PCM	●	●	●	●	●	●	●	027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 02F9, 0044, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 0177, 0304, 0173, 0281, 0280, 02FA, 0176, 024E, 0170, 012B, 0269, 01FC, 013B, 016F, 02BA, 02BF, 02BD, 0049, 031D, 02C1, 02C2
2010	Wrangler	ASBS	●	●	●	●	●	○	○	0317, 0318, 031A, 031B, 0319
2010	Wrangler	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2010	Wrangler	RADIO	●	●	●	●	●	●	●	
2010	Wrangler	SAS	●	●	●	●	○	○	○	
2010	Wrangler	ITM	●	●	●	●	●	●	●	
2010	Wrangler	TIPMCGW	●	●	●	●	●	●	●	003F, 003A, 002E, 021F
2010	Sebring / 200 / Avenger	RADIO	●	●	●	●	●	●	●	
2010	Sebring / 200 / Avenger	DDM	●	●	●	●	●	●	○	
2010	Sebring / 200 / Avenger	AWD	●	●	●	●	●	○	●	
2010	Sebring / 200 / Avenger	CCN	●	●	●	●	●	●	○	008C, 008F, 008E, 0094, 0092, 0096
2010	Sebring / 200 / Avenger	PDM	●	●	●	●	●	●	○	
2010	Sebring / 200 / Avenger	SAS	●	●	●	●	○	○	○	
2010	Sebring / 200 / Avenger	HVAC	●	●	●	●	●	●	●	
2010	Sebring / 200 / Avenger	TCM	●	●	●	●	●	●	●	027B, 0167, 0166, 01EE, 027C, 016A, 0169, 027D, 0291, 016C, 016B, 02F8, 0290, 027E, 016E, 016D, 0177, 0176, 024E, 01FB, 016F, 01FC
2010	Sebring / 200 / Avenger	VES3	●	●	●	●	●	●	●	
2010	Sebring / 200 / Avenger	PCM	●	●	●	●	●	●	●	027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 02F9, 0044, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 0177, 0304, 0173, 0281, 0280, 02FA, 0176, 024E, 0170, 012B, 0269, 01FC, 013B, 0042, 0142, 012D, 0310, 03A3, 03A4, 016F, 0144, 02E7, 013E, 0141, 012E, 0314



YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2010	Liberty	OCM	●	●	●	●	●	○	○	011E
2010	Liberty	PTS	●	●	●	●	●	●	●	02ED, 03B7
2010	Liberty	FDCM	●	●	●	●	●	●	○	
2010	Liberty	WCM	●	●	●	●	●	○	●	
2010	Liberty	DMFR	●	●	●	●	●	●	●	
2010	Liberty	ORC	●	●	●	●	●	○	●	
2010	Liberty	SUNR	●	●	●	●	●	○	○	
2010	Liberty	HFM	●	●	●	●	●	●	○	
2010	Liberty	PCM	●	●	●	●	●	●	●	027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 0044, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 0177, 0173, 0281, 0280, 0176, 024E, 0170, 016F, 012B, 0269, 01FC, 013B, 02F9, 0304, 02FA, 02BA, 02BF, 02BD, 0049, 031D, 02C1, 02C2
2010	Liberty	DMFL	●	●	●	●	●	●	●	
2010	Liberty	SAS	●	●	●	●	○	○	○	
2010	Liberty	RADIO	●	●	●	●	●	●	●	
2010	Liberty	AMP	●	●	●	●	●	○	●	
2010	Challenger	PEM	●	●	●	●	●	○	●	
2010	Challenger	SCM	●	●	●	●	○	●	●	
2010	Challenger	ORC	●	●	●	●	○	●	○	
2010	Challenger	HFM	●	●	●	●	●	●	○	
2010	Challenger	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2010	Challenger	DDM	●	●	●	●	●	●	○	
2010	Challenger	EOM	●	●	●	●	●	○	●	
2010	Challenger	HVAC	●	●	●	●	●	●	●	
2010	Challenger	CCN	●	●	●	●	●	●	●	
2010	Challenger	AMP	●	●	●	●	●	○	●	
2010	Challenger	TIPMCGW	●	●	●	●	●	●	●	
2010	Challenger	ESM	●	●	●	●	●	●	○	
2010	Challenger	TCM	●	●	●	●	●	○	○	
2010	Challenger	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2010	Challenger	WCM	●	●	●	●	●	●	●	02A7, 03E6, 0232, 0230, 0231, 022F, 01DA
2010	Challenger	RADIO	●	●	●	●	●	●	●	
2010	Challenger	SUNR	●	●	●	●	●	●	○	
2010	Challenger	HSM	●	●	●	●	●	●	●	

[illegible]



YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2010	Raider	HFM	●	●	●	●	●	●	○	
2010	Raider	ORC	●	●	●	●	○	●	○	
2010	Raider	HVAC	●	●	●	●	●	●	●	00EA, 00E8, 00E9
2010	Raider	CCN	●	●	●	●	●	●	●	008F, 008E, 008D, 0090
2010	Raider	FCMCGW	●	●	●	●	●	●	●	02F1, 02F0, 02F3, 02EF, 0039, 003C, 003D, 02A6, 02A5, 02A4, 0032, 003E, 0036, 00D5, 00D8, 0037, 0035, 0034, 00DB, 00D6, 00D9, 003A, 0293, 0033, 00C6, 0040, 00DA, 0272, 0273
2010	Raider	EOM	●	●	●	●	●	○	●	
2010	Raider	PCM	●	●	●	●	●	●	●	027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 02F9, 0044, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 0177, 0304, 0173, 0281, 0280, 0176, 024E, 0170, 016F, 012B, 0269, 01FC, 013B, 02FA
2010	Caliber	HFM	●	●	●	●	●	●	○	
2010	Caliber	AWD	●	●	●	●	●	●	●	
2010	Caliber	HVAC	●	●	●	●	●	●	●	02E9, 00EA, 02EA
2010	Caliber	PCM	●	●	●	●	●	●	●	02E7, 0140, 013E, 0126, 0141, 0044, 0128, 012E, 0314, 012C, 0173, 012B, 013B, 03E1, 03DA, 0049, 03D8
2010	Caliber	SAS	●	●	●	●	○	○	○	
2010	Caliber	AMP	●	●	●	●	●	○	●	0069, 006D, 0079, 0068, 0303
2010	Caliber	ITM	●	●	●	●	●	●	●	
2010	Caliber	WCM	●	●	●	●	●	○	●	
2010	Caliber	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2010	Caliber	TCM	●	●	●	●	●	●	●	
2010	Caliber	TIPMCGW	●	●	●	●	●	●	●	003F, 020E, 0215, 028F, 0211
2010	Caliber	EBG	●	●	●	●	●	○	○	
2010	Caliber	RADIO	●	●	●	●	●	●	●	
2010	Caliber	CCN	●	●	●	●	●	●	○	008C, 008F, 008E, 0094, 0092, 0096
2010	Caliber	ORC	●	●	●	●	●	○	●	
2010	PT Cruiser	HFM	●	●	●	●	●	●	○	
2010	PT Cruiser	CCN	●	●	●	●	●	●	●	008C, 008F, 008E, 0094, 0092, 0096
2010	PT Cruiser	ITM	●	●	●	●	●	●	●	
2010	PT Cruiser	WCM	●	●	●	●	●	○	●	01D2, 0228, 0226, 0225, 0230, 0231, 0233, 023D, 023E, 0271, 0270
2010	PT Cruiser	TCM	●	●	●	●	○	●	●	
2010	PT Cruiser	RADIO	●	●	●	●	●	○	●	
2010	PT Cruiser	SDAR	●	●	●	●	●	○	○	
2010	PT Cruiser	TIPMCGW	●	●	●	●	●	●	●	003F, 020E, 0215, 028F, 028E, 0211
2010	PT Cruiser	PDM	●	●	●	●	○	●	○	
2010	PT Cruiser	ORC	●	●	●	●	●	○	●	



YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2010	PT Cruiser	ABS	●	●	●	●	●	●	●	005E, 0060, 005B
2010	PT Cruiser	PCM	●	●	●	●	●	●	●	0042, 0149, 0142, 0044, 0145, 012D, 0173, 0049, 013B, 0127, 0126, 0411, 0129, 026C, 026D, 0128, 012E, 012F, 013C, 012C, 012A, 012B
2010	PT Cruiser	AMP	●	●	●	●	●	○	●	0069, 006D, 0073, 0068, 006A, 0289, 028A, 006B, 006C
2010	PT Cruiser	OCM	●	●	●	●	●	○	○	011E
2010	PT Cruiser	DDM	●	●	●	●	●	●	○	
2010	Mini-Van	HFM	●	●	●	●	○	●	○	
2010	Mini-Van	DSD	●	●	●	●	○	●	○	
2010	Mini-Van	SKREEM	●	●	●	●	●	○	○	8003, 8004, 8005, 8006, 8007, 01D2, 800D, 8008, 8009, 800A, 800B, 800C, 01DE, 800E, 01DA
2010	Mini-Van	PTS	●	●	●	●	●	●	○	
2010	Mini-Van	OCM	●	●	●	●	○	○	○	011E, 802A, 802B, 8023, 8024
2010	Mini-Van	SDAR	●	●	●	●	●	●	○	
2010	Mini-Van	MIC/CCN	●	●	●	●	○	●	○	
2010	Mini-Van	PCM	●	●	●	●	○	●	○	
2010	Mini-Van	BCM	●	●	●	●	○	●	○	
2010	Mini-Van	TCM	●	●	●	●	●	●	●	
2010	Mini-Van	IPM	●	●	●	●	○	●	○	
2010	Mini-Van	MHSM	●	●	●	●	○	●	○	
2010	Mini-Van	EOM	●	●	●	○	○	○	○	
2010	Mini-Van	MTC	●	●	●	●	○	●	○	
2010	Mini-Van	PSD	●	●	●	●	○	●	○	
2010	Mini-Van	ORC	●	●	●	●	○	○	○	
2010	Mini-Van	ABS	●	●	●	●	●	○	○	
2010	Mini-Van	PLGM	●	●	●	●	●	●	●	
2010	Mini-Van	ATC	●	●	●	●	○	●	○	
2010	Routan	VES2	●	●	●	●	●	●	●	
2010	Routan	RADIO	●	●	●	●	●	●	●	
2010	Routan	DMFR	●	●	●	●	●	●	●	
2010	Routan	PSDML	●	●	●	●	●	○	●	
2010	Routan	HVAC	●	●	●	●	●	●	●	00EA, 00E9, 00EC
2010	Routan	TIPMCGW	●	●	●	●	●	●	●	003F, 002E, 021F
2010	Routan	DMRL	●	●	●	●	●	●	●	
2010	Routan	ORC	●	●	●	●	●	○	●	0122
2010	Routan	SUNR	●	●	●	●	●	●	○	
2010	Routan	HFM	●	●	●	●	●	●	○	
2010	Routan	CCN	●	●	●	●	●	●	○	008C, 0091, 0094, 0096

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2010	Routan	WCM	●	●	●	●	●	●	●	02A7, 03E6, 0232, 0230, 022F, 01DE, 01D2, 0228, 0225, 0231, 0233, 01DA
2010	Routan	PCM	●	●	●	●	●	●	●	027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 02F9, 0044, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 0177, 0304, 0173, 0281, 0280, 02FA, 0176, 024E, 0170, 012B, 0269, 01FC, 013B, 016F
2010	Routan	FSM	●	●	●	●	●	●	○	
2010	Routan	DMFL	●	●	●	●	●	●	●	
2010	Routan	AMP	●	●	●	●	●	○	●	
2010	Routan	DVD	●	●	●	●	●	○	○	
2010	Routan	PLGM	●	●	●	●	●	●	●	
2010	Routan	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2010	Routan	PTS	●	●	●	●	●	●	●	02ED, 03B7
2010	Routan	DMRR	●	●	●	●	●	●	●	
2010	Routan	VES3	●	●	●	●	●	●	●	
2010	Routan	PSDMR	●	●	●	●	●	○	●	
2010	Routan	SAS	●	●	●	●	○	○	○	
2010	Routan	MSMD	●	●	●	●	●	○	○	0117
2010	Town & Country / Caravan	PCM	●	●	●	●	●	●	●	027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 02F9, 0044, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 0177, 0304, 0173, 0281, 0280, 0176, 024E, 0170, 016F, 012B, 0269, 01FC, 013B, 02BA, 02BF, 02BD, 0049, 031D, 02C1, 02C2, 02FA
2010	Town & Country / Caravan	TIPMCGW	●	●	●	●	●	●	●	002E
2010	Town & Country / Caravan	RADIO	●	●	●	●	●	●	●	
2010	Town & Country / Caravan	AHBM	●	●	●	●	●	○	○	
2010	Town & Country / Caravan	PSDMR	●	●	●	●	●	○	●	
2010	Town & Country / Caravan	DMFL	●	●	●	●	●	●	●	
2010	Town & Country / Caravan	HLDT	●	●	●	●	●	●	○	
2010	Town & Country / Caravan	HVAC	●	●	●	●	●	●	●	00EA, 00E9, 00EC
2010	Town & Country / Caravan	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2010	Town & Country / Caravan	ITM	●	●	●	●	●	●	●	
2010	Town & Country / Caravan	VES2	●	●	●	●	●	●	●	
2010	Town & Country / Caravan	FSM	●	●	●	●	●	●	○	
2010	Town & Country / Caravan	DMRR	●	●	●	●	●	●	●	
2010	Town & Country / Caravan	AMP	●	●	●	●	●	○	●	
2010	Town & Country / Caravan	CCN	●	●	●	●	●	●	○	008C, 0091, 0094, 0096
2010	Town & Country / Caravan	DMFR	●	●	●	●	●	●	●	
2010	Town & Country / Caravan	BSM	●	●	●	●	●	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2010	Town & Country / Caravan	SDARV	●	●	●	●	●	○	○	
2010	Town & Country / Caravan	ORC	●	●	●	●	●	○	●	0122
2010	Town & Country / Caravan	DMRL	●	●	●	●	●	●	●	
2010	Town & Country / Caravan	HFM	●	●	●	●	●	●	○	
2010	Town & Country / Caravan	DVD	●	●	●	●	●	○	○	
2010	Town & Country / Caravan	PLGM	●	●	●	●	●	●	●	
2010	Town & Country / Caravan	SAS	●	●	●	●	○	○	○	
2010	Town & Country / Caravan	MSMD	●	●	●	●	●	○	○	0117
2010	Town & Country / Caravan	TCM	●	●	●	●	●	●	○	
2010	Town & Country / Caravan	VES3	●	●	●	●	●	●	●	
2010	Town & Country / Caravan	WCM	●	●	●	●	●	●	●	02A7, 03E6, 0232, 0230, 022F, 01DE, 01D2, 0228, 0225, 0231, 0233, 01DA
2010	Town & Country / Caravan	SUNR	●	●	●	●	●	●	○	
2010	Town & Country / Caravan	PSDML	●	●	●	●	●	○	●	
2010	Town & Country / Caravan	PTS	●	●	●	●	●	●	●	02ED, 03B7
2010	Grand Cherokee	TM	●	●	●	○	○	○	○	
2010	Grand Cherokee	LRSM	●	●	●	●	●	○	○	
2010	Grand Cherokee	PTS	●	●	●	●	●	●	●	02ED, 03B7
2010	Grand Cherokee	ESM	●	●	●	●	●	●	○	
2010	Grand Cherokee	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2010	Grand Cherokee	AMP	●	●	●	●	●	○	●	
2010	Grand Cherokee	PDM	●	●	●	●	●	●	●	
2010	Grand Cherokee	MSMD	●	●	●	●	●	○	○	0117
2010	Grand Cherokee	HVAC	●	●	●	●	●	●	●	00EA, 00E9
2010	Grand Cherokee	SUNR	●	●	●	●	●	●	○	
2010	Grand Cherokee	SAS	●	●	●	●	○	○	○	
2010	Grand Cherokee	HFM	●	●	●	●	●	●	○	
2010	Grand Cherokee	EOM	●	●	●	●	●	○	●	
2010	Grand Cherokee	TCM	●	●	●	●	●	○	○	
2010	Grand Cherokee	DDM	●	●	●	●	●	●	●	
2010	Grand Cherokee	VES3	●	●	●	●	●	●	●	
2010	Grand Cherokee	HSM	●	●	●	●	●	●	●	
2010	Grand Cherokee	SDARV	●	●	●	●	●	○	○	
2010	Grand Cherokee	AHBM	●	●	●	●	●	○	○	
2010	Grand Cherokee	CCN	●	●	●	●	●	●	●	0097, 008C, 008F, 008E, 0091, 0094, 0099, 0098, 0090
2010	Grand Cherokee	ORC	●	●	●	●	○	●	○	0122
2010	Grand Cherokee	AHLM	●	●	●	●	●	●	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2010	Grand Cherokee	WCM	●	●	●	●	●	●	●	02A7, 03E6, 0232, 0230, 022F, 01DE, 01D2, 0228, 0225, 0233, 01DA
2010	Grand Cherokee	FCMCGW	●	●	●	●	●	●	●	02F1, 02F0, 02F3, 02EF, 0039, 003C, 003D, 02A6, 02A5, 02A4, 0032, 003E, 0036, 00D5, 00D8, 0037, 0035, 0034, 00DB, 00D6, 00D9, 003A, 002E, 0293, 0033, 00C6, 00DA, 0272, 0273
2010	Grand Cherokee	RADIO	●	●	●	●	●	●	●	
2010	Grand Cherokee	ITM	●	●	●	●	●	●	●	
2010	Grand Cherokee	FDCM	●	●	●	●	●	●	●	
2010	Grand Cherokee	PCM	●	●	●	●	●	●	●	027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 02F9, 0044, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 0177, 0304, 0173, 0281, 0280, 02FA, 0176, 024E, 0170, 012B, 0269, 01FC, 013B, 016F, 0042, 0149, 0142, 012D, 0045, 0046, 014B, 014A, 0049, 014D, 0146, 0147
2010	Commander	HSM	●	●	●	●	●	●	●	
2010	Commander	TCM	●	●	●	●	●	○	○	
2010	Commander	AHLM	●	●	●	●	●	●	○	
2010	Commander	DDM	●	●	●	●	●	●	●	
2010	Commander	HVAC	●	●	●	●	●	●	●	00EA, 00E9
2010	Commander	CCN	●	●	●	●	●	●	●	0097, 008C, 008F, 008E, 0091, 0094, 0099, 0098, 0090
2010	Commander	FCMCGW	●	●	●	●	●	●	●	02F1, 02F0, 02F3, 02EF, 0039, 003C, 003D, 02A6, 02A5, 02A4, 0032, 003E, 0036, 00D5, 00D8, 0037, 0035, 0034, 00DB, 00D6, 00D9, 003A, 002E, 0293, 0033, 00C6, 00DA, 0272, 0273
2010	Commander	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2010	Commander	PCM	●	●	●	●	●	●	●	027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 0126, 02F9, 0044, 0411, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 0177, 0304, 0173, 0281, 0280, 0176, 024E, 0170, 016F, 012B, 0269, 01FC, 013B, 02FA, 0042, 0149, 0142, 012D, 0045, 0046, 014B, 014A, 0049, 0146, 0147
2010	Commander	PLGM	●	●	●	●	●	●	●	
2010	Commander	SDARV	●	●	●	●	●	○	○	
2010	Commander	VES3	●	●	●	●	●	●	●	
2010	Commander	ESM	●	●	●	●	●	●	○	
2010	Commander	SAS	●	●	●	●	○	○	○	
2010	Commander	ITM	●	●	●	●	●	●	●	
2010	Commander	ORC	●	●	●	●	○	●	○	0122
2010	Commander	LRSM	●	●	●	●	●	○	○	
2010	Commander	WCM	●	●	●	●	●	●	●	02A7, 01D2, 0228, 0225, 0232, 0230, 022F, 0233, 01DA, 03E6, 01DE
2010	Commander	PDM	●	●	●	●	●	●	●	
2010	Commander	RADIO	●	●	●	●	●	●	●	
2010	Commander	FDCM	●	●	●	●	●	●	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2010	Commander	MSMD	●	●	●	●	●	○	○	0117
2010	Commander	PTS	●	●	●	●	●	●	●	02ED, 03B7
2010	Commander	TM	●	●	●	○	○	○	○	
2010	Commander	HFM	●	●	●	●	●	●	○	
2010	Commander	AHBM	●	●	●	●	●	○	○	
2010	Commander	AMP	●	●	●	●	●	○	●	
2010	Commander	SUNR	●	●	●	●	●	●	○	
2010	Viper (Pre-2011)	PCM	●	●	●	●	●	●	○	013E, 0126, 0141, 0044, 0325, 0193, 0128, 0145, 0326, 012C, 012A, 0081
2010	Viper (Pre-2011)	OCM	●	●	●	●	●	○	○	02AD
2010	Viper (Pre-2011)	HVAC	●	●	●	●	○	●	○	
2010	Viper (Pre-2011)	MIC/CCN	●	●	●	●	●	○	○	801A
2010	Viper (Pre-2011)	RADIO	●	●	●	○	○	●	○	
2010	Viper (Pre-2011)	PCI to CAN Gateway	●	●	●	●	○	○	○	
2010	Viper (Pre-2011)	BCM	●	●	●	●	○	●	○	
2010	Viper (Pre-2011)	SDAR	●	●	●	●	●	●	○	
2010	Viper (Pre-2011)	ABS	●	●	●	●	○	●	○	
2010	Viper (Pre-2011)	ORC	●	●	●	●	●	●	●	
2011	Ram 3500 Pickup	SDARV	●	●	●	●	●	○	○	
2011	Ram 3500 Pickup	DTCM	●	●	●	●	●	●	○	
2011	Ram 3500 Pickup	HSM	●	●	●	●	●	●	●	0412
2011	Ram 3500 Pickup	AMP	●	●	●	●	●	○	●	
2011	Ram 3500 Pickup	MSMD	●	●	●	●	●	○	○	0117
2011	Ram 3500 Pickup	CCN	●	●	●	●	●	●	●	
2011	Ram 3500 Pickup	WCM	●	●	●	●	●	●	●	02A7, 03E6
2011	Ram 3500 Pickup	DMFR	●	●	●	●	●	●	●	
2011	Ram 3500 Pickup	ITBM	●	●	●	●	○	○	○	
2011	Ram 3500 Pickup	RADIO	●	●	●	●	●	●	●	
2011	Ram 3500 Pickup	HVAC	●	●	●	●	●	●	●	
2011	Ram 3500 Pickup	ORC	●	●	●	●	●	○	●	
2011	Ram 3500 Pickup	TIPMCGW	●	●	●	●	●	●	●	0214, 0476
2011	Ram 3500 Pickup	SAS	●	●	●	●	○	○	○	
2011	Ram 3500 Pickup	ABS	●	●	●	●	●	●	●	0002
2011	Ram 3500 Pickup	HFM	●	●	●	●	●	●	○	
2011	Ram 3500 Pickup	VES3	●	●	●	●	●	●	●	
2011	Ram 3500 Pickup	PCM	●	●	●	●	●	●	●	025E, 0260, 0261, 0263, 0154, 0155, 0044, 0265, 0049, 0280, 03C8, 024E, 0179

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2011	Ram 3500 Pickup	DMFL	●	●	●	●	●	●	●	
2011	Ram 3500 Pickup	PTS	●	●	●	●	●	●	●	02ED, 03B7
2011	Ram 3500 Cab Chassis	MSMD	●	●	●	●	●	○	○	0117
2011	Ram 3500 Cab Chassis	AMP	●	●	●	●	●	○	●	
2011	Ram 3500 Cab Chassis	RADIO	●	●	●	●	●	●	●	
2011	Ram 3500 Cab Chassis	TCM	●	●	●	●	○	●	○	01F6
2011	Ram 3500 Cab Chassis	HFM	●	●	●	●	●	●	○	
2011	Ram 3500 Cab Chassis	HSM	●	●	●	●	●	●	●	0412
2011	Ram 3500 Cab Chassis	DCU	●	○	○	○	○	○	○	
2011	Ram 3500 Cab Chassis	WCM	●	●	●	●	●	●	●	02A7, 03E6
2011	Ram 3500 Cab Chassis	ORC	●	●	●	●	●	○	●	
2011	Ram 3500 Cab Chassis	PCM	●	●	●	●	●	●	●	0126, 0411, 0154, 0155, 0044, 017B, 0049, 03C8, 0179
2011	Ram 3500 Cab Chassis	ITBM	●	●	●	●	○	○	○	
2011	Ram 3500 Cab Chassis	DMFL	●	●	●	●	●	●	●	
2011	Ram 3500 Cab Chassis	CCN	●	●	●	●	●	●	●	
2011	Ram 3500 Cab Chassis	HVAC	●	●	●	●	●	●	●	
2011	Ram 3500 Cab Chassis	DMFR	●	●	●	●	●	●	●	
2011	Ram 3500 Cab Chassis	DTCM	●	●	●	●	●	●	○	
2011	Ram 3500 Cab Chassis	TIPMCGW	●	●	●	●	●	●	●	0214, 003F, 002E
2011	Ram 3500 Cab Chassis	SAS	●	●	●	●	○	○	○	
2011	Ram 3500 Cab Chassis	ABS	●	●	●	●	●	●	●	0002
2011	Ram 2500	DTCM	●	●	●	●	●	●	○	
2011	Ram 2500	SDARV	●	●	●	●	●	○	○	
2011	Ram 2500	WCM	●	●	●	●	●	●	●	02A7, 03E6, 0232, 0230, 0231, 022F
2011	Ram 2500	HVAC	●	●	●	●	●	●	●	
2011	Ram 2500	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2011	Ram 2500	SAS	●	●	●	●	○	○	○	
2011	Ram 2500	FDCM	●	●	●	●	●	○	○	
2011	Ram 2500	PTS	●	●	●	●	●	●	●	02ED, 03B7
2011	Ram 2500	ITBM	●	●	●	●	○	○	○	
2011	Ram 2500	HSM	●	●	●	●	●	●	●	0412
2011	Ram 2500	RADIO	●	●	●	●	●	●	●	
2011	Ram 2500	AMP	●	●	●	●	●	○	●	
2011	Ram 2500	DMFL	●	●	●	●	●	●	●	
2011	Ram 2500	HFM	●	●	●	●	●	●	○	
2011	Ram 2500	ORC	●	●	●	●	●	○	●	
2011	Ram 2500	CCN	●	●	●	●	●	●	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2011	Ram 2500	PCM	●	●	●	●	●	●	●	0126, 0411, 025E, 0260, 0261, 0263, 0154, 0155, 0044, 0265, 0049, 0280, 03C8, 024E, 0179
2011	Ram 2500	DMFR	●	●	●	●	●	●	●	
2011	Ram 2500	TIPMCGW	●	●	●	●	●	●	●	0476
2011	Ram 2500	ABS	●	●	●	●	●	●	●	0002
2011	Ram 2500	VES3	●	●	●	●	●	●	●	
2011	Ram 2500	MSMD	●	●	●	●	●	○	○	0117
2011	Ram 4500/5500	AMP	●	●	●	●	●	○	●	
2011	Ram 4500/5500	CCN	●	●	●	●	●	●	●	
2011	Ram 4500/5500	MSMD	●	●	●	●	●	○	○	0117
2011	Ram 4500/5500	DCU	●	○	○	○	○	○	○	
2011	Ram 4500/5500	DTCM	●	●	●	●	●	●	○	
2011	Ram 4500/5500	WCM	●	●	●	●	●	●	●	02A7, 03E6
2011	Ram 4500/5500	SAS	●	●	●	●	○	○	○	
2011	Ram 4500/5500	HVAC	●	●	●	●	●	●	●	
2011	Ram 4500/5500	ORC	●	●	●	●	●	○	●	
2011	Ram 4500/5500	TCM	●	●	●	●	○	●	○	01F6
2011	Ram 4500/5500	DMFL	●	●	●	●	●	●	●	
2011	Ram 4500/5500	HFM	●	●	●	●	●	●	○	
2011	Ram 4500/5500	PCM	●	●	●	●	●	●	●	0154, 0155, 0044, 017B, 0049, 03C8, 0179
2011	Ram 4500/5500	TIPMCGW	●	●	●	●	●	●	●	0214, 003F, 002E
2011	Ram 4500/5500	ITBM	●	●	●	●	○	○	○	
2011	Ram 4500/5500	DMFR	●	●	●	●	●	●	●	
2011	Ram 4500/5500	HSM	●	●	●	●	●	●	●	0412
2011	Ram 4500/5500	RADIO	●	●	●	●	●	●	●	
2011	Ram 4500/5500	ABS	●	●	●	●	●	●	●	0002
2011	Ram 1500	TIPMCGW	●	●	●	●	●	●	●	0476, 002E
2011	Ram 1500	BTM	●	●	●	●	●	●	○	
2011	Ram 1500	DMFL	●	●	●	●	●	●	●	
2011	Ram 1500	DRM	●	●	●	●	●	○	○	
2011	Ram 1500	WCM	●	●	●	●	●	●	●	02A7, 03E6, 0232, 0230, 0231, 022F
2011	Ram 1500	SAS	●	●	●	●	○	○	○	
2011	Ram 1500	DMFR	●	●	●	●	●	●	●	
2011	Ram 1500	PTS	●	●	●	●	●	●	●	02ED, 03B7
2011	Ram 1500	MCPB	●	○	○	●	○	○	○	
2011	Ram 1500	ABS	●	●	●	●	●	●	●	0002, 03BB
2011	Ram 1500	MCPA	●	○	○	●	○	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2011	Ram 1500	BPCM	●	●	●	●	●	●	○	
2011	Ram 1500	HSM	●	●	●	●	●	●	●	0412
2011	Ram 1500	OBCM	●	●	●	●	●	●	○	
2011	Ram 1500	HCP	●	●	●	●	●	○	○	
2011	Ram 1500	ITBM	●	●	●	●	○	○	○	
2011	Ram 1500	APM	●	○	○	○	○	○	○	
2011	Ram 1500	MSMD	●	●	●	●	●	○	○	0117
2011	Ram 1500	PCM	●	●	●	●	●	●	●	0126, 0411, 027B, 025F, 025E, 0260, 027C, 0262, 0261, 027D, 0264, 0263, 02F8, 0127, 0140, 02F9, 0044, 026C, 026D, 0128, 027E, 0266, 0265, 0145, 02FB, 013C, 012C, 0177, 0173, 0281, 0280, 02FA, 0176, 024E, 0170, 012B, 0269, 01FC, 013B
2011	Ram 1500	HFM	●	●	●	●	●	●	○	
2011	Ram 1500	EPS	●	●	●	●	●	○	○	
2011	Ram 1500	DTCM	●	●	●	●	●	●	●	
2011	Ram 1500	TCM	●	●	●	●	●	○	○	
2011	Ram 1500	EAC	●	●	●	●	●	○	○	
2011	Ram 1500	CCN	●	●	●	●	●	●	●	
2011	Ram 1500	RADIO	●	●	●	●	●	●	●	
2011	Ram 1500	SDARV	●	●	●	●	●	○	○	
2011	Ram 1500	PHGM	●	●	●	●	○	●	○	
2011	Ram 1500	HVAC	●	●	●	●	●	●	●	00EC
2011	Ram 1500	ORC	●	●	●	●	●	○	●	
2011	Ram 1500	HGM	●	●	●	●	●	●	●	
2011	Ram 1500	AMP	●	●	●	●	●	○	●	
2011	Ram 1500	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2011	Ram 1500	VES3	●	●	●	●	●	●	●	
2011	Ram (Mexico)	DMFR	●	●	●	●	●	●	●	
2011	Ram (Mexico)	WCM	●	●	●	●	●	●	●	02A7, 03E6, 0232, 0230, 0231, 022F
2011	Ram (Mexico)	ABS	●	●	●	●	●	●	●	0002
2011	Ram (Mexico)	DTCM	●	●	●	●	●	●	○	
2011	Ram (Mexico)	PCM	●	●	●	●	●	●	●	0126, 0411, 025E, 0260, 0261, 0263, 0154, 0155, 0044, 0265, 017B, 0049, 0280, 03C8, 024E
2011	Ram (Mexico)	TIPMCGW	●	●	●	●	●	●	●	0476
2011	Ram (Mexico)	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2011	Ram (Mexico)	CCN	●	●	●	●	●	●	●	
2011	Ram (Mexico)	HSM	●	●	●	●	●	●	●	0412
2011	Ram (Mexico)	DMFL	●	●	●	●	●	●	●	
2011	Ram (Mexico)	SAS	●	●	●	●	○	○	○	





YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2011	Journey	HSM	●	●	●	●	●	●	●	
2011	Journey	HFM	●	●	●	●	●	○	○	
2011	Freemont	HVAC	●	●	●	●	●	●	●	
2011	Freemont	TGW	●	●	●	●	●	○	○	
2011	Freemont	DDM	●	●	●	●	●	●	●	
2011	Freemont	PDM	●	●	●	●	●	●	●	
2011	Freemont	PCM	●	●	●	●	●	●	●	0432, 042D, 031D, 0126, 0411
2011	Freemont	BCM	●	●	●	●	●	●	●	
2011	Freemont	AMP	●	●	●	●	●	○	○	
2011	Freemont	RFH	●	●	●	●	●	●	●	0442
2011	Freemont	VES3	●	●	●	●	●	●	○	
2011	Freemont	HSM	●	●	●	●	●	●	●	
2011	Freemont	ABS	●	●	●	●	●	●	●	
2011	Freemont	HFM	●	●	●	●	●	○	○	
2011	Freemont	IPC	●	●	●	●	●	●	○	
2011	Freemont	DTCM	●	●	●	●	●	●	●	
2011	Freemont	ORC	●	●	●	●	●	○	●	
2011	Freemont	SCCM	●	●	●	●	●	○	○	
2011	Freemont	ICS	●	●	●	●	●	●	○	
2011	Freemont	ITM	●	●	●	●	●	●	●	
2011	Freemont	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2011	Freemont	PTS	●	●	●	●	●	●	●	02ED, 03B7
2011	Wrangler	TIPMCGW	●	●	●	●	●	●	●	003F, 003A, 002E, 021F
2011	Wrangler	CCN	●	●	●	●	●	●	○	008C, 0091, 0094, 0096
2011	Wrangler	ASBS	●	●	●	●	●	○	○	0317, 0318, 031A, 031B, 0319
2011	Wrangler	PCM	●	●	●	●	●	●	●	0126, 0411, 02BA, 031D
2011	Wrangler	AMP	●	●	●	●	●	○	●	
2011	Wrangler	HFM	●	●	●	●	●	●	○	
2011	Wrangler	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2011	Wrangler	ORC	●	●	●	●	●	○	●	0122
2011	Wrangler	HVAC	●	●	●	●	●	●	●	
2011	Wrangler	RADIO	●	●	●	●	●	●	●	
2011	Wrangler	ITM	●	●	●	●	●	●	●	
2011	Wrangler	SAS	●	●	●	●	○	○	○	
2011	Wrangler	WCM	●	●	●	●	●	○	●	
2011	Wrangler	TCM	●	●	●	●	●	○	○	
2011	Wrangler	ESM	●	●	●	●	●	●	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2011	Sebring / 200 / Avenger	TIPMCGW	●	●	●	●	●	●	●	
2011	Sebring / 200 / Avenger	AWD	●	●	●	●	●	○	●	
2011	Sebring / 200 / Avenger	ABS	●	●	●	●	●	●	●	0002
2011	Sebring / 200 / Avenger	RADIO	●	●	●	●	●	●	●	
2011	Sebring / 200 / Avenger	ITM	●	●	●	●	●	●	●	
2011	Sebring / 200 / Avenger	HVAC	●	●	●	●	●	●	●	
2011	Sebring / 200 / Avenger	HFM	●	●	●	●	●	●	○	
2011	Sebring / 200 / Avenger	VES3	●	●	●	●	●	●	●	
2011	Sebring / 200 / Avenger	AMP	●	●	●	●	●	○	●	
2011	Sebring / 200 / Avenger	ESM	●	●	●	●	○	●	●	
2011	Sebring / 200 / Avenger	PCM	●	●	●	●	●	●	●	0126,0411
2011	Sebring / 200 / Avenger	PDM	●	●	●	●	●	●	○	
2011	Sebring / 200 / Avenger	SAS	●	●	●	●	○	○	○	
2011	Sebring / 200 / Avenger	WCM	●	●	●	●	●	○	●	
2011	Sebring / 200 / Avenger	ORC	●	●	●	●	●	○	●	
2011	Sebring / 200 / Avenger	TCM	●	●	●	●	○	●	●	
2011	Sebring / 200 / Avenger	CCN	●	●	●	●	●	●	●	
2011	Sebring / 200 / Avenger	PTCM	●	●	●	●	●	○	●	
2011	Sebring / 200 / Avenger	DDM	●	●	●	●	●	●	○	
2011	Nitro	TCM	●	●	●	●	●	○	○	
2011	Nitro	CCN	●	●	●	●	●	●	○	008C, 0091, 0094, 0096
2011	Nitro	HFM	●	●	●	●	●	●	○	
2011	Nitro	ORC	●	●	●	●	●	○	●	
2011	Nitro	DMFR	●	●	●	●	●	●	●	
2011	Nitro	TIPMCGW	●	●	●	●	●	●	●	003F, 003A, 021F, 02E2
2011	Nitro	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2011	Nitro	AMP	●	●	●	●	●	○	●	
2011	Nitro	PTS	●	●	●	●	●	●	●	02ED, 03B7
2011	Nitro	DMFL	●	●	●	●	●	●	●	
2011	Nitro	WCM	●	●	●	●	●	○	●	
2011	Nitro	ESM	●	●	●	●	●	●	○	
2011	Nitro	OCM	●	●	●	●	●	○	○	011E
2011	Nitro	ITM	●	●	●	●	●	●	●	
2011	Nitro	SAS	●	●	●	●	○	○	○	
2011	Nitro	PCM	●	●	●	●	●	●	●	0126,0411
2011	Nitro	HVAC	●	●	●	●	●	●	●	
2011	Nitro	RADIO	●	●	●	●	●	●	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2011	Liberty	HFM	●	●	●	●	●	●	○	
2011	Liberty	PCM	●	●	●	●	●	●	●	0126, 0411, 02BA, 031D
2011	Liberty	MSMD	●	●	●	●	●	●	●	0452, 0117
2011	Liberty	DMFL	●	●	●	●	●	●	●	
2011	Liberty	ESM	●	●	●	●	●	●	○	
2011	Liberty	ITM	●	●	●	●	●	●	●	
2011	Liberty	SUNR	●	●	●	●	●	○	○	
2011	Liberty	TCM	●	●	●	●	●	○	○	
2011	Liberty	RADIO	●	●	●	●	●	●	●	
2011	Liberty	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2011	Liberty	AMP	●	●	●	●	●	○	●	
2011	Liberty	HVAC	●	●	●	●	●	●	●	
2011	Liberty	OCM	●	●	●	●	●	○	○	011E
2011	Liberty	ORC	●	●	●	●	●	○	●	
2011	Liberty	TIPMCGW	●	●	●	●	●	●	●	003F, 003A, 021F, 02E2
2011	Liberty	CCN	●	●	●	●	●	●	●	
2011	Liberty	FDCM	●	●	●	●	●	●	○	
2011	Liberty	PTS	●	●	●	●	●	●	●	02ED, 03B7
2011	Liberty	SAS	●	●	●	●	○	○	○	
2011	Liberty	DMFR	●	●	●	●	●	●	●	
2011	Liberty	WCM	●	●	●	●	●	○	●	
2011	Challenger	WCM	●	●	●	●	●	●	●	02A7, 03E6, 0232, 0230, 0231, 022F
2011	Challenger	ORC	●	●	●	●	●	○	●	
2011	Challenger	TCM	●	●	●	●	●	○	○	
2011	Challenger	RADIO	●	●	●	●	●	●	●	
2011	Challenger	DDM	●	●	●	●	●	●	○	
2011	Challenger	PDM	●	●	●	●	●	●	○	
2011	Challenger	AMP	●	●	●	●	●	○	●	
2011	Challenger	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2011	Challenger	CCN	●	●	●	●	●	●	●	
2011	Challenger	HVAC	●	●	●	●	●	●	●	
2011	Challenger	PEM	●	●	●	●	●	○	●	0442
2011	Challenger	HSM	●	●	●	●	●	●	●	
2011	Challenger	EOM	●	●	●	●	●	○	●	
2011	Challenger	SAS	●	●	●	●	●	●	○	
2011	Challenger	PCM	●	●	●	●	●	●	●	0126, 0411
2011	Challenger	SUNR	●	●	●	●	●	●	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2011	Challenger	ABS	●	●	●	●	●	●	●	
2011	Challenger	ESM	●	●	●	●	●	●	○	
2011	Challenger	EPS	●	●	●	●	●	○	○	
2011	Challenger	TIPMCGW	●	●	●	●	●	●	●	002E
2011	Challenger	HFM	●	●	●	●	●	●	○	
2011	Charger (Post-2011)	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2011	Charger (Post-2011)	MSM	●	●	●	●	●	●	●	0452
2011	Charger (Post-2011)	BCM	●	●	●	●	●	●	●	
2011	Charger (Post-2011)	SCCM	●	●	●	●	●	○	○	
2011	Charger (Post-2011)	BSM	●	●	●	●	●	○	○	
2011	Charger (Post-2011)	ESM	●	●	●	●	●	●	○	
2011	Charger (Post-2011)	ORC	●	●	●	●	●	○	●	
2011	Charger (Post-2011)	VSIM	●	●	●	●	●	●	●	
2011	Charger (Post-2011)	HVAC	●	●	●	●	●	●	●	
2011	Charger (Post-2011)	RFH	●	●	●	●	●	●	●	0442
2011	Charger (Post-2011)	IPC	●	●	●	●	●	●	○	
2011	Charger (Post-2011)	ACC	●	●	●	●	●	○	●	
2011	Charger (Post-2011)	DDM	●	●	●	●	●	●	●	
2011	Charger (Post-2011)	HFM	●	●	●	●	●	○	○	
2011	Charger (Post-2011)	EPS	●	●	●	●	●	○	○	
2011	Charger (Post-2011)	PDM	●	●	●	●	●	●	●	
2011	Charger (Post-2011)	AMP	●	●	●	●	●	○	○	
2011	Charger (Post-2011)	PTS	●	●	●	●	●	●	●	02ED, 03B7
2011	Charger (Post-2011)	TGW	●	●	●	●	●	○	○	
2011	Charger (Post-2011)	ABS	●	●	●	●	●	●	●	
2011	Charger (Post-2011)	TCM	●	●	●	●	●	○	●	
2011	Charger (Post-2011)	PCM	●	●	●	●	●	●	●	0126, 0411
2011	Charger (Post-2011)	ICS	●	●	●	●	●	●	○	
2011	Charger (Post-2011)	HSM	●	●	●	●	●	●	●	
2011	Charger (Post-2011)	DTCM	●	●	●	●	●	●	●	
2011	300 / Magnum / Charger (Pre-2011)	PDM	●	●	●	●	●	●	●	
2011	300 / Magnum / Charger (Pre-2011)	RFH	●	●	●	●	●	●	●	0442
2011	300 / Magnum / Charger (Pre-2011)	ABS	●	●	●	●	●	●	●	
2011	300 / Magnum / Charger (Pre-2011)	ORC	●	●	●	●	●	○	●	
2011	300 / Magnum / Charger (Pre-2011)	TGW	●	●	●	●	●	○	○	
2011	300 / Magnum / Charger (Pre-2011)	IPC	●	●	●	●	●	●	○	
2011	300 / Magnum / Charger (Pre-2011)	DTCM	●	●	●	●	●	●	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2011	300 / Magnum / Charger (Pre-2011)	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2011	300 / Magnum / Charger (Pre-2011)	AMP	●	●	●	●	●	○	○	
2011	300 / Magnum / Charger (Pre-2011)	DDM	●	●	●	●	●	●	●	
2011	300 / Magnum / Charger (Pre-2011)	TCM	●	●	●	●	●	○	●	
2011	300 / Magnum / Charger (Pre-2011)	AFLS	●	●	●	●	●	●	○	
2011	300 / Magnum / Charger (Pre-2011)	ICS	●	●	●	●	●	●	○	
2011	300 / Magnum / Charger (Pre-2011)	HSM	●	●	●	●	●	●	●	
2011	300 / Magnum / Charger (Pre-2011)	PTS	●	●	●	●	●	●	●	02ED, 03B7
2011	300 / Magnum / Charger (Pre-2011)	BCM	●	●	●	●	●	●	●	
2011	300 / Magnum / Charger (Pre-2011)	HFM	●	●	●	●	●	○	○	
2011	300 / Magnum / Charger (Pre-2011)	EPS	●	●	●	●	●	○	○	
2011	300 / Magnum / Charger (Pre-2011)	MSM	●	●	●	●	●	●	●	0452
2011	300 / Magnum / Charger (Pre-2011)	SCCM	●	●	●	●	●	○	○	
2011	300 / Magnum / Charger (Pre-2011)	ESM	●	●	●	●	●	●	○	
2011	300 / Magnum / Charger (Pre-2011)	BSM	●	●	●	●	●	○	○	
2011	300 / Magnum / Charger (Pre-2011)	ACC	●	●	●	●	●	○	●	
2011	300 / Magnum / Charger (Pre-2011)	HVAC	●	●	●	●	●	●	●	
2011	300 / Magnum / Charger (Pre-2011)	PCM	●	●	●	●	●	●	●	0126, 0411, 0432, 042D, 031D
2011	Compass	CCN	●	●	●	●	●	●	●	
2011	Compass	AMP	●	●	●	●	●	○	●	0069, 006D, 0079, 0068, 0303
2011	Compass	WCM	●	●	●	●	●	○	●	
2011	Compass	ORC	●	●	●	●	●	○	●	
2011	Compass	RADIO	●	●	●	●	●	●	●	
2011	Compass	PCM	●	●	●	●	●	●	●	0126, 0411, 03E1, 03DA, 0049, 03D8
2011	Compass	TCM	●	●	●	●	●	●	●	
2011	Compass	ITM	●	●	●	●	●	●	●	
2011	Compass	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2011	Compass	HVAC	●	●	●	●	●	●	●	
2011	Compass	SAS	●	●	●	●	○	○	○	
2011	Compass	TIPMCGW	●	●	●	●	●	●	●	003F, 020E, 0215, 028F, 0211
2011	Compass	HFM	●	●	●	●	●	●	○	
2011	Compass	AWD	●	●	●	●	●	●	●	
2011	Dakota	EOM	●	●	●	●	●	○	●	
2011	Dakota	AMP	●	●	●	●	●	○	●	
2011	Dakota	CCN	●	●	●	●	●	●	●	008F, 008E, 008D, 0090
2011	Dakota	RADIO	●	●	●	●	●	●	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2011	Dakota	WCM	●	●	●	●	●	○	●	01D2, 0228, 0226, 0225, 0232, 0231, 022F, 01DE, 0233, 023E, 0271
2011	Dakota	ORC	●	●	●	●	○	●	○	
2011	Dakota	HVAC	●	●	●	●	●	●	●	00EA, 00E8, 00E9
2011	Dakota	HFM	●	●	●	●	●	●	○	
2011	Dakota	PCM	●	●	●	●	●	●	●	0126, 0411
2011	Dakota	FCMCGW	●	●	●	●	●	●	●	02F1, 02F0, 02F3, 02EF, 0039, 003C, 003D, 02A6, 02A5, 02A4, 0032, 003E, 0036, 00D5, 00D8, 0037, 0035, 0034, 00DB, 00D6, 00D9, 003A, 0293, 0033, 00C6, 0040, 00DA, 0272, 0273
2011	Dakota	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2011	Ypsilon	ECM	●	●	●	●	●	●	●	
2011	Ypsilon	HVAC	●	●	●	●	●	●	●	
2011	Ypsilon	TCM	●	●	●	●	○	●	●	
2011	Ypsilon	EPS	●	●	●	●	○	○	●	
2011	Ypsilon	ORC	●	●	●	●	●	●	●	
2011	Ypsilon	IPC	●	●	●	●	●	●	○	
2011	Ypsilon	AHM	●	●	●	●	●	●	○	
2011	Ypsilon	BCM	●	●	●	●	●	●	○	
2011	Ypsilon	ABS	●	●	●	●	○	●	●	
2011	Caliber	TIPMCGW	●	●	●	●	●	●	●	003F, 020E, 0215, 028F, 0211
2011	Caliber	PCM	●	●	●	●	●	●	●	0126, 0411, 03E1, 03DA, 0049, 03D8
2011	Caliber	HFM	●	●	●	●	●	●	○	
2011	Caliber	AMP	●	●	●	●	●	○	●	0069, 006D, 0079, 0068, 0303
2011	Caliber	WCM	●	●	●	●	●	○	●	
2011	Caliber	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2011	Caliber	HVAC	●	●	●	●	●	●	●	
2011	Caliber	RADIO	●	●	●	●	●	●	●	
2011	Caliber	CCN	●	●	●	●	●	●	○	008C, 008F, 008E, 0094, 0092, 0096
2011	Caliber	ITM	●	●	●	●	●	●	●	
2011	Caliber	TCM	●	●	●	●	●	●	●	
2011	Caliber	SAS	●	●	●	●	○	○	○	
2011	Caliber	ORC	●	●	●	●	●	○	●	
2011	Mini-Van	IPM	●	●	●	●	○	●	○	
2011	Mini-Van	ATC	●	●	●	●	○	●	○	
2011	Mini-Van	PLGM	●	●	●	●	●	●	●	
2011	Mini-Van	MHSM	●	●	●	●	○	●	○	
2011	Mini-Van	ORC	●	●	●	●	○	○	○	
2011	Mini-Van	SDAR	●	●	●	●	●	●	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2011	Mini-Van	ABS	●	●	●	●	●	○	○	
2011	Mini-Van	BCM	●	●	●	●	○	●	○	
2011	Mini-Van	HFM	●	●	●	●	○	●	○	
2011	Mini-Van	SKREEM	●	●	●	●	●	○	○	8003, 8004, 8005, 8006, 8007, 01D2, 800D, 8008, 8009, 800A, 800B, 800C, 01DE, 800E, 01DA
2011	Mini-Van	MTC	●	●	●	●	○	●	○	
2011	Mini-Van	PTS	●	●	●	●	●	●	○	
2011	Mini-Van	DSD	●	●	●	●	○	●	○	
2011	Mini-Van	PCM	●	●	●	●	○	●	○	
2011	Mini-Van	PSD	●	●	●	●	○	●	○	
2011	Mini-Van	TCM	●	●	●	●	●	●	●	
2011	Mini-Van	EOM	●	●	●	○	○	○	○	
2011	Mini-Van	OCM	●	●	●	●	○	○	○	011E, 802A, 802B, 8023, 8024
2011	Mini-Van	MIC/CCN	●	●	●	●	○	●	○	
2011	Routan	SAS	●	●	●	●	○	○	○	
2011	Routan	PSDMR	●	●	●	●	●	○	○	
2011	Routan	DMFL	●	●	●	●	●	●	●	
2011	Routan	PEM	●	●	●	●	●	○	●	0442
2011	Routan	HVAC	●	●	●	●	●	●	●	
2011	Routan	ABS	●	●	●	●	●	●	●	0002
2011	Routan	VES3	●	●	●	●	●	●	●	
2011	Routan	HFM	●	●	●	●	●	●	○	
2011	Routan	SUNR	●	●	●	●	●	●	○	
2011	Routan	CCN	●	●	●	●	●	●	●	008C, 0091, 0094, 0096
2011	Routan	DMRL	●	●	●	●	●	●	●	
2011	Routan	TIPMCGW	●	●	●	●	●	●	●	003F, 003A, 002E, 021F
2011	Routan	DVD	●	●	●	●	●	○	○	
2011	Routan	WCM	●	●	●	●	●	●	●	02A7, 03E6, 0232, 0230, 0231, 022F
2011	Routan	AMP	●	●	●	●	●	○	●	
2011	Routan	HSM	●	●	●	●	●	●	●	0412
2011	Routan	PCM	●	●	●	●	●	●	●	0126, 0411
2011	Routan	PLGM	●	●	●	●	●	●	●	
2011	Routan	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2011	Routan	DMFR	●	●	●	●	●	●	●	
2011	Routan	VES2	●	●	●	●	●	●	●	
2011	Routan	PSDML	●	●	●	●	●	○	○	
2011	Routan	RADIO	●	●	●	●	●	●	●	



YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2011	Routan	FSM	●	●	●	●	●	●	○	
2011	Routan	PTS	●	●	●	●	●	●	●	02ED, 03B7
2011	Routan	MSMD	●	●	●	●	●	●	●	0452
2011	Routan	DMRR	●	●	●	●	●	●	●	
2011	Routan	ORC	●	●	●	●	●	○	●	
2011	Town & Country / Caravan	BTM	●	●	●	●	●	●	○	
2011	Town & Country / Caravan	ORC	●	●	●	●	●	○	●	
2011	Town & Country / Caravan	PCM	●	●	●	●	●	●	●	0126, 0411, 0145, 02BA, 02BF, 02BD, 0044, 0049, 031D, 02C1, 02C2
2011	Town & Country / Caravan	PSDML	●	●	●	●	●	○	○	
2011	Town & Country / Caravan	DMRR	●	●	●	●	●	●	●	
2011	Town & Country / Caravan	DMFR	●	●	●	●	●	●	●	
2011	Town & Country / Caravan	HVAC	●	●	●	●	●	●	●	
2011	Town & Country / Caravan	HSM	●	●	●	●	●	●	●	0412
2011	Town & Country / Caravan	DMFL	●	●	●	●	●	●	●	
2011	Town & Country / Caravan	TCM	●	●	●	●	●	●	○	
2011	Town & Country / Caravan	SAS	●	●	●	●	○	○	○	
2011	Town & Country / Caravan	EAC	●	●	●	●	●	○	○	
2011	Town & Country / Caravan	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2011	Town & Country / Caravan	HIDT	●	●	●	●	●	●	○	
2011	Town & Country / Caravan	SDARV	●	●	●	●	●	○	○	
2011	Town & Country / Caravan	MSMD	●	●	●	●	●	●	●	0452
2011	Town & Country / Caravan	PSDMR	●	●	●	●	●	○	○	
2011	Town & Country / Caravan	VES3	●	●	●	●	●	●	●	
2011	Town & Country / Caravan	PEM	●	●	●	●	●	○	●	0442
2011	Town & Country / Caravan	DMRL	●	●	●	●	●	●	●	
2011	Town & Country / Caravan	ABS	●	●	●	●	●	●	●	0002
2011	Town & Country / Caravan	WCM	●	●	●	●	●	●	●	02A7, 03E6, 0232, 0230, 0231, 022F
2011	Town & Country / Caravan	BSM	●	●	●	●	●	○	○	
2011	Town & Country / Caravan	CCN	●	●	●	●	●	●	●	
2011	Town & Country / Caravan	MCPA	●	○	○	●	○	○	○	
2011	Town & Country / Caravan	AMP	●	●	●	●	●	○	●	
2011	Town & Country / Caravan	AHBM	●	●	●	●	●	○	○	
2011	Town & Country / Caravan	HFM	●	●	●	●	●	●	○	
2011	Town & Country / Caravan	EPS	●	●	●	●	●	○	○	
2011	Town & Country / Caravan	PTS	●	●	●	●	●	●	●	02ED, 03B7
2011	Town & Country / Caravan	DRM	●	●	●	●	●	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2011	Town & Country / Caravan	BPCM	●	●	●	●	●	●	○	
2011	Town & Country / Caravan	ITM	●	●	●	●	●	●	●	
2011	Town & Country / Caravan	OBCM	●	●	●	○	●	○	○	
2011	Town & Country / Caravan	MCPB	●	○	○	●	○	○	○	
2011	Town & Country / Caravan	HCP	●	●	●	●	●	○	○	
2011	Town & Country / Caravan	RADIO	●	●	●	●	●	●	●	
2011	Town & Country / Caravan	FSM	●	●	●	●	●	●	○	
2011	Town & Country / Caravan	SUNR	●	●	●	●	●	●	○	
2011	Town & Country / Caravan	TIPMCGW	●	●	●	●	●	●	●	002E
2011	Town & Country / Caravan	DVD	●	●	●	●	●	○	○	
2011	Town & Country / Caravan	PLGM	●	●	●	●	●	●	●	
2011	Town & Country / Caravan	VES2	●	●	●	●	●	●	●	
2011	Town & Country / Caravan	PHGM	●	●	●	●	○	●	○	
2011	Town & Country / Caravan	HGM	●	●	●	●	●	●	●	
2011	Town & Country / Caravan	APM	●	○	○	○	○	○	○	
2011	Durango (Post-2011)	TIPMCGW	●	●	●	●	●	●	●	0476
2011	Durango (Post-2011)	ORC	●	●	●	●	●	○	●	0122
2011	Durango (Post-2011)	HSM	●	●	●	●	●	●	●	0412
2011	Durango (Post-2011)	RADIO	●	●	●	●	●	●	●	
2011	Durango (Post-2011)	ITM	●	●	●	●	●	●	●	
2011	Durango (Post-2011)	ACC	●	●	●	●	●	○	○	
2011	Durango (Post-2011)	SDARV	●	●	●	●	●	○	○	
2011	Durango (Post-2011)	CCN	●	●	●	●	●	●	●	
2011	Durango (Post-2011)	DTCM	●	●	●	●	●	●	●	
2011	Durango (Post-2011)	AHLM	●	●	●	●	●	●	○	
2011	Durango (Post-2011)	SAS	●	●	●	●	●	●	○	
2011	Durango (Post-2011)	BSM	●	●	●	●	●	○	○	
2011	Durango (Post-2011)	PCM	●	●	●	●	●	●	●	0126, 0411
2011	Durango (Post-2011)	MSMD	●	●	●	●	●	●	●	0452
2011	Durango (Post-2011)	PLGM	●	●	●	●	○	●	●	
2011	Durango (Post-2011)	TCM	●	●	●	●	●	○	○	
2011	Durango (Post-2011)	HFM	●	●	●	●	●	●	○	
2011	Durango (Post-2011)	DMFL	●	●	●	●	●	●	●	
2011	Durango (Post-2011)	VES3	●	●	●	●	●	●	●	
2011	Durango (Post-2011)	AHBM	●	●	●	●	○	●	○	
2011	Durango (Post-2011)	EPS	●	●	●	●	●	○	○	
2011	Durango (Post-2011)	PEM	●	●	●	●	●	○	●	0442

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2011	Durango (Post-2011)	ESM	●	●	●	●	●	●	○	
2011	Durango (Post-2011)	ABS	●	●	●	●	●	●	●	
2011	Durango (Post-2011)	WCM	●	●	●	●	●	●	●	02A7, 03E6, 0232, 0230, 0231, 022F
2011	Durango (Post-2011)	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2011	Durango (Post-2011)	AMP	●	●	●	●	●	○	●	
2011	Durango (Post-2011)	PTS	●	●	●	●	●	●	●	02ED, 03B7
2011	Durango (Post-2011)	HVAC	●	●	●	●	●	●	●	
2011	Durango (Post-2011)	DMFR	●	●	●	●	●	●	●	
2011	Grand Cherokee	EPS	●	●	●	●	●	○	○	
2011	Grand Cherokee	VES3	●	●	●	●	●	●	●	
2011	Grand Cherokee	BSM	●	●	●	●	●	○	○	
2011	Grand Cherokee	ASCM	●	●	●	●	●	○	○	
2011	Grand Cherokee	PLGM	●	●	●	●	○	●	●	
2011	Grand Cherokee	AHLM	●	●	●	●	●	●	○	
2011	Grand Cherokee	HSM	●	●	●	●	●	●	●	0412
2011	Grand Cherokee	SAS	●	●	●	●	●	●	○	
2011	Grand Cherokee	SDARV	●	●	●	●	●	○	○	
2011	Grand Cherokee	ABS	●	●	●	●	●	●	●	
2011	Grand Cherokee	PEM	●	●	●	●	●	○	●	0442
2011	Grand Cherokee	MSMD	●	●	●	●	●	●	●	0452
2011	Grand Cherokee	HFM	●	●	●	●	●	●	○	
2011	Grand Cherokee	AMP	●	●	●	●	●	○	●	
2011	Grand Cherokee	AHBM	●	●	●	●	○	●	○	
2011	Grand Cherokee	DMFR	●	●	●	●	●	●	●	
2011	Grand Cherokee	DMFL	●	●	●	●	●	●	●	
2011	Grand Cherokee	ORC	●	●	●	●	●	○	●	0122
2011	Grand Cherokee	ELSD	●	●	●	●	●	●	○	
2011	Grand Cherokee	HVAC	●	●	●	●	●	●	●	
2011	Grand Cherokee	WCM	●	●	●	●	●	●	●	02A7, 03E6, 0232, 0230, 0231, 022F
2011	Grand Cherokee	DTCM	●	●	●	●	●	●	●	
2011	Grand Cherokee	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2011	Grand Cherokee	TIPMCGW	●	●	●	●	●	●	●	0476
2011	Grand Cherokee	ITM	●	●	●	●	●	●	●	
2011	Grand Cherokee	PTS	●	●	●	●	●	●	●	02ED, 03B7
2011	Grand Cherokee	RADIO	●	●	●	●	●	●	●	
2011	Grand Cherokee	PCM	●	●	●	●	●	●	●	0126, 0411, 0432, 042D, 031D
2011	Grand Cherokee	TCM	●	●	●	●	●	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2011	Grand Cherokee	ACC	●	●	●	●	●	○	○	
2011	Grand Cherokee	CCN	●	●	●	●	●	●	●	
2011	Grand Cherokee	ESM	●	●	●	●	●	●	○	
2012	Ram 3500 Pickup	ABS	●	●	●	●	●	●	●	0002
2012	Ram 3500 Pickup	CCN	●	●	●	●	●	●	●	
2012	Ram 3500 Pickup	PCM	●	●	●	●	●	●	●	025E, 0260, 0261, 0263, 0154, 0155, 0044, 0265, 0049, 0280, 03C8, 024E, 0179
2012	Ram 3500 Pickup	DTCM	●	●	●	●	●	●	○	
2012	Ram 3500 Pickup	HFM	●	●	●	●	●	●	○	
2012	Ram 3500 Pickup	PTS	●	●	●	●	●	●	●	02ED, 03B7
2012	Ram 3500 Pickup	TIPMCGW	●	●	●	●	●	●	●	0476
2012	Ram 3500 Pickup	HVAC	●	●	●	●	●	●	●	
2012	Ram 3500 Pickup	ORC	●	●	●	●	●	○	●	
2012	Ram 3500 Pickup	RADIO	●	●	●	●	●	●	●	
2012	Ram 3500 Pickup	DMFL	●	●	●	●	●	●	●	
2012	Ram 3500 Pickup	ITBM	●	●	●	●	○	○	○	
2012	Ram 3500 Pickup	HSM	●	●	●	●	●	●	●	0412
2012	Ram 3500 Pickup	MSMD	●	●	●	●	●	○	○	0117
2012	Ram 3500 Pickup	WCM	●	●	●	●	●	●	●	02A7, 03E6
2012	Ram 3500 Pickup	VES3	●	●	●	●	●	●	●	
2012	Ram 3500 Pickup	AMP	●	●	●	●	●	○	●	
2012	Ram 3500 Pickup	DMFR	●	●	●	●	●	●	●	
2012	Ram 3500 Pickup	SAS	●	●	●	●	○	○	○	
2012	Ram 3500 Cab Chassis	DCU	●	○	○	○	○	○	○	
2012	Ram 3500 Cab Chassis	DTCM	●	●	●	●	●	●	○	
2012	Ram 3500 Cab Chassis	HFM	●	●	●	●	●	●	○	
2012	Ram 3500 Cab Chassis	ITBM	●	●	●	●	○	○	○	
2012	Ram 3500 Cab Chassis	CCN	●	●	●	●	●	●	●	
2012	Ram 3500 Cab Chassis	HVAC	●	●	●	●	●	●	●	
2012	Ram 3500 Cab Chassis	HSM	●	●	●	●	●	●	●	0412
2012	Ram 3500 Cab Chassis	RADIO	●	●	●	●	●	●	●	
2012	Ram 3500 Cab Chassis	AMP	●	●	●	●	●	○	●	
2012	Ram 3500 Cab Chassis	WCM	●	●	●	●	●	●	●	02A7, 03E6
2012	Ram 3500 Cab Chassis	ABS	●	●	●	●	●	●	●	0002
2012	Ram 3500 Cab Chassis	SAS	●	●	●	●	○	○	○	
2012	Ram 3500 Cab Chassis	TIPMCGW	●	●	●	●	●	●	●	0214, 0476
2012	Ram 3500 Cab Chassis	MSMD	●	●	●	●	●	○	○	0117

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2012	Ram 3500 Cab Chassis	DMFR	●	●	●	●	●	●	●	
2012	Ram 3500 Cab Chassis	DMFL	●	●	●	●	●	●	●	
2012	Ram 3500 Cab Chassis	PCM	●	●	●	●	●	●	●	0126, 0411, 0154, 0155, 0044, 017B, 0049, 03C8, 0179
2012	Ram 3500 Cab Chassis	ORC	●	●	●	●	●	○	●	
2012	Ram 3500 Cab Chassis	TCM	●	●	●	●	○	●	○	01F6
2012	Ram 2500	HSM	●	●	●	●	●	●	●	0412
2012	Ram 2500	ITBM	●	●	●	●	○	○	○	
2012	Ram 2500	PTS	●	●	●	●	●	●	●	02ED, 03B7
2012	Ram 2500	DMFR	●	●	●	●	●	●	●	
2012	Ram 2500	CCN	●	●	●	●	●	●	●	
2012	Ram 2500	MSMD	●	●	●	●	●	○	○	0117
2012	Ram 2500	PCM	●	●	●	●	●	●	●	0126, 0411, 025E, 0260, 0261, 0263, 0154, 0155, 0044, 0265, 0049, 0280, 03C8, 024E, 0179
2012	Ram 2500	DMFL	●	●	●	●	●	●	●	
2012	Ram 2500	VES3	●	●	●	●	●	●	●	
2012	Ram 2500	AMP	●	●	●	●	●	○	●	
2012	Ram 2500	WCM	●	●	●	●	●	●	●	02A7, 03E6, 0232, 0230, 0231, 022F
2012	Ram 2500	FDCM	●	●	●	●	●	○	○	
2012	Ram 2500	RADIO	●	●	●	●	●	●	●	
2012	Ram 2500	DTCM	●	●	●	●	●	●	○	
2012	Ram 2500	HVAC	●	●	●	●	●	●	●	
2012	Ram 2500	ABS	●	●	●	●	●	●	●	0002
2012	Ram 2500	TIPMCGW	●	●	●	●	●	●	●	0476
2012	Ram 2500	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2012	Ram 2500	ORC	●	●	●	●	●	○	●	
2012	Ram 2500	SAS	●	●	●	●	○	○	○	
2012	Ram 2500	HFM	●	●	●	●	●	●	○	
2012	Ram 4500/5500	WCM	●	●	●	●	●	●	●	02A7, 03E6
2012	Ram 4500/5500	DCU	●	○	○	○	○	○	○	
2012	Ram 4500/5500	HSM	●	●	●	●	●	●	●	0412
2012	Ram 4500/5500	DMFL	●	●	●	●	●	●	●	
2012	Ram 4500/5500	DTCM	●	●	●	●	●	●	○	
2012	Ram 4500/5500	HVAC	●	●	●	●	●	●	●	
2012	Ram 4500/5500	TIPMCGW	●	●	●	●	●	●	●	0214, 0476
2012	Ram 4500/5500	ABS	●	●	●	●	●	●	●	0002
2012	Ram 4500/5500	AMP	●	●	●	●	●	○	●	
2012	Ram 4500/5500	RADIO	●	●	●	●	●	●	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2012	Ram 4500/5500	HFM	●	●	●	●	●	●	○	
2012	Ram 4500/5500	TCM	●	●	●	●	○	●	○	01F6
2012	Ram 4500/5500	DMFR	●	●	●	●	●	●	●	
2012	Ram 4500/5500	ORC	●	●	●	●	●	○	●	
2012	Ram 4500/5500	ITBM	●	●	●	●	○	○	○	
2012	Ram 4500/5500	MSMD	●	●	●	●	●	○	○	0117
2012	Ram 4500/5500	SAS	●	●	●	●	○	○	○	
2012	Ram 4500/5500	CCN	●	●	●	●	●	●	●	
2012	Ram 4500/5500	PCM	●	●	●	●	●	●	●	0154, 0155, 0044, 017B, 0049, 03C8, 0179
2012	Ram 1500	ABS	●	●	●	●	●	●	●	0002
2012	Ram 1500	DTCM	●	●	●	●	●	●	●	
2012	Ram 1500	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2012	Ram 1500	HVAC	●	●	●	●	●	●	●	00EC
2012	Ram 1500	PCM	●	●	●	●	●	●	●	0126, 0411
2012	Ram 1500	DMFR	●	●	●	●	●	●	●	
2012	Ram 1500	RADIO	●	●	●	●	●	●	●	
2012	Ram 1500	HFM	●	●	●	●	●	●	○	
2012	Ram 1500	HSM	●	●	●	●	●	●	●	0412
2012	Ram 1500	DMFL	●	●	●	●	●	●	●	
2012	Ram 1500	VES3	●	●	●	●	●	●	●	
2012	Ram 1500	SAS	●	●	●	●	○	○	○	
2012	Ram 1500	ITBM	●	●	●	●	○	○	○	
2012	Ram 1500	WCM	●	●	●	●	●	●	●	02A7, 03E6, 0232, 0230, 0231, 022F
2012	Ram 1500	CCN	●	●	●	●	●	●	●	
2012	Ram 1500	ORC	●	●	●	●	●	○	●	
2012	Ram 1500	TIPMCGW	●	●	●	●	●	●	●	0476
2012	Ram 1500	AMP	●	●	●	●	●	○	●	
2012	Ram 1500	MSMD	●	●	●	●	●	○	○	0117
2012	Ram 1500	PTS	●	●	●	●	●	●	●	02ED, 03B7
2012	Ram (Mexico)	PCM	●	●	●	●	●	●	●	0126, 0411, 025E, 0260, 0261, 0263, 0154, 0155, 0044, 0265, 017B, 0049, 0280, 03C8, 024E
2012	Ram (Mexico)	AMP	●	●	●	●	●	○	●	
2012	Ram (Mexico)	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2012	Ram (Mexico)	HFM	●	●	●	●	●	●	○	
2012	Ram (Mexico)	PTS	●	●	●	●	●	●	●	02ED, 03B7
2012	Ram (Mexico)	CCN	●	●	●	●	●	●	●	
2012	Ram (Mexico)	DTCM	●	●	●	●	●	●	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2012	Ram (Mexico)	RADIO	●	●	●	●	●	●	●	
2012	Ram (Mexico)	MSMD	●	●	●	●	●	○	○	0117
2012	Ram (Mexico)	DMFL	●	●	●	●	●	●	●	
2012	Ram (Mexico)	SAS	●	●	●	●	○	○	○	
2012	Ram (Mexico)	ITBM	●	●	●	●	○	○	○	
2012	Ram (Mexico)	ORC	●	●	●	●	●	○	●	
2012	Ram (Mexico)	HSM	●	●	●	●	●	●	●	0412
2012	Ram (Mexico)	VES3	●	●	●	●	●	●	●	
2012	Ram (Mexico)	TIPMCGW	●	●	●	●	●	●	●	0476
2012	Ram (Mexico)	DMFR	●	●	●	●	●	●	●	
2012	Ram (Mexico)	WCM	●	●	●	●	●	●	●	02A7, 03E6, 0232, 0230, 0231, 022F
2012	Ram (Mexico)	HVAC	●	●	●	●	●	●	●	
2012	Ram (Mexico)	ABS	●	●	●	●	●	●	●	0002
2012	500	RADIO	●	●	●	●	●	○	○	
2012	500	ABS	●	●	●	●	●	●	○	
2012	500	TPM	●	●	●	●	●	●	●	
2012	500	VTM	●	●	●	●	●	○	○	
2012	500	TCM	●	●	●	●	●	●	○	
2012	500	IPC	●	●	●	●	●	●	○	
2012	500	HVAC	●	●	●	●	●	●	○	
2012	500	ORC	●	●	●	●	●	○	●	
2012	500	CTM	●	●	●	●	○	●	○	
2012	500	BCM	●	●	●	●	●	●	●	
2012	500	PCM	●	●	●	●	●	●	●	
2012	500	PTS	●	●	●	●	●	○	○	
2012	500	EPS	●	●	●	●	●	○	○	
2012	Wrangler (Export)	SAS	●	●	●	●	○	○	○	
2012	Wrangler (Export)	CCN	●	●	●	●	●	●	○	008C, 0091, 0094, 0096
2012	Wrangler (Export)	WCM	●	●	●	●	●	○	●	
2012	Wrangler (Export)	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2012	Wrangler (Export)	TIPMCGW	●	●	●	●	●	●	●	003F, 003A, 021F
2012	Wrangler (Export)	RADIO	●	●	●	●	●	●	●	
2012	Wrangler (Export)	PCM	●	●	●	●	●	●	●	02BA, 031D
2012	Wrangler (Export)	ORC	●	●	●	●	●	○	●	0122
2012	Wrangler (Export)	TCM	●	●	●	●	●	○	○	
2012	Journey	ITM	●	●	●	●	●	●	●	
2012	Journey	ICS	●	●	●	●	●	●	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2012	Journey	DDM	●	●	●	●	●	●	●	
2012	Journey	PDM	●	●	●	●	●	●	●	
2012	Journey	AMP	●	●	●	●	●	○	○	
2012	Journey	HFM	●	●	●	●	●	○	○	
2012	Journey	ABS	●	●	●	●	●	●	●	
2012	Journey	IPC	●	●	●	●	●	●	○	
2012	Journey	TGW	●	●	●	●	●	○	○	
2012	Journey	PCM	●	●	●	●	●	●	●	0432, 042D, 031D, 0126, 0411
2012	Journey	ORC	●	●	●	●	●	○	●	
2012	Journey	BCM	●	●	●	●	●	●	●	
2012	Journey	PTS	●	●	●	●	●	●	●	02ED, 03B7
2012	Journey	HVAC	●	●	●	●	●	●	●	
2012	Journey	EPPM	●	●	●	●	●	○	●	
2012	Journey	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2012	Journey	DTCM	●	●	●	●	●	●	●	
2012	Journey	RFH	●	●	●	●	●	●	●	0442
2012	Journey	SCCM	●	●	●	●	●	○	○	
2012	Journey	HSM	●	●	●	●	●	●	●	
2012	Journey	TCM	●	●	●	●	●	●	●	
2012	Journey	VES3	●	●	●	●	●	●	○	
2012	Freemont	ORC	●	●	●	●	●	○	●	
2012	Freemont	SCCM	●	●	●	●	●	○	○	
2012	Freemont	VES3	●	●	●	●	●	●	○	
2012	Freemont	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2012	Freemont	RFH	●	●	●	●	●	●	●	0442
2012	Freemont	ABS	●	●	●	●	●	●	●	
2012	Freemont	HFM	●	●	●	●	●	○	○	
2012	Freemont	IPC	●	●	●	●	●	●	○	
2012	Freemont	AMP	●	●	●	●	●	○	○	
2012	Freemont	ITM	●	●	●	●	●	●	●	
2012	Freemont	TGW	●	●	●	●	●	○	○	
2012	Freemont	EPPM	●	●	●	●	●	○	●	
2012	Freemont	HSM	●	●	●	●	●	●	●	
2012	Freemont	TCM	●	●	●	●	●	●	●	
2012	Freemont	HVAC	●	●	●	●	●	●	●	
2012	Freemont	PTS	●	●	●	●	●	●	●	02ED, 03B7
2012	Freemont	DTCM	●	●	●	●	●	●	●	



[illegible]

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2012	Nitro	ESM	●	●	●	●	●	●	○	
2012	Nitro	PCM	●	●	●	●	●	●	●	0126, 0411
2012	Nitro	HVAC	●	●	●	●	●	●	●	
2012	Nitro	DMFR	●	●	●	●	●	●	●	
2012	Nitro	RADIO	●	●	●	●	●	●	●	
2012	Nitro	ORC	●	●	●	●	●	○	●	
2012	Nitro	ITM	●	●	●	●	●	●	●	
2012	Nitro	OCM	●	●	●	●	●	○	○	011E
2012	Nitro	DMFL	●	●	●	●	●	●	●	
2012	Nitro	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2012	Nitro	TCM	●	●	●	●	●	○	○	
2012	Nitro	WCM	●	●	●	●	●	○	●	
2012	Nitro	AMP	●	●	●	●	●	○	●	
2012	Nitro	SAS	●	●	●	●	○	○	○	
2012	Nitro	CCN	●	●	●	●	●	●	○	008C, 0091, 0094, 0096
2012	Liberty	HFM	●	●	●	●	●	●	○	
2012	Liberty	DMFL	●	●	●	●	●	●	●	
2012	Liberty	ITM	●	●	●	●	●	●	●	
2012	Liberty	AMP	●	●	●	●	●	○	●	
2012	Liberty	MSMD	●	●	●	●	●	●	●	0117, 0452
2012	Liberty	SUNR	●	●	●	●	●	○	○	
2012	Liberty	TCM	●	●	●	●	●	○	○	
2012	Liberty	HVAC	●	●	●	●	●	●	●	
2012	Liberty	SAS	●	●	●	●	○	○	○	
2012	Liberty	TIPMCGW	●	●	●	●	●	●	●	003F, 003A, 021F
2012	Liberty	OCM	●	●	●	●	●	○	○	011E
2012	Liberty	DMFR	●	●	●	●	●	●	●	
2012	Liberty	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2012	Liberty	ORC	●	●	●	●	●	○	●	
2012	Liberty	RADIO	●	●	●	●	●	●	●	
2012	Liberty	CCN	●	●	●	●	●	●	●	
2012	Liberty	ESM	●	●	●	●	●	●	○	
2012	Liberty	FDCM	●	●	●	●	●	●	○	
2012	Liberty	PCM	●	●	●	●	●	●	●	02BA, 031D, 0126, 0411
2012	Liberty	PTS	●	●	●	●	●	●	●	02ED, 03B7
2012	Liberty	WCM	●	●	●	●	●	○	●	
2012	Challenger	EPS	●	●	●	●	●	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2012	Challenger	EOM	●	●	●	●	●	○	●	
2012	Challenger	HVAC	●	●	●	●	●	●	●	
2012	Challenger	CCN	●	●	●	●	●	●	●	
2012	Challenger	ADCM	●	●	●	●	●	○	○	
2012	Challenger	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2012	Challenger	PCM	●	●	●	●	●	●	●	0126, 0411
2012	Challenger	SUNR	●	●	●	●	●	●	○	
2012	Challenger	TCM	●	●	●	●	●	○	○	
2012	Challenger	RADIO	●	●	●	●	●	●	●	
2012	Challenger	ABS	●	●	●	●	●	●	●	
2012	Challenger	DDM	●	●	●	●	●	●	○	
2012	Challenger	ESM	●	●	●	●	●	●	○	
2012	Challenger	PEM	●	●	●	●	●	○	●	0442
2012	Challenger	SAS	●	●	●	●	●	●	○	
2012	Challenger	AMP	●	●	●	●	●	○	●	
2012	Challenger	HFM	●	●	●	●	●	●	○	
2012	Challenger	ORC	●	●	●	●	●	○	●	
2012	Challenger	TIPMCGW	●	●	●	●	●	●	●	002E
2012	Challenger	PDM	●	●	●	●	●	●	○	
2012	Challenger	HSM	●	●	●	●	●	●	●	
2012	Challenger	WCM	●	●	●	●	●	●	●	02A7, 03E6, 0232, 0230, 0231, 022F
2012	Charger (Post-2011)	BCM	●	●	●	●	●	●	●	
2012	Charger (Post-2011)	MSM	●	●	●	●	●	●	●	0452
2012	Charger (Post-2011)	ABS	●	●	●	●	●	●	●	
2012	Charger (Post-2011)	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2012	Charger (Post-2011)	HVAC	●	●	●	●	●	●	●	
2012	Charger (Post-2011)	AMP	●	●	●	●	●	○	○	
2012	Charger (Post-2011)	ACC	●	●	●	●	●	○	●	
2012	Charger (Post-2011)	ICS	●	●	●	●	●	●	○	
2012	Charger (Post-2011)	BSM	●	●	●	●	●	○	○	
2012	Charger (Post-2011)	IPC	●	●	●	●	●	●	○	
2012	Charger (Post-2011)	HFM	●	●	●	●	●	○	○	
2012	Charger (Post-2011)	PTS	●	●	●	●	●	●	●	02ED, 03B7
2012	Charger (Post-2011)	TGW	●	●	●	●	●	○	○	
2012	Charger (Post-2011)	DTCM	●	●	●	●	●	●	●	
2012	Charger (Post-2011)	PDM	●	●	●	●	●	●	●	
2012	Charger (Post-2011)	SCCM	●	●	●	●	●	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2012	Charger (Post-2011)	VSIM	●	●	●	●	●	●	●	
2012	Charger (Post-2011)	DDM	●	●	●	●	●	●	●	
2012	Charger (Post-2011)	ADCM	●	●	●	●	●	○	○	
2012	Charger (Post-2011)	ORC	●	●	●	●	●	○	●	
2012	Charger (Post-2011)	TCM	●	●	●	●	●	○	●	
2012	Charger (Post-2011)	PCM	●	●	●	●	●	●	●	0126, 0411
2012	Charger (Post-2011)	ESM	●	●	●	●	●	●	○	
2012	Charger (Post-2011)	HSM	●	●	●	●	●	●	●	
2012	Charger (Post-2011)	EPS	●	●	●	●	●	○	○	
2012	Charger (Post-2011)	RFH	●	●	●	●	●	●	●	0442
2012	Charger (Post-2011)	ITM	●	●	●	●	●	●	●	
2012	300 / Magnum / Charger (Pre-2011)	DTCM	●	●	●	●	●	●	●	
2012	300 / Magnum / Charger (Pre-2011)	HSM	●	●	●	●	●	●	●	
2012	300 / Magnum / Charger (Pre-2011)	PDM	●	●	●	●	●	●	●	
2012	300 / Magnum / Charger (Pre-2011)	BCM	●	●	●	●	●	●	●	
2012	300 / Magnum / Charger (Pre-2011)	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2012	300 / Magnum / Charger (Pre-2011)	SCCM	●	●	●	●	●	○	○	
2012	300 / Magnum / Charger (Pre-2011)	TCM	●	●	●	●	●	○	●	
2012	300 / Magnum / Charger (Pre-2011)	HFM	●	●	●	●	●	○	○	
2012	300 / Magnum / Charger (Pre-2011)	MSM	●	●	●	●	●	●	●	0452
2012	300 / Magnum / Charger (Pre-2011)	HVAC	●	●	●	●	●	●	●	
2012	300 / Magnum / Charger (Pre-2011)	ORC	●	●	●	●	●	○	●	
2012	300 / Magnum / Charger (Pre-2011)	RFH	●	●	●	●	●	●	●	0442
2012	300 / Magnum / Charger (Pre-2011)	BSM	●	●	●	●	●	○	○	
2012	300 / Magnum / Charger (Pre-2011)	ESM	●	●	●	●	●	●	○	
2012	300 / Magnum / Charger (Pre-2011)	ITM	●	●	●	●	●	●	●	
2012	300 / Magnum / Charger (Pre-2011)	PCM	●	●	●	●	●	●	●	0126, 0411, 0432, 042D, 031D
2012	300 / Magnum / Charger (Pre-2011)	PTS	●	●	●	●	●	●	●	02ED, 03B7
2012	300 / Magnum / Charger (Pre-2011)	EPS	●	●	●	●	●	○	○	
2012	300 / Magnum / Charger (Pre-2011)	ABS	●	●	●	●	●	●	●	
2012	300 / Magnum / Charger (Pre-2011)	DDM	●	●	●	●	●	●	●	
2012	300 / Magnum / Charger (Pre-2011)	AMP	●	●	●	●	●	○	○	
2012	300 / Magnum / Charger (Pre-2011)	TGW	●	●	●	●	●	○	○	
2012	300 / Magnum / Charger (Pre-2011)	ICS	●	●	●	●	●	●	○	
2012	300 / Magnum / Charger (Pre-2011)	AFLS	●	●	●	●	●	●	○	
2012	300 / Magnum / Charger (Pre-2011)	IPC	●	●	●	●	●	●	○	
2012	300 / Magnum / Charger (Pre-2011)	ACC	●	●	●	●	●	○	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2012	300 / Magnum / Charger (Pre-2011)	ADCM	●	●	●	●	●	○	○	
2012	Compass	TCM	●	●	●	●	●	●	●	
2012	Compass	ITM	●	●	●	●	●	●	●	
2012	Compass	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2012	Compass	AWD	●	●	●	●	●	●	●	
2012	Compass	TIPMCGW	●	●	●	●	●	●	●	003F, 020E, 0215, 028F, 0211
2012	Compass	HVAC	●	●	●	●	●	●	●	
2012	Compass	SAS	●	●	●	●	○	○	○	
2012	Compass	RADIO	●	●	●	●	●	●	●	
2012	Compass	WCM	●	●	●	●	●	○	●	
2012	Compass	HFM	●	●	●	●	●	●	○	
2012	Compass	CCN	●	●	●	●	●	●	●	
2012	Compass	AMP	●	●	●	●	●	○	●	0069, 006D, 0079, 0068, 0303
2012	Compass	ORC	●	●	●	●	●	○	●	
2012	Compass	PCM	●	●	●	●	●	●	●	0126, 0411, 03E1, 03DA, 0049, 03D8
2012	Dakota	PCM	●	●	●	●	●	●	●	0126, 0411
2012	Dakota	AMP	●	●	●	●	●	○	●	
2012	Dakota	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2012	Dakota	HVAC	●	●	●	●	●	●	●	00EA, 00E8, 00E9
2012	Dakota	HFM	●	●	●	●	●	●	○	
2012	Dakota	CCN	●	●	●	●	●	●	●	008F, 008E, 008D, 0090
2012	Dakota	FCMCGW	●	●	●	●	●	●	●	02F1, 02F0, 02F3, 02EF, 0039, 003C, 003D, 02A6, 02A5, 02A4, 0032, 003E, 0036, 00D5, 00D8, 0037, 0035, 0034, 00DB, 00D6, 00D9, 003A, 0293, 0033, 00C6, 0040, 00DA, 0272, 0273
2012	Dakota	RADIO	●	●	●	●	●	●	●	
2012	Dakota	ORC	●	●	●	●	○	●	○	
2012	Dakota	WCM	●	●	●	●	●	○	●	01D2, 0228, 0226, 0225, 0232, 0231, 022F, 01DE, 0233, 023E, 0271
2012	Dakota	EOM	●	●	●	●	●	○	●	
2012	Dart	OCM	●	●	●	●	●	○	●	
2012	Dart	TCM	●	●	●	●	●	●	●	
2012	Dart	PAM	●	●	●	●	●	○	○	
2012	Dart	PCM	●	●	●	●	●	●	●	0126, 0411
2012	Dart	ORC	●	●	●	●	●	●	●	
2012	Dart	EDM	●	●	●	○	○	●	○	
2012	Dart	SCCM	●	●	●	●	●	○	○	
2012	Dart	CSWM	●	●	●	●	●	●	●	
2012	Dart	ABS	●	●	●	●	●	○	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2012	Dart	CTM	●	●	●	●	●	○	○	
2012	Dart	AMP	●	●	●	●	●	○	○	
2012	Dart	ESM	●	●	●	●	○	○	●	
2012	Dart	RADIO	●	●	●	●	●	●	●	
2012	Dart	ICS	●	●	●	●	●	●	○	
2012	Dart	LBSS	●	●	●	●	●	○	●	
2012	Dart	BCM	●	●	●	●	●	●	●	
2012	Dart	EPS	●	●	●	●	●	○	○	
2012	Dart	RBSS	●	●	●	●	●	○	●	
2012	Dart	RFH	●	●	●	●	●	●	●	
2012	Dart	IPC	●	●	●	●	●	●	○	
2012	Dart	HVAC	●	●	●	●	●	●	●	
2012	Caliber	WCM	●	●	●	●	●	○	●	
2012	Caliber	HVAC	●	●	●	●	●	●	●	
2012	Caliber	ORC	●	●	●	●	●	○	●	
2012	Caliber	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2012	Caliber	RADIO	●	●	●	●	●	●	●	
2012	Caliber	AMP	●	●	●	●	●	○	●	0069, 006D, 0079, 0068, 0303
2012	Caliber	HFM	●	●	●	●	●	●	○	
2012	Caliber	CCN	●	●	●	●	●	●	○	008C, 008F, 008E, 0094, 0092, 0096
2012	Caliber	SAS	●	●	●	●	○	○	○	
2012	Caliber	ITM	●	●	●	●	●	●	●	
2012	Caliber	PCM	●	●	●	●	●	●	●	0126, 0411, 03E1, 03DA, 0049, 03D8
2012	Caliber	TCM	●	●	●	●	●	●	●	
2012	Caliber	TIPMCGW	●	●	●	●	●	●	●	003F, 020E, 0215, 028F, 0211
2012	Caliber	AWD	●	●	●	●	●	●	●	
2012	Mini-Van	MHSM	●	●	●	●	○	●	○	
2012	Mini-Van	PSD	●	●	●	●	○	●	○	
2012	Mini-Van	SDAR	●	●	●	●	●	●	○	
2012	Mini-Van	BCM	●	●	●	●	○	●	○	
2012	Mini-Van	HFM	●	●	●	●	○	●	○	
2012	Mini-Van	DSD	●	●	●	●	○	●	○	
2012	Mini-Van	ORC	●	●	●	●	○	○	○	
2012	Mini-Van	MIC/CCN	●	●	●	●	○	●	○	
2012	Mini-Van	MTC	●	●	●	●	○	●	○	
2012	Mini-Van	ABS	●	●	●	●	●	○	○	
2012	Mini-Van	EOM	●	●	●	○	○	○	○	



YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2012	Routan	DVD	●	●	●	●	●	○	○	
2012	Town & Country / Caravan	DMRL	●	●	●	●	●	●	●	
2012	Town & Country / Caravan	PSDMR	●	●	●	●	●	○	○	
2012	Town & Country / Caravan	MSMD	●	●	●	●	●	●	●	0452
2012	Town & Country / Caravan	CCN	●	●	●	●	●	●	●	
2012	Town & Country / Caravan	PLGM	●	●	●	●	●	●	●	
2012	Town & Country / Caravan	DMFR	●	●	●	●	●	●	●	
2012	Town & Country / Caravan	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2012	Town & Country / Caravan	PTS	●	●	●	●	●	●	●	02ED, 03B7
2012	Town & Country / Caravan	HFM	●	●	●	●	●	●	○	
2012	Town & Country / Caravan	SUNR	●	●	●	●	●	●	○	
2012	Town & Country / Caravan	HVAC	●	●	●	●	●	●	●	
2012	Town & Country / Caravan	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2012	Town & Country / Caravan	PCM	●	●	●	●	●	●	●	0126, 0411, 02BA, 031D
2012	Town & Country / Caravan	TIPMCGW	●	●	●	●	●	●	●	003F, 003A, 021F
2012	Town & Country / Caravan	ORC	●	●	●	●	●	○	●	
2012	Town & Country / Caravan	HSM	●	●	●	●	●	●	●	0412
2012	Town & Country / Caravan	EPPM	●	●	●	●	●	○	●	
2012	Town & Country / Caravan	HIDT	●	●	●	●	●	●	○	
2012	Town & Country / Caravan	SAS	●	●	●	●	○	○	○	
2012	Town & Country / Caravan	AMP	●	●	●	●	●	○	●	
2012	Town & Country / Caravan	DMFL	●	●	●	●	●	●	●	
2012	Town & Country / Caravan	ITM	●	●	●	●	●	●	●	
2012	Town & Country / Caravan	AHBM	●	●	●	●	●	○	○	
2012	Town & Country / Caravan	PEM	●	●	●	●	●	○	●	0442
2012	Town & Country / Caravan	PSDML	●	●	●	●	●	○	○	
2012	Town & Country / Caravan	BSM	●	●	●	●	●	○	○	
2012	Town & Country / Caravan	DMRR	●	●	●	●	●	●	●	
2012	Town & Country / Caravan	DVD	●	●	●	●	●	○	○	
2012	Town & Country / Caravan	RADIO	●	●	●	●	●	●	●	
2012	Town & Country / Caravan	WCM	●	●	●	●	●	●	●	02A7, 03E6, 0232, 0230, 0231, 022F
2012	Town & Country / Caravan	FSM	●	●	●	●	●	●	○	
2012	Town & Country / Caravan	VES2	●	●	●	●	●	●	●	
2012	Town & Country / Caravan	TCM	●	●	●	●	●	●	●	
2012	Town & Country / Caravan	VES3	●	●	●	●	●	●	●	
2012	Durango (Post-2011)	DMFR	●	●	●	●	●	●	●	
2012	Durango (Post-2011)	RADIO	●	●	●	●	●	●	●	



YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2012	Durango (Post-2011)	WCM	●	●	●	●	●	●	●	02A7, 03E6, 0232, 0230, 0231, 022F
2012	Durango (Post-2011)	PLGM	●	●	●	●	○	●	●	
2012	Durango (Post-2011)	AHBM	●	●	●	●	○	●	○	
2012	Durango (Post-2011)	AMP	●	●	●	●	●	○	●	
2012	Durango (Post-2011)	TIPMCGW	●	●	●	●	●	●	●	0476
2012	Durango (Post-2011)	PTS	●	●	●	●	●	●	●	02ED, 03B7
2012	Durango (Post-2011)	ESM	●	●	●	●	●	●	○	
2012	Durango (Post-2011)	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2012	Durango (Post-2011)	ITM	●	●	●	●	●	●	●	
2012	Durango (Post-2011)	HSM	●	●	●	●	●	●	●	0412
2012	Durango (Post-2011)	HVAC	●	●	●	●	●	●	●	
2012	Durango (Post-2011)	DTCM	●	●	●	●	●	●	●	
2012	Durango (Post-2011)	DMFL	●	●	●	●	●	●	●	
2012	Durango (Post-2011)	EPS	●	●	●	●	●	○	○	
2012	Durango (Post-2011)	MSMD	●	●	●	●	●	●	●	0452
2012	Durango (Post-2011)	TCM	●	●	●	●	●	○	○	
2012	Durango (Post-2011)	AHLM	●	●	●	●	●	●	○	
2012	Durango (Post-2011)	HFM	●	●	●	●	●	●	○	
2012	Durango (Post-2011)	BSM	●	●	●	●	●	○	○	
2012	Durango (Post-2011)	ACC	●	●	●	●	●	○	○	
2012	Durango (Post-2011)	PCM	●	●	●	●	●	●	●	0126, 0411
2012	Durango (Post-2011)	CCN	●	●	●	●	●	●	●	
2012	Durango (Post-2011)	ORC	●	●	●	●	●	○	●	0122
2012	Durango (Post-2011)	ABS	●	●	●	●	●	●	●	
2012	Durango (Post-2011)	SAS	●	●	●	●	●	●	○	
2012	Durango (Post-2011)	VES3	●	●	●	●	●	●	●	
2012	Durango (Post-2011)	PEM	●	●	●	●	●	○	●	0442
2012	Grand Cherokee	ADCM	●	●	●	●	●	○	○	
2012	Grand Cherokee	MSMD	●	●	●	●	●	●	●	0452
2012	Grand Cherokee	RADIO	●	●	●	●	●	●	●	
2012	Grand Cherokee	ORC	●	●	●	●	●	○	●	0122
2012	Grand Cherokee	ESM	●	●	●	●	●	●	○	
2012	Grand Cherokee	ELSD	●	●	●	●	●	●	○	
2012	Grand Cherokee	CCN	●	●	●	●	●	●	●	
2012	Grand Cherokee	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2012	Grand Cherokee	BSM	●	●	●	●	●	○	○	
2012	Grand Cherokee	PCM	●	●	●	●	●	●	●	0126, 0411, 0432, 042D, 031D

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2012	Grand Cherokee	HFM	●	●	●	●	●	●	○	
2012	Grand Cherokee	WCM	●	●	●	●	●	●	●	02A7, 03E6, 0232, 0230, 0231, 022F
2012	Grand Cherokee	ACC	●	●	●	●	●	○	○	
2012	Grand Cherokee	TIPMGW	●	●	●	●	●	●	●	0476
2012	Grand Cherokee	PEM	●	●	●	●	●	○	●	0442
2012	Grand Cherokee	VES3	●	●	●	●	●	●	●	
2012	Grand Cherokee	ABS	●	●	●	●	●	●	●	
2012	Grand Cherokee	DTCM	●	●	●	●	●	●	●	
2012	Grand Cherokee	AHBM	●	●	●	●	○	●	○	
2012	Grand Cherokee	SAS	●	●	●	●	●	●	○	
2012	Grand Cherokee	AHLM	●	●	●	●	●	●	○	
2012	Grand Cherokee	TCM	●	●	●	●	●	○	○	
2012	Grand Cherokee	HVAC	●	●	●	●	●	●	●	
2012	Grand Cherokee	PLGM	●	●	●	●	○	●	●	
2012	Grand Cherokee	EPS	●	●	●	●	●	○	○	
2012	Grand Cherokee	PTS	●	●	●	●	●	●	●	02ED, 03B7
2012	Grand Cherokee	HSM	●	●	●	●	●	●	●	0412
2012	Grand Cherokee	ITM	●	●	●	●	●	●	●	
2012	Grand Cherokee	ASCM	●	●	●	●	●	○	○	
2012	Grand Cherokee	DMFL	●	●	●	●	●	●	●	
2012	Grand Cherokee	AMP	●	●	●	●	●	○	●	
2012	Grand Cherokee	DMFR	●	●	●	●	●	●	●	
2013	Forza	ORC	●	●	●	●	○	●	○	
2013	Forza	IPC	●	●	●	●	○	●	○	
2013	Ram 3500 Pickup	PCM	●	●	●	●	●	●	●	0126, 0411
2013	Ram 3500 Pickup	DCU	●	●	●	○	○	○	○	
2013	Ram 3500 Pickup	ORC	●	●	●	●	●	●	●	
2013	Ram 3500 Pickup	ITBM	●	●	●	●	●	○	○	
2013	Ram 3500 Pickup	ABS	●	●	●	●	●	●	●	
2013	Ram 3500 Pickup	BCM	●	●	●	●	●	●	●	
2013	Ram 3500 Pickup	HSM	●	●	●	●	●	●	●	
2013	Ram 3500 Pickup	RADIO	●	●	●	●	●	●	●	
2013	Ram 3500 Pickup	EDM	●	●	●	●	●	●	○	
2013	Ram 3500 Pickup	DTCM	●	●	●	●	●	●	●	
2013	Ram 3500 Pickup	VSIM	●	●	●	●	●	●	○	
2013	Ram 3500 Pickup	TCM	●	●	●	●	●	●	●	
2013	Ram 3500 Pickup	RFH	●	●	●	●	●	●	●	0442

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2013	Ram 3500 Pickup	HVAC	●	●	●	●	●	●	●	
2013	Ram 3500 Pickup	PTS	●	●	●	●	●	●	●	02ED, 03B7
2013	Ram 3500 Pickup	VGT	●	●	●	○	○	○	○	
2013	Ram 3500 Pickup	ASCM	●	●	●	●	●	○	●	
2013	Ram 3500 Pickup	SCCM	●	●	●	●	●	○	○	
2013	Ram 3500 Pickup	PDM	●	●	●	●	●	●	●	
2013	Ram 3500 Pickup	IPC	●	●	●	●	●	●	○	
2013	Ram 3500 Pickup	DDM	●	●	●	●	●	●	●	
2013	Ram 3500 Pickup	AMP	●	●	●	●	●	○	○	
2013	Ram 3500 Pickup	ICS	●	●	●	●	●	●	●	
2013	Ram 3500 Pickup	MSM	●	●	●	●	●	●	●	0452
2013	Ram 3500 Cab Chassis	DCU	●	●	●	○	○	○	○	
2013	Ram 3500 Cab Chassis	TCM	●	●	●	●	●	●	●	
2013	Ram 3500 Cab Chassis	PDM	●	●	●	●	●	●	●	
2013	Ram 3500 Cab Chassis	VGT	●	●	●	○	○	○	○	
2013	Ram 3500 Cab Chassis	PTS	●	●	●	●	●	●	●	02ED, 03B7
2013	Ram 3500 Cab Chassis	MSM	●	●	●	●	●	●	●	0452
2013	Ram 3500 Cab Chassis	PCM	●	●	●	●	●	●	●	03C8, 0126, 0411
2013	Ram 3500 Cab Chassis	ABS	●	●	●	●	●	●	●	
2013	Ram 3500 Cab Chassis	VSIM	●	●	●	●	●	●	○	
2013	Ram 3500 Cab Chassis	BCM	●	●	●	●	●	●	●	
2013	Ram 3500 Cab Chassis	ITBM	●	●	●	●	●	○	○	
2013	Ram 3500 Cab Chassis	RFH	●	●	●	●	●	●	●	0442
2013	Ram 3500 Cab Chassis	DDM	●	●	●	●	●	●	●	
2013	Ram 3500 Cab Chassis	ORC	●	●	●	●	●	●	●	
2013	Ram 3500 Cab Chassis	EDM	●	●	●	●	●	●	○	
2013	Ram 3500 Cab Chassis	SCCM	●	●	●	●	●	○	○	
2013	Ram 3500 Cab Chassis	DTCM	●	●	●	●	●	●	●	
2013	Ram 3500 Cab Chassis	ICS	●	●	●	●	●	●	●	
2013	Ram 3500 Cab Chassis	HVAC	●	●	●	●	●	●	●	
2013	Ram 3500 Cab Chassis	RADIO	●	●	●	●	●	●	●	
2013	Ram 3500 Cab Chassis	IPC	●	●	●	●	●	●	○	
2013	Ram 3500 Cab Chassis	HSM	●	●	●	●	●	●	●	
2013	Ram 3500 Cab Chassis	AMP	●	●	●	●	●	○	○	
2013	Ram 2500	MSM	●	●	●	●	●	●	●	0452
2013	Ram 2500	RADIO	●	●	●	●	●	●	●	
2013	Ram 2500	AMP	●	●	●	●	●	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2013	Ram 2500	ORC	●	●	●	●	●	●	●	
2013	Ram 2500	FDCM	●	●	●	●	●	○	○	
2013	Ram 2500	BCM	●	●	●	●	●	●	●	
2013	Ram 2500	DCU	●	●	●	○	○	○	○	
2013	Ram 2500	RFH	●	●	●	●	●	●	●	0442
2013	Ram 2500	ITBM	●	●	●	●	●	○	○	
2013	Ram 2500	PCM	●	●	●	●	●	●	●	0126, 0411
2013	Ram 2500	TCM	●	●	●	●	●	●	●	
2013	Ram 2500	ICS	●	●	●	●	●	●	●	
2013	Ram 2500	VSIM	●	●	●	●	●	●	○	
2013	Ram 2500	IPC	●	●	●	●	●	●	○	
2013	Ram 2500	ASCM	●	●	●	●	●	○	●	
2013	Ram 2500	HSM	●	●	●	●	●	●	●	
2013	Ram 2500	PDM	●	●	●	●	●	●	●	
2013	Ram 2500	EDM	●	●	●	●	●	●	○	
2013	Ram 2500	HVAC	●	●	●	●	●	●	●	
2013	Ram 2500	SCCM	●	●	●	●	●	○	○	
2013	Ram 2500	VGT	●	●	●	○	○	○	○	
2013	Ram 2500	PTS	●	●	●	●	●	●	●	02ED, 03B7
2013	Ram 2500	ABS	●	●	●	●	●	●	●	
2013	Ram 2500	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2013	Ram 2500	DDM	●	●	●	●	●	●	●	
2013	Ram 2500	DTCM	●	●	●	●	●	●	●	
2013	Ram 4500/5500	DCU	●	●	●	○	○	○	○	
2013	Ram 4500/5500	HVAC	●	●	●	●	●	●	●	
2013	Ram 4500/5500	IPC	●	●	●	●	●	●	○	
2013	Ram 4500/5500	SCCM	●	●	●	●	●	○	○	
2013	Ram 4500/5500	RADIO	●	●	●	●	●	●	●	
2013	Ram 4500/5500	ORC	●	●	●	●	●	●	●	
2013	Ram 4500/5500	MSM	●	●	●	●	●	●	●	0452
2013	Ram 4500/5500	PCM	●	●	●	●	●	●	●	03C8, 0126, 0411
2013	Ram 4500/5500	AMP	●	●	●	●	●	○	○	
2013	Ram 4500/5500	RFH	●	●	●	●	●	●	●	0442
2013	Ram 4500/5500	DTCM	●	●	●	●	●	●	●	
2013	Ram 4500/5500	EDM	●	●	●	●	●	●	○	
2013	Ram 4500/5500	VSIM	●	●	●	●	●	●	○	
2013	Ram 4500/5500	PDM	●	●	●	●	●	●	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2013	Ram 4500/5500	PTS	●	●	●	●	●	●	●	02ED, 03B7
2013	Ram 4500/5500	ABS	●	●	●	●	●	●	●	
2013	Ram 4500/5500	ITBM	●	●	●	●	●	○	○	
2013	Ram 4500/5500	BCM	●	●	●	●	●	●	●	
2013	Ram 4500/5500	ICS	●	●	●	●	●	●	●	
2013	Ram 4500/5500	DDM	●	●	●	●	●	●	●	
2013	Ram 4500/5500	VGT	●	●	●	○	○	○	○	
2013	Ram 4500/5500	HSM	●	●	●	●	●	●	●	
2013	Ram 4500/5500	TCM	●	●	●	●	●	●	●	
2013	Ram 1500	TCM	●	●	●	●	●	○	●	
2013	Ram 1500	ASCM	●	●	●	●	●	○	●	
2013	Ram 1500	DTCM	●	●	●	●	●	●	●	
2013	Ram 1500	EDM	●	●	●	●	●	●	○	
2013	Ram 1500	PTS	●	●	●	●	●	●	●	02ED, 03B7
2013	Ram 1500	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2013	Ram 1500	ABS	●	●	●	●	●	●	●	
2013	Ram 1500	HSM	●	●	●	●	●	●	●	
2013	Ram 1500	AMP	●	●	●	●	●	○	○	
2013	Ram 1500	HVAC	●	●	●	●	●	●	●	
2013	Ram 1500	ICS	●	●	●	●	●	●	●	
2013	Ram 1500	PCM	●	●	●	●	●	●	●	0126, 0411
2013	Ram 1500	ESM	●	●	●	●	●	○	○	
2013	Ram 1500	DDM	●	●	●	●	●	●	●	
2013	Ram 1500	SCCM	●	●	●	●	●	○	○	
2013	Ram 1500	MSM	●	●	●	●	●	●	●	0452
2013	Ram 1500	RADIO	●	●	●	●	●	●	●	
2013	Ram 1500	RFH	●	●	●	●	●	●	●	0442
2013	Ram 1500	BCM	●	●	●	●	●	●	●	
2013	Ram 1500	PDM	●	●	●	●	●	●	●	
2013	Ram 1500	ORC	●	●	●	●	●	●	●	
2013	Ram 1500	ITBM	●	●	●	●	●	○	○	
2013	Ram 1500	EPS	●	●	●	●	●	○	○	
2013	Ram 1500	IPC	●	●	●	●	●	●	○	
2013	Ram (Mexico)	EDM	●	●	●	●	●	●	○	
2013	Ram (Mexico)	ASCM	●	●	●	●	●	○	●	
2013	Ram (Mexico)	ITBM	●	●	●	●	●	○	○	
2013	Ram (Mexico)	RADIO	●	●	●	●	●	●	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2013	Ram (Mexico)	DDM	●	●	●	●	●	●	●	
2013	Ram (Mexico)	DTCM	●	●	●	●	●	●	●	
2013	Ram (Mexico)	BCM	●	●	●	●	●	●	●	
2013	Ram (Mexico)	TCM	●	●	●	●	●	●	●	
2013	Ram (Mexico)	MSM	●	●	●	●	●	●	●	0452
2013	Ram (Mexico)	EPS	●	●	●	●	●	○	○	
2013	Ram (Mexico)	SCCM	●	●	●	●	●	○	○	
2013	Ram (Mexico)	RFH	●	●	●	●	●	●	●	0442
2013	Ram (Mexico)	IPC	●	●	●	●	●	●	○	
2013	Ram (Mexico)	AMP	●	●	●	●	●	○	○	
2013	Ram (Mexico)	PCM	●	●	●	●	●	●	●	03C8, 0126, 0411
2013	Ram (Mexico)	ABS	●	●	●	●	●	●	●	
2013	Ram (Mexico)	VSIM	●	●	●	●	●	●	○	
2013	Ram (Mexico)	ESM	●	●	●	●	●	○	○	
2013	Ram (Mexico)	HVAC	●	●	●	●	●	●	●	
2013	Ram (Mexico)	DCU	●	●	●	○	○	○	○	
2013	Ram (Mexico)	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2013	Ram (Mexico)	PTS	●	●	●	●	●	●	●	02ED, 03B7
2013	Ram (Mexico)	VGT	●	●	●	○	○	○	○	
2013	Ram (Mexico)	PDM	●	●	●	●	●	●	●	
2013	Ram (Mexico)	HSM	●	●	●	●	●	●	●	
2013	Ram (Mexico)	ORC	●	●	●	●	●	●	●	
2013	Ram (Mexico)	ICS	●	●	●	●	●	●	●	
2013	500	EAC	●	●	●	●	●	○	○	
2013	500	RBC	●	●	●	●	●	○	○	
2013	500	BPCM	●	●	●	●	●	●	○	
2013	500	PTS	●	●	●	●	●	○	○	
2013	500	VTM	●	●	●	●	●	○	○	
2013	500	EPS	●	●	●	●	●	○	○	
2013	500	ABS	●	●	●	●	●	●	○	
2013	500	TPM	●	●	●	●	●	●	●	
2013	500	ESM	●	●	●	○	●	○	○	
2013	500	EVCU	●	●	●	●	●	●	○	
2013	500	HVAC	●	●	●	●	●	●	○	
2013	500	OBCM	●	●	●	●	●	○	○	
2013	500	IPC	●	●	●	●	●	●	○	
2013	500	CTM	●	●	●	●	○	●	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2013	500	RADIO	●	●	●	●	●	○	○	
2013	500	PIM	●	●	●	●	●	○	○	
2013	500	PCM	●	●	●	●	●	●	●	
2013	500	ORC	●	●	●	●	●	○	●	
2013	500	BCM	●	●	●	●	●	●	●	
2013	500	TCM	●	●	●	●	●	●	○	
2013	Wrangler (Export)	CCN	●	●	●	●	●	●	○	008C, 0091, 0094, 0096
2013	Wrangler (Export)	TIPMCGW	●	●	●	●	●	●	●	003F, 003A, 021F
2013	Wrangler (Export)	WCM	●	●	●	●	●	○	●	
2013	Wrangler (Export)	ORC	●	●	●	●	●	○	●	0122
2013	Wrangler (Export)	RADIO	●	●	●	●	●	●	●	
2013	Wrangler (Export)	PCM	●	●	●	●	●	●	●	02BA, 031D
2013	Wrangler (Export)	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2013	Wrangler (Export)	SAS	●	●	●	●	○	○	○	
2013	Wrangler (Export)	TCM	●	●	●	●	●	○	○	
2013	Journey	PDM	●	●	●	●	●	●	●	
2013	Journey	ITM	●	●	●	●	●	●	●	
2013	Journey	BCM	●	●	●	●	●	●	●	
2013	Journey	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2013	Journey	SCCM	●	●	●	●	●	○	○	
2013	Journey	TGW	●	●	●	●	●	○	○	
2013	Journey	VES3	●	●	●	●	●	●	○	
2013	Journey	VTM	●	●	●	●	●	○	○	
2013	Journey	PTS	●	●	●	●	●	●	●	02ED, 03B7
2013	Journey	PCM	●	●	●	●	●	●	●	0126, 0411, 0432, 042D, 031D
2013	Journey	HSM	●	●	●	●	●	●	●	
2013	Journey	DTCM	●	●	●	●	●	●	●	
2013	Journey	ORC	●	●	●	●	●	○	●	
2013	Journey	HFM	●	●	●	●	●	○	○	
2013	Journey	RFH	●	●	●	●	●	●	●	0442
2013	Journey	ABS	●	●	●	●	●	●	●	
2013	Journey	DDM	●	●	●	●	●	●	●	
2013	Journey	TCM	●	●	●	●	●	●	●	
2013	Journey	ICS	●	●	●	●	●	●	○	
2013	Journey	EPPM	●	●	●	●	●	○	●	
2013	Journey	IPC	●	●	●	●	●	●	○	
2013	Journey	AMP	●	●	●	●	●	○	○	

[illegible]



YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2013	Wrangler	PCM	●	●	●	●	●	●	●	02BA, 031D, 0126, 0411
2013	Wrangler	WCM	●	●	●	●	●	○	●	
2013	Wrangler	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2013	Sebring / 200 / Avenger	HVAC	●	●	●	●	●	●	●	
2013	Sebring / 200 / Avenger	CCN	●	●	●	●	●	●	●	
2013	Sebring / 200 / Avenger	WCM	●	●	●	●	●	○	●	
2013	Sebring / 200 / Avenger	DDM	●	●	●	●	●	●	○	
2013	Sebring / 200 / Avenger	AMP	●	●	●	●	●	○	●	
2013	Sebring / 200 / Avenger	PTCM	●	●	●	●	●	○	●	
2013	Sebring / 200 / Avenger	TIPMCGW	●	●	●	●	●	●	●	
2013	Sebring / 200 / Avenger	ORC	●	●	●	●	●	○	●	
2013	Sebring / 200 / Avenger	SAS	●	●	●	●	○	○	○	
2013	Sebring / 200 / Avenger	RADIO	●	●	●	●	●	●	●	
2013	Sebring / 200 / Avenger	PDM	●	●	●	●	●	●	○	
2013	Sebring / 200 / Avenger	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2013	Sebring / 200 / Avenger	HFM	●	●	●	●	●	●	○	
2013	Sebring / 200 / Avenger	PCM	●	●	●	●	●	●	●	0126, 0411
2013	Liberty	PCM	●	●	●	●	●	●	●	0126, 0411, 02BA, 031D
2013	Liberty	RADIO	●	●	●	●	●	●	●	
2013	Liberty	HVAC	●	●	●	●	●	●	●	
2013	Liberty	FDCM	●	●	●	●	●	●	○	
2013	Liberty	SAS	●	●	●	●	○	○	○	
2013	Liberty	DMFR	●	●	●	●	●	●	●	
2013	Liberty	HFM	●	●	●	●	●	●	○	
2013	Liberty	SUNR	●	●	●	●	●	○	○	
2013	Liberty	ORC	●	●	●	●	●	○	●	
2013	Liberty	PTS	●	●	●	●	●	●	●	02ED, 03B7
2013	Liberty	TIPMCGW	●	●	●	●	●	●	●	003F, 003A, 021F
2013	Liberty	ESM	●	●	●	●	●	●	○	
2013	Liberty	OCM	●	●	●	●	●	○	○	011E
2013	Liberty	TCM	●	●	●	●	●	○	○	
2013	Liberty	CCN	●	●	●	●	●	●	●	
2013	Liberty	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2013	Liberty	DMFL	●	●	●	●	●	●	●	
2013	Liberty	ITM	●	●	●	●	●	●	●	
2013	Liberty	AMP	●	●	●	●	●	○	●	
2013	Liberty	WCM	●	●	●	●	●	○	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2013	Liberty	MSMD	●	●	●	●	●	●	●	0452, 0117
2013	Challenger	CCN	●	●	●	●	●	●	●	
2013	Challenger	PDM	●	●	●	●	●	●	○	
2013	Challenger	WCM	●	●	●	●	●	●	●	02A7, 03E6, 0232, 0230, 0231, 022F
2013	Challenger	PEM	●	●	●	●	●	○	●	0442
2013	Challenger	ADCM	●	●	●	●	●	○	○	
2013	Challenger	DDM	●	●	●	●	●	●	○	
2013	Challenger	PCM	●	●	●	●	●	●	●	0126, 0411
2013	Challenger	RADIO	●	●	●	●	●	●	●	
2013	Challenger	PTS	●	●	●	●	●	○	●	02ED
2013	Challenger	HSM	●	●	●	●	●	●	●	
2013	Challenger	TIPMCGW	●	●	●	●	●	●	●	002E
2013	Challenger	SAS	●	●	●	●	●	●	○	
2013	Challenger	TCM	●	●	●	●	●	○	○	
2013	Challenger	ESM	●	●	●	●	●	●	○	
2013	Challenger	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2013	Challenger	ABS	●	●	●	●	●	●	●	
2013	Challenger	HFM	●	●	●	●	●	●	○	
2013	Challenger	ORC	●	●	●	●	●	○	●	
2013	Challenger	EPS	●	●	●	●	●	○	○	
2013	Challenger	EOM	●	●	●	●	●	○	●	
2013	Challenger	SUNR	●	●	●	●	●	●	○	
2013	Challenger	AMP	●	●	●	●	●	○	●	
2013	Challenger	HVAC	●	●	●	●	●	●	●	
2013	Charger (Post-2011)	ADCM	●	●	●	●	●	○	○	
2013	Charger (Post-2011)	BCM	●	●	●	●	●	●	●	
2013	Charger (Post-2011)	LBSS	●	●	●	●	●	○	○	
2013	Charger (Post-2011)	ICS	●	●	●	●	●	●	○	
2013	Charger (Post-2011)	EPS	●	●	●	●	●	○	○	
2013	Charger (Post-2011)	RFH	●	●	●	●	●	●	●	0442
2013	Charger (Post-2011)	VSIM	●	●	●	●	●	●	●	
2013	Charger (Post-2011)	ABS	●	●	●	●	●	●	●	
2013	Charger (Post-2011)	PTS	●	●	●	●	●	●	●	02ED, 03B7
2013	Charger (Post-2011)	SCCM	●	●	●	●	●	○	○	
2013	Charger (Post-2011)	ITM	●	●	●	●	●	●	●	
2013	Charger (Post-2011)	ACC	●	●	●	●	●	○	●	
2013	Charger (Post-2011)	HFM	●	●	●	●	●	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2013	Charger (Post-2011)	AMP	●	●	●	●	●	○	○	
2013	Charger (Post-2011)	HSM	●	●	●	●	●	●	●	
2013	Charger (Post-2011)	DTCM	●	●	●	●	●	●	●	
2013	Charger (Post-2011)	PCM	●	●	●	●	●	●	●	0126, 0411
2013	Charger (Post-2011)	ESM	●	●	●	●	●	●	○	
2013	Charger (Post-2011)	RBSS	●	●	●	●	●	○	○	
2013	Charger (Post-2011)	ORC	●	●	●	●	●	○	●	
2013	Charger (Post-2011)	TCM	●	●	●	●	●	○	●	
2013	Charger (Post-2011)	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2013	Charger (Post-2011)	MSM	●	●	●	●	●	●	●	0452
2013	Charger (Post-2011)	IPC	●	●	●	●	●	●	○	
2013	Charger (Post-2011)	TGW	●	●	●	●	●	○	○	
2013	Charger (Post-2011)	DDM	●	●	●	●	●	●	●	
2013	Charger (Post-2011)	PDM	●	●	●	●	●	●	●	
2013	Charger (Post-2011)	HVAC	●	●	●	●	●	●	●	
2013	300 / Magnum / Charger (Pre-2011)	DTCM	●	●	●	●	●	●	●	
2013	300 / Magnum / Charger (Pre-2011)	AMP	●	●	●	●	●	○	○	
2013	300 / Magnum / Charger (Pre-2011)	ACC	●	●	●	●	●	○	●	
2013	300 / Magnum / Charger (Pre-2011)	DDM	●	●	●	●	●	●	●	
2013	300 / Magnum / Charger (Pre-2011)	ITM	●	●	●	●	●	●	●	
2013	300 / Magnum / Charger (Pre-2011)	IPC	●	●	●	●	●	●	○	
2013	300 / Magnum / Charger (Pre-2011)	TCM	●	●	●	●	●	○	●	
2013	300 / Magnum / Charger (Pre-2011)	ORC	●	●	●	●	●	○	●	
2013	300 / Magnum / Charger (Pre-2011)	RBSS	●	●	●	●	●	○	○	
2013	300 / Magnum / Charger (Pre-2011)	HFM	●	●	●	●	●	○	○	
2013	300 / Magnum / Charger (Pre-2011)	PTS	●	●	●	●	●	●	●	02ED, 03B7
2013	300 / Magnum / Charger (Pre-2011)	TGW	●	●	●	●	●	○	○	
2013	300 / Magnum / Charger (Pre-2011)	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2013	300 / Magnum / Charger (Pre-2011)	ESM	●	●	●	●	●	●	○	
2013	300 / Magnum / Charger (Pre-2011)	EPS	●	●	●	●	●	○	○	
2013	300 / Magnum / Charger (Pre-2011)	PDM	●	●	●	●	●	●	●	
2013	300 / Magnum / Charger (Pre-2011)	ADCM	●	●	●	●	●	○	○	
2013	300 / Magnum / Charger (Pre-2011)	ICS	●	●	●	●	●	●	○	
2013	300 / Magnum / Charger (Pre-2011)	LBSS	●	●	●	●	●	○	○	
2013	300 / Magnum / Charger (Pre-2011)	BCM	●	●	●	●	●	●	●	
2013	300 / Magnum / Charger (Pre-2011)	SCCM	●	●	●	●	●	○	○	
2013	300 / Magnum / Charger (Pre-2011)	RFH	●	●	●	●	●	●	●	0442

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2013	300 / Magnum / Charger (Pre-2011)	ABS	●	●	●	●	●	●	●	
2013	300 / Magnum / Charger (Pre-2011)	MSM	●	●	●	●	●	●	●	0452
2013	300 / Magnum / Charger (Pre-2011)	HVAC	●	●	●	●	●	●	●	
2013	300 / Magnum / Charger (Pre-2011)	HSM	●	●	●	●	●	●	●	
2013	300 / Magnum / Charger (Pre-2011)	PCM	●	●	●	●	●	●	●	0432, 042D, 031D, 0126, 0411
2013	300 / Magnum / Charger (Pre-2011)	AFLS	●	●	●	●	●	●	○	
2013	Compass	ORC	●	●	●	●	●	○	●	
2013	Compass	ITM	●	●	●	●	●	●	●	
2013	Compass	TIPMCGW	●	●	●	●	●	●	●	003F, 020E, 0215, 028F, 0211
2013	Compass	RADIO	●	●	●	●	●	●	●	
2013	Compass	AWD	●	●	●	●	●	●	●	
2013	Compass	SAS	●	●	●	●	○	○	○	
2013	Compass	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2013	Compass	TCM	●	●	●	●	●	●	●	
2013	Compass	AMP	●	●	●	●	●	○	●	0069, 006D, 0079, 0068, 0303
2013	Compass	PCM	●	●	●	●	●	●	●	0126, 0411, 03E1, 03DA, 0049, 03D8
2013	Compass	CCN	●	●	●	●	●	●	●	
2013	Compass	HFM	●	●	●	●	●	●	○	
2013	Compass	HVAC	●	●	●	●	●	●	●	
2013	Compass	WCM	●	●	●	●	●	○	●	
2013	Ypsilon	ECM	●	●	●	●	●	●	●	
2013	Ypsilon	ABS	●	●	●	●	○	●	●	
2013	Ypsilon	EPS	●	●	●	●	○	○	●	
2013	Ypsilon	AHM	●	●	●	●	●	●	○	
2013	Ypsilon	HVAC	●	●	●	●	●	●	●	
2013	Ypsilon	IPC	●	●	●	●	●	●	○	
2013	Ypsilon	ORC	●	●	●	●	●	●	●	
2013	Ypsilon	TCM	●	●	●	●	○	●	●	
2013	Ypsilon	BCM	●	●	●	●	●	●	○	
2013	Dart	TCM	●	●	●	●	●	●	●	
2013	Dart	SCCM	●	●	●	●	●	○	○	
2013	Dart	IPC	●	●	●	●	●	●	○	
2013	Dart	ICS	●	●	●	●	●	●	○	
2013	Dart	CSWM	●	●	●	●	●	●	●	
2013	Dart	EDM	●	●	●	○	○	●	○	
2013	Dart	RADIO	●	●	●	●	●	●	●	
2013	Dart	AMP	●	●	●	●	●	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2013	Dart	LBSS	●	●	●	●	●	○	●	
2013	Dart	RFH	●	●	●	●	●	●	●	
2013	Dart	CTM	●	●	●	●	●	○	○	
2013	Dart	OCM	●	●	●	●	●	○	●	
2013	Dart	ORC	●	●	●	●	●	●	●	
2013	Dart	BCM	●	●	●	●	●	●	●	
2013	Dart	HVAC	●	●	●	●	●	●	●	
2013	Dart	PCM	●	●	●	●	●	●	●	0126, 0411
2013	Dart	RBSS	●	●	●	●	●	○	●	
2013	Dart	ESM	●	●	●	●	○	○	●	
2013	Dart	ABS	●	●	●	●	●	○	●	
2013	Dart	PAM	●	●	●	●	●	○	○	
2013	Dart	EPS	●	●	●	●	●	○	○	
2013	Routan	DMFR	●	●	●	●	●	●	●	
2013	Routan	PCM	●	●	●	●	●	●	●	0126, 0411
2013	Routan	LBSS	●	●	●	●	●	○	○	
2013	Routan	PSDMR	●	●	●	●	●	○	○	
2013	Routan	RBSS	●	●	●	●	●	○	○	
2013	Routan	HFM	●	●	●	●	●	●	○	
2013	Routan	HSM	●	●	●	●	●	●	●	0412
2013	Routan	DMFL	●	●	●	●	●	●	●	
2013	Routan	PTS	●	●	●	●	●	●	●	02ED, 03B7
2013	Routan	SUNR	●	●	●	●	●	●	○	
2013	Routan	AMP	●	●	●	●	●	○	●	
2013	Routan	WCM	●	●	●	●	●	●	●	02A7, 03E6, 0232, 0230, 0231, 022F
2013	Routan	RADIO	●	●	●	●	●	●	●	
2013	Routan	PSDML	●	●	●	●	●	○	○	
2013	Routan	MSMD	●	●	●	●	●	●	●	0452
2013	Routan	HVAC	●	●	●	●	●	●	●	
2013	Routan	VES2	●	●	●	●	●	●	●	
2013	Routan	SAS	●	●	●	●	○	○	○	
2013	Routan	FSM	●	●	●	●	●	●	○	
2013	Routan	DVD	●	●	●	●	●	○	○	
2013	Routan	CCN	●	●	●	●	●	●	●	008C, 0091, 0094, 0096
2013	Routan	VES3	●	●	●	●	●	●	●	
2013	Routan	DMRR	●	●	●	●	●	●	●	
2013	Routan	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2013	Routan	ABS	●	●	●	●	●	●	●	0002
2013	Routan	PEM	●	●	●	●	●	○	●	0442
2013	Routan	PLGM	●	●	●	●	●	●	●	
2013	Routan	DMRL	●	●	●	●	●	●	●	
2013	Routan	TIPMCGW	●	●	●	●	●	●	●	
2013	Routan	ORC	●	●	●	●	●	○	●	
2013	Town & Country / Caravan	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2013	Town & Country / Caravan	VES2	●	●	●	●	●	●	●	
2013	Town & Country / Caravan	HFM	●	●	●	●	●	●	○	
2013	Town & Country / Caravan	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2013	Town & Country / Caravan	HSM	●	●	●	●	●	●	●	0412
2013	Town & Country / Caravan	SUNR	●	●	●	●	●	●	○	
2013	Town & Country / Caravan	PCM	●	●	●	●	●	●	●	0126, 0411, 02BA, 031D
2013	Town & Country / Caravan	DMRL	●	●	●	●	●	●	●	
2013	Town & Country / Caravan	DMFL	●	●	●	●	●	●	●	
2013	Town & Country / Caravan	EPPM	●	●	●	●	●	○	●	
2013	Town & Country / Caravan	HIDT	●	●	●	●	●	●	○	
2013	Town & Country / Caravan	RBSS	●	●	●	●	●	○	○	
2013	Town & Country / Caravan	DVD	●	●	●	●	●	○	○	
2013	Town & Country / Caravan	ORC	●	●	●	●	●	○	●	
2013	Town & Country / Caravan	WCM	●	●	●	●	●	●	●	02A7, 03E6, 0232, 0230, 0231, 022F
2013	Town & Country / Caravan	TIPMCGW	●	●	●	●	●	●	●	
2013	Town & Country / Caravan	HVAC	●	●	●	●	●	●	●	
2013	Town & Country / Caravan	AMP	●	●	●	●	●	○	●	
2013	Town & Country / Caravan	ITM	●	●	●	●	●	●	●	
2013	Town & Country / Caravan	PEM	●	●	●	●	●	○	●	0442
2013	Town & Country / Caravan	CCN	●	●	●	●	●	●	●	
2013	Town & Country / Caravan	PSDML	●	●	●	●	●	○	○	
2013	Town & Country / Caravan	DMRR	●	●	●	●	●	●	●	
2013	Town & Country / Caravan	PSDMR	●	●	●	●	●	○	○	
2013	Town & Country / Caravan	DMFR	●	●	●	●	●	●	●	
2013	Town & Country / Caravan	TCM	●	●	●	●	●	●	●	
2013	Town & Country / Caravan	PTS	●	●	●	●	●	●	●	02ED, 03B7
2013	Town & Country / Caravan	AHBM	●	●	●	●	○	●	○	
2013	Town & Country / Caravan	LBSS	●	●	●	●	●	○	○	
2013	Town & Country / Caravan	MSMD	●	●	●	●	●	●	●	0452
2013	Town & Country / Caravan	FSM	●	●	●	●	●	●	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2013	Town & Country / Caravan	SAS	●	●	●	●	○	○	○	
2013	Town & Country / Caravan	PLGM	●	●	●	●	●	●	●	
2013	Town & Country / Caravan	VES3	●	●	●	●	●	●	●	
2013	Town & Country / Caravan	RADIO	●	●	●	●	●	●	●	
2013	Durango (Post-2011)	TIPMCGW	●	●	●	●	●	●	●	0476
2013	Durango (Post-2011)	CCN	●	●	●	●	●	●	●	
2013	Durango (Post-2011)	AHBM	●	●	●	●	○	●	○	
2013	Durango (Post-2011)	ABS	●	●	●	●	●	●	●	
2013	Durango (Post-2011)	TCM	●	●	●	●	●	○	○	
2013	Durango (Post-2011)	MSMD	●	●	●	●	●	●	●	0452
2013	Durango (Post-2011)	ITM	●	●	●	●	●	●	●	
2013	Durango (Post-2011)	AHLM	●	●	●	●	●	●	○	
2013	Durango (Post-2011)	ESM	●	●	●	●	●	●	○	
2013	Durango (Post-2011)	DTCM	●	●	●	●	●	●	●	
2013	Durango (Post-2011)	DMFR	●	●	●	●	●	●	●	
2013	Durango (Post-2011)	SAS	●	●	●	●	●	●	○	
2013	Durango (Post-2011)	PLGM	●	●	●	●	○	●	●	
2013	Durango (Post-2011)	RADIO	●	●	●	●	●	●	●	
2013	Durango (Post-2011)	PTS	●	●	●	●	●	●	●	02ED, 03B7
2013	Durango (Post-2011)	HSM	●	●	●	●	●	●	●	0412
2013	Durango (Post-2011)	WCM	●	●	●	●	●	●	●	02A7, 03E6, 0232, 0230, 0231, 022F
2013	Durango (Post-2011)	BSM	●	●	●	●	●	○	○	
2013	Durango (Post-2011)	PCM	●	●	●	●	●	●	●	0126, 0411
2013	Durango (Post-2011)	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2013	Durango (Post-2011)	ACC	●	●	●	●	●	○	○	
2013	Durango (Post-2011)	DMFL	●	●	●	●	●	●	●	
2013	Durango (Post-2011)	ORC	●	●	●	●	●	○	●	0122
2013	Durango (Post-2011)	HVAC	●	●	●	●	●	●	●	
2013	Durango (Post-2011)	EPS	●	●	●	●	●	○	○	
2013	Durango (Post-2011)	PEM	●	●	●	●	●	○	●	0442
2013	Durango (Post-2011)	HFM	●	●	●	●	●	●	○	
2013	Durango (Post-2011)	VES3	●	●	●	●	●	●	●	
2013	Durango (Post-2011)	AMP	●	●	●	●	●	○	●	
2013	Grand Cherokee	AHLM	●	●	●	●	●	●	○	
2013	Grand Cherokee	ADCM	●	●	●	●	●	○	○	
2013	Grand Cherokee	ASCM	●	●	●	●	●	○	○	
2013	Grand Cherokee	HFM	●	●	●	●	●	●	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2013	Grand Cherokee	AMP	●	●	●	●	●	○	●	
2013	Grand Cherokee	ITM	●	●	●	●	●	●	●	
2013	Grand Cherokee	EPS	●	●	●	●	●	○	○	
2013	Grand Cherokee	VES3	●	●	●	●	●	●	●	
2013	Grand Cherokee	ORC	●	●	●	●	●	○	●	0122
2013	Grand Cherokee	WCM	●	●	●	●	●	●	●	02A7, 03E6, 0232, 0230, 0231, 022F
2013	Grand Cherokee	DMFL	●	●	●	●	●	●	●	
2013	Grand Cherokee	MSMD	●	●	●	●	●	●	●	0452
2013	Grand Cherokee	ACC	●	●	●	●	●	○	○	
2013	Grand Cherokee	ABS	●	●	●	●	●	●	●	
2013	Grand Cherokee	RADIO	●	●	●	●	●	●	●	
2013	Grand Cherokee	SAS	●	●	●	●	●	●	○	
2013	Grand Cherokee	BSM	●	●	●	●	●	○	○	
2013	Grand Cherokee	HVAC	●	●	●	●	●	●	●	
2013	Grand Cherokee	PEM	●	●	●	●	●	○	●	0442
2013	Grand Cherokee	TIPMCGW	●	●	●	●	●	●	●	0476
2013	Grand Cherokee	DTCM	●	●	●	●	●	●	●	
2013	Grand Cherokee	PCM	●	●	●	●	●	●	●	0126, 0411, 0432, 042D, 031D
2013	Grand Cherokee	ESM	●	●	●	●	●	●	○	
2013	Grand Cherokee	ELSD	●	●	●	●	●	●	○	
2013	Grand Cherokee	PTS	●	●	●	●	●	●	●	02ED, 03B7
2013	Grand Cherokee	HSM	●	●	●	●	●	●	●	0412
2013	Grand Cherokee	TCM	●	●	●	●	●	○	○	
2013	Grand Cherokee	AHBM	●	●	●	●	○	●	○	
2013	Grand Cherokee	DMFR	●	●	●	●	●	●	●	
2013	Grand Cherokee	CCN	●	●	●	●	●	●	●	
2013	Grand Cherokee	PLGM	●	●	●	●	○	●	●	
2013	Grand Cherokee	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2013	Viper (Post-2013)	RFH	●	●	●	●	●	●	●	0442
2013	Viper (Post-2013)	HVAC	●	●	●	●	●	●	●	
2013	Viper (Post-2013)	PDM	●	●	●	●	●	●	●	
2013	Viper (Post-2013)	DDM	●	●	●	●	●	●	●	
2013	Viper (Post-2013)	IPC	●	●	●	●	●	●	●	
2013	Viper (Post-2013)	BCM	●	●	●	●	●	●	●	
2013	Viper (Post-2013)	OCM	●	●	●	●	●	○	○	
2013	Viper (Post-2013)	RADIO	●	●	●	●	●	●	●	
2013	Viper (Post-2013)	ADCM	●	●	●	●	●	○	○	



YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2013	Viper (Post-2013)	ABS	●	●	●	●	●	●	●	
2013	Viper (Post-2013)	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2013	Viper (Post-2013)	ORC	●	●	●	●	●	●	●	
2013	Viper (Post-2013)	AMP	●	●	●	●	●	○	○	
2013	Viper (Post-2013)	SCCM	●	●	●	●	●	○	○	
2013	Viper (Post-2013)	ICS	●	●	●	●	●	●	●	
2013	Viper (Post-2013)	PCM	●	●	●	●	●	●	○	
2014	Fiat 500L	TPM	●	●	●	●	●	●	●	
2014	Fiat 500L	EPS	●	●	●	●	●	○	○	
2014	Fiat 500L	ESM	●	●	●	●	●	●	●	
2014	Fiat 500L	BCM	●	●	●	●	●	●	●	
2014	Fiat 500L	IPC	●	●	●	●	○	●	○	
2014	Fiat 500L	ETM	●	●	●	●	●	○	●	
2014	Fiat 500L	PAM	●	●	●	●	●	○	○	
2014	Fiat 500L	HVAC	●	●	●	●	●	●	○	
2014	Fiat 500L	ORC	●	●	●	●	●	○	●	
2014	Fiat 500L	TCM	●	●	●	●	●	●	●	
2014	Fiat 500L	PCM	●	●	●	●	●	●	●	
2014	Fiat 500L	ABS	●	●	●	●	●	○	●	
2014	Forza	IPC	●	●	●	●	○	●	○	
2014	Forza	ORC	●	●	●	●	○	●	○	
2014	Ram 3500 Pickup	ITBM	●	●	●	●	●	○	○	
2014	Ram 3500 Pickup	ASCM	●	●	●	●	●	○	●	
2014	Ram 3500 Pickup	RADIO	●	●	●	●	●	●	●	
2014	Ram 3500 Pickup	DCU	●	●	●	○	○	○	○	
2014	Ram 3500 Pickup	MSM	●	●	●	●	●	●	●	0452
2014	Ram 3500 Pickup	RFH	●	●	●	●	●	●	●	0442
2014	Ram 3500 Pickup	DTCM	●	●	●	●	●	●	●	
2014	Ram 3500 Pickup	AMP	●	●	●	●	●	○	○	
2014	Ram 3500 Pickup	PCM	●	●	●	●	●	●	●	0126, 0411
2014	Ram 3500 Pickup	BCM	●	●	●	●	●	●	●	
2014	Ram 3500 Pickup	IPC	●	●	●	●	●	●	○	
2014	Ram 3500 Pickup	PTS	●	●	●	●	●	●	●	02ED, 03B7
2014	Ram 3500 Pickup	ICS	●	●	●	●	●	●	●	
2014	Ram 3500 Pickup	ORC	●	●	●	●	●	●	●	
2014	Ram 3500 Pickup	VSIM	●	●	●	●	●	●	○	
2014	Ram 3500 Pickup	PDM	●	●	●	●	●	●	●	



YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2014	Ram 2500	SCCM	●	●	●	●	●	○	○	
2014	Ram 2500	RADIO	●	●	●	●	●	●	●	
2014	Ram 2500	MSM	●	●	●	●	●	●	●	0452
2014	Ram 2500	TCM	●	●	●	●	●	●	●	
2014	Ram 2500	DCU	●	●	●	○	○	○	○	
2014	Ram 2500	AMP	●	●	●	●	●	○	○	
2014	Ram 2500	PCM	●	●	●	●	●	●	●	0126, 0411
2014	Ram 2500	IPC	●	●	●	●	●	●	○	
2014	Ram 2500	ITBM	●	●	●	●	●	○	○	
2014	Ram 2500	DTCM	●	●	●	●	●	●	●	
2014	Ram 2500	PDM	●	●	●	●	●	●	●	
2014	Ram 2500	RFH	●	●	●	●	●	●	●	0442
2014	Ram 2500	VSIM	●	●	●	●	●	●	○	
2014	Ram 2500	HSM	●	●	●	●	●	●	●	
2014	Ram 2500	EDM	●	●	●	●	●	●	○	
2014	Ram 2500	ABS	●	●	●	●	●	●	●	
2014	Ram 2500	ICS	●	●	●	●	●	●	●	
2014	Ram 2500	ASCM	●	●	●	●	●	○	●	
2014	Ram 2500	BCM	●	●	●	●	●	●	●	
2014	Ram 4500/5500	MSM	●	●	●	●	●	●	●	0452
2014	Ram 4500/5500	AMP	●	●	●	●	●	○	○	
2014	Ram 4500/5500	DDM	●	●	●	●	●	●	●	
2014	Ram 4500/5500	EDM	●	●	●	●	●	●	○	
2014	Ram 4500/5500	PTS	●	●	●	●	●	●	●	02ED, 03B7
2014	Ram 4500/5500	VGT	●	●	●	○	○	○	○	
2014	Ram 4500/5500	ITBM	●	●	●	●	●	○	○	
2014	Ram 4500/5500	HSM	●	●	●	●	●	●	●	
2014	Ram 4500/5500	PCM	●	●	●	●	●	●	●	0126, 0411, 03C8
2014	Ram 4500/5500	ORC	●	●	●	●	●	●	●	
2014	Ram 4500/5500	DCU	●	●	●	○	○	○	○	
2014	Ram 4500/5500	TCM	●	●	●	●	●	●	●	
2014	Ram 4500/5500	RADIO	●	●	●	●	●	●	●	
2014	Ram 4500/5500	SCCM	●	●	●	●	●	○	○	
2014	Ram 4500/5500	PDM	●	●	●	●	●	●	●	
2014	Ram 4500/5500	ICS	●	●	●	●	●	●	●	
2014	Ram 4500/5500	RFH	●	●	●	●	●	●	●	0442
2014	Ram 4500/5500	ABS	●	●	●	●	●	●	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2014	Ram 4500/5500	VSIM	●	●	●	●	●	●	○	
2014	Ram 4500/5500	BCM	●	●	●	●	●	●	●	
2014	Ram 4500/5500	DTCM	●	●	●	●	●	●	●	
2014	Ram 4500/5500	HVAC	●	●	●	●	●	●	●	
2014	Ram 4500/5500	IPC	●	●	●	●	●	●	○	
2014	Ram 1500	MSM	●	●	●	●	●	●	●	0452
2014	Ram 1500	EPS	●	●	●	●	●	○	○	
2014	Ram 1500	EDM	●	●	●	●	●	●	○	
2014	Ram 1500	SCCM	●	●	●	●	●	○	○	
2014	Ram 1500	HSM	●	●	●	●	●	●	●	
2014	Ram 1500	RADIO	●	●	●	●	●	●	●	
2014	Ram 1500	ICS	●	●	●	●	●	●	●	
2014	Ram 1500	HVAC	●	●	●	●	●	●	●	
2014	Ram 1500	ESM	●	●	●	●	●	○	○	
2014	Ram 1500	PCM	●	●	●	●	●	●	●	0126, 0411, 0432, 042D, 031D
2014	Ram 1500	ABS	●	●	●	●	●	●	●	
2014	Ram 1500	ASCM	●	●	●	●	●	○	●	
2014	Ram 1500	PDM	●	●	●	●	●	●	●	
2014	Ram 1500	DTCM	●	●	●	●	●	●	●	
2014	Ram 1500	ITBM	●	●	●	●	●	○	○	
2014	Ram 1500	ORC	●	●	●	●	●	●	●	
2014	Ram 1500	AMP	●	●	●	●	●	○	○	
2014	Ram 1500	PTS	●	●	●	●	●	●	●	02ED, 03B7
2014	Ram 1500	RFH	●	●	●	●	●	●	●	0442
2014	Ram 1500	DDM	●	●	●	●	●	●	●	
2014	Ram 1500	TCM	●	●	●	●	●	○	●	
2014	Ram 1500	BCM	●	●	●	●	●	●	●	
2014	Ram 1500	IPC	●	●	●	●	●	●	○	
2014	Ram (Mexico)	ESM	●	●	●	●	●	○	○	
2014	Ram (Mexico)	HSM	●	●	●	●	●	●	●	
2014	Ram (Mexico)	AMP	●	●	●	●	●	○	○	
2014	Ram (Mexico)	PCM	●	●	●	●	●	●	●	03C8, 0126, 0411
2014	Ram (Mexico)	IPC	●	●	●	●	●	●	○	
2014	Ram (Mexico)	EDM	●	●	●	●	●	●	○	
2014	Ram (Mexico)	ASCM	●	●	●	●	●	○	●	
2014	Ram (Mexico)	VSIM	●	●	●	●	●	●	○	
2014	Ram (Mexico)	ITBM	●	●	●	●	●	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2014	Ram (Mexico)	BCM	●	●	●	●	●	●	●	
2014	Ram (Mexico)	PTS	●	●	●	●	●	●	●	02ED, 03B7
2014	Ram (Mexico)	PDM	●	●	●	●	●	●	●	
2014	Ram (Mexico)	DDM	●	●	●	●	●	●	●	
2014	Ram (Mexico)	VGT	●	●	●	○	○	○	○	
2014	Ram (Mexico)	SCCM	●	●	●	●	●	○	○	
2014	Ram (Mexico)	ABS	●	●	●	●	●	●	●	
2014	Ram (Mexico)	TCM	●	●	●	●	●	●	●	
2014	Ram (Mexico)	ORC	●	●	●	●	●	●	●	
2014	Ram (Mexico)	ICS	●	●	●	●	●	●	●	
2014	Ram (Mexico)	HVAC	●	●	●	●	●	●	●	
2014	Ram (Mexico)	DTCM	●	●	●	●	●	●	●	
2014	Ram (Mexico)	RADIO	●	●	●	●	●	●	●	
2014	Ram (Mexico)	DCU	●	●	●	○	○	○	○	
2014	Ram (Mexico)	MSM	●	●	●	●	●	●	●	0452
2014	Ram (Mexico)	EPS	●	●	●	●	●	○	○	
2014	Ram (Mexico)	RFH	●	●	●	●	●	●	●	0442
2014	500	PTS	●	●	●	●	●	○	○	
2014	500	ORC	●	●	●	●	●	○	●	
2014	500	BCM	●	●	●	●	●	●	●	
2014	500	PIM	●	●	●	●	●	○	○	
2014	500	VTM	●	●	●	●	●	○	○	
2014	500	RBC	●	●	●	●	●	○	○	
2014	500	ABS	●	●	●	●	●	●	○	
2014	500	TPM	●	●	●	●	●	●	●	
2014	500	PCM	●	●	●	●	●	●	●	
2014	500	CTM	●	●	●	●	○	●	○	
2014	500	IPC	●	●	●	●	●	●	○	
2014	500	RADIO	●	●	●	●	●	○	○	
2014	500	OBCM	●	●	●	●	●	○	○	
2014	500	EVCU	●	●	●	●	●	●	○	
2014	500	EAC	●	●	●	●	●	○	○	
2014	500	HVAC	●	●	●	●	●	●	○	
2014	500	TCM	●	●	●	●	●	●	○	
2014	500	ESM	●	●	●	○	●	○	○	
2014	500	BPCM	●	●	●	●	●	●	○	
2014	500	EPS	●	●	●	●	●	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2014	Wrangler (Export)	TCM	●	●	●	●	●	○	○	
2014	Wrangler (Export)	ORC	●	●	●	●	●	○	●	0122
2014	Wrangler (Export)	PCM	●	●	●	●	●	●	●	02BA, 031D
2014	Wrangler (Export)	WCM	●	●	●	●	●	○	●	
2014	Wrangler (Export)	RADIO	●	●	●	●	●	●	●	
2014	Wrangler (Export)	ABS	●	●	●	●	●	●	●	0002
2014	Wrangler (Export)	CCN	●	●	●	●	●	●	○	008C, 0091, 0094, 0096
2014	Wrangler (Export)	SAS	●	●	●	●	○	○	○	
2014	Wrangler (Export)	TIPMCGW	●	●	●	●	●	●	●	
2014	Journey	BCM	●	●	●	●	●	●	●	
2014	Journey	IPC	●	●	●	●	●	●	○	
2014	Journey	VTM	●	●	●	●	●	○	○	
2014	Journey	EPPM	●	●	●	●	●	○	●	
2014	Journey	HVAC	●	●	●	●	●	●	●	
2014	Journey	PTS	●	●	●	●	●	●	●	02ED, 03B7
2014	Journey	ICS	●	●	●	●	●	●	○	
2014	Journey	HFM	●	●	●	●	●	○	○	
2014	Journey	PDM	●	●	●	●	●	●	●	
2014	Journey	VES3	●	●	●	●	●	●	○	
2014	Journey	TCM	●	●	●	●	●	●	●	
2014	Journey	DTCM	●	●	●	●	●	●	●	
2014	Journey	RFH	●	●	●	●	●	●	●	0442
2014	Journey	TGW	●	●	●	●	●	○	○	
2014	Journey	SCCM	●	●	●	●	●	○	○	
2014	Journey	DDM	●	●	●	●	●	●	●	
2014	Journey	HSM	●	●	●	●	●	●	●	
2014	Journey	PCM	●	●	●	●	●	●	●	0126, 0411, 0432, 042D, 031D
2014	Journey	ABS	●	●	●	●	●	●	●	
2014	Journey	ITM	●	●	●	●	●	●	●	
2014	Journey	AMP	●	●	●	●	●	○	○	
2014	Journey	ORC	●	●	●	●	●	○	●	
2014	Journey	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2014	Freemont	ICS	●	●	●	●	●	●	○	
2014	Freemont	BCM	●	●	●	●	●	●	●	
2014	Freemont	AMP	●	●	●	●	●	○	○	
2014	Freemont	PTS	●	●	●	●	●	●	●	02ED, 03B7
2014	Freemont	ITM	●	●	●	●	●	●	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2014	Freemont	VTM	●	●	●	●	●	○	○	
2014	Freemont	TCM	●	●	●	●	●	●	●	
2014	Freemont	HFM	●	●	●	●	●	○	○	
2014	Freemont	DTCM	●	●	●	●	●	●	●	
2014	Freemont	HVAC	●	●	●	●	●	●	●	
2014	Freemont	SCCM	●	●	●	●	●	○	○	
2014	Freemont	ORC	●	●	●	●	●	○	●	
2014	Freemont	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2014	Freemont	EPPM	●	●	●	●	●	○	●	
2014	Freemont	PCM	●	●	●	●	●	●	●	0126, 0411, 0432, 042D, 031D
2014	Freemont	ABS	●	●	●	●	●	●	●	
2014	Freemont	TGW	●	●	●	●	●	○	○	
2014	Freemont	PDM	●	●	●	●	●	●	●	
2014	Freemont	DDM	●	●	●	●	●	●	●	
2014	Freemont	VES3	●	●	●	●	●	●	○	
2014	Freemont	IPC	●	●	●	●	●	●	○	
2014	Freemont	HSM	●	●	●	●	●	●	●	
2014	Freemont	RFH	●	●	●	●	●	●	●	0442
2014	Wrangler	AMP	●	●	●	●	●	○	●	
2014	Wrangler	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2014	Wrangler	CCN	●	●	●	●	●	●	○	008C, 0091, 0094, 0096
2014	Wrangler	PCM	●	●	●	●	●	●	●	0126, 0411, 02BA, 031D
2014	Wrangler	WCM	●	●	●	●	●	○	●	
2014	Wrangler	HVAC	●	●	●	●	●	●	●	
2014	Wrangler	TIPMCGW	●	●	●	●	●	●	●	
2014	Wrangler	RADIO	●	●	●	●	●	●	●	
2014	Wrangler	SAS	●	●	●	●	○	○	○	
2014	Wrangler	TCM	●	●	●	●	●	○	○	
2014	Wrangler	ASBS	●	●	●	●	●	○	○	0317, 0318, 031A, 031B, 0319
2014	Wrangler	ABS	●	●	●	●	●	●	●	0002
2014	Wrangler	HFM	●	●	●	●	●	●	○	
2014	Wrangler	ORC	●	●	●	●	●	○	●	0122
2014	Wrangler	ESM	●	●	●	●	●	●	○	
2014	Wrangler	ITM	●	●	●	●	●	●	●	
2014	Sebring / 200 / Avenger	AMP	●	●	●	●	●	○	●	
2014	Sebring / 200 / Avenger	RADIO	●	●	●	●	●	●	●	
2014	Sebring / 200 / Avenger	WCM	●	●	●	●	●	○	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2014	Sebring / 200 / Avenger	DDM	●	●	●	●	●	●	○	
2014	Sebring / 200 / Avenger	PDM	●	●	●	●	●	●	○	
2014	Sebring / 200 / Avenger	ORC	●	●	●	●	●	○	●	
2014	Sebring / 200 / Avenger	ABS	●	●	●	●	●	●	●	0002
2014	Sebring / 200 / Avenger	SAS	●	●	●	●	○	○	○	
2014	Sebring / 200 / Avenger	TIPMCGW	●	●	●	●	●	●	●	
2014	Sebring / 200 / Avenger	HFM	●	●	●	●	●	●	○	
2014	Sebring / 200 / Avenger	HVAC	●	●	●	●	●	●	●	
2014	Sebring / 200 / Avenger	PTCM	●	●	●	●	●	○	●	
2014	Sebring / 200 / Avenger	PCM	●	●	●	●	●	●	●	0126, 0411
2014	Sebring / 200 / Avenger	CCN	●	●	●	●	●	●	●	
2014	Liberty	WCM	●	●	●	●	●	○	●	
2014	Liberty	TCM	●	●	●	●	●	○	○	
2014	Liberty	ABS	●	●	●	●	●	●	●	0002
2014	Liberty	CCN	●	●	●	●	●	●	●	
2014	Liberty	HFM	●	●	●	●	●	●	○	
2014	Liberty	ITM	●	●	●	●	●	●	●	
2014	Liberty	SUNR	●	●	●	●	●	○	○	
2014	Liberty	ORC	●	●	●	●	●	○	●	
2014	Liberty	PTS	●	●	●	●	●	●	●	02ED, 03B7
2014	Liberty	TIPMCGW	●	●	●	●	●	●	●	003F, 003A, 021F
2014	Liberty	ESM	●	●	●	●	●	●	○	
2014	Liberty	AMP	●	●	●	●	●	○	●	
2014	Liberty	RADIO	●	●	●	●	●	●	●	
2014	Liberty	MSMD	●	●	●	●	●	●	●	0452, 0117
2014	Liberty	HVAC	●	●	●	●	●	●	●	
2014	Liberty	DMFR	●	●	●	●	●	●	●	
2014	Liberty	SAS	●	●	●	●	○	○	○	
2014	Liberty	FDCM	●	●	●	●	●	●	○	
2014	Liberty	PCM	●	●	●	●	●	●	●	0126, 0411, 02BA, 031D
2014	Liberty	OCM	●	●	●	●	●	○	○	011E
2014	Liberty	DMFL	●	●	●	●	●	●	●	
2014	Cherokee	AMP	●	●	●	●	●	○	○	
2014	Cherokee	ICS	●	●	●	●	●	●	●	
2014	Cherokee	ESL	●	●	●	●	●	○	●	
2014	Cherokee	BCM	●	●	●	●	●	●	●	
2014	Cherokee	IPC	●	●	●	●	●	●	○	





YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2014	Challenger	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2014	Challenger	EPS	●	●	●	●	●	○	○	
2014	Challenger	PTS	●	●	●	●	●	○	●	02ED
2014	Challenger	EOM	●	●	●	●	●	○	●	
2014	Challenger	HVAC	●	●	●	●	●	●	●	
2014	Challenger	ORC	●	●	●	●	●	○	●	
2014	Challenger	CCN	●	●	●	●	●	●	●	
2014	Challenger	PEM	●	●	●	●	●	○	●	0442
2014	Challenger	ABS	●	●	●	●	●	●	●	
2014	Challenger	HFM	●	●	●	●	●	●	○	
2014	Challenger	TCM	●	●	●	●	●	○	○	
2014	Challenger	TIPMCGW	●	●	●	●	●	●	●	
2014	Challenger	RADIO	●	●	●	●	●	●	●	
2014	Charger (Post-2011)	PDM	●	●	●	●	●	●	●	
2014	Charger (Post-2011)	TCM	●	●	●	●	●	○	●	
2014	Charger (Post-2011)	ADCM	●	●	●	●	●	○	○	
2014	Charger (Post-2011)	DDM	●	●	●	●	●	●	●	
2014	Charger (Post-2011)	RFH	●	●	●	●	●	●	●	0442
2014	Charger (Post-2011)	VSIM	●	●	●	●	●	●	●	
2014	Charger (Post-2011)	EPS	●	●	●	●	●	○	○	
2014	Charger (Post-2011)	ABS	●	●	●	●	●	●	●	
2014	Charger (Post-2011)	ITM	●	●	●	●	●	●	●	
2014	Charger (Post-2011)	IPC	●	●	●	●	●	●	○	
2014	Charger (Post-2011)	AMP	●	●	●	●	●	○	○	
2014	Charger (Post-2011)	DTCM	●	●	●	●	●	●	●	
2014	Charger (Post-2011)	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2014	Charger (Post-2011)	ACC	●	●	●	●	●	○	●	
2014	Charger (Post-2011)	HFM	●	●	●	●	●	○	○	
2014	Charger (Post-2011)	BCM	●	●	●	●	●	●	●	
2014	Charger (Post-2011)	ESM	●	●	●	●	●	●	○	
2014	Charger (Post-2011)	ICS	●	●	●	●	●	●	○	
2014	Charger (Post-2011)	ORC	●	●	●	●	●	○	●	
2014	Charger (Post-2011)	SCCM	●	●	●	●	●	○	○	
2014	Charger (Post-2011)	RBSS	●	●	●	●	●	○	○	
2014	Charger (Post-2011)	PCM	●	●	●	●	●	●	●	0126, 0411
2014	Charger (Post-2011)	HVAC	●	●	●	●	●	●	●	
2014	Charger (Post-2011)	MSM	●	●	●	●	●	●	●	0452

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2014	Charger (Post-2011)	HSM	●	●	●	●	●	●	●	
2014	Charger (Post-2011)	LBSS	●	●	●	●	●	○	○	
2014	Charger (Post-2011)	TGW	●	●	●	●	●	○	○	
2014	Charger (Post-2011)	PTS	●	●	●	●	●	●	●	02ED, 03B7
2014	300 / Magnum / Charger (Pre-2011)	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2014	300 / Magnum / Charger (Pre-2011)	ABS	●	●	●	●	●	●	●	
2014	300 / Magnum / Charger (Pre-2011)	TCM	●	●	●	●	●	○	●	
2014	300 / Magnum / Charger (Pre-2011)	LBSS	●	●	●	●	●	○	○	
2014	300 / Magnum / Charger (Pre-2011)	ESM	●	●	●	●	●	●	○	
2014	300 / Magnum / Charger (Pre-2011)	EPS	●	●	●	●	●	○	○	
2014	300 / Magnum / Charger (Pre-2011)	AMP	●	●	●	●	●	○	○	
2014	300 / Magnum / Charger (Pre-2011)	BCM	●	●	●	●	●	●	●	
2014	300 / Magnum / Charger (Pre-2011)	ICS	●	●	●	●	●	●	○	
2014	300 / Magnum / Charger (Pre-2011)	PDM	●	●	●	●	●	●	●	
2014	300 / Magnum / Charger (Pre-2011)	SCCM	●	●	●	●	●	○	○	
2014	300 / Magnum / Charger (Pre-2011)	HFM	●	●	●	●	●	○	○	
2014	300 / Magnum / Charger (Pre-2011)	ITM	●	●	●	●	●	●	●	
2014	300 / Magnum / Charger (Pre-2011)	ADCM	●	●	●	●	●	○	○	
2014	300 / Magnum / Charger (Pre-2011)	PTS	●	●	●	●	●	●	●	02ED, 03B7
2014	300 / Magnum / Charger (Pre-2011)	DTCM	●	●	●	●	●	●	●	
2014	300 / Magnum / Charger (Pre-2011)	ORC	●	●	●	●	●	○	●	
2014	300 / Magnum / Charger (Pre-2011)	MSM	●	●	●	●	●	●	●	0452
2014	300 / Magnum / Charger (Pre-2011)	IPC	●	●	●	●	●	●	○	
2014	300 / Magnum / Charger (Pre-2011)	ACC	●	●	●	●	●	○	●	
2014	300 / Magnum / Charger (Pre-2011)	HVAC	●	●	●	●	●	●	●	
2014	300 / Magnum / Charger (Pre-2011)	DDM	●	●	●	●	●	●	●	
2014	300 / Magnum / Charger (Pre-2011)	RBSS	●	●	●	●	●	○	○	
2014	300 / Magnum / Charger (Pre-2011)	RFH	●	●	●	●	●	●	●	0442
2014	300 / Magnum / Charger (Pre-2011)	HSM	●	●	●	●	●	●	●	
2014	300 / Magnum / Charger (Pre-2011)	AFLS	●	●	●	●	●	●	○	
2014	300 / Magnum / Charger (Pre-2011)	PCM	●	●	●	●	●	●	●	0126, 0411, 0432, 042D, 031D
2014	300 / Magnum / Charger (Pre-2011)	TGW	●	●	●	●	●	○	○	
2014	Compass	TIPMCGW	●	●	●	●	●	●	●	
2014	Compass	ABS	●	●	●	●	●	●	●	0002, 0285, 0062
2014	Compass	HFM	●	●	●	●	●	●	○	
2014	Compass	ORC	●	●	●	●	●	○	●	
2014	Compass	RADIO	●	●	●	●	●	●	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2014	Compass	ITM	●	●	●	●	●	●	●	
2014	Compass	WCM	●	●	●	●	●	○	●	
2014	Compass	HVAC	●	●	●	●	●	●	●	
2014	Compass	CCN	●	●	●	●	●	●	●	
2014	Compass	AWD	●	●	●	●	●	●	●	
2014	Compass	SAS	●	●	●	●	○	○	○	
2014	Compass	AMP	●	●	●	●	●	○	●	
2014	Compass	TCM	●	●	●	●	●	●	●	
2014	Compass	PCM	●	●	●	●	●	●	●	0126, 0411, 03E1, 03DA, 0049, 03D8
2014	Dart	PAM	●	●	●	●	●	○	○	
2014	Dart	CTM	●	●	●	●	●	○	○	
2014	Dart	HVAC	●	●	●	●	●	●	●	
2014	Dart	RFH	●	●	●	●	●	●	●	
2014	Dart	SCCM	●	●	●	●	●	○	○	
2014	Dart	IPC	●	●	●	●	●	●	○	
2014	Dart	ICS	●	●	●	●	●	●	○	
2014	Dart	OCM	●	●	●	●	●	○	●	
2014	Dart	RBSS	●	●	●	●	●	○	●	
2014	Dart	CSWM	●	●	●	●	●	●	●	
2014	Dart	ESM	●	●	●	●	○	○	●	
2014	Dart	AMP	●	●	●	●	●	○	○	
2014	Dart	PCM	●	●	●	●	●	●	●	0126, 0411
2014	Dart	RADIO	●	●	●	●	●	●	●	
2014	Dart	ORC	●	●	●	●	●	●	●	
2014	Dart	EPS	●	●	●	●	●	○	○	
2014	Dart	LBSS	●	●	●	●	●	○	●	
2014	Dart	BCM	●	●	●	●	●	●	●	
2014	Dart	EDM	●	●	●	○	○	●	○	
2014	Dart	ABS	●	●	●	●	●	○	●	
2014	Dart	TCM	●	●	●	●	●	●	●	
2014	Routan	DMRL	●	●	●	●	●	●	●	
2014	Routan	VES3	●	●	●	●	●	●	●	
2014	Routan	VES2	●	●	●	●	●	●	●	
2014	Routan	PTS	●	●	●	●	●	●	●	02ED, 03B7
2014	Routan	CCN	●	●	●	●	●	●	●	008C, 0091, 0094, 0096
2014	Routan	PSDMR	●	●	●	●	●	○	○	
2014	Routan	SUNR	●	●	●	●	●	●	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2014	Routan	RBSS	●	●	●	●	●	○	○	
2014	Routan	DMFL	●	●	●	●	●	●	●	
2014	Routan	LBSS	●	●	●	●	●	○	○	
2014	Routan	HVAC	●	●	●	●	●	●	●	
2014	Routan	DMFR	●	●	●	●	●	●	●	
2014	Routan	SAS	●	●	●	●	○	○	○	
2014	Routan	DVD	●	●	●	●	●	○	○	
2014	Routan	AMP	●	●	●	●	●	○	●	
2014	Routan	PCM	●	●	●	●	●	●	●	0126, 0411
2014	Routan	TIPMCGW	●	●	●	●	●	●	●	
2014	Routan	HFM	●	●	●	●	●	●	○	
2014	Routan	ORC	●	●	●	●	●	○	●	
2014	Routan	FSM	●	●	●	●	●	●	○	
2014	Routan	DMRR	●	●	●	●	●	●	●	
2014	Routan	WCM	●	●	●	●	●	●	●	02A7, 03E6, 0232, 0230, 0231, 022F
2014	Routan	HSM	●	●	●	●	●	●	●	0412
2014	Routan	PEM	●	●	●	●	●	○	●	0442
2014	Routan	RADIO	●	●	●	●	●	●	●	
2014	Routan	ABS	●	●	●	●	●	●	●	
2014	Routan	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2014	Routan	PLGM	●	●	●	●	●	●	●	
2014	Routan	MSMD	●	●	●	●	●	●	●	0452
2014	Routan	PSDML	●	●	●	●	●	○	○	
2014	Town & Country / Caravan	PEM	●	●	●	●	●	○	●	0442
2014	Town & Country / Caravan	PLGM	●	●	●	●	●	●	●	
2014	Town & Country / Caravan	WCM	●	●	●	●	●	●	●	02A7, 03E6, 0232, 0230, 0231, 022F
2014	Town & Country / Caravan	ABS	●	●	●	●	●	●	●	
2014	Town & Country / Caravan	RBSS	●	●	●	●	●	○	○	
2014	Town & Country / Caravan	HSM	●	●	●	●	●	●	●	0412
2014	Town & Country / Caravan	ORC	●	●	●	●	●	○	●	
2014	Town & Country / Caravan	PSDML	●	●	●	●	●	○	○	
2014	Town & Country / Caravan	DMRR	●	●	●	●	●	●	●	
2014	Town & Country / Caravan	EPPM	●	●	●	●	●	○	●	
2014	Town & Country / Caravan	DMFL	●	●	●	●	●	●	●	
2014	Town & Country / Caravan	PTS	●	●	●	●	●	●	●	02ED, 03B7
2014	Town & Country / Caravan	DMRL	●	●	●	●	●	●	●	
2014	Town & Country / Caravan	VES3	●	●	●	●	●	●	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2014	Town & Country / Caravan	PSDMR	●	●	●	●	●	○	○	
2014	Town & Country / Caravan	RADIO	●	●	●	●	●	●	●	
2014	Town & Country / Caravan	CCN	●	●	●	●	●	●	●	
2014	Town & Country / Caravan	DMFR	●	●	●	●	●	●	●	
2014	Town & Country / Caravan	SUNR	●	●	●	●	●	●	○	
2014	Town & Country / Caravan	HIDT	●	●	●	●	●	●	○	
2014	Town & Country / Caravan	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2014	Town & Country / Caravan	DVD	●	●	●	●	●	○	○	
2014	Town & Country / Caravan	HVAC	●	●	●	●	●	●	●	
2014	Town & Country / Caravan	TCM	●	●	●	●	●	●	●	
2014	Town & Country / Caravan	MSMD	●	●	●	●	●	●	●	0452
2014	Town & Country / Caravan	PCM	●	●	●	●	●	●	●	02BA, 031D, 0126, 0411
2014	Town & Country / Caravan	SAS	●	●	●	●	○	○	○	
2014	Town & Country / Caravan	TIPMCGW	●	●	●	●	●	●	●	
2014	Town & Country / Caravan	FSM	●	●	●	●	●	●	○	
2014	Town & Country / Caravan	HFM	●	●	●	●	●	●	○	
2014	Town & Country / Caravan	AMP	●	●	●	●	●	○	●	
2014	Town & Country / Caravan	VES2	●	●	●	●	●	●	●	
2014	Town & Country / Caravan	LBSS	●	●	●	●	●	○	○	
2014	Town & Country / Caravan	AHBM	●	●	●	●	○	●	○	
2014	Town & Country / Caravan	ITM	●	●	●	●	●	●	●	
2014	ProMaster	ABS	●	●	●	●	●	○	●	
2014	ProMaster	HVAC	●	●	●	●	●	●	○	
2014	ProMaster	PAM	●	●	●	●	●	○	○	
2014	ProMaster	TPM	●	●	●	●	●	●	●	
2014	ProMaster	BCM	●	●	●	●	●	●	●	
2014	ProMaster	PCM	●	●	●	●	●	●	●	0126, 0411
2014	ProMaster	TCM	●	●	●	●	○	●	●	
2014	ProMaster	IPC	●	●	●	●	●	●	○	
2014	ProMaster	ETM	●	●	●	●	●	○	●	
2014	ProMaster	ORC	●	●	●	●	●	○	●	
2014	Durango (Post-2011)	PCM	●	●	●	●	●	●	●	0432, 042D, 031D, 0126, 0411
2014	Durango (Post-2011)	RFH	●	●	●	●	●	●	●	0442
2014	Durango (Post-2011)	PTS	●	●	●	●	●	●	●	02ED, 03B7
2014	Durango (Post-2011)	PLGM	●	●	●	●	●	●	○	
2014	Durango (Post-2011)	BCM	●	●	●	●	●	●	●	
2014	Durango (Post-2011)	ITM	●	●	●	●	●	●	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2014	Durango (Post-2011)	HVAC	●	●	●	●	●	●	●	
2014	Durango (Post-2011)	ORC	●	●	●	●	●	○	●	
2014	Durango (Post-2011)	DTCM	●	●	●	●	●	●	●	
2014	Durango (Post-2011)	ICS	●	●	●	●	●	●	○	
2014	Durango (Post-2011)	EDM	●	●	●	●	●	●	○	
2014	Durango (Post-2011)	EPS	●	●	●	●	●	○	○	
2014	Durango (Post-2011)	ELSD	●	●	●	●	●	●	○	
2014	Durango (Post-2011)	AMP	●	●	●	●	●	○	○	
2014	Durango (Post-2011)	VES2	●	●	●	●	●	●	○	
2014	Durango (Post-2011)	DDM	●	●	●	●	●	●	●	
2014	Durango (Post-2011)	HVACR	●	●	●	●	●	●	●	
2014	Durango (Post-2011)	HSM	●	●	●	●	●	●	●	
2014	Durango (Post-2011)	LBSS	●	●	●	○	●	○	○	
2014	Durango (Post-2011)	ACC	●	●	●	●	●	○	○	
2014	Durango (Post-2011)	VES3	●	●	●	●	●	●	○	
2014	Durango (Post-2011)	PDM	●	●	●	●	●	●	●	
2014	Durango (Post-2011)	ESM	●	●	●	●	●	○	○	
2014	Durango (Post-2011)	MSM	●	●	●	●	●	●	●	0452
2014	Durango (Post-2011)	SCCM	●	●	●	●	●	○	●	
2014	Durango (Post-2011)	IPC	●	●	●	●	●	●	●	
2014	Durango (Post-2011)	AHLM	●	●	●	●	●	○	○	
2014	Durango (Post-2011)	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2014	Durango (Post-2011)	ABS	●	●	●	●	●	●	●	
2014	Durango (Post-2011)	FFCM	●	●	●	●	●	○	○	
2014	Durango (Post-2011)	TCM	●	●	●	●	●	○	●	
2014	Durango (Post-2011)	RADIO	●	●	●	●	●	●	●	
2014	Durango (Post-2011)	RBSS	●	●	●	○	●	○	○	
2014	Grand Cherokee	VES3	●	●	●	●	●	●	○	
2014	Grand Cherokee	EDM	●	●	●	●	●	●	○	
2014	Grand Cherokee	ABS	●	●	●	●	●	●	●	
2014	Grand Cherokee	HVAC	●	●	●	●	●	●	●	
2014	Grand Cherokee	AFLS	●	●	●	●	●	●	●	
2014	Grand Cherokee	RFH	●	●	●	●	●	●	●	0442
2014	Grand Cherokee	ASCM	●	●	●	●	●	○	●	
2014	Grand Cherokee	PDM	●	●	●	●	●	●	●	
2014	Grand Cherokee	LBSS	●	●	●	○	●	○	○	
2014	Grand Cherokee	PCM	●	●	●	●	●	●	●	0126, 0411, 0432, 042D, 031D

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2014	Grand Cherokee	ORC	●	●	●	●	●	○	●	
2014	Grand Cherokee	PLGM	●	●	●	●	●	●	○	
2014	Grand Cherokee	TCM	●	●	●	●	●	○	●	
2014	Grand Cherokee	ACC	●	●	●	●	●	○	○	
2014	Grand Cherokee	SCCM	●	●	●	●	●	○	●	
2014	Grand Cherokee	BCM	●	●	●	●	●	●	●	
2014	Grand Cherokee	PTS	●	●	●	●	●	●	●	02ED, 03B7
2014	Grand Cherokee	ESM	●	●	●	●	●	○	○	
2014	Grand Cherokee	DTCM	●	●	●	●	●	●	●	
2014	Grand Cherokee	HSM	●	●	●	●	●	●	●	
2014	Grand Cherokee	MSM	●	●	●	●	●	●	●	0452
2014	Grand Cherokee	ADCM	●	●	●	●	●	○	○	
2014	Grand Cherokee	DDM	●	●	●	●	●	●	●	
2014	Grand Cherokee	AMP	●	●	●	●	●	○	○	
2014	Grand Cherokee	RADIO	●	●	●	●	●	●	●	
2014	Grand Cherokee	ICS	●	●	●	●	●	●	○	
2014	Grand Cherokee	EPS	●	●	●	●	●	○	○	
2014	Grand Cherokee	FFCM	●	●	●	●	●	○	○	
2014	Grand Cherokee	RBSS	●	●	●	○	●	○	○	
2014	Grand Cherokee	ELSD	●	●	●	●	●	●	○	
2014	Grand Cherokee	IPC	●	●	●	●	●	●	●	
2014	Grand Cherokee	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2014	Grand Cherokee	ITM	●	●	●	●	●	●	●	
2014	Grand Cherokee	VES2	●	●	●	●	●	●	○	
2014	Viper (Post-2013)	IPC	●	●	●	●	●	●	●	
2014	Viper (Post-2013)	OCM	●	●	●	●	●	○	○	
2014	Viper (Post-2013)	PDM	●	●	●	●	●	●	●	
2014	Viper (Post-2013)	ADCM	●	●	●	●	●	○	○	
2014	Viper (Post-2013)	ABS	●	●	●	●	●	●	●	
2014	Viper (Post-2013)	BCM	●	●	●	●	●	●	●	
2014	Viper (Post-2013)	RFH	●	●	●	●	●	●	●	0442
2014	Viper (Post-2013)	AMP	●	●	●	●	●	○	○	
2014	Viper (Post-2013)	ORC	●	●	●	●	●	●	●	
2014	Viper (Post-2013)	ICS	●	●	●	●	●	●	●	
2014	Viper (Post-2013)	TPM	●	●	●	●	●	○	●	0232, 0230, 0231, 022F
2014	Viper (Post-2013)	PCM	●	●	●	●	●	●	○	
2014	Viper (Post-2013)	HVAC	●	●	●	●	●	●	●	



YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2014	Viper (Post-2013)	RADIO	●	●	●	●	●	●	●	
2014	Viper (Post-2013)	DDM	●	●	●	●	●	●	●	
2014	Viper (Post-2013)	SCCM	●	●	●	●	●	○	○	
2015	Cherokee	DTCM	●	●	●	●	○	●	●	
2015	Cherokee	PTU	●	●	●	○	○	○	○	
2015	Cherokee	RBSS	●	●	●	●	●	○	●	
2015	Cherokee	AHLM	●	●	●	●	○	○	○	
2015	Cherokee	BCM	●	●	●	●	●	●	●	
2015	Cherokee	ICS	●	●	●	●	●	●	●	
2015	Cherokee	ABS	●	●	●	●	●	○	●	
2015	Cherokee	SCCM	●	●	●	●	●	●	○	
2015	Cherokee	EPS	●	●	●	●	●	○	○	
2015	Cherokee	PLGM	●	●	●	●	●	○	○	
2015	Cherokee	ACC	●	●	●	●	●	○	●	
2015	Cherokee	PDM	●	●	●	●	●	●	●	
2015	Cherokee	DDM	●	●	●	●	●	●	●	
2015	Cherokee	AMP	●	●	●	●	●	○	○	
2015	Cherokee	ESM	●	●	●	●	●	○	○	
2015	Cherokee	RADIO	●	●	●	●	●	●	●	
2015	Cherokee	PAM	●	●	●	●	●	●	●	
2015	Cherokee	CSWM	●	●	●	●	●	●	●	
2015	Cherokee	OCM	●	●	●	●	●	○	●	
2015	Cherokee	LBSS	●	●	●	●	●	○	●	
2015	Cherokee	MSM	●	●	●	●	●	○	○	
2015	Cherokee	ORC	●	●	●	●	●	●	●	
2015	Cherokee	IPC	●	●	●	●	●	●	○	
2015	Cherokee	HVAC	●	●	●	●	●	●	●	
2015	Cherokee	TCM	○	○	○	○	○	○	○	
2015	Cherokee	FFCM	●	●	●	●	●	○	●	
2015	Cherokee	PCM	●	●	●	●	●	●	●	0126, 0411
2015	Cherokee	EDM	●	●	●	○	○	●	○	
2015	Cherokee	RFH	●	●	●	●	●	●	●	
2015	Cherokee	RDM	●	●	●	○	○	○	○	
2015	Cherokee	EPB	●	●	●	●	●	○	●	

# Specil\_Function

Index	Specil Function Name	Index	Specil Function Name
C000	Catalyst Replaced	C01A	Bosch ECM Replaced
C001	Check PCM Odometer	C01B	Cummins ECM Replaced
C002	Check VIN	C01C	Display TPM Sensors IDs
C003	Clear DTCs	C01D	Enable/Disable TPM
C004	Clear PCM Batt Disconnect	C01E	Erase All Current Ign Keys
C005	EGR SYSTEM TEST	C01F	Erase FOB Only Keys
C006	ETC SYSTEM TEST	C020	Manual SKIM Functions
C007	ETC THROTTLE FOLLOWER TEST	C021	Manual SKREEM Functions
C008	GENERATOR FULL FIELD TEST	C022	PCM Replaced
C009	GOV 3 & 4 SHIFT VALVE TEST	C023	Program Ignition Key(s)
C00A	IAC WIGGLE TEST	C024	Program New FOB
C00B	INJECTOR KILL TEST	C025	Program Tire Sensor ID
C00C	LDP MONITOR TEST	C026	SKIM Key Test
C00D	LEAK DETECTION PUMP TEST	C027	SKIM Replaced
C00E	LINEAR IAC TEST	C028	SKREEM Replaced
C00F	Learn ETC	C029	TPM Sensors Test
C010	MINIMUM AIRFLOW Test	C02A	TPM Tire Pressures
C011	MISFIRE MONITOR TEST	C02B	TPM Trigger Module Test
C012	NVLD Forced Monitor Test	C02C	Tire Pressure Placard Values
C013	O2 HEATER TEST	C02D	Battery Disconnect
C014	PURGE VAPORS TEST	C02E	Clutch Test
C015	ReLearn Cam Crank	C02F	EATX TCM Has Been Changed
C016	Reset Memory	C030	Quicklearn
C017	SET RPM SYSTEM TEST	C031	Shift Lever
C018	Set Sync Signal	C032	TCC Break-In
C019	TORQUE CONV CLUTCH TEST	C033	Trans Overhauled/Replaced
0081	Reset ECU	0260	2 Prime Gear Clutch Test:RFE
0039	Accessory Time Delay	027C	2nd Gear Clutch Test:62TE
003C	Add Navigation Radio	0262	2nd Gear Clutch Test:NonRFE
003D	Change Country Code	0261	2nd Gear Clutch Test:RFE
0032	Disable Radio Clock Display	027D	3rd Gear Clutch Test:62TE
003F	Enable DRL	0264	3rd Gear Clutch Test:NonRFE
003E	Enable Front Fog Lamp Output	0263	3rd Gear Clutch Test:RFE
0036	Flash Hazard Lamps On Lock	02F8	4th Gear Clutch Test:62TE
0037	Headlamps Delay Time	0140	ESIM Forced Monitor Test
0035	Headlamps On With Wipers	027E	Reverse Gear Clutch Test:62TE
0034	Horn Chirp Duration	0266	Reverse Gear Clutch Test:NonRFE
0038	Illuminated Entry Time	0265	Reverse Gear Clutch Test:RFE
003A	Program Network Configuration	02FB	SRV Test
0033	Sound Horn On Lock	0281	Neutral Gate Test:NOT_RFE
0040	Trailer Tow Relay Outputs	0280	Neutral Gate Test:RFE
00EA	Actuator Calibration Test	0176	Overdrive Switch Test
00E8	Actuator DTC Detection	024E	Overdrive Switch Test:RFE
0378	ATC Data Display	016F	Quick Learn:RFE
00E9	Cool Down Test	0269	TCC BreakIn
0324	Rear AC and Rear Wiper Wash Data Display	01FC	Thermistor Test
0117	Key Fobs Linked to Memory Feature	802A	Software Reset Module
002F	Bleed Brakes ABS only	802B	Hardware Reset Module
002E	Program Tire Size	01F6	Enable or Disable Mobile PTO
0030	Bleed Brakes 2WD	0291	3rd Gear Clutch Test:68RFE
0031	Bleed Brakes 4WD	0290	Direct Gear Clutch Test:68RFE
0127	EGR System Test	01FB	Quick Learn:Non-RFE
0126	ETC Throttle Follower Test	033D	Aisin Trans Data
0044	Injector Kill System Test	017B	Enable / Disable Vehicle Features:cc
0129	NVLD Forced Monitor Test	0292	Enable / Disable Vehicle Features:pu
026C	O2 Heater System Test:1bank	0276	Mobile DeSoot - Minimum Required Soot Load
026D	O2 Heater System Test:2bank	0277	Mobile DeSoot - No Minimum Required Soot Load
0128	Purge Vapors System Test	033B	Mobile DeSoot - No Minimum Required Soot Load_Var03
012E	Set RPM Test - ETC Equipped	033C	Mobile DeSoot - No Minimum Required Soot Load_Var05
012F	Set RPM Test - non - ETC Equipped	017A	Reset Aftertreatment Trip Information
012C	Check PCM Odometer	0178	Reset NOx Adsorber Counts

Index	Specil Function Name	Index	Specil Function Name
012D	Check PCM VIN	0179	Reset Pressure limiting Valve Accumulators
0173	FCM Enable Emissions Rolls Test Mode	0278	Reset Regenerative Filter Timers
012A	Learn ETC	033A	VIEW/RESET DUTY CYCLE ACCUMULATORS:03
012B	Reset Memory	0303	AMP Tone Test with volume control
013B	TIPM Enable Emissions Rolls Test Mode	00D5	HB and HG:Enable DRL
01D2	Erase All Ignition Keys	00D8	HB and HG:Program Tire Size
0228	PCM Replaced	00DB	ND:Enable Cruise Control
0226	Program Ignition Keys or Key FOBs:RKEONLY	00D6	ND:Enable DRL
0225	Program Ignition Keys or Key FOBs:SKIM	00D9	ND:Program Tire Size
0227	WCM Replaced	00DA	WK and XK:Program Tire Size
008C	CCN Self Test	0272	WK:Enable DRL
008F	Auto Door Lock	0273	XK:Enable DRL
008E	Auto Door Unlock	0323	IR Sensor Data
0091	Change Measurement Units	0317	Smart Bar Motor Self Test
008D	Disable Seatbelt Minder Chime	0318	Sway Bar Telltale Fast Blink Actuator
0090	Unlock Driver Door On 1st Press	031A	Sway Bar Telltale Off Actuator
0167	1st Gear Clutch Test:FWD	031B	Sway Bar Telltale On Actuator
0166	1st Gear Clutch Test:RWD	0319	Sway Bar Telltale Slow Blink Actuator
01EE	2 Prime Gear Clutch Test	02BA	Diesel Particulate Filter Replacement
016A	2nd Gear Clutch Test:FWD	02B9	Differential Pressure Sensor Replacement
0169	2nd Gear Clutch Test:RWD	02BF	Display Diesel Particulate Filter Values
016C	3rd Gear Clutch Test:FWD	02BD	ECU Replacement With Value Transfer
016B	3rd Gear Clutch Test:RWD	02BE	ECU Replacement Without Value Transfer
016E	Reverse Gear Clutch Test:FWD	02BC	Emission-Relevant Component Replacement
016D	Reverse Gear Clutch Test:RWD	0144	Program Variant Code
01F0	Shift Lever Position Test:NON RFE	02C0	Reset Inhibiting Timer
0172	Shift Lever Position Test:RFE	02BB	Reset Mass Airflow Values
0177	Clear Variable Line Pressure (VLP) Counters	031D	Service Diesel Particulate Filter Regeneration
0170	Quick Learn:NOT RFE	02C1	Set Oil Dilution Mass Value
0175	TCC Break-In	02C2	View Oil Dilution Mass Value
0289	AMP Channel Output Channel Test:6 Channel	0219	Auto Wipers
028A	AMP Channel Output Channel Test:8 Channel	021E	Program Tire Size:JK
006D	AMP Input Test	021F	Program Tire Size:KA
006B	AMP Mute Channel:6 Channel	021D	Unlock All Doors 1st Press
006C	AMP Mute Channel:8 Channel	0288	Actuator Calibration Front Only
0068	AMP Software Test	0287	Actuator Calibration w/Rear
006A	AMP Tone Test	00EC	HVAC Self Test
011E	OCM System Verification Test	02E7	Downstream O2 Response Monitor
013C	Cam Crank Relearn	013E	ETC System Test
01F1	Clear Variable Line Pressure (VLP)	0314	Adaptive Numerator Learn
01EF	Quick Learn	0310	Cruise Control Data
01F4	Initialize EGS-52	03A3	Flexible Oil Change Indicator Reset
01F3	Reset Learned Adaptives	03A4	Set Oil Type
01F2	Store Learned Adaptives	0064	ACC Cutout Reasons Clear
005A	Cycle Stop Lamp Relay	0065	Align ACC Sensor
0058	Bleed Brakes:LX	02CE	Change Cruise Control Mode
0059	Bleed Brakes:WK	0067	AHBM Self Test
005E	Initialize ABS Module	01F5	CVT Initialization
005C	Initialize ESP Module:LX	0012	Learn Motor
005D	Initialize ESP Module:WK	02D6	Modulator Solenoid Test
005F	Initialize ESP Module:WK-Non ESP	02D7	Shift Pressure Solenoid Test
005B	Initialize Steering Angle Sensor	02D4	TCC Solenoid Test
0094	Language Preference	02D5	Transmission Shift Solenoids Test
00C4	Enable Cruise Control	0018	TCM Reset Learned Adaptives
0002	Bleed Brakes	0014	ORC Initialize ECU
0232	Program Left Front Tire Sensor ID	0013	Reset ORC
0230	Program Left Rear Tire Sensor ID	02CF	Sensors:Bussed Inputs:and Bussed Outputs
0231	Program Right Front Tire Sensor ID	032D	Activate/Deactivate Cruise Control
022F	Program Right Rear Tire Sensor ID	0001	Calibrate G-Sensor
01DE	Program Spare Tire Sensor ID	0003	Drive Test
022D	Update Pressure Thresholds	029F	Calibrate AHLM
0274	WCM Replaced Non TPM	02D0	Verify Front TPM Antenna
0373	Program Tire Size for EATX	02D1	Verify Rear TPM Antenna
0374	Program Tire Size for EGS 52	001A	Left Front Tire Pressure Signal Transmission Test
0097	CCN Gauge Test	001B	Left Rear Tire Pressure Signal Transmission Test

Index	Specil Function Name	Index	Specil Function Name
0042	Compression Test	001C	Right Front Tire Pressure Signal Transmission Test
0149	Cylinder Balance Test	001D	Right Rear Tire Pressure Signal Transmission Test
0142	Cylinder Fuel Quantity Correction Test	0247	Tire Pressure ECU Replacement with Manual Initialization
0145	Set RPM System Test	004E	View Electronic TPM ID
014B	Exhaust Throttle Plate Adaptive Learn Position	0004	AEHM Actuate Heater Booster
014A	Fuel Mean Value Adaptation Initialization	002C	Erase All Keys and Program New Ignition Key FOB
0148	IMA Rapid Calibration	002B	Program New Ignition Key FOB
0049	Injector Quantity Adjustment	002A	Replace Steering Column Lock
0146	NOx Catalyst(New) Initialization	0007	CCN Display Dimmer Test
0147	NOx Catalyst(Used) Learning	0008	CCN LCD Display Test
0066	Aim Test	0005	Gauge Sweep Test
0156	CYLINDER PERFORMANCE TEST - Automatic Transmission	0334	Pushbutton Test
0157	CYLINDER PERFORMANCE TEST - Manual Transmission	0006	Speaker Test
0154	FUEL PRESSURE OVERRIDE - Automatic Transmission	032F	Customer Programmable- Clock
0155	FUEL PRESSURE OVERRIDE - Manual Transmission	0330	Customer Programmable- Daytime Running Lamps
0141	GENERATOR FULL FIELD TEST	0331	Customer Programmable- Language
0150	Set RPM System Test - Automatic Transmission	0332	Customer Programmable- Speedometer/Odometer Units
0151	Set RPM System Test - Manual Transmission	0333	Customer Programmable- Temperature
0153	TORQUE CONVERTER CLUTCH TEST	0009	Oil Change Reset
015A	TVA AUTO ZERO TEST	000A	Personalize with Electronic Ignition Switch
0159	TVA SPAN TEST	032E	Update Service Interval
0158	IDLE UP FEATURE ENABLE	0337	Set High Idle Allowed Speeds
014F	VIEW/RESET DUTY CYCLE ACCUMULATORS	001E	Check/Write VIN
0152	VIEW/RESET TRIP INFORMATION ACCUMULATORS	0023	Engine ECU Replaced (Drive Authorization)
0242	DR WCM Replaced SCI	0043	Exhaust Throttle Plate Adaptive Learn
023F	PCM Replaced SRT-10 Only	026E	Mass Air Flow Sensor Initialization
0233	TPM Trigger Module Test	026F	Rail Pressure Initialization
0241	WCM Gateway Replaced	0336	Set Maximum Vehicle Speed
023D	WCM Replaced 1	0025	O2 Sensor Monitor Test
023E	WCM Replaced 2	0024	Camshaft Reference Adaptation
0271	WCM Replaced Not Var 5 non TPM	0022	Fuel Pump Activation
0270	WCM Replaced Var 5 non TPM	0020	Reset Adaptive Memory
0285	Initialize ABS Non ESP	0021	Throttle Valve Initialization
0062	Initialize ESP Sensor	8001	TPM Train Tires
028D	AMP Channel Output Channel Test:No Channel 7	8002	Stop Tire Training
027F	AMP Mute Channel:No Channel 7	8070	Oil Change
00EB	Actuator Calibration Test DR	817D	RESET OIL CHANGE
0214	Combined Rear Lighting	033F	TPM Trigger Module Test DH
0210	DR Restore Customer Preference	02DE	Update Heavy Load Pressure Thresholds
020E	Program Tire Size:DR	02DF	Update Light Load Pressure Thresholds
0213	Program Tire Size:JS	02F1	View Last Successful Remote Start Event Data
0215	Program Tire Size:PM or MK	02F0	View Remote Start Abort Data
028F	Program Tire Size:PM or MK No TCM	02F3	View Remote Start Enable Data
0211	PT Restore Customer Preference	02EF	View Remote Start Inhibit Data
00C6	Tip Start Override	02A6	Clear Last Successful Remote Start
0069	AMP Channel Output Channel Test	02A5	Clear Remote Start Abort Reasons
0079	AMP Multiple Mute Channel	02A4	Clear Remote Start Inhibit Reasons
02F6	AMP Tone Test without volume control	0293	Remote Start Override
010E	OCM System Verification Test	0313	DPF Replacement
801A	Reset Module	0312	ECM Replacement
8023	Original VIN Read	0311	Manual DPF Regeneration
8024	Current VIN Read	02E3	Program Tire Size:JC
8003	WCM Replaced - Gas	0122	Rollover Detection
8004	PCM Replaced - Gas	01DA	WCM TPM Sensor Test
8005	WCM Replaced - Diesel	0245	WIN Replaced
8006	PCM Replaced - Diesel	02E2	Program Tire Size:KK
8007	Erase Key FOBs Only	0315	Location of the Learned Keys by PEM Verification Test
80DD	Erase All Ignition Keys	02F7	TPM Sensor Test
800D	Program Ignition Keys	0321	ACC Exit In-Plant Mode
8008	Program Key FOBs	02AD	OCM Rezero Procedure
8009	View SKREEM VIN	0325	LDP Forced Monitor Test
800A	View SKREEM Country Code	0193	Leak detection pump test
800B	Reset SKREEM	0326	View Adaptive Numerator Status

Index	Specil Function Name	Index	Specil Function Name
800C	Enable Disable TPM	037A	EVR Enable/Disable
01DE	Program Spare Tire Sensor ID	0379	PTO RPM Adjustment
800E	WCM Trigger Module Test	02F9	Exhaust Phaser 1 Cleaning
01DA	WCM TPM Sensor Test	0304	Engine On Odometer
008C	CCN Self Test	02FA	New Engine Installed
804F	Configure Cluster	02EA	First Pass Cool Down Test Results
8050	Clear Learned Features	02EB	Most Recent Cool Down Test Results
8051	Seatbelt Alert System 2007	02E9	AC Cool Down Test
8052	Seatbelt Alert System 2006	02A1	Initialize ORC
8018	Horn Chirp	018D	Check Vin
8017	Optical Horn Chirp	0360	Replace TCM
8015	Rolling Door Locks	035B	Shift Lever Position Test
8057	RKE Unlock Sequence	035C	Trans Adapts Reset Trigger
8012	Enable VTSS	035D	Trans Fast Learn Trigger
806F	Enable DRL	035E	Trans Line Pressure
8073	Program Tire Size	035F	Transmission Cleaning Procedure
8158	Update Model Year to 2007	035A	Abs System Calibration
0073	AMP Mute Channel:7 Channel	03BB	Vacuum Pump Rezero
028B	AMP Channel Output Channel Test:7 Channel	03BE	Regen Brake Control
0045	Diesel Particulate Filter (New) Initialization	034A	Aux Heater Coolant Pump Temp Test
0046	Diesel Particulate Filter (Used) Learning	034B	EVAP Temp Target Speed
014D	Manual Diesel Particulate Filter Regeneration	02A7	Antenna Loop Test
00C8	Police VTA	03C8	Oil Change Monitor Type
00C9	Program Tire Size:ND	0309	Location of the Learned Keys
0060	Initialize ESP Module:PT	031E	WCM Replaced SK 3101DFF0 Non TPM
0092	Measurement Unit	031F	WCM Replaced SK 3101DFF0 TPM
0096	Seatbelt Alert System	037C	WCM Replaced TPM
028E	Program Tire Size:PT No TCM	03E1	Injector Circuit Test
0240	PCM Replaced 1.6L Only	03DA	Injector Accelerated Drift Learn
0243	PT WCM Replaced SCI	03D8	Throttle Valve Learn
0099	Service Interval - Diesel	03E6	Program Ignition Keys or Key FOBs
0098	Service Interval - Gas	0411	Injector Kill Test
007E	Enable FCM/IPM Diagnostics	0412	Heated Steering Wheel Configuration
007D	Program Tire Size:CS	0432	Reset Oil Change Indicator
027B	1st Gear Clutch Test:62TE	042D	Reset Zero Fuel Quantity Calibration
025F	1st Gear Clutch Test:NonRFE	0442	Locate Learned Keys
025E	1st Gear Clutch Test:RFE	0452	Key Fobs Linked to Memory
		0476	Program Tire Size/Pinion Factor