

MaxiDas_Great Wall_V5. 10 Function List (Note:For reference only)

Note:

- indicates the function is supported. ** indicates the function may be supported according to actual vehicle conditions.
- O indicates the function is not available. A indicates the function is newly added to the latest version.

Refer to the Special Function List for details.

Mode1	System	ECU	Version Info.	Read DTCs	Clear	Read DataStream	Read Freeze Frame	Active Test	Special Function
Haval H3	Engine System	Delphi MT20U2 EOBD Engine System	•	•	•	•	•	•	
Haval H3	Engine System	BOSCH V50 Diesel Engine System	•	•		•	•	•	
Haval H3	Engine System	Delphi System (MT20U)	0	•		•	0	•	
Haval H3	Engine System	BOSCH EDC16 Diesel Engine System	0	•	•	•	0	•	0001 0002 0003 0004 0005
Haval H3	Engine System	Liaoning Xinfeng Electronic Control	•	•	•	•	0	0	0011 0015 0021
Haval H3	ABS	Great Wall (Haval, Wingle) ABS	•	•	•	•	0	•	
Haval H3	Airbag System	JinZhou Jinheng Airbag	•	•	•	•	0	0	
Haval H3	Airbag System	BOSCH Airbag	•	•	•	•	0	0	
Haval H3	Airbag System	Tianhe Airbag	•	•	•	•	0	0	
Haval H3	Airbag System	Continental Airbag System	•	•	•	0	0	•	
Haval H3	Immobilizer System	Delphi Immobilizer System (Cowry, Haval Petrol)	•	•	•	•	0	0	0022 0023
Haval H3	Immobilizer System	Delphi Immobilizer System (Wingle, Haval Diesel)	•	•	•	•	0	0	0022 0023
Haval H3	Body Control	Delphi Body Control System		•		•	0		0016 0017 0018 0019 0020
Haval H3	Body Control	Tung Thih Body Control System	•	•		•	0		0042 0018 0029
GWPeri, Haval M1	Engine System	GW413EF UAES EOBD Engine System	•			•	•	•	
GWPeri, Haval M1	Engine System	UAES M797 System	•	•	•	•	•	•	
GWPeri, Haval M1	ABS	Great Wall (Haval, Wingle) ABS	•			•	0	•	
GWPeri, Haval M1	ABS	GWPeri ABS	•			•	0	•	
GWPeri, Haval M1	Airbag System	JinZhou Jinheng Airbag	•	•	•	•	0	0	
GWPeri, Haval M1	Immobilizer System	STEC Immobilizer System	•	•	•	•	0	0	
GWPeri, Haval M1	Immobilizer System	GWPeri Immobilizer System	•	•	•	•	0	•	0024 0025
Cowry, Great Wall	Engine System	Delphi System (MT20U2)	0	•	•	•	0	•	
Cowry, Great Wall	Engine System	Delphi MT80 Engine	•	•		•	0	•	
Cowry, Great Wall	Engine System	UAES 1.5T Engine System	•	•	•	•	•	•	
Cowry, Great Wall	ABS	Great Wall (Haval, Wingle) ABS	•	•	•	•	0	•	
Cowry, Great Wall	ABS	BOSCH ABS8(K LINE)	•	•	•	•	0	•	
Cowry, Great Wall	Airbag System	JinZhou Jinheng Airbag	•	•	•	•	0	0	
Cowry, Great Wall	Airbag System	GWPeri, Cowry Airbag System	•	•	•	•	0	0	
Cowry, Great Wall 780	Immobilizer System	Delphi Immobilizer System (Cowry, Haval Petrol)	•	•	•	•	0	0	
Cowry, Great Wall V80	Auto Transmission System	Hyundai Mobis_P4FI_AT System	•	•	•	•	0	•	
Vingle	Engine System	Delphi MT20U2 EOBD Engine System	•	•	•	•	•	•	
Vingle	Engine System	BOSCH V50 Diesel Engine System	•	•	•	•	•	•	
Vingle		UAES EURO IV System	•	•	•	•	•	•	
Wingle	Engine System	4D20 Delphi EURO V Engine System	•			•	0	•	

Mode1	System	ECU	Version Info.	Read DTCs	Clear DTCs	Read DataStream	Read Freeze Frame	Active Test	Special Function
Wingle	Engine System	Liaoning Xinfeng Electronic Control System	•	•	•	•	0	0	0011 0015 0021
Wingle	Engine System	4D20 BOSCH Diesel Engine System	•	•	•	•	0	•	
	Engine System	4D20 Delphi Electronic Control System	•	•	•	•	0	•	0026 0027 0029
Wingle	ABS	BOSCH ABS	•	•	•	•	0	•	0013
Wingle	ABS	BOSCH ABS (CAN)	•	•	•	•	0	•	0040 0067 0056
Wingle	Airbag System	JinZhou Jinheng Airbag	•	•	•	•	0	0	
Wingle	Immobilizer System	Delphi Immobilizer System (Cowry, Haval Petrol)	•	•	•	•	0	0	0022 0023
Wingle	Immobilizer System	Delphi Immobilizer System (Wingle, Haval Diesel)	•	•	•	•	0	0	0022 0023
Wingle	Immobilizer System	Delphi Diesel (Delphi 4D20) Immobilizer System	•	•	•	•	0	0	0043 0044 0045 0016 0046 0047 0048 0022
Wingle	Immobilizer System	Delphi Diesel (BOSCH 4D20) Immobilizer System	•	•	•	•	0	0	0043 0044 0045 0016 0046 0047 0048 0022
Wingle	Immobilizer System	Delphi Gasoline Immobilizer System(UAES)	0	•	•	•	0	0	
Florid, M4	Engine System	UAES M797 System	•	•	•	•	•	•	
Florid, M4	Engine System	Siemens Engine System	•	•	•	•	•	•	
Florid, M4	Engine System	Delphi EOBD Electronic Control Unit		•		•	•		
Florid, M4	ABS	BOSCH ABS	•	•		•	0	•	0013
Florid, M4	ABS	Great Wall (Haval, Wingle) ABS				•	0		
Florid, M4	ABS	Tianhe ABS				•	0		0013
Florid, M4	Airbag System	AUTOLIV Airbag	•	•		•	0	0	
Florid, M4	Airbag System	CHO41 AUTOLIV Airbag				•	0	0	
Florid, M4	Immobilizer System	STEC Immobilizer System				•	0	0	
Florid, M4	Auto Transmission System	Punch_VT2_CVT System	•	•	•	•	0	0	0049
Florid, M4	Auto Transmission System	Auto Transmission (AMT)	•	•	•	•	•	0	
	Engine System	UAES II Electronic Control Unit	•	•	•	•	•	•	
		UAES M797 System	•	•	•	•	•	•	
	ABS	BOSCH ABS	•	•	•	•	0	•	0013
Cool Bear, Haval M2	ABS	Tianhe ABS	•	•	•	•	0	•	0013
	Auto Transmission System	Punch_VT2_CVT System	•	•	•	•	0	0	0049
Cool Bear, Haval M2	Auto Transmission System	Auto Transmission (AMT)	•	•	•	•	•	0	
Cool Bear, Haval M2	Airbag System	AUTOLIV Airbag	•	•	•	•	0	0	
Cool Bear, Haval M2	Airbag System	JinZhou Jinheng Airbag		•	•	•	0	0	
Cool Bear, Haval M2	Immobilizer System	DIAS Immobilizer System		•	•	•	0	•	
Lingao, Great Wall C20R		UAES M797 System	•	•	•	•	•	•	
Lingao,Great Wall C20R	Engine System	Siemens Engine System	•	•	•	•	•	•	
Lingae Creet Well	Engine System	UAES EURO V Engine System(CAN)	•	•	•	•	0	•	

Model	System	ECU	Version Info.	Read DTCs	Clear DTCs	Read DataStream	Read Freeze Frame	Active Test	Special Function
C20R	Engine System	UAES Engine (CAN)	•	•	•	•	0	•	0015
Lingao,Great Wall C20R	ABS	BOSCH ABS	•	•	•	•	0	•	0013
Lingao,Great Wall C20R	ABS	Tianhe ABS	•	•	•	•	0	•	0013
Lingao,Great Wall C20R	ABS	BOSCH ESP System	•	•	•	0	0	•	0040 0029 0013 0053
Lingao,Great Wall C20R	ABS	BOSCH ABS9 System	•	•	•	•	•	•	0056 0057
CZUR	Airbag System	AUTOLIV Airbag	•	•	•	•	0	0	
CZUR	Airbag System	CHO41 AUTOLIV Airbag	•	•	•	•	0	0	
Lingao,Great Wall C20R		STEC Immobilizer System	•	•	•	•	0	0	
C20R	System	Punch_VT2_CVT System	•	•	•	•	0	0	0049
C20R	Auto Transmission System	Auto Transmission (AMT)	•	•	•	•	0	0	
C20R	Electric Power Steering System	Yubei EPS System	•	•	•	•	0	0	
Great Wall C30	Engine System	UAES M797 System	•			•	•		
Great Wall C30	Engine System	Siemens Engine System	•	•	•	•	•		
Great Wall C30	Engine System	UAES Start-Stop Engine System	•		•	•			0031 0032 0033 0034 0035
Great Wall C30	Engine System	UAES Engine (New Vision)					0		0015 0066
Great Wall C30	Engine System	UAES Engine (CAN)					0		0015 0066
Great Wall C30	ABS	Great Wall (Haval, Wingle) ABS	•	•		•	0	•	
Great Wall C30	ABS	Tianhe ABS	•	•	•	•	0	•	0013
Great Wall C30	ABS	BOSCH ABS8 (K LINE)	•	•	•	•	0	•	
Great Wall C30	ABS	Bosch ABS (ESP) System (CAN)	A	A	A	A	0	A	0029 0056 0040 0053 0067
Great Wall C30	Airbag System	AUTOLIV Airbag	•	•	•	•	0	0	
Great Wall C30		CHO41 AUTOLIV Airbag	•	•	•	•	0	0	
Great Wall C30		STEC Immobilizer System	•	•	•	•	0	0	
Great Wall C30	Auto Transmission	Punch_VT2_CVT System	•	•	•	•	0	0	0049
K-roat Wall (30)	A T	Auto Transmission (AMT)	•	•	•	•	•	0	
Great Wall C30	Auto Transmission System	GETRAG AMT (UAES)	A	A	A	A	0	A	0015 0050 0072 0073
Great Wall C30	Instrument Panel System	Delco	A	A	A	A	0	0	0030 0076
Great Wall C30	Instrument Panel System	STEC	A	A	A	A	0	A	
Haval H5	Engine System	4D20 Delphi Electronic Control System	•	•	•	•	0	•	0026 0027 0029
Haval H5	Engine System	4D20 BOSCH Diesel Engine System	•	•	•	•	0	•	

Mode1	System	ECU	Version Info.	Read DTCs	Clear DTCs	Read DataStream	Read Freeze Frame	Active Test	Special Function
Haval H5	Engine System	BOSCH V50 Diesel Engine System	•	•	•	•	•		0011
Haval H5	Engine System	UAES M797 System		•		•	•		
Haval H5	Engine System	Delphi MT20U2 EOBD Engine System		•		•	•		
Haval H5	Engine System	4G63T Engine System	•	•	•	•	0	•	0015 0051 0066
Haval H5	ABS	BOSCH ABS9 ESP System		•		0	0		0040 0029 0013 0053
Haval H5	ABS	Bosch ABS	•	•	•	•	0	•	
Haval H5	ABS	BOSCH ABS (CAN)		•		•	0	0	0056 0040 0053 0067 0074
Haval H5	Airbag System	BOSCH Airbag		•		•	0	0	0029
Haval H5	Airbag System	Bosch Airbag System		•		•	0	0	
Haval H5	Airbag System	Continental Airbag System		•			0		
Haval H5	Airbag System	Tianhe Airbag	•	•	•	•	0	0	
Haval H5	Body Control	Delphi Body Control System (CAN)		•		•	0	•	
Haval H5	Body Control	Delphi Body Control System		•		•	0	•	0026 0027 0029
Haval H5	Body Control	Tung Thih Body Control System	•	•		•	0	•	0042 0018 0029
Haval H5	Immobilizer System	Delphi Immobilizer System (Cowry, Haval Petrol)	•	•	•	•	0	0	
Haval H5	Immobilizer System	Delphi Immobilizer System (Wingle, Haval Diesel)	•	•	•	•	0	0	
Haval H5	Immobilizer System	Delphi Diesel (Delphi 4D20) Immobilizer System	•	•	•	•	0	0	0043 0044 0045 0016 0046 0047 0048 0022
Haval H5	Immobilizer System	Delphi Diesel (BOSCH 4D20) Immobilizer System	•	•	•	•	0	0	0043 0044 0045 0016 0046 0047 0048 0022
Haval H5	Instrument System	Continental Instrument System (CAN)	•	•	•	•	0	•	0029
Haval H5	Transmission	Hyundai Mobis 5R35 AT System		•		•	0		
Haval H5	TOD	Borgwarner TOD System (Intelligent 4WD)	•	•	•	•	0	•	0029
Pickup and early models (Sailing, Di'er, Saic ool, Saijun, Saiving)	Engine System	Delphi Electronic Control Unit	•	•	•	•	0	•	
Pickup and early models (Sailing, Di'er, Saic ool, Saijun, Saiving)	Engine System	Aerospace Mitsubishi Electronic Control System	•	•	•	•	0	•	
Pickup and early models (Sailing, Di'er, Saic ool, Saijun, Saiving)	Engine System	UAES II Electronic Control Unit	•	•	•	•	•	•	
Pickup and early models (Sailing, Di'er, Saic ool, Saiiun, Saiving)	Engine System	UAES M797 System	•	•	•	•	•	•	
Pickup and early models (Sailing, Di'er, Saic ool, Saijun, Saiving)	Engine System	BOSCH V50 Diesel Engine System	•	•	•	•	•	•	

Mode1	System	ECU	Version Info.		Clear DTCs	Read DataStream	Read Freeze Frame	Active Test	Special Function
Pickup and early models (Sailing, Di'er, Saic ool, Saiiun, Saiving)	Engine System	GW413EF UAES EOBD Engine System	•	•	•	•	•	•	
Pickup and early models (Sailing, Di'er, Saic ool, Saiiun, Saiving)	Engine System	Delphi MT80 Engine	•	•	•	•	0	•	
Pickup and early models (Sailing, Di'er, Saic ool.Saiiun, Saiving)	Engine System	Delphi System (MT20U)	0	•	•	•	0	•	
Pickup and early models (Sailing,Di'er,Saic ool.Saiiun.Saiving)	Engine System	Delphi EOBD Electronic Control Unit	•	•	•	•	•	•	
(Sailing, Di er, Saic ool, Saijun, Saiving)	Engine System	UAES Electronic Control System	•	•	•	•	0	•	0007 0008 0009
Pickup and early models (Sailing,Di'er,Saic ool.Saiiun,Saiving)	Engine System	BOSCH EDC16 Diesel Engine System	0	•	•	•	0	•	0001 0002 0003 0004 0005 0006
Pickup and early models (Sailing,Di'er,Saic ool.Saiiun.Saiving)		4L88 Engine EGR System	0	•	0	•	0	•	0010
(Sailing, Di'er, Saic ool, Saijun, Saiving)		Magneti Marelli Single Point System	•	•	•	•	0	•	
Pickup and early models (Sailing,Di'er,Saic ool,Saiiun,Saiving)	ABS	Great Wall (Haval,Wingle) ABS	•	•	•	•	0	•	
Pickup and early models (Sailing, Di'er, Saic ool, Saiiun, Saiving)	ABS	GWPeri ABS	•	•	•	•	0	•	
(Sailing, Di'er, Saic ool, Saijun, Saiving)	Airbag System	Great Wall Haval Airbag System	•	•	•	•	0	0	
Pickup and early models (Sailing, Di'er, Saic ool, Saijun, Saiving)		Great Wall Wingle Airbag System	•	•	•	•	0	0	

Mode1	System	ECU	Version Info.	Read DTCs	Clear DTCs	Read DataStream	Read Freeze Frame	Active Test	Special Function
(Sailing, Di'er, Saic ool, Saijun, Saiving)	Airbag System	GWPeri,Cowry Airbag System	•	•	•	•	0	0	
(Sailing, Di'er, Saic ool, Saijun, Saiving)	Airbag System	BOSCH Airbag	•	•	•	•	0	0	
Pickup and early models (Sailing, Di'er, Saic ool, Saiiun, Saiving)	Airbag System	AUTOLIV Airbag	•	•	•	•	0	0	
Pickup and early models (Sailing, Di'er, Saic ool, Saijun, Saiving)	Auto Transmission System	Great Wall Auto Transmission System	0	•	•	•	0	0	
Pickup and early	Auto Transmission System	Siemens Transmission	•	•	•	•	0	•	
Pickup and early models (Sailing, Di'er, Saic ool, Saijun, Saiving)	Immobilizer System	Delphi Immobilizer System (Cowry, Haval Petrol)	•	•	•	•	0	0	
Pickup and early models (Sailing, Di'er, Saic ool, Saijun, Saiving)	Immobilizer System	Delphi Immobilizer System (Wingle, Haval Diesel)	•	•	•	•	0	0	
Pickup and early models (Sailing, Di'er, Saic ool, Saijun, Saiving)	Immobilizer System	GWPeri Immobilizer System	•	•	•	•	0	•	
Haval H6-2012	Engine System	Delphi MT80 Engine System	•	•	•	•	0	•	0015
Haval H6-2012		Delphi MT20U2 EOBD Engine System	•	•	•	•	•	•	
Haval H6-2012	Engine System	4D20 Delphi Electronic Control System	•	•	•	•	0	•	0026 0027 0029
Haval H6-2012		Delphi 4D20 EURO V Engine System	•	•	•	•	0	•	
Haval H6-2012		4G15T Engine Electronic Control System	•	•	•	•	0	•	
Haval H6-2012	Engine System	4D20 BOSCH Diesel Engine System	•	•	•	•	0	•	
Haval H6-2012	ABS	BOSCH ABS	•	•	•	•	0	•	0027 0029 0040 0013
Haval H6-2012	ABS	BOSCH ABS9 ESP System	•	•	•	•	0	•	0027 0029 0040 0013 0053
Haval H6-2012	Airbag System	Airbag System	•	•	•	0	0	0	0028 0030
Haval H6-2012		Delphi Body Control System	•	•	•	•	0	•	0026 0027 0029
Haval H6-2012		UAES Body Control System	•	•	•	•	0	•	0029 0042 0055 0019
Haval H6-2012		SDE Instrument Control System	0	•	•	0	0	•	
Haval H6-2012		Tung Thih Immobilizer System	•	•	•	•	0	1	0014
Haval H6-2012	Immobilizer System	STEC Immobilizer System	•			•	0	0	

Model	System	ECU	Version Info.	Read DTCs	Clear DTCs	Read DataStream	Read Freeze Frame	Active Test	Special Function
Haval H6-2012	TOD	Borgwarner TOD System(2012)	•	•	•	•	0		0027 0029
Haval H6-2012	Auto Transmission	Hyundai Mobis P4MFI AT System	•	•	•	•	0	•	
Haval H6-2013	Engine System	Delphi MT80 Engine System	•			•	0	•	0015
Haval H6-2013	Engine System	Delphi MT20U2 EOBD Engine System				•	•		
Haval H6-2013	Engine System	Delphi 4D20 EURO V Engine System				•	0		
Haval H6-2013	Engine System	4G15T Engine Electronic Control System	•	•	•	•	0	•	
Haval H6-2013	Engine System	4D20 BOSCH Diesel Engine System	•	•	•	•	0	•	
Haval H6-2013	ABS	BOSCH ABS9 ESP System	•	•	•	•	0	•	0040 0029 0013 0053
Haval H6-2013	Airbag System	Airbag System	•	•	•	0	0	0	
Haval H6-2013		PEPS System	•	•	•	•	0	•	0068
Haval H6-2013	Body Control	Delphi Body Control System	•	•	•	•	0	•	0019 0055
Haval H6-2013	Body Control	UAES Body Control System	•	•	•	•	0	•	0019 0055
Haval H6-2013	Auto Transmission	Auto Transmission (DSI)	A			A	0	A	0050 0057
		SDE Instrument Control System	0	•	•	0	0	•	
Haval H6-2013		Yazaki Instrument Control System	•	•	•	0	0	0	
Haval H6-2013	TOD	Borgwarner TOD System(2013)	•	•	•	•	0	0	
Haval H6-2013	Entertainment System	Entertainment System (CD)	•	•	•	0	0	0	
Haval H6-2013	Hoodlight	Headlight Adjustment System(ALS)	•	•	•	•	0	•	
Haval H6-2013	Parking Assistant	Parking Assistant System (PAS)	•	•	•	0	0	0	
		Gateway	•	•	•	0	0	0	
		A/C Control System(AC)(CHB022)	•	•	•	•	0	•	
Haval H6-2013	A/C Control System	A/C Control System(AC)(CHB021)	•	•	•	0	0	•	
Great Wall C50-2012	Engine System	Engine System	•	•	•	•	0	•	
Great Wall C50-2012	ABS	ABS	•	•	•	•	0	•	0029 0013
Great Wall C50-2012	Airbag System	Airbag System	•	•	•	•	0		0029
Great Wall C50-2012	Auto Transmission	Punch_CVT System	•	•	•	•	0	0	0049
Great Wall C50-2012	Auto Transmission	Auto Transmission (AMT)	•	•	•	•	0	0	
Great Wall C50-2012	Body Control	UAES Body Control System	•	•	•	•	0	•	0029 0042 0055 0019
Great Wall C50-2012	Instrument System	Instrument System	•	•	•	0	0	0	0029
Great Wall C50-2012		STEC Immobilizer System	•	•	•	•	0	0	
Great Wall C50-2013	Engine System	Engine System	•	•	•	•	0	•	
Great Wall C50-2013		ABS	•	•		•	0	0	0056
Great Wall C50-2013		Airbag System	•	•	•	0	0	0	
Great Wall C50-2013		PEPS System	•	•	•	•	0	•	0068
Great Wall C50-2013		Delphi Body Control System	•	•	•	•	0	•	0019 0055
Great Wall C50-2013		IP System	•	•	•	0	0	0	
Great Wall C50-2013	ESP	ESP	•	•	•	•	0	0	0056 0040
		A/C Control System(AC)	•	•	•	0	0	•	
Great Wall C50-2013	Darking Assistant	Parking Assistant System (PAS)	A	•	A	A	0	0	
Crost Wall C50-		Engine System	•	•	•	•	0	•	
Crost Wall C50-	ABS	ABS	•	•	•	•	0	0	0056

Mode1	System	ECU	Version Info.	Read DTCs	Clear DTCs	Read DataStream	Read Freeze Frame	Active Test	Special Function
Great Wall C50- Upgraded(CHB012)	Airbag System	Airbag System	•	•	•	0	0	0	
Great Wall C50- Upgraded(CHB012)	PEPS System	PEPS System	•	•	•	•	0	•	0068
Great Wall C50- Upgraded(CHB012)	Body Control System	Body Control System	•	•	•	•	0	•	0019 0055
Great Wall C50- Upgraded(CHB012)	IP System	IP System	•	•	•	0	0	0	
Great Wall C50- Upgraded(CHB012)	ESP	ESP	•	•	•	•	0	0	0056
Great Wall C50- Upgraded(CHB012)	A/C Control System	A/C Control System(AC)	•	•	•	0	0	•	
Great Wall C50- Sport(JZ40)	Engine System	Engine System	•	•	•	•	0	•	
Great Wall C50- Sport(JZ40)	ABS	ABS	•	•	•	•	0	0	
Great Wall C50- Sport(JZ40)	Airbag System	Airbag System	•	•	•	0	0	0	
Great Wall C50- Sport(JZ40)	·	PEPS System	•	•	•	•	0	•	0068
Great Wall C50- Sport(JZ40)	Body Control System	Body Control System	•	•	•	•	0	•	0019 0055
Great Wall C50- Sport(JZ40)	IP System	IP System	•	•	•	0	0	0	
Great Wall C50- Sport(JZ40)		ESP	•	•	•	•	0	0	0056
Wingle6	Engine System	4D20 Delphi EURO V Engine System	•	•	•	•	0	•	0029 0026 0027 0066 0071
Wingle6	Engine System	4D20 BOSCH Diesel Engine System	•	•	•	•	0	•	0029 0026 0037 0038
Wingle6	Engine System	DelphiMT80 Engine System	•	•	•	•	0	•	0015
Wingle6	ABS	ABS	•	•	•	•	0	•	0040 0056
Wingle6	Airbag System	Airbag System	•	•	•	•	0		0010 0055
Wingle6	Body Control	Body Control System Instrument System(IP)	•			0	0		0019 0055
Wingle6 Wingle6	Instrument System TOD	Borgwarner TOD System (Intelligent 4WD)	•	•	•	•	0	0	
Wingle6	A/C Control System	A/C Control System(AC)	•	•	•	•	0	0	
Haval H8		Engine System	•	•	•	•	0	•	0015 0051 0028
Haval H8	Airbag System	Airbag System	•	•	•	•	•	0	0058
Haval H8	PEPS System	PEPS System	•	•	•	•	0	•	
Haval H8		Body Control System	•	•	•	•	0	•	0019 0055 0059
Haval H8	Auto Transmission	Auto Transmission	•	•	•	•	0	0	0060 0061
Haval H8	Instrument System	Instrument System(IP)	•	•	•	0	0	•	
Haval H8	TOD	Intelligent 4WD(TOD)	•	•		•	0	•	
Haval H8	Entertainment System	Entertainment System (CD)	•	•	•	0	0	0	
Haval H8	Adaptive Front Lighting System	Adaptive Front Lighting System (AFS)	•	•	•	•	0	•	0064

Mode1	System	ECU	Version Info.	Read DTCs	Clear DTCs	Read DataStream	Read Freeze Frame	Active Test	Special Function
Haval H8	Parking Assistant System	Parking Assistant System (Front)	•	0	0	0	0	0	
Haval H8	Parking Assistant System	Parking Assistant System (Rear)	•	0	0	0	0	0	
Haval H8	Gateway	Gateway	•	•	•	0	0	0	
Haval H8	Driver Side Door System	Driver Side Door System (DDCM)	•	•	•	0	0	0	
Haval H8	Front Passenger Side Door System	Front Passenger Side Door System (PDCM)	•	•	•	0	0	0	
Haval H8	Driver Side Seat Memory System	Driver Side Seat Memory System (DSM)	•	•	•	0	0	•	
Haval H8	Rear View Camera	Rear View Camera (RVC)	•	0	0	0	0	0	
Haval H8	ESP	ESP				•	0	0	
Haval H8	Rain Light Sensor	Rain Light Sensor (RLS)	0	0	0	0	0	0	0065
Haval H8		A/C Control System(AC)	•	•	•	•	0	0	
Haval H8	Steering Wheel Angle Sensor	Steering Wheel Angle Sensor (SAS)	•	•	•	•	0	0	
Haval H1	Body Control	Body Control System(BCM)	A			A	0		0019 0055
Haval H1	Electric Steering System	Electric Steering System	A	A	•	A	0	0	0040
Haval H1	Engine System	Engine Electronic Control System (ECM)	A	•	•	A	0	•	0066 0015
Haval H1	ABS	ABS	lack			A	0		0040 0053 0056 0074
Haval H1	Anti-theft System	Shanghai Industry Anti-theft System		•	•	•	0	0	
Haval H1	Instrument Panel System	Instrument Panel System (IP)	•	•	•	A	0	0	
Haval H2	Airbag System	Airbag System(SRS)	lack		lack	A	0	A	0075
Haval H2	TOD	Borgwarner TOD System				A	0		
Haval H2	Body Control	Body Control System(BCM)				A	0		0055
Haval H2	Headlight Leveling System	Headlight Leveling System(ALS)	A	A	A	A	0	A	
Haval H2	Electric Steering System	Electric Steering System(EPS)	A	A	A	A	0	0	0040
Haval H2	Electronic Steering Column	Electronic Steering Column Lock(ESCL)	A	A	•	A	0	0	
Haval H2	Engine System	Engine System(ECM)					0		0015 0066
Haval H2	Steering Wheel Angle Sensor	Steering Wheel Angle Sensor(SAS)	A	•	•	A	0	0	0040
Haval H2	ABS	ABS				A	0		0056
Haval H2		Rear View Camera(RVC)		0	0	A	0	0	
Haval H2		A/C Control System	A			A	0	A	
Haval H2	Gateway	Gateway(GW)	A	A		A	0	0	
Haval H2	Keyless Start System	Keyless Start System (PEPS)	A	A	A	A	0	A	
Haval H2	Instrument Panel System	Instrument Panel System (IP)	A	•	•	A	0	•	0062 0063

-Autel®-

Specil_Function

Index	Specil Function Name	Index	Specil Function Name
0001	Compression Test	0002	Fuel Injection Comparison
0003	Idle RPM Comparison	0004	High Speed Test
0005	High Voltage Test	0006	Cylinder Shutoff
0007	Idle Speed Initialization	0008	Canister Control Valve
0009	Distributor Adjustment	0010	System Parameter
0011	Engine Test	0012	End-of-Line Test
0013	Bleeding Mode	0014	Matching Function
0015	Write VIN	0016	Match Key
0017	Read Network Configuration	0018	Function Configuration
0019	System Configuration	0020	Write Network Configuration (Manual)
0021	Write Fuel Injector Code	0022	User Authorization Code Setting
0023	Anti-theft Matching Function	0024	Input Code
0025	Immobilizer Matching	0026	Read Fuel Injector Code
0027		0028	
0021	Write Fuel Injector Code	0020	Read Network Configuration Information
0029	Write Network Configuration Information	0030	
	(Automatic)		Network Configuration(Manual)
0031	ReadEBS Information	0032	WriteBatteryIDNo.
0033	ReadPedal Information	0034	ReadBatteryInformation
0035	ClearMotorStartTimes	0036	ReadStart-StopTimes
0037	Write Fuel Injector Code (All)	0038	Write Fuel Injector Code (Separate)
0039	Key Learning	0040	SteeringSensorCalibration
0041	ReadandWrite NetworkConfiguration	0042	Match Key
0043	Write User Authorization	0044	Match EntireSystem
0045	ReplaceEngineECM	0046	ProgramEngineVIN
0047	Reset Engine, Immobilizer	0048	Clear Key List
0049	Clear Adaptation Value	0050	Special Function
0051	Tooth Correction Error Learning	0052	Routine Control
0053	Longitudinal Acceleration Calibration	0054	DPF
0055	Tire Pressure Sensor Learning	0056	Manual Bleeding
0057	End-of-Line Configuration	0058	IMU Static Calibration
0059	Write Four-Wheel Tire Pressure Sensor ID	0060	Reset Adaptive Value
0061	Write Network Topology Information	0062	Reset Service Mileage
0063	Reset Mileage	0064	Horizontal Zero Point Calibration
0065	Rain Sensor Initialization Routine	0066	IUPR
0067	Yaw Angle Sensor Calibration	0068	Aftermarket Function
0069	FPAS Configuration (Manual)	0070	FPAS Configuration (Automatic)
0071	EGR Clear Self-Learning	0072	TCU RESET
0073	Write-in TSN Code	0074	Write Filling Status
0075	Return Circuit Configuration	0076	LCD Image Distortion (WOW)