

MaxiDiag_Benz_V3.00 Function List (Note:For reference only)

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| Up to 11/2005 | A-Class | 169 | Drive | ESM-Electronic selector module | ● | ● | ● | ● | ● | ○ |
| Up to 11/2005 | A-Class | 169 | Drive | FCVT-Continuously variable automatic transmission | ● | ● | ● | ● | ● | ● |
| Up to 11/2005 | A-Class | 169 | Drive | ME-SFI-Gasoline engine control | ● | ● | ● | ● | ● | ● |
| Up to 11/2005 | A-Class | 169 | Drive | CDI-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| Up to 11/2005 | A-Class | 169 | Chassis | ES-Electrical power steering | ● | ● | ● | ● | ● | ○ |
| Up to 11/2005 | A-Class | 169 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| Up to 11/2005 | A-Class | 169 | Body | CGW-Central gateway | ● | ● | ● | ● | ○ | ○ |
| Up to 11/2005 | A-Class | 169 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ○ |
| Up to 11/2005 | A-Class | 169 | Body | AB-Airbag | ● | ● | ● | ● | ● | ● |
| Up to 11/2005 | A-Class | 169 | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ○ |
| Up to 11/2005 | A-Class | 169 | Body | ATA-Anti-theft alarm system | ● | ● | ● | ● | ● | ○ |
| Up to 11/2005 | A-Class | 169 | Body | SAM-Signal acquisition and actuation module | ● | ● | ● | ● | ● | ○ |
| Up to 11/2005 | A-Class | 169 | Body | AHE-Trailer recognition | ● | ● | ● | ● | ● | ○ |
| Up to 11/2005 | A-Class | 169 | Body | MSS-Special vehicle multifunction control module | ● | ● | ● | ● | ● | ○ |
| Up to 11/2005 | A-Class | 169 | Body | MSS-Special vehicle multifunction control module | ● | ● | ● | ● | ● | ○ |
| Up to 11/2005 | A-Class | 169 | Body | HRA-FR-Front right headlamp range control | ● | ● | ● | ● | ● | ○ |
| Up to 11/2005 | A-Class | 169 | Body | HRA-FL-Front left headlamp range control | ● | ● | ● | ● | ● | ○ |
| Up to 11/2005 | A-Class | 169 | Body | System diagnosis (CAN) | ● | ● | ● | ● | ● | ● |
| Up to 11/2005 | A-Class | 169 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ● |
| Up to 11/2005 | A-Class | 169 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ● |
| Up to 11/2005 | A-Class | 169 | Information and communication | IC-Instrument cluster | ● | ● | ● | ● | ● | ○ |
| Up to 11/2005 | A-Class | 169 | Information and communication | ASSYST-Active Service System | ● | ● | ○ | ● | ● | ○ |
| Up to 11/2005 | A-Class | 169 | Information and communication | ASSYST PLUS-PLUS Active Service System | ● | ● | ○ | ● | ● | ● |
| Up to 11/2005 | A-Class | 169 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| Up to 11/2005 | A-Class | 169 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| Up to 11/2005 | A-Class | 169 | Information and communication | AGW-Audio gateway or Audio 20 with CD drive | ● | ● | ● | ● | ● | ● |
| Up to 11/2005 | A-Class | 169 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| Up to 11/2005 | A-Class | 169 | Information and communication | COMAND or AUDIO | ● | ● | ○ | ● | ● | ● |
| Up to 11/2005 | A-Class | 169 | Information and communication | CTEL-Mobile phone adapter with universal interface | ● | ● | ● | ● | ● | ● |
| Up to 11/2005 | A-Class | 169 | Information and communication | CDC-CD changer | ● | ● | ○ | ● | ● | ● |
| Up to 11/2005 | A-Class | 169 | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ● |
| Up to 11/2005 | A-Class | 169 | Information and communication | SOUND- Sound system | ● | ● | ○ | ● | ● | ● |
| Up to 11/2005 | A-Class | 169 | Information and communication | CTEL-Cellular telephone | ● | ● | ● | ● | ● | ● |
| Up to 11/2005 | A-Class | 169 | Seats and doors | DCM-FL-Door control module front left | ● | ● | ● | ● | ● | ○ |
| Up to 11/2005 | A-Class | 169 | Seats and doors | DCM-FR-Door control module front right | ● | ● | ● | ● | ● | ○ |
| Up to 11/2005 | A-Class | 169 | Seats and doors | DCM-RL-Door control module rear left | ● | ● | ● | ● | ● | ○ |
| Up to 11/2005 | A-Class | 169 | Seats and doors | DCM-RR-Door control module rear right | ● | ● | ● | ● | ● | ○ |
| Up to 11/2005 | A-Class | 169 | Air conditioning | C-AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater | ● | ● | ● | ● | ● | ○ |
| As of 12/2005 | A-Class | 169 | Drive | ESM-Electronic selector module | ● | ● | ● | ● | ● | ○ |
| As of 12/2005 | A-Class | 169 | Drive | FCVT-Continuously variable automatic transmission | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | A-Class | 169 | Drive | ME-SFI-Gasoline engine control | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | A-Class | 169 | Drive | TV-TV tuner | ● | ● | ● | ● | ● | |
| As of 12/2005 | A-Class | 169 | Drive | CDI-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | A-Class | 169 | Drive | CDI-Common Rail Diesel Injection | ● | ● | ● | ● | ● | |
| As of 12/2005 | A-Class | 169 | Drive | N93/4 (Vehicle gateway control unit) | ● | ● | ● | ● | ○ | ○ |
| As of 12/2005 | A-Class | 169 | Chassis | ES-Electrical power steering | ● | ● | ● | ● | ● | ○ |
| As of 12/2005 | A-Class | 169 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | A-Class | 169 | Body | CGW-Central gateway | ● | ● | ● | ● | ○ | ○ |
| As of 12/2005 | A-Class | 169 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ○ |
| As of 12/2005 | A-Class | 169 | Body | AB-Airbag | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | A-Class | 169 | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ○ |
| As of 12/2005 | A-Class | 169 | Body | ATA-Anti-theft alarm system | ● | ● | ● | ● | ● | ○ |
| As of 12/2005 | A-Class | 169 | Body | SAM-Signal acquisition and actuation module | ● | ● | ● | ● | ● | ○ |
| As of 12/2005 | A-Class | 169 | Body | AHE-Trailer recognition | ● | ● | ● | ● | ● | ○ |
| As of 12/2005 | A-Class | 169 | Body | MSS-Special vehicle multifunction control module | ● | ● | ● | ● | ● | ○ |
| As of 12/2005 | A-Class | 169 | Body | MSS-Special vehicle multifunction control module | ● | ● | ● | ● | ● | ○ |
| As of 12/2005 | A-Class | 169 | Body | HRA-FR-Front right headlamp range control | ● | ● | ● | ● | ● | ○ |
| As of 12/2005 | A-Class | 169 | Body | HRA-FL-Front left headlamp range control | ● | ● | ● | ● | ● | ○ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| As of 12/2005 | A-Class | 169 | Body | System diagnosis(CAN) | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | A-Class | 169 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | A-Class | 169 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | A-Class | 169 | Information and communication | IC-Instrument cluster | ● | ● | ● | ● | ● | ○ |
| As of 12/2005 | A-Class | 169 | Information and communication | ASSYST-Active Service System | ● | ● | ○ | ● | ● | ○ |
| As of 12/2005 | A-Class | 169 | Information and communication | ASSYST PLUS-PLUS Active Service System | ● | ● | ○ | ● | ● | ● |
| As of 12/2005 | A-Class | 169 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | A-Class | 169 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | A-Class | 169 | Information and communication | AGW-Audio gateway or Audio 20 with CD drive | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | A-Class | 169 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | A-Class | 169 | Information and communication | COMAND or AUDIO | ● | ● | ○ | ● | ● | ● |
| As of 12/2005 | A-Class | 169 | Information and communication | CTEL-Mobile phone adapter with universal interface | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | A-Class | 169 | Information and communication | CDC-CD changer | ● | ● | ○ | ● | ● | ● |
| As of 12/2005 | A-Class | 169 | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ● |
| As of 12/2005 | A-Class | 169 | Information and communication | SOUND- Sound system | ● | ● | ○ | ● | ● | ● |
| As of 12/2005 | A-Class | 169 | Information and communication | CTEL-Cellular telephone | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | A-Class | 169 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | A-Class | 169 | Information and communication | COMAND or AUDIO | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | A-Class | 169 | Information and communication | Sound system (Main amplifier) | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | A-Class | 169 | Information and communication | UCI-Media interface | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | A-Class | 169 | Information and communication | DAB-Digital radio | ● | ● | ● | ● | ● | ○ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| As of 12/2005 | A-Class | 169 | Information and communication | SDAR-Satellite radio(Valid for USA) | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | A-Class | 169 | Information and communication | CTEL-Cellular telephone(JAPAN) | ● | ● | ● | ● | ● | ○ |
| As of 12/2005 | A-Class | 169 | Seats and doors | DCM-FL-Door control module front left | ● | ● | ● | ● | ● | ○ |
| As of 12/2005 | A-Class | 169 | Seats and doors | DCM-FR-Door control module front right | ● | ● | ● | ● | ● | ○ |
| As of 12/2005 | A-Class | 169 | Seats and doors | DCM-RL-Door control module rear left | ● | ● | ● | ● | ● | ○ |
| As of 12/2005 | A-Class | 169 | Seats and doors | DCM-RR-Door control module rear right | ● | ● | ● | ● | ● | ○ |
| As of 12/2005 | A-Class | 169 | Air conditioning | C-AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater | ● | ● | ● | ● | ● | ○ |
| As of 12/2005 | A-Class | 169 | Air conditioning | EKMK-Electric refrigerant compressor (A9/5) | ● | ● | ● | ● | ● | |
| As of 12/2005 | A-Class | 169 | Air conditioning | C-AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater | ● | ● | ● | ● | ● | |
| ALL | A-Class | 168 | Drive | ECM-Engine control monolith | ● | ● | ○ | ● | ● | ※ |
| ALL | A-Class | 168 | Drive | ECM-Engine control monolith | ● | ● | ● | ● | ● | ※ |
| ALL | A-Class | 168 | Drive | ACS-Automatic clutch system | ● | ● | ● | ● | ● | ※ |
| ALL | A-Class | 168 | Drive | FTC-Front transmission control | ● | ● | ● | ● | ● | ※ |
| ALL | A-Class | 168 | Drive | FTC2 -Front transmission control2 | ● | ● | ● | ● | ● | ● |
| ALL | A-Class | 168 | Drive | GRM-Gear recognition module | ● | ● | ● | ● | ● | ※ |
| ALL | A-Class | 168 | Drive | CDI-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ※ |
| ALL | A-Class | 168 | Chassis | ESP-Electronic stability program | ● | ● | ○ | ● | ● | ※ |
| ALL | A-Class | 168 | Chassis | ESP-Electronic stability program | ● | ● | ○ | ● | ● | ※ |
| ALL | A-Class | 168 | Body | AB-Airbag | ● | ● | ○ | ● | ● | ※ |
| ALL | A-Class | 168 | Body | AB-Airbag | ● | ● | ○ | ● | | ※ |
| ALL | A-Class | 168 | Body | RFL-Radio frequency locking/electric central locking | ● | ● | ○ | ● | ● | ※ |
| ALL | A-Class | 168 | Body | LCP-Lower control panel | ● | ● | ○ | ● | ● | ※ |
| ALL | A-Class | 168 | Body | ATA-Anti-theft alarm system | ● | ● | ○ | ● | ● | ※ |
| ALL | A-Class | 168 | Body | APS-Auto pilot system | ● | ● | ○ | ● | ● | ※ |
| ALL | A-Class | 168 | Body | HB-Heater booster | ● | ● | ○ | ● | | ※ |
| ALL | A-Class | 168 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ○ | ● | ● | ※ |
| ALL | A-Class | 168 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| ALL | A-Class | 168 | Information and communication | CTEL- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ○ | ○ |
| ALL | A-Class | 168 | Information and communication | CDC-CD changer | ● | ● | ● | ● | ○ | ○ |
| ALL | A-Class | 168 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ※ |
| ALL | A-Class | 168 | Seats and doors | DCM-FL-Door control module front left | ● | ● | ○ | ● | ● | ※ |
| ALL | A-Class | 168 | Seats and doors | DCM-FR-Door control module front right | ● | ● | ○ | ● | ● | ※ |
| ALL | A-Class | 168 | Seats and doors | DCM-RL-Door control module rear left | ● | ● | ○ | ● | ● | ※ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | A-Class | 168 | Seats and doors | DCM-RR-Door control module rear right | ● | ● | ○ | ● | ● | ※ |
| ALL | A-Class | 168 | Air conditioning | STH-Stationary heater | ● | ● | ○ | ● | ● | ※ |
| ALL | A-Class | 168 | Air conditioning | TAC-Automatic temperature control | ● | ● | ● | ● | ● | ※ |
| Up to 11/2005 | B-Class | 245 | Drive | ESM-Electronic selector module | ● | ● | ● | ● | ● | ○ |
| Up to 11/2005 | B-Class | 245 | Drive | FCVT-Continuously variable automatic transmission | ● | ● | ● | ● | ● | ● |
| Up to 11/2005 | B-Class | 245 | Drive | ME-SFI-Gasoline engine control | ● | ● | ● | ● | ● | ● |
| Up to 11/2005 | B-Class | 245 | Drive | CDI-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| Up to 11/2005 | B-Class | 245 | Chassis | ES-Electrical power steering | ● | ● | ● | ● | ● | ○ |
| Up to 11/2005 | B-Class | 245 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| Up to 11/2005 | B-Class | 245 | Body | CGW-Central gateway | ● | ● | ● | ● | ○ | ○ |
| Up to 11/2005 | B-Class | 245 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ○ |
| Up to 11/2005 | B-Class | 245 | Body | AB-Airbag | ● | ● | ● | ● | ● | ● |
| Up to 11/2005 | B-Class | 245 | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ○ |
| Up to 11/2005 | B-Class | 245 | Body | ATA-Anti-theft alarm system | ● | ● | ● | ● | ● | ○ |
| Up to 11/2005 | B-Class | 245 | Body | SAM-Signal acquisition and actuation module | ● | ● | ● | ● | ● | ○ |
| Up to 11/2005 | B-Class | 245 | Body | AHE-Trailer recognition | ● | ● | ● | ● | ● | ○ |
| Up to 11/2005 | B-Class | 245 | Body | MSS-Special vehicle multifunction control module | ● | ● | ● | ● | ● | ○ |
| Up to 11/2005 | B-Class | 245 | Body | MSS-Special vehicle multifunction control module | ● | ● | ● | ● | ● | ○ |
| Up to 11/2005 | B-Class | 245 | Body | XALWA-L-Xenon headlamp, left | ● | ● | ● | ● | ● | ○ |
| Up to 11/2005 | B-Class | 245 | Body | XALWA-R-Xenon headlamp, right | ● | ● | ● | ● | ● | ○ |
| Up to 11/2005 | B-Class | 245 | Body | System diagnosis(CAN) | ● | ● | ● | ● | ● | ● |
| Up to 11/2005 | B-Class | 245 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ● |
| Up to 11/2005 | B-Class | 245 | Information and communication | CM-Compass module | ● | ● | ● | ● | ● | ● |
| Up to 11/2005 | B-Class | 245 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ● |
| Up to 11/2005 | B-Class | 245 | Information and communication | IC-Instrument cluster | ● | ● | ● | ● | ● | ○ |
| Up to 11/2005 | B-Class | 245 | Information and communication | ASSYST-Active Service System | ● | ● | ○ | ● | ● | ○ |
| Up to 11/2005 | B-Class | 245 | Information and communication | ASSYST PLUS-PLUS Active Service System | ● | ● | ○ | ● | ● | ● |
| Up to 11/2005 | B-Class | 245 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| Up to 11/2005 | B-Class | 245 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| Up to 11/2005 | B-Class | 245 | Information and communication | AGW-Audio gateway or Audio 20 with CD drive | ● | ● | ● | ● | ● | ● |
| Up to 11/2005 | B-Class | 245 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| Up to 11/2005 | B-Class | 245 | Information and communication | COMAND or AUDIO | ● | ● | ○ | ● | ● | ● |
| Up to 11/2005 | B-Class | 245 | Information and communication | CTEL-Mobile phone adapter with universal interface | ● | ● | ● | ● | ● | ● |
| Up to 11/2005 | B-Class | 245 | Information and communication | CDC-CD changer | ● | ● | ○ | ● | ● | ● |
| Up to 11/2005 | B-Class | 245 | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ● |
| Up to 11/2005 | B-Class | 245 | Information and communication | SOUND- Sound system | ● | ● | ○ | ● | ● | ● |
| Up to 11/2005 | B-Class | 245 | Information and communication | SDAR-Satellite radio | ● | ● | ○ | ● | ● | ● |
| Up to 11/2005 | B-Class | 245 | Information and communication | NAVI-Navigation system | ● | ● | ● | ● | ● | ● |
| Up to 11/2005 | B-Class | 245 | Information and communication | CTEL-Cellular telephone | ● | ● | ● | ● | ● | ● |
| Up to 11/2005 | B-Class | 245 | Information and communication | TELE AID-Control unit | ● | ● | ● | ● | ● | ● |
| Up to 11/2005 | B-Class | 245 | Information and communication | TELE AID-Telematic services Emergency call | ● | ● | ● | ● | | ● |
| Up to 11/2005 | B-Class | 245 | Information and communication | TELE AID-Telematic services MB Info, Roadside assistance (USA, Canada), Tele diagnosis (ECE) | ● | ● | ● | ● | | ● |
| Up to 11/2005 | B-Class | 245 | Information and communication | TELE AID-Telematic services Stolen vehicle tracking | ● | ● | ● | ● | | ● |
| Up to 11/2005 | B-Class | 245 | Information and communication | TELE AID-Telematic services Remote door unlocking, Remote door locking | ● | ● | ● | ● | | ● |
| Up to 11/2005 | B-Class | 245 | Seats and doors | DCM-FL-Door control module front left | ● | ● | ● | ● | ● | ○ |
| Up to 11/2005 | B-Class | 245 | Seats and doors | DCM-FR-Door control module front right | ● | ● | ● | ● | ● | ○ |
| Up to 11/2005 | B-Class | 245 | Seats and doors | DCM-RL-Door control module rear left | ● | ● | ● | ● | ● | ○ |
| Up to 11/2005 | B-Class | 245 | Seats and doors | DCM-RR-Door control module rear right | ● | ● | ● | ● | ● | ○ |
| Up to 11/2005 | B-Class | 245 | Air conditioning | C-AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater | ● | ● | ● | ● | ● | ○ |
| As of 12/2005 | B-Class | 245 | Drive | ESM-Electronic selector module | ● | ● | ● | ● | ● | ○ |
| As of 12/2005 | B-Class | 245 | Drive | FCVT-Continuously variable automatic transmission | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | B-Class | 245 | Drive | ME-SFI-Gasoline engine control | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | B-Class | 245 | Drive | ME-SFI-Motor electronics | ● | ● | ● | ● | ● | |
| As of 12/2005 | B-Class | 245 | Drive | ME-SFI-CNG compressed natural gas | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | B-Class | 245 | Drive | BSA-Belt-driven starter/alternator | ● | ● | ● | ● | ● | |
| As of 12/2005 | B-Class | 245 | Drive | TV-TV tuner | ● | ● | ● | ● | ● | |
| As of 12/2005 | B-Class | 245 | Drive | CDI-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | B-Class | 245 | Drive | CDI-Common Rail Diesel Injection | ● | ● | ● | ● | ○ | |
| As of 12/2005 | B-Class | 245 | Drive | N93/4 (Vehicle gateway control unit) | ● | ● | ● | ● | ○ | ○ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| As of 12/2005 | B-Class | 245 | Chassis | ES-Electrical power steering | ● | ● | ● | ● | ● | ○ |
| As of 12/2005 | B-Class | 245 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | B-Class | 245 | Chassis | VP-Vacuum pump brake booster | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | B-Class | 245 | Chassis | TPC-Tire pressure monitor | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | B-Class | 245 | Body | CGW-Central gateway | ● | ● | ● | ● | ○ | ○ |
| As of 12/2005 | B-Class | 245 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ○ |
| As of 12/2005 | B-Class | 245 | Body | AB-Airbag | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | B-Class | 245 | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ○ |
| As of 12/2005 | B-Class | 245 | Body | ATA-Anti-theft alarm system | ● | ● | ● | ● | ● | ○ |
| As of 12/2005 | B-Class | 245 | Body | SAM-Signal acquisition and actuation module | ● | ● | ● | ● | ● | ○ |
| As of 12/2005 | B-Class | 245 | Body | AHE-Trailer recognition | ● | ● | ● | ● | ● | ○ |
| As of 12/2005 | B-Class | 245 | Body | MSS-Special vehicle multifunction control module | ● | ● | ● | ● | ● | ○ |
| As of 12/2005 | B-Class | 245 | Body | MSS-Special vehicle multifunction control module | ● | ● | ● | ● | ● | ○ |
| As of 12/2005 | B-Class | 245 | Body | XALWA-L-Xenon headlamp, left | ● | ● | ● | ● | ● | ○ |
| As of 12/2005 | B-Class | 245 | Body | XALWA-R-Xenon headlamp, right | ● | ● | ● | ● | ● | ○ |
| As of 12/2005 | B-Class | 245 | Body | System diagnosis (CAN) | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | B-Class | 245 | Body | WSS-Weight sensing system | ● | ● | ● | ● | ● | |
| As of 12/2005 | B-Class | 245 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | B-Class | 245 | Information and communication | CM-Compass module | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | B-Class | 245 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | B-Class | 245 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | B-Class | 245 | Information and communication | IC-Instrument cluster | ● | ● | ● | ● | ● | ○ |
| As of 12/2005 | B-Class | 245 | Information and communication | ASSYST-Active Service System | ● | ● | ○ | ● | ● | ○ |
| As of 12/2005 | B-Class | 245 | Information and communication | ASSYST PLUS-PLUS Active Service System | ● | ● | ○ | ● | ● | ● |
| As of 12/2005 | B-Class | 245 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | B-Class | 245 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | B-Class | 245 | Information and communication | AGW-Audio gateway or Audio 20 with CD drive | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | B-Class | 245 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | B-Class | 245 | Information and communication | COMAND or AUDIO | ● | ● | ○ | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| As of 12/2005 | B-Class | 245 | Information and communication | CTEL-Mobile phone adapter with universal interface | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | B-Class | 245 | Information and communication | CDC-CD changer | ● | ● | ○ | ● | ● | ● |
| As of 12/2005 | B-Class | 245 | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ● |
| As of 12/2005 | B-Class | 245 | Information and communication | SOUND- Sound system | ● | ● | ○ | ● | ● | ● |
| As of 12/2005 | B-Class | 245 | Information and communication | SDAR-Satellite radio | ● | ● | ○ | ● | ● | ● |
| As of 12/2005 | B-Class | 245 | Information and communication | NAVI-Navigation system | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | B-Class | 245 | Information and communication | CTEL-Cellular telephone | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | B-Class | 245 | Information and communication | TELE AID-Control unit | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | B-Class | 245 | Information and communication | TELE AID-Telematic services Emergency call | ● | ● | ● | ● | | ● |
| As of 12/2005 | B-Class | 245 | Information and communication | TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE) | ● | ● | ● | ● | | ● |
| As of 12/2005 | B-Class | 245 | Information and communication | TELE AID-Telematic services Stolen vehicle tracking | ● | ● | ● | ● | | ● |
| As of 12/2005 | B-Class | 245 | Information and communication | TELE AID-Telematic services Remote door unlocking,Remote door locking | ● | ● | ● | ● | | ● |
| As of 12/2005 | B-Class | 245 | Information and communication | COMAND or AUDIO | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | B-Class | 245 | Information and communication | Sound system (Main amplifier) | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | B-Class | 245 | Information and communication | UCI-Media interface | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | B-Class | 245 | Information and communication | DAB-Digital radio | ● | ● | ● | ● | ● | ○ |
| As of 12/2005 | B-Class | 245 | Information and communication | SDAR-Satellite radio(Valid for USA) | ● | ● | ● | ● | ● | ● |
| As of 12/2005 | B-Class | 245 | Information and communication | CTEL-Cellular telephone(JAPAN) | ● | ● | ● | ● | ● | ○ |
| As of 12/2005 | B-Class | 245 | Seats and doors | DCM-FL-Door control module front left | ● | ● | ● | ● | ● | ○ |
| As of 12/2005 | B-Class | 245 | Seats and doors | DCM-FR-Door control module front right | ● | ● | ● | ● | ● | ○ |
| As of 12/2005 | B-Class | 245 | Seats and doors | DCM-RL-Door control module rear left | ● | ● | ● | ● | ● | ○ |
| As of 12/2005 | B-Class | 245 | Seats and doors | DCM-RR-Door control module rear right | ● | ● | ● | ● | ● | ○ |
| As of 12/2005 | B-Class | 245 | Air conditioning | C-AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater | ● | ● | ● | ● | ● | ○ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| As of 12/2005 | B-Class | 245 | Air conditioning | C-AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater | ● | ● | ● | ● | ● | |
| As of 12/2005 | B-Class | 245 | Air conditioning | EKMK-Electric refrigerant compressor (A9/5) | ● | ● | ● | ● | ● | |
| ALL | B-Class | 246 | Drive | PTCU-Common powertrain controller (N127) | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | Drive | PTCU-Common powertrain controller (N127) | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | Drive | ME-Motor electronics 'MED40' for combustion engine 'M270' (N3/10) | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | Drive | ME-Motor electronics 'MED40CNG' for combustion engine 'M274' (N3/10) | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ● | ● |
| ALL | B-Class | 246 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ● | ● |
| ALL | B-Class | 246 | Drive | mbrace-mbrace (N123/4) | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | Drive | SCR-Selective Catalytic Reduction | ● | ● | ● | ● | ● | ● |
| ALL | B-Class | 246 | Drive | CDI 3-Common Rail Diesel Injection3 | ● | ● | ● | ● | ● | |
| ALL | B-Class | 246 | Drive | CDI-Motor electronics 'CRR1' for combustion engine 'OM607' (N3/9) | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | Chassis | ES-Electrical power steering (N68) | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | Chassis | ESP-Electronic stability program (N30/4) | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | Chassis | EFB-Electronic parking break (N128) | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | Chassis | DTR-DISTRONIC (A89) | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | Chassis | DTR-DISTRONIC (A89) | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | Chassis | TPM-Tire pressure monitor | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | Body | EZS-Electronic ignition switch | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | Body | SAM-Signal acquisition and actuation module (N10) | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | Body | SG-AWF-Control unit 'COLLISION PREVENTION ASSIST' | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | Body | IRS-HRA-Outer right rear intelligent radar sensor | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | Body | IRS-HLA-Outer left rear intelligent radar sensor system (B29/4) | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | Body | SRS-Supplemental restraint system (N2/10) | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | Body | SG-SW-Control unit 'Headlamp' (N71/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | Body | RevETR-LF-Left front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |
| ALL | B-Class | 246 | Body | RevETR-RF-Right front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |
| ALL | B-Class | 246 | Body | SCM-Steering column module (N80) | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | Body | Trailer recognition module-Trailer recognition (N28/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | Body | ATA-ATA[EDW]/tow-away protection/interior protection (N26/6) | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | Information and communication | COU [ZBE]-Central operating unit | ● | ● | ● | ● | ● | ● |
| ALL | B-Class | 246 | Information and communication | DAB-Digital Audio Broadcasting (N87/3) | ● | ● | ○ | ● | ○ | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|---------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | B-Class | 246 | Information and communication | DAB-Digital radio | ● | ● | ● | ● | ● | ● |
| ALL | B-Class | 246 | Information and communication | DKG-Electronic transmission control for double-plate clutch transmission (N15/13) | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | Information and communication | ZAN-Central display | ● | ● | ● | ● | ● | ● |
| ALL | B-Class | 246 | Information and communication | IC-Instrument cluster (A1) | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | Information and communication | IC-Instrument cluster (A1) | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ● |
| ALL | B-Class | 246 | Information and communication | Audio-Audio or COMAND (A2-A40/3) | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | Information and communication | MFK-Multifunction camera | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |
| ALL | B-Class | 246 | Information and communication | NAV-Navigation module (A2/30) | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | Information and communication | PTS-Parktronic | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | Information and communication | PTS-PARKTRONIC (N62) | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | Information and communication | SDAR-Satellite radio(Valid for USA) | ● | ● | ● | ● | ● | ● |
| ALL | B-Class | 246 | Information and communication | Sound system (Main amplifier) | ● | ● | ● | ● | ● | ● |
| ALL | B-Class | 246 | Information and communication | TV-TV tuner(AGW) | ● | ● | ● | ● | ● | ● |
| ALL | B-Class | 246 | Information and communication | UCI-Media interface | ● | ● | ● | ● | ● | ● |
| ALL | B-Class | 246 | Information and communication | Audio-Audio 5 USB(A2) | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | Seats and doors | DCU-LF-Left front door (N69/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | Seats and doors | DCU-RF-Right front door (N69/2) | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | Seats and doors | ESA 'Driver' -Electrical seat adjustment 'Driver' with memory function(N32/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | Seats and doors | ESA' Front passenger' -Electric seat adjustment 'Front passenger' with memory function(N32/2) | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | Air conditioning | AAC-Air conditioning (N22/7) | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | Air conditioning | STH-Stationary heater (A6n1) | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | LIN Bus | UCP-Upper control panel (N72/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | LIN Bus | AISP-Dimming inside rearview mirror (A67) | ● | ● | ○ | ● | ○ | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|---------|--------------|---------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | B-Class | 246 | LIN Bus | BSN-Battery sensor (B95) | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | LIN Bus | GTO-Garage door opener (A67n2) | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | LIN Bus | AMLAB-L 1-Actuation module 1, LED exterior lighting, left front (E1n7) | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | LIN Bus | AMLAB-R 1-Actuation module 1, LED exterior lighting, right front (E2n7) | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | LIN Bus | RGLS-Rain/light sensor (B38/2) | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | LIN Bus | OCP-Control unit 'Overhead control panel' (N70) | ● | ● | ○ | ● | ○ | ● |
| ALL | B-Class | 246 | LIN Bus | AS-Alarm siren(H3/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | C-Class | 204 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Drive | ME - Motor electronics 'SIM271DE20' for combustion engine 'M271EVO' (N3/10) | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Drive | ME-SFI-Motor electronics | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ○ | ● |
| ALL | C-Class | 204 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Drive | ESM-Electronic selector module | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Drive | ME 9.7-Motor electronics 9.7 | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Drive | ME 9.7 (AMG)-Motor electronics 9.7 (AMG) | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Drive | MED 17.7-Motor electronics for direct injection 17.7 | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Drive | ME-Motor electronics 'MED40' for combustion engine 'M270' (N3/10) | ● | ● | ○ | ● | ○ | ● |
| ALL | C-Class | 204 | Drive | MED 9.7-Motor electronics for direct injection 9.7 | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Drive | FSCU Left-Control unit 'left fuel pump' | ● | ● | ● | ● | ○ | ● |
| ALL | C-Class | 204 | Drive | FSCU Right-Control unit 'Right fuel pump' | ● | ● | ● | ● | ○ | ● |
| ALL | C-Class | 204 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Drive | PTCU-Common powertrain controller(N127) | ● | ● | ○ | ● | ○ | ● |
| ALL | C-Class | 204 | Drive | ISM-Shift module (A80) | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |
| ALL | C-Class | 204 | Drive | mbrace-mbrace (N123/4) | ● | ● | ○ | ● | ○ | ● |
| ALL | C-Class | 204 | Drive | SCR-Selective Catalytic Reduction | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ○ | ● |
| ALL | C-Class | 204 | Drive | CDID-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Drive | CDID-Common Rail Diesel Injection | ● | ● | ● | ● | ○ | ● |
| ALL | C-Class | 204 | Drive | CDI 3-Common Rail Diesel Injection3 | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Drive | ESM-Electronic selector module | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Drive | CDI 6-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Drive | CDI 60LS-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Drive | CDI 6-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Drive | CDI 6-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Chassis | ABR-Adaptive Brake | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Chassis | TPC-Tire pressure monitor | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|---------|--------------|---------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | C-Class | 204 | Chassis | TPM - Tire pressure monitor(N88) | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Chassis | AIRMATIC-AIRMATIC | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |
| ALL | C-Class | 204 | Chassis | ESP-Electronic stability program (N30/4) | ● | ● | ○ | ● | ○ | ● |
| ALL | C-Class | 204 | Chassis | EHPS-Electrohydraulic Power Steering | ● | ● | ● | ● | ● | |
| ALL | C-Class | 204 | Chassis | ES-Electrical power steering (N68) | ● | ● | ○ | ● | ○ | ● |
| ALL | C-Class | 204 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Chassis | ESP-Regenerative braking system (N30/6) | ● | ● | ○ | ● | ○ | ● |
| ALL | C-Class | 204 | Body | CGW-Central gateway | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Body | CGW[ZGW]-Central gateway (CGW[ZGW]) | ● | ● | ○ | ● | ○ | ● |
| ALL | C-Class | 204 | Body | CGW-Central gateway | ● | ● | ● | ● | ▲ | ● |
| ALL | C-Class | 204 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Body | KG-Keyless Go | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Body | KG-KEYLESS GO(N69/5) | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Body | Trailer recognition module | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Body | AB-Airbag | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Body | SRS-Supplemental restraint system (N2/10) | ● | ● | ● | ● | ▲ | ● |
| ALL | C-Class | 204 | Body | SRS-Supplemental restraint system | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Body | WSS-Weight sensing system | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Body | PSD-Control mudule 'Panoramic sliding roof' (A98) | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Body | PSD-Control mudule 'Panoramic sliding roof' (A98) | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Body | Dr-side SAM-Driver signal acquisition and actuation module | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Body | Driver-side SAM-Driver signal acquisition and actuation module | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Body | Driver-side SAM-Driver signal acquisition and actuation module | ● | ● | ● | ● | ▲ | |
| ALL | C-Class | 204 | Body | REAR SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Body | Rear SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ▲ | ▲ |
| ALL | C-Class | 204 | Body | AHE-Trailer recognition | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Body | MSS-Special vehicle multifunction control module | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Body | RevETR-LF-Left front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Body | RevETR-LF-Left front reversible emergency tensioning retractor(A76) | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Body | RevETR-RF-Right front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Body | RevETR-RF-Right front reversible emergency tensioning retractor(A76/1) | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Body | XALWA-L-Xenon headlamp, left | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Body | XALWA-L-Xenon headlamp, left | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Body | XALWA-L-Xenon headlamp, left | ● | ● | ● | ● | ● | |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|---------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | C-Class | 204 | Body | XALWA-R-Xenon headlamp, right | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Body | XALWA-R-Xenon headlamp, right | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Body | XALWA-R-Xenon headlamp, right | ● | ● | ● | ● | ● | |
| ALL | C-Class | 204 | Body | Multifunction control unit-Multifunction control unit (N26/14) | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Body | EZS-Electronic ignition lock | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Body | SG-SW-Control unit 'Headlamp' (N71/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | C-Class | 204 | Body | IRS-HRA-Outer right rear intelligent radar sensor | ● | ● | ○ | ● | ○ | ● |
| ALL | C-Class | 204 | Body | IRS-HLA-Outer left rear intelligent radar sensor system (B29/4) | ● | ● | ○ | ● | ○ | ● |
| ALL | C-Class | 204 | Body | SGR-Radar sensors control unit | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |
| ALL | C-Class | 204 | Body | RFK-Backup camera (B84/3) | ● | ● | ○ | ● | ○ | ● |
| ALL | C-Class | 204 | Body | Rear SAM-Rear signal acquisition and actuation module | ● | ● | ○ | ● | ○ | ● |
| ALL | C-Class | 204 | Body | SCM-Steering column module(N80) | ● | ● | ○ | ● | ○ | ● |
| ALL | C-Class | 204 | Body | SGR-Radar sensors control unit | ● | ● | ● | ● | ○ | ● |
| ALL | C-Class | 204 | Information and communication | ES-Electrical power steering | ● | ● | ● | ● | ● | ○ |
| ALL | C-Class | 204 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Information and communication | IC-Instrument cluster (A1) | ● | ● | ○ | ● | ○ | ● |
| ALL | C-Class | 204 | Information and communication | IC-Instrument cluster (A1) | ● | ● | ○ | ● | ○ | ● |
| ALL | C-Class | 204 | Information and communication | ICI-InCar Internet (N125/3) | ● | ● | ○ | ● | ○ | ● |
| ALL | C-Class | 204 | Information and communication | PTS-Parktronic | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Information and communication | PTS-PARKTRONIC (N62) | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Information and communication | PTS-PARKTRONIC (N62) | ● | ● | ○ | ● | ○ | ● |
| ALL | C-Class | 204 | Information and communication | RFK-Backup camera(B84/3) | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Information and communication | SCCM-Steering column module(N80) | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Information and communication | COMAND or AUDIO | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|---------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | C-Class | 204 | Information and communication | COMAND or AUDIO | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Information and communication | Audio-Audio or COMAND (A2-A40/3) | ● | ● | ○ | ● | ○ | ● |
| ALL | C-Class | 204 | Information and communication | COU [ZBE]-Central operating unit | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Information and communication | ZBE-Audio/COMAND operating unit(A40/9) | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Information and communication | ZAN-Central display | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Information and communication | TV-TV tuner | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Information and communication | TV-TV tuner(AGW) | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Information and communication | CTEL-Cellular telephone(JAPAN) | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Information and communication | DAB-Digital radio | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Information and communication | DAB-Digital Audio Broadcasting (N87/3) | ● | ● | ○ | ● | ○ | ● |
| ALL | C-Class | 204 | Information and communication | Sound system (Main amplifier) | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Information and communication | SDAR-Satellite radio(Valid for USA) | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Information and communication | UCI-Media interface | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Information and communication | AVE-H-Rear audio video unit | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Information and communication | Left rear screen | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Information and communication | Right rear screen | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Information and communication | TELE AID-Control unit | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Information and communication | TELE AID-Telematic services Emergency call | ● | ● | ● | ● | | ● |
| ALL | C-Class | 204 | Information and communication | TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE) | ● | ● | ● | ● | | ● |
| ALL | C-Class | 204 | Information and communication | TELE AID-Telematic services Stolen vehicle tracking | ● | ● | ● | ● | | ● |
| ALL | C-Class | 204 | Information and communication | TELE AID-Telematic services Remote door unlocking,Remote door locking | ● | ● | ● | ● | | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | C-Class | 204 | Information and communication | AMG PM-AMG Performance Media(N125/2) | ● | ● | ○ | ● | ○ | ● |
| ALL | C-Class | 204 | Information and communication | AMG DRVU-AMG DRIVE UNIT (N145) | ● | ● | ○ | ● | ○ | ● |
| ALL | C-Class | 204 | Information and communication | Drive-side SAM-Front signal acquisition and actuation module (N10/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | C-Class | 204 | Information and communication | MFK-Multifunction camera | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |
| ALL | C-Class | 204 | Information and communication | NAV-Navigation module (A2/30) | ● | ● | ○ | ● | ○ | ● |
| ALL | C-Class | 204 | Information and communication | 360° camera-360° camera(N148) | ● | ● | ○ | ● | ○ | ● |
| ALL | C-Class | 204 | Information and communication | NAVI20 - Navigation(N125/2) | ● | ● | ○ | ● | ○ | ● |
| ALL | C-Class | 204 | Seats and doors | DCM-FL-Door control module front left | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Seats and doors | DCU-LF-Left front door | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Seats and doors | DCM-FR-Door control module front right | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Seats and doors | DCU-RF-Right front door | ● | ● | ● | ● | ● | ▲ |
| ALL | C-Class | 204 | Seats and doors | DCM-RL-Door control module rear left | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Seats and doors | DCU-LR-Left rear door | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Seats and doors | DCM-RR-Door control module rear right | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Seats and doors | DCU-RR-Right rear door | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Seats and doors | HKS-Tailgate control (N121/1) | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Seats and doors | ESA driver | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Seats and doors | ESA 'Driver'-Electric seat adjustment 'Driver' (N32/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | C-Class | 204 | Seats and doors | ESA passenger | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Seats and doors | ESA-Electirc seat adjustment 'Front passenger' (N32/2) | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Seats and doors | ESA' Front passenger'-Electric seat adjustment 'Front passenger' with memory function(N32/2) | ● | ● | ○ | ● | ○ | ● |
| ALL | C-Class | 204 | Air conditioning | Stationary heater | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Air conditioning | AAC-Air conditioning (N22/7) | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Air conditioning | AAC-Air conditioning (N22/7) | ● | ● | ● | ● | ● | ● |
| ALL | C-Class | 204 | Air conditioning | EKMK-Electric refrigerant compressor (A9/5) | ● | ● | ○ | ● | ○ | ● |
| ALL | C-Class | 204 | LIN Bus | LCP-Lower control panel (S77) | ● | ● | ○ | ● | ○ | ● |
| ALL | C-Class | 204 | LIN Bus | GTO-Garage door opener (A67n2) | ● | ● | ○ | ● | ○ | ● |
| ALL | C-Class | 204 | LIN Bus | AMLAB-L 1-Actuation module 1, LED exterior lighting, left front (E1n7) | ● | ● | ○ | ● | ○ | ● |
| ALL | C-Class | 204 | LIN Bus | AMLAB-R 1-Actuation module 1, LED exterior lighting, right front (E2n7) | ● | ● | ○ | ● | ○ | ● |
| Up to 08/2003 | C-Class | 203 | Drive | ETC-Electronic transmission control | ● | ● | ○ | ● | ● | ※ |
| Up to 08/2003 | C-Class | 203 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Drive | SEQ-Sequentronic automated manual transmission | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| Up to 08/2003 | C-Class | 203 | Drive | ESM-Electronic selector module | ● | ● | ● | ● | ● | ○ |
| Up to 08/2003 | C-Class | 203 | Drive | ME-SFI-Motor electronics | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ※ |
| Up to 08/2003 | C-Class | 203 | Drive | ME-SFI-Motor electronics | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Drive | ME-SFI-Motor electronics | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Drive | CDI 2-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Drive | CDI 3-Common Rail Diesel Injection3 | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Drive | CDI 2-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Chassis | BAS-Brake assist | ● | ● | ○ | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Chassis | VP-Vacuum pump brake booster | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ○ |
| Up to 08/2003 | C-Class | 203 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ○ |
| Up to 08/2003 | C-Class | 203 | Body | AB-Airbag | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ○ |
| Up to 08/2003 | C-Class | 203 | Body | LCP-Lower control panel | ● | ● | ● | ● | ● | ○ |
| Up to 08/2003 | C-Class | 203 | Body | UCP-Upper control panel | ● | ● | ● | ● | ● | ○ |
| Up to 08/2003 | C-Class | 203 | Body | SAM-F-Signal acquisition and actuation module front | ● | ● | ● | ● | ● | ○ |
| Up to 08/2003 | C-Class | 203 | Body | REAR SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ● | ○ |
| Up to 08/2003 | C-Class | 203 | Body | AHE-Trailer recognition | ● | ● | ● | ● | ● | ○ |
| Up to 08/2003 | C-Class | 203 | Body | MSS-Special vehicle multifunction control module | ● | ● | ● | ● | ● | ○ |
| Up to 08/2003 | C-Class | 203 | Body | HRA-FR-Front right headlamp range control | ● | ● | ● | ● | ● | ○ |
| Up to 08/2003 | C-Class | 203 | Body | HRA-FL-Front left headlamp range control | ● | ● | ● | ● | ● | ○ |
| Up to 08/2003 | C-Class | 203 | Body | CGW-Central gateway | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Body | AB-Airbag | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Body | WSS-Weight sensing system | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Body | AHE-Trailer recognition | ● | ● | ● | ● | ● | ○ |
| Up to 08/2003 | C-Class | 203 | Body | System diagnosis (CAN) | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ○ |
| Up to 08/2003 | C-Class | 203 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Information and communication | TV-TV tuner | ● | ● | ● | ● | | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| Up to 08/2003 | C-Class | 203 | Information and communication | E-call [Japan]-Emergency call system | ● | ● | ○ | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Information and communication | E-call [Japan]-Telematic system | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Information and communication | E-call [USA]-Telematic system | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Information and communication | TELE AID-Telematic system | ● | ● | ● | ● | ● | |
| Up to 08/2003 | C-Class | 203 | Information and communication | CTEL over K-wire-Telematic system | ● | ● | ● | ● | ○ | ○ |
| Up to 08/2003 | C-Class | 203 | Information and communication | D2B-COMAND, MCS or AUDIO | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Information and communication | COMAND | ● | ● | ○ | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Information and communication | CDC-CD changer | ● | ● | ● | ● | ○ | ○ |
| Up to 08/2003 | C-Class | 203 | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ○ |
| Up to 08/2003 | C-Class | 203 | Information and communication | SOUND- Sound system | ● | ● | ○ | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Information and communication | CTEL- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ○ | ○ |
| Up to 08/2003 | C-Class | 203 | Information and communication | UHI- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ● | ○ |
| Up to 08/2003 | C-Class | 203 | Information and communication | SDAR-Satellite radio | ● | ● | ● | ● | ○ | ● |
| Up to 08/2003 | C-Class | 203 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ○ |
| Up to 08/2003 | C-Class | 203 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Information and communication | COMAND or AUDIO | ● | ● | ○ | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Information and communication | CTEL-Mobile phone adapter with universal interface | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|-------------------------|---------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| Up to 08/2003 | C-Class | 203 | Information and communication | CDC-CD changer | ● | ● | ○ | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ● |
| Up to 08/2003 | C-Class | 203 | Information and communication | SOUND- Sound system | ● | ● | ○ | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Information and communication | TV-TV tuner | ● | ● | ○ | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Information and communication | SDAR-Satellite radio | ● | ● | ○ | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Information and communication | NAVI-Navigation system | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Information and communication | TELE AID-Control unit | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Information and communication | TELE AID-Telematic services Emergency call | ● | ● | ● | ● | | ● |
| Up to 08/2003 | C-Class | 203 | Information and communication | TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE) | ● | ● | ● | ● | | ● |
| Up to 08/2003 | C-Class | 203 | Information and communication | TELE AID-Telematic services Stolen vehicle tracking | ● | ● | ● | ● | | ● |
| Up to 08/2003 | C-Class | 203 | Information and communication | TELE AID-Telematic services Remote door unlocking,Remote door locking | ● | ● | ● | ● | | ● |
| Up to 08/2003 | C-Class | 203 | Information and communication | CTEL-Cellular telephone | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Seats and doors | DCM-FL-Door control module front left | ● | ● | ● | ● | ● | ○ |
| Up to 08/2003 | C-Class | 203 | Seats and doors | DCM-FR-Door control module front right | ● | ● | ● | ● | ● | ○ |
| Up to 08/2003 | C-Class | 203 | Seats and doors | DCM-RL-Door control module rear left | ● | ● | ● | ● | ● | ○ |
| Up to 08/2003 | C-Class | 203 | Seats and doors | DCM-RR-Door control module rear right | ● | ● | ● | ● | ● | ○ |
| Up to 08/2003 | C-Class | 203 | Seats and doors | ESA passenger-Electric seat adjustment passenger | ● | ● | ● | ● | ● | ○ |
| Up to 08/2003 | C-Class | 203 | Seats and doors | ESA passenger-Electric seat adjustment passenger | ● | ● | ● | ● | ● | ○ |
| Up to 08/2003 | C-Class | 203 | Seats and doors | ESA passenger-Electric seat adjustment passenger | ● | ● | ● | ● | ● | ○ |
| Up to 08/2003 | C-Class | 203 | Seats and doors | ESA driver-Electric seat adjustment driver | ● | ● | ● | ● | ● | ○ |
| Up to 08/2003 | C-Class | 203 | Seats and doors | ESA driver-Electric seat adjustment driver | ● | ● | ● | ● | ● | ○ |
| Up to 08/2003 | C-Class | 203 | Seats and doors | ESA driver-Electric seat adjustment driver (with | ● | ● | ● | ● | ● | ○ |
| Up to 08/2003 | C-Class | 203 | Air conditioning | AAC-Automatic air conditioning | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Air conditioning | STH-Stationary heater | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | C-Class | 203 | Air conditioning | STH-Stationary heater | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 12/2007 | C-Class | 203 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 12/2007 | C-Class | 203 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|-------------------------|---------|--------------|---------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| From 09/2003 to 12/2007 | C-Class | 203 | Drive | SEQ-Sequentronic automated manual transmission | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 12/2007 | C-Class | 203 | Drive | ESM-Electronic selector module | ● | ● | ● | ● | ● | ○ |
| From 09/2003 to 12/2007 | C-Class | 203 | Drive | ME-SFI-Motor electronics | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 12/2007 | C-Class | 203 | Drive | ME-SFI-Motor electronics | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 12/2007 | C-Class | 203 | Drive | ME 9.7-Motor electronics 9.7 | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 12/2007 | C-Class | 203 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 12/2007 | C-Class | 203 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 12/2007 | C-Class | 203 | Drive | CDI 3-Common Rail Diesel Injection3 | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 12/2007 | C-Class | 203 | Drive | CDI 2-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 12/2007 | C-Class | 203 | Drive | CDI 2-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 12/2007 | C-Class | 203 | Drive | CDI 4-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 12/2007 | C-Class | 203 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 12/2007 | C-Class | 203 | Body | CGW-Central gateway | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 12/2007 | C-Class | 203 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ○ |
| From 09/2003 to 12/2007 | C-Class | 203 | Body | AB-Airbag | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 12/2007 | C-Class | 203 | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ○ |
| From 09/2003 to 12/2007 | C-Class | 203 | Body | WSS-Weight sensing system | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 12/2007 | C-Class | 203 | Body | LCP-Lower control panel | ● | ● | ● | ● | ● | ○ |
| From 09/2003 to 12/2007 | C-Class | 203 | Body | UCP-Upper control panel | ● | ● | ● | ● | ● | ○ |
| From 09/2003 to 12/2007 | C-Class | 203 | Body | SAM-F-Signal acquisition and actuation module front | ● | ● | ● | ● | ● | ○ |
| From 09/2003 to 12/2007 | C-Class | 203 | Body | REAR SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ● | ○ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|-------------------------|---------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| From 09/2003 to 12/2007 | C-Class | 203 | Body | AHE-Trailer recognition | ● | ● | ● | ● | ● | ○ |
| From 09/2003 to 12/2007 | C-Class | 203 | Body | AHE-Trailer recognition | ● | ● | ● | ● | ● | ○ |
| From 09/2003 to 12/2007 | C-Class | 203 | Body | MSS-Special vehicle multifunction control module | ● | ● | ● | ● | ● | ○ |
| From 09/2003 to 12/2007 | C-Class | 203 | Body | HRA-FR-Front right headlamp range control | ● | ● | ● | ● | ● | ○ |
| From 09/2003 to 12/2007 | C-Class | 203 | Body | HRA-FL-Front left headlamp range control | ● | ● | ● | ● | ● | ○ |
| From 09/2003 to 12/2007 | C-Class | 203 | Body | System diagnosis (CAN) | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 12/2007 | C-Class | 203 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ○ |
| From 09/2003 to 12/2007 | C-Class | 203 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 12/2007 | C-Class | 203 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 12/2007 | C-Class | 203 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 12/2007 | C-Class | 203 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 12/2007 | C-Class | 203 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 12/2007 | C-Class | 203 | Information and communication | COMAND or AUDIO | ● | ● | ○ | ● | ● | ● |
| From 09/2003 to 12/2007 | C-Class | 203 | Information and communication | CTEL-Mobile phone adapter with universal interface | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 12/2007 | C-Class | 203 | Information and communication | CDC-CD changer | ● | ● | ○ | ● | ● | ● |
| From 09/2003 to 12/2007 | C-Class | 203 | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ● |
| From 09/2003 to 12/2007 | C-Class | 203 | Information and communication | SOUND- Sound system | ● | ● | ○ | ● | ● | ● |
| From 09/2003 to 12/2007 | C-Class | 203 | Information and communication | TV-TV tuner | ● | ● | ○ | ● | ● | ● |
| From 09/2003 to 12/2007 | C-Class | 203 | Information and communication | SDAR-Satellite radio | ● | ● | ○ | ● | ● | ● |
| From 09/2003 to 12/2007 | C-Class | 203 | Information and communication | NAVI-Navigation system | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 12/2007 | C-Class | 203 | Information and communication | TELE AID-Control unit | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|-------------------------|---------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| From 09/2003 to 12/2007 | C-Class | 203 | Information and communication | TELE AID-Telematic services Emergency call | ● | ● | ● | ● | | ● |
| From 09/2003 to 12/2007 | C-Class | 203 | Information and communication | TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE) | ● | ● | ● | ● | | ● |
| From 09/2003 to 12/2007 | C-Class | 203 | Information and communication | TELE AID-Telematic services Stolen vehicle tracking | ● | ● | ● | ● | | ● |
| From 09/2003 to 12/2007 | C-Class | 203 | Information and communication | TELE AID-Telematic services Remote door unlocking,Remote door locking | ● | ● | ● | ● | | ● |
| From 09/2003 to 12/2007 | C-Class | 203 | Information and communication | CTEL-Cellular telephone | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 12/2007 | C-Class | 203 | Seats and doors | DCM-FL-Door control module front left | ● | ● | ● | ● | ● | ○ |
| From 09/2003 to 12/2007 | C-Class | 203 | Seats and doors | DCM-FR-Door control module front right | ● | ● | ● | ● | ● | ○ |
| From 09/2003 to 12/2007 | C-Class | 203 | Seats and doors | DCM-RL-Door control module rear left | ● | ● | ● | ● | ● | ○ |
| From 09/2003 to 12/2007 | C-Class | 203 | Seats and doors | DCM-RR-Door control module rear right | ● | ● | ● | ● | ● | ○ |
| From 09/2003 to 12/2007 | C-Class | 203 | Seats and doors | ESA passenger-Electric seat adjustment passenger | ● | ● | ● | ● | ● | ○ |
| From 09/2003 to 12/2007 | C-Class | 203 | Seats and doors | ESA passenger-Electric seat adjustment passenger | ● | ● | ● | ● | ● | ○ |
| From 09/2003 to 12/2007 | C-Class | 203 | Seats and doors | ESA passenger-Electric seat adjustment passenger | ● | ● | ● | ● | ● | ○ |
| From 09/2003 to 12/2007 | C-Class | 203 | Seats and doors | ESA driver-Electric seat adjustment driver | ● | ● | ● | ● | ● | ○ |
| From 09/2003 to 12/2007 | C-Class | 203 | Seats and doors | ESA driver-Electric seat adjustment driver | ● | ● | ● | ● | ● | ○ |
| From 09/2003 to 12/2007 | C-Class | 203 | Seats and doors | ESA driver-Electric seat adjustment driver (with memory) | ● | ● | ● | ● | ● | ○ |
| From 09/2003 to 12/2007 | C-Class | 203 | Air conditioning | AAC-Automatic air conditioning | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 12/2007 | C-Class | 203 | Air conditioning | STH-Stationary heater | ● | ● | ● | ● | ● | ● |
| As of 01/2008 | C-Class | 203 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| As of 01/2008 | C-Class | 203 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| As of 01/2008 | C-Class | 203 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| As of 01/2008 | C-Class | 203 | Drive | ESM-Electronic selector module | ● | ● | ● | ● | ● | ○ |
| As of 01/2008 | C-Class | 203 | Drive | ME-SFI-Motor electronics | ● | ● | ● | ● | ● | ● |
| As of 01/2008 | C-Class | 203 | Drive | ME 9.7-Motor electronics 9.7 | ● | ● | ● | ● | ● | ● |
| As of 01/2008 | C-Class | 203 | Drive | CDI 3-Common Rail Diesel Injection3 | ● | ● | ● | ● | ● | ● |
| As of 01/2008 | C-Class | 203 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| As of 01/2008 | C-Class | 203 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ○ |
| As of 01/2008 | C-Class | 203 | Body | AB-Airbag | ● | ● | ● | ● | ● | ● |
| As of 01/2008 | C-Class | 203 | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ○ |
| As of 01/2008 | C-Class | 203 | Body | LCP-Lower control panel | ● | ● | ● | ● | ● | ○ |
| As of 01/2008 | C-Class | 203 | Body | UCP-Upper control panel | ● | ● | ● | ● | ● | ○ |
| As of 01/2008 | C-Class | 203 | Body | SAM-F-Signal acquisition and actuation module front | ● | ● | ● | ● | ● | ○ |
| As of 01/2008 | C-Class | 203 | Body | REAR SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ● | ○ |
| As of 01/2008 | C-Class | 203 | Body | MSS-Special vehicle multifunction control module | ● | ● | ● | ● | ● | ○ |
| As of 01/2008 | C-Class | 203 | Body | XALWA-L-Xenon headlamp, left | ● | ● | ● | ● | ● | ● |
| As of 01/2008 | C-Class | 203 | Body | XALWA-R-Xenon headlamp, right | ● | ● | ● | ● | ● | ● |
| As of 01/2008 | C-Class | 203 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ○ |
| As of 01/2008 | C-Class | 203 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ○ |
| As of 01/2008 | C-Class | 203 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ● |
| As of 01/2008 | C-Class | 203 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| As of 01/2008 | C-Class | 203 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| As of 01/2008 | C-Class | 203 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| As of 01/2008 | C-Class | 203 | Information and communication | COMAND or AUDIO | ● | ● | ○ | ● | ● | ● |
| As of 01/2008 | C-Class | 203 | Information and communication | CTEL-Mobile phone adapter with universal interface | ● | ● | ● | ● | ● | ● |
| As of 01/2008 | C-Class | 203 | Information and communication | CDC-CD changer | ● | ● | ○ | ● | ● | ● |
| As of 01/2008 | C-Class | 203 | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ● |
| As of 01/2008 | C-Class | 203 | Information and communication | SOUND- Sound system | ● | ● | ○ | ● | ● | ● |
| As of 01/2008 | C-Class | 203 | Information and communication | SDAR-Satellite radio | ● | ● | ○ | ● | ● | ● |
| As of 01/2008 | C-Class | 203 | Information and communication | NAVI-Navigation system | ● | ● | ○ | ● | ● | ● |
| As of 01/2008 | C-Class | 203 | Information and communication | COMAND or AUDIO | ● | ● | ● | ● | ● | ● |
| As of 01/2008 | C-Class | 203 | Information and communication | Sound system (Main amplifier) | ● | ● | ● | ● | ● | ● |
| As of 01/2008 | C-Class | 203 | Information and communication | UCI-Media interface | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| As of 01/2008 | C-Class | 203 | Information and communication | DAB-Digital radio | ● | ● | ● | ● | ● | ○ |
| As of 01/2008 | C-Class | 203 | Information and communication | SDAR-Satellite radio(Valid for USA) | ● | ● | ● | ● | ● | ● |
| As of 01/2008 | C-Class | 203 | Information and communication | CTEL-Cellular telephone(JAPAN) | ● | ● | ● | ● | ● | ○ |
| As of 01/2008 | C-Class | 203 | Seats and doors | DCM-FL-Door control module front left | ● | ● | ● | ● | ● | ○ |
| As of 01/2008 | C-Class | 203 | Seats and doors | DCM-FR-Door control module front right | ● | ● | ● | ● | ● | ○ |
| As of 01/2008 | C-Class | 203 | Seats and doors | ESA passenger-Electric seat adjustment passenger | ● | ● | ● | ● | ● | ○ |
| As of 01/2008 | C-Class | 203 | Seats and doors | ESA driver-Electric seat adjustment driver (with | ● | ● | ● | ● | ● | ○ |
| As of 01/2008 | C-Class | 203 | Air conditioning | AAC-Automatic air conditioning | ● | ● | ● | ● | ● | ● |
| As of 01/2008 | C-Class | 203 | Air conditioning | STH-Stationary heater | ● | ● | ● | ● | ● | ● |
| As of 06/97 | C-Class | 202 | Drive | ETC-Electronic transmission control | ● | ● | ○ | ● | | ※ |
| As of 06/97 | C-Class | 202 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| As of 06/97 | C-Class | 202 | Drive | ETC-Electronic transmission control | ● | ● | ○ | ● | ● | ※ |
| As of 06/97 | C-Class | 202 | Drive | ESM-Electronic selector module | ● | ● | ○ | ● | ● | ※ |
| As of 06/97 | C-Class | 202 | Drive | ME2-SFI-Motor electronics 2 | ● | ● | ○ | ● | ● | ※ |
| As of 06/97 | C-Class | 202 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| As of 06/97 | C-Class | 202 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| As of 06/97 | C-Class | 202 | Drive | DFI-Electronic distributor injection system diesel | ● | ● | ○ | ● | | ※ |
| As of 06/97 | C-Class | 202 | Drive | IFI-Electronic in-line injection system diesel | ● | ● | ○ | ● | | ※ |
| As of 06/97 | C-Class | 202 | Drive | CDI-Common Rail Diesel Injection | ● | ● | ○ | ● | | ※ |
| As of 06/97 | C-Class | 202 | Drive | ME-SFI-Motor electronics | ● | ● | ● | ● | ● | ● |
| As of 06/97 | C-Class | 202 | Chassis | ABS-Antilock brake system | ● | ● | ○ | ● | ● | ※ |
| As of 06/97 | C-Class | 202 | Chassis | ASR-Acceleration Slip Regulation | ● | ● | ○ | ● | ● | ※ |
| As of 06/97 | C-Class | 202 | Chassis | ESP-Electronic stability program | ● | ● | ○ | ● | ● | ※ |
| As of 06/97 | C-Class | 202 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| As of 06/97 | C-Class | 202 | Chassis | ASR-Acceleration Slip Regulation | ● | ● | ○ | ● | ● | ※ |
| As of 06/97 | C-Class | 202 | Chassis | ESP-Electronic stability program | ● | ● | ○ | ● | ● | ※ |
| As of 06/97 | C-Class | 202 | Chassis | ETS-Electronic traction system | ● | ● | ○ | ● | ● | ※ |
| As of 06/97 | C-Class | 202 | Chassis | ESP-Electronic stability program | ● | ● | ○ | ● | ● | ※ |
| As of 06/97 | C-Class | 202 | Chassis | ETS-Electronic traction system | ● | ● | ○ | ● | ● | ※ |
| As of 06/97 | C-Class | 202 | Chassis | BAS-Brake assist | ● | ● | ○ | ● | ● | ※ |
| As of 06/97 | C-Class | 202 | Chassis | BAS-Brake assist | ● | ● | ○ | ● | ● | ● |
| As of 06/97 | C-Class | 202 | Chassis | VP-Vacuum pump brake booster | ● | ● | ● | ● | ● | ● |
| As of 06/97 | C-Class | 202 | Body | AB-Airbag | ● | ● | ○ | ● | | ※ |
| As of 06/97 | C-Class | 202 | Body | EZS-Electronic ignition switch | ● | ● | ○ | ● | ● | ※ |
| As of 06/97 | C-Class | 202 | Body | OCP-Overhead control panel | ● | ● | ○ | ● | ● | ※ |
| As of 06/97 | C-Class | 202 | Body | LCP-Lower control panel | ● | ● | ○ | ● | ● | ※ |
| As of 06/97 | C-Class | 202 | Body | PSE-Pneumatic system equipment | ● | ● | ○ | ● | ● | ※ |
| As of 06/97 | C-Class | 202 | Body | SAM-Signal acquisition and actuation module | ● | ● | ○ | ● | ● | ※ |
| As of 06/97 | C-Class | 202 | Body | MSS-Special vehicle multifunction control module | ● | ● | ○ | ● | ● | ※ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| As of 06/97 | C-Class | 202 | Body | HRA-Headlamp range adjustment | ● | ● | ○ | ● | | ※ |
| As of 06/97 | C-Class | 202 | Body | APS-Auto pilot system | ● | ● | ○ | ● | ● | ※ |
| As of 06/97 | C-Class | 202 | Body | HB-Heater booster | ● | ● | ○ | ● | | ※ |
| As of 06/97 | C-Class | 202 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ○ | ● | ● | ※ |
| As of 06/97 | C-Class | 202 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| As of 06/97 | C-Class | 202 | Information and communication | CTEL- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ○ | ○ |
| As of 06/97 | C-Class | 202 | Information and communication | UHI- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ● | ○ |
| As of 06/97 | C-Class | 202 | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ○ |
| As of 06/97 | C-Class | 202 | Information and communication | CDC-CD changer | ● | ● | ● | ● | ○ | ○ |
| As of 06/97 | C-Class | 202 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ※ |
| As of 06/97 | C-Class | 202 | Information and communication | E-call [Japan]-Emergency call system | ● | ● | ○ | ● | ● | ● |
| As of 06/97 | C-Class | 202 | Information and communication | E-call [USA]-Emergency call system | ● | ● | ● | ● | ○ | ○ |
| As of 06/97 | C-Class | 202 | Information and communication | TELE AID-Emergency call system | ● | ● | ● | ● | ● | ● |
| As of 06/97 | C-Class | 202 | Information and communication | TELE AID-Telematic system | ● | ● | ○ | ● | | ● |
| As of 06/97 | C-Class | 202 | Information and communication | DN-Dynamic navigation by means of CTEL | ● | ● | ● | ● | ● | ○ |
| As of 06/97 | C-Class | 202 | Seats and doors | DCM1-Door control module front driver side | ● | ● | ○ | ● | ● | ※ |
| As of 06/97 | C-Class | 202 | Seats and doors | DCM2-Door control module front passenger side | ● | ● | ○ | ● | ● | ※ |
| As of 06/97 | C-Class | 202 | Seats and doors | DCM3-Door control module rear driver side | ● | ● | ○ | ● | ● | ※ |
| As of 06/97 | C-Class | 202 | Seats and doors | DCM4-Door control module rear passenger side | ● | ● | ○ | ● | ● | ※ |
| As of 06/97 | C-Class | 202 | Air conditioning | TAC-Automatic temperature control | ● | ● | ○ | ● | | ※ |
| As of 06/97 | C-Class | 202 | Air conditioning | AAC-Automatic air conditioning | ● | ● | ○ | ● | | ※ |
| As of 06/97 | C-Class | 202 | Air conditioning | STH-Stationary heater | ● | ● | ○ | ● | ● | ※ |
| Up to 03/2004 | CLK | 209 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| Up to 03/2004 | CLK | 209 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| Up to 03/2004 | CLK | 209 | Drive | SEQ-Sequentronic automated manual transmission | ● | ● | ● | ● | ● | ● |
| Up to 03/2004 | CLK | 209 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| Up to 03/2004 | CLK | 209 | Drive | ESM-Electronic selector module | ● | ● | ● | ● | ● | ○ |
| Up to 03/2004 | CLK | 209 | Drive | ME-SFI-Motor electronics | ● | ● | ● | ● | ● | ● |
| Up to 03/2004 | CLK | 209 | Drive | ME-SFI-Motor electronics | ● | ● | ● | ● | ● | ● |
| Up to 03/2004 | CLK | 209 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ※ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|-------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| Up to 03/2004 | CLK | 209 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| Up to 03/2004 | CLK | 209 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| Up to 03/2004 | CLK | 209 | Drive | CDI 2-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| Up to 03/2004 | CLK | 209 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| Up to 03/2004 | CLK | 209 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ○ |
| Up to 03/2004 | CLK | 209 | Body | AB-Airbag | ● | ● | ● | ● | ● | ● |
| Up to 03/2004 | CLK | 209 | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ○ |
| Up to 03/2004 | CLK | 209 | Body | LCP-Lower control panel | ● | ● | ● | ● | ● | ○ |
| Up to 03/2004 | CLK | 209 | Body | UCP-Upper control panel | ● | ● | ● | ● | ● | ○ |
| Up to 03/2004 | CLK | 209 | Body | SAM-F-Signal acquisition and actuation module front | ● | ● | ● | ● | ● | ○ |
| Up to 03/2004 | CLK | 209 | Body | REAR SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ● | ○ |
| Up to 03/2004 | CLK | 209 | Body | AHE-Trailer recognition | ● | ● | ● | ● | ● | ○ |
| Up to 03/2004 | CLK | 209 | Body | MSS-Special vehicle multifunction control module | ● | ● | ● | ● | ● | ○ |
| Up to 03/2004 | CLK | 209 | Body | RVC-Rollover bar soft top control module | ● | ● | ● | ● | ● | ○ |
| Up to 03/2004 | CLK | 209 | Body | HRA-FR-Front right headlamp range control | ● | ● | ● | ● | ● | ○ |
| Up to 03/2004 | CLK | 209 | Body | HRA-FL-Front left headlamp range control | ● | ● | ● | ● | ● | ○ |
| Up to 03/2004 | CLK | 209 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ○ |
| Up to 03/2004 | CLK | 209 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ● |
| Up to 03/2004 | CLK | 209 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ● |
| Up to 03/2004 | CLK | 209 | Information and communication | TV-TV tuner | ● | ● | ● | ● | | ● |
| Up to 03/2004 | CLK | 209 | Information and communication | E-call [Japan]-Telematic system | ● | ● | ● | ● | ● | ● |
| Up to 03/2004 | CLK | 209 | Information and communication | E-call [USA]-Telematic system | ● | ● | ● | ● | ● | ● |
| Up to 03/2004 | CLK | 209 | Information and communication | TELE AID-Telematic system | ● | ● | ● | ● | ● | |
| Up to 03/2004 | CLK | 209 | Information and communication | CTEL over K-wire-Telematic system | ● | ● | ● | ● | ○ | ○ |
| Up to 03/2004 | CLK | 209 | Information and communication | TELE AID-Control unit | ● | ● | ● | ● | ● | ● |
| Up to 03/2004 | CLK | 209 | Information and communication | TELE AID-Telematic services Emergency call | ● | ● | ● | ● | | ● |
| Up to 03/2004 | CLK | 209 | Information and communication | TELE AID-Telematic services MB Info, Roadside assistance (USA, Canada), Tele diagnosis (ECE) | ● | ● | ● | ● | | ● |
| Up to 03/2004 | CLK | 209 | Information and communication | TELE AID-Telematic services Stolen vehicle tracking | ● | ● | ● | ● | | ● |
| Up to 03/2004 | CLK | 209 | Information and communication | TELE AID-Telematic services Remote door unlocking, Remote door locking | ● | ● | ● | ● | | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|-------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| Up to 03/2004 | CLK | 209 | Information and communication | D2B-COMAND, MCS or AUDIO | ● | ● | ● | ● | ● | ● |
| Up to 03/2004 | CLK | 209 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| Up to 03/2004 | CLK | 209 | Information and communication | COMAND | ● | ● | ○ | ● | ● | ● |
| Up to 03/2004 | CLK | 209 | Information and communication | CDC-CD changer | ● | ● | ● | ● | ○ | ○ |
| Up to 03/2004 | CLK | 209 | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ○ |
| Up to 03/2004 | CLK | 209 | Information and communication | SOUND- Sound system | ● | ● | ○ | ● | ● | ● |
| Up to 03/2004 | CLK | 209 | Information and communication | SDAR-Satellite radio | ● | ● | ● | ● | ○ | ● |
| Up to 03/2004 | CLK | 209 | Information and communication | CTEL- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ○ | ○ |
| Up to 03/2004 | CLK | 209 | Information and communication | UHI- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ● | ○ |
| Up to 03/2004 | CLK | 209 | Seats and doors | ESA passenger-Electric seat adjustment passenger | ● | ● | ● | ● | ● | ○ |
| Up to 03/2004 | CLK | 209 | Seats and doors | ESA passenger-Electric seat adjustment passenger | ● | ● | ● | ● | ● | ○ |
| Up to 03/2004 | CLK | 209 | Seats and doors | ESA driver-Electric seat adjustment driver | ● | ● | ● | ● | ● | ○ |
| Up to 03/2004 | CLK | 209 | Seats and doors | ESA driver-Electric seat adjustment driver (with | ● | ● | ● | ● | ● | ○ |
| Up to 03/2004 | CLK | 209 | Seats and doors | DCM-L-Door control module left | ● | ● | ● | ● | ● | ○ |
| Up to 03/2004 | CLK | 209 | Seats and doors | DCM-R-Door control module right | ● | ● | ● | ● | ● | ○ |
| Up to 03/2004 | CLK | 209 | Seats and doors | TLC-Trunk lid control | ● | ● | ● | ● | ● | ● |
| Up to 03/2004 | CLK | 209 | Seats and doors | RCM-Rear control module | ● | ● | ● | ● | ● | ○ |
| Up to 03/2004 | CLK | 209 | Air conditioning | AAC-Automatic air conditioning | ● | ● | ● | ● | ● | ● |
| Up to 03/2004 | CLK | 209 | Air conditioning | STH-Stationary heater | ● | ● | ● | ● | ● | ● |
| As of 04/2004 | CLK | 209 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| As of 04/2004 | CLK | 209 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| As of 04/2004 | CLK | 209 | Drive | SEQ-Sequentronic automated manual transmission | ● | ● | ● | ● | ● | ● |
| As of 04/2004 | CLK | 209 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| As of 04/2004 | CLK | 209 | Drive | ESM-Electronic selector module | ● | ● | ● | ● | ● | ○ |
| As of 04/2004 | CLK | 209 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ● |
| As of 04/2004 | CLK | 209 | Drive | ME-SFI-Motor electronics | ● | ● | ● | ● | ● | ● |
| As of 04/2004 | CLK | 209 | Drive | ME-SFI-Motor electronics | ● | ● | ● | ● | ● | ● |
| As of 04/2004 | CLK | 209 | Drive | ME 9.7-Motor electronics 9.7 | ● | ● | ● | ● | ● | ● |
| As of 04/2004 | CLK | 209 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| As of 04/2004 | CLK | 209 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| As of 04/2004 | CLK | 209 | Drive | ME 9.7 (AMG)-Motor electronics 9.7 (AMG) | ● | ● | ● | ● | ● | ● |
| As of 04/2004 | CLK | 209 | Drive | FSCU Left-Control unit 'Left fuel pump' | ● | ● | ● | ● | ● | ● |
| As of 04/2004 | CLK | 209 | Drive | FSCU Right-Control unit 'Right fuel pump' | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|-------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| As of 04/2004 | CLK | 209 | Drive | CDI 4-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| As of 04/2004 | CLK | 209 | Drive | CDI 3-Common Rail Diesel Injection3 | ● | ● | ● | ● | ● | ● |
| As of 04/2004 | CLK | 209 | Drive | CDI 3-Common Rail Diesel Injection3 | ● | ● | ● | ● | ● | ● |
| As of 04/2004 | CLK | 209 | Drive | CDI 2-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| As of 04/2004 | CLK | 209 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| As of 04/2004 | CLK | 209 | Chassis | TPC-Tire pressure monitor | ● | ● | ● | ● | ● | ● |
| As of 04/2004 | CLK | 209 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ○ |
| As of 04/2004 | CLK | 209 | Body | AB-Airbag | ● | ● | ● | ● | ● | ● |
| As of 04/2004 | CLK | 209 | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ○ |
| As of 04/2004 | CLK | 209 | Body | WSS-Weight sensing system | ● | ● | ● | ● | ● | ● |
| As of 04/2004 | CLK | 209 | Body | LCP-Lower control panel | ● | ● | ● | ● | ● | ○ |
| As of 04/2004 | CLK | 209 | Body | UCP-Upper control panel | ● | ● | ● | ● | ● | ○ |
| As of 04/2004 | CLK | 209 | Body | SAM-F-Signal acquisition and actuation module front | ● | ● | ● | ● | ● | ○ |
| As of 04/2004 | CLK | 209 | Body | REAR SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ● | ○ |
| As of 04/2004 | CLK | 209 | Body | AHE-Trailer recognition | ● | ● | ● | ● | ● | ○ |
| As of 04/2004 | CLK | 209 | Body | AHE-Trailer recognition | ● | ● | ● | ● | ● | ○ |
| As of 04/2004 | CLK | 209 | Body | MSS-Special vehicle multifunction control module | ● | ● | ● | ● | ● | ○ |
| As of 04/2004 | CLK | 209 | Body | RVC-Rollover bar soft top control module | ● | ● | ● | ● | ● | ○ |
| As of 04/2004 | CLK | 209 | Body | HRA-Automatic headlamp range adjustment and headlamp control | ● | ● | ● | ● | ● | ○ |
| As of 04/2004 | CLK | 209 | Body | HRA-FR-Front right headlamp range control | ● | ● | ● | ● | ● | ○ |
| As of 04/2004 | CLK | 209 | Body | HRA-FL-Front left headlamp range control | ● | ● | ● | ● | ● | ○ |
| As of 04/2004 | CLK | 209 | Body | On board electrical system(voltage supply) | ● | ● | ● | ● | ● | ● |
| As of 04/2004 | CLK | 209 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ○ |
| As of 04/2004 | CLK | 209 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ● |
| As of 04/2004 | CLK | 209 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ● |
| As of 04/2004 | CLK | 209 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| As of 04/2004 | CLK | 209 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| As of 04/2004 | CLK | 209 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| As of 04/2004 | CLK | 209 | Information and communication | COMAND or AUDIO | ● | ● | ○ | ● | ● | ● |
| As of 04/2004 | CLK | 209 | Information and communication | CTEL-Mobile phone adapter with universal interface | ● | ● | ● | ● | ● | ● |
| As of 04/2004 | CLK | 209 | Information and communication | CDC-CD changer | ● | ● | ○ | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|-------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| As of 04/2004 | CLK | 209 | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ● |
| As of 04/2004 | CLK | 209 | Information and communication | SOUND- Sound system | ● | ● | ○ | ● | ● | ● |
| As of 04/2004 | CLK | 209 | Information and communication | TV-TV tuner | ● | ● | ○ | ● | ● | ● |
| As of 04/2004 | CLK | 209 | Information and communication | TV-TV tuner(AGW) | ● | ● | ● | ● | ● | ● |
| As of 04/2004 | CLK | 209 | Information and communication | SDAR-Satellite radio | ● | ● | ○ | ● | ● | ● |
| As of 04/2004 | CLK | 209 | Information and communication | NAVI-Navigation system | ● | ● | ● | ● | ● | ● |
| As of 04/2004 | CLK | 209 | Information and communication | TELE AID-Control unit | ● | ● | ● | ● | ● | ● |
| As of 04/2004 | CLK | 209 | Information and communication | TELE AID-Telematic services Emergency call | ● | ● | ● | ● | | ● |
| As of 04/2004 | CLK | 209 | Information and communication | TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE) | ● | ● | ● | ● | | ● |
| As of 04/2004 | CLK | 209 | Information and communication | TELE AID-Telematic services Stolen vehicle tracking | ● | ● | ● | ● | | ● |
| As of 04/2004 | CLK | 209 | Information and communication | TELE AID-Telematic services Remote door unlocking,Remote door locking | ● | ● | ● | ● | | ● |
| As of 04/2004 | CLK | 209 | Seats and doors | ESA passenger-Electric seat adjustment passenger | ● | ● | ● | ● | ● | ○ |
| As of 04/2004 | CLK | 209 | Seats and doors | ESA passenger-Electric seat adjustment passenger | ● | ● | ● | ● | ● | ○ |
| As of 04/2004 | CLK | 209 | Seats and doors | ESA driver-Electric seat adjustment driver | ● | ● | ● | ● | ● | ○ |
| As of 04/2004 | CLK | 209 | Seats and doors | ESA driver-Electric seat adjustment driver (with | ● | ● | ● | ● | ● | ○ |
| As of 04/2004 | CLK | 209 | Seats and doors | DCM-L-Door control module left | ● | ● | ● | ● | ● | ○ |
| As of 04/2004 | CLK | 209 | Seats and doors | DCM-R-Door control module right | ● | ● | ● | ● | ● | ○ |
| As of 04/2004 | CLK | 209 | Seats and doors | TLC-Trunk lid control | ● | ● | ● | ● | ● | ● |
| As of 04/2004 | CLK | 209 | Seats and doors | RCM-Rear control module | ● | ● | ● | ● | ● | ○ |
| As of 04/2004 | CLK | 209 | Air conditioning | AAC-Automatic air conditioning | ● | ● | ● | ● | ● | ● |
| As of 04/2004 | CLK | 209 | Air conditioning | STH-Stationary heater | ● | ● | ● | ● | ● | ● |
| ALL | CLK | 208 | Drive | ETC-Electronic transmission control | ● | ● | ○ | ● | | ※ |
| ALL | CLK | 208 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| ALL | CLK | 208 | Drive | SEQ-Sequentronic automated manual transmission | ● | ● | ● | ● | ● | ● |
| ALL | CLK | 208 | Drive | ESM-Electronic selector module | ● | ● | ○ | ● | ● | ※ |
| ALL | CLK | 208 | Drive | ME2-SFI-Motor electronics 2 | ● | ● | ○ | ● | ● | ※ |
| ALL | CLK | 208 | Drive | ME-SFI-Motor electronics | ● | ● | ● | ● | ● | ● |
| ALL | CLK | 208 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| ALL | CLK | 208 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| ALL | CLK | 208 | Chassis | ABS-Antilock brake system | ● | ● | ○ | ● | ● | ※ |
| ALL | CLK | 208 | Chassis | ESP-Electronic stability program | ● | ● | ○ | ● | ● | ※ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|-------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | CLK | 208 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| ALL | CLK | 208 | Chassis | ASR-Acceleration Slip Regulation | ● | ● | ○ | ● | ● | ※ |
| ALL | CLK | 208 | Chassis | BAS-Brake assist | ● | ● | ○ | ● | ● | ※ |
| ALL | CLK | 208 | Chassis | BAS-Brake assist | ● | ● | ○ | ● | ● | ● |
| ALL | CLK | 208 | Chassis | VP-Vacuum pump brake booster | ● | ● | ● | ● | ● | ● |
| ALL | CLK | 208 | Body | AB-Airbag | ● | ● | ○ | ● | | ※ |
| ALL | CLK | 208 | Body | EZS-Electronic ignition switch | ● | ● | ○ | ● | ● | ※ |
| ALL | CLK | 208 | Body | OCP-Overhead control panel | ● | ● | ○ | ● | ● | ※ |
| ALL | CLK | 208 | Body | LCP-Lower control panel | ● | ● | ○ | ● | ● | ※ |
| ALL | CLK | 208 | Body | PSE-Pneumatic system equipment | ● | ● | ○ | ● | ● | ※ |
| ALL | CLK | 208 | Body | SAM-Signal acquisition and actuation module | ● | ● | ○ | ● | ● | ※ |
| ALL | CLK | 208 | Body | HRA-Headlamp range adjustment | ● | ● | ○ | ● | | ※ |
| ALL | CLK | 208 | Body | HRA-Headlamp range adjustment | ● | ● | ○ | ● | ● | ○ |
| ALL | CLK | 208 | Body | APS-Auto pilot system | ● | ● | ○ | ● | ● | ※ |
| ALL | CLK | 208 | Body | RVC-Rollover bar soft top control module | ● | ● | ○ | ● | | ※ |
| ALL | CLK | 208 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ○ | ● | ● | ※ |
| ALL | CLK | 208 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ● |
| ALL | CLK | 208 | Information and communication | COMAND | ● | ● | ○ | ● | ● | ● |
| ALL | CLK | 208 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| ALL | CLK | 208 | Information and communication | CTEL- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ○ | ○ |
| ALL | CLK | 208 | Information and communication | UHI- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ● | ○ |
| ALL | CLK | 208 | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ○ |
| ALL | CLK | 208 | Information and communication | CDC-CD changer | ● | ● | ● | ● | ○ | ○ |
| ALL | CLK | 208 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ※ |
| ALL | CLK | 208 | Information and communication | TV-TV tuner | ● | ● | ● | ● | | ● |
| ALL | CLK | 208 | Information and communication | E-call [Japan]-Emergency call system | ● | ● | ○ | ● | ● | ● |
| ALL | CLK | 208 | Information and communication | E-call [USA]-Emergency call system | ● | ● | ● | ● | ○ | ○ |
| ALL | CLK | 208 | Information and communication | TELE AID-Emergency call system | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | CLK | 208 | Information and communication | E-call [USA]-Telematic system | ● | ● | ● | ● | ● | ● |
| ALL | CLK | 208 | Information and communication | TELE AID-Telematic system | ● | ● | ● | ● | ● | |
| ALL | CLK | 208 | Information and communication | CTEL over K-wire-Telematic system | ● | ● | ● | ● | ○ | ○ |
| ALL | CLK | 208 | Information and communication | DN-Dynamic navigation by means of CTEL | ● | ● | ● | ● | ● | ○ |
| ALL | CLK | 208 | Seats and doors | DCM1-Door control module front driver side | ● | ● | ○ | ● | ● | ※ |
| ALL | CLK | 208 | Seats and doors | DCM2-Door control module front passenger side | ● | ● | ○ | ● | ● | ※ |
| ALL | CLK | 208 | Seats and doors | ESA-FL-Electric seat adjustment front left | ● | ● | ○ | ● | ● | ※ |
| ALL | CLK | 208 | Seats and doors | ESA-FR-Electric seat adjustment front right | ● | ● | ○ | ● | ● | ※ |
| ALL | CLK | 208 | Air conditioning | TAC-Automatic temperature control | ● | ● | ○ | ● | | ※ |
| ALL | CLK | 208 | Air conditioning | AAC-Automatic air conditioning | ● | ● | ○ | ● | | ※ |
| ALL | CLK | 208 | Air conditioning | STH-Stationary heater | ● | ● | ○ | ● | ● | ※ |
| Up to 05/2005 | E-Class | 211 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Drive | SEQ-Sequentronic automated manual transmission | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ※ |
| Up to 05/2005 | E-Class | 211 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Drive | ME-SFI-Motor electronics | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Drive | ME-SFI-Motor electronics | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Drive | ME-SFI-Motor electronics | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Drive | ESM-Electronic selector module | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | E-Class | 211 | Drive | ME 9.7-Motor electronics 9.7 | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Drive | CDI 3-Common Rail Diesel Injection3 | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Drive | CDI 3-Common Rail Diesel Injection3 | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Drive | CDID-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Drive | TV-TV tuner | ● | ● | ● | ● | ● | |
| Up to 05/2005 | E-Class | 211 | Drive | CDI-V-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Chassis | SBC-Sensotronic Brake Control | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Chassis | SBC-Sensotronic Brake Control | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Chassis | AIRmatic | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | E-Class | 211 | Chassis | Suspension | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Chassis | TPC-Tire pressure monitor | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Chassis | TPC-Tire pressure monitor | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Chassis | ABR-Adaptive Brake | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| Up to 05/2005 | E-Class | 211 | Body | CGW-Central gateway | ● | ● | ● | ● | ○ | ○ |
| Up to 05/2005 | E-Class | 211 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | E-Class | 211 | Body | AB-Airbag | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Body | WSS-Weight sensing system | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Body | BCM-Battery control module | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Body | On board electrical system(voltage supply) | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Body | System diagnosis(CAN) | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Body | Dr-side SAM-Driver signal acquisition and actuation module | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | E-Class | 211 | Body | Pass-side SAM-Passenger-side signal acquisition and actuation module | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | E-Class | 211 | Body | REAR SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | E-Class | 211 | Body | AHE-Trailer recognition | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | E-Class | 211 | Body | MSS-Special vehicle multifunction control module | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | E-Class | 211 | Body | LCP-Lower control panel | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | E-Class | 211 | Body | UCP-Upper control panel | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | E-Class | 211 | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | E-Class | 211 | Body | RevETR-LF-Left front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Body | RevETR-RF-Right front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Body | HRA-Automatic headlamp range adjustment and headlamp control | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | E-Class | 211 | Body | On board electrical system(voltage supply) | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Body | XALWA-L-Xenon headlamp, left | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Body | XALWA-R-Xenon headlamp, right | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Information and communication | IC-Instrument cluster | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | E-Class | 211 | Information and communication | ASSYST-Active Service System | ● | ● | ○ | ● | ● | ○ |
| Up to 05/2005 | E-Class | 211 | Information and communication | ASSYST PLUS-PLUS Active Service System | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| Up to 05/2005 | E-Class | 211 | Information and communication | CTEL-Telecommunication for telematics services | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Information and communication | Telephone adapter for portable CTET-Telecommunication for telematics services | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Information and communication | CTEL-Mobile phone adapter with universal interface | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Information and communication | COMAND or AUDIO | ● | ● | ○ | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Information and communication | NAVI-Navigation system | ● | ● | ○ | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Information and communication | CDC-CD changer | ● | ● | ○ | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ● |
| Up to 05/2005 | E-Class | 211 | Information and communication | TV-TV tuner | ● | ● | ○ | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Information and communication | TV-TV tuner (AGW) | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Information and communication | SDAR-Satellite radio | ● | ● | ○ | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Information and communication | GPS box | ● | ● | ○ | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Information and communication | TELE AID-Control unit | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Information and communication | TELE AID-Telematic services Emergency call | ● | ● | ● | ● | | ● |
| Up to 05/2005 | E-Class | 211 | Information and communication | TELE AID-Telematic services MB Info, Roadside assistance (USA, Canada), Tele diagnosis (ECE) | ● | ● | ● | ● | | ● |
| Up to 05/2005 | E-Class | 211 | Information and communication | TELE AID-Telematic services Stolen vehicle tracking | ● | ● | ● | ● | | ● |
| Up to 05/2005 | E-Class | 211 | Information and communication | TELE AID-Telematic services Remote door unlocking, Remote door locking | ● | ● | ● | ● | | ● |
| Up to 05/2005 | E-Class | 211 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | E-Class | 211 | Information and communication | COMAND or AUDIO | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Information and communication | Sound system (Main amplifier) | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Information and communication | UCI-Media interface | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|-------------------------|---------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| Up to 05/2005 | E-Class | 211 | Information and communication | DAB-Digital radio | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | E-Class | 211 | Information and communication | SDAR-Satellite radio(Valid for USA) | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Information and communication | TV-TV tuner | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Information and communication | CTEL-Cellular telephone(JAPAN) | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | E-Class | 211 | Seats and doors | ESA driver-Electric seat adjustment driver | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | E-Class | 211 | Seats and doors | ESA driver-Electric seat adjustment driver (with | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | E-Class | 211 | Seats and doors | ESA passenger-Electric seat adjustment passenger | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | E-Class | 211 | Seats and doors | ESA passenger-Electric seat adjustment passenger | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | E-Class | 211 | Seats and doors | DS-LF-Left front dynamic seat | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Seats and doors | DS-RF-Right front dynamic seat | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Seats and doors | DSP-Pneumatic pump for dynamic seat | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Seats and doors | HS-Seat heater | ● | ● | ● | ● | ○ | ○ |
| Up to 05/2005 | E-Class | 211 | Seats and doors | HS-Seat heater | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | E-Class | 211 | Seats and doors | DCM-FL-Door control module front left | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | E-Class | 211 | Seats and doors | DCM-FR-Door control module front right | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | E-Class | 211 | Seats and doors | DCM-RL-Door control module rear left | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | E-Class | 211 | Seats and doors | DCM-RR-Door control module rear right | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | E-Class | 211 | Seats and doors | TLC-Trunk lid control | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Seats and doors | LAE [LAA]-Loading floor automatically extendable | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Seats and doors | RWT-Rear-end door control module | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | E-Class | 211 | Seats and doors | TLC-Trunk lid control | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Air conditioning | AAC-Automatic air conditioning | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Air conditioning | HSW-Heated steering wheel | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | E-Class | 211 | Air conditioning | HSW-Heated steering wheel | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | E-Class | 211 | Air conditioning | STH-Stationary heater | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Drive | SEQ-Sequentronic automated manual transmission | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Drive | ME-SFI-Motor electronics | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Drive | ME-SFI-Motor electronics | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|-------------------------|---------|--------------|---------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| From 06/2005 to 05/2006 | E-Class | 211 | Drive | ME-SFI-Motor electronics | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Drive | ESM-Electronic selector module | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | E-Class | 211 | Drive | ME 9.7-Motor electronics 9.7 | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Drive | CDI 3-Common Rail Diesel Injection3 | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Drive | CDI 3-Common Rail Diesel Injection3 | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Drive | CDI 4-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Drive | CDI5-Common Rail Diesel Injection(USA) | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Drive | CDI 5-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Chassis | SBC-Sensotronic Brake Control | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Chassis | SBC-Sensotronic Brake Control | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Chassis | AIRmatic | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | E-Class | 211 | Chassis | Suspension | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Chassis | TPC-Tire pressure monitor | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Body | CGW-Central gateway | ● | ● | ● | ● | ○ | ○ |
| From 06/2005 to 05/2006 | E-Class | 211 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | E-Class | 211 | Body | AB-Airbag | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|-------------------------|---------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| From 06/2005 to 05/2006 | E-Class | 211 | Body | WSS-Weight sensing system | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Body | BCM-Battery control module | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Body | On board electrical system(voltage supply) | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Body | System diagnosis(CAN) | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Body | Dr-side SAM-Driver signal acquisition and actuation module | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | E-Class | 211 | Body | Pass-side SAM-Passenger-side signal acquisition and actuation module | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | E-Class | 211 | Body | REAR SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | E-Class | 211 | Body | AHE-Trailer recognition | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | E-Class | 211 | Body | MSS-Special vehicle multifunction control module | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | E-Class | 211 | Body | LCP-Lower control panel | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | E-Class | 211 | Body | UCP-Upper control panel | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | E-Class | 211 | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | E-Class | 211 | Body | RevETR-LF-Left front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Body | RevETR-RF-Right front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Body | HRA-Automatic headlamp range adjustment and headlamp control | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | E-Class | 211 | Body | On board electrical system(voltage supply) | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Information and communication | IC-Instrument cluster | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | E-Class | 211 | Information and communication | ASSYST-Active Service System | ● | ● | ○ | ● | ● | ○ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|-------------------------|---------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| From 06/2005 to 05/2006 | E-Class | 211 | Information and communication | ASSYST PLUS-PLUS Active Service System | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Information and communication | CTEL-Telecommunication for telematics services | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Information and communication | Telephone adapter for portable CTEL-Telecommunication for telematics services | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Information and communication | CTEL-Mobile phone adapter with universal interface | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Information and communication | COMAND or AUDIO | ● | ● | ○ | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Information and communication | NAVI-Navigation system | ● | ● | ○ | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Information and communication | CDC-CD changer | ● | ● | ○ | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Information and communication | TV-TV tuner | ● | ● | ○ | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Information and communication | TV-TV tuner (AGW) | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Information and communication | SDAR-Satellite radio | ● | ● | ○ | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Information and communication | GPS box | ● | ● | ○ | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Information and communication | TELE AID-Control unit | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Information and communication | TELE AID-Telematic services Emergency call | ● | ● | ● | ● | | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Information and communication | TELE AID-Telematic services MB Info, Roadside assistance (USA, Canada), Tele diagnosis (ECE) | ● | ● | ● | ● | | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Information and communication | TELE AID-Telematic services Stolen vehicle tracking | ● | ● | ● | ● | | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Information and communication | TELE AID-Telematic services Remote door unlocking, Remote door locking | ● | ● | ● | ● | | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Seats and doors | ESA driver-Electric seat adjustment driver | ● | ● | ● | ● | ● | ○ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|-------------------------|---------|--------------|---------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| From 06/2005 to 05/2006 | E-Class | 211 | Seats and doors | ESA driver-Electric seat adjustment driver (with memory) | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | E-Class | 211 | Seats and doors | ESA passenger-Electric seat adjustment passenger | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | E-Class | 211 | Seats and doors | ESA passenger-Electric seat adjustment passenger | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | E-Class | 211 | Seats and doors | DS-LF-Left front dynamic seat | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Seats and doors | DS-RF-Right front dynamic seat | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Seats and doors | DSP-Pneumatic pump for dynamic seat | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Seats and doors | HS-Seat heater | ● | ● | ● | ● | ○ | ○ |
| From 06/2005 to 05/2006 | E-Class | 211 | Seats and doors | HS-Seat heater | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | E-Class | 211 | Seats and doors | DCM-FL-Door control module front left | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | E-Class | 211 | Seats and doors | DCM-FR-Door control module front right | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | E-Class | 211 | Seats and doors | DCM-RL-Door control module rear left | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | E-Class | 211 | Seats and doors | DCM-RR-Door control module rear right | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | E-Class | 211 | Seats and doors | TLC-Trunk lid control | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Seats and doors | LAE [LAA]-Loading floor automatically extendable | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Seats and doors | RWT-Rear-end door control module | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | E-Class | 211 | Seats and doors | TLC-Trunk lid control | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Seats and doors | ARWT-Automatic rear-end door | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | E-Class | 211 | Air conditioning | AAC-Automatic air conditioning | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Air conditioning | HSW-Heated steering wheel | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | E-Class | 211 | Air conditioning | HSW-Heated steering wheel | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | E-Class | 211 | Air conditioning | STH-Stationary heater | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------|---------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| As of 06/2006 | E-Class | 211 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Drive | SEQ-Sequentronic automated manual transmission | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Drive | ME-SFI-Motor electronics | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Drive | ME-SFI-Motor electronics | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Drive | ME-SFI-Motor electronics | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Drive | ME-SFI-Motor electronics | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Drive | ESM-Electronic selector module | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | E-Class | 211 | Drive | TV-TV tuner | ● | ● | ● | ● | ● | |
| As of 06/2006 | E-Class | 211 | Drive | ME 9.7-Motor electronics 9.7 | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Drive | ME 9.7 (AMG)-Motor electronics 9.7 (AMG) | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Drive | FSCU Right-Control unit 'Right fuel pump' | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Drive | FSCU Left-Control unit 'Left fuel pump' | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Drive | CDID-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Drive | CDI 4-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Drive | CDI5-Common Rail Diesel Injection(USA) | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Drive | CDI 5-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Chassis | ABR-Adaptive Brake | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Chassis | AIRmatic | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | E-Class | 211 | Chassis | Suspension | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Chassis | TPC-Tire pressure monitor | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Body | CGW-Central gateway | ● | ● | ● | ● | ○ | ○ |
| As of 06/2006 | E-Class | 211 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | E-Class | 211 | Body | AB-Airbag | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Body | WSS-Weight sensing system | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Body | System diagnosis(CAN) | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Body | Dr-side SAM-Driver signal acquisition and actuation module | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | E-Class | 211 | Body | Pass-side SAM-Passenger-side signal acquisition and actuation module | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | E-Class | 211 | Body | REAR SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | E-Class | 211 | Body | AHE-Trailer recognition | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | E-Class | 211 | Body | MSS-Special vehicle multifunction control module | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | E-Class | 211 | Body | LCP-Lower control panel | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | E-Class | 211 | Body | UCP-Upper control panel | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | E-Class | 211 | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | E-Class | 211 | Body | RevETR-LF-Left front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Body | RevETR-RF-Right front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| As of 06/2006 | E-Class | 211 | Body | XALWA-L-Xenon headlamp, left | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Body | XALWA-R-Xenon headlamp, right | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | E-Class | 211 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Information and communication | IC-Instrument cluster | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | E-Class | 211 | Information and communication | ASSYST-Active Service System | ● | ● | ○ | ● | ● | ○ |
| As of 06/2006 | E-Class | 211 | Information and communication | ASSYST PLUS-PLUS Active Service System | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Information and communication | CTEL-Telecommunication for telematics services | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Information and communication | Telephone adapter for portable CTEL-Telecommunication for telematics services | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Information and communication | CTEL-Mobile phone adapter with universal interface | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Information and communication | COMAND or AUDIO | ● | ● | ○ | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Information and communication | NAVI-Navigation system | ● | ● | ○ | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Information and communication | CDC-CD changer | ● | ● | ○ | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Information and communication | TV-TV tuner | ● | ● | ○ | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Information and communication | TV-TV tuner(AGW) | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Information and communication | SDAR-Satellite radio | ● | ● | ○ | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Information and communication | GPS box | ● | ● | ○ | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| As of 06/2006 | E-Class | 211 | Information and communication | TELE AID-Control unit | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Information and communication | TELE AID-Telematic services Emergency call | ● | ● | ● | ● | | ● |
| As of 06/2006 | E-Class | 211 | Information and communication | TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE) | ● | ● | ● | ● | | ● |
| As of 06/2006 | E-Class | 211 | Information and communication | TELE AID-Telematic services Stolen vehicle tracking | ● | ● | ● | ● | | ● |
| As of 06/2006 | E-Class | 211 | Information and communication | TELE AID-Telematic services Remote door unlocking,Remote door locking | ● | ● | ● | ● | | ● |
| As of 06/2006 | E-Class | 211 | Information and communication | COMAND or AUDIO | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Information and communication | Sound system (Main amplifier) | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Information and communication | UCI-Media interface | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Information and communication | DAB-Digital radio | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | E-Class | 211 | Information and communication | SDAR-Satellite radio(Valid for USA) | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Information and communication | TV-TV tuner | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Information and communication | CTEL-Cellular telephone(JAPAN) | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | E-Class | 211 | Seats and doors | ESA driver-Electric seat adjustment driver | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | E-Class | 211 | Seats and doors | ESA driver-Electric seat adjustment driver (with | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | E-Class | 211 | Seats and doors | ESA passenger-Electric seat adjustment passenger | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | E-Class | 211 | Seats and doors | ESA passenger-Electric seat adjustment passenger | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | E-Class | 211 | Seats and doors | DS-LF-Left front dynamic seat | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Seats and doors | DS-RF-Right front dynamic seat | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Seats and doors | DSP-Pneumatic pump for dynamic seat | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Seats and doors | HS-Seat heater | ● | ● | ● | ● | ○ | ○ |
| As of 06/2006 | E-Class | 211 | Seats and doors | HS-Seat heater | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | E-Class | 211 | Seats and doors | DCM-FL-Door control module front left | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | E-Class | 211 | Seats and doors | DCM-FR-Door control module front right | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | E-Class | 211 | Seats and doors | DCM-RL-Door control module rear left | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | E-Class | 211 | Seats and doors | DCM-RR-Door control module rear right | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | E-Class | 211 | Seats and doors | TLC-Trunk lid control | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Seats and doors | LAE [LAA]-Loading floor automatically extendable | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Seats and doors | RWT-Rear-end door control module | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | E-Class | 211 | Seats and doors | TLC-Trunk lid control | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Seats and doors | ARWT-Automatic rear-end door | ● | ● | ● | ● | ● | ○ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|-----------------|---------|--------------|---------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| As of 06/2006 | E-Class | 211 | Air conditioning | AAC-Automatic air conditioning | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Air conditioning | HSW-Heated steering wheel | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | E-Class | 211 | Air conditioning | HSW-Heated steering wheel | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | E-Class | 211 | Air conditioning | STH-Stationary heater | ● | ● | ● | ● | ● | ● |
| As of 03/97 DAS | E-Class | 210 | Drive | ETC-Electronic transmission control | ● | ● | ○ | ● | | ※ |
| As of 03/97 DAS | E-Class | 210 | Drive | ETC-Electronic transmission control | ● | ● | ○ | ● | ● | ※ |
| As of 03/97 DAS | E-Class | 210 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| As of 03/97 DAS | E-Class | 210 | Drive | ESM-Electronic selector module | ● | ● | ○ | ● | ● | ※ |
| As of 03/97 DAS | E-Class | 210 | Drive | ME2-SFI-Motor electronics 2 | ● | ● | ○ | ● | ● | ※ |
| As of 03/97 DAS | E-Class | 210 | Drive | ME-SFI-Motor electronics | ● | ● | ● | ● | ● | ● |
| As of 03/97 DAS | E-Class | 210 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| As of 03/97 DAS | E-Class | 210 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| As of 03/97 DAS | E-Class | 210 | Drive | DFI-Electronic distributor injection system diesel | ● | ● | ○ | ● | | ※ |
| As of 03/97 DAS | E-Class | 210 | Drive | IFI-Electronic in-line injection system diesel | ● | ● | ○ | ● | | ※ |
| As of 03/97 DAS | E-Class | 210 | Drive | CDI-Common Rail Diesel Injection | ● | ● | ○ | ● | | ※ |
| As of 03/97 DAS | E-Class | 210 | Drive | CDI 2-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| As of 03/97 DAS | E-Class | 210 | Chassis | ABS-Antilock brake system | ● | ● | ○ | ● | ● | ※ |
| As of 03/97 DAS | E-Class | 210 | Chassis | ASR-Acceleration Slip Regulation | ● | ● | ○ | ● | ● | ※ |
| As of 03/97 DAS | E-Class | 210 | Chassis | ESP-Electronic stability program | ● | ● | ○ | ● | ● | ※ |
| As of 03/97 DAS | E-Class | 210 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| As of 03/97 DAS | E-Class | 210 | Chassis | ASR-Acceleration Slip Regulation | ● | ● | ○ | ● | ● | ※ |
| As of 03/97 DAS | E-Class | 210 | Chassis | ESP-Electronic stability program | ● | ● | ○ | ● | ● | ※ |
| As of 03/97 DAS | E-Class | 210 | Chassis | ETS-Electronic traction system | ● | ● | ○ | ● | ● | ※ |
| As of 03/97 DAS | E-Class | 210 | Chassis | ESP-Electronic stability program | ● | ● | ○ | ● | ● | ※ |
| As of 03/97 DAS | E-Class | 210 | Chassis | ETS-Electronic traction system | ● | ● | ○ | ● | ● | ※ |
| As of 03/97 DAS | E-Class | 210 | Chassis | BAS-Brake assist | ● | ● | ○ | ● | ● | ※ |
| As of 03/97 DAS | E-Class | 210 | Chassis | BAS-Brake assist | ● | ● | ○ | ● | ● | ● |
| As of 03/97 DAS | E-Class | 210 | Chassis | SPS-Speed-sensitive power steering | ● | ● | ○ | ● | ● | ※ |
| As of 03/97 DAS | E-Class | 210 | Chassis | TPM - Tire pressure monitor (N88) | ● | ● | ● | ● | ● | ※ |
| As of 03/97 DAS | E-Class | 210 | Chassis | VP-Vacuum pump brake booster | ● | ● | ● | ● | ● | ● |
| As of 03/97 DAS | E-Class | 210 | Body | AB-Airbag | ● | ● | ○ | ● | ● | ※ |
| As of 03/97 DAS | E-Class | 210 | Body | AB-Airbag | ● | ● | ○ | ● | | ※ |
| As of 03/97 DAS | E-Class | 210 | Body | EZS-Electronic ignition switch | ● | ● | ○ | ● | ● | ※ |
| As of 03/97 DAS | E-Class | 210 | Body | OCP-Overhead control panel | ● | ● | ○ | ● | ● | ※ |
| As of 03/97 DAS | E-Class | 210 | Body | LCP-Lower control panel | ● | ● | ○ | ● | ● | ※ |
| As of 03/97 DAS | E-Class | 210 | Body | PSE-Pneumatic system equipment | ● | ● | ○ | ● | ● | ※ |
| As of 03/97 DAS | E-Class | 210 | Body | SAM-Signal acquisition and actuation module | ● | ● | ○ | ● | ● | ※ |
| As of 03/97 DAS | E-Class | 210 | Body | MSS-Special vehicle multifunction control module | ● | ● | ○ | ● | ● | ※ |
| As of 03/97 DAS | E-Class | 210 | Body | HRA-Headlamp range adjustment | ● | ● | ○ | ● | | ※ |
| As of 03/97 DAS | E-Class | 210 | Body | HRA-Headlamp range adjustment | ● | ● | ○ | ● | ● | ○ |
| As of 03/97 DAS | E-Class | 210 | Body | APS-Auto pilot system | ● | ● | ○ | ● | ● | ※ |
| As of 03/97 DAS | E-Class | 210 | Body | HB-Heater booster | ● | ● | ○ | ● | | ※ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|-------------------|---------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| As of 03/97 DAS 3 | E-Class | 210 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ○ | ● | ● | ※ |
| As of 03/97 DAS 3 | E-Class | 210 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ● |
| As of 03/97 DAS 3 | E-Class | 210 | Information and communication | COMAND | ● | ● | ○ | ● | ● | ● |
| As of 03/97 DAS 3 | E-Class | 210 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| As of 03/97 DAS 3 | E-Class | 210 | Information and communication | CTEL- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ○ | ○ |
| As of 03/97 DAS 3 | E-Class | 210 | Information and communication | UHI- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ● | ○ |
| As of 03/97 DAS 3 | E-Class | 210 | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ○ |
| As of 03/97 DAS 3 | E-Class | 210 | Information and communication | CDC-CD changer | ● | ● | ● | ● | ○ | ○ |
| As of 03/97 DAS 3 | E-Class | 210 | Information and communication | ICS-Information and communication system | ● | ● | ○ | ● | | ※ |
| As of 03/97 DAS 3 | E-Class | 210 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ※ |
| As of 03/97 DAS 3 | E-Class | 210 | Information and communication | TV-TV tuner | ● | ● | ● | ● | | ● |
| As of 03/97 DAS 3 | E-Class | 210 | Information and communication | E-call [Japan]-Emergency call system | ● | ● | ○ | ● | ● | ● |
| As of 03/97 DAS 3 | E-Class | 210 | Information and communication | E-call [USA]-Emergency call system | ● | ● | ● | ● | ○ | ○ |
| As of 03/97 DAS 3 | E-Class | 210 | Information and communication | TELE AID-Emergency call system | ● | ● | ● | ● | ● | ● |
| As of 03/97 DAS 3 | E-Class | 210 | Information and communication | TELE AID-Telematic system | ● | ● | ○ | ● | | ● |
| As of 03/97 DAS 3 | E-Class | 210 | Information and communication | E-call [USA]-Telematic system | ● | ● | ● | ● | ● | ● |
| As of 03/97 DAS 3 | E-Class | 210 | Information and communication | TELE AID-Telematic system | ● | ● | ● | ● | ● | |
| As of 03/97 DAS 3 | E-Class | 210 | Information and communication | CTEL over K-wire-Telematic system | ● | ● | ● | ● | ○ | ○ |
| As of 03/97 DAS 3 | E-Class | 210 | Information and communication | DN-Dynamic navigation by means of CTEL | ● | ● | ● | ● | ● | ○ |
| As of 03/97 DAS | E-Class | 210 | Seats and doors | DCM1-Door control module front driver side | ● | ● | ○ | ● | ● | ※ |
| As of 03/97 DAS | E-Class | 210 | Seats and doors | DCM2-Door control module front passenger side | ● | ● | ○ | ● | ● | ※ |
| As of 03/97 DAS | E-Class | 210 | Seats and doors | DCM3-Door control module rear driver side | ● | ● | ○ | ● | ● | ※ |
| As of 03/97 DAS | E-Class | 210 | Seats and doors | DCM4-Door control module rear passenger side | ● | ● | ○ | ● | ● | ※ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|-----------------|---------|--------------|---------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| As of 03/97 DAS | E-Class | 210 | Seats and doors | ESA-FL-Electric seat adjustment front left | ● | ● | ○ | ● | ● | ※ |
| As of 03/97 DAS | E-Class | 210 | Seats and doors | ESA-FR-Electric seat adjustment front right | ● | ● | ○ | ● | ● | ※ |
| As of 03/97 DAS | E-Class | 210 | Air conditioning | TAC-Automatic temperature control | ● | ● | ○ | ● | | ※ |
| As of 03/97 DAS | E-Class | 210 | Air conditioning | AAC-Automatic air conditioning | ● | ● | ○ | ● | | ※ |
| As of 03/97 DAS | E-Class | 210 | Air conditioning | STH-Stationary heater | ● | ● | ○ | ● | ● | ※ |
| Up to 05/2005 | CLS | 219 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Drive | SEQ-Sequentronic automated manual transmission | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Drive | ME 9.7-Motor electronics 9.7 | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Drive | ESM-Electronic selector module | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | CLS | 219 | Drive | MED 9.7-Motor electronics for direct injection 9.7 | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ○ | ● |
| Up to 05/2005 | CLS | 219 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Drive | ME 9.7 (AMG)-Motor electronics 9.7 (AMG) | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Drive | FSCU Right-Control unit 'Right fuel pump' | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Drive | FSCU Left-Control unit 'Left fuel pump' | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Drive | CDI 4-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Chassis | SBC-Sensotronic Brake Control | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Chassis | AIRmatic | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | CLS | 219 | Chassis | TPC-Tire pressure monitor | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Chassis | TPC-Tire pressure monitor | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Body | CGW-Central gateway | ● | ● | ● | ● | ○ | ○ |
| Up to 05/2005 | CLS | 219 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | CLS | 219 | Body | AB-Airbag | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Body | WSS-Weight sensing system | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Body | BCM-Battery control module | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Body | System diagnosis (CAN) | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Body | Dr-side SAM-Driver signal acquisition and actuation module | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | CLS | 219 | Body | Pass-side SAM-Passenger-side signal acquisition and actuation module | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | CLS | 219 | Body | REAR SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | CLS | 219 | Body | LCP-Lower control panel | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | CLS | 219 | Body | UCP-Upper control panel | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | CLS | 219 | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | CLS | 219 | Body | RevETR-LF-Left front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Body | RevETR-RF-Right front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|-------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| Up to 05/2005 | CLS | 219 | Body | HRA-Automatic headlamp range adjustment and headlamp control | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | CLS | 219 | Body | On board electrical system(voltage supply) | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Information and communication | IC-Instrument cluster | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | CLS | 219 | Information and communication | ASSYST-Active Service System | ● | ● | ○ | ● | ● | ○ |
| Up to 05/2005 | CLS | 219 | Information and communication | ASSYST PLUS-PLUS Active Service System | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Information and communication | COMAND or AUDIO | ● | ● | ○ | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Information and communication | CTEL-Mobile phone adapter with universal interface | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Information and communication | NAVI-Navigation system | ● | ● | ○ | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Information and communication | CDC-CD changer | ● | ● | ○ | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ● |
| Up to 05/2005 | CLS | 219 | Information and communication | TV-TV tuner | ● | ● | ○ | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Information and communication | TV-TV tuner(AGW) | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Information and communication | SDAR-Satellite radio | ● | ● | ○ | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Information and communication | GPS box | ● | ● | ○ | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Information and communication | TELE AID-Control unit | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Information and communication | TELE AID-Telematic services Emergency call | ● | ● | ● | ● | | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|-------------------------|-------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| Up to 05/2005 | CLS | 219 | Information and communication | TELE AID-Telematic services MB Info, Roadside assistance (USA, Canada), Tele diagnosis (ECE) | ● | ● | ● | ● | | ● |
| Up to 05/2005 | CLS | 219 | Information and communication | TELE AID-Telematic services Stolen vehicle tracking | ● | ● | ● | ● | | ● |
| Up to 05/2005 | CLS | 219 | Information and communication | TELE AID-Telematic services Remote door unlocking, Remote door locking | ● | ● | ● | ● | | ● |
| Up to 05/2005 | CLS | 219 | Seats and doors | ESA driver-Electric seat adjustment driver (with | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | CLS | 219 | Seats and doors | ESA passenger-Electric seat adjustment passenger | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | CLS | 219 | Seats and doors | DS-LF-Left front dynamic seat | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Seats and doors | DS-RF-Right front dynamic seat | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Seats and doors | DSP-Pneumatic pump for dynamic seat | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Seats and doors | HS-Seat heater | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | CLS | 219 | Seats and doors | DCM-FL-Door control module front left | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | CLS | 219 | Seats and doors | DCM-FR-Door control module front right | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | CLS | 219 | Seats and doors | DCM-RL-Door control module rear left | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | CLS | 219 | Seats and doors | DCM-RR-Door control module rear right | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | CLS | 219 | Seats and doors | TLC-Trunk lid control | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Seats and doors | LAE [LAA]-Loading floor automatically extendable | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Seats and doors | RWT-Rear-end door control module | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | CLS | 219 | Air conditioning | AAC-Automatic air conditioning | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | CLS | 219 | Air conditioning | HSW-Heated steering wheel | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | CLS | 219 | Air conditioning | STH-Stationary heater | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Drive | SEQ-Sequentronic automated manual transmission | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Drive | ME 9.7-Motor electronics 9.7 | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Drive | ESM-Electronic selector module | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | CLS | 219 | Drive | MED 9.7-Motor electronics for direct injection 9.7 | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ○ | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|-------------------------|-------|--------------|---------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| From 06/2005 to 05/2006 | CLS | 219 | Drive | ME 9.7 (AMG)-Motor electronics 9.7 (AMG) | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Drive | FSCU Right-Control unit 'Right fuel pump' | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Drive | FSCU Left-Control unit 'Left fuel pump' | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Drive | CDI 4-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Chassis | SBC-Sensotronic Brake Control | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Chassis | AIRmatic | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | CLS | 219 | Chassis | TPC-Tire pressure monitor | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Body | CGW-Central gateway | ● | ● | ● | ● | ○ | ○ |
| From 06/2005 to 05/2006 | CLS | 219 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | CLS | 219 | Body | AB-Airbag | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Body | WSS-Weight sensing system | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Body | BCM-Battery control module | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Body | System diagnosis(CAN) | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Body | Dr-side SAM-Driver signal acquisition and actuation module | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | CLS | 219 | Body | Pass-side SAM-Passenger-side signal acquisition and actuation module | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | CLS | 219 | Body | REAR SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | CLS | 219 | Body | LCP-Lower control panel | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | CLS | 219 | Body | UCP-Upper control panel | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | CLS | 219 | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | CLS | 219 | Body | RevETR-LF-Left front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|-------------------------|-------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| From 06/2005 to 05/2006 | CLS | 219 | Body | RevETR-RF-Right front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Body | HRA-Automatic headlamp range adjustment and headlamp control | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | CLS | 219 | Body | On board electrical system(voltage supply) | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Information and communication | IC-Instrument cluster | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | CLS | 219 | Information and communication | ASSYST-Active Service System | ● | ● | ○ | ● | ● | ○ |
| From 06/2005 to 05/2006 | CLS | 219 | Information and communication | ASSYST PLUS-PLUS Active Service System | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Information and communication | COMAND or AUDIO | ● | ● | ○ | ● | ● | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Information and communication | CTEL-Mobile phone adapter with universal interface | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Information and communication | NAVI-Navigation system | ● | ● | ○ | ● | ● | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Information and communication | CDC-CD changer | ● | ● | ○ | ● | ● | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Information and communication | TV-TV tuner | ● | ● | ○ | ● | ● | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Information and communication | TV-TV tuner(AGW) | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Information and communication | SDAR-Satellite radio | ● | ● | ○ | ● | ● | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Information and communication | GPS box | ● | ● | ○ | ● | ● | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Information and communication | TELE AID-Control unit | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|-------------------------|-------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| From 06/2005 to 05/2006 | CLS | 219 | Information and communication | TELE AID-Telematic services Emergency call | ● | ● | ● | ● | | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Information and communication | TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE) | ● | ● | ● | ● | | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Information and communication | TELE AID-Telematic services Stolen vehicle tracking | ● | ● | ● | ● | | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Information and communication | TELE AID-Telematic services Remote door unlocking,Remote door locking | ● | ● | ● | ● | | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Seats and doors | ESA driver-Electric seat adjustment driver (with memory) | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | CLS | 219 | Seats and doors | ESA passenger-Electric seat adjustment passenger | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | CLS | 219 | Seats and doors | DS-LF-Left front dynamic seat | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Seats and doors | DS-RF-Right front dynamic seat | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Seats and doors | DSP-Pneumatic pump for dynamic seat | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Seats and doors | HS-Seat heater | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | CLS | 219 | Seats and doors | DCM-FL-Door control module front left | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | CLS | 219 | Seats and doors | DCM-FR-Door control module front right | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | CLS | 219 | Seats and doors | DCM-RL-Door control module rear left | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | CLS | 219 | Seats and doors | DCM-RR-Door control module rear right | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | CLS | 219 | Seats and doors | TLC-Trunk lid control | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Seats and doors | LAE [LAA]-Loading floor automatically extendable | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Seats and doors | RWT-Rear-end door control module | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | CLS | 219 | Air conditioning | AAC-Automatic air conditioning | ● | ● | ● | ● | ● | ● |
| From 06/2005 to 05/2006 | CLS | 219 | Air conditioning | HSW-Heated steering wheel | ● | ● | ● | ● | ● | ○ |
| From 06/2005 to 05/2006 | CLS | 219 | Air conditioning | STH-Stationary heater | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Drive | SEQ-Sequentronic automated manual transmission | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|-------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| As of 06/2006 | CLS | 219 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Drive | ME 9.7-Motor electronics 9.7 | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Drive | ESM-Electronic selector module | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | CLS | 219 | Drive | TV-TV tuner | ● | ● | ● | ● | ● | |
| As of 06/2006 | CLS | 219 | Drive | MED 9.7-Motor electronics for direct injection 9.7 | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ○ | ● |
| As of 06/2006 | CLS | 219 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Drive | ME 9.7 (AMG)-Motor electronics 9.7 (AMG) | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Drive | FSCU Right-Control unit 'Right fuel pump' | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Drive | FSCU Left-Control unit 'Left fuel pump' | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Drive | CDI 4-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Chassis | ABR-Adaptive Brake | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Chassis | AIRmatic | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | CLS | 219 | Chassis | TPC-Tire pressure monitor | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Body | CGW-Central gateway | ● | ● | ● | ● | ○ | ○ |
| As of 06/2006 | CLS | 219 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | CLS | 219 | Body | AB-Airbag | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Body | WSS-Weight sensing system | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Body | System diagnosis (CAN) | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Body | Dr-side SAM-Driver signal acquisition and actuation module | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | CLS | 219 | Body | Pass-side SAM-Passenger-side signal acquisition and actuation module | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | CLS | 219 | Body | REAR SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | CLS | 219 | Body | LCP-Lower control panel | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | CLS | 219 | Body | UCP-Upper control panel | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | CLS | 219 | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | CLS | 219 | Body | RevETR-LF-Left front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Body | RevETR-RF-Right front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Body | HRA-Automatic headlamp range adjustment and headlamp control | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | CLS | 219 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | CLS | 219 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|-------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| As of 06/2006 | CLS | 219 | Information and communication | IC-Instrument cluster | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | CLS | 219 | Information and communication | ASSYST-Active Service System | ● | ● | ○ | ● | ● | ○ |
| As of 06/2006 | CLS | 219 | Information and communication | ASSYST PLUS-PLUS Active Service System | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Information and communication | COMAND or AUDIO | ● | ● | ○ | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Information and communication | CTEL-Mobile phone adapter with universal interface | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Information and communication | NAVI-Navigation system | ● | ● | ○ | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Information and communication | CDC-CD changer | ● | ● | ○ | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ● |
| As of 06/2006 | CLS | 219 | Information and communication | TV-TV tuner | ● | ● | ○ | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Information and communication | TV-TV tuner (AGW) | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Information and communication | SDAR-Satellite radio | ● | ● | ○ | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Information and communication | GPS box | ● | ● | ○ | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Information and communication | TELE AID-Control unit | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Information and communication | TELE AID-Telematic services Emergency call | ● | ● | ● | ● | | ● |
| As of 06/2006 | CLS | 219 | Information and communication | TELE AID-Telematic services MB Info, Roadside assistance (USA, Canada), Tele diagnosis (ECE) | ● | ● | ● | ● | | ● |
| As of 06/2006 | CLS | 219 | Information and communication | TELE AID-Telematic services Stolen vehicle tracking | ● | ● | ● | ● | | ● |
| As of 06/2006 | CLS | 219 | Information and communication | TELE AID-Telematic services Remote door unlocking, Remote door locking | ● | ● | ● | ● | | ● |
| As of 06/2006 | CLS | 219 | Information and communication | COMAND or AUDIO | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|-------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| As of 06/2006 | CLS | 219 | Information and communication | Sound system (Main amplifier) | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Information and communication | UCI-Media interface | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Information and communication | DAB-Digital radio | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | CLS | 219 | Information and communication | SDAR-Satellite radio(Valid for USA) | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Information and communication | TV-TV tuner | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Information and communication | CTEL-Cellular telephone(JAPAN) | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | CLS | 219 | Seats and doors | ESA driver-Electric seat adjustment driver (with | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | CLS | 219 | Seats and doors | ESA passenger-Electric seat adjustment passenger | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | CLS | 219 | Seats and doors | DS-LF-Left front dynamic seat | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Seats and doors | DS-RF-Right front dynamic seat | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Seats and doors | DSP-Pneumatic pump for dynamic seat | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Seats and doors | HS-Seat heater | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | CLS | 219 | Seats and doors | DCM-FL-Door control module front left | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | CLS | 219 | Seats and doors | DCM-FR-Door control module front right | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | CLS | 219 | Seats and doors | DCM-RL-Door control module rear left | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | CLS | 219 | Seats and doors | DCM-RR-Door control module rear right | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | CLS | 219 | Seats and doors | TLC-Trunk lid control | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Seats and doors | LAE [LAA]-Loading floor automatically extendable | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Seats and doors | RWT-Rear-end door control module | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | CLS | 219 | Air conditioning | AAC-Automatic air conditioning | ● | ● | ● | ● | ● | ● |
| As of 06/2006 | CLS | 219 | Air conditioning | HSW-Heated steering wheel | ● | ● | ● | ● | ● | ○ |
| As of 06/2006 | CLS | 219 | Air conditioning | STH-Stationary heater | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Drive | ME 9.7-Motor electronics 9.7 | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Drive | ME 9.7 (AMG)-Motor electronics 9.7 (AMG) | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Drive | MED 17.7-Motor electronics for direct injection 17.7 | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Drive | ME-Motor electronics 'MED40' for combustion engine 'M270' (N3/10) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLS | 218 | Drive | MED 9.7-Motor electronics for direct injection 9.7 | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Drive | ISM-Shift module (A80) | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |
| ALL | CLS | 218 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Drive | mbrace-mbrace (N123/4) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLS | 218 | Drive | SCR-Selective Catalytic Reduction | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Drive | ESM-Electronic selector module | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ○ | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|-------|--------------|---------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | CLS | 218 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Drive | CDI-Motor electronics 'CR42' for combustion engine 'OM607' (N3/9) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLS | 218 | Drive | CDI-Motor electronics 'CR43' for combustion engine 'OM651' (N3/9) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLS | 218 | Drive | CDI 60LS-Common Rail Diesel Injection | ● | ● | ● | ● | ● | |
| ALL | CLS | 218 | Drive | CDI-Motor electronics 'CDI61' for combustion engine 'OM642' (N3/9) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLS | 218 | Drive | CDI 6-Common Rail Diesel Injection | ● | ● | ● | ● | ● | |
| ALL | CLS | 218 | Drive | CDI 3-Common Rail Diesel Injection3 | ● | ● | ● | ● | ● | |
| ALL | CLS | 218 | Chassis | ES-Electrical power steering (N68) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLS | 218 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Chassis | ESP-Electronic stability program (N30/4) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLS | 218 | Chassis | FWGW-Chassis gateway (N97/7) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLS | 218 | Chassis | TPM - Tire pressure monitor(N88) | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Body | CGW[ZGW]-Central gateway (CGW[ZGW]) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLS | 218 | Body | CGW-Central gateway | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Body | CGW-Central gateway | ● | ● | ● | ● | ▲ | ● |
| ALL | CLS | 218 | Body | EZS-Electronic ignition lock | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Body | EZS-Electronic ignition lock (N73) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLS | 218 | Body | XALWA-L-Left xenon headlamp(E1n1) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLS | 218 | Body | XALWA-R-Right xenon headlamp(E2n1) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLS | 218 | Body | SGR-Radar sensors control unit | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |
| ALL | CLS | 218 | Body | SG-AWF-Control unit 'COLLISION PREVENTION ASSIST' | ● | ● | ○ | ● | ○ | ● |
| ALL | CLS | 218 | Body | IRS-HRA-Outer right rear intelligent radar sensor | ● | ● | ○ | ● | ○ | ● |
| ALL | CLS | 218 | Body | IRS-HLA-Outer left rear intelligent radar sensor system (B29/4) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLS | 218 | Body | KG-KEYLESS GO (N69/5) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLS | 218 | Body | KG-Keyless Go | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Body | WSS-Weight sensing system | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Body | SRS-Supplemental restraint system (N2/10) | ● | ● | ● | ● | ▲ | ● |
| ALL | CLS | 218 | Body | SRS-Supplemental restraint system | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Body | RevETR-LF-Left front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Body | RevETR-RF-Right front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Body | RFK-Backup camera (B84/3) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLS | 218 | Body | Driver-side SAM-Driver signal acquisition and actuation module | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Body | Dr-side SAM-Driver signal acquisition and actuation module | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|-------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | CLS | 218 | Body | Driver-side SAM-Driver signal acquisition and actuation module | ● | ● | ● | ● | ▲ | |
| ALL | CLS | 218 | Body | REAR SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Body | Rear SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ▲ | ▲ |
| ALL | CLS | 218 | Body | Rear SAM-Rear signal acquisition and actuation module | ● | ● | ○ | ● | ○ | ● |
| ALL | CLS | 218 | Body | SCM-Steering column module (N80) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLS | 218 | Body | Trailer recognition module | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Body | PSD-Control mudule 'Panoramic sliding roof' (A98) | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Body | SGR-Radar sensors control unit | ● | ● | ● | ● | ○ | ● |
| ALL | CLS | 218 | Information and communication | ES-Electrical power steering | ● | ● | ● | ● | ● | ○ |
| ALL | CLS | 218 | Information and communication | IC-Instrument cluster (A1) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLS | 218 | Information and communication | IC-Instrument cluster (A1) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLS | 218 | Information and communication | ICI-InCar Internet (N125/3) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLS | 218 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Information and communication | COU [ZBE]-Central operating unit | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Information and communication | DAB-Digital Audio Broadcasting (N87/3) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLS | 218 | Information and communication | DAB-Digital radio | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Information and communication | ZAN-Central display | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Information and communication | Left rear screen | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Information and communication | Right rear screen | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Information and communication | RFK-Backup camera (B84/3) | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Information and communication | AMG DRVU-AMG DRIVE UNIT (N145) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLS | 218 | Information and communication | DSI-DIRECT SELECT interface (N150) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLS | 218 | Information and communication | AVE-H-Rear audio video unit | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Information and communication | Audio-Audio or COMAND (A2-A40/3) | ● | ● | ○ | ● | ○ | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|-------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | CLS | 218 | Information and communication | COMAND or AUDIO | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Information and communication | MFK-Multifunction camera | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |
| ALL | CLS | 218 | Information and communication | NSA-Night View Assist | ● | ● | ● | ● | ● | ○ |
| ALL | CLS | 218 | Information and communication | NSA-Night View Assist(N101) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLS | 218 | Information and communication | PTS-Parktronic | ● | ● | ○ | ● | ○ | ● |
| ALL | CLS | 218 | Information and communication | PTS-PARKTRONIC (N62) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLS | 218 | Information and communication | SCCM-Steering column module(N80) | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Information and communication | SDAR-Satellite radio(Valid for USA) | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Information and communication | Sound system (Main amplifier) | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Information and communication | Sound system (Main amplifier) | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Information and communication | Sound system (Bass amplifier) | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Information and communication | 360° camera-360° camera(N148) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLS | 218 | Information and communication | CTEL-Cellular telephone(JAPAN) | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Information and communication | TV-TV tuner(AGW) | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Information and communication | UCI-Media interface | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Information and communication | NAVI20 - Navigation(N125/2) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLS | 218 | Information and communication | TELE AID-Control unit | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Information and communication | TELE AID-Telematic services Emergency call | ● | ● | ● | ● | | ● |
| ALL | CLS | 218 | Information and communication | TELE AID-Telematic services Remote door unlocking, Remote door locking | ● | ● | ● | ● | | ● |
| ALL | CLS | 218 | Information and communication | TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE) | ● | ● | ● | ● | | ● |
| ALL | CLS | 218 | Information and communication | TELE AID-Telematic services Stolen vehicle tracking | ● | ● | ● | ● | | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------|---------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | CLS | 218 | Seats and doors | DCU-LF-Left front door | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Seats and doors | DCU-RF-Right front door | ● | ● | ● | ● | ● | ▲ |
| ALL | CLS | 218 | Seats and doors | DCU-LR-Left rear door | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Seats and doors | DCU-RR-Right rear door | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Seats and doors | SIH-FOND-Rear passenger compartment seat heater | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |
| ALL | CLS | 218 | Seats and doors | AMKS-LF-Active multicontour seat (N32/19) | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Seats and doors | AMKS-RF-Active multicontour seat (N32/22) | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Seats and doors | DSP-Pneumatic pump for dynamic seat | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Seats and doors | HKS-Tailgate control (N121/1) | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Seats and doors | ESA 'Driver' -Electric seat adjustment 'Driver' (N32/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLS | 218 | Seats and doors | ESA driver | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Seats and doors | ESA'Front passenger'-Electric seat adjustment 'Front passenger' with memory function(N32/2) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLS | 218 | Seats and doors | ESA passenger | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Air conditioning | AAC-Air conditioning (N22/7) | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | Air conditioning | Stationary heater | ● | ● | ● | ● | ● | ● |
| ALL | CLS | 218 | LIN Bus | AU-Analog clock (A70/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLS | 218 | LIN Bus | LCP-Lower control panel (S77) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLS | 218 | LIN Bus | AISP-Dimming inside rearview mirror (A67) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLS | 218 | LIN Bus | GTO-Garage door opener (A67n2) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLS | 218 | LIN Bus | AMLAB-L 2-Actuation module 2, LED exterior lighting, left front (E1n8) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLS | 218 | LIN Bus | AMLAB-R 2-Actuation module 2, LED exterior lighting, right front (E2n8) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLS | 218 | LIN Bus | AMLAB-L 1-Actuation module 1, LED exterior lighting, left front (E1n7) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLS | 218 | LIN Bus | AMLAB-R 1-Actuation module 1, LED exterior lighting, right front (E2n7) | ● | ● | ○ | ● | ○ | ● |
| Up to 06/2009 | S-Class | 221 | Drive | ISM-Intelligent servo module | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Drive | ISM-Shift module (A80) | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |
| Up to 06/2009 | S-Class | 221 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Drive | ME 9.7-Motor electronics 9.7 | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ○ | ● |
| Up to 06/2009 | S-Class | 221 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Drive | SGR-Radar sensors control unit | ● | ● | ● | ● | ● | ○ |
| Up to 06/2009 | S-Class | 221 | Drive | ME 9.7 (AMG)-Motor electronics 9.7 (AMG) | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Drive | FSCU-Fuel pump AMG | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ○ | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| Up to 06/2009 | S-Class | 221 | Drive | CDI 5-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Drive | ME 2.7.2-Motor electronics 2.7.2 | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Drive | ME 2.7.2-Motor electronics 2.7.2 | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Chassis | ABR-Adaptive Brake | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Chassis | AIRmatic | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Chassis | ABC-ABC active body control | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Chassis | Electronic parking brake-Electric parking brake | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Chassis | TPC-Tire pressure monitor | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Body | CGW-Central gateway | ● | ● | ● | ● | ○ | ● |
| Up to 06/2009 | S-Class | 221 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Body | KG-Keyless Go | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Body | KG-KEYLESS GO | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Body | MSS-Special vehicle multifunction control module | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Body | AB-Airbag | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Body | WSS-Weight sensing system | ● | ● | ● | ● | ● | ○ |
| Up to 06/2009 | S-Class | 221 | Body | WSS-Weight sensing system | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Body | UCP-Upper control panel | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Body | Dr-side SAM-Driver signal acquisition and actuation module | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Body | REAR SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Body | BNS-Vehicle power supply control module | ● | ● | ● | ● | ● | ○ |
| Up to 06/2009 | S-Class | 221 | Body | AHE-Trailer recognition | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Body | PSD-Panoramic sliding roof(Interior CAN bus) | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Body | RevETR-LF-Left front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Body | RevETR-RF-Right front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Body | XALWA-L-Xenon headlamp, left | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Body | XALWA-L-Xenon headlamp, left | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Body | XALWA-R-Xenon headlamp, right | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Body | XALWA-R-Xenon headlamp, right | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Body | System diagnosis(CAN) | ● | ● | ● | ● | ● | ○ |
| Up to 06/2009 | S-Class | 221 | Body | COU [ZBE]-Central operating unit | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Body | HBF (Rear control panel)-Rear control field | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Information and communication | NSA-Night View Assist | ● | ● | ● | ● | ● | ○ |
| Up to 06/2009 | S-Class | 221 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Information and communication | IC-Instrument cluster | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| Up to 06/2009 | S-Class | 221 | Information and communication | ASSYST-Active Service System | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Information and communication | ASSYST PLUS | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Information and communication | PTS-Parktronic | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Information and communication | RFK-Backup camera (B84/3) | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Information and communication | COMAND | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Information and communication | COMAND | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Information and communication | Tuner-Standard tuner | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Information and communication | Tuner-Tuner sound | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Information and communication | Tuner-Tuner sound | ● | ● | ● | ● | ○ | ○ |
| Up to 06/2009 | S-Class | 221 | Information and communication | VCS-Voice control | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Information and communication | CTEL-Mobile phone adapter with universal interface | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Information and communication | TV-TV tuner (AGW) | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Information and communication | SDAR-Satellite radio (Valid for USA) | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Information and communication | DAB-Digital radio | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Information and communication | ZAN-Central display | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Information and communication | AVE-H-Rear audio video unit | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Information and communication | UCI-Media interface | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Information and communication | AVE-H-Rear audio video unit | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Information and communication | Left rear screen | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Information and communication | Right rear screen | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Information and communication | TELE AID-Control unit | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| Up to 06/2009 | S-Class | 221 | Information and communication | TELE AID-Telematic services Emergency call | ● | ● | ● | ● | | ● |
| Up to 06/2009 | S-Class | 221 | Information and communication | TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE) | ● | ● | ● | ● | | ● |
| Up to 06/2009 | S-Class | 221 | Information and communication | TELE AID-Telematic services Stolen vehicle tracking | ● | ● | ● | ● | | ● |
| Up to 06/2009 | S-Class | 221 | Information and communication | TELE AID-Telematic services Remote door unlocking,Remote door locking | ● | ● | ● | ● | | ● |
| Up to 06/2009 | S-Class | 221 | Seats and doors | DS-LF-Left front dynamic seat | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Seats and doors | DS-RF-Right front dynamic seat | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Seats and doors | MKL-HL-Rear left multicontour backrest | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Seats and doors | MKL-HR-Rear right multicontour backrest | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Seats and doors | DSP-Pneumatic pump for dynamic seat | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Seats and doors | DCM-FL-Door control module front left | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Seats and doors | DCM-FR-Door control module front right | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Seats and doors | DCM-RL-Door control module rear left | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Seats and doors | DCM-RR-Door control module rear right | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Seats and doors | ESA-FL-Electric seat adjustment front left | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Seats and doors | ESA-FR-Electric seat adjustment front right | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Seats and doors | ESA-R-Electric seat adjustment rear | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Seats and doors | TLC-Trunk lid control | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Seats and doors | TLC-Trunk lid control | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Seats and doors | TSG-ML-Left center door control unit (interior Can | ● | ● | ● | ● | ● | |
| Up to 06/2009 | S-Class | 221 | Seats and doors | TSG-MR-Right center door control unit (interior Can | ● | ● | ● | ● | ● | |
| Up to 06/2009 | S-Class | 221 | Air conditioning | AAC-Automatic air conditioning | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Air conditioning | STH-Stationary heater with remote control | ● | ● | ● | ● | ● | ● |
| Up to 06/2009 | S-Class | 221 | Air conditioning | KBE-H-Rear A/C operating unit | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Drive | ISM-Shift module (A80) | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |
| As of 07/2009 | S-Class | 221 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Drive | ME 9.7-Motor electronics 9.7 | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ○ | ● |
| As of 07/2009 | S-Class | 221 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Drive | MED 17.7-Motor electronics for direct injection 17.7 | ● | ● | ● | ● | ● | |
| As of 07/2009 | S-Class | 221 | Drive | ME-SF 17.7-Motor electronics 17.7 | ● | ● | ● | ● | ● | |
| As of 07/2009 | S-Class | 221 | Drive | SG-EM - Electric motor control unit | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ○ | ● |
| As of 07/2009 | S-Class | 221 | Drive | ME 9.7 (AMG)-Motor electronics 9.7 (AMG) | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Drive | FSCU-Fuel pump AMG | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Drive | CDI 3-Common Rail Diesel Injection3 | ● | ● | ● | ● | ● | |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------|---------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| As of 07/2009 | S-Class | 221 | Drive | CDI 5-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Drive | CDI 60LS-Common Rail Diesel Injection | ● | ● | ● | ● | ● | |
| As of 07/2009 | S-Class | 221 | Drive | SCR-Selective Catalytic Reduction | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Drive | ME 2.7.2-Motor electronics 2.7.2 | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Drive | ME 2.7.2-Motor electronics 2.7.2 | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Chassis | ABR-Adaptive Brake | ● | ● | ● | ● | ● | |
| As of 07/2009 | S-Class | 221 | Chassis | ABR-Adaptive Brake | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Chassis | AIRmatic | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Chassis | ABC-ABC active body control | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Chassis | Electronic parking brake-Electric parking brake | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Chassis | TPM - Tire pressure monitor(N88) | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Chassis | EHPS-Electrohydraulic Power Steering | ● | ● | ● | ● | ● | |
| As of 07/2009 | S-Class | 221 | Chassis | RBS-Brake system | ▲ | ▲ | ▲ | ▲ | ▲ | |
| As of 07/2009 | S-Class | 221 | Body | CGW-Central gateway | ● | ● | ● | ● | ○ | ● |
| As of 07/2009 | S-Class | 221 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | |
| As of 07/2009 | S-Class | 221 | Body | KG-Keyless Go | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Body | KG-KEYLESS GO | ● | ● | ● | ● | ● | |
| As of 07/2009 | S-Class | 221 | Body | MSS-Special vehicle multifunction control module | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Body | AB-Airbag | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Body | SGR-Radar sensors control unit | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |
| As of 07/2009 | S-Class | 221 | Body | SGR-Radar sensors control unit | ● | ● | ● | ● | ○ | ● |
| As of 07/2009 | S-Class | 221 | Body | WSS-Weight sensing system | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Body | UCP-Upper control panel | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Body | Dr-side SAM-Driver signal acquisition and actuation module | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Body | REAR SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Body | Trailer recognition module | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Body | PSD-Panoramic sliding roof(Interior CAN bus) | ● | ● | ● | ● | ● | |
| As of 07/2009 | S-Class | 221 | Body | RevETR-LF-Left front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Body | RevETR-LF-Left front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | |
| As of 07/2009 | S-Class | 221 | Body | RevETR-RF-Right front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Body | RevETR-LF-Left front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | |
| As of 07/2009 | S-Class | 221 | Body | XALWA-L-Xenon headlamp, left | ● | ● | ● | ● | ● | |
| As of 07/2009 | S-Class | 221 | Body | XALWA-L-Xenon headlamp, left | ● | ● | ● | ● | ● | |
| As of 07/2009 | S-Class | 221 | Body | XALWA-R-Xenon headlamp, right | ● | ● | ● | ● | ● | |
| As of 07/2009 | S-Class | 221 | Body | XALWA-R-Xenon headlamp, right | ● | ● | ● | ● | ● | |
| As of 07/2009 | S-Class | 221 | Body | System diagnosis(CAN) | ● | ● | ● | ● | ● | ○ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| As of 07/2009 | S-Class | 221 | Body | COU [ZBE]-Central operating unit | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Body | HBF (Rear control panel)-Rear control field | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Body | SG-BMS - Battery management system control unit | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Body | SG-DDW - DC/DC converter control unit | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Body | BNS-Vehicle power supply control module | ● | ● | ● | ● | ● | ○ |
| As of 07/2009 | S-Class | 221 | Information and communication | NSA-Night View Assist | ● | ● | ● | ● | ● | ○ |
| As of 07/2009 | S-Class | 221 | Information and communication | MFK-Multifunction camera | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |
| As of 07/2009 | S-Class | 221 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Information and communication | IC-Instrument cluster | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Information and communication | ASSYST-Active Service System | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Information and communication | ASSYST PLUS | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Information and communication | PTS-PARKTRONIC(N62) | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Information and communication | RFK-Backup camera(B84/3) | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Information and communication | COMAND | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Information and communication | COMAND | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Information and communication | Sound system (Main amplifier) | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Information and communication | Sound system (Bass amplifier) | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Information and communication | Tuner-Standard tuner | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Information and communication | Tuner-Tuner sound | ● | ● | ● | ● | ○ | ○ |
| As of 07/2009 | S-Class | 221 | Information and communication | Tuner-Tuner sound | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Information and communication | VCS-Voice control | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Information and communication | CTEL-Mobile phone adapter with universal interface | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Information and communication | TV-TV tuner(AGW) | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| As of 07/2009 | S-Class | 221 | Information and communication | SDAR-Satellite radio(Valid for USA) | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Information and communication | DAB-Digital radio | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Information and communication | ZAN-Central display | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Information and communication | AVE-H-Rear audio video unit | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Information and communication | UCI-Media interface | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Information and communication | AVE-H-Rear audio video unit | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Information and communication | Left rear screen | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Information and communication | Right rear screen | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Information and communication | TELE AID-Control unit | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Information and communication | TELE AID-Telematic services Emergency call | ● | ● | ● | ● | | ● |
| As of 07/2009 | S-Class | 221 | Information and communication | TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE) | ● | ● | ● | ● | | ● |
| As of 07/2009 | S-Class | 221 | Information and communication | TELE AID-Telematic services Stolen vehicle tracking | ● | ● | ● | ● | | ● |
| As of 07/2009 | S-Class | 221 | Information and communication | TELE AID-Telematic services Remote door unlocking,Remote door locking | ● | ● | ● | ● | | ● |
| As of 07/2009 | S-Class | 221 | Information and communication | ICI-InCar Internet (N125/3) | ● | ● | ○ | ● | ○ | ● |
| As of 07/2009 | S-Class | 221 | Seats and doors | DS-LF-Left front dynamic seat | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Seats and doors | DS-RF-Right front dynamic seat | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Seats and doors | MKL-HL-Rear left multicontour backrest | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Seats and doors | MKL-HR-Rear right multicontour backrest | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Seats and doors | DSP-Pneumatic pump for dynamic seat | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Seats and doors | DCM-FL-Door control module front left | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Seats and doors | DCM-FR-Door control module front right | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Seats and doors | DCM-RL-Door control module rear left | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Seats and doors | DCM-RR-Door control module rear right | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Seats and doors | ESA-FL-Electric seat adjustment front left | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Seats and doors | ESA-FR-Electric seat adjustment front right | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Seats and doors | ESA-R-Electric seat adjustment rear | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Seats and doors | TLC-Trunk lid control | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Seats and doors | TSG-ML-Left center door control unit (interior Can | ● | ● | ● | ● | ● | |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------|---------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| As of 07/2009 | S-Class | 221 | Seats and doors | TSG-MR-Right center door control unit (interior Can | ● | ● | ● | ● | ● | |
| As of 07/2009 | S-Class | 221 | Air conditioning | AAC-Automatic air conditioning | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Air conditioning | STH-Stationary heater with remote control | ● | ● | ● | ● | ● | ● |
| As of 07/2009 | S-Class | 221 | Air conditioning | KBE-H-Rear A/C operating unit | ● | ● | ● | ● | ● | ● |
| Up to 08/2002 | S-Class | 220 | Drive | ETC-Electronic transmission control | ● | ● | ○ | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| Up to 08/2002 | S-Class | 220 | Drive | ESM-Electronic selector module | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Drive | ME-SFI 2.0-Motor electronics 2.0 | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| Up to 08/2002 | S-Class | 220 | Drive | ME-SFI 2.0-Motor electronics 2.0 | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| Up to 08/2002 | S-Class | 220 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| Up to 08/2002 | S-Class | 220 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ● |
| Up to 08/2002 | S-Class | 220 | Drive | ME-SFI 2.7-Motor electronics 2.7 | ● | ● | ● | ● | ● | ● |
| Up to 08/2002 | S-Class | 220 | Drive | CDI 2-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| Up to 08/2002 | S-Class | 220 | Drive | CDI-V-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| Up to 08/2002 | S-Class | 220 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Chassis | AIRmatic | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Chassis | ABC-ABC active body control | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Chassis | TPM - Tire pressure monitor(N88) | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Body | AB-Airbag | ● | ● | ○ | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Body | SAM-FL-Front left signal acquisition and actuation module | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Body | SAM-FR-Front right signal acquisition and actuation module | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Body | REAR SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Body | AHE-Trailer recognition | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Body | PSE-Pneumatic system equipment | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Body | UCP-Upper control panel | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Body | KG-Keyless Go | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Body | MSS-Special vehicle multifunction control module | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Body | HRA-Headlamp range adjustment | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Body | HRA-Headlamp range adjustment | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Body | HRA-FR-Front right headlamp range control | ● | ● | ● | ● | ● | ○ |
| Up to 08/2002 | S-Class | 220 | Body | HRA-FL-Front left headlamp range control | ● | ● | ● | ● | ● | ○ |
| Up to 08/2002 | S-Class | 220 | Body | CGW-Central gateway | ● | ● | ● | ● | ○ | ○ |
| Up to 08/2002 | S-Class | 220 | Body | AB-Airbag | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| Up to 08/2002 | S-Class | 220 | Body | RevETR-LF-Left front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |
| Up to 08/2002 | S-Class | 220 | Body | RevETR-RF-Right front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |
| Up to 08/2002 | S-Class | 220 | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ○ |
| Up to 08/2002 | S-Class | 220 | Body | UCP-Upper control panel | ● | ● | ● | ● | ● | ○ |
| Up to 08/2002 | S-Class | 220 | Body | System diagnosis (CAN) | ● | ● | ● | ● | ● | ● |
| Up to 08/2002 | S-Class | 220 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Information and communication | TSTH-Radio remote control of stationary heater | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ○ |
| Up to 08/2002 | S-Class | 220 | Information and communication | COMAND | ● | ● | ○ | ● | ● | ● |
| Up to 08/2002 | S-Class | 220 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| Up to 08/2002 | S-Class | 220 | Information and communication | CDC-CD changer | ● | ● | ● | ● | ○ | ○ |
| Up to 08/2002 | S-Class | 220 | Information and communication | CTEL- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ○ | ○ |
| Up to 08/2002 | S-Class | 220 | Information and communication | UHI- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ● | ○ |
| Up to 08/2002 | S-Class | 220 | Information and communication | SOUND- Sound system | ● | ● | ○ | ● | ● | ● |
| Up to 08/2002 | S-Class | 220 | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ○ |
| Up to 08/2002 | S-Class | 220 | Information and communication | TV-TV tuner | ● | ● | ● | ● | | ● |
| Up to 08/2002 | S-Class | 220 | Information and communication | E-call [Japan]-Emergency call system | ● | ● | ○ | ● | ● | ● |
| Up to 08/2002 | S-Class | 220 | Information and communication | E-call [Japan]-Telematic system | ● | ● | ● | ● | ● | ● |
| Up to 08/2002 | S-Class | 220 | Information and communication | E-call [USA]-Emergency call system | ● | ● | ● | ● | ○ | ○ |
| Up to 08/2002 | S-Class | 220 | Information and communication | TELE AID-Emergency call system | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| Up to 08/2002 | S-Class | 220 | Information and communication | E-call [USA]-Telematic system | ● | ● | ● | ● | ● | ● |
| Up to 08/2002 | S-Class | 220 | Information and communication | TELE AID-Telematic system | ● | ● | ● | ● | ● | |
| Up to 08/2002 | S-Class | 220 | Information and communication | CTEL over K-wire-Telematic system | ● | ● | ● | ● | ○ | ○ |
| Up to 08/2002 | S-Class | 220 | Information and communication | DN-Dynamic navigation by means of CTEL | ● | ● | ● | ● | ● | ○ |
| Up to 08/2002 | S-Class | 220 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Information and communication | SDAR-Satellite radio | ● | ● | ● | ● | ○ | ● |
| Up to 08/2002 | S-Class | 220 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| Up to 08/2002 | S-Class | 220 | Information and communication | CTEL-Telecommunication for telematics services | ● | ● | ● | ● | ● | ● |
| Up to 08/2002 | S-Class | 220 | Information and communication | Telephone adapter for portable CTET-Telecommunication for telematics services | ● | ● | ● | ● | ● | ● |
| Up to 08/2002 | S-Class | 220 | Information and communication | CTEL-Mobile phone adapter with universal interface | ● | ● | ● | ● | ● | ● |
| Up to 08/2002 | S-Class | 220 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| Up to 08/2002 | S-Class | 220 | Information and communication | COMAND or AUDIO | ● | ● | ○ | ● | ● | ● |
| Up to 08/2002 | S-Class | 220 | Information and communication | NAVI-Navigation system | ● | ● | ○ | ● | ● | ● |
| Up to 08/2002 | S-Class | 220 | Information and communication | CDC-CD changer | ● | ● | ○ | ● | ● | ● |
| Up to 08/2002 | S-Class | 220 | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ● |
| Up to 08/2002 | S-Class | 220 | Information and communication | SOUND-Bose sound system | ● | ● | ○ | ● | ● | ● |
| Up to 08/2002 | S-Class | 220 | Information and communication | TV-TV tuner | ● | ● | ○ | ● | ● | ● |
| Up to 08/2002 | S-Class | 220 | Information and communication | TV-TV tuner(AGW) | ● | ● | ● | ● | ● | ● |
| Up to 08/2002 | S-Class | 220 | Information and communication | SDAR-Satellite radio | ● | ● | ○ | ● | ● | ● |
| Up to 08/2002 | S-Class | 220 | Information and communication | GPS box | ● | ● | ○ | ● | ● | ● |
| Up to 08/2002 | S-Class | 220 | Information and communication | TELE AID-Control unit | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| Up to 08/2002 | S-Class | 220 | Information and communication | TELE AID-Telematic services Emergency call | ● | ● | ● | ● | | ● |
| Up to 08/2002 | S-Class | 220 | Information and communication | TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE) | ● | ● | ● | ● | | ● |
| Up to 08/2002 | S-Class | 220 | Information and communication | TELE AID-Telematic services Stolen vehicle tracking | ● | ● | ● | ● | | ● |
| Up to 08/2002 | S-Class | 220 | Information and communication | TELE AID-Telematic services Remote door unlocking,Remote door locking | ● | ● | ● | ● | | ● |
| Up to 08/2002 | S-Class | 220 | Seats and doors | DCM-FL-Door control module front left | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Seats and doors | DCM-FR-Door control module front right | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Seats and doors | DCM-RL-Door control module rear left | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Seats and doors | DCM-RR-Door control module rear right | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Seats and doors | ESA-R-Electric seat adjustment rear | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Seats and doors | ESA-FL-Electric seat adjustment front left | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Seats and doors | ESA-FR-Electric seat adjustment front right | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Seats and doors | OSB-R-Multicontour backrest rear | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Seats and doors | OSB-FL-Multicontour backrest front left | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Seats and doors | OSB-FR-Multicontour backrest front right | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Seats and doors | DS-LF-Left front dynamic seat | ● | ● | ● | ● | ● | ● |
| Up to 08/2002 | S-Class | 220 | Seats and doors | DS-RF-Right front dynamic seat | ● | ● | ● | ● | ● | ● |
| Up to 08/2002 | S-Class | 220 | Seats and doors | DSP-Pneumatic pump for dynamic seat | ● | ● | ● | ● | ● | ● |
| Up to 08/2002 | S-Class | 220 | Air conditioning | AAC-Automatic air conditioning | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Air conditioning | REAR AC- Rear air conditioning | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Air conditioning | STH-Stationary heater | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Air conditioning | HSW-Heated steering wheel | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Air conditioning | STH-Stationary heater | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | S-Class | 220 | Air conditioning | STH-Stationary heater | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | S-Class | 220 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | S-Class | 220 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | S-Class | 220 | Drive | ESM-Electronic selector module | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | S-Class | 220 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | S-Class | 220 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | S-Class | 220 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | S-Class | 220 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | S-Class | 220 | Drive | ME-SFI 2.7.1-Motor electronics 2.7.1 | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | S-Class | 220 | Drive | CDI 3-Common Rail Diesel Injection3 | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | S-Class | 220 | Drive | CDI 3-Common Rail Diesel Injection3 | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | S-Class | 220 | Drive | CDI-V-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | S-Class | 220 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | S-Class | 220 | Chassis | AIRmatic | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | S-Class | 220 | Chassis | ABC-ABC active body control | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | S-Class | 220 | Chassis | TPM - Tire pressure monitor(N88) | ● | ● | ● | ● | ● | ※ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| As of 09/2002 | S-Class | 220 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | S-Class | 220 | Body | SAM-FL-Front left signal acquisition and actuation module | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | S-Class | 220 | Body | SAM-FR-Front right signal acquisition and actuation module | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | S-Class | 220 | Body | REAR SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | S-Class | 220 | Body | AHE-Trailer recognition | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | S-Class | 220 | Body | PSE-Pneumatic system equipment | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | S-Class | 220 | Body | KG-Keyless Go | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | S-Class | 220 | Body | MSS-Special vehicle multifunction control module | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | S-Class | 220 | Body | HRA-Headlamp range adjustment | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | S-Class | 220 | Body | HRA-FR-Front right headlamp range control | ● | ● | ● | ● | ● | ○ |
| As of 09/2002 | S-Class | 220 | Body | HRA-FL-Front left headlamp range control | ● | ● | ● | ● | ● | ○ |
| As of 09/2002 | S-Class | 220 | Body | CGW-Central gateway | ● | ● | ● | ● | ○ | ○ |
| As of 09/2002 | S-Class | 220 | Body | AB-Airbag | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | S-Class | 220 | Body | RevETR-LF-Left front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | S-Class | 220 | Body | RevETR-RF-Right front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | S-Class | 220 | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ○ |
| As of 09/2002 | S-Class | 220 | Body | UCP-Upper control panel | ● | ● | ● | ● | ● | ○ |
| As of 09/2002 | S-Class | 220 | Body | System diagnosis(CAN) | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | S-Class | 220 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | S-Class | 220 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | S-Class | 220 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ○ |
| As of 09/2002 | S-Class | 220 | Information and communication | COMAND | ● | ● | ○ | ● | ● | ● |
| As of 09/2002 | S-Class | 220 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | S-Class | 220 | Information and communication | CDC-CD changer | ● | ● | ● | ● | ○ | ○ |
| As of 09/2002 | S-Class | 220 | Information and communication | CTEL- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ○ | ○ |
| As of 09/2002 | S-Class | 220 | Information and communication | UHI- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ● | ○ |
| As of 09/2002 | S-Class | 220 | Information and communication | SOUND- Sound system | ● | ● | ○ | ● | ● | ● |
| As of 09/2002 | S-Class | 220 | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ○ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| As of 09/2002 | S-Class | 220 | Information and communication | SDAR-Satellite radio | ● | ● | ● | ● | ○ | ● |
| As of 09/2002 | S-Class | 220 | Information and communication | TV-TV tuner | ● | ● | ● | ● | | ● |
| As of 09/2002 | S-Class | 220 | Information and communication | E-call [Japan]-Telematic system | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | S-Class | 220 | Information and communication | E-call [USA]-Telematic system | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | S-Class | 220 | Information and communication | TELE AID-Telematic system | ● | ● | ● | ● | ● | |
| As of 09/2002 | S-Class | 220 | Information and communication | CTEL over K-wire-Telematic system | ● | ● | ● | ● | ○ | ○ |
| As of 09/2002 | S-Class | 220 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | S-Class | 220 | Information and communication | CTEL-Telecommunication for telematics services | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | S-Class | 220 | Information and communication | Telephone adapter for portable CTCL-Telecommunication for telematics services | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | S-Class | 220 | Information and communication | CTEL-Mobile phone adapter with universal interface | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | S-Class | 220 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | S-Class | 220 | Information and communication | COMAND or AUDIO | ● | ● | ○ | ● | ● | ● |
| As of 09/2002 | S-Class | 220 | Information and communication | NAVI-Navigation system | ● | ● | ○ | ● | ● | ● |
| As of 09/2002 | S-Class | 220 | Information and communication | CDC-CD changer | ● | ● | ○ | ● | ● | ● |
| As of 09/2002 | S-Class | 220 | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ● |
| As of 09/2002 | S-Class | 220 | Information and communication | SOUND-Bose sound system | ● | ● | ○ | ● | ● | ● |
| As of 09/2002 | S-Class | 220 | Information and communication | TV-TV tuner | ● | ● | ○ | ● | ● | ● |
| As of 09/2002 | S-Class | 220 | Information and communication | TV-TV tuner(AGW) | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | S-Class | 220 | Information and communication | SDAR-Satellite radio | ● | ● | ○ | ● | ● | ● |
| As of 09/2002 | S-Class | 220 | Information and communication | GPS box | ● | ● | ○ | ● | ● | ● |
| As of 09/2002 | S-Class | 220 | Information and communication | TELE AID-Control unit | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| As of 09/2002 | S-Class | 220 | Information and communication | TELE AID-Telematic services Emergency call | ● | ● | ● | ● | | ● |
| As of 09/2002 | S-Class | 220 | Information and communication | TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE) | ● | ● | ● | ● | | ● |
| As of 09/2002 | S-Class | 220 | Information and communication | TELE AID-Telematic services Stolen vehicle tracking | ● | ● | ● | ● | | ● |
| As of 09/2002 | S-Class | 220 | Information and communication | TELE AID-Telematic services Remote door unlocking,Remote door locking | ● | ● | ● | ● | | ● |
| As of 09/2002 | S-Class | 220 | Seats and doors | DCM-FL-Door control module front left | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | S-Class | 220 | Seats and doors | DCM-FR-Door control module front right | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | S-Class | 220 | Seats and doors | DCM-RL-Door control module rear left | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | S-Class | 220 | Seats and doors | DCM-RR-Door control module rear right | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | S-Class | 220 | Seats and doors | ESA-R-Electric seat adjustment rear | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | S-Class | 220 | Seats and doors | ESA-FL-Electric seat adjustment front left | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | S-Class | 220 | Seats and doors | ESA-FR-Electric seat adjustment front right | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | S-Class | 220 | Seats and doors | OSB-R-Multicontour backrest rear | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | S-Class | 220 | Seats and doors | OSB-FL-Multicontour backrest front left | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | S-Class | 220 | Seats and doors | OSB-FR-Multicontour backrest front right | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | S-Class | 220 | Seats and doors | DS-LF-Left front dynamic seat | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | S-Class | 220 | Seats and doors | DS-RF-Right front dynamic seat | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | S-Class | 220 | Seats and doors | DSP-Pneumatic pump for dynamic seat | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | S-Class | 220 | Air conditioning | AAC-Automatic air conditioning | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | S-Class | 220 | Air conditioning | REAR AC- Rear air conditioning | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | S-Class | 220 | Air conditioning | HSW-Heated steering wheel | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | S-Class | 220 | Air conditioning | STH-Stationary heater | ● | ● | ● | ● | ● | ● |
| ALL | S-Class | 140 | Drive | ME2-SFI-Motor electronics 2 | ● | ● | ○ | ● | ● | ※ |
| ALL | S-Class | 140 | Drive | ME1RE-Motor electronics 1 RE | ● | ● | ○ | ● | ○ | ※ |
| ALL | S-Class | 140 | Drive | EFP,TPM,ISC-Electronic accelerator pedal,Cruise control,Idle speed control | ● | ● | ○ | ● | ○ | ※ |
| ALL | S-Class | 140 | Chassis | EGS,EAG-Electronic control for automatic transmission | ● | ● | ○ | ● | ○ | ※ |
| ALL | S-Class | 140 | Chassis | ESP-Electronic stability program | ● | ● | ○ | ● | ● | ※ |
| ALL | S-Class | 140 | Chassis | BAS-Brake assist | ● | ● | ○ | ● | ● | ※ |
| ALL | S-Class | 140 | Chassis | SPS-Speed-sensitive power steering | ● | ● | ○ | ● | ● | ※ |
| ALL | S-Class | 140 | Body | RFL-Radio frequency locking/electric central locking | ● | ● | ○ | ● | ● | ※ |
| ALL | S-Class | 140 | Body | PTS-Parktronic system | ● | ● | ○ | ● | ○ | ※ |
| ALL | S-Class | 140 | Body | PSE-Pneumatic system equipment | ● | ● | ○ | ● | ○ | ※ |
| ALL | S-Class | 140 | Body | AirBag | ● | ● | ○ | ● | ○ | ※ |
| ALL | S-Class | 140 | Body | KFB-Power windows,emergency opening,convenience closing,tilting/sliding roof | ● | ● | ○ | ● | ○ | ※ |
| ALL | S-Class | 140 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ○ | ● | ● | ※ |
| ALL | S-Class | 140 | Air conditioning | AAC-Automatic air conditioning | ● | ● | ○ | ● | | ※ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|-------|--------------|---------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | CL | 216 | Drive | ISM-Intelligent servo module | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Drive | ISM-Shift module (A80) | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |
| ALL | CL | 216 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Drive | ME 9.7-Motor electronics 9.7 | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ○ | ● |
| ALL | CL | 216 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Drive | SGR-Radar sensors control unit | ● | ● | ● | ● | ● | ○ |
| ALL | CL | 216 | Drive | ME 2.7.2-Motor electronics 2.7.2 | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Drive | ME 2.7.2-Motor electronics 2.7.2 | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Drive | FSCU-Fuel pump AMG | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ○ | ● |
| ALL | CL | 216 | Drive | ME 9.7 (AMG)-Motor electronics 9.7 (AMG) | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Drive | MED 17.7-Motor electronics for direct injection 17.7 | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Chassis | ABR-Adaptive Brake | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Chassis | ABR-Adaptive Brake | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Chassis | AIRmatic | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Chassis | ABC-ABC active body control | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Chassis | Electronic parking brake-Electric parking brake | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Chassis | TPC-Tire pressure monitor | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Chassis | TPM - Tire pressure monitor(N88) | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Chassis | EHPS-Electrohydraulic Power Steering | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Body | CGW-Central gateway | ● | ● | ● | ● | ○ | ● |
| ALL | CL | 216 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Body | SGR-Radar sensors control unit | ● | ● | ● | ● | ○ | ● |
| ALL | CL | 216 | Body | KG-Keyless Go | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Body | KG-KEYLESS GO | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Body | AB-Airbag | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Body | WSS-Weight sensing system | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Body | UCP-Upper control panel | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Body | Dr-side SAM-Driver signal acquisition and actuation module | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Body | REAR SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Body | BNS-Vehicle power supply control module | ● | ● | ● | ● | ● | ○ |
| ALL | CL | 216 | Body | AHE-Trailer recognition | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Body | XALWA-L-Xenon headlamp, left | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Body | XALWA-L-Xenon headlamp, left | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|-------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | CL | 216 | Body | XALWA-L-Xenon headlamp, left | ● | ● | ● | ● | ● | |
| ALL | CL | 216 | Body | XALWA-R-Xenon headlamp, right | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Body | XALWA-R-Xenon headlamp, right | ● | ● | ● | ● | ● | |
| ALL | CL | 216 | Body | XALWA-R-Xenon headlamp, right | ● | ● | ● | ● | ● | |
| ALL | CL | 216 | Body | System diagnosis(CAN) | ● | ● | ● | ● | ● | ○ |
| ALL | CL | 216 | Body | COU [ZBE]-Central operating unit | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Information and communication | NSA-Night View Assist | ● | ● | ● | ● | ● | ○ |
| ALL | CL | 216 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Information and communication | IC-Instrument cluster | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Information and communication | ASSYST-Active Service System | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Information and communication | ASSYST PLUS | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Information and communication | PTS-Parktronic | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Information and communication | PTS-PARKTRONIC(N62) | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Information and communication | RFK-Backup camera(B84/3) | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Information and communication | MFK-Multifunction camera | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |
| ALL | CL | 216 | Information and communication | COMAND | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Information and communication | COMAND | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Information and communication | Tuner-Standard tuner | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Information and communication | Tuner-Tuner sound | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Information and communication | Tuner-Tuner sound | ● | ● | ● | ● | ○ | ○ |
| ALL | CL | 216 | Information and communication | VCS-Voice control | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Information and communication | CTEL-Mobile phone adapter with universal interface | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Information and communication | TV-TV tuner(AGW) | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Information and communication | DAB-Digital radio | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|-------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | CL | 216 | Information and communication | SDAR-Satellite radio(Valid for USA) | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Information and communication | ZAN-Central display | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Information and communication | UCI-Media interface | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Information and communication | TELE AID-Control unit | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Information and communication | TELE AID-Telematic services Emergency call | ● | ● | ● | ● | | ● |
| ALL | CL | 216 | Information and communication | TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE) | ● | ● | ● | ● | | ● |
| ALL | CL | 216 | Information and communication | TELE AID-Telematic services Stolen vehicle tracking | ● | ● | ● | ● | | ● |
| ALL | CL | 216 | Information and communication | TELE AID-Telematic services Remote door unlocking,Remote door locking | ● | ● | ● | ● | | ● |
| ALL | CL | 216 | Information and communication | ICI-InCar Internet (N125/3) | ● | ● | ○ | ● | ○ | ● |
| ALL | CL | 216 | Seats and doors | DS-LF-Left front dynamic seat | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Seats and doors | DS-RF-Right front dynamic seat | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Seats and doors | DSP-Pneumatic pump for dynamic seat | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Seats and doors | DCM-FL-Door control module front left | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Seats and doors | DCM-FR-Door control module front right | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Seats and doors | RCM-Rear control module | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Seats and doors | ESA-FL-Electric seat adjustment front left | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Seats and doors | ESA-FR-Electric seat adjustment front right | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Seats and doors | TLC-Trunk lid control | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Seats and doors | TLC-Trunk lid control | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Air conditioning | AAC-Automatic air conditioning | ● | ● | ● | ● | ● | ● |
| ALL | CL | 216 | Air conditioning | STH-Stationary heater with remote control | ● | ● | ● | ● | ● | ● |
| Up to 08/2002 | CL | 215 | Drive | ETC-Electronic transmission control | ● | ● | ○ | ● | ● | ※ |
| Up to 08/2002 | CL | 215 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| Up to 08/2002 | CL | 215 | Drive | ESM-Electronic selector module | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | CL | 215 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | CL | 215 | Drive | ME-SFI 2.0-Motor electronics 2.0 | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | CL | 215 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| Up to 08/2002 | CL | 215 | Drive | ME-SFI 2.0-Motor electronics 2.0 | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | CL | 215 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| Up to 08/2002 | CL | 215 | Drive | ME-SFI 2.7-Motor electronics 2.7 | ● | ● | ● | ● | ● | ● |
| Up to 08/2002 | CL | 215 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | CL | 215 | Chassis | ABC-ABC active body control | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | CL | 215 | Chassis | TPM - Tire pressure monitor(N88) | ● | ● | ● | ● | ● | ※ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|-------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| Up to 08/2002 | CL | 215 | Body | AB-Airbag | ● | ● | ○ | ● | ● | ※ |
| Up to 08/2002 | CL | 215 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | CL | 215 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | CL | 215 | Body | SAM-FL-Front left signal acquisition and actuation module | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | CL | 215 | Body | SAM-FR-Front right signal acquisition and actuation module | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | CL | 215 | Body | REAR SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | CL | 215 | Body | AHE-Trailer recognition | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | CL | 215 | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | CL | 215 | Body | PSE-Pneumatic system equipment | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | CL | 215 | Body | UCP-Upper control panel | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | CL | 215 | Body | KG-Keyless Go | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | CL | 215 | Body | MSS-Special vehicle multifunction control module | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | CL | 215 | Body | HRA-Headlamp range adjustment | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | CL | 215 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | CL | 215 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | CL | 215 | Information and communication | TSTH-Radio remote control of stationary heater | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | CL | 215 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | CL | 215 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ○ |
| Up to 08/2002 | CL | 215 | Information and communication | COMAND | ● | ● | ○ | ● | ● | ● |
| Up to 08/2002 | CL | 215 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| Up to 08/2002 | CL | 215 | Information and communication | CDC-CD changer | ● | ● | ● | ● | ○ | ○ |
| Up to 08/2002 | CL | 215 | Information and communication | CTEL- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ○ | ○ |
| Up to 08/2002 | CL | 215 | Information and communication | UHI- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ● | ○ |
| Up to 08/2002 | CL | 215 | Information and communication | SOUND- Sound system | ● | ● | ○ | ● | ● | ● |
| Up to 08/2002 | CL | 215 | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ○ |
| Up to 08/2002 | CL | 215 | Information and communication | TV-TV tuner | ● | ● | ● | ● | | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|-------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| Up to 08/2002 | CL | 215 | Information and communication | E-call [Japan]-Emergency call system | ● | ● | ○ | ● | ● | ● |
| Up to 08/2002 | CL | 215 | Information and communication | E-call [Japan]-Telematic system | ● | ● | ● | ● | ● | ● |
| Up to 08/2002 | CL | 215 | Information and communication | E-call [USA]-Emergency call system | ● | ● | ● | ● | ○ | ○ |
| Up to 08/2002 | CL | 215 | Information and communication | TELE AID-Emergency call system | ● | ● | ● | ● | ● | ● |
| Up to 08/2002 | CL | 215 | Information and communication | E-call [USA]-Telematic system | ● | ● | ● | ● | ● | ● |
| Up to 08/2002 | CL | 215 | Information and communication | TELE AID-Telematic system | ● | ● | ● | ● | ● | |
| Up to 08/2002 | CL | 215 | Information and communication | CTEL over K-wire-Telematic system | ● | ● | ● | ● | ○ | ○ |
| Up to 08/2002 | CL | 215 | Information and communication | DN-Dynamic navigation by means of CTEL | ● | ● | ● | ● | ● | ○ |
| Up to 08/2002 | CL | 215 | Seats and doors | DCM-FL-Door control module front left | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | CL | 215 | Seats and doors | DCM-FR-Door control module front right | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | CL | 215 | Seats and doors | RCM-Rear control module | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | CL | 215 | Seats and doors | ESA-FL-Electric seat adjustment front left | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | CL | 215 | Seats and doors | ESA-FR-Electric seat adjustment front right | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | CL | 215 | Seats and doors | OSB-FL-Multicontour backrest front left | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | CL | 215 | Seats and doors | OSB-FR-Multicontour backrest front right | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | CL | 215 | Air conditioning | AAC-Automatic air conditioning | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | CL | 215 | Air conditioning | STH-Stationary heater | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | CL | 215 | Air conditioning | HSW-Heated steering wheel | ● | ● | ● | ● | ● | ※ |
| Up to 08/2002 | CL | 215 | Air conditioning | STH-Stationary heater | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | CL | 215 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | CL | 215 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | CL | 215 | Drive | ESM-Electronic selector module | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | CL | 215 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | CL | 215 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | CL | 215 | Drive | ME-SFI 2.0-Motor electronics 2.0 | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | CL | 215 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | CL | 215 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | CL | 215 | Drive | ME-SFI 2.7.1-Motor electronics 2.7.1 | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | CL | 215 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | CL | 215 | Chassis | ABC-ABC active body control | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | CL | 215 | Chassis | TPM - Tire pressure monitor (N88) | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | CL | 215 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | CL | 215 | Body | PSE-Pneumatic system equipment | ● | ● | ● | ● | ● | ※ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|-------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| As of 09/2002 | CL | 215 | Body | SAM-FL-Front left signal acquisition and actuation module | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | CL | 215 | Body | SAM-FR-Front right signal acquisition and actuation module | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | CL | 215 | Body | REAR SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | CL | 215 | Body | AHE-Trailer recognition | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | CL | 215 | Body | KG-Keyless Go | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | CL | 215 | Body | MSS-Special vehicle multifunction control module | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | CL | 215 | Body | HRA-FR-Front right headlamp range control | ● | ● | ● | ● | ● | ○ |
| As of 09/2002 | CL | 215 | Body | HRA-FL-Front left headlamp range control | ● | ● | ● | ● | ● | ○ |
| As of 09/2002 | CL | 215 | Body | CGW-Central gateway | ● | ● | ● | ● | ○ | ○ |
| As of 09/2002 | CL | 215 | Body | AB-Airbag | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | CL | 215 | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ○ |
| As of 09/2002 | CL | 215 | Body | UCP-Upper control panel | ● | ● | ● | ● | ● | ○ |
| As of 09/2002 | CL | 215 | Body | System diagnosis (CAN) | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | CL | 215 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | CL | 215 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | CL | 215 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ○ |
| As of 09/2002 | CL | 215 | Information and communication | COMAND | ● | ● | ○ | ● | ● | ● |
| As of 09/2002 | CL | 215 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | CL | 215 | Information and communication | CDC-CD changer | ● | ● | ● | ● | ○ | ○ |
| As of 09/2002 | CL | 215 | Information and communication | CTEL- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ○ | ○ |
| As of 09/2002 | CL | 215 | Information and communication | UHI- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ● | ○ |
| As of 09/2002 | CL | 215 | Information and communication | SOUND- Sound system | ● | ● | ○ | ● | ● | ● |
| As of 09/2002 | CL | 215 | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ○ |
| As of 09/2002 | CL | 215 | Information and communication | SDAR-Satellite radio | ● | ● | ● | ● | ○ | ● |
| As of 09/2002 | CL | 215 | Information and communication | TV-TV tuner | ● | ● | ● | ● | | ● |
| As of 09/2002 | CL | 215 | Information and communication | E-call [Japan]-Telematic system | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|-------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| As of 09/2002 | CL | 215 | Information and communication | E-call [USA]-Telematic system | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | CL | 215 | Information and communication | TELE AID-Telematic system | ● | ● | ● | ● | ● | |
| As of 09/2002 | CL | 215 | Information and communication | CTEL over K-wire-Telematic system | ● | ● | ● | ● | ○ | ○ |
| As of 09/2002 | CL | 215 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | CL | 215 | Information and communication | CTEL-Telecommunication for telematics services | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | CL | 215 | Information and communication | Telephone adapter for portable CTEL-Telecommunication for telematics services | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | CL | 215 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | CL | 215 | Information and communication | COMAND or AUDIO | ● | ● | ○ | ● | ● | ● |
| As of 09/2002 | CL | 215 | Information and communication | CTEL-Mobile phone adapter with universal interface | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | CL | 215 | Information and communication | NAVI-Navigation system | ● | ● | ○ | ● | ● | ● |
| As of 09/2002 | CL | 215 | Information and communication | CDC-CD changer | ● | ● | ○ | ● | ● | ● |
| As of 09/2002 | CL | 215 | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ● |
| As of 09/2002 | CL | 215 | Information and communication | SOUND-Bose sound system | ● | ● | ○ | ● | ● | ● |
| As of 09/2002 | CL | 215 | Information and communication | TV-TV tuner | ● | ● | ○ | ● | ● | ● |
| As of 09/2002 | CL | 215 | Information and communication | TV-TV tuner(AGW) | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | CL | 215 | Information and communication | SDAR-Satellite radio | ● | ● | ○ | ● | ● | ● |
| As of 09/2002 | CL | 215 | Information and communication | GPS box | ● | ● | ○ | ● | ● | ● |
| As of 09/2002 | CL | 215 | Information and communication | TELE AID-Control unit | ● | ● | ● | ● | ● | ● |
| As of 09/2002 | CL | 215 | Information and communication | TELE AID-Telematic services Emergency call | ● | ● | ● | ● | | ● |
| As of 09/2002 | CL | 215 | Information and communication | TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE) | ● | ● | ● | ● | | ● |
| As of 09/2002 | CL | 215 | Information and communication | TELE AID-Telematic services Stolen vehicle tracking | ● | ● | ● | ● | | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| As of 09/2002 | CL | 215 | Information and communication | TELE AID-Telematic services Remote door unlocking, Remote door locking | ● | ● | ● | ● | | ● |
| As of 09/2002 | CL | 215 | Seats and doors | DCM-FL-Door control module front left | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | CL | 215 | Seats and doors | DCM-FR-Door control module front right | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | CL | 215 | Seats and doors | RCM-Rear control module | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | CL | 215 | Seats and doors | ESA-FL-Electric seat adjustment front left | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | CL | 215 | Seats and doors | ESA-FR-Electric seat adjustment front right | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | CL | 215 | Seats and doors | OSB-FL-Multicontour backrest front left | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | CL | 215 | Seats and doors | OSB-FR-Multicontour backrest front right | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | CL | 215 | Air conditioning | AAC-Automatic air conditioning | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | CL | 215 | Air conditioning | REAR AC- Rear air conditioning | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | CL | 215 | Air conditioning | HSW-Heated steering wheel | ● | ● | ● | ● | ● | ※ |
| As of 09/2002 | CL | 215 | Air conditioning | STH-Stationary heater | ● | ● | ● | ● | ● | ● |
| Up to 08/2006 | MayBach | 240 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| Up to 08/2006 | MayBach | 240 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| Up to 08/2006 | MayBach | 240 | Drive | ESM-Electronic selector module | ● | ● | ● | ● | ● | ※ |
| Up to 08/2006 | MayBach | 240 | Drive | SGR-Radar sensors control unit | ● | ● | ● | ● | ● | ● |
| Up to 08/2006 | MayBach | 240 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ※ |
| Up to 08/2006 | MayBach | 240 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ● |
| Up to 08/2006 | MayBach | 240 | Drive | ME-SFI 2.7.1-Motor electronics 2.7.1 | ● | ● | ● | ● | ● | ● |
| Up to 08/2006 | MayBach | 240 | Chassis | SBC-Sensotronic Brake Control | ● | ● | ● | ● | ● | ○ |
| Up to 08/2006 | MayBach | 240 | Chassis | SBC-Right Sensotronic Brake Control | ● | ● | ● | ● | ● | ○ |
| Up to 08/2006 | MayBach | 240 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| Up to 08/2006 | MayBach | 240 | Chassis | AIRmatic | ● | ● | ● | ● | ● | ○ |
| Up to 08/2006 | MayBach | 240 | Chassis | TPC-Tire pressure monitor | ● | ● | ● | ● | ● | ● |
| Up to 08/2006 | MayBach | 240 | Body | CGW-Central gateway | ● | ● | ● | ● | ● | ○ |
| Up to 08/2006 | MayBach | 240 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ● |
| Up to 08/2006 | MayBach | 240 | Body | AB-Airbag | ● | ● | ● | ● | ● | ● |
| Up to 08/2006 | MayBach | 240 | Body | WSS-Weight sensing system | ● | ● | ● | ● | ● | ○ |
| Up to 08/2006 | MayBach | 240 | Body | BNS-Vehicle power supply control module | ● | ● | ● | ● | ● | ○ |
| Up to 08/2006 | MayBach | 240 | Body | Dr-side SAM-Driver signal acquisition and actuation module | ● | ● | ● | ● | ● | ○ |
| Up to 08/2006 | MayBach | 240 | Body | Pass-side SAM-Passenger-side signal acquisition and actuation module | ● | ● | ● | ● | ● | ○ |
| Up to 08/2006 | MayBach | 240 | Body | Rear SAM 1-Rear signal acquisition and actuation | ● | ● | ● | ● | ● | ○ |
| Up to 08/2006 | MayBach | 240 | Body | Rear SAM 2-Rear signal acquisition and actuation | ● | ● | ● | ● | ● | ○ |
| Up to 08/2006 | MayBach | 240 | Body | MSS-Special vehicle multifunction control module | ● | ● | ● | ● | ● | ○ |
| Up to 08/2006 | MayBach | 240 | Body | VBF (Front control panel)-Front control panel | ● | ● | ● | ● | ● | ○ |
| Up to 08/2006 | MayBach | 240 | Body | HBF (Rear control panel)-Rear control field | ● | ● | ● | ● | ● | ○ |
| Up to 08/2006 | MayBach | 240 | Body | BCG-Remote control(Rear control field) | ● | ● | ● | ● | ● | ○ |
| Up to 08/2006 | MayBach | 240 | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ○ |
| Up to 08/2006 | MayBach | 240 | Body | CRN-Center roof node | ● | ● | ○ | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| Up to 08/2006 | MayBach | 240 | Body | PSE-Pneumatic system equipment | ● | ● | ● | ● | ● | ○ |
| Up to 08/2006 | MayBach | 240 | Body | HRA-Automatic headlamp range adjustment and headlamp control | ● | ● | ● | ● | ● | ○ |
| Up to 08/2006 | MayBach | 240 | Body | System diagnosis(CAN) | ● | ● | ● | ● | ● | ● |
| Up to 08/2006 | MayBach | 240 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ● |
| Up to 08/2006 | MayBach | 240 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ● |
| Up to 08/2006 | MayBach | 240 | Information and communication | ICM-Instrument cluster | ● | ● | ● | ● | ● | ○ |
| Up to 08/2006 | MayBach | 240 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| Up to 08/2006 | MayBach | 240 | Information and communication | CTEL-Telecommunication for telematics services | ● | ● | ● | ● | ● | ● |
| Up to 08/2006 | MayBach | 240 | Information and communication | Telephone adapter for portable CTEL-Telecommunication for telematics services | ● | ● | ● | ● | ● | ● |
| Up to 08/2006 | MayBach | 240 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| Up to 08/2006 | MayBach | 240 | Information and communication | COMAND or AUDIO | ● | ● | ○ | ● | ● | ● |
| Up to 08/2006 | MayBach | 240 | Information and communication | NAVI-Navigation system | ● | ● | ○ | ● | ● | ● |
| Up to 08/2006 | MayBach | 240 | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ● |
| Up to 08/2006 | MayBach | 240 | Information and communication | TV-TV tuner | ● | ● | ○ | ● | ● | ● |
| Up to 08/2006 | MayBach | 240 | Information and communication | TV-TV tuner(AGW) | ● | ● | ● | ● | ● | ● |
| Up to 08/2006 | MayBach | 240 | Information and communication | SOUND-Bose sound system | ● | ● | ○ | ● | ● | ● |
| Up to 08/2006 | MayBach | 240 | Information and communication | SDAR-Satellite radio | ● | ● | ○ | ● | ● | ● |
| Up to 08/2006 | MayBach | 240 | Information and communication | CTEL-Mobile phone adapter with universal interface | ● | ● | ● | ● | ● | ● |
| Up to 08/2006 | MayBach | 240 | Information and communication | AVC-Audio video controller | ● | ● | ○ | ● | ● | ● |
| Up to 08/2006 | MayBach | 240 | Information and communication | TV-TV tuner(REAR) | ● | ● | ○ | ● | ● | ● |
| Up to 08/2006 | MayBach | 240 | Information and communication | TV-TV tuner (rear) | ● | ● | ● | ● | ● | ● |
| Up to 08/2006 | MayBach | 240 | Information and communication | CDC-CD changer (REAR) | ● | ● | ○ | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| Up to 08/2006 | MayBach | 240 | Information and communication | KTL-Left headphone transmitter | ● | ● | ○ | ● | ● | ○ |
| Up to 08/2006 | MayBach | 240 | Information and communication | KTR-Right headphone transmitter | ● | ● | ○ | ● | ● | ○ |
| Up to 08/2006 | MayBach | 240 | Information and communication | GPS box | ● | ● | ○ | ● | ● | ● |
| Up to 08/2006 | MayBach | 240 | Information and communication | TELE AID-Control unit | ● | ● | ● | ● | ● | ● |
| Up to 08/2006 | MayBach | 240 | Information and communication | TELE AID-Telematic services Emergency call | ● | ● | ● | ● | | ● |
| Up to 08/2006 | MayBach | 240 | Information and communication | TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE) | ● | ● | ● | ● | | ● |
| Up to 08/2006 | MayBach | 240 | Information and communication | TELE AID-Telematic services Stolen vehicle tracking | ● | ● | ● | ● | | ● |
| Up to 08/2006 | MayBach | 240 | Information and communication | TELE AID-Telematic services Remote door unlocking,Remote door locking | ● | ● | ● | ● | | ● |
| Up to 08/2006 | MayBach | 240 | Seats and doors | ESA-FL-Electric seat adjustment front left | ● | ● | ● | ● | ● | ○ |
| Up to 08/2006 | MayBach | 240 | Seats and doors | ESA-FR-Electric seat adjustment front right | ● | ● | ● | ● | ● | ○ |
| Up to 08/2006 | MayBach | 240 | Seats and doors | ESA-LR-Left rear electrical seat adjustment | ● | ● | ● | ● | ● | ○ |
| Up to 08/2006 | MayBach | 240 | Seats and doors | ESA-RR-Right rear electrical seat adjustment | ● | ● | ○ | ● | ● | ● |
| Up to 08/2006 | MayBach | 240 | Seats and doors | OSB-FL-Multicontour backrest front left | ● | ● | ● | ● | ● | ○ |
| Up to 08/2006 | MayBach | 240 | Seats and doors | OSB-FR-Multicontour backrest front right | ● | ● | ○ | ● | ● | ○ |
| Up to 08/2006 | MayBach | 240 | Seats and doors | MKL-HL-Rear left multicontour backrest | ● | ● | ● | ● | ● | ○ |
| Up to 08/2006 | MayBach | 240 | Seats and doors | MKL-HR-Rear right multicontour backrest | ● | ● | ● | ● | ● | ○ |
| Up to 08/2006 | MayBach | 240 | Seats and doors | DCM-FL-Door control module front left | ● | ● | ● | ● | ● | ○ |
| Up to 08/2006 | MayBach | 240 | Seats and doors | DCM-FR-Door control module front right | ● | ● | ● | ● | ● | ○ |
| Up to 08/2006 | MayBach | 240 | Seats and doors | DCM-RL-Door control module rear left | ● | ● | ● | ● | ● | ○ |
| Up to 08/2006 | MayBach | 240 | Seats and doors | DCM-RR-Door control module rear right | ● | ● | ● | ● | ● | ○ |
| Up to 08/2006 | MayBach | 240 | Seats and doors | PWC-Partition wall control module | ● | ● | ● | ● | ● | ○ |
| Up to 08/2006 | MayBach | 240 | Seats and doors | LDCA-Electric left door closing assist | ● | ● | ● | ● | ● | ● |
| Up to 08/2006 | MayBach | 240 | Seats and doors | RDCA-Electric right door closing assist | ● | ● | ● | ● | ● | ● |
| Up to 08/2006 | MayBach | 240 | Seats and doors | TLC-Trunk lid control | ● | ● | ● | ● | ● | ● |
| Up to 08/2006 | MayBach | 240 | Air conditioning | AAC-Automatic air conditioning | ● | ● | ● | ● | ● | ○ |
| Up to 08/2006 | MayBach | 240 | Air conditioning | REAR AC-Rear air conditioning | ● | ● | ● | ● | ● | ○ |
| Up to 08/2006 | MayBach | 240 | Air conditioning | STH-Stationary heater | ● | ● | ● | ● | ● | ● |
| Up to 08/2006 | MayBach | 240 | Air conditioning | HSW-Heated steering wheel | ● | ● | ● | ● | ● | ● |
| As of 09/2006 | MayBach | 240 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| As of 09/2006 | MayBach | 240 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| As of 09/2006 | MayBach | 240 | Drive | ESM-Electronic selector module | ● | ● | ● | ● | ● | ※ |
| As of 09/2006 | MayBach | 240 | Drive | SGR-Radar sensors control unit | ● | ● | ● | ● | ● | ● |
| As of 09/2006 | MayBach | 240 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ● |
| As of 09/2006 | MayBach | 240 | Drive | ME 2.7.2-Motor electronics 2.7.2 | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| As of 09/2006 | MayBach | 240 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ○ | ● |
| As of 09/2006 | MayBach | 240 | Drive | ME 2.7.2-Motor electronics 2.7.2 | ● | ● | ● | ● | ● | ● |
| As of 09/2006 | MayBach | 240 | Chassis | SBC-Sensotronic Brake Control | ● | ● | ● | ● | ● | ○ |
| As of 09/2006 | MayBach | 240 | Chassis | SBC-Right Sensotronic Brake Control | ● | ● | ● | ● | ● | ○ |
| As of 09/2006 | MayBach | 240 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| As of 09/2006 | MayBach | 240 | Chassis | AIRmatic | ● | ● | ● | ● | ● | ○ |
| As of 09/2006 | MayBach | 240 | Chassis | TPC-Tire pressure monitor | ● | ● | ● | ● | ● | ● |
| As of 09/2006 | MayBach | 240 | Body | CGW-Central gateway | ● | ● | ● | ● | ● | ○ |
| As of 09/2006 | MayBach | 240 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ● |
| As of 09/2006 | MayBach | 240 | Body | AB-Airbag | ● | ● | ● | ● | ● | ● |
| As of 09/2006 | MayBach | 240 | Body | WSS-Weight sensing system | ● | ● | ● | ● | ● | ○ |
| As of 09/2006 | MayBach | 240 | Body | BNS-Vehicle power supply control module | ● | ● | ● | ● | ● | ○ |
| As of 09/2006 | MayBach | 240 | Body | Dr-side SAM-Driver signal acquisition and actuation module | ● | ● | ● | ● | ● | ○ |
| As of 09/2006 | MayBach | 240 | Body | Pass-side SAM-Passenger-side signal acquisition and actuation module | ● | ● | ● | ● | ● | ○ |
| As of 09/2006 | MayBach | 240 | Body | Rear SAM 1-Rear signal acquisition and actuation | ● | ● | ● | ● | ● | ○ |
| As of 09/2006 | MayBach | 240 | Body | Rear SAM 2-Rear signal acquisition and actuation | ● | ● | ● | ● | ● | ○ |
| As of 09/2006 | MayBach | 240 | Body | MSS-Special vehicle multifunction control module | ● | ● | ● | ● | ● | ○ |
| As of 09/2006 | MayBach | 240 | Body | VBF (Front control panel)-Front control panel | ● | ● | ● | ● | ● | ○ |
| As of 09/2006 | MayBach | 240 | Body | HBF (Rear control panel)-Rear control field | ● | ● | ● | ● | ● | ○ |
| As of 09/2006 | MayBach | 240 | Body | BCG-Remote control(Rear control field) | ● | ● | ● | ● | ● | ○ |
| As of 09/2006 | MayBach | 240 | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ○ |
| As of 09/2006 | MayBach | 240 | Body | CRN-Center roof node | ● | ● | ○ | ● | ● | ● |
| As of 09/2006 | MayBach | 240 | Body | PSE-Pneumatic system equipment | ● | ● | ● | ● | ● | ○ |
| As of 09/2006 | MayBach | 240 | Body | HRA-Automatic headlamp range adjustment and headlamp control | ● | ● | ● | ● | ● | ○ |
| As of 09/2006 | MayBach | 240 | Body | System diagnosis(CAN) | ● | ● | ● | ● | ● | ● |
| As of 09/2006 | MayBach | 240 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ● |
| As of 09/2006 | MayBach | 240 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ● |
| As of 09/2006 | MayBach | 240 | Information and communication | ICM-Instrument cluster | ● | ● | ● | ● | ● | ○ |
| As of 09/2006 | MayBach | 240 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| As of 09/2006 | MayBach | 240 | Information and communication | CTEL-Telecommunication for telematics services | ● | ● | ● | ● | ● | ● |
| As of 09/2006 | MayBach | 240 | Information and communication | Telephone adapter for portable CTEL-Telecommunication for telematics services | ● | ● | ● | ● | ● | ● |
| As of 09/2006 | MayBach | 240 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| As of 09/2006 | MayBach | 240 | Information and communication | COMAND or AUDIO | ● | ● | ○ | ● | ● | ● |
| As of 09/2006 | MayBach | 240 | Information and communication | NAVI-Navigation system | ● | ● | ○ | ● | ● | ● |
| As of 09/2006 | MayBach | 240 | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ● |
| As of 09/2006 | MayBach | 240 | Information and communication | TV-TV tuner | ● | ● | ○ | ● | ● | ● |
| As of 09/2006 | MayBach | 240 | Information and communication | TV-TV tuner(AGW) | ● | ● | ● | ● | ● | ● |
| As of 09/2006 | MayBach | 240 | Information and communication | SOUND-Bose sound system | ● | ● | ○ | ● | ● | ● |
| As of 09/2006 | MayBach | 240 | Information and communication | SDAR-Satellite radio | ● | ● | ○ | ● | ● | ● |
| As of 09/2006 | MayBach | 240 | Information and communication | CTEL-Mobile phone adapter with universal interface | ● | ● | ● | ● | ● | ● |
| As of 09/2006 | MayBach | 240 | Information and communication | AVC-Audio video controller | ● | ● | ○ | ● | ● | ● |
| As of 09/2006 | MayBach | 240 | Information and communication | TV-TV tuner(REAR) | ● | ● | ○ | ● | ● | ● |
| As of 09/2006 | MayBach | 240 | Information and communication | TV-TV tuner (rear) | ● | ● | ● | ● | ● | ● |
| As of 09/2006 | MayBach | 240 | Information and communication | CDC-CD changer(REAR) | ● | ● | ○ | ● | ● | ● |
| As of 09/2006 | MayBach | 240 | Information and communication | KTL-Left headphone transmitter | ● | ● | ○ | ● | ● | ○ |
| As of 09/2006 | MayBach | 240 | Information and communication | KTR-Right headphone transmitter | ● | ● | ○ | ● | ● | ○ |
| As of 09/2006 | MayBach | 240 | Information and communication | GPS box | ● | ● | ○ | ● | ● | ● |
| As of 09/2006 | MayBach | 240 | Information and communication | TELE AID-Control unit | ● | ● | ● | ● | ● | ● |
| As of 09/2006 | MayBach | 240 | Information and communication | TELE AID-Telematic services Emergency call | ● | ● | ● | ● | | ● |
| As of 09/2006 | MayBach | 240 | Information and communication | TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE) | ● | ● | ● | ● | | ● |
| As of 09/2006 | MayBach | 240 | Information and communication | TELE AID-Telematic services Stolen vehicle tracking | ● | ● | ● | ● | | ● |
| As of 09/2006 | MayBach | 240 | Information and communication | TELE AID-Telematic services Remote door unlocking,Remote door locking | ● | ● | ● | ● | | ● |
| As of 09/2006 | MayBach | 240 | Seats and doors | ESA-FL-Electric seat adjustment front left | ● | ● | ● | ● | ● | ○ |
| As of 09/2006 | MayBach | 240 | Seats and doors | ESA-FR-Electric seat adjustment front right | ● | ● | ● | ● | ● | ○ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------|---------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| As of 09/2006 | MayBach | 240 | Seats and doors | ESA-LR-Left rear electrical seat adjustment | ● | ● | ● | ● | ● | ○ |
| As of 09/2006 | MayBach | 240 | Seats and doors | ESA-RR-Right rear electrical seat adjustment | ● | ● | ○ | ● | ● | ● |
| As of 09/2006 | MayBach | 240 | Seats and doors | OSB-FL-Multicontour backrest front left | ● | ● | ● | ● | ● | ○ |
| As of 09/2006 | MayBach | 240 | Seats and doors | OSB-FR-Multicontour backrest front right | ● | ● | ○ | ● | ● | ○ |
| As of 09/2006 | MayBach | 240 | Seats and doors | MKL-HL-Rear left multicontour backrest | ● | ● | ● | ● | ● | ○ |
| As of 09/2006 | MayBach | 240 | Seats and doors | MKL-HR-Rear right multicontour backrest | ● | ● | ● | ● | ● | ○ |
| As of 09/2006 | MayBach | 240 | Seats and doors | DCM-FL-Door control module front left | ● | ● | ● | ● | ● | ○ |
| As of 09/2006 | MayBach | 240 | Seats and doors | DCM-FR-Door control module front right | ● | ● | ● | ● | ● | ○ |
| As of 09/2006 | MayBach | 240 | Seats and doors | DCM-RL-Door control module rear left | ● | ● | ● | ● | ● | ○ |
| As of 09/2006 | MayBach | 240 | Seats and doors | DCM-RR-Door control module rear right | ● | ● | ● | ● | ● | ○ |
| As of 09/2006 | MayBach | 240 | Seats and doors | PWC-Partition wall control module | ● | ● | ● | ● | ● | ○ |
| As of 09/2006 | MayBach | 240 | Seats and doors | LDCA-Electric left door closing assist | ● | ● | ● | ● | ● | ● |
| As of 09/2006 | MayBach | 240 | Seats and doors | RDCA-Electric right door closing assist | ● | ● | ● | ● | ● | ● |
| As of 09/2006 | MayBach | 240 | Seats and doors | TLC-Trunk lid control | ● | ● | ● | ● | ● | ● |
| As of 09/2006 | MayBach | 240 | Air conditioning | AAC-Automatic air conditioning | ● | ● | ● | ● | ● | ○ |
| As of 09/2006 | MayBach | 240 | Air conditioning | REAR AC-Rear air conditioning | ● | ● | ● | ● | ● | ○ |
| As of 09/2006 | MayBach | 240 | Air conditioning | STH-Stationary heater | ● | ● | ● | ● | ● | ● |
| As of 09/2006 | MayBach | 240 | Air conditioning | HSW-Heated steering wheel | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | SL | 230 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | SL | 230 | Drive | SEQ-Sequentronic automated manual transmission | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | SL | 230 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | SL | 230 | Drive | ESM-Electronic selector module | ● | ● | ● | ● | ● | ※ |
| Up to 08/2003 | SL | 230 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | SL | 230 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | SL | 230 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ※ |
| Up to 08/2003 | SL | 230 | Chassis | SBC-Sensotronic Brake Control | ● | ● | ● | ● | ● | ○ |
| Up to 08/2003 | SL | 230 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | SL | 230 | Chassis | ABC-ABC active body control | ● | ● | ● | ● | ● | ※ |
| Up to 08/2003 | SL | 230 | Chassis | TPM - Tire pressure monitor (N88) | ● | ● | ● | ● | ● | ※ |
| Up to 08/2003 | SL | 230 | Body | System diagnosis (CAN) | ● | ● | ● | ● | ○ | ● |
| Up to 08/2003 | SL | 230 | Body | AB-Airbag | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | SL | 230 | Body | AB-Airbag | ● | ● | ○ | ● | ● | ※ |
| Up to 08/2003 | SL | 230 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ※ |
| Up to 08/2003 | SL | 230 | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ※ |
| Up to 08/2003 | SL | 230 | Body | LCP-Lower control panel | ● | ● | ● | ● | ● | ※ |
| Up to 08/2003 | SL | 230 | Body | Pass-side SAM-Passenger-side signal acquisition and actuation module | ● | ● | ● | ● | ● | ※ |
| Up to 08/2003 | SL | 230 | Body | Dr-side SAM-Driver signal acquisition and actuation module | ● | ● | ● | ● | ● | ※ |
| Up to 08/2003 | SL | 230 | Body | REAR SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ● | ※ |
| Up to 08/2003 | SL | 230 | Body | BNS-Vehicle power supply control module | ● | ● | ● | ● | ● | ※ |
| Up to 08/2003 | SL | 230 | Body | RVC-Rollover bar/vario roof control module | ● | ● | ● | ● | ● | ※ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|-------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| Up to 08/2003 | SL | 230 | Body | PSE-Pneumatic system equipment | ● | ● | ● | ● | ● | ※ |
| Up to 08/2003 | SL | 230 | Body | KG-Keyless Go | ● | ● | ● | ● | ● | ※ |
| Up to 08/2003 | SL | 230 | Body | HRA-FR-Front right headlamp range control | ● | ● | ● | ● | ● | ○ |
| Up to 08/2003 | SL | 230 | Body | HRA-FL-Front left headlamp range control | ● | ● | ● | ● | ● | ○ |
| Up to 08/2003 | SL | 230 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ※ |
| Up to 08/2003 | SL | 230 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ※ |
| Up to 08/2003 | SL | 230 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ○ |
| Up to 08/2003 | SL | 230 | Information and communication | TV-TV tuner | ● | ● | ● | ● | | ● |
| Up to 08/2003 | SL | 230 | Information and communication | E-call [Japan]-Telematic system | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | SL | 230 | Information and communication | E-call [USA]-Telematic system | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | SL | 230 | Information and communication | TELE AID-Telematic system | ● | ● | ● | ● | ● | |
| Up to 08/2003 | SL | 230 | Information and communication | CTEL over K-wire-Telematic system | ● | ● | ● | ● | ○ | ○ |
| Up to 08/2003 | SL | 230 | Information and communication | COMAND | ● | ● | ○ | ● | ● | ● |
| Up to 08/2003 | SL | 230 | Information and communication | D2B-COMAND, MCS or AUDIO | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | SL | 230 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| Up to 08/2003 | SL | 230 | Information and communication | CDC-CD changer | ● | ● | ● | ● | ○ | ○ |
| Up to 08/2003 | SL | 230 | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ○ |
| Up to 08/2003 | SL | 230 | Information and communication | SOUND- Sound system | ● | ● | ○ | ● | ● | ● |
| Up to 08/2003 | SL | 230 | Information and communication | SDAR-Satellite radio | ● | ● | ● | ● | ○ | ● |
| Up to 08/2003 | SL | 230 | Information and communication | CTEL- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ○ | ○ |
| Up to 08/2003 | SL | 230 | Information and communication | UHI- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ● | ○ |
| Up to 08/2003 | SL | 230 | Seats and doors | DCM-L-Door control module left | ● | ● | ● | ● | ● | ※ |
| Up to 08/2003 | SL | 230 | Seats and doors | DCM-R-Door control module right | ● | ● | ● | ● | ● | ※ |
| Up to 08/2003 | SL | 230 | Seats and doors | ESA-FL-Electric seat adjustment front left | ● | ● | ● | ● | ● | ※ |
| Up to 08/2003 | SL | 230 | Seats and doors | ESA-FR-Electric seat adjustment front right | ● | ● | ● | ● | ● | ※ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|-------------------------|-------|--------------|---------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| Up to 08/2003 | SL | 230 | Seats and doors | OSB-FL-Multicontour backrest front left | ● | ● | ● | ● | ● | ※ |
| Up to 08/2003 | SL | 230 | Seats and doors | OSB-FR-Multicontour backrest front right | ● | ● | ● | ● | ● | ※ |
| Up to 08/2003 | SL | 230 | Air conditioning | AAC-Automatic air conditioning | ● | ● | ● | ● | ● | ※ |
| Up to 08/2003 | SL | 230 | Air conditioning | STH-Stationary heater | ● | ● | ● | ● | ● | ※ |
| Up to 08/2003 | SL | 230 | Air conditioning | HSW-Heated steering wheel | ● | ● | ● | ● | ● | ※ |
| From 09/2003 to 05/2006 | SL | 230 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 05/2006 | SL | 230 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 05/2006 | SL | 230 | Drive | SEQ-Sequentronic automated manual transmission | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 05/2006 | SL | 230 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 05/2006 | SL | 230 | Drive | ESM-Electronic selector module | ● | ● | ● | ● | ● | ※ |
| From 09/2003 to 05/2006 | SL | 230 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 05/2006 | SL | 230 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 05/2006 | SL | 230 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 05/2006 | SL | 230 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ※ |
| From 09/2003 to 05/2006 | SL | 230 | Drive | ME 9.7-Motor electronics 9.7 | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 05/2006 | SL | 230 | Drive | ME-SFI 2.7.1-Motor electronics 2.7.1 | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 05/2006 | SL | 230 | Drive | ME 2.7.2-Motor electronics 2.7.2 | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 05/2006 | SL | 230 | Chassis | SBC-Sensotronic Brake Control | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 05/2006 | SL | 230 | Chassis | SBC-Sensotronic Brake Control | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 05/2006 | SL | 230 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 05/2006 | SL | 230 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 05/2006 | SL | 230 | Chassis | ABC-ABC active body control | ● | ● | ● | ● | ● | ※ |
| From 09/2003 to 05/2006 | SL | 230 | Chassis | ABC-ABC active body control | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|-------------------------|-------|--------------|---------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| From 09/2003 to 05/2006 | SL | 230 | Chassis | TPM - Tire pressure monitor (N88) | ● | ● | ● | ● | ● | ※ |
| From 09/2003 to 05/2006 | SL | 230 | Chassis | TPC-Tire pressure monitor | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 05/2006 | SL | 230 | Body | CGW-Central gateway | ● | ● | ● | ● | ○ | ○ |
| From 09/2003 to 05/2006 | SL | 230 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ※ |
| From 09/2003 to 05/2006 | SL | 230 | Body | System diagnosis (CAN) | ● | ● | ● | ● | ○ | ● |
| From 09/2003 to 05/2006 | SL | 230 | Body | AB-Airbag | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 05/2006 | SL | 230 | Body | WSS-Weight sensing system | ● | ● | ● | ● | ● | ○ |
| From 09/2003 to 05/2006 | SL | 230 | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ※ |
| From 09/2003 to 05/2006 | SL | 230 | Body | LCP-Lower control panel | ● | ● | ● | ● | ● | ※ |
| From 09/2003 to 05/2006 | SL | 230 | Body | Dr-side SAM-Driver signal acquisition and actuation module | ● | ● | ● | ● | ● | ※ |
| From 09/2003 to 05/2006 | SL | 230 | Body | Pass-side SAM-Passenger-side signal acquisition and actuation module | ● | ● | ● | ● | ● | ※ |
| From 09/2003 to 05/2006 | SL | 230 | Body | REAR SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ● | ※ |
| From 09/2003 to 05/2006 | SL | 230 | Body | BNS-Vehicle power supply control module | ● | ● | ● | ● | ● | ※ |
| From 09/2003 to 05/2006 | SL | 230 | Body | RVC-Rollover bar/vario roof control module | ● | ● | ● | ● | ● | ※ |
| From 09/2003 to 05/2006 | SL | 230 | Body | RVC-Rollover bar/vario roof control module | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 05/2006 | SL | 230 | Body | PSE-Pneumatic system equipment | ● | ● | ● | ● | ● | ※ |
| From 09/2003 to 05/2006 | SL | 230 | Body | KG-Keyless Go | ● | ● | ● | ● | ● | ※ |
| From 09/2003 to 05/2006 | SL | 230 | Body | KG-Keyless Go | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 05/2006 | SL | 230 | Body | HRA-FR-Front right headlamp range control | ● | ● | ● | ● | ● | ○ |
| From 09/2003 to 05/2006 | SL | 230 | Body | HRA-FL-Front left headlamp range control | ● | ● | ● | ● | ● | ○ |
| From 09/2003 to 05/2006 | SL | 230 | Body | System diagnosis (CAN) | ● | ● | ○ | ● | ※ | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|-------------------------|-------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| From 09/2003 to 05/2006 | SL | 230 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ※ |
| From 09/2003 to 05/2006 | SL | 230 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ※ |
| From 09/2003 to 05/2006 | SL | 230 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ○ |
| From 09/2003 to 05/2006 | SL | 230 | Information and communication | TV-TV tuner | ● | ● | ● | ● | | ● |
| From 09/2003 to 05/2006 | SL | 230 | Information and communication | E-call [Japan]-Telematic system | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 05/2006 | SL | 230 | Information and communication | E-call [USA]-Telematic system | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 05/2006 | SL | 230 | Information and communication | TELE AID-Telematic system | ● | ● | ● | ● | ● | |
| From 09/2003 to 05/2006 | SL | 230 | Information and communication | CTEL over K-wire-Telematic system | ● | ● | ● | ● | ○ | ○ |
| From 09/2003 to 05/2006 | SL | 230 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 05/2006 | SL | 230 | Information and communication | CTEL-Telecommunication for telematics services | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 05/2006 | SL | 230 | Information and communication | Telephone adapter for portable CTEL-Telecommunication for telematics services | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 05/2006 | SL | 230 | Information and communication | CTEL-Mobile phone adapter with universal interface | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 05/2006 | SL | 230 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 05/2006 | SL | 230 | Information and communication | NAVI-Navigation system | ● | ● | ○ | ● | ● | ● |
| From 09/2003 to 05/2006 | SL | 230 | Information and communication | CDC-CD changer | ● | ● | ○ | ● | ● | ● |
| From 09/2003 to 05/2006 | SL | 230 | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ● |
| From 09/2003 to 05/2006 | SL | 230 | Information and communication | SOUND-Bose sound system | ● | ● | ○ | ● | ● | ● |
| From 09/2003 to 05/2006 | SL | 230 | Information and communication | TV-TV tuner | ● | ● | ○ | ● | ● | ● |
| From 09/2003 to 05/2006 | SL | 230 | Information and communication | TV-TV tuner(AGW) | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 05/2006 | SL | 230 | Information and communication | SDAR-Satellite radio | ● | ● | ○ | ● | ● | ● |
| From 09/2003 to 05/2006 | SL | 230 | Information and communication | TELE AID-Control unit | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|-------------------------|-------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| From 09/2003 to 05/2006 | SL | 230 | Information and communication | TELE AID-Telematic services Emergency call | ● | ● | ● | ● | | ● |
| From 09/2003 to 05/2006 | SL | 230 | Information and communication | TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE) | ● | ● | ● | ● | | ● |
| From 09/2003 to 05/2006 | SL | 230 | Information and communication | TELE AID-Telematic services Stolen vehicle tracking | ● | ● | ● | ● | | ● |
| From 09/2003 to 05/2006 | SL | 230 | Information and communication | TELE AID-Telematic services Remote door unlocking,Remote door locking | ● | ● | ● | ● | | ● |
| From 09/2003 to 05/2006 | SL | 230 | Information and communication | COMAND | ● | ● | ○ | ● | ● | ● |
| From 09/2003 to 05/2006 | SL | 230 | Information and communication | D2B-COMAND, MCS or AUDIO | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 05/2006 | SL | 230 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| From 09/2003 to 05/2006 | SL | 230 | Information and communication | CDC-CD changer | ● | ● | ● | ● | ○ | ○ |
| From 09/2003 to 05/2006 | SL | 230 | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ○ |
| From 09/2003 to 05/2006 | SL | 230 | Information and communication | SOUND- Sound system | ● | ● | ○ | ● | ● | ● |
| From 09/2003 to 05/2006 | SL | 230 | Information and communication | SDAR-Satellite radio | ● | ● | ● | ● | ○ | ● |
| From 09/2003 to 05/2006 | SL | 230 | Information and communication | CTEL- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ○ | ○ |
| From 09/2003 to 05/2006 | SL | 230 | Information and communication | UHI- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ● | ○ |
| From 09/2003 to 05/2006 | SL | 230 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ○ |
| From 09/2003 to 05/2006 | SL | 230 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ○ |
| From 09/2003 to 05/2006 | SL | 230 | Seats and doors | DCM-L-Door control module left | ● | ● | ● | ● | ● | ※ |
| From 09/2003 to 05/2006 | SL | 230 | Seats and doors | DCM-R-Door control module right | ● | ● | ● | ● | ● | ※ |
| From 09/2003 to 05/2006 | SL | 230 | Seats and doors | ESA-FL-Electric seat adjustment front left | ● | ● | ● | ● | ● | ※ |
| From 09/2003 to 05/2006 | SL | 230 | Seats and doors | ESA-FR-Electric seat adjustment front right | ● | ● | ● | ● | ● | ※ |
| From 09/2003 to 05/2006 | SL | 230 | Seats and doors | OSB-FL-Multicontour backrest front left | ● | ● | ● | ● | ● | ※ |
| From 09/2003 to 05/2006 | SL | 230 | Seats and doors | OSB-FR-Multicontour backrest front right | ● | ● | ● | ● | ● | ※ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|-------------------------|-------|--------------|---------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| From 09/2003 to 05/2006 | SL | 230 | Air conditioning | AAC-Automatic air conditioning | ● | ● | ● | ● | ● | ※ |
| From 09/2003 to 05/2006 | SL | 230 | Air conditioning | STH-Stationary heater | ● | ● | ● | ● | ● | ※ |
| From 09/2003 to 05/2006 | SL | 230 | Air conditioning | HSW-Heated steering wheel | ● | ● | ● | ● | ● | ※ |
| From 06/2006 to 02/2008 | SL | 230 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| From 06/2006 to 02/2008 | SL | 230 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| From 06/2006 to 02/2008 | SL | 230 | Drive | SEQ-Sequentronic automated manual transmission | ● | ● | ● | ● | ● | ● |
| From 06/2006 to 02/2008 | SL | 230 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| From 06/2006 to 02/2008 | SL | 230 | Drive | ESM-Electronic selector module | ● | ● | ● | ● | ● | ※ |
| From 06/2006 to 02/2008 | SL | 230 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ● |
| From 06/2006 to 02/2008 | SL | 230 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| From 06/2006 to 02/2008 | SL | 230 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| From 06/2006 to 02/2008 | SL | 230 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ※ |
| From 06/2006 to 02/2008 | SL | 230 | Drive | ME 9.7-Motor electronics 9.7 | ● | ● | ● | ● | ● | ● |
| From 06/2006 to 02/2008 | SL | 230 | Drive | ME-SFI 2.7.1-Motor electronics 2.7.1 | ● | ● | ● | ● | ● | ● |
| From 06/2006 to 02/2008 | SL | 230 | Drive | ME 2.7.2-Motor electronics 2.7.2 | ● | ● | ● | ● | ● | ● |
| From 06/2006 to 02/2008 | SL | 230 | Drive | ME 2.7.2-Motor electronics 2.7.2 | ● | ● | ● | ● | ● | ● |
| From 06/2006 to 02/2008 | SL | 230 | Chassis | SBC-Sensotronic Brake Control | ● | ● | ● | ● | ● | ● |
| From 06/2006 to 02/2008 | SL | 230 | Chassis | SBC-Sensotronic Brake Control | ● | ● | ● | ● | ● | ● |
| From 06/2006 to 02/2008 | SL | 230 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| From 06/2006 to 02/2008 | SL | 230 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| From 06/2006 to 02/2008 | SL | 230 | Chassis | ABC-ABC active body control | ● | ● | ● | ● | ● | ※ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|-------------------------|-------|--------------|---------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| From 06/2006 to 02/2008 | SL | 230 | Chassis | ABC-ABC active body control | ● | ● | ● | ● | ● | ● |
| From 06/2006 to 02/2008 | SL | 230 | Chassis | TPM - Tire pressure monitor (N88) | ● | ● | ● | ● | ● | ※ |
| From 06/2006 to 02/2008 | SL | 230 | Chassis | TPC-Tire pressure monitor | ● | ● | ● | ● | ● | ● |
| From 06/2006 to 02/2008 | SL | 230 | Body | CGW-Central gateway | ● | ● | ● | ● | ○ | ○ |
| From 06/2006 to 02/2008 | SL | 230 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ※ |
| From 06/2006 to 02/2008 | SL | 230 | Body | System diagnosis (CAN) | ● | ● | ● | ● | ○ | ● |
| From 06/2006 to 02/2008 | SL | 230 | Body | AB-Airbag | ● | ● | ● | ● | ● | ● |
| From 06/2006 to 02/2008 | SL | 230 | Body | WSS-Weight sensing system | ● | ● | ● | ● | ● | ○ |
| From 06/2006 to 02/2008 | SL | 230 | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ※ |
| From 06/2006 to 02/2008 | SL | 230 | Body | LCP-Lower control panel | ● | ● | ● | ● | ● | ※ |
| From 06/2006 to 02/2008 | SL | 230 | Body | Dr-side SAM-Driver signal acquisition and actuation module | ● | ● | ● | ● | ● | ※ |
| From 06/2006 to 02/2008 | SL | 230 | Body | Pass-side SAM-Passenger-side signal acquisition and actuation module | ● | ● | ● | ● | ● | ※ |
| From 06/2006 to 02/2008 | SL | 230 | Body | REAR SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ● | ※ |
| From 06/2006 to 02/2008 | SL | 230 | Body | BNS-Vehicle power supply control module | ● | ● | ● | ● | ● | ※ |
| From 06/2006 to 02/2008 | SL | 230 | Body | RVC-Rollover bar/vario roof control module | ● | ● | ● | ● | ● | ※ |
| From 06/2006 to 02/2008 | SL | 230 | Body | RVC-Rollover bar/vario roof control module | ● | ● | ● | ● | ● | ● |
| From 06/2006 to 02/2008 | SL | 230 | Body | PSE-Pneumatic system equipment | ● | ● | ● | ● | ● | ※ |
| From 06/2006 to 02/2008 | SL | 230 | Body | KG-Keyless Go | ● | ● | ● | ● | ● | ※ |
| From 06/2006 to 02/2008 | SL | 230 | Body | KG-Keyless Go | ● | ● | ● | ● | ● | ● |
| From 06/2006 to 02/2008 | SL | 230 | Body | HRA-FR-Front right headlamp range control | ● | ● | ● | ● | ● | ○ |
| From 06/2006 to 02/2008 | SL | 230 | Body | HRA-FL-Front left headlamp range control | ● | ● | ● | ● | ● | ○ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|-------------------------|-------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| From 06/2006 to 02/2008 | SL | 230 | Body | System diagnosis(CAN) | ● | ● | ○ | ● | ※ | ● |
| From 06/2006 to 02/2008 | SL | 230 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ※ |
| From 06/2006 to 02/2008 | SL | 230 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ※ |
| From 06/2006 to 02/2008 | SL | 230 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ○ |
| From 06/2006 to 02/2008 | SL | 230 | Information and communication | TV-TV tuner | ● | ● | ● | ● | | ● |
| From 06/2006 to 02/2008 | SL | 230 | Information and communication | E-call [Japan]-Telematic system | ● | ● | ● | ● | ● | ● |
| From 06/2006 to 02/2008 | SL | 230 | Information and communication | E-call [USA]-Telematic system | ● | ● | ● | ● | ● | ● |
| From 06/2006 to 02/2008 | SL | 230 | Information and communication | TELE AID-Telematic system | ● | ● | ● | ● | ● | |
| From 06/2006 to 02/2008 | SL | 230 | Information and communication | CTEL over K-wire-Telematic system | ● | ● | ● | ● | ○ | ○ |
| From 06/2006 to 02/2008 | SL | 230 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| From 06/2006 to 02/2008 | SL | 230 | Information and communication | CTEL-Telecommunication for telematics services | ● | ● | ● | ● | ● | ● |
| From 06/2006 to 02/2008 | SL | 230 | Information and communication | Telephone adapter for portable CTEL-Telecommunication for telematics services | ● | ● | ● | ● | ● | ● |
| From 06/2006 to 02/2008 | SL | 230 | Information and communication | CTEL-Mobile phone adapter with universal interface | ● | ● | ● | ● | ● | ● |
| From 06/2006 to 02/2008 | SL | 230 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| From 06/2006 to 02/2008 | SL | 230 | Information and communication | NAVI-Navigation system | ● | ● | ○ | ● | ● | ● |
| From 06/2006 to 02/2008 | SL | 230 | Information and communication | CDC-CD changer | ● | ● | ○ | ● | ● | ● |
| From 06/2006 to 02/2008 | SL | 230 | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ● |
| From 06/2006 to 02/2008 | SL | 230 | Information and communication | SOUND-Bose sound system | ● | ● | ○ | ● | ● | ● |
| From 06/2006 to 02/2008 | SL | 230 | Information and communication | TV-TV tuner | ● | ● | ○ | ● | ● | ● |
| From 06/2006 to 02/2008 | SL | 230 | Information and communication | TV-TV tuner(AGW) | ● | ● | ● | ● | ● | ● |
| From 06/2006 to 02/2008 | SL | 230 | Information and communication | SDAR-Satellite radio | ● | ● | ○ | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|-------------------------|-------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| From 06/2006 to 02/2008 | SL | 230 | Information and communication | TELE AID-Control unit | ● | ● | ● | ● | ● | ● |
| From 06/2006 to 02/2008 | SL | 230 | Information and communication | TELE AID-Telematic services Emergency call | ● | ● | ● | ● | | ● |
| From 06/2006 to 02/2008 | SL | 230 | Information and communication | TELE AID-Telematic services MB Info,Roadside assistance (USA, Canada),Tele diagnosis (ECE) | ● | ● | ● | ● | | ● |
| From 06/2006 to 02/2008 | SL | 230 | Information and communication | TELE AID-Telematic services Stolen vehicle tracking | ● | ● | ● | ● | | ● |
| From 06/2006 to 02/2008 | SL | 230 | Information and communication | TELE AID-Telematic services Remote door unlocking,Remote door locking | ● | ● | ● | ● | | ● |
| From 06/2006 to 02/2008 | SL | 230 | Information and communication | COMAND | ● | ● | ○ | ● | ● | ● |
| From 06/2006 to 02/2008 | SL | 230 | Information and communication | D2B-COMAND, MCS or AUDIO | ● | ● | ● | ● | ● | ● |
| From 06/2006 to 02/2008 | SL | 230 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| From 06/2006 to 02/2008 | SL | 230 | Information and communication | CDC-CD changer | ● | ● | ● | ● | ○ | ○ |
| From 06/2006 to 02/2008 | SL | 230 | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ○ |
| From 06/2006 to 02/2008 | SL | 230 | Information and communication | SOUND- Sound system | ● | ● | ○ | ● | ● | ● |
| From 06/2006 to 02/2008 | SL | 230 | Information and communication | SDAR-Satellite radio | ● | ● | ● | ● | ○ | ● |
| From 06/2006 to 02/2008 | SL | 230 | Information and communication | CTEL- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ○ | ○ |
| From 06/2006 to 02/2008 | SL | 230 | Information and communication | UHI- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ● | ○ |
| From 06/2006 to 02/2008 | SL | 230 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ○ |
| From 06/2006 to 02/2008 | SL | 230 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ○ |
| From 06/2006 to 02/2008 | SL | 230 | Seats and doors | DCM-L-Door control module left | ● | ● | ● | ● | ● | ※ |
| From 06/2006 to 02/2008 | SL | 230 | Seats and doors | DCM-R-Door control module right | ● | ● | ● | ● | ● | ※ |
| From 06/2006 to 02/2008 | SL | 230 | Seats and doors | ESA-FL-Electric seat adjustment front left | ● | ● | ● | ● | ● | ※ |
| From 06/2006 to 02/2008 | SL | 230 | Seats and doors | ESA-FR-Electric seat adjustment front right | ● | ● | ● | ● | ● | ※ |
| From 06/2006 to 02/2008 | SL | 230 | Seats and doors | OSB-FL-Multicontour backrest front left | ● | ● | ● | ● | ● | ※ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|-------------------------|-------|--------------|---------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| From 06/2006 to 02/2008 | SL | 230 | Seats and doors | OSB-FR-Multicontour backrest front right | ● | ● | ● | ● | ● | ※ |
| From 06/2006 to 02/2008 | SL | 230 | Air conditioning | AAC-Automatic air conditioning | ● | ● | ● | ● | ● | ※ |
| From 06/2006 to 02/2008 | SL | 230 | Air conditioning | STH-Stationary heater | ● | ● | ● | ● | ● | ※ |
| From 06/2006 to 02/2008 | SL | 230 | Air conditioning | HSW-Heated steering wheel | ● | ● | ● | ● | ● | ※ |
| As of 03/2008 | SL | 230 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| As of 03/2008 | SL | 230 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| As of 03/2008 | SL | 230 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| As of 03/2008 | SL | 230 | Drive | ESM-Electronic selector module | ● | ● | ● | ● | ● | ※ |
| As of 03/2008 | SL | 230 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ● |
| As of 03/2008 | SL | 230 | Drive | ME 9.7-Motor electronics 9.7 | ● | ● | ● | ● | ● | ● |
| As of 03/2008 | SL | 230 | Drive | TV-TV tuner | ● | ● | ● | ● | ● | ● |
| As of 03/2008 | SL | 230 | Drive | ME 2.7.2-Motor electronics 2.7.2 | ● | ● | ● | ● | ● | ● |
| As of 03/2008 | SL | 230 | Drive | ME 9.7 (AMG)-Motor electronics 9.7 (AMG) | ● | ● | ● | ● | ● | ● |
| As of 03/2008 | SL | 230 | Drive | ME 2.7.2-Motor electronics 2.7.2 | ● | ● | ● | ● | ● | ● |
| As of 03/2008 | SL | 230 | Chassis | SBC-Sensotronic Brake Control | ● | ● | ● | ● | ● | ● |
| As of 03/2008 | SL | 230 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| As of 03/2008 | SL | 230 | Chassis | ABC-ABC active body control | ● | ● | ● | ● | ● | ● |
| As of 03/2008 | SL | 230 | Chassis | TPC-Tire pressure monitor | ● | ● | ● | ● | ● | ● |
| As of 03/2008 | SL | 230 | Body | CGW-Central gateway | ● | ● | ● | ● | ○ | ○ |
| As of 03/2008 | SL | 230 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ※ |
| As of 03/2008 | SL | 230 | Body | System diagnosis(CAN) | ● | ● | ● | ● | ○ | ● |
| As of 03/2008 | SL | 230 | Body | AB-Airbag | ● | ● | ● | ● | ● | ● |
| As of 03/2008 | SL | 230 | Body | WSS-Weight sensing system | ● | ● | ● | ● | ● | ○ |
| As of 03/2008 | SL | 230 | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ※ |
| As of 03/2008 | SL | 230 | Body | LCP-Lower control panel | ● | ● | ● | ● | ● | ※ |
| As of 03/2008 | SL | 230 | Body | Dr-side SAM-Driver signal acquisition and actuation module | ● | ● | ● | ● | ● | ※ |
| As of 03/2008 | SL | 230 | Body | Pass-side SAM-Passenger-side signal acquisition and actuation module | ● | ● | ● | ● | ● | ※ |
| As of 03/2008 | SL | 230 | Body | REAR SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ● | ※ |
| As of 03/2008 | SL | 230 | Body | BNS-Vehicle power supply control module | ● | ● | ● | ● | ● | ※ |
| As of 03/2008 | SL | 230 | Body | RVC-Rollover bar/vario roof control module | ● | ● | ● | ● | ● | ● |
| As of 03/2008 | SL | 230 | Body | PSE-Pneumatic system equipment | ● | ● | ● | ● | ● | ※ |
| As of 03/2008 | SL | 230 | Body | KG-Keyless Go | ● | ● | ● | ● | ● | ● |
| As of 03/2008 | SL | 230 | Body | XALWA-L-Xenon headlamp, left | ● | ● | ● | ● | ● | ● |
| As of 03/2008 | SL | 230 | Body | XALWA-R-Xenon headlamp, right | ● | ● | ● | ● | ● | ● |
| As of 03/2008 | SL | 230 | Body | System diagnosis(CAN) | ● | ● | ○ | ● | ※ | ● |
| As of 03/2008 | SL | 230 | Body | AMG DRVU-AMG DRIVE UNIT (N145) | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|-------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| As of 03/2008 | SL | 230 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ● |
| As of 03/2008 | SL | 230 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ※ |
| As of 03/2008 | SL | 230 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ○ |
| As of 03/2008 | SL | 230 | Information and communication | TV-TV tuner | ● | ● | ● | ● | | ● |
| As of 03/2008 | SL | 230 | Information and communication | E-call [Japan]-Telematic system | ● | ● | ● | ● | ● | ● |
| As of 03/2008 | SL | 230 | Information and communication | E-call [USA]-Telematic system | ● | ● | ● | ● | ● | ● |
| As of 03/2008 | SL | 230 | Information and communication | TELE AID-Telematic system | ● | ● | ● | ● | ● | |
| As of 03/2008 | SL | 230 | Information and communication | CTEL over K-wire-Telematic system | ● | ● | ● | ● | ○ | ○ |
| As of 03/2008 | SL | 230 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| As of 03/2008 | SL | 230 | Information and communication | CTEL-Telecommunication for telematics services | ● | ● | ● | ● | ● | ● |
| As of 03/2008 | SL | 230 | Information and communication | Telephone adapter for portable CTEL-Telecommunication for telematics services | ● | ● | ● | ● | ● | ● |
| As of 03/2008 | SL | 230 | Information and communication | CTEL-Mobile phone adapter with universal interface | ● | ● | ● | ● | ● | ● |
| As of 03/2008 | SL | 230 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| As of 03/2008 | SL | 230 | Information and communication | NAVI-Navigation system | ● | ● | ○ | ● | ● | ● |
| As of 03/2008 | SL | 230 | Information and communication | CDC-CD changer | ● | ● | ○ | ● | ● | ● |
| As of 03/2008 | SL | 230 | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ● |
| As of 03/2008 | SL | 230 | Information and communication | SOUND-Bose sound system | ● | ● | ○ | ● | ● | ● |
| As of 03/2008 | SL | 230 | Information and communication | TV-TV tuner | ● | ● | ○ | ● | ● | ● |
| As of 03/2008 | SL | 230 | Information and communication | TV-TV tuner(AGW) | ● | ● | ● | ● | ● | ● |
| As of 03/2008 | SL | 230 | Information and communication | SDAR-Satellite radio | ● | ● | ○ | ● | ● | ● |
| As of 03/2008 | SL | 230 | Information and communication | COMAND or AUDIO | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|-------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| As of 03/2008 | SL | 230 | Information and communication | Sound system (Main amplifier) | ● | ● | ● | ● | ● | ● |
| As of 03/2008 | SL | 230 | Information and communication | UCI-Media interface | ● | ● | ● | ● | ● | ● |
| As of 03/2008 | SL | 230 | Information and communication | DAB-Digital radio | ● | ● | ● | ● | ● | ○ |
| As of 03/2008 | SL | 230 | Information and communication | SDAR-Satellite radio(Valid for USA) | ● | ● | ● | ● | ● | ● |
| As of 03/2008 | SL | 230 | Information and communication | TV-TV tuner | ● | ● | ● | ● | ● | ● |
| As of 03/2008 | SL | 230 | Information and communication | CTEL-Cellular telephone(JAPAN) | ● | ● | ● | ● | ● | ○ |
| As of 03/2008 | SL | 230 | Information and communication | TELE AID-Control unit | ● | ● | ● | ● | ● | ● |
| As of 03/2008 | SL | 230 | Information and communication | TELE AID-Telematic services Emergency call | ● | ● | ● | ● | | ● |
| As of 03/2008 | SL | 230 | Information and communication | TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE) | ● | ● | ● | ● | | ● |
| As of 03/2008 | SL | 230 | Information and communication | TELE AID-Telematic services Stolen vehicle tracking | ● | ● | ● | ● | | ● |
| As of 03/2008 | SL | 230 | Information and communication | TELE AID-Telematic services Remote door unlocking,Remote door locking | ● | ● | ● | ● | | ● |
| As of 03/2008 | SL | 230 | Seats and doors | DCM-L-Door control module left | ● | ● | ● | ● | ● | ※ |
| As of 03/2008 | SL | 230 | Seats and doors | DCM-R-Door control module right | ● | ● | ● | ● | ● | ※ |
| As of 03/2008 | SL | 230 | Seats and doors | ESA-FL-Electric seat adjustment front left | ● | ● | ● | ● | ● | ※ |
| As of 03/2008 | SL | 230 | Seats and doors | ESA-FR-Electric seat adjustment front right | ● | ● | ● | ● | ● | ※ |
| As of 03/2008 | SL | 230 | Seats and doors | OSB-FL-Multicontour backrest front left | ● | ● | ● | ● | ● | ※ |
| As of 03/2008 | SL | 230 | Seats and doors | OSB-FR-Multicontour backrest front right | ● | ● | ● | ● | ● | ※ |
| As of 03/2008 | SL | 230 | Seats and doors | AIRSCARF | ● | ● | ● | ● | ● | ● |
| As of 03/2008 | SL | 230 | Air conditioning | AAC-Automatic air conditioning | ● | ● | ● | ● | ● | ※ |
| As of 03/2008 | SL | 230 | Air conditioning | STH-Stationary heater | ● | ● | ● | ● | ● | ※ |
| As of 03/2008 | SL | 230 | Air conditioning | HSW-Heated steering wheel | ● | ● | ● | ● | ● | ※ |
| As of 09/99 | SL | 129 | Drive | ETC-Electronic transmission control | ● | ● | ○ | ● | | ※ |
| As of 09/99 | SL | 129 | Drive | ME2-SFI-Motor electronics 2 | ● | ● | ○ | ● | ● | ※ |
| As of 09/99 | SL | 129 | Drive | ME1-SFI-Motor electronics | ● | ● | ○ | ● | | ※ |
| As of 09/99 | SL | 129 | Chassis | ASR-Acceleration Slip Regulation | ● | ● | ○ | ● | ● | ※ |
| As of 09/99 | SL | 129 | Chassis | ESP-Electronic stability program | ● | ● | ○ | ● | ● | ※ |
| As of 09/99 | SL | 129 | Chassis | ASR-Acceleration Slip Regulation | ● | ● | ○ | ● | ● | ※ |
| As of 09/99 | SL | 129 | Chassis | ESP-Electronic stability program | ● | ● | ○ | ● | ● | ※ |
| As of 09/99 | SL | 129 | Chassis | ETS-Electronic traction system | ● | ● | ○ | ● | ● | ※ |
| As of 09/99 | SL | 129 | Chassis | ESP-Electronic stability program | ● | ● | ○ | ● | ● | ※ |
| As of 09/99 | SL | 129 | Chassis | BAS-Brake assist | ● | ● | ○ | ● | ● | ※ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|-------------|-------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| As of 09/99 | SL | 129 | Body | AB-Airbag | ● | ● | ○ | ● | | ※ |
| As of 09/99 | SL | 129 | Body | HRA-Headlamp range adjustment | ● | ● | ○ | ● | | ※ |
| As of 09/99 | SL | 129 | Body | RFL-Radio frequency locking/electric central locking | ● | ● | ○ | ● | ● | ※ |
| As of 09/99 | SL | 129 | Body | APS-Auto pilot system | ● | ● | ○ | ● | ● | ※ |
| As of 09/99 | SL | 129 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ○ | ● | ● | ※ |
| As of 09/99 | SL | 129 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ● |
| As of 09/99 | SL | 129 | Information and communication | E-call [Japan]-Emergency call system | ● | ● | ○ | ● | ● | ● |
| As of 09/99 | SL | 129 | Information and communication | E-call [USA]-Emergency call system | ● | ● | ● | ● | ○ | ○ |
| As of 09/99 | SL | 129 | Information and communication | TELE AID-Emergency call system | ● | ● | ● | ● | ● | ● |
| As of 09/99 | SL | 129 | Information and communication | E-call [USA]-Telematic system | ● | ● | ● | ● | ● | ● |
| As of 09/99 | SL | 129 | Information and communication | CTEL over K-wire-Telematic system | ● | ● | ● | ● | ○ | ○ |
| As of 09/99 | SL | 129 | Information and communication | DN-Dynamic navigation by means of CTEL | ● | ● | ● | ● | ● | ○ |
| As of 09/99 | SL | 129 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| As of 09/99 | SL | 129 | Information and communication | CDC-CD changer | ● | ● | ● | ● | ○ | ○ |
| As of 09/99 | SL | 129 | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ○ |
| As of 09/99 | SL | 129 | Information and communication | CTEL- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ○ | ○ |
| As of 09/99 | SL | 129 | Information and communication | UHI- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ● | ○ |
| As of 09/99 | SL | 129 | Air conditioning | AAC-Automatic air conditioning | ● | ● | ○ | ● | | ※ |
| As of 09/99 | SL | 129 | Air conditioning | STH-Stationary heater | ● | ● | ○ | ● | ● | ※ |
| ALL | SLR | 199 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| ALL | SLR | 199 | Drive | ESM-Electronic selector module | ● | ● | ● | ● | ● | ※ |
| ALL | SLR | 199 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| ALL | SLR | 199 | Chassis | SBC-Sensotronic Brake Control | ● | ● | ● | ● | ● | ○ |
| ALL | SLR | 199 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| ALL | SLR | 199 | Chassis | TPM - Tire pressure monitor (N88) | ● | ● | ● | ● | ● | ※ |
| ALL | SLR | 199 | Chassis | TPC-Tire pressure monitor | ● | ● | ● | ● | ● | ● |
| ALL | SLR | 199 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ※ |
| ALL | SLR | 199 | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ※ |
| ALL | SLR | 199 | Body | LCP-Lower control panel | ● | ● | ● | ● | ● | ※ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|-------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | SLR | 199 | Body | Dr-side SAM-Driver signal acquisition and actuation module | ● | ● | ● | ● | ● | ※ |
| ALL | SLR | 199 | Body | Pass-side SAM-Passenger-side signal acquisition and actuation module | ● | ● | ● | ● | ● | ※ |
| ALL | SLR | 199 | Body | REAR SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ● | ※ |
| ALL | SLR | 199 | Body | BNS-Vehicle power supply control module | ● | ● | ● | ● | ● | ※ |
| ALL | SLR | 199 | Body | HRA-FR-Front right headlamp range control | ● | ● | ● | ● | ● | ○ |
| ALL | SLR | 199 | Body | HRA-FL-Front left headlamp range control | ● | ● | ● | ● | ● | ○ |
| ALL | SLR | 199 | Body | RS-Roadster soft top | ● | ● | ● | ● | ● | ● |
| ALL | SLR | 199 | Body | CGW-Central gateway | ● | ● | ● | ● | ○ | ○ |
| ALL | SLR | 199 | Body | AB-Airbag | ● | ● | ● | ● | ● | ● |
| ALL | SLR | 199 | Body | WSS-Weight sensing system | ● | ● | ● | ● | ● | ○ |
| ALL | SLR | 199 | Body | ACL [ZLB]-Air brake (spoiler) and central locking control unit | ● | ● | ● | ● | ● | ● |
| ALL | SLR | 199 | Body | BKGS-Brake cooling and gearshift | ● | ● | ● | ● | ● | ● |
| ALL | SLR | 199 | Body | System diagnosis (CAN) | ● | ● | ● | ● | ● | ● |
| ALL | SLR | 199 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ※ |
| ALL | SLR | 199 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ○ |
| ALL | SLR | 199 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| ALL | SLR | 199 | Information and communication | CDC-CD changer | ● | ● | ● | ● | ○ | ○ |
| ALL | SLR | 199 | Information and communication | SOUND- Sound system | ● | ● | ○ | ● | ● | ● |
| ALL | SLR | 199 | Information and communication | CTEL- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ○ | ○ |
| ALL | SLR | 199 | Information and communication | UHI- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ● | ○ |
| ALL | SLR | 199 | Information and communication | E-call [Japan]-Telematic system | ● | ● | ● | ● | ● | ● |
| ALL | SLR | 199 | Information and communication | E-call [USA]-Telematic system | ● | ● | ● | ● | ● | ● |
| ALL | SLR | 199 | Information and communication | TELE AID-Telematic system | ● | ● | ● | ● | ● | |
| ALL | SLR | 199 | Information and communication | CTEL over K-wire-Telematic system | ● | ● | ● | ● | ○ | ○ |
| ALL | SLR | 199 | Seats and doors | DCM-L-Door control module left | ● | ● | ● | ● | ● | ※ |
| ALL | SLR | 199 | Seats and doors | DCM-R-Door control module right | ● | ● | ● | ● | ● | ※ |
| ALL | SLR | 199 | Air conditioning | AAC-Automatic air conditioning | ● | ● | ● | ● | ● | ※ |
| Up to 05/2005 | SLK | 171 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|-------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| Up to 05/2005 | SLK | 171 | Drive | SEQ-Sequentronic automated manual transmission | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | SLK | 171 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | SLK | 171 | Drive | ESM-Electronic selector module | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | SLK | 171 | Drive | ME-SFI-Motor electronics | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | SLK | 171 | Drive | ME-SFI-Motor electronics | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | SLK | 171 | Drive | TV-TV tuner | ● | ● | ● | ● | ● | |
| Up to 05/2005 | SLK | 171 | Drive | ME 9.7-Motor electronics 9.7 | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | SLK | 171 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | SLK | 171 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | SLK | 171 | Body | CGW-Central gateway | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | SLK | 171 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | SLK | 171 | Body | System diagnosis (CAN) | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | SLK | 171 | Body | AB-Airbag | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | SLK | 171 | Body | VR-Vario roof | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | SLK | 171 | Body | UCP-Upper control panel | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | SLK | 171 | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | SLK | 171 | Body | SAM-F-Signal acquisition and actuation module front | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | SLK | 171 | Body | REAR SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | SLK | 171 | Body | HRA-Automatic headlamp range adjustment and headlamp control | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | SLK | 171 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | SLK | 171 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | SLK | 171 | Information and communication | IC-Instrument cluster | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | SLK | 171 | Information and communication | ASSYST-Active Service System | ● | ● | ○ | ● | ● | ○ |
| Up to 05/2005 | SLK | 171 | Information and communication | ASSYST PLUS-PLUS Active Service System | ● | ● | ○ | ● | ● | ● |
| Up to 05/2005 | SLK | 171 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | SLK | 171 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | SLK | 171 | Information and communication | CTEL-Mobile phone adapter with universal interface | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | SLK | 171 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | SLK | 171 | Information and communication | COMAND or AUDIO | ● | ● | ○ | ● | ● | ● |
| Up to 05/2005 | SLK | 171 | Information and communication | NAVI-Navigation system | ● | ● | ○ | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|-------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| Up to 05/2005 | SLK | 171 | Information and communication | CDC-CD changer | ● | ● | ○ | ● | ● | ● |
| Up to 05/2005 | SLK | 171 | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ● |
| Up to 05/2005 | SLK | 171 | Information and communication | SDAR-Satellite radio | ● | ● | ○ | ● | ● | ● |
| Up to 05/2005 | SLK | 171 | Information and communication | COMAND or AUDIO | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | SLK | 171 | Information and communication | Sound system (Main amplifier) | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | SLK | 171 | Information and communication | UCI-Media interface | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | SLK | 171 | Information and communication | DAB-Digital radio | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | SLK | 171 | Information and communication | SDAR-Satellite radio(Valid for USA) | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | SLK | 171 | Information and communication | TV-TV tuner | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | SLK | 171 | Information and communication | CTEL-Cellular telephone(JAPAN) | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | SLK | 171 | Information and communication | GPS box | ● | ● | ○ | ● | ● | ● |
| Up to 05/2005 | SLK | 171 | Information and communication | TELE AID-Control unit | ● | ● | ● | ● | ● | ● |
| Up to 05/2005 | SLK | 171 | Information and communication | TELE AID-Telematic services Emergency call | ● | ● | ● | ● | | ● |
| Up to 05/2005 | SLK | 171 | Information and communication | TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE) | ● | ● | ● | ● | | ● |
| Up to 05/2005 | SLK | 171 | Information and communication | TELE AID-Telematic services Stolen vehicle tracking | ● | ● | ● | ● | | ● |
| Up to 05/2005 | SLK | 171 | Information and communication | TELE AID-Telematic services Remote door unlocking, Remote door locking | ● | ● | ● | ● | | ● |
| Up to 05/2005 | SLK | 171 | Seats and doors | DCM-L-Door control module left | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | SLK | 171 | Seats and doors | DCM-R-Door control module right | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | SLK | 171 | Seats and doors | ESA driver-Electric seat adjustment driver (with | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | SLK | 171 | Seats and doors | ESA passenger-Electric seat adjustment passenger | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | SLK | 171 | Seats and doors | HS-Seat heater | ● | ● | ● | ● | ● | ○ |
| Up to 05/2005 | SLK | 171 | Air conditioning | C-AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater | ● | ● | ● | ● | ● | ○ |
| As of 06/2005 | SLK | 171 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| As of 06/2005 | SLK | 171 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| As of 06/2005 | SLK | 171 | Drive | SEQ-Sequentronic automated manual transmission | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|-------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| As of 06/2005 | SLK | 171 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| As of 06/2005 | SLK | 171 | Drive | ESM-Electronic selector module | ● | ● | ● | ● | ● | ○ |
| As of 06/2005 | SLK | 171 | Drive | ME-SFI-Motor electronics | ● | ● | ● | ● | ● | ● |
| As of 06/2005 | SLK | 171 | Drive | ME-SFI-Motor electronics | ● | ● | ● | ● | ● | ● |
| As of 06/2005 | SLK | 171 | Drive | TV-TV tuner | ● | ● | ● | ● | ● | |
| As of 06/2005 | SLK | 171 | Drive | ME 9.7-Motor electronics 9.7 | ● | ● | ● | ● | ● | ● |
| As of 06/2005 | SLK | 171 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| As of 06/2005 | SLK | 171 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| As of 06/2005 | SLK | 171 | Chassis | TPC-Tire pressure monitor | ● | ● | ● | ● | ● | ● |
| As of 06/2005 | SLK | 171 | Body | CGW-Central gateway | ● | ● | ● | ● | ● | ○ |
| As of 06/2005 | SLK | 171 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ○ |
| As of 06/2005 | SLK | 171 | Body | System diagnosis (CAN) | ● | ● | ● | ● | ● | ● |
| As of 06/2005 | SLK | 171 | Body | AB-Airbag | ● | ● | ● | ● | ● | ● |
| As of 06/2005 | SLK | 171 | Body | WSS-Weight sensing system | ● | ● | ● | ● | ● | ○ |
| As of 06/2005 | SLK | 171 | Body | VR-Vario roof | ● | ● | ● | ● | ● | ○ |
| As of 06/2005 | SLK | 171 | Body | UCP-Upper control panel | ● | ● | ● | ● | ● | ○ |
| As of 06/2005 | SLK | 171 | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ○ |
| As of 06/2005 | SLK | 171 | Body | SAM-F-Signal acquisition and actuation module front | ● | ● | ● | ● | ● | ○ |
| As of 06/2005 | SLK | 171 | Body | REAR SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ● | ○ |
| As of 06/2005 | SLK | 171 | Body | HRA-Automatic headlamp range adjustment and headlamp control | ● | ● | ● | ● | ● | ○ |
| As of 06/2005 | SLK | 171 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ● |
| As of 06/2005 | SLK | 171 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ○ |
| As of 06/2005 | SLK | 171 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ● |
| As of 06/2005 | SLK | 171 | Information and communication | IC-Instrument cluster | ● | ● | ● | ● | ● | ○ |
| As of 06/2005 | SLK | 171 | Information and communication | ASSYST-Active Service System | ● | ● | ○ | ● | ● | ○ |
| As of 06/2005 | SLK | 171 | Information and communication | ASSYST PLUS-PLUS Active Service System | ● | ● | ○ | ● | ● | ● |
| As of 06/2005 | SLK | 171 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| As of 06/2005 | SLK | 171 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| As of 06/2005 | SLK | 171 | Information and communication | CTEL-Mobile phone adapter with universal interface | ● | ● | ● | ● | ● | ● |
| As of 06/2005 | SLK | 171 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|-------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| As of 06/2005 | SLK | 171 | Information and communication | COMAND or AUDIO | ● | ● | ○ | ● | ● | ● |
| As of 06/2005 | SLK | 171 | Information and communication | NAVI-Navigation system | ● | ● | ○ | ● | ● | ● |
| As of 06/2005 | SLK | 171 | Information and communication | CDC-CD changer | ● | ● | ○ | ● | ● | ● |
| As of 06/2005 | SLK | 171 | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ● |
| As of 06/2005 | SLK | 171 | Information and communication | SDAR-Satellite radio | ● | ● | ○ | ● | ● | ● |
| As of 06/2005 | SLK | 171 | Information and communication | COMAND or AUDIO | ● | ● | ● | ● | ● | ● |
| As of 06/2005 | SLK | 171 | Information and communication | Sound system (Main amplifier) | ● | ● | ● | ● | ● | ● |
| As of 06/2005 | SLK | 171 | Information and communication | UCI-Media interface | ● | ● | ● | ● | ● | ● |
| As of 06/2005 | SLK | 171 | Information and communication | DAB-Digital radio | ● | ● | ● | ● | ● | ○ |
| As of 06/2005 | SLK | 171 | Information and communication | SDAR-Satellite radio(Valid for USA) | ● | ● | ● | ● | ● | ● |
| As of 06/2005 | SLK | 171 | Information and communication | TV-TV tuner | ● | ● | ● | ● | ● | ● |
| As of 06/2005 | SLK | 171 | Information and communication | CTEL-Cellular telephone(JAPAN) | ● | ● | ● | ● | ● | ○ |
| As of 06/2005 | SLK | 171 | Information and communication | GPS box | ● | ● | ○ | ● | ● | ● |
| As of 06/2005 | SLK | 171 | Information and communication | TELE AID-Control unit | ● | ● | ● | ● | ● | ● |
| As of 06/2005 | SLK | 171 | Information and communication | TELE AID-Telematic services Emergency call | ● | ● | ● | ● | | ● |
| As of 06/2005 | SLK | 171 | Information and communication | TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE) | ● | ● | ● | ● | | ● |
| As of 06/2005 | SLK | 171 | Information and communication | TELE AID-Telematic services Stolen vehicle tracking | ● | ● | ● | ● | | ● |
| As of 06/2005 | SLK | 171 | Information and communication | TELE AID-Telematic services Remote door unlocking, Remote door locking | ● | ● | ● | ● | | ● |
| As of 06/2005 | SLK | 171 | Seats and doors | DCM-L-Door control module left | ● | ● | ● | ● | ● | ○ |
| As of 06/2005 | SLK | 171 | Seats and doors | DCM-R-Door control module right | ● | ● | ● | ● | ● | ○ |
| As of 06/2005 | SLK | 171 | Seats and doors | ESA driver-Electric seat adjustment driver (with | ● | ● | ● | ● | ● | ○ |
| As of 06/2005 | SLK | 171 | Seats and doors | ESA passenger-Electric seat adjustment passenger | ● | ● | ● | ● | ● | ○ |
| As of 06/2005 | SLK | 171 | Seats and doors | HS-Seat heater | ● | ● | ● | ● | ● | ○ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|-------|-------------------------------|---------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| As of 06/2005 | SLK | 171 | Air conditioning | C-AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater | ● | ● | ● | ● | ● | ○ |
| ALL | SLK | 170(16-pin diagnostic socket) | Drive | ETC-Electronic transmission control | ● | ● | ○ | ● | ● | ※ |
| ALL | SLK | 170(16-pin diagnostic socket) | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| ALL | SLK | 170(16-pin diagnostic socket) | Drive | ESM-Electronic selector module | ● | ● | ○ | ● | ● | ※ |
| ALL | SLK | 170(16-pin diagnostic socket) | Drive | ME-SFI-Motor electronics | ● | ● | ● | ● | ● | ● |
| ALL | SLK | 170(16-pin diagnostic socket) | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| ALL | SLK | 170(16-pin diagnostic socket) | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| ALL | SLK | 170(16-pin diagnostic socket) | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| ALL | SLK | 170(16-pin diagnostic socket) | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|-------|-------------------------------|---------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | SLK | 170(16-pin diagnostic socket) | Chassis | BAS-Brake assist | ● | ● | ○ | ● | ● | ● |
| ALL | SLK | 170(16-pin diagnostic socket) | Chassis | VP-Vacuum pump brake booster | ● | ● | ● | ● | ● | ● |
| ALL | SLK | 170(16-pin diagnostic socket) | Body | AB-Airbag | ● | ● | ○ | ● | | ※ |
| ALL | SLK | 170(16-pin diagnostic socket) | Body | RFL-Radio frequency locking/electric central locking | ● | ● | ○ | ● | ● | ※ |
| ALL | SLK | 170(16-pin diagnostic socket) | Body | PSE-Pneumatic system equipment | ● | ● | ○ | ● | ● | ※ |
| ALL | SLK | 170(16-pin diagnostic socket) | Body | CCM-Multifunction control module | ● | ● | ○ | ● | ● | ※ |
| ALL | SLK | 170(16-pin diagnostic socket) | Body | VR-Vario roof | ● | ● | ○ | ● | ● | ※ |
| ALL | SLK | 170(16-pin diagnostic socket) | Body | HRA-Headlamp range adjustment | ● | ● | ● | ● | ● | ※ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|-------|-------------------------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | SLK | 170(16-pin diagnostic socket) | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ○ | ● | ● | ※ |
| ALL | SLK | 170(16-pin diagnostic socket) | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| ALL | SLK | 170(16-pin diagnostic socket) | Information and communication | CTEL- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ○ | ○ |
| ALL | SLK | 170(16-pin diagnostic socket) | Information and communication | UHI- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ● | ○ |
| ALL | SLK | 170(16-pin diagnostic socket) | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ○ |
| ALL | SLK | 170(16-pin diagnostic socket) | Information and communication | CDC-CD changer | ● | ● | ● | ● | ○ | ○ |
| ALL | SLK | 170(16-pin diagnostic socket) | Information and communication | E-call [Japan]-Emergency call system | ● | ● | ○ | ● | ● | ● |
| ALL | SLK | 170(16-pin diagnostic socket) | Information and communication | E-call [USA]-Emergency call system | ● | ● | ● | ● | ○ | ○ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|-------|-------------------------------|-------------------------------|-------------------------------------|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | SLK | 170(16-pin diagnostic socket) | Information and communication | E-call [USA]-Telematic system | ● | ● | ● | ● | ● | ● |
| ALL | SLK | 170(16-pin diagnostic socket) | Information and communication | CTEL over K-wire-Telematic system | ● | ● | ● | ● | ○ | ○ |
| ALL | SLK | 170(16-pin diagnostic socket) | Air conditioning | TAC-Automatic temperature control | ● | ● | ○ | ● | | ※ |
| ALL | SLK | 170(16-pin diagnostic socket) | Air conditioning | AAC-Automatic air conditioning | ● | ● | ○ | ● | | ※ |
| ALL | SLK | 170(16-pin diagnostic socket) | Air conditioning | STH-Stationary heater | ● | ● | ○ | ● | ● | ※ |
| ALL | SLK | 170(38-pin diagnostic socket) | Drive | ETC-Electronic transmission control | ● | ● | ○ | ● | | ※ |
| ALL | SLK | 170(38-pin diagnostic socket) | Drive | ME2-SFI-Motor electronics 2 | ● | ● | ○ | ● | ● | ※ |
| ALL | SLK | 170(38-pin diagnostic socket) | Chassis | ABS-Antilock brake system | ● | ● | ○ | ● | ● | ※ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|-------|-------------------------------|---------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | SLK | 170(38-pin diagnostic socket) | Chassis | ASR-Acceleration Slip Regulation | ● | ● | ○ | ● | ● | ※ |
| ALL | SLK | 170(38-pin diagnostic socket) | Chassis | ETS-Electronic traction system | ● | ● | ○ | ● | ● | ※ |
| ALL | SLK | 170(38-pin diagnostic socket) | Chassis | BAS-Brake assist | ● | ● | ○ | ● | ● | ※ |
| ALL | SLK | 170(38-pin diagnostic socket) | Body | AB-Airbag | ● | ● | ○ | ● | | ※ |
| ALL | SLK | 170(38-pin diagnostic socket) | Body | RFL-Radio frequency locking/electric central locking | ● | ● | ○ | ● | ● | ※ |
| ALL | SLK | 170(38-pin diagnostic socket) | Body | PSE-Pneumatic system equipment | ● | ● | ○ | ● | ● | ※ |
| ALL | SLK | 170(38-pin diagnostic socket) | Body | CCM-Multifunction control module | ● | ● | ○ | ● | ● | ※ |
| ALL | SLK | 170(38-pin diagnostic socket) | Body | VR-Vario roof | ● | ● | ○ | ● | ● | ※ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|-------|--------------------------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | SLK | 170 (38-pin diagnostic socket) | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ○ | ● | ● | ※ |
| ALL | SLK | 170 (38-pin diagnostic socket) | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| ALL | SLK | 170 (38-pin diagnostic socket) | Information and communication | CTEL- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ○ | ○ |
| ALL | SLK | 170 (38-pin diagnostic socket) | Information and communication | UHI- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ● | ○ |
| ALL | SLK | 170 (38-pin diagnostic socket) | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ○ |
| ALL | SLK | 170 (38-pin diagnostic socket) | Information and communication | CDC-CD changer | ● | ● | ● | ● | ○ | ○ |
| ALL | SLK | 170 (38-pin diagnostic socket) | Air conditioning | TAC-Automatic temperature control | ● | ● | ○ | ● | | ※ |
| ALL | SLK | 170 (38-pin diagnostic socket) | Air conditioning | AAC-Automatic air conditioning | ● | ● | ○ | ● | | ※ |
| ALL | SLK | 172 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ● |
| ALL | SLK | 172 | Drive | MED 17.7-Motor electronics for direct injection 17.7 | ● | ● | ● | ● | ● | |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|-------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | SLK | 172 | Drive | ME-Motor electronics 'MED177AMG' for combustion engine 'M152' (N3/10) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLK | 172 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ● | ● |
| ALL | SLK | 172 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ● | ● |
| ALL | SLK | 172 | Drive | mbrace-mbrace (N123/4) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLK | 172 | Drive | ESM-Electronic selector module | ● | ● | ● | ● | ● | ● |
| ALL | SLK | 172 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ○ | ● |
| ALL | SLK | 172 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| ALL | SLK | 172 | Drive | CDI 3-Common Rail Diesel Injection3 | ● | ● | ● | ● | ● | |
| ALL | SLK | 172 | Chassis | ESP-Electronic stability program (N30/4) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLK | 172 | Chassis | AIRSCARF-AIRSCARF system (N25/7) | ● | ● | ● | ● | ● | ● |
| ALL | SLK | 172 | Chassis | EHPS-Electrohydraulic Power Steering | ● | ● | ● | ● | ● | |
| ALL | SLK | 172 | Chassis | EFB-Electronic parking break (N128) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLK | 172 | Chassis | TPM-Tire pressure monitor | ● | ● | ○ | ● | ○ | ● |
| ALL | SLK | 172 | Body | CGW[ZGW]-Central gateway (CGW[ZGW]) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLK | 172 | Body | CGW-Central gateway | ● | ● | ● | ● | ● | ● |
| ALL | SLK | 172 | Body | CGW-Central gateway | ● | ● | ● | ● | ▲ | ● |
| ALL | SLK | 172 | Body | EZS-Electronic ignition lock | ● | ● | ● | ● | ● | ● |
| ALL | SLK | 172 | Body | VDS-Vario roof control (N52) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLK | 172 | Body | SGR-Radar sensors control unit | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |
| ALL | SLK | 172 | Body | SG-SW-Control unit 'Headlamp' (N71/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLK | 172 | Body | KG-Keyless Go | ● | ● | ● | ● | ● | ● |
| ALL | SLK | 172 | Body | MSC-MAGIC SKY CONTROL (N53) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLK | 172 | Body | SRS-Supplemental restraint system (N2/10) | ● | ● | ● | ● | ▲ | ● |
| ALL | SLK | 172 | Body | RevETR-LF-Left front reversible emergency tensioning retractor (A76) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLK | 172 | Body | RevETR-RF-Right front reversible emergency tensioning retractor (A76/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLK | 172 | Body | Driver-side SAM-Driver signal acquisition and actuation module | ● | ● | ● | ● | ● | ● |
| ALL | SLK | 172 | Body | Dr-side SAM-Driver signal acquisition and actuation module | ● | ● | ● | ● | ● | ● |
| ALL | SLK | 172 | Body | Driver-side SAM-Driver signal acquisition and actuation module | ● | ● | ● | ● | ▲ | |
| ALL | SLK | 172 | Body | REAR SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ● | ● |
| ALL | SLK | 172 | Body | Rear SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ▲ | ▲ |
| ALL | SLK | 172 | Body | Rear SAM-Rear signal acquisition and actuation module | ● | ● | ○ | ● | ○ | ● |
| ALL | SLK | 172 | Body | SCM-Steering column module (N80) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLK | 172 | Body | SGR-Radar sensors control unit | ● | ● | ● | ● | ○ | ● |
| ALL | SLK | 172 | Information and communication | COU [ZBE]-Central operating unit | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|-------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | SLK | 172 | Information and communication | IC-Instrument cluster (A1) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLK | 172 | Information and communication | IC-Instrument cluster (A1) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLK | 172 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ● |
| ALL | SLK | 172 | Information and communication | DAB-Digital Audio Broadcasting (N87/3) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLK | 172 | Information and communication | DAB-Digital radio | ● | ● | ● | ● | ● | ● |
| ALL | SLK | 172 | Information and communication | ZAN-Central display | ● | ● | ● | ● | ● | ● |
| ALL | SLK | 172 | Information and communication | Audio-Audio or COMAND (A2-A40/3) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLK | 172 | Information and communication | MFK-Multifunction camera | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |
| ALL | SLK | 172 | Information and communication | NAV-Navigation module (A2/30) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLK | 172 | Information and communication | PTS-PARKTRONIC(N62) | ● | ● | ● | ● | ● | ● |
| ALL | SLK | 172 | Information and communication | SCCM-Steering column module(N80) | ● | ● | ● | ● | ● | ● |
| ALL | SLK | 172 | Information and communication | SDAR-Satellite radio(Valid for USA) | ● | ● | ● | ● | ● | ● |
| ALL | SLK | 172 | Information and communication | Sound system (Main amplifier) | ● | ● | ● | ● | ● | ● |
| ALL | SLK | 172 | Information and communication | TV-TV tuner(AGW) | ● | ● | ● | ● | ● | ● |
| ALL | SLK | 172 | Information and communication | UCI-Media interface | ● | ● | ● | ● | ● | ● |
| ALL | SLK | 172 | Information and communication | NAVI20 - Navigation(N125/2) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLK | 172 | Information and communication | TELE AID-Control unit | ● | ● | ● | ● | ● | ● |
| ALL | SLK | 172 | Information and communication | TELE AID-Telematic services Emergency call | ● | ● | ● | ● | | ● |
| ALL | SLK | 172 | Information and communication | TELE AID-Telematic services Remote door unlocking, Remote door locking | ● | ● | ● | ● | | ● |
| ALL | SLK | 172 | Information and communication | TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE) | ● | ● | ● | ● | | ● |
| ALL | SLK | 172 | Information and communication | TELE AID-Telematic services Stolen vehicle tracking | ● | ● | ● | ● | | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|-------|--------------|---------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | SLK | 172 | Seats and doors | DCU-LF-Left front door | ● | ● | ● | ● | ● | ● |
| ALL | SLK | 172 | Seats and doors | DCU-RF-Right front door | ● | ● | ● | ● | ● | ▲ |
| ALL | SLK | 172 | Seats and doors | ESA 'Driver' -Electric seat adjustment 'Driver' (N32/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLK | 172 | Seats and doors | ESA' Front passenger' -Electric seat adjustment 'Front passenger' with memory function(N32/2) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLK | 172 | Air conditioning | AAC-Air conditioning (N22/7) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLK | 172 | LIN Bus | AU-Analog clock (A70/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLK | 172 | LIN Bus | GTO-Garage door opener (A67n2) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLK | 172 | LIN Bus | OCP-Overhead control panel(N70) | ● | ● | ○ | ● | ○ | ● |
| ALL | GLK | X204 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Drive | ME 9.7-Motor electronics 9.7 | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Drive | ME 9.7 (AMG)-Motor electronics 9.7 (AMG) | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Drive | MED 17.7-Motor electronics for direct injection 17.7 | ● | ● | ● | ● | ● | |
| ALL | GLK | X204 | Drive | ME-Motor electronics 'MED40' for combustion engine 'M270' (N3/10) | ● | ● | ○ | ● | ○ | ● |
| ALL | GLK | X204 | Drive | MED 9.7-Motor electronics for direct injection 9.7 | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ○ | ● |
| ALL | GLK | X204 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Drive | FSCU Left-Control unit 'left fuel pump' | ● | ● | ● | ● | ○ | ● |
| ALL | GLK | X204 | Drive | FSCU Right-Control unit 'Right fuel pump' | ● | ● | ● | ● | ○ | ● |
| ALL | GLK | X204 | Drive | ME - Motor electronics 'SIM271DE20' for combustion engine 'M271EVO' (N3/10) | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Drive | ME-SFI-Motor electronics | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Drive | ESM-Electronic selector module | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Drive | PTCU-Common powertrain controller(N127) | ● | ● | ○ | ● | ○ | ● |
| ALL | GLK | X204 | Drive | ISM-Shift module (A80) | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |
| ALL | GLK | X204 | Drive | mbrace-mbrace (N123/4) | ● | ● | ○ | ● | ○ | ● |
| ALL | GLK | X204 | Drive | SCR-Selective Catalytic Reduction | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ○ | ● |
| ALL | GLK | X204 | Drive | CDID-Common Rail Diesel Injection | ● | ● | ● | ● | ○ | ● |
| ALL | GLK | X204 | Drive | CDI 3-Common Rail Diesel Injection3 | ● | ● | ● | ● | ● | |
| ALL | GLK | X204 | Drive | ESM-Electronic selector module | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Drive | CDI 6-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Drive | CDI 60LS-Common Rail Diesel Injection | ● | ● | ● | ● | ● | |
| ALL | GLK | X204 | Drive | CDI 6-Common Rail Diesel Injection | ● | ● | ● | ● | ● | |
| ALL | GLK | X204 | Drive | CDI 6-Common Rail Diesel Injection | ● | ● | ● | ● | ● | |
| ALL | GLK | X204 | Chassis | ESP-Electronic stability program (N30/4) | ● | ● | ○ | ● | ○ | ● |
| ALL | GLK | X204 | Chassis | ABR-Adaptive Brake | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Chassis | TPC-Tire pressure monitor | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|-------|--------------|---------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | GLK | X204 | Chassis | TPM - Tire pressure monitor(N88) | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Chassis | AIRMATIC-AIRMATIC | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |
| ALL | GLK | X204 | Chassis | EHPS-Electrohydraulic Power Steering | ● | ● | ● | ● | ● | |
| ALL | GLK | X204 | Chassis | ES-Electrical power steering (N68) | ● | ● | ○ | ● | ○ | ● |
| ALL | GLK | X204 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Chassis | ESP-Regenerative braking system (N30/6) | ● | ● | ○ | ● | ○ | ● |
| ALL | GLK | X204 | Body | CGW-Central gateway | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Body | CGW[ZGW]-Central gateway (CGW[ZGW]) | ● | ● | ○ | ● | ○ | ● |
| ALL | GLK | X204 | Body | CGW-Central gateway | ● | ● | ● | ● | ▲ | ● |
| ALL | GLK | X204 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Body | KG-Keyless Go | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Body | KG-KEYLESS GO(N69/5) | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Body | Trailer recognition module | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Body | AB-Airbag | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Body | SRS-Supplemental restraint system (N2/10) | ● | ● | ● | ● | ▲ | ● |
| ALL | GLK | X204 | Body | SRS-Supplemental restraint system | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Body | WSS-Weight sensing system | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Body | PSD-Control mudule 'Panoramic sliding roof' (A98) | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Body | PSD-Control mudule 'Panoramic sliding roof' (A98) | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Body | Dr-side SAM-Driver signal acquisition and actuation module | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Body | Driver-side SAM-Driver signal acquisition and actuation module | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Body | Driver-side SAM-Driver signal acquisition and actuation module | ● | ● | ● | ● | ▲ | |
| ALL | GLK | X204 | Body | REAR SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Body | Rear SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ▲ | ▲ |
| ALL | GLK | X204 | Body | AHE-Trailer recognition | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Body | MSS-Special vehicle multifunction control module | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Body | Multifunction control unit-Multifunction control unit (N26/14) | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Body | RevETR-LF-Left front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Body | RevETR-LF-Left front reversible emergency tensioning retractor(A76) | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Body | RevETR-RF-Right front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Body | RevETR-RF-Right front reversible emergency tensioning retractor(A76/1) | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Body | XALWA-L-Xenon headlamp, left | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Body | XALWA-L-Xenon headlamp, left | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|-------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | GLK | X204 | Body | XALWA-L-Xenon headlamp, left | ● | ● | ● | ● | ● | |
| ALL | GLK | X204 | Body | XALWA-R-Xenon headlamp, right | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Body | XALWA-R-Xenon headlamp, right | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Body | XALWA-R-Xenon headlamp, right | ● | ● | ● | ● | ● | |
| ALL | GLK | X204 | Body | EZS-Electronic ignition lock | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Body | SG-SW-Control unit 'Headlamp' (N71/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | GLK | X204 | Body | IRS-HRA-Outer right rear intelligent radar sensor | ● | ● | ○ | ● | ○ | ● |
| ALL | GLK | X204 | Body | IRS-HLA-Outer left rear intelligent radar sensor system (B29/4) | ● | ● | ○ | ● | ○ | ● |
| ALL | GLK | X204 | Body | SGR-Radar sensors control unit | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |
| ALL | GLK | X204 | Body | RFK-Backup camera (B84/3) | ● | ● | ○ | ● | ○ | ● |
| ALL | GLK | X204 | Body | Rear SAM-Rear signal acquisition and actuation module | ● | ● | ○ | ● | ○ | ● |
| ALL | GLK | X204 | Body | SCM-Steering column module(N80) | ● | ● | ○ | ● | ○ | ● |
| ALL | GLK | X204 | Body | SGR-Radar sensors control unit | ● | ● | ● | ● | ○ | ● |
| ALL | GLK | X204 | Information and communication | ES-Electrical power steering | ● | ● | ● | ● | ● | ○ |
| ALL | GLK | X204 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Information and communication | IC-Instrument cluster (A1) | ● | ● | ○ | ● | ○ | ● |
| ALL | GLK | X204 | Information and communication | IC-Instrument cluster (A1) | ● | ● | ○ | ● | ○ | ● |
| ALL | GLK | X204 | Information and communication | ICI-InCar Internet (N125/3) | ● | ● | ○ | ● | ○ | ● |
| ALL | GLK | X204 | Information and communication | PTS-Parktronic | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Information and communication | PTS-PARKTRONIC (N62) | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Information and communication | PTS-PARKTRONIC (N62) | ● | ● | ○ | ● | ○ | ● |
| ALL | GLK | X204 | Information and communication | RFK-Backup camera(B84/3) | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Information and communication | SCCM-Steering column module(N80) | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Information and communication | COMAND or AUDIO | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Information and communication | COMAND or AUDIO | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|-------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | GLK | X204 | Information and communication | Audio-Audio or COMAND (A2-A40/3) | ● | ● | ○ | ● | ○ | ● |
| ALL | GLK | X204 | Information and communication | COU [ZBE]-Central operating unit | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Information and communication | ZBE-Audio/COMAND operating unit(A40/9) | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Information and communication | ZAN-Central display | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Information and communication | TV-TV tuner | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Information and communication | TV-TV tuner(AGW) | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Information and communication | CTEL-Cellular telephone(JAPAN) | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Information and communication | DAB-Digital radio | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Information and communication | DAB-Digital Audio Broadcasting (N87/3) | ● | ● | ○ | ● | ○ | ● |
| ALL | GLK | X204 | Information and communication | Sound system (Main amplifier) | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Information and communication | SDAR-Satellite radio(Valid for USA) | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Information and communication | UCI-Media interface | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Information and communication | AVE-H-Rear audio video unit | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Information and communication | Left rear screen | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Information and communication | Right rear screen | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Information and communication | TELE AID-Control unit | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Information and communication | TELE AID-Telematic services Emergency call | ● | ● | ● | ● | | ● |
| ALL | GLK | X204 | Information and communication | TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE) | ● | ● | ● | ● | | ● |
| ALL | GLK | X204 | Information and communication | TELE AID-Telematic services Stolen vehicle tracking | ● | ● | ● | ● | | ● |
| ALL | GLK | X204 | Information and communication | TELE AID-Telematic services Remote door unlocking, Remote door locking | ● | ● | ● | ● | | ● |
| ALL | GLK | X204 | Information and communication | AMG PM-AMG Performance Media(N125/2) | ● | ● | ○ | ● | ○ | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|---------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | GLK | X204 | Information and communication | AMG DRVU-AMG DRIVE UNIT (N145) | ● | ● | ○ | ● | ○ | ● |
| ALL | GLK | X204 | Information and communication | Drive-side SAM-Front signal acquisition and actuation module (N10/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | GLK | X204 | Information and communication | MFK-Multifunction camera | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |
| ALL | GLK | X204 | Information and communication | NAV-Navigation module (A2/30) | ● | ● | ○ | ● | ○ | ● |
| ALL | GLK | X204 | Information and communication | 360° camera-360° camera(N148) | ● | ● | ○ | ● | ○ | ● |
| ALL | GLK | X204 | Information and communication | NAVI20 - Navigation(N125/2) | ● | ● | ○ | ● | ○ | ● |
| ALL | GLK | X204 | Seats and doors | DCM-FL-Door control module front left | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Seats and doors | DCU-LF-Left front door | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Seats and doors | DCM-FR-Door control module front right | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Seats and doors | DCU-RF-Right front door | ● | ● | ● | ● | ● | ▲ |
| ALL | GLK | X204 | Seats and doors | DCM-RL-Door control module rear left | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Seats and doors | DCU-LR-Left rear door | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Seats and doors | DCM-RR-Door control module rear right | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Seats and doors | DCU-RR-Right rear door | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Seats and doors | HKS-Tailgate control (N121/1) | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Seats and doors | ESA driver | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Seats and doors | ESA 'Driver'-Electric seat adjustment 'Driver' (N32/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | GLK | X204 | Seats and doors | ESA passenger | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Seats and doors | ESA-Electirc seat adjustment 'Front passenger' (N32/2) | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Seats and doors | ESA' Front passenger'-Electric seat adjustment 'Front passenger' with memory function(N32/2) | ● | ● | ○ | ● | ○ | ● |
| ALL | GLK | X204 | Air conditioning | Stationary heater | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Air conditioning | AAC-Air conditioning (N22/7) | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Air conditioning | AAC-Air conditioning (N22/7) | ● | ● | ● | ● | ● | ● |
| ALL | GLK | X204 | Air conditioning | EKMK-Electric refrigerant compressor (A9/5) | ● | ● | ○ | ● | ○ | ● |
| ALL | GLK | X204 | LIN Bus | LCP-Lower control panel (S77) | ● | ● | ○ | ● | ○ | ● |
| ALL | GLK | X204 | LIN Bus | GTO-Garage door opener (A67n2) | ● | ● | ○ | ● | ○ | ● |
| ALL | GLK | X204 | LIN Bus | AMLAB-L 1-Actuation module 1, LED exterior lighting, left front (E1n7) | ● | ● | ○ | ● | ○ | ● |
| ALL | GLK | X204 | LIN Bus | AMLAB-R 1-Actuation module 1, LED exterior lighting, right front (E2n7) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 164 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Drive | VG-Transfer case | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Drive | HAQ-Interwheel differential lock at rear axle | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Drive | ISM-Intelligent servo module | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Drive | ISM-Shift module (A80) | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|---------|--------------|---------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | M-Class | 164 | Drive | ME 9.7-Motor electronics 9.7 | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Drive | IRS-HRA-Outer right rear intelligent radar sensor | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Drive | IRS-HLA - Outer left rear intelligent radar sensor system | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Drive | TV-TV tuner | ● | ● | ● | ● | ● | |
| ALL | M-Class | 164 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Drive | ME 9.7 (AMG)-Motor electronics 9.7 (AMG) | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Drive | FSCU Left-Control unit 'Left fuel pump' | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Drive | FSCU Right-Control unit 'Right fuel pump' | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Drive | CDI 4-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Drive | CDI 6BIN5-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Drive | CDI 6-Common Rail Diesel Injection | ● | ● | ● | ● | ● | |
| ALL | M-Class | 164 | Drive | CDI 6-Common Rail Diesel Injection | ● | ● | ● | ● | ● | |
| ALL | M-Class | 164 | Drive | SCR-Selective Catalytic Reduction | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Drive | CDI 5-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | |
| ALL | M-Class | 164 | Drive | ME-SF 17.7-Motor electronics 17.7 | ● | ● | ● | ● | ● | |
| ALL | M-Class | 164 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Drive | HSG-Hybrid control unit | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Chassis | Suspension | ● | ● | ● | ● | ● | ○ |
| ALL | M-Class | 164 | Chassis | TPC-Tire pressure monitor | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Chassis | TPM - Tire pressure monitor(N88) | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Chassis | EHPS-Electrohydraulic Power Steering | ● | ● | ● | ● | ● | |
| ALL | M-Class | 164 | Chassis | RBS-Brake system | ▲ | ▲ | ▲ | ▲ | ▲ | |
| ALL | M-Class | 164 | Body | CGW-Central gateway | ● | ● | ● | ● | ○ | ○ |
| ALL | M-Class | 164 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ○ |
| ALL | M-Class | 164 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Body | KG-Keyless Go | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Body | KG-KEYLESS GO | ● | ● | ● | ● | ● | |
| ALL | M-Class | 164 | Body | AB-Airbag | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Body | WSS-Weight sensing system | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Body | UCP-Upper control panel | ● | ● | ● | ● | ● | ○ |
| ALL | M-Class | 164 | Body | HBF (Rear control panel)-Rear control field | ● | ● | ● | ● | ● | ○ |
| ALL | M-Class | 164 | Body | SAM-F-Signal acquisition and actuation module front | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Body | REAR SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ● | ○ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|---------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | M-Class | 164 | Body | RevETR-RF-Right front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Body | RevETR-LF-Left front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | |
| ALL | M-Class | 164 | Body | RevETR-LF-Left front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Body | RevETR-LF-Left front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | |
| ALL | M-Class | 164 | Body | HRA-Automatic headlamp range adjustment and headlamp control | ● | ● | ● | ● | ● | ○ |
| ALL | M-Class | 164 | Body | XALWA-L-Xenon headlamp, left | ● | ● | ● | ● | ● | |
| ALL | M-Class | 164 | Body | XALWA-L-Xenon headlamp, left | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Body | XALWA-R-Xenon headlamp, right | ● | ● | ● | ● | ● | |
| ALL | M-Class | 164 | Body | XALWA-R-Xenon headlamp, right | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Body | System diagnosis (CAN) | ● | ● | ○ | ● | ● | ● |
| ALL | M-Class | 164 | Body | SG-DDW - DC/DC converter control unit | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Body | SG-BMS - Battery management system control unit | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Information and communication | CM-Compass module | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Information and communication | IC-Instrument cluster | ● | ● | ● | ● | ● | ○ |
| ALL | M-Class | 164 | Information and communication | ASSYST-Active Service System | ● | ● | ○ | ● | ● | ○ |
| ALL | M-Class | 164 | Information and communication | ASSYST PLUS-PLUS Active Service System | ● | ● | ○ | ● | ● | ● |
| ALL | M-Class | 164 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ○ |
| ALL | M-Class | 164 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ○ |
| ALL | M-Class | 164 | Information and communication | RFK-Backup camera | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Information and communication | CDC-CD changer | ● | ● | ○ | ● | ● | ● |
| ALL | M-Class | 164 | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|---------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | M-Class | 164 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Information and communication | COMAND or AUDIO | ● | ● | ○ | ● | ● | ● |
| ALL | M-Class | 164 | Information and communication | TV-TV tuner | ● | ● | ○ | ● | ● | ● |
| ALL | M-Class | 164 | Information and communication | TV-TV tuner(AGW) | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Information and communication | SDAR-Satellite radio | ● | ● | ○ | ● | ● | ● |
| ALL | M-Class | 164 | Information and communication | SOUND- Sound system | ● | ● | ○ | ● | ● | ● |
| ALL | M-Class | 164 | Information and communication | CTEL-Mobile phone adapter with universal interface | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Information and communication | NAVI-Navigation system | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Information and communication | AVE-H-Rear audio video unit | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Information and communication | CTEL-Cellular telephone | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Information and communication | COMAND or AUDIO | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Information and communication | Sound system (Main amplifier) | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Information and communication | UCI-Media interface | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Information and communication | DAB-Digital radio | ● | ● | ● | ● | ● | ○ |
| ALL | M-Class | 164 | Information and communication | SDAR-Satellite radio(Valid for USA) | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Information and communication | TV-TV tuner | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Information and communication | CTEL-Cellular telephone(JAPAN) | ● | ● | ● | ● | ● | ○ |
| ALL | M-Class | 164 | Information and communication | AVE-H-Rear audio video unit | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Information and communication | Left rear screen | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Information and communication | Right rear screen | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Information and communication | TELE AID-Control unit | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|---------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | M-Class | 164 | Information and communication | TELE AID-Telematic services Emergency call | ● | ● | ● | ● | | ● |
| ALL | M-Class | 164 | Information and communication | TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE) | ● | ● | ● | ● | | ● |
| ALL | M-Class | 164 | Information and communication | TELE AID-Telematic services Stolen vehicle tracking | ● | ● | ● | ● | | ● |
| ALL | M-Class | 164 | Information and communication | TELE AID-Telematic services Remote door unlocking,Remote door locking | ● | ● | ● | ● | | ● |
| ALL | M-Class | 164 | Seats and doors | DCM-FL-Door control module front left | ● | ● | ● | ● | ● | ○ |
| ALL | M-Class | 164 | Seats and doors | DCM-FR-Door control module front right | ● | ● | ● | ● | ● | ○ |
| ALL | M-Class | 164 | Seats and doors | ESA driver-Electric seat adjustment driver (with | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Seats and doors | ESA passenger-Electric seat adjustment passenger | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Seats and doors | DS-LF-Left front dynamic seat | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Seats and doors | DS-RF-Right front dynamic seat | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Seats and doors | DSP-Pneumatic pump for dynamic seat | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Seats and doors | REDC-Rear-end door closing control module | ● | ● | ● | ● | ● | ○ |
| ALL | M-Class | 164 | Seats and doors | REDC-Rear-end door closing control module | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Seats and doors | HS-Seat heater | ● | ● | ● | ● | ● | ○ |
| ALL | M-Class | 164 | Air conditioning | AAC-Automatic air conditioning | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Air conditioning | HSW-Heated steering wheel | ● | ● | ● | ● | ● | ○ |
| ALL | M-Class | 164 | Air conditioning | STH-Stationary heater with remote control | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 164 | Air conditioning | EKMK-Electric refrigerant compressor (A9/5) | ● | ● | ● | ● | ● | |
| ALL | M-Class | 163 | Drive | ETC-Electronic transmission control | ● | ● | ○ | ● | | ※ |
| ALL | M-Class | 163 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 163 | Drive | ESM-Electronic selector module | ● | ● | ○ | ● | ● | ※ |
| ALL | M-Class | 163 | Drive | ME2-SFI-Motor electronics 2 | ● | ● | ○ | ● | ● | ※ |
| ALL | M-Class | 163 | Drive | VG-Transfer case | ● | ● | ○ | ● | ● | ※ |
| ALL | M-Class | 163 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 163 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 163 | Drive | CDI 2-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 163 | Drive | CDI-V-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 163 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 163 | Chassis | ESP-Electronic stability program | ● | ● | ○ | ● | ● | ※ |
| ALL | M-Class | 163 | Chassis | ESP-Electronic stability program | ● | ● | ○ | ● | ● | ※ |
| ALL | M-Class | 163 | Chassis | ESP-Electronic stability program | ● | ● | ○ | ● | ● | ※ |
| ALL | M-Class | 163 | Chassis | ETS-Electronic traction system | ● | ● | ○ | ● | ● | ※ |
| ALL | M-Class | 163 | Chassis | ETS-Electronic traction system | ● | ● | ○ | ● | ● | ※ |
| ALL | M-Class | 163 | Chassis | BAS-Brake assist | ● | ● | ○ | ● | ● | ※ |
| ALL | M-Class | 163 | Chassis | VP-Vacuum pump brake booster | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 163 | Body | AB-Airbag | ● | ● | ○ | ● | | ※ |
| ALL | M-Class | 163 | Body | AB-Airbag | ● | ● | ○ | ● | ● | ※ |
| ALL | M-Class | 163 | Body | EAM-Extended activity module | ● | ● | ○ | ● | ● | ※ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|---------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | M-Class | 163 | Body | AAM-All Activity Module | ● | ● | ○ | ● | ● | ※ |
| ALL | M-Class | 163 | Body | AAM-All Activity Module | ● | ● | ○ | ● | ● | ※ |
| ALL | M-Class | 163 | Body | DAS-Drive authorization system | ● | ● | ● | ● | ● | ※ |
| ALL | M-Class | 163 | Body | HRA-Headlamp range adjustment | ● | ● | ● | ● | ● | ○ |
| ALL | M-Class | 163 | Body | LCP-Lower operating panel with power window function | ● | ● | ● | ● | ● | ※ |
| ALL | M-Class | 163 | Body | SEM-Security Module | ● | ● | ○ | ● | | ※ |
| ALL | M-Class | 163 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ○ | ● | ● | ※ |
| ALL | M-Class | 163 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ※ |
| ALL | M-Class | 163 | Information and communication | COMAND | ● | ● | ○ | ● | ● | ● |
| ALL | M-Class | 163 | Information and communication | MCS-Modular control system | ● | ● | ○ | ● | ● | ● |
| ALL | M-Class | 163 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 163 | Information and communication | CTEL- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ○ | ○ |
| ALL | M-Class | 163 | Information and communication | UHI- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ● | ○ |
| ALL | M-Class | 163 | Information and communication | CDC-CD changer | ● | ● | ● | ● | ○ | ○ |
| ALL | M-Class | 163 | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ○ |
| ALL | M-Class | 163 | Information and communication | SOUND- Sound system | ● | ● | ○ | ● | ● | ● |
| ALL | M-Class | 163 | Information and communication | SDAR-Satellite radio | ● | ● | ● | ● | ○ | ● |
| ALL | M-Class | 163 | Information and communication | MCS navigation-Navigation in MCS | ● | ● | ○ | ● | ● | ● |
| ALL | M-Class | 163 | Information and communication | E-call [USA]-Telematic system | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 163 | Information and communication | CTEL over K-wire-Telematic system | ● | ● | ● | ● | ○ | ○ |
| ALL | M-Class | 163 | Air conditioning | STH-Stationary heater | ● | ● | ○ | ● | ● | ※ |
| ALL | M-Class | 163 | Air conditioning | AAC-Automatic air conditioning | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 166 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 166 | Drive | MED 17.7-Motor electronics for direct injection 17.7 | ● | ● | ● | ● | ● | |
| ALL | M-Class | 166 | Drive | ISM-Shift module (A80) | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |
| ALL | M-Class | 166 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 166 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 166 | Drive | mbrace-mbrace (N123/4) | ● | ● | ○ | ● | ○ | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|---------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | M-Class | 166 | Drive | SCR-Selective Catalytic Reduction | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 166 | Drive | N15/7(Transfer case control module) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 166 | Drive | CDI-Motor electronics 'CR43' for combustion engine 'OM651' (N3/9) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Drive | CDI 60LS-Common Rail Diesel Injection | ● | ● | ● | ● | ● | |
| ALL | M-Class | 166 | Drive | CDI 3-Common Rail Diesel Injection3 | ● | ● | ● | ● | ● | |
| ALL | M-Class | 166 | Chassis | Roll control-Roll control (N51/6) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Chassis | ESP-Electronic stability program (N30/4) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Chassis | TPM-Tire pressure monitor | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Chassis | EPB-Electronic parking break (N128) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Chassis | ES-Electrical power steering (N68) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Chassis | ESP-Regenerative braking system (N30/6) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Chassis | AIRMATIC - AIRMATIC(N51/3) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Body | EZS-Electronic ignition switch | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Body | KG-KEYLESS GO | ● | ● | ● | ● | ● | |
| ALL | M-Class | 166 | Body | KG-KEYLESS GO (N69/5) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Body | BMS-Battery management system (N82/2) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Body | IRS-HRA-Outer right rear intelligent radar sensor | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Body | IRS-HLA-Outer left rear intelligent radar sensor system (B29/4) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Body | SAM-Signal acquisition and actuation module (N10) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Body | SG-AWF-Control unit 'COLLISION PREVENTION ASSIST' | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Body | SG-SW-Control unit 'Headlamp' (N71/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Body | SG-EM-Power electronics (N129/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Body | SRS-Supplemental restraint system (N2/10) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Body | HKS-Tailgate control (N121/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Body | Rear-Rear control unit (N10/8) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Body | RevETR-LF-Left front reversible emergency tensioning retractor (A76) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Body | RevETR-RF-Right front reversible emergency tensioning retractor(A76/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Body | SGR-Radar sensors control unit | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |
| ALL | M-Class | 166 | Body | SCM-Steering column module(N80) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Body | SD-Control module 'Sliding roof (A98/1)' | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Body | Trailer recognition module-Trailer recognition(N28/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Body | PSD-Control module 'Panoramic sliding roof' (A98) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Body | SGR-Radar sensors control unit | ● | ● | ● | ● | ○ | ● |
| ALL | M-Class | 166 | Body | ATA-ATA[EDW]/tow-away protection/interior protection(N26/6) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Information and communication | IC-Instrument cluster (A1) | ● | ● | ○ | ● | ○ | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|---------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | M-Class | 166 | Information and communication | IC-Instrument cluster (A1) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 166 | Information and communication | COU [ZBE]-Central operating unit | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 166 | Information and communication | DAB-Digital Audio Broadcasting (N87/3) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Information and communication | DAB-Digital radio | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 166 | Information and communication | ZAN-Central display | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 166 | Information and communication | Left rear screen | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 166 | Information and communication | Right rear screen | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 166 | Information and communication | AVE-H-Rear audio video unit | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 166 | Information and communication | Audio-Audio or COMAND (A2-A40/3) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Information and communication | MFK-Multifunction camera | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |
| ALL | M-Class | 166 | Information and communication | NAV-Navigation module (A2/30) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Information and communication | NSA-Night View Assist | ● | ● | ● | ● | ● | ○ |
| ALL | M-Class | 166 | Information and communication | PTS-PARKTRONIC (N62) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Information and communication | SDAR-Satellite radio(Valid for USA) | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 166 | Information and communication | SOUND - Sound system(N40/3) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Information and communication | Sound system (Main amplifier) | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 166 | Information and communication | Sound system (Bass amplifier) | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 166 | Information and communication | 360° camera-360° camera(N148) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Information and communication | TV-TV tuner(AGW) | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 166 | Information and communication | UCI-Media interface | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|--------------------------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | M-Class | 166 | Information and communication | TELE AID-Control unit | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 166 | Information and communication | TELE AID-Telematic services Emergency call | ● | ● | ● | ● | | ● |
| ALL | M-Class | 166 | Information and communication | TELE AID-Telematic services Remote door unlocking, Remote door locking | ● | ● | ● | ● | | ● |
| ALL | M-Class | 166 | Information and communication | TELE AID-Telematic services MB Info, Roadside assistance (USA, Canada), Tele diagnosis (ECE) | ● | ● | ● | ● | | ● |
| ALL | M-Class | 166 | Information and communication | TELE AID-Telematic services Stolen vehicle tracking | ● | ● | ● | ● | | ● |
| ALL | M-Class | 166 | Seats and doors | DCU-LF-Left front door (N69/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Seats and doors | DCU-RF-Right front door (N69/2) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Seats and doors | DCU-LR-Left rear door (N69/3) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Seats and doors | DCU-RR-Right rear door (N69/4) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Seats and doors | MKS-FS-Multicontour seat 'Driver' (N32/29) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Seats and doors | MKS-BFS-Multicontour seat 'Front passenger' (N32/30) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Seats and doors | DSP-Pneumatic pump for dynamic seat | ● | ● | ● | ● | ● | ● |
| ALL | M-Class | 166 | Seats and doors | ESA 'Driver' -Electrical seat adjustment 'Driver' with memory function (N32/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Seats and doors | ESA 'Front passenger' -Electric seat adjustment 'Front passenger' with memory function (N32/2) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Air conditioning | AAC-Air conditioning (N22/7) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Air conditioning | HBF-Rear control panel (N72/2) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | Air conditioning | STH-Stationary heater (A6n1) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | LIN Bus | LCP-Lower control panel (N72) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | LIN Bus | UCP-Upper control panel (N72/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | LIN Bus | BSN-Battery sensor (B95) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | LIN Bus | AISP-Dimming inside rearview mirror (A67) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | LIN Bus | GTO-Garage door opener (A67n2) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | LIN Bus | AMLAB-L 1-Actuation module 1, LED exterior lighting, left front (E1n7) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | LIN Bus | AMLAB-R 1-Actuation module 1, LED exterior lighting, right front (E2n7) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | LIN Bus | RGLS-Rain/light sensor (B38/2) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | LIN Bus | ORBF-Off-road operating panel (N72/3) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | LIN Bus | OCP-Control unit 'Overhead control panel' (N70) | ● | ● | ○ | ● | ○ | ● |
| ALL | M-Class | 166 | LIN Bus | AS-Alarm siren (H3/1) | ● | ● | ○ | ● | ○ | ● |
| Up to 03/2004 | G-Class | 463 (16-pin diagnostic socket) | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|-------------------------------|---------------------|-------------------------------------|-----------|------------|--------------|-------------|-----------|--------------|
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Drive | ESM-Electronic selector module | ● | ● | ○ | ● | ● | ※ |
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Drive | N15/7(Transfer case control module) | ● | ● | ● | ● | ● | ○ |
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Drive | CDI-V-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Drive | CDI 2-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Chassis | ABS-Antilock brake system | ● | ● | ● | ● | ● | ※ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|-------------------------------|---------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ※ |
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Body | AB-Airbag | ● | ● | ○ | ● | ● | ※ |
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ○ |
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ○ |
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Body | UCP-Upper control panel | ● | ● | ● | ● | ● | ○ |
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Body | SAM-F-Signal acquisition and actuation module front | ● | ● | ● | ● | ● | ○ |
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Body | REAR SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ● | ○ |
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ○ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|-------------------------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Body | MSS-Special vehicle multifunction control module | ● | ● | ● | ● | ● | ○ |
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Body | AHE-Trailer recognition | ● | ● | ● | ● | ● | ○ |
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ○ |
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ● |
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ● |
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Information and communication | D2B-COMAND, MCS or AUDIO | ● | ● | ● | ● | ● | ● |
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Information and communication | COMAND | ● | ● | ○ | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|-------------------------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Information and communication | CDC-CD changer | ● | ● | ● | ● | ○ | ○ |
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ○ |
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Information and communication | SDAR-Satellite radio | ● | ● | ● | ● | ○ | ● |
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Information and communication | CTEL- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ○ | ○ |
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Information and communication | UHI- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ● | ○ |
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Information and communication | TV-TV tuner | ● | ● | ● | ● | | ● |
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Information and communication | E-call [Japan]-Telematic system | ● | ● | ● | ● | ● | ● |
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Information and communication | E-call [USA]-Telematic system | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|-------------------------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Information and communication | TELE AID-Telematic system | ● | ● | ● | ● | ● | |
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Information and communication | CTEL over K-wire-Telematic system | ● | ● | ● | ● | ○ | ○ |
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Seats and doors | DCM-FL-Door control module front left | ● | ● | ● | ● | ● | ○ |
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Seats and doors | DCM-FR-Door control module front right | ● | ● | ● | ● | ● | ○ |
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Seats and doors | DCM-RL-Door control module rear left | ● | ● | ● | ● | ● | ○ |
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Seats and doors | DCM-RR-Door control module rear right | ● | ● | ● | ● | ● | ○ |
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Seats and doors | ESA passenger-Electric seat adjustment passenger | ● | ● | ● | ● | ● | ○ |
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Seats and doors | ESA passenger-Electric seat adjustment passenger | ● | ● | ● | ● | ● | ○ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|-------------------------|---------|-------------------------------|---------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Seats and doors | ESA passenger-Electric seat adjustment passenger | ● | ● | ● | ● | ● | ○ |
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Seats and doors | ESA driver-Electric seat adjustment driver | ● | ● | ● | ● | ● | ○ |
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Seats and doors | ESA driver-Electric seat adjustment driver | ● | ● | ● | ● | ● | ○ |
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Seats and doors | ESA driver-Electric seat adjustment driver (with memory) | ● | ● | ● | ● | ● | ○ |
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Air conditioning | AAC-Automatic air conditioning | ● | ● | ● | ● | ● | ● |
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Air conditioning | STH-Stationary heater | ● | ● | ● | ● | ● | ● |
| Up to 03/2004 | G-Class | 463(16-pin diagnostic socket) | Air conditioning | HSW-Heated steering wheel | ● | ● | ● | ● | ● | ● |
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|-------------------------|---------|-------------------------------|---------------------|-------------------------------------|-----------|------------|--------------|-------------|-----------|--------------|
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Drive | ESM-Electronic selector module | ● | ● | ○ | ● | ● | ※ |
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Drive | N15/7(Transfer case control module) | ● | ● | ● | ● | ● | ○ |
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Drive | CDI-V-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Drive | CDI 2-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Chassis | ABS-Antilock brake system | ● | ● | ● | ● | ● | ※ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|-------------------------|---------|-------------------------------|---------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ※ |
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ○ |
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Body | AB-Airbag | ● | ● | ○ | ● | ● | ※ |
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Body | UCP-Upper control panel | ● | ● | ● | ● | ● | ○ |
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Body | SAM-F-Signal acquisition and actuation module front | ● | ● | ● | ● | ● | ○ |
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Body | REAR SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ● | ○ |
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ○ |
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Body | MSS-Special vehicle multifunction control module | ● | ● | ● | ● | ● | ○ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|-------------------------|---------|-------------------------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Body | AHE-Trailer recognition | ● | ● | ● | ● | ● | ○ |
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ○ |
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ● |
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ● |
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Information and communication | D2B-COMAND, MCS or AUDIO | ● | ● | ● | ● | ● | ● |
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Information and communication | COMAND | ● | ● | ○ | ● | ● | ● |
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Information and communication | CDC-CD changer | ● | ● | ● | ● | ○ | ○ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|-------------------------|---------|-------------------------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ○ |
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Information and communication | SDAR-Satellite radio | ● | ● | ● | ● | ○ | ● |
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Information and communication | CTEL- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ○ | ○ |
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Information and communication | UHI- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ● | ○ |
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Information and communication | TV-TV tuner | ● | ● | ● | ● | | ● |
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Information and communication | E-call [Japan]-Telematic system | ● | ● | ● | ● | ● | ● |
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Information and communication | E-call [USA]-Telematic system | ● | ● | ● | ● | ● | ● |
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Information and communication | TELE AID-Telematic system | ● | ● | ● | ● | ● | |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|-------------------------|---------|-------------------------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Information and communication | CTEL over K-wire-Telematic system | ● | ● | ● | ● | ○ | ○ |
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Seats and doors | DCM-FL-Door control module front left | ● | ● | ● | ● | ● | ○ |
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Seats and doors | DCM-FR-Door control module front right | ● | ● | ● | ● | ● | ○ |
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Seats and doors | DCM-RL-Door control module rear left | ● | ● | ● | ● | ● | ○ |
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Seats and doors | DCM-RR-Door control module rear right | ● | ● | ● | ● | ● | ○ |
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Seats and doors | ESA passenger-Electric seat adjustment passenger | ● | ● | ● | ● | ● | ○ |
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Seats and doors | ESA passenger-Electric seat adjustment passenger | ● | ● | ● | ● | ● | ○ |
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Seats and doors | ESA passenger-Electric seat adjustment passenger | ● | ● | ● | ● | ● | ○ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|-------------------------|---------|-------------------------------|---------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Seats and doors | ESA driver-Electric seat adjustment driver | ● | ● | ● | ● | ● | ○ |
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Seats and doors | ESA driver-Electric seat adjustment driver | ● | ● | ● | ● | ● | ○ |
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Seats and doors | ESA driver-Electric seat adjustment driver (with memory) | ● | ● | ● | ● | ● | ○ |
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Air conditioning | AAC-Automatic air conditioning | ● | ● | ● | ● | ● | ● |
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Air conditioning | STH-Stationary heater | ● | ● | ● | ● | ● | ● |
| From 04/2004 to 08/2006 | G-Class | 463(16-pin diagnostic socket) | Air conditioning | HSW-Heated steering wheel | ● | ● | ● | ● | ● | ○ |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|-------------------------|---------|-------------------------------|---------------------|-------------------------------------|-----------|------------|--------------|-------------|-----------|--------------|
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Drive | ESM-Electronic selector module | ● | ● | ○ | ● | ● | ※ |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Drive | N15/7(Transfer case control module) | ● | ● | ● | ● | ● | ○ |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Drive | CDI 4-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Chassis | ABS-Antilock brake system | ● | ● | ● | ● | ● | ※ |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ※ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|-------------------------|---------|-------------------------------|---------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ○ |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Body | AB-Airbag | ● | ● | ○ | ● | ● | ※ |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Body | UCP-Upper control panel | ● | ● | ● | ● | ● | ○ |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Body | SAM-F-Signal acquisition and actuation module front | ● | ● | ● | ● | ● | ○ |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Body | REAR SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ● | ○ |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ○ |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Body | ALWR-Headlamp range adjustment | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|-------------------------|---------|-------------------------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Body | MSS-Special vehicle multifunction control module | ● | ● | ● | ● | ● | ○ |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Body | AHE-Trailer recognition | ● | ● | ● | ● | ● | ○ |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ○ |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ● |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ● |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | D2B-COMAND, MCS or AUDIO | ● | ● | ● | ● | ● | ● |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | COMAND | ● | ● | ○ | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|-------------------------|---------|-------------------------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | CDC-CD changer | ● | ● | ● | ● | ○ | ○ |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ○ |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | SDAR-Satellite radio | ● | ● | ● | ● | ○ | ● |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | CTEL- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ○ | ○ |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | UHI- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ● | ○ |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | TV-TV tuner | ● | ● | ● | ● | | ● |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | E-call [Japan]-Telematic system | ● | ● | ● | ● | ● | ● |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | E-call [USA]-Telematic system | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|-------------------------|---------|-------------------------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | TELE AID-Telematic system | ● | ● | ● | ● | ● | |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | CTEL over K-wire-Telematic system | ● | ● | ● | ● | ○ | ○ |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | COMAND or AUDIO | ● | ● | ○ | ● | ● | ● |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | CDC-CD changer | ● | ● | ○ | ● | ● | ● |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|-------------------------|---------|-------------------------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | SDAR-Satellite radio | ● | ● | ○ | ● | ● | ● |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | SOUND- Sound system | ● | ● | ○ | ● | ● | ● |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | TV-TV tuner(AGW) | ● | ● | ● | ● | ● | ● |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | CTEL-Mobile phone adapter with universal interface | ● | ● | ● | ● | ● | ● |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | NAVI-Navigation system | ● | ● | ● | ● | ● | ● |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | TELE AID-Control unit | ● | ● | ● | ● | ● | ● |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE) | ● | ● | ● | ● | | ● |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | TELE AID-Telematic services Emergency call | ● | ● | ● | ● | | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|-------------------------|---------|-------------------------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | TELE AID-Telematic services Remote door unlocking, Remote door locking | ● | ● | ● | ● | | ● |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | TELE AID-Telematic services Stolen vehicle tracking | ● | ● | ● | ● | | ● |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Seats and doors | DCM-FL-Door control module front left | ● | ● | ● | ● | ● | ○ |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Seats and doors | DCM-FR-Door control module front right | ● | ● | ● | ● | ● | ○ |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Seats and doors | DCM-RL-Door control module rear left | ● | ● | ● | ● | ● | ○ |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Seats and doors | DCM-RR-Door control module rear right | ● | ● | ● | ● | ● | ○ |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Seats and doors | ESA passenger-Electric seat adjustment passenger | ● | ● | ● | ● | ● | ○ |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Seats and doors | ESA passenger-Electric seat adjustment passenger | ● | ● | ● | ● | ● | ○ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|-------------------------|---------|-------------------------------|---------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Seats and doors | ESA passenger-Electric seat adjustment passenger | ● | ● | ● | ● | ● | ○ |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Seats and doors | ESA driver-Electric seat adjustment driver | ● | ● | ● | ● | ● | ○ |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Seats and doors | ESA driver-Electric seat adjustment driver | ● | ● | ● | ● | ● | ○ |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Seats and doors | ESA driver-Electric seat adjustment driver (with memory) | ● | ● | ● | ● | ● | ○ |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Air conditioning | AAC-Automatic air conditioning | ● | ● | ● | ● | ● | ● |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Air conditioning | STH-Stationary heater | ● | ● | ● | ● | ● | ● |
| From 09/2006 to 02/2007 | G-Class | 463(16-pin diagnostic socket) | Air conditioning | HSW-Heated steering wheel | ● | ● | ● | ● | ● | ○ |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|-------------------------------|---------------------|-------------------------------------|-----------|------------|--------------|-------------|-----------|--------------|
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Drive | ESM-Electronic selector module | ● | ● | ○ | ● | ● | ※ |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Drive | N15/7(Transfer case control module) | ● | ● | ● | ● | ● | ○ |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Drive | TV-TV tuner | ● | ● | ● | ● | ● | |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Drive | ME 9.7-Motor electronics 9.7 | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|-------------------------------|---------------------|------------------------------------|-----------|------------|--------------|-------------|-----------|--------------|
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Drive | CDI 4-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Drive | CDI 6-Common Rail Diesel Injection | ● | ● | ● | ● | ● | |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Drive | SCR-Selective Catalytic Reduction | ● | ● | ● | ● | ● | ● |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Chassis | ABS-Antilock brake system | ● | ● | ● | ● | ● | ※ |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ※ |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Chassis | TPC-Tire pressure monitor | ● | ● | ● | ● | ● | ● |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ○ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|-------------------------------|---------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Body | AB-Airbag | ● | ● | ○ | ● | ● | ※ |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Body | UCP-Upper control panel | ● | ● | ● | ● | ● | ○ |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Body | SAM-F-Signal acquisition and actuation module front | ● | ● | ● | ● | ● | ○ |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Body | REAR SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ● | ○ |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ○ |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Body | ALWR-Headlamp range adjustment | ● | ● | ● | ● | ● | ● |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Body | MSS-Special vehicle multifunction control module | ● | ● | ● | ● | ● | ○ |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Body | AHE-Trailer recognition | ● | ● | ● | ● | ● | ○ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|-------------------------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Body | AHE-Trailer recognition | ● | ● | ● | ● | ● | ○ |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ○ |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ● |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ● |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | COMAND or AUDIO | ● | ● | ○ | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|-------------------------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | CDC-CD changer | ● | ● | ○ | ● | ● | ● |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ● |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | SDAR-Satellite radio | ● | ● | ○ | ● | ● | ● |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | SOUND- Sound system | ● | ● | ○ | ● | ● | ● |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | TV-TV tuner(AGW) | ● | ● | ● | ● | ● | ● |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | CTEL-Mobile phone adapter with universal interface | ● | ● | ● | ● | ● | ● |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | NAVI-Navigation system | ● | ● | ● | ● | ● | ● |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | COMAND or AUDIO | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|-------------------------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | Sound system (Main amplifier) | ● | ● | ● | ● | ● | ● |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | UCI-Media interface | ● | ● | ● | ● | ● | ● |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | DAB-Digital radio | ● | ● | ● | ● | ● | ○ |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | SDAR-Satellite radio(Valid for USA) | ● | ● | ● | ● | ● | ● |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | TV-TV tuner | ● | ● | ● | ● | ● | ● |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | CTEL-Cellular telephone(JAPAN) | ● | ● | ● | ● | ● | ○ |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | TELE AID-Control unit | ● | ● | ● | ● | ● | ● |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE) | ● | ● | ● | ● | | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|-------------------------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | TELE AID-Telematic services Emergency call | ● | ● | ● | ● | | ● |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | TELE AID-Telematic services Remote door unlocking, Remote door locking | ● | ● | ● | ● | | ● |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Information and communication | TELE AID-Telematic services Stolen vehicle tracking | ● | ● | ● | ● | | ● |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Seats and doors | DCM-FL-Door control module front left | ● | ● | ● | ● | ● | ○ |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Seats and doors | DCM-FR-Door control module front right | ● | ● | ● | ● | ● | ○ |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Seats and doors | DCM-RL-Door control module rear left | ● | ● | ● | ● | ● | ○ |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Seats and doors | DCM-RR-Door control module rear right | ● | ● | ● | ● | ● | ○ |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Seats and doors | ESA passenger-Electric seat adjustment passenger | ● | ● | ● | ● | ● | ○ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|-------------------------------|---------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Seats and doors | ESA passenger-Electric seat adjustment passenger | ● | ● | ● | ● | ● | ○ |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Seats and doors | ESA passenger-Electric seat adjustment passenger | ● | ● | ● | ● | ● | ○ |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Seats and doors | ESA driver-Electric seat adjustment driver | ● | ● | ● | ● | ● | ○ |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Seats and doors | ESA driver-Electric seat adjustment driver | ● | ● | ● | ● | ● | ○ |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Seats and doors | ESA driver-Electric seat adjustment driver (with memory) | ● | ● | ● | ● | ● | ○ |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Seats and doors | HS-Seat heater | ● | ● | ● | ● | ● | ○ |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Air conditioning | AAC-Automatic air conditioning | ● | ● | ● | ● | ● | ● |
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Air conditioning | STH-Stationary heater | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|---------------|---------|-------------------------------|---------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| As of 03/2007 | G-Class | 463(16-pin diagnostic socket) | Air conditioning | HSW-Heated steering wheel | ● | ● | ● | ● | ● | ○ |
| ALL | G-Class | 463(38-pin diagnostic socket) | Drive | ETC-Electronic transmission control | ● | ● | ○ | ● | | ※ |
| ALL | G-Class | 463(38-pin diagnostic socket) | Drive | ESM-Electronic selector module | ● | ● | ○ | ● | ● | ※ |
| ALL | G-Class | 463(38-pin diagnostic socket) | Drive | ME2-SFI-Motor electronics 2 | ● | ● | ○ | ● | ● | ※ |
| ALL | G-Class | 463(38-pin diagnostic socket) | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| ALL | G-Class | 463(38-pin diagnostic socket) | Drive | HFM-SFI-Hot film engine management | ● | ● | ○ | ● | | ※ |
| ALL | G-Class | 463(38-pin diagnostic socket) | Drive | IFI-Electronic in-line injection system diesel | ● | ● | ○ | ● | | ※ |
| ALL | G-Class | 463(38-pin diagnostic socket) | Chassis | ABS-Antilock brake system | ● | ● | ○ | ● | ● | ※ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|---------|-------------------------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | G-Class | 463(38-pin diagnostic socket) | Body | AB-Airbag | ● | ● | ○ | ● | | ※ |
| ALL | G-Class | 463(38-pin diagnostic socket) | Body | APS-Auto pilot system | ● | ● | ○ | ● | ● | ※ |
| ALL | G-Class | 463(38-pin diagnostic socket) | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ○ | ● | ● | ※ |
| ALL | G-Class | 463(38-pin diagnostic socket) | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ● |
| ALL | G-Class | 463(38-pin diagnostic socket) | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| ALL | G-Class | 463(38-pin diagnostic socket) | Information and communication | CTEL- Cellular telephone 1 (fixed installation or portable) (D2B) | ● | ● | ● | ● | ○ | ○ |
| ALL | G-Class | 463(38-pin diagnostic socket) | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ○ |
| ALL | G-Class | 463(38-pin diagnostic socket) | Information and communication | CDC-CD changer | ● | ● | ● | ● | ○ | ○ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|---------|-------------------------------|---------------------|-------------------------------------|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | G-Class | 463(38-pin diagnostic socket) | Air conditioning | STH-Stationary heater | ● | ● | ○ | ● | ● | ※ |
| ALL | G-Class | 461(16-pin diagnostic socket) | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| ALL | G-Class | 461(16-pin diagnostic socket) | Drive | ESM-Electronic selector module | ● | ● | ○ | ● | ● | ※ |
| ALL | G-Class | 461(16-pin diagnostic socket) | Drive | N15/7(Transfer case control module) | ● | ● | ● | ● | ● | ○ |
| ALL | G-Class | 461(16-pin diagnostic socket) | Drive | CDI 2-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| ALL | G-Class | 461(16-pin diagnostic socket) | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| ALL | G-Class | 461(16-pin diagnostic socket) | Drive | CDI 4-Common Rail Diesel Injection | ● | ● | ● | ● | ● | |
| ALL | G-Class | 461(16-pin diagnostic socket) | Drive | CDI 6-Common Rail Diesel Injection | ● | ● | ● | ● | ● | |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|----------|-------------------------------|-------------------------------|-------------------------------------|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | G-Class | 461(16-pin diagnostic socket) | Chassis | ABS-Antilock brake system | ● | ● | ● | ● | ● | ※ |
| ALL | G-Class | 461(16-pin diagnostic socket) | Chassis | Traction systems ABS | ● | ● | ● | ● | ● | |
| ALL | G-Class | 461(16-pin diagnostic socket) | Body | AB-Airbag | ● | ● | ○ | ● | ● | ※ |
| ALL | G-Class | 461(16-pin diagnostic socket) | Body | CGW-Central gateway | ● | ● | ● | ● | ● | ● |
| ALL | G-Class | 461(16-pin diagnostic socket) | Information and communication | WSP immobilizer | ● | ● | ● | ● | ● | ※ |
| ALL | G-Class | 461(16-pin diagnostic socket) | Information and communication | IC-Instrument cluster | ● | ● | ● | ● | ● | ※ |
| ALL | G-Class | 461(16-pin diagnostic socket) | Information and communication | AUDIO | ● | ● | ○ | ● | ○ | ● |
| ALL | G-Class | 461(16-pin diagnostic socket) | Air conditioning | STH-Stationary heater | ● | ● | ○ | ● | ● | ※ |
| ALL | GL-Class | X 164 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Drive | VG-Transfer case | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|----------|--------------|---------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | GL-Class | X 164 | Drive | HAQ-Interwheel differential lock at rear axle | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Drive | ISM-Intelligent servo module | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Drive | ISM-Shift module (A80) | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |
| ALL | GL-Class | X 164 | Drive | ME 9.7-Motor electronics 9.7 | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Drive | IRS-HRA-Outer right rear intelligent radar sensor | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Drive | IRS-HLA - Outer left rear intelligent radar sensor system | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Drive | TV-TV tuner | ● | ● | ● | ● | ● | |
| ALL | GL-Class | X 164 | Drive | CDI 4-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Drive | CDI 5-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Drive | CDI 6BIN5-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Drive | CDI 6-Common Rail Diesel Injection | ● | ● | ● | ● | ● | |
| ALL | GL-Class | X 164 | Drive | SCR-Selective Catalytic Reduction | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Drive | CDI 60LS-Common Rail Diesel Injection | ● | ● | ● | ● | ● | |
| ALL | GL-Class | X 164 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Chassis | EHPS-Electrohydraulic Power Steering | ● | ● | ● | ● | ● | |
| ALL | GL-Class | X 164 | Chassis | Suspension | ● | ● | ● | ● | ● | ○ |
| ALL | GL-Class | X 164 | Chassis | TPC-Tire pressure monitor | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Chassis | TPM - Tire pressure monitor(N88) | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Body | CGW-Central gateway | ● | ● | ● | ● | ○ | ○ |
| ALL | GL-Class | X 164 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ○ |
| ALL | GL-Class | X 164 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Body | KG-Keyless Go | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Body | KG-KEYLESS GO | ● | ● | ● | ● | ● | |
| ALL | GL-Class | X 164 | Body | AB-Airbag | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Body | WSS-Weight sensing system | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Body | UCP-Upper control panel | ● | ● | ● | ● | ● | ○ |
| ALL | GL-Class | X 164 | Body | HBF (Rear control panel)-Rear control field | ● | ● | ● | ● | ● | ○ |
| ALL | GL-Class | X 164 | Body | SAM-F-Signal acquisition and actuation module front | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Body | REAR SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ● | ○ |
| ALL | GL-Class | X 164 | Body | RevETR-RF-Right front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Body | RevETR-LF-Left front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | |
| ALL | GL-Class | X 164 | Body | RevETR-LF-Left front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Body | RevETR-LF-Left front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|----------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | GL-Class | X 164 | Body | HRA-Automatic headlamp range adjustment and headlamp control | ● | ● | ● | ● | ● | ○ |
| ALL | GL-Class | X 164 | Body | XALWA-L-Xenon headlamp, left | ● | ● | ● | ● | ● | |
| ALL | GL-Class | X 164 | Body | XALWA-L-Xenon headlamp, left | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Body | XALWA-R-Xenon headlamp, right | ● | ● | ● | ● | ● | |
| ALL | GL-Class | X 164 | Body | XALWA-R-Xenon headlamp, right | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Body | System diagnosis (CAN) | ● | ● | ○ | ● | ● | ● |
| ALL | GL-Class | X 164 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Information and communication | CM-Compass module | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Information and communication | IC-Instrument cluster | ● | ● | ● | ● | ● | ○ |
| ALL | GL-Class | X 164 | Information and communication | ASSYST-Active Service System | ● | ● | ○ | ● | ● | ○ |
| ALL | GL-Class | X 164 | Information and communication | ASSYST PLUS-PLUS Active Service System | ● | ● | ○ | ● | ● | ● |
| ALL | GL-Class | X 164 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ○ |
| ALL | GL-Class | X 164 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ○ |
| ALL | GL-Class | X 164 | Information and communication | RFK-Backup camera | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Information and communication | CDC-CD changer | ● | ● | ○ | ● | ● | ● |
| ALL | GL-Class | X 164 | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ● |
| ALL | GL-Class | X 164 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Information and communication | COMAND or AUDIO | ● | ● | ○ | ● | ● | ● |
| ALL | GL-Class | X 164 | Information and communication | TV-TV tuner | ● | ● | ○ | ● | ● | ● |
| ALL | GL-Class | X 164 | Information and communication | TV-TV tuner (AGW) | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Information and communication | SDAR-Satellite radio | ● | ● | ○ | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|----------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | GL-Class | X 164 | Information and communication | SOUND- Sound system | ● | ● | ○ | ● | ● | ● |
| ALL | GL-Class | X 164 | Information and communication | CTEL-Mobile phone adapter with universal interface | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Information and communication | NAVI-Navigation system | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Information and communication | AVE-H-Rear audio video unit | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Information and communication | CTEL-Cellular telephone | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Information and communication | COMAND or AUDIO | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Information and communication | Sound system (Main amplifier) | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Information and communication | UCI-Media interface | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Information and communication | DAB-Digital radio | ● | ● | ● | ● | ● | ○ |
| ALL | GL-Class | X 164 | Information and communication | SDAR-Satellite radio(Valid for USA) | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Information and communication | TV-TV tuner | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Information and communication | CTEL-Cellular telephone(JAPAN) | ● | ● | ● | ● | ● | ○ |
| ALL | GL-Class | X 164 | Information and communication | AVE-H-Rear audio video unit | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Information and communication | Left rear screen | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Information and communication | Right rear screen | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Information and communication | TELE AID-Control unit | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Information and communication | TELE AID-Telematic services Emergency call | ● | ● | ● | ● | | ● |
| ALL | GL-Class | X 164 | Information and communication | TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE) | ● | ● | ● | ● | | ● |
| ALL | GL-Class | X 164 | Information and communication | TELE AID-Telematic services Stolen vehicle tracking | ● | ● | ● | ● | | ● |
| ALL | GL-Class | X 164 | Information and communication | TELE AID-Telematic services Remote door unlocking, Remote door locking | ● | ● | ● | ● | | ● |
| ALL | GL-Class | X 164 | Seats and doors | DCM-FL-Door control module front left | ● | ● | ● | ● | ● | ○ |
| ALL | GL-Class | X 164 | Seats and doors | DCM-FR-Door control module front right | ● | ● | ● | ● | ● | ○ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|----------|--------------|---------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | GL-Class | X 164 | Seats and doors | ESA driver-Electric seat adjustment driver (with | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Seats and doors | ESA passenger-Electric seat adjustment passenger | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Seats and doors | DS-LF-Left front dynamic seat | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Seats and doors | DS-RF-Right front dynamic seat | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Seats and doors | DSP-Pneumatic pump for dynamic seat | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Seats and doors | ERA-Electric fold-down backrest system (3rd seat row) | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Seats and doors | REDC-Rear-end door closing control module | ● | ● | ● | ● | ● | ○ |
| ALL | GL-Class | X 164 | Seats and doors | REDC-Rear-end door closing control module | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Seats and doors | HS-Seat heater | ● | ● | ● | ● | ● | ○ |
| ALL | GL-Class | X 164 | Air conditioning | AAC-Automatic air conditioning | ● | ● | ● | ● | ● | ● |
| ALL | GL-Class | X 164 | Air conditioning | HSW-Heated steering wheel | ● | ● | ● | ● | ● | ○ |
| ALL | GL-Class | X 164 | Air conditioning | STH-Stationary heater with remote control | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Drive | ISM-Intelligent servo module | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Drive | ISM-Shift module (A80) | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |
| ALL | R-Class | 251 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Drive | ME 9.7-Motor electronics 9.7 | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Drive | IRS-HRA-Outer right rear intelligent radar sensor | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Drive | IRS-HLA - Outer left rear intelligent radar sensor system | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Drive | TV-TV tuner | ● | ● | ● | ● | ● | |
| ALL | R-Class | 251 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Drive | ME-SFI 2.8-Motor electronics 2.8 | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Drive | ME 9.7 (AMG)-Motor electronics 9.7 (AMG) | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Drive | FSCU Left-Control unit 'Left fuel pump' | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Drive | FSCU Right-Control unit 'Right fuel pump' | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Drive | CDI 4-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Drive | CDI 6BIN5-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Drive | CDI 6-Common Rail Diesel Injection | ● | ● | ● | ● | ● | |
| ALL | R-Class | 251 | Drive | SCR-Selective Catalytic Reduction | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Drive | CDI 60LS-Common Rail Diesel Injection | ● | ● | ● | ● | ● | |
| ALL | R-Class | 251 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Chassis | Suspension | ● | ● | ● | ● | ● | ○ |
| ALL | R-Class | 251 | Chassis | Suspension | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Chassis | TPC-Tire pressure monitor | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Chassis | TPM - Tire pressure monitor(N88) | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Chassis | EHPS-Electrohydraulic Power Steering | ● | ● | ● | ● | ● | |
| ALL | R-Class | 251 | Body | CGW-Central gateway | ● | ● | ● | ● | ○ | ○ |
| ALL | R-Class | 251 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ○ |
| ALL | R-Class | 251 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|---------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | R-Class | 251 | Body | KG-Keyless Go | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Body | KG-KEYLESS GO | ● | ● | ● | ● | ● | |
| ALL | R-Class | 251 | Body | AB-Airbag | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Body | WSS-Weight sensing system | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Body | UCP-Upper control panel | ● | ● | ● | ● | ● | ○ |
| ALL | R-Class | 251 | Body | HBF (Rear control panel)-Rear control field | ● | ● | ● | ● | ● | ○ |
| ALL | R-Class | 251 | Body | SAM-F-Signal acquisition and actuation module front | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Body | REAR SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ● | ○ |
| ALL | R-Class | 251 | Body | RevETR-RF-Right front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Body | RevETR-LF-Left front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | |
| ALL | R-Class | 251 | Body | RevETR-LF-Left front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Body | RevETR-LF-Left front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | |
| ALL | R-Class | 251 | Body | HRA-Automatic headlamp range adjustment and headlamp control | ● | ● | ● | ● | ● | ○ |
| ALL | R-Class | 251 | Body | HRA-FL-Front left headlamp range control | ● | ● | ● | ● | ● | |
| ALL | R-Class | 251 | Body | XALWA-R-Xenon headlamp, right | ● | ● | ● | ● | ● | |
| ALL | R-Class | 251 | Body | System diagnosis(CAN) | ● | ● | ○ | ● | ● | ● |
| ALL | R-Class | 251 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Information and communication | CM-Compass module | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Information and communication | IC-Instrument cluster | ● | ● | ● | ● | ● | ○ |
| ALL | R-Class | 251 | Information and communication | ASSYST-Active Service System | ● | ● | ○ | ● | ● | ○ |
| ALL | R-Class | 251 | Information and communication | ASSYST PLUS-PLUS Active Service System | ● | ● | ○ | ● | ● | ● |
| ALL | R-Class | 251 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ○ |
| ALL | R-Class | 251 | Information and communication | PTS-Parktronic system | ● | ● | ● | ● | ● | ○ |
| ALL | R-Class | 251 | Information and communication | RFK-Backup camera | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner) | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|---------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | R-Class | 251 | Information and communication | CDC-CD changer | ● | ● | ○ | ● | ● | ● |
| ALL | R-Class | 251 | Information and communication | VCS-Voice control system | ● | ● | ○ | ● | | ● |
| ALL | R-Class | 251 | Information and communication | AUDIO | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Information and communication | COMAND or AUDIO | ● | ● | ○ | ● | ● | ● |
| ALL | R-Class | 251 | Information and communication | TV-TV tuner | ● | ● | ○ | ● | ● | ● |
| ALL | R-Class | 251 | Information and communication | TV-TV tuner(AGW) | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Information and communication | SDAR-Satellite radio | ● | ● | ○ | ● | ● | ● |
| ALL | R-Class | 251 | Information and communication | SOUND- Sound system | ● | ● | ○ | ● | ● | ● |
| ALL | R-Class | 251 | Information and communication | CTEL-Mobile phone adapter with universal interface | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Information and communication | NAVI-Navigation system | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Information and communication | AVE-H-Rear audio video unit | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Information and communication | CTEL-Cellular telephone | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Information and communication | COMAND or AUDIO | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Information and communication | Sound system (Main amplifier) | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Information and communication | UCI-Media interface | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Information and communication | DAB-Digital radio | ● | ● | ● | ● | ● | ○ |
| ALL | R-Class | 251 | Information and communication | SDAR-Satellite radio(Valid for USA) | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Information and communication | TV-TV tuner | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Information and communication | CTEL-Cellular telephone(JAPAN) | ● | ● | ● | ● | ● | ○ |
| ALL | R-Class | 251 | Information and communication | AVE-H-Rear audio video unit | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Information and communication | Left rear screen | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|---------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | R-Class | 251 | Information and communication | Right rear screen | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Information and communication | TELE AID-Control unit | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Information and communication | TELE AID-Telematic services Emergency call | ● | ● | ● | ● | | ● |
| ALL | R-Class | 251 | Information and communication | TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE) | ● | ● | ● | ● | | ● |
| ALL | R-Class | 251 | Information and communication | TELE AID-Telematic services Stolen vehicle tracking | ● | ● | ● | ● | | ● |
| ALL | R-Class | 251 | Information and communication | TELE AID-Telematic services Remote door unlocking,Remote door locking | ● | ● | ● | ● | | ● |
| ALL | R-Class | 251 | Seats and doors | DCM-FL-Door control module front left | ● | ● | ● | ● | ● | ○ |
| ALL | R-Class | 251 | Seats and doors | DCM-FR-Door control module front right | ● | ● | ● | ● | ● | ○ |
| ALL | R-Class | 251 | Seats and doors | ESA driver-Electric seat adjustment driver (with | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Seats and doors | ESA passenger-Electric seat adjustment passenger | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Seats and doors | DS-LF-Left front dynamic seat | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Seats and doors | DS-RF-Right front dynamic seat | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Seats and doors | DSP-Pneumatic pump for dynamic seat | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Seats and doors | REDC-Rear-end door closing control module | ● | ● | ● | ● | ● | ○ |
| ALL | R-Class | 251 | Seats and doors | REDC-Rear-end door closing control module | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Seats and doors | HS-Seat heater | ● | ● | ● | ● | ● | ○ |
| ALL | R-Class | 251 | Air conditioning | AAC-Automatic air conditioning | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Air conditioning | STH-Stationary heater with remote control | ● | ● | ● | ● | ● | ● |
| ALL | R-Class | 251 | Air conditioning | HSW-Heated steering wheel | ● | ● | ● | ● | ● | ○ |
| ALL | E-Class | 212 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Drive | ME 9.7-Motor electronics 9.7 | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Drive | ME 9.7 (AMG)-Motor electronics 9.7 (AMG) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Drive | MED 17.7-Motor electronics for direct injection 17.7 | ● | ● | ● | ● | ● | |
| ALL | E-Class | 212 | Drive | ME-Motor electronics 'MED40' for combustion engine 'M270' (N3/10) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 212 | Drive | MED 9.7-Motor electronics for direct injection 9.7 | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Drive | ME-Motor electronics 'MED40CNG' for combustion engine 'M274' (N3/10) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 212 | Drive | ME - Motor electronics 'SIM271DE20' for combustion engine 'M271EVO' (N3/10) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Drive | ESM-Electronic selector module | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Drive | ISM-Shift module (A80) | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|---------|--------------|---------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | E-Class | 212 | Drive | mbrace-mbrace (N123/4) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 212 | Drive | SCR-Selective Catalytic Reduction | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ○ | ● |
| ALL | E-Class | 212 | Drive | CDI 6-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Drive | CDI 60LS-Common Rail Diesel Injection | ● | ● | ● | ● | ● | |
| ALL | E-Class | 212 | Drive | CDI 6-Common Rail Diesel Injection | ● | ● | ● | ● | ● | |
| ALL | E-Class | 212 | Drive | CDI 6-Common Rail Diesel Injection | ● | ● | ● | ● | ● | |
| ALL | E-Class | 212 | Drive | CDID-Common Rail Diesel Injection | ● | ● | ● | ● | ○ | ● |
| ALL | E-Class | 212 | Drive | CDI 3-Common Rail Diesel Injection3 | ● | ● | ● | ● | ● | |
| ALL | E-Class | 212 | Drive | CDI-Motor electronics 'CR42' for combustion engine 'OM607' (N3/9) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 212 | Drive | CDI-Motor electronics 'CR43' for combustion engine 'OM651' (N3/9) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 212 | Drive | CDI-Motor electronics 'CDI61' for combustion engine 'OM642' (N3/9) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 212 | Chassis | ES-Electrical power steering (N68) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 212 | Chassis | ESP-Electronic stability program (N30/4) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 212 | Chassis | ESP-Regenerative braking system (N30/6) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 212 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Chassis | TPC-Tire pressure monitor | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Chassis | TPM - Tire pressure monitor(N88) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Chassis | AIRMATIC-AIRMATIC | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |
| ALL | E-Class | 212 | Chassis | FWGW-Chassis gateway (N97/7) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 212 | Body | CGW-Central gateway | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Body | CGW[ZGW]-Central gateway (CGW[ZGW]) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 212 | Body | CGW-Central gateway | ● | ● | ● | ● | ▲ | ● |
| ALL | E-Class | 212 | Body | EZS-Electronic ignition lock | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Body | EZS-Electronic ignition lock (N73) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 212 | Body | KG-Keyless Go | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Body | KG-KEYLESS GO(N69/5) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Body | IRS-HRA-Outer right rear intelligent radar sensor | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 212 | Body | IRS-HLA-Outer left rear intelligent radar sensor system (B29/4) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 212 | Body | SRS-Supplemental restraint system (N2/10) | ● | ● | ● | ● | ▲ | ● |
| ALL | E-Class | 212 | Body | SRS-Supplemental restraint system | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Body | WSS-Weight sensing system | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Body | OCP-Overhead control panel(N70) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Body | PSD-Control mudule 'Panoramic sliding roof' (A98) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Body | SGR-Radar sensors control unit | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |
| ALL | E-Class | 212 | Body | SGR-Radar sensors control unit | ● | ● | ● | ● | ○ | ● |
| ALL | E-Class | 212 | Body | Dr-side SAM-Driver signal acquisition and actuation module | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|---------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | E-Class | 212 | Body | Driver-side SAM-Driver signal acquisition and actuation module | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Body | Driver-side SAM-Driver signal acquisition and actuation module | ● | ● | ● | ● | ▲ | |
| ALL | E-Class | 212 | Body | REAR SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Body | Rear SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ▲ | ▲ |
| ALL | E-Class | 212 | Body | BMS-Battery management system (N82/2) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 212 | Body | Trailer recognition module | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Body | Multifunction control unit-Multifunction control unit (N26/14) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Body | RevETR-LF-Left front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Body | RevETR-LF-Left front reversible emergency tensioning retractor (A76) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Body | RevETR-RF-Right front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Body | RevETR-RF-Right front reversible emergency tensioning retractor (A76/1) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Body | XALWA-L-Left xenon headlamp (E1n1) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Body | XALWA-R-Right xenon headlamp (E2n1) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Body | SG-AWF-Control unit 'COLLISION PREVENTION ASSIST' | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 212 | Body | KG-KEYLESS GO (N69/5) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 212 | Body | SG-EM-Power electronics (N129/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 212 | Body | RFK-Backup camera (B84/3) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 212 | Body | Rear SAM-Rear signal acquisition and actuation module | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 212 | Body | SCM-Steering column module (N80) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 212 | Information and communication | ES-Electrical power steering | ● | ● | ● | ● | ● | ○ |
| ALL | E-Class | 212 | Information and communication | AMG DRVU-AMG DRIVE UNIT (N145) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 212 | Information and communication | NSA-Night View Assist | ● | ● | ● | ● | ● | ○ |
| ALL | E-Class | 212 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Information and communication | IC-Instrument cluster (A1) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 212 | Information and communication | IC-Instrument cluster (A1) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 212 | Information and communication | ICI-InCar Internet (N125/3) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 212 | Information and communication | PTS-PARKTRONIC (N62) | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|---------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | E-Class | 212 | Information and communication | RFK-Backup camera(B84/3) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Information and communication | SCCM-Steering column module(N80) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Information and communication | COMAND or AUDIO | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Information and communication | COMAND or AUDIO | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Information and communication | COU [ZBE]-Central operating unit | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Information and communication | ZBE-Audio/COMAND operating unit(A40/9) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Information and communication | ZAN-Central display | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Information and communication | TV-TV tuner(AGW) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Information and communication | CTEL-Cellular telephone(JAPAN) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Information and communication | DAB-Digital radio | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Information and communication | DAB-Digital Audio Broadcasting (N87/3) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 212 | Information and communication | Sound system (Main amplifier) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Information and communication | SDAR-Satellite radio(Valid for USA) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Information and communication | UCI-Media interface | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Information and communication | AVE-H-Rear audio video unit | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Information and communication | Left rear screen | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Information and communication | Right rear screen | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Information and communication | TELE AID-Control unit | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Information and communication | TELE AID-Telematic services Emergency call | ● | ● | ● | ● | | ● |
| ALL | E-Class | 212 | Information and communication | TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE) | ● | ● | ● | ● | | ● |
| ALL | E-Class | 212 | Information and communication | TELE AID-Telematic services Stolen vehicle tracking | ● | ● | ● | ● | | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|---------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | E-Class | 212 | Information and communication | TELE AID-Telematic services Remote door unlocking, Remote door locking | ● | ● | ● | ● | | ● |
| ALL | E-Class | 212 | Information and communication | MFK-Multifunction camera | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |
| ALL | E-Class | 212 | Information and communication | DSI-DIRECT SELECT interface (N150) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 212 | Information and communication | Drive-side SAM-Front signal acquisition and actuation module (N10/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 212 | Information and communication | Audio-Audio or COMAND (A2-A40/3) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 212 | Information and communication | NAV-Navigation module (A2/30) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 212 | Information and communication | NSA-Night View Assist(N101) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 212 | Information and communication | PTS-Parktronic | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 212 | Information and communication | Sound system (Main amplifier) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Information and communication | Sound system (Bass amplifier) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Information and communication | 360° camera-360° camera(N148) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 212 | Information and communication | NAVI20 - Navigation(N125/2) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 212 | Seats and doors | DSP-Pneumatic pump for dynamic seat | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Seats and doors | DCU-LF-Left front door | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Seats and doors | DCU-RF-Right front door | ● | ● | ● | ● | ● | ▲ |
| ALL | E-Class | 212 | Seats and doors | DCU-LR-Left rear door | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Seats and doors | DCU-RR-Right rear door | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Seats and doors | AMKS-LF-Active multicontour seat(N32/19) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Seats and doors | AMKS-RF-Active multicontour seat(N32/22) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Seats and doors | TLC-Trunk lid control | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Seats and doors | ESA 'Driver' -Electric seat adjustment 'Driver' (N32/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 212 | Seats and doors | ESA driver | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Seats and doors | ESA' Front passenger' -Electric seat adjustment 'Front passenger' with memory function(N32/2) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 212 | Seats and doors | ESA passenger | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Seats and doors | ESA-Electirc seat adjustment 'Front passenger' (N32/2) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Seats and doors | SIH-FOND-Rear passenger compartment seat heater | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |
| ALL | E-Class | 212 | Air conditioning | Stationary heater | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Air conditioning | AAC-Air conditioniing | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 212 | Air conditioning | LRH-Steering wheel heater | ● | ● | ● | ● | ○ | ▲ |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|---------|--------------|---------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | E-Class | 212 | Air conditioning | EKMK-Electric refrigerant compressor (A9/5) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 212 | LIN Bus | LCP-Lower control panel (S77) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 212 | LIN Bus | AU-Analog clock (A70/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 212 | LIN Bus | GTO-Garage door opener (A67n2) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 207 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Drive | ETC-Electronic transmission control | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Drive | ME 9.7-Motor electronics 9.7 | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Drive | ME 9.7 (AMG)-Motor electronics 9.7 (AMG) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Drive | MED 17.7-Motor electronics for direct injection 17.7 | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Drive | MED 9.7-Motor electronics for direct injection 9.7 | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Drive | ME-Motor electronics 'MED40' for combustion engine 'M270' (N3/10) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 207 | Drive | ME-Motor electronics 'MED40CNG' for combustion engine 'M274' (N3/10) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 207 | Drive | ME - Motor electronics 'SIM271DE20' for combustion engine 'M271EVO' (N3/10) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Drive | ESM-Electronic selector module | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Drive | ISM-Shift module (A80) | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |
| ALL | E-Class | 207 | Drive | mbrace-mbrace (N123/4) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 207 | Drive | SCR-Selective Catalytic Reduction | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Drive | CDI 6-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Drive | CDI 60LS-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Drive | CDI 6-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Drive | CDI 6-Common Rail Diesel Injection | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Drive | CDID-Common Rail Diesel Injection | ● | ● | ● | ● | ○ | ● |
| ALL | E-Class | 207 | Drive | CDI 3-Common Rail Diesel Injection3 | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Drive | CDI-Motor electronics 'CR42' for combustion engine 'OM607' (N3/9) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 207 | Drive | CDI-Motor electronics 'CR43' for combustion engine 'OM651' (N3/9) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 207 | Drive | CDI-Motor electronics 'CDI61' for combustion engine 'OM642' (N3/9) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 207 | Chassis | ESP-Electronic stability program | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Chassis | ES-Electrical power steering (N68) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 207 | Chassis | ESP-Electronic stability program (N30/4) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 207 | Chassis | TPM - Tire pressure monitor (N88) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Chassis | AIRMATIC-AIRMATIC | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |
| ALL | E-Class | 207 | Chassis | AIRSCARF-AIRSCARF system (N25/7) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Chassis | FWGW-Chassis gateway (N97/7) | ● | ● | ○ | ● | ○ | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|---------|--------------|---------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | E-Class | 207 | Body | CGW-Central gateway | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Body | CGW[ZGW]-Central gateway (CGW[ZGW]) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 207 | Body | CGW-Central gateway | ● | ● | ● | ● | ▲ | ● |
| ALL | E-Class | 207 | Body | EZS-Electronic ignition switch | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Body | EZS-Electronic ignition lock (N73) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 207 | Body | KG-Keyless Go | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Body | KG-KEYLESS GO (N69/5) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Body | IRS-HRA-Outer right rear intelligent radar sensor | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 207 | Body | IRS-HLA-Outer left rear intelligent radar sensor system (B29/4) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 207 | Body | SRS-Supplemental restraint system | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Body | SRS-Supplemental restraint system (N2/10) | ● | ● | ● | ● | ▲ | ● |
| ALL | E-Class | 207 | Body | WSS-Weight sensing system | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Body | OCP-Overhead control panel | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Body | PSD-Control mudule 'Panoramic sliding roof' (A98) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Body | SGR-Radar sensors control unit | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |
| ALL | E-Class | 207 | Body | SGR-Radar sensors control unit | ● | ● | ● | ● | ○ | ● |
| ALL | E-Class | 207 | Body | Dr-side SAM-Driver signal acquisition and actuation module | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Body | Driver-side SAM-Driver signal acquisition and actuation module | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Body | Driver-side SAM-Driver signal acquisition and actuation module | ● | ● | ● | ● | ▲ | |
| ALL | E-Class | 207 | Body | REAR SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Body | Rear SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ▲ | ▲ |
| ALL | E-Class | 207 | Body | Rear SAM-Rear signal acquisition and actuation module | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 207 | Body | Trailer recognition module | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Body | RevETR-LF-Left front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Body | RevETR-LF-Left front reversible emergency tensioning retractor (A76) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Body | RevETR-RF-Right front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Body | RevETR-RF-Right front reversible emergency tensioning retractor (A76/1) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Body | XALWA-L-Left xenon headlamp (E1n1) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Body | XALWA-R-Right xenon headlamp (E2n1) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Body | BMS-Battery management system (N82/2) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 207 | Body | SG-AWF-Control unit 'COLLISION PREVENTION ASSIST' | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 207 | Body | KG-KEYLESS GO (N69/5) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 207 | Body | SG-EM-Power electronics (N129/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 207 | Body | RFK-Backup camera (B84/3) | ● | ● | ○ | ● | ○ | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|---------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | E-Class | 207 | Body | SCM-Steering column module(N80) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 207 | Information and communication | ES-Electrical power steering | ● | ● | ● | ● | ● | ○ |
| ALL | E-Class | 207 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Information and communication | IC-Instrument cluster (A1) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 207 | Information and communication | IC-Instrument cluster (A1) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 207 | Information and communication | ICI-InCar Internet (N125/3) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 207 | Information and communication | PTS-PARKTRONIC(N62) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Information and communication | RFK-Backup camera(B84/3) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Information and communication | SCCM-Steering column module(N80) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Information and communication | COMAND or AUDIO | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Information and communication | COMAND or AUDIO | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Information and communication | COU [ZBE]-Central operating unit | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Information and communication | ZBE-Audio/COMAND operating unit(A40/9) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Information and communication | ZAN-Central display | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Information and communication | TV-TV tuner(AGW) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Information and communication | CTEL-Cellular telephone(JAPAN) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Information and communication | DAB-Digital radio | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Information and communication | DAB-Digital Audio Broadcasting (N87/3) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 207 | Information and communication | Sound system (Main amplifier) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Information and communication | SDAR-Satellite radio(Valid for USA) | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|---------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | E-Class | 207 | Information and communication | UCI-Media interface | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Information and communication | TELE AID-Control unit | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Information and communication | TELE AID-Telematic services Emergency call | ● | ● | ● | ● | | ● |
| ALL | E-Class | 207 | Information and communication | TELE AID-Telematic services MB Info, Roadside assistance (USA, Canada), Tele diagnosis (ECE) | ● | ● | ● | ● | | ● |
| ALL | E-Class | 207 | Information and communication | TELE AID-Telematic services Stolen vehicle tracking | ● | ● | ● | ● | | ● |
| ALL | E-Class | 207 | Information and communication | TELE AID-Telematic services Remote door unlocking, Remote door locking | ● | ● | ● | ● | | ● |
| ALL | E-Class | 207 | Information and communication | SG-FOND-Rear control unit (N22/6) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Information and communication | MFK-Multifunction camera | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |
| ALL | E-Class | 207 | Information and communication | Left rear screen | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Information and communication | Right rear screen | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Information and communication | AMG DRVU-AMG DRIVE UNIT (N145) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 207 | Information and communication | DSI-DIRECT SELECT interface (N150) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 207 | Information and communication | Drive-side SAM-Front signal acquisition and actuation module (N10/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 207 | Information and communication | AVE-H-Rear audio video unit | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Information and communication | Audio-Audio or COMAND (A2-A40/3) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 207 | Information and communication | NAV-Navigation module (A2/30) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 207 | Information and communication | NSA-Night View Assist (N101) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 207 | Information and communication | PTS-Parktronic | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 207 | Information and communication | Sound system (Main amplifier) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Information and communication | Sound system (Bass amplifier) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Information and communication | 360° camera-360° camera (N148) | ● | ● | ○ | ● | ○ | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|---------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | E-Class | 207 | Information and communication | 360° camera-360° camera (N148) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 207 | Information and communication | NAVI20 - Navigation (N125/2) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 207 | Seats and doors | DCU-LF-Left front door | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Seats and doors | DCU-RF-Right front door | ● | ● | ● | ● | ● | ▲ |
| ALL | E-Class | 207 | Seats and doors | ESA 'Driver' -Electric seat adjustment 'Driver' (N32/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 207 | Seats and doors | ESA driver | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Seats and doors | ESA'Front passenger'-Electric seat adjustment 'Front passenger' with memory function (N32/2) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 207 | Seats and doors | ESA passenger | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Seats and doors | ESA-Electirc seat adjustment 'Front passenger' (N32/2) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Seats and doors | SIH-FOND-Rear passenger compartment seat heater | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |
| ALL | E-Class | 207 | Seats and doors | DSP-Pneumatic pump for dynamic seat | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Seats and doors | HKS-Tailgate control (N121/1) | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Air conditioning | Stationary heater | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Air conditioning | AAC-Air conditioining | ● | ● | ● | ● | ● | ● |
| ALL | E-Class | 207 | Air conditioning | EKMK-Electric refrigerant compressor (A9/5) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 207 | LIN Bus | LCP-Lower control panel (S77) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 207 | LIN Bus | AU-Analog clock (A70/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | E-Class | 207 | LIN Bus | GTO-Garage door opener (A67n2) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLS | 197 | Drive | ME 9.7 (AMG)-Motor electronics 9.7 (AMG) | ● | ● | ● | ● | ● | ● |
| ALL | SLS | 197 | Drive | ISM-Shift module (A80) | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |
| ALL | SLS | 197 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ○ | ● |
| ALL | SLS | 197 | Chassis | AIRSCARF-AIRSCARF system (N25/7) | ● | ● | ● | ● | ● | ● |
| ALL | SLS | 197 | Chassis | ESP-Electronic stability program (N30/4) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLS | 197 | Chassis | ESP-Electronic stability program (N30/4) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLS | 197 | Chassis | Electronic parking brake-Electric parking brake | ● | ● | ● | ● | ● | ● |
| ALL | SLS | 197 | Chassis | EHPS-Electrohydraulic Power Steering | ● | ● | ● | ● | ● | ● |
| ALL | SLS | 197 | Chassis | EFB-Electronic parking break (N128) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLS | 197 | Chassis | TPM - Tire pressure monitor (N88) | ● | ● | ● | ● | ● | ● |
| ALL | SLS | 197 | Body | CGW[ZGW]-Central gateway (CGW[ZGW]) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLS | 197 | Body | CGW-Central gateway | ● | ● | ● | ● | ● | ● |
| ALL | SLS | 197 | Body | CGW-Central gateway | ● | ● | ● | ● | ▲ | ● |
| ALL | SLS | 197 | Body | EZS-Electronic ignition lock | ● | ● | ● | ● | ● | ● |
| ALL | SLS | 197 | Body | BMS-Battery management system | ● | ● | ○ | ● | ○ | ● |
| ALL | SLS | 197 | Body | BMS-Battery management system | ● | ● | ○ | ● | ○ | ● |
| ALL | SLS | 197 | Body | BMS-Battery management system | ● | ● | ○ | ● | ○ | ● |
| ALL | SLS | 197 | Body | VDS-Soft top control (N52) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLS | 197 | Body | SRS-Supplemental restraint system | ● | ● | ● | ● | ● | ● |
| ALL | SLS | 197 | Body | DDW-DC/DC converter (N83/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLS | 197 | Body | IRS-HRA-Outer right rear intelligent radar sensor | ● | ● | ○ | ● | ○ | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|-------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | SLS | 197 | Body | IRS-HLA-Outer left rear intelligent radar sensor system (B29/4) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLS | 197 | Body | KG-Keyless Go | ● | ● | ● | ● | ● | ● |
| ALL | SLS | 197 | Body | WSS-Weight sensing system | ● | ● | ● | ● | ● | ● |
| ALL | SLS | 197 | Body | Driver-side SAM-Driver signal acquisition and actuation module | ● | ● | ● | ● | ● | ● |
| ALL | SLS | 197 | Body | Dr-side SAM-Driver signal acquisition and actuation module | ● | ● | ● | ● | ● | ● |
| ALL | SLS | 197 | Body | Driver-side SAM-Driver signal acquisition and actuation module | ● | ● | ● | ● | ▲ | |
| ALL | SLS | 197 | Body | REAR SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ● | ● |
| ALL | SLS | 197 | Body | Rear SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ▲ | ▲ |
| ALL | SLS | 197 | Body | Rear SAM-Rear signal acquisition and actuation module | ● | ● | ○ | ● | ○ | ● |
| ALL | SLS | 197 | Information and communication | AMG PM-AMG Performance Media(N125/2) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLS | 197 | Information and communication | COU [ZBE]-Central operating unit | ● | ● | ● | ● | ● | ● |
| ALL | SLS | 197 | Information and communication | IC-Instrument cluster (A1) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLS | 197 | Information and communication | IC-Instrument cluster (A1) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLS | 197 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ● |
| ALL | SLS | 197 | Information and communication | DAB-Digital Audio Broadcasting (N87/3) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLS | 197 | Information and communication | DAB-Digital radio | ● | ● | ● | ● | ● | ● |
| ALL | SLS | 197 | Information and communication | DKG-Electronic transmission control for double-plate clutch transmission (N15/13) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLS | 197 | Information and communication | ZAN-Central display | ● | ● | ● | ● | ● | ● |
| ALL | SLS | 197 | Information and communication | AMG DRVU-AMG DRIVE UNIT (N145) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLS | 197 | Information and communication | DSI-DIRECT SELECT interface (N150) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLS | 197 | Information and communication | Audio-Audio or COMAND (A2-A40/3) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLS | 197 | Information and communication | COMAND or AUDIO | ● | ● | ● | ● | ● | ● |
| ALL | SLS | 197 | Information and communication | PTS-PARKTRONIC(N62) | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|-------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | SLS | 197 | Information and communication | SCM [MRM]-Steering column module | ● | ● | ● | ● | ● | ● |
| ALL | SLS | 197 | Information and communication | SCCM-Steering column module(N80) | ● | ● | ● | ● | ● | ● |
| ALL | SLS | 197 | Information and communication | SDAR-Satellite radio(Valid for USA) | ● | ● | ● | ● | ● | ● |
| ALL | SLS | 197 | Information and communication | Sound system (Main amplifier) | ● | ● | ● | ● | ● | ● |
| ALL | SLS | 197 | Information and communication | Sound system (Main amplifier) | ● | ● | ● | ● | ● | ● |
| ALL | SLS | 197 | Information and communication | Sound system (Bass amplifier) | ● | ● | ● | ● | ● | ● |
| ALL | SLS | 197 | Information and communication | UCI-Media interface | ● | ● | ● | ● | ● | ● |
| ALL | SLS | 197 | Information and communication | TELE AID-Control unit | ● | ● | ● | ● | ● | ● |
| ALL | SLS | 197 | Information and communication | TELE AID-Telematic services Emergency call | ● | ● | ● | ● | | ● |
| ALL | SLS | 197 | Information and communication | TELE AID-Telematic services Remote door unlocking, Remote door locking | ● | ● | ● | ● | | ● |
| ALL | SLS | 197 | Information and communication | TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE) | ● | ● | ● | ● | | ● |
| ALL | SLS | 197 | Information and communication | TELE AID-Telematic services Stolen vehicle tracking | ● | ● | ● | ● | | ● |
| ALL | SLS | 197 | Seats and doors | DCU-LF-Left front door | ● | ● | ● | ● | ● | ● |
| ALL | SLS | 197 | Seats and doors | DCU-RF-Right front door | ● | ● | ● | ● | ● | ▲ |
| ALL | SLS | 197 | Seats and doors | ESA 'Driver'-Electric seat adjustment 'Driver' (N32/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLS | 197 | Seats and doors | ESA driver | ● | ● | ● | ● | ● | ● |
| ALL | SLS | 197 | Seats and doors | ESA' Front passenger'-Electric seat adjustment 'Front passenger' with memory function(N32/2) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLS | 197 | Seats and doors | ESA passenger | ● | ● | ● | ● | ● | ● |
| ALL | SLS | 197 | Air conditioning | EKMK-Electric refrigerant compressor (A9/5) | ● | ● | ● | ● | ● | |
| ALL | SLS | 197 | Air conditioning | AAC-Air conditioning (N22/7) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLS | 197 | LIN Bus | GTO-Garage door opener (A67n2) | ● | ● | ○ | ● | ○ | ● |
| ALL | SLS | 197 | LIN Bus | BSN-Battery sensor (B95) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | Drive | PTCU-Common powertrain controller(N127) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | Drive | ME-Motor electronics 'MED40' for combustion engine 'M270' (N3/10) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | Drive | ME-Motor electronics 'MED40AMG' for combustion engine 'M133' (N3/10) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ● | ● |
| ALL | CLA | 117 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ● | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|-------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | CLA | 117 | Drive | mbrace-mbrace (N123/4) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | Drive | SCR-Selective Catalytic Reduction | ● | ● | ● | ● | ● | ● |
| ALL | CLA | 117 | Drive | PTCU-Common powertrain controller(N127) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | Drive | CDI 3-Common Rail Diesel Injection3 | ● | ● | ● | ● | ● | |
| ALL | CLA | 117 | Drive | CDI-Motor electronics 'CRR1' for combustion engine 'OM607' (N3/9) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | Chassis | ES-Electrical power steering (N68) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | Chassis | ESP-Electronic stability program (N30/4) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | Chassis | TPM-Tire pressure monitor | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | Chassis | EPB-Electronic parking break (N128) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | Chassis | DTR-DISTRONIC (A89) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | Chassis | DTR-DISTRONIC (A89) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | Body | EZS-Electronic ignition switch | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | Body | SAM-Signal acquisition and actuation module (N10) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | Body | SG-AWF-Control unit 'COLLISION PREVENTION ASSIST' | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | Body | SG-SW-Control unit 'Headlamp' (N71/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | Body | IRS-HRA-Outer right rear intelligent radar sensor | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | Body | IRS-HLA-Outer left rear intelligent radar sensor system (B29/4) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | Body | SRS-Supplemental restraint system (N2/10) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | Body | RevETR-LF-Left front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |
| ALL | CLA | 117 | Body | RevETR-RF-Right front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |
| ALL | CLA | 117 | Body | SCM-Steering column module(N80) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | Body | Trailer recognition module-Trailer recognition(N28/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | Body | PSD-Control module 'Panoramic sliding roof (A98)' | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | Body | ATA-ATA[EDW]/tow-away protection/interior protection(N26/6) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | Information and communication | KAB-Control unit 'Camera cover' (N42) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | Information and communication | COU [ZBE]-Central operating unit | ● | ● | ● | ● | ● | ● |
| ALL | CLA | 117 | Information and communication | IC-Instrument cluster (A1) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | Information and communication | IC-Instrument cluster (A1) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ● |
| ALL | CLA | 117 | Information and communication | DAB-Digital Audio Broadcasting (N87/3) | ● | ● | ○ | ● | ○ | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|-------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | CLA | 117 | Information and communication | DAB-Digital radio | ● | ● | ● | ● | ● | ● |
| ALL | CLA | 117 | Information and communication | DKG-Electronic transmission control for double-plate clutch transmission (N15/13) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | Information and communication | ZAN-Central display | ● | ● | ● | ● | ● | ● |
| ALL | CLA | 117 | Information and communication | DSI-DIRECT SELECT interface (N150) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | Information and communication | MPK-Multifunction camera | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |
| ALL | CLA | 117 | Information and communication | Audio-Audio or COMAND (A2-A40/3) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | Information and communication | NAV-Navigation module (A2/30) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | Information and communication | PTS-Parktronic | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | Information and communication | SDAR-Satellite radio(Valid for USA) | ● | ● | ● | ● | ● | ● |
| ALL | CLA | 117 | Information and communication | SOUND - Sound system(N40/3) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | Information and communication | Sound system (Main amplifier) | ● | ● | ● | ● | ● | ● |
| ALL | CLA | 117 | Information and communication | TV-TV tuner(AGW) | ● | ● | ● | ● | ● | ● |
| ALL | CLA | 117 | Information and communication | UCI-Media interface | ● | ● | ● | ● | ● | ● |
| ALL | CLA | 117 | Information and communication | Audio-Audio 5 USB(A2) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | Seats and doors | DCU-LF-Left front door (N69/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | Seats and doors | DCU-RF-Right front door (N69/2) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | Seats and doors | ESA 'Driver' -Electrical seat adjustment 'Driver' with memory function(N32/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | Seats and doors | ESA' Front passenger' -Electric seat adjustment 'Front passenger' with memory function(N32/2) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | Air conditioning | AAC-Air conditioning (N22/7) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | Air conditioning | STH-Stationary heater (A6n1) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | LIN Bus | AISP-Dimming inside rearview mirror (A67) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | LIN Bus | UCP-Upper control panel (N72/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | LIN Bus | GTO-Garage door opener (A67n2) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | LIN Bus | BSN-Battery sensor (B95) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | LIN Bus | AMLAB-L 1-Actuation module 1, LED exterior lighting, left front (E1n7) | ● | ● | ○ | ● | ○ | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|---------|--------------|---------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | CLA | 117 | LIN Bus | AMLAB-R 1-Actuation module 1, LED exterior lighting, right front (E2n7) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | LIN Bus | RGLS-Rain/light sensor (B38/2) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | LIN Bus | OCP-Control unit 'Overhead control panel' (N70) | ● | ● | ○ | ● | ○ | ● |
| ALL | CLA | 117 | LIN Bus | AS-Alarm siren(H3/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | Drive | PTCU-Common powertrain controller(N127) | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | Drive | PTCU-Common powertrain controller(N127) | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | Drive | ME-Motor electronics 'MED40' for combustion engine 'M270' (N3/10) | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | Drive | ME-Motor electronics 'MED40AMG' for combustion engine 'M133' (N3/10) | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ● | ● |
| ALL | A-Class | 176 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ● | ● |
| ALL | A-Class | 176 | Drive | mbrace-mbrace (N123/4) | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | Drive | SCR-Selective Catalytic Reduction | ● | ● | ● | ● | ● | ● |
| ALL | A-Class | 176 | Drive | CDI 3-Common Rail Diesel Injection3 | ● | ● | ● | ● | ● | |
| ALL | A-Class | 176 | Drive | CDI-Motor electronics 'CRR1' for combustion engine 'OM607' (N3/9) | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | Chassis | ES-Electrical power steering (N68) | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | Chassis | ESP-Electronic stability program (N30/4) | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | Chassis | EFB-Electronic parking break (N128) | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | Chassis | DTR-DISTRONIC (A89) | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | Chassis | DTR-DISTRONIC (A89) | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | Chassis | TPM-Tire pressure monitor | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | Body | EZS-Electronic ignition switch | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | Body | SAM-Signal acquisition and actuation module (N10) | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | Body | IRS-HRA-Outer right rear intelligent radar sensor | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | Body | IRS-HLA-Outer left rear intelligent radar sensor system (B29/4) | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | Body | SG-AWF-Control unit 'COLLISION PREVENTION ASSIST' | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | Body | SG-SW-Control unit 'Headlamp' (N71/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | Body | SRS-Supplemental restraint system (N2/10) | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | Body | RevETR-LF-Left front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |
| ALL | A-Class | 176 | Body | RevETR-RF-Right front reversible emergency tensioning retractor | ● | ● | ● | ● | ● | ● |
| ALL | A-Class | 176 | Body | SCM-Steering column module(N80) | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | Body | Trailer recognition module-Trailer recognition(N28/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | Body | PSD-Control module 'Panoramic sliding roof (A98)' | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | Body | ATA-ATA[EDW]/tow-away protection/interior protection(N26/6) | ● | ● | ○ | ● | ○ | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|---------|--------------|-------------------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | A-Class | 176 | Information and communication | IC-Instrument cluster (A1) | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | Information and communication | IC-Instrument cluster (A1) | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ● |
| ALL | A-Class | 176 | Information and communication | COU [ZBE]-Central operating unit | ● | ● | ● | ● | ● | ● |
| ALL | A-Class | 176 | Information and communication | DAB-Digital Audio Broadcasting (N87/3) | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | Information and communication | DAB-Digital radio | ● | ● | ● | ● | ● | ● |
| ALL | A-Class | 176 | Information and communication | DKG-Electronic transmission control for double-plate clutch transmission (N15/13) | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | Information and communication | ZAN-Central display | ● | ● | ● | ● | ● | ● |
| ALL | A-Class | 176 | Information and communication | DSI-DIRECT SELECT interface (N150) | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | Information and communication | Audio-Audio or COMAND (A2-A40/3) | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | Information and communication | MFK-Multifunction camera | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |
| ALL | A-Class | 176 | Information and communication | NAV-Navigation module (A2/30) | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | Information and communication | PTS-PARKTRONIC (N62) | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | Information and communication | SDAR-Satellite radio(Valid for USA) | ● | ● | ● | ● | ● | ● |
| ALL | A-Class | 176 | Information and communication | SOUND - Sound system(N40/3) | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | Information and communication | Sound system (Main amplifier) | ● | ● | ● | ● | ● | ● |
| ALL | A-Class | 176 | Information and communication | TV-TV tuner(AGW) | ● | ● | ● | ● | ● | ● |
| ALL | A-Class | 176 | Information and communication | UCI-Media interface | ● | ● | ● | ● | ● | ● |
| ALL | A-Class | 176 | Information and communication | Audio-Audio 5 USB(A2) | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | Seats and doors | DCU-LF-Left front door (N69/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | Seats and doors | DCU-RF-Right front door (N69/2) | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | Seats and doors | ESA 'Driver' -Electrical seat adjustment 'Driver' with memory function(N32/1) | ● | ● | ○ | ● | ○ | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|---------|--------------|---------------------|---|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | A-Class | 176 | Seats and doors | ESA' Front passenger' -Electric seat adjustment 'Front passenger' with memory function(N32/2) | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | Air conditioning | AAC-Air conditioning (N22/7) | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | Air conditioning | STH-Stationary heater (A6n1) | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | LIN Bus | UCP-Upper control panel (N72/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | LIN Bus | BSN-Battery sensor (B95) | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | LIN Bus | AISP-Dimming inside rearview mirror (A67) | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | LIN Bus | GTO-Garage door opener (A67n2) | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | LIN Bus | AMLAB-L 1-Actuation module 1, LED exterior lighting, left front (E1n7) | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | LIN Bus | AMLAB-R 1-Actuation module 1, LED exterior lighting, right front (E2n7) | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | LIN Bus | RGLS-Rain/light sensor (B38/2) | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | LIN Bus | OCP-Control unit 'Overhead control panel' (N70) | ● | ● | ○ | ● | ○ | ● |
| ALL | A-Class | 176 | LIN Bus | AS-Alarm siren(H3/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | SL | 231 | Drive | ME-Motor electronics 'ME1778' for combustion engine 'M277' (N3/10) | ● | ● | ○ | ● | ○ | ● |
| ALL | SL | 231 | Drive | MED 17.7-Motor electronics for direct injection 17.7 | ● | ● | ● | ● | ● | |
| ALL | SL | 231 | Drive | DTR-Distronic | ● | ● | ● | ● | ● | ● |
| ALL | SL | 231 | Drive | ISM-Shift module (A80) | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |
| ALL | SL | 231 | Drive | FSCU-Fuel pump | ● | ● | ● | ● | ● | ● |
| ALL | SL | 231 | Drive | mbrace-mbrace (N123/4) | ● | ● | ○ | ● | ○ | ● |
| ALL | SL | 231 | Chassis | ABC-ABC (N51/2) | ● | ● | ○ | ● | ○ | ● |
| ALL | SL | 231 | Chassis | ESP-Electronic stability program (N30/4) | ● | ● | ○ | ● | ○ | ● |
| ALL | SL | 231 | Chassis | AIRSCARF-AIRSCARF system (N25/7) | ● | ● | ● | ● | ● | ● |
| ALL | SL | 231 | Chassis | EFB-Electronic parking break (N128) | ● | ● | ○ | ● | ○ | ● |
| ALL | SL | 231 | Chassis | TPM-Tire pressure monitor | ● | ● | ○ | ● | ○ | ● |
| ALL | SL | 231 | Body | CGW[ZGW]-Central gateway (CGW[ZGW]) | ● | ● | ○ | ● | ○ | ● |
| ALL | SL | 231 | Body | CGW-Central gateway | ● | ● | ● | ● | ● | ● |
| ALL | SL | 231 | Body | CGW-Central gateway | ● | ● | ● | ● | ▲ | ● |
| ALL | SL | 231 | Body | EZS-Electronic ignition lock (N73) | ● | ● | ○ | ● | ○ | ● |
| ALL | SL | 231 | Body | SRS-Supplemental restraint system (N2/10) | ● | ● | ● | ● | ▲ | ● |
| ALL | SL | 231 | Body | SGR-Radar sensors control unit | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |
| ALL | SL | 231 | Body | VDS-Vario roof control (N52) | ● | ● | ○ | ● | ○ | ● |
| ALL | SL | 231 | Body | SG-SW-Control unit 'Headlamp' (N71/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | SL | 231 | Body | KG-KEYLESS GO | ● | ● | ● | ● | ● | |
| ALL | SL | 231 | Body | KG-KEYLESS GO (N69/5) | ● | ● | ○ | ● | ○ | ● |
| ALL | SL | 231 | Body | MSC-MAGIC SKY CONTROL (N53) | ● | ● | ○ | ● | ○ | ● |
| ALL | SL | 231 | Body | RevETR-LF-Left front reversible emergency tensioning retractor (A76) | ● | ● | ○ | ● | ○ | ● |
| ALL | SL | 231 | Body | RevETR-RF-Right front reversible emergency tensioning retractor (A76/1) | ● | ● | ○ | ● | ○ | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|-------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | SL | 231 | Body | Driver-side SAM-Driver signal acquisition and actuation module | ● | ● | ● | ● | ● | ● |
| ALL | SL | 231 | Body | Dr-side SAM-Driver signal acquisition and actuation module | ● | ● | ● | ● | ● | ● |
| ALL | SL | 231 | Body | Driver-side SAM-Driver signal acquisition and actuation module | ● | ● | ● | ● | ▲ | |
| ALL | SL | 231 | Body | REAR SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ● | ● |
| ALL | SL | 231 | Body | Rear SAM-Rear signal acquisition and actuation module | ● | ● | ● | ● | ▲ | ▲ |
| ALL | SL | 231 | Body | Rear SAM-Rear signal acquisition and actuation module | ● | ● | ○ | ● | ○ | ● |
| ALL | SL | 231 | Body | SCM-Steering column module (N80) | ● | ● | ○ | ● | ○ | ● |
| ALL | SL | 231 | Body | SGR-Radar sensors control unit | ● | ● | ● | ● | ○ | ● |
| ALL | SL | 231 | Information and communication | AMG PM-AMG Performance Media (N125/2) | ● | ● | ○ | ● | ○ | ● |
| ALL | SL | 231 | Information and communication | ES-Electrical power steering | ● | ● | ● | ● | ● | ○ |
| ALL | SL | 231 | Information and communication | IC-Instrument cluster (A1) | ● | ● | ○ | ● | ○ | ● |
| ALL | SL | 231 | Information and communication | IC-Instrument cluster (A1) | ● | ● | ○ | ● | ○ | ● |
| ALL | SL | 231 | Information and communication | ICM-Instrument cluster with maintenance interval display | ● | ● | ● | ● | ● | ● |
| ALL | SL | 231 | Information and communication | COU [ZBE]-Central operating unit | ● | ● | ● | ● | ● | ● |
| ALL | SL | 231 | Information and communication | DAB-Digital Audio Broadcasting (N87/3) | ● | ● | ○ | ● | ○ | ● |
| ALL | SL | 231 | Information and communication | DAB-Digital radio | ● | ● | ● | ● | ● | ● |
| ALL | SL | 231 | Information and communication | ZAN-Central display | ● | ● | ● | ● | ● | ● |
| ALL | SL | 231 | Information and communication | AMG DRVU-AMG DRIVE UNIT (N145) | ● | ● | ○ | ● | ○ | ● |
| ALL | SL | 231 | Information and communication | DSI-DIRECT SELECT interface (N150) | ● | ● | ○ | ● | ○ | ● |
| ALL | SL | 231 | Information and communication | Audio-Audio or COMAND (A2-A40/3) | ● | ● | ○ | ● | ○ | ● |
| ALL | SL | 231 | Information and communication | MFK-Multifunction camera | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ |
| ALL | SL | 231 | Information and communication | NSA-Night View Assist (N101) | ● | ● | ○ | ● | ○ | ● |
| ALL | SL | 231 | Information and communication | PTS-PARKTRONIC (N62) | ● | ● | ○ | ● | ○ | ● |

| Model year | Model | Model Series | Control Unit Groups | System Name | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame |
|------------|-------|--------------|-------------------------------|--|-----------|------------|--------------|-------------|-----------|--------------|
| ALL | SL | 231 | Information and communication | SDAR-Satellite radio(Valid for USA) | ● | ● | ● | ● | ● | ● |
| ALL | SL | 231 | Information and communication | SOUND - Sound system(N40/3) | ● | ● | ○ | ● | ○ | ● |
| ALL | SL | 231 | Information and communication | Sound system (Main amplifier) | ● | ● | ● | ● | ● | ● |
| ALL | SL | 231 | Information and communication | Sound system (Bass amplifier) | ● | ● | ● | ● | ● | ● |
| ALL | SL | 231 | Information and communication | TV-TV tuner(AGW) | ● | ● | ● | ● | ● | ● |
| ALL | SL | 231 | Information and communication | UCI-Media interface | ● | ● | ● | ● | ● | ● |
| ALL | SL | 231 | Seats and doors | DCU-LF-Left front door (N69/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | SL | 231 | Seats and doors | DCU-RF-Right front door (N69/2) | ● | ● | ○ | ● | ○ | ● |
| ALL | SL | 231 | Seats and doors | DS-LF-Left front dynamic seat | ● | ● | ● | ● | ● | ● |
| ALL | SL | 231 | Seats and doors | DS-RF-Right front dynamic seat | ● | ● | ● | ● | ● | ● |
| ALL | SL | 231 | Seats and doors | DSP-Pneumatic pump for dynamic seat | ● | ● | ● | ● | ● | ● |
| ALL | SL | 231 | Seats and doors | ESA 'Driver'-Electrical seat adjustment 'Driver' with memory function(N32/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | SL | 231 | Seats and doors | ESA' Front passenger'-Electric seat adjustment 'Front passenger' with memory function(N32/2) | ● | ● | ○ | ● | ○ | ● |
| ALL | SL | 231 | Air conditioning | AAC-Air conditioning (N22/7) | ● | ● | ○ | ● | ○ | ● |
| ALL | SL | 231 | LIN Bus | AU-Analog clock (A70/1) | ● | ● | ○ | ● | ○ | ● |
| ALL | SL | 231 | LIN Bus | BFS LSE-Lumbar support 'Front passenger seat' (N32/24) | ● | ● | ○ | ● | ○ | ● |
| ALL | SL | 231 | LIN Bus | GTO-Garage door opener (A67n2) | ● | ● | ○ | ● | ○ | ● |
| ALL | SL | 231 | LIN Bus | AMLAB-L 1-Actuation module 1, LED exterior lighting, left front (E1n7) | ● | ● | ○ | ● | ○ | ● |
| ALL | SL | 231 | LIN Bus | AMLAB-R 1-Actuation module 1, LED exterior lighting, right front (E2n7) | ● | ● | ○ | ● | ○ | ● |
| ALL | SL | 231 | LIN Bus | OCP-Overhead control panel(N70) | ● | ● | ○ | ● | ○ | ● |