

## MaxiDiag\_Citroen\_V2.00 Function List (Note:For reference only)

### NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.
- ▲ This function is the new feature in this version.

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data
BERLINGO	Injection	Petrol engine	1.1 L HDY/HDZ BOSCH MA3.1	●			●
BERLINGO	Injection	Petrol engine	1.4 L KFX MM1AP	●			●
BERLINGO	Injection	Petrol engine	1.8 L LFX MM1AP	●			●
BERLINGO	Injection	Petrol engine	1.1 L HDY/HDZ BOSCH MA3.1	●			●
BERLINGO	Injection	Petrol engine	1.1 L HFX BOSCH M7.4.4	●	●	●	●
BERLINGO	Injection	Petrol engine	1.4 L KFW SAGEM S2000	●			●
BERLINGO	Injection	Petrol engine	1.4 L KFW SAGEM S2000	●			●
BERLINGO	Injection	Petrol engine	1.4L KFX SAGEM SL96	●			●
BERLINGO	Injection	Petrol engine	1.4 L KFX BOSCH MP7.3	●			●
BERLINGO	Injection	Petrol engine	1.8 L LFX MM1AP	●			●
BERLINGO	Injection	Diesel engine	2.0 L RHY BOSCH EDC15C2	●	●	●	●
BERLINGO	Injection	Diesel engine	1.9 L WJY LUCAS DCN2	●	●	●	●
BERLINGO	Anti-lock brake system	ABS electronic distribution		●			●
BERLINGO	Injection	Diesel engine	RHY SIEMENS SID801	●	●	●	●
BERLINGO	Airbag			●			
BERLINGO	BSI			●			●
BERLINGO	Radio post-equipment			●			●
BERLINGO	CD player			●			●
BERLINGO	Instrument panel			●			●
BERLINGO	Airbag	Airbag TRW		●			
BERLINGO	Airbag	Airbag AUTOLIV		●			
BERLINGO (B9)	ABS	ESP8.1_BOSCH		●	●	●	●
BERLINGO (B9)	ABS	ABS8.1_BOSCH		●	●	●	●
BERLINGO (B9)	Injection	Petrol engine	MEV174	●	●	●	●
BERLINGO (B9)	Injection	Petrol engine	NFU BOSCH ME745	●	●	●	●
BERLINGO (B9)	Injection	Petrol engine	N6A BOSCH ME745	●	●	●	●
BERLINGO (B9)	Injection	Petrol engine	NFS BOSCH ME745	●	●	●	●
BERLINGO (B9)	Injection	Petrol engine	NFR BOSCH ME745	●	●	●	●
BERLINGO (B9)	Injection	Diesel engine	9HT BOSCH EDC16C34 DV6BUTED4-75CV	●	●	●	●
BERLINGO (B9)	Injection	Diesel engine	9HT BOSCH EDC16C34 DV6BTED4-75CV	●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data
BERLINGO (B9)	Injection	Diesel engine	9HZ (FAP) BOSCH EDC16C34 DV6TED4-110CV	●	●	●	●
BERLINGO (B9)	Injection	Diesel engine	9HX BOSCH EDC16C34 DV6AUTED4- 90CV	●	●	●	●
BERLINGO (B9)	Injection	Diesel engine	9HX BOSCH EDC16C34 DV6ATED4- 90CV	●	●	●	●
BERLINGO (B9)	Injection	Diesel engine	9HV FAP BOSCH EDC16C34 DV6TED4B-90CV	●	●	●	●
BERLINGO (B9)	Injection	Diesel engine	9HS FAP BOSCH EDC16C34 DV6TED4BU-90CV	●	●	●	●
BERLINGO (B9)	BSI			●	●	●	●
BERLINGO (B9)	Instrument panel			●	●	●	●
BERLINGO (B9)	Radio	Radio post-equipment		●	●	●	●
BERLINGO (B9)	CD player			●	●	●	
BERLINGO (B9)	Parking aid			●	●	●	●
BERLINGO (B9)	Air conditioning			●	●	●	●
BERLINGO (B9)	Switch module under the steering wheel			●	●	●	●
BERLINGO (B9)	Alarm			●	●	●	●
BERLINGO (B9)	Trailer relay unit			●	●	●	●
BERLINGO (B9)	Engine relay unit			●	●	●	●
BERLINGO (B9)	Rain sensor/ Brightness			●	●	●	
BERLINGO (B9)	Airbag			●	●	●	●
BERLINGO (B9)	Multifunction screen(EMF)	Type "A" (segments)		●	●	●	●
BERLINGO (B9)	Multifunction screen(EMF)	Type "C" (dot matrix)		●	●	●	●
BERLINGO (B9)	Telematic	RNEG navigation radio		●	●	●	●
BERLINGO (B9)	Multiplexed diesel additive pump			●	●	●	●
BERLINGO (B9)	Power steering	Electric pump unit(GEP)		●	●	●	●
BERLINGO (B9)	Hands Free Kit	Mobile Housing		●	●	●	●
BERLINGO (B9)	Bodywork Conversion Unit			●	●	●	●
BERLINGO (B9)	Deflation detection			●	●	●	●
BERLINGO (B9)	Anti-slip mode selector			●			●
BERLINGO 2	Anti-lock brake system	ABS8.1_BOSCH		●	●	●	●
BERLINGO 2	Anti-lock brake system	ABS8_BOSCH			●	●	
BERLINGO 2	Anti-lock brake system	ABR5.3		●			●
BERLINGO 2	Injection	Petrol engine	TU3A J34P	●	●	●	●
BERLINGO 2	Injection	Petrol engine	MM48P	●	●	●	●
BERLINGO 2	Injection	Petrol engine	ME749	●	●	●	●
BERLINGO 2	Injection	Petrol engine	2.0L RFN MM48P	●	●	●	●
BERLINGO 2	Injection	Petrol engine	NFU BOSCH ME744	●	●	●	●
BERLINGO 2	Injection	Petrol engine	KFV SAGEM S2000PM1		●	●	

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data
BERLINGO 2	Injection	Petrol engine	KFV SAGEM S2000PM2		●	●	
BERLINGO 2	Injection	Petrol engine	NFS BOSCH ME745	●	●	●	●
BERLINGO 2	Anti-lock brake system	ESP8.1_BOSCH		●	●	●	●
BERLINGO 2	Anti-lock brake system	ESP_BOSCH5.7		●	●	●	●
BERLINGO 2	Anti-lock brake system	ESP8_BOSCH			●	●	
BERLINGO 2	Injection	Petrol engine	NFU BOSCH ME745	●	●	●	●
BERLINGO 2	Injection	Petrol engine	N6A BOSCH ME745	●	●	●	●
BERLINGO 2	Injection	Petrol engine	NFR BOSCH ME745	●	●	●	●
BERLINGO 2	Injection	Diesel engine	9HX BOSCH EDC16C34 DV6ATED4	●	●	●	●
BERLINGO 2	Injection	Diesel engine	RHY SIEMENS SID801	●	●	●	●
BERLINGO 2	Injection	Diesel engine	RHY SIEMENS SID801		●	●	
BERLINGO 2	Injection	Diesel engine	WJY DCN2	●	●	●	●
BERLINGO 2	BSI			●	●	●	●
BERLINGO 2	Instrument panel			●	●	●	●
BERLINGO 2	Radio post-equipment			●	●	●	●
BERLINGO 2	CD player			●	●	●	●
BERLINGO 2	Parking aid			●	●	●	●
BERLINGO 2	Alarm			●	●	●	
BERLINGO 2	Switch module at the steering wheel	Top of column			●	●	
BERLINGO 2	Rain sensor/ Brightness			●	●	●	●
BERLINGO 2	Airbag			●	●	●	
BERLINGO 2	Display or Telematics	Multifunction display SAGEM A		●	●	●	●
BERLINGO 2	Display or Telematics	Multifunction display SAGEM B		●	●	●	●
BERLINGO 2	Display or Telematics	Telematics unit		●	●	●	●
BERLINGO 2	Gas injection	SAX500_GPL			●	●	
BERLINGO 2	Gas injection	SAX500_GNV			●	●	
BERLINGO 2	additional heating			●	●	●	●
C1	ABS	ABS anti-lock braking system			●	●	●
C1	ABS	ESP S2000 ABS			●	●	●
C1	Injection	Petrol engine	384 F injection		●	●	●
C1	Injection	Diesel engine	DV4 injection	●	●	●	●
C1	Gearbox ECU	Sequential manual gearbox (MMT)			●	●	●
C1	Airbag			●	●	●	●
C1	Immobiliser control module( Immobiliser)				●	●	●
C1	Electric power steering			●	●	●	●
C15	Engine	Diesel engine	1.9 L WJY LUCAS DCN2	●	●	●	●
C2 CHINE	ABS			●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data
C2 CHINE	Injection	Petrol engine	1.6 L NFU BOSCH ME745	●	●	●	●
C2 CHINE	Injection	Petrol engine	J34P	●	●	●	●
C2 CHINE	BSI			●	●	●	●
C2 CHINE	Instrument panel			●	●	●	●
C2 CHINE	Air conditioning			●	●	●	●
C2 CHINE	Steering wheel with fixed central controls	Top of column			●	●	
C2 CHINE	Airbag			●	●	●	
C2 CHINE	Gearbox ECU	Auto gearbox AL4 TA2000		●			●
C2 CHINE	Gearbox ECU	Auto gearbox AL4 TA2000		●			●
C2 CHINE	Gearbox ECU	Auto gearbox AL4 TA2000		●			●
C2_CAN	Injection	Petrol engine	KFU MM6LPC	●	●	●	●
C2_CAN	Injection	Petrol engine	TU1A J34P	●	●	●	●
C2_CAN	Injection	Petrol engine	TU3A J34P	●	●	●	●
C2_CAN	Injection	Petrol engine	NFS BOSCH ME745	●	●	●	●
C2_CAN	Injection	Petrol engine	NFU BOSCH ME745	●	●	●	●
C2_CAN	Injection	Petrol engine	N6A BOSCH ME745	●	●	●	●
C2_CAN	Anti-lock brake system	ABS MK70		●	●	●	●
C2_CAN	Anti-lock brake system	ABS MK70.1		●	●	●	●
C2_CAN	BSI			●	●	●	●
C2_CAN	Instrument panel			●	●	●	●
C2_CAN	Radio	Radio post-equipment		●	●	●	●
C2_CAN	CD player			●	●	●	●
C2_CAN	Parking aid			●	●	●	●
C2_CAN	Air conditioning			●	●	●	●
C2_CAN	Alarm			●	●	●	●
C2_CAN	Switch module under the steering wheel	Top of column		●	●	●	●
C2_CAN	Rain sensor/ Brightness			●	●	●	
C2_CAN	Airbag			●	●	●	●
C2_CAN	Multifunction screen	Multifunction screen A		●	●	●	●
C2_CAN	Multifunction screen	Multifunction screen C		●	●	●	●
C2_CAN	Telematic	Telematics (RT3)		●	●	●	●
C2_CAN	Telematic	Telematic (RT4)		●	●	●	●
C2_CAN	Telematic	Telematic (RT5)		●	●	●	●
C2_CAN	High frequency receiver			●	●	●	●
C2_CAN	Injection	Petrol engine	NFR BOSCH ME745	●	●	●	●
C2_CAN	Injection	Petrol engine	KFV SAGEM S2000PM2		●	●	
C2_CAN	Injection	Diesel engine	9HZ (FAP) BOSCH EDC16C34 DV6TED4	●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data
C2_CAN	Injection	Diesel engine	8HZ BOSCH EDC16C34 DV4TD	●	●	●	●
C2_CAN	Injection	Diesel engine	8HZ SIEMENS SID806	●	●	●	●
C2_CAN	Trailer relay unit			●	●	●	●
C2_CAN	Engine relay unit			●	●	●	●
C2_CAN	Anti-lock brake system	ESP MK60		●	●	●	●
C2_CAN	Anti-lock brake system	ESP MK60-0		●	●	●	●
C2_CAN	Gearbox ECU			●	●	●	●
C2_CAN	Electric power steering ECU			●	●	●	●
C2_CAN	Hands Free Kit			●	●	●	●
C2_CAN	ECU Reversible "Stop-Start" alternator			●	●	●	●
C2_VAN	BSI			●	●	●	●
C2_VAN	Instrument panel			●	●	●	●
C2_VAN	Radio			●	●	●	●
C2_VAN	CD player			●	●	●	●
C2_VAN	Parking aid			●	●	●	●
C2_VAN	Air conditioning			●	●	●	●
C2_VAN	Navigation			●	●	●	●
C2_VAN	Alarm			●	●	●	●
C2_VAN	Switch module under the steering wheel	Top of column		●	●	●	●
C2_VAN	Rain sensor/ Brightness			●	●	●	●
C2_VAN	Airbag			●	●	●	●
C2_VAN	Display or Telematics	Multifunction display SAGEM A		●	●	●	●
C2_VAN	Display or Telematics	Multifunction display SIEMENS B		●	●	●	●
C2_VAN	Display or Telematics	Multifunction display SIEMENS C		●	●	●	●
C2_VAN	Display or Telematics	Telematics unit		●	●	●	●
C2_VAN	Gearbox ECU	Controlled manual gearbox ECU		●	●	●	●
C2_VAN	Electric power steering ECU			●	●	●	●
C2_VAN	Injection	Petrol engine	HFX MM48P	●	●	●	●
C2_VAN	Injection	Petrol engine	NFU BOSCH ME744	●	●	●	●
C2_VAN	Injection	Petrol engine	NFS BOSCH ME744	●	●	●	●
C2_VAN	Injection	Petrol engine	KFV SAGEM S2000PM1		●	●	
C2_VAN	Injection	Petrol engine	KFV SAGEM S2000PM1		●	●	
C2_VAN	Injection	Petrol engine	KFV SAGEM S2000PM2		●	●	
C2_VAN	Anti-lock brake system	ABS		●	●	●	●
C2_VAN	Anti-lock brake system	ESP		●	●	●	●
C2_VAN	Injection	Diesel engine	8HZ BOSCH EDC16C34 DV4TD	●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data
C2_VAN	Injection	Diesel engine	8HX BOSCH EDC16C34 DV4TD	●	●	●	●
C2_VAN	Injection	Diesel engine	8HX SIEMENS SID802	●	●	●	●
C2_VAN	Injection	Diesel engine	8HX SIEMENS SID804		●	●	
C2_VAN	Injection	Diesel engine	8HX SIEMENS SID804		●	●	
C2_VAN	Injection	Diesel engine	8HZ SIEMENS SID804		●	●	
C2_VAN	Injection	Diesel engine	8HZ SIEMENS SID804		●	●	
C3	BSI			●	●	●	●
C3	Instrument panel			●	●	●	●
C3	Radio	Radio post-equipment		●	●	●	●
C3	CD player			●	●	●	●
C3	Parking aid			●	●	●	●
C3	Air conditioning			●	●	●	●
C3	Navigation			●	●	●	●
C3	Alarm				●	●	
C3	Switch module under the steering wheel	Top of column			●	●	
C3	Rain sensor/ Brightness				●	●	
C3	Driving school mode			●			●
C3	Airbag			●	●	●	●
C3	Multifunction display	Multifunction display SAGEM A		●	●	●	●
C3	Multifunction display	Multifunction display SIEMENS B		●	●	●	●
C3	Multifunction display	Multifunction display SIEMENS C		●	●	●	●
C3	Multifunction display	Telematics unit		●	●	●	●
C3	Telematic	RASTREADOR		●	●	●	●
C3	Diesel additive function			●	●	●	●
C3	Injection	Petrol engine	HFX MM48P	●	●	●	●
C3	Injection	Petrol engine	KFU MM6LP	●	●	●	●
C3	Injection	Petrol engine	KFU MM6LP	●	●	●	●
C3	Injection	Petrol engine	NFU BOSCH ME744	●	●	●	●
C3	Injection	Petrol engine	N6A BOSCH ME744	●	●	●	●
C3	Injection	Petrol engine	KFV BOSCH ME744	●	●	●	●
C3	Injection	Petrol engine	KFV SAGEM S2000PM1		●	●	
C3	Injection	Petrol engine	KFV SAGEM S2000PM1	●	●	●	●
C3	Injection	Petrol engine	KFV SAGEM S2000PM2		●	●	
C3	Injection	Petrol engine	NFU BOSCH ME749	●	●	●	●
C3	Injection	Petrol engine	N6A BOSCH ME749	●	●	●	●
C3	Injection	Petrol engine	NFS BOSCH ME749	●	●	●	●
C3	Injection	Petrol engine	NFR BOSCH ME749	●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data
C3	Injection	Petrol engine	KFV BOSCH ME749	●	●	●	●
C3	Injection	Diesel engine	9HZ (FAP) BOSCH EDC16C34 DV6TED4	●	●	●	●
C3	Injection	Diesel engine	9HX BOSCH EDC16C34 DV6ATED4	●	●	●	●
C3	Gas injection	SAX500_GPL			●	●	
C3	Gas injection	SAX500_GNV			●	●	
C3	Anti-lock brake system	ABS MK60		●			●
C3	Anti-lock brake system	ABS MK70		●	●	●	●
C3	Anti-lock brake system	ESP		●	●	●	●
C3	Gearbox ECU	Auto gearbox AL4		●			●
C3	Gearbox ECU	Auto gearbox AL4		●			●
C3	Gearbox ECU	Auto gearbox AL4		●			●
C3	Gearbox ECU	Controlled manual gearbox ECU		●	●	●	●
C3	Electric power steering ECU			●	●	●	●
C3	ECU Reversible "Stop-Start" alternator			●	●	●	●
C3	Injection	Diesel engine	8HX SIEMENS SID802	●	●	●	●
C3	Injection	Diesel engine	8HX SIEMENS SID804		●	●	
C3	Injection	Diesel engine	8HX SIEMENS SID804		●	●	
C3	Injection	Diesel engine	8HZ SIEMENS SID804		●	●	
C3	Injection	Diesel engine	8HZ SIEMENS SID804		●	●	
C3	Injection	Diesel engine	8HY DELPHI C6	●	●	●	●
C3	Injection	Diesel engine	8HY DELPHI C6	●	●	●	●
C3 (A51)	Auto gearbox		BVA_AL4	●	●	●	●
C3 (A51)	Injection		J34P	●	●	●	●
C3 (A51)	Injection		MED17.4	●	●	●	●
C3 (A51)	Injection		MEV174	●	●	●	●
C3 (A51)	Injection		V34.1	●	●	●	●
C3 (A51)	Injection		MEV17_4_2	●	●	●	●
C3 AIRCROSS	Auto gearbox		BVA_AL4	●	●	●	●
C3 AIRCROSS	Injection		ME749	●	●	●	●
C3 PICASSO	BSI			●	●	●	●
C3 PICASSO	Seat belt reminder LED			●			
C3 PICASSO	Instrument panel			●	●	●	●
C3 PICASSO	Radio	Radio post-equipment		●	●	●	●
C3 PICASSO	Parking aid			●	●	●	●
C3 PICASSO	Air conditioning			●	●	●	●
C3 PICASSO	Alarm			●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data
C3 PICASSO	Switch module under the steering wheel			●	●	●	●
C3 PICASSO	Rain sensor/ Brightness			●	●	●	
C3 PICASSO	Airbag			●	●	●	●
C3 PICASSO	Multifunction screen(EMF)	Type "A" (segments)		●	●	●	●
C3 PICASSO	Multifunction screen(EMF)	Type "C" (dot matrix)		●	●	●	●
C3 PICASSO	Telematic			●	●	●	●
C3 PICASSO	Multiplexed diesel additive pump			●	●	●	●
C3 PICASSO	Engine relay unit			●	●	●	●
C3 PICASSO	Trailer relay unit			●	●	●	●
C3 PICASSO	Power steering	Electric power steering		●	●	●	●
C3 PICASSO	Hands Free Kit			●	●	●	●
C3 PICASSO	Driver's door control panel			●	●	●	●
C3 PICASSO	ABS	ESP_MK60			●	●	
C3 PICASSO	ABS	ABS MK 70.2		●	●	●	●
C3 PICASSO	Injection	Petrol engine	5FW MEV17.4	●	●	●	●
C3 PICASSO	Injection	Petrol engine	8FS MEV17.4	●	●	●	●
C3 PICASSO	Injection	Diesel engine	9HZ (FAP) BOSCH EDC16C34 DV6TED4-110CV	●	●	●	●
C3 PICASSO	Injection	Diesel engine	9HX BOSCH EDC16C34 DV6ATED4- 90CV	●	●	●	●
C3 PICASSO Ai58	Injection/ignition		ME749	●	●	●	●
C3 PICASSO Ai58	Injection/ignition		ME749_EC5	●	●	●	●
C3 PICASSO Ai58	Injection/ignition		V34.4	●	●	●	●
C3 PICASSO Ai58	ABS/traction control		ABSMK70_1	●	●	●	●
C3 PICASSO Ai58	ABS/traction control		ESPMK60_0	●	●	●	●
C3 PICASSO Ai58	Gearbox		BVA_AL4	●	●	●	●
C3 PICASSO Ai58	Built-in Systems Interface (BSI)			●	●	●	●
C3 PICASSO Ai58	Trailer relay unit			●	●	●	●
C3 PICASSO Ai58	Telematics			●	●	●	●
C3 PICASSO Ai58	Services module			●	●	●	●
C3 PICASSO Ai58	Instrument panel			●	●	●	●
C3 PICASSO Ai58	Radio			●	●	●	●
C3 PICASSO Ai58	Anti-theft alarm			●	●	●	●
C3 PICASSO Ai58	Driver and passenger airbags		SAC_AUTOLIV	●	●	●	●
C3 PICASSO Ai58	Air conditioning			●	●	●	●
C3 PICASSO Ai58	Parking aid			●	●	●	●
C3 PICASSO Ai58	Rain and brightness sensor (CDPL)			●	●	●	●
C3 PICASSO Ai58	Switch module under the steering wheel (top of column)			●	●	●	●



Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data
C3 PICASSO(A58)	Injection		MED17.4	●	●	●	●
C3 PICASSO(A58)	Injection		MEV174	●	●	●	●
C3 PICASSO(A58)	Injection		MEV17_4_2	●	●	●	●
C3 PLURIEL_CAN	BSI			●	●	●	●
C3 PLURIEL_CAN	Instrument panel			●	●	●	●
C3 PLURIEL_CAN	Radio	Radio post-equipment		●	●	●	●
C3 PLURIEL_CAN	CD player			●	●	●	●
C3 PLURIEL_CAN	Parking aid			●	●	●	●
C3 PLURIEL_CAN	Air conditioning			●	●	●	●
C3 PLURIEL_CAN	Alarm			●	●	●	●
C3 PLURIEL_CAN	Switch module under the steering wheel	Top of column		●	●	●	●
C3 PLURIEL_CAN	Rain sensor/ Brightness			●	●	●	
C3 PLURIEL_CAN	Sun roof			●	●	●	●
C3 PLURIEL_CAN	Airbag			●	●	●	●
C3 PLURIEL_CAN	Multifunction screen	Multifunction screen A		●	●	●	●
C3 PLURIEL_CAN	Multifunction screen	Multifunction screen C		●	●	●	●
C3 PLURIEL_CAN	Telematic	Telematics (RT3)		●	●	●	●
C3 PLURIEL_CAN	Telematic	Telematic (RT4)		●	●	●	●
C3 PLURIEL_CAN	Telematic	Telematic (RT5)		●	●	●	●
C3 PLURIEL_CAN	High frequency receiver			●	●	●	●
C3 PLURIEL_CAN	Trailer relay unit			●	●	●	●
C3 PLURIEL_CAN	Engine relay unit			●	●	●	●
C3 PLURIEL_CAN	Gearbox ECU			●	●	●	●
C3 PLURIEL_CAN	Electric power steering ECU			●	●	●	●
C3 PLURIEL_CAN	Hands Free Kit			●	●	●	●
C3 PLURIEL_CAN	Injection	Petrol engine	TU1A J34P	●	●	●	●
C3 PLURIEL_CAN	Injection	Petrol engine	TU3A J34P	●	●	●	●
C3 PLURIEL_CAN	Injection	Petrol engine	NFS BOSCH ME745	●	●	●	●
C3 PLURIEL_CAN	Injection	Petrol engine	NFU BOSCH ME745	●	●	●	●
C3 PLURIEL_CAN	Injection	Petrol engine	N6A BOSCH ME745	●	●	●	●
C3 PLURIEL_CAN	Injection	Petrol engine	NFR BOSCH ME745	●	●	●	●
C3 PLURIEL_CAN	Injection	Diesel engine	8HZ BOSCH EDC16C34 DV4TD	●	●	●	●
C3 PLURIEL_CAN	Injection	Diesel engine	8HZ SIEMENS SID806	●	●	●	●
C3 PLURIEL_CAN	Anti-lock brake system	ABS MK70		●	●	●	●
C3 PLURIEL_CAN	Anti-lock brake system	ABS MK70.1		●	●	●	●
C3 PLURIEL_CAN	Anti-lock brake system	ESP MK60		●	●	●	●
C3 PLURIEL_CAN	Anti-lock brake system	ESP MK60-0		●	●	●	●
C3 PLURIEL_VAN	BSI			●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data
C3 PLURIEL_VAN	Instrument panel			●	●	●	●
C3 PLURIEL_VAN	Radio	Radio post-equipment		●	●	●	●
C3 PLURIEL_VAN	CD player			●	●	●	●
C3 PLURIEL_VAN	Parking aid			●	●	●	●
C3 PLURIEL_VAN	Air conditioning			●	●	●	●
C3 PLURIEL_VAN	Navigation			●	●	●	●
C3 PLURIEL_VAN	Alarm			●	●	●	●
C3 PLURIEL_VAN	Switch module under the steering wheel			●	●	●	●
C3 PLURIEL_VAN	Rain sensor/ Brightness				●	●	
C3 PLURIEL_VAN	Sun roof			●			●
C3 PLURIEL_VAN	Driving school mode			●			●
C3 PLURIEL_VAN	Airbag			●	●	●	●
C3 PLURIEL_VAN	Display or Telematics	Multifunction display SAGEM A		●	●	●	●
C3 PLURIEL_VAN	Display or Telematics	Multifunction display SIEMENS B		●	●	●	●
C3 PLURIEL_VAN	Display or Telematics	Multifunction display SIEMENS C		●	●	●	●
C3 PLURIEL_VAN	Display or Telematics	Telematics unit		●	●	●	●
C3 PLURIEL_VAN	Gearbox ECU			●	●	●	●
C3 PLURIEL_VAN	Electric power steering ECU			●	●	●	●
C3 PLURIEL_VAN	Injection	Petrol engine	NFU BOSCH ME744	●	●	●	●
C3 PLURIEL_VAN	Injection	Petrol engine	KFV SAGEM S2000PM1		●	●	
C3 PLURIEL_VAN	Injection	Petrol engine	KFV SAGEM S2000PM1		●	●	
C3 PLURIEL_VAN	Injection	Petrol engine	KFV SAGEM S2000PM2		●	●	
C3 PLURIEL_VAN	Injection	Diesel engine	8HZ BOSCH EDC16C34 DV4TD	●	●	●	●
C3 PLURIEL_VAN	Injection	Diesel engine	8HX SIEMENS SID802	●	●	●	●
C3 PLURIEL_VAN	Injection	Diesel engine	8HX SIEMENS SID804	●	●	●	●
C3 PLURIEL_VAN	Injection	Diesel engine	8HX SIEMENS SID804		●	●	
C3 PLURIEL_VAN	Injection	Diesel engine	8HZ SIEMENS SID804	●	●	●	●
C3 PLURIEL_VAN	Injection	Diesel engine	8HZ SIEMENS SID804		●	●	
C3 PLURIEL_VAN	Anti-lock brake system	ABS		●	●	●	●
C3 PLURIEL_VAN	Anti-lock brake system	ESP		●	●	●	●
C3 R	BSI			●	●	●	●
C3 R	Instrument panel			●	●	●	●
C3 R	Radio			●	●	●	●
C3 R	CD player			●	●	●	●
C3 R	Parking aid			●	●	●	●
C3 R	Air conditioning			●	●	●	●
C3 R	Alarm			●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data
C3 R	Switch module under the steering wheel	Top of column		●	●	●	●
C3 R	Rain sensor/ Brightness			●	●	●	
C3 R	Airbag			●	●	●	●
C3 R	Driving school mode			●	●	●	
C3 R	Multifunction screen	Multifunction screen A		●	●	●	●
C3 R	Multifunction screen	Multifunction screen C		●	●	●	●
C3 R	Telematic	Telematics (RT3)		●	●	●	●
C3 R	Telematic	Telematic (RT4)		●	●	●	●
C3 R	Telematic	Telematic (RT5)		●	●	●	●
C3 R	High frequency receiver			●	●	●	●
C3 R	Gas injection	SAX500_GPL			●	●	
C3 R	Gas injection	SAX500_GNV			●	●	
C3 R	Multiplexed diesel additive pump			●	●	●	●
C3 R	Trailer relay unit			●	●	●	●
C3 R	Engine relay unit			●	●	●	●
C3 R	Gearbox ECU	Auto gearbox AL4		●	●	●	●
C3 R	Gearbox ECU	Controlled manual gearbox ECU		●	●	●	●
C3 R	Electric power steering ECU			●	●	●	●
C3 R	Hands Free Kit			●	●	●	●
C3 R	ECU Reversible "Stop-Start" alternator			●	●	●	●
C3 R	Injection	Petrol engine	TU1A J34P	●	●	●	●
C3 R	Injection	Petrol engine	TU3A J34P	●	●	●	●
C3 R	Injection	Petrol engine	KFU MM6LPC	●	●	●	●
C3 R	Injection	Petrol engine	NFS BOSCH ME745	●	●	●	●
C3 R	Injection	Petrol engine	NFU BOSCH ME745	●	●	●	●
C3 R	Injection	Petrol engine	N6A BOSCH ME745	●	●	●	●
C3 R	Injection	Petrol engine	NFR BOSCH ME745	●	●	●	●
C3 R	Injection	Petrol engine	KFV SAGEM S2000PM2		●	●	
C3 R	Injection	Diesel engine	8HZ BOSCH EDC16C34 DV4TD	●	●	●	●
C3 R	Injection	Diesel engine	9HZ (FAP) BOSCH EDC16C34 DV6TED4	●	●	●	●
C3 R	Injection	Diesel engine	9HX BOSCH EDC16C34 DV6ATED4	●	●	●	●
C3 R	Injection	Diesel engine	8HZ SIEMENS SID806	●	●	●	●
C3 R	Anti-lock brake system	ABS MK70		●	●	●	●
C3 R	Anti-lock brake system	ABS MK70.1		●	●	●	●
C3 R	Anti-lock brake system	ESP MK60		●	●	●	●
C3 R	Anti-lock brake system	ESP MK60-0		●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data
C4	BSI			●	●	●	●
C4	Instrument panel			●	●	●	●
C4	Radio	Radio post-equipment		●	●	●	●
C4	CD player			●	●	●	●
C4	Parking aid			●	●	●	●
C4	Air conditioning			●	●	●	●
C4	Lane departure warning system			●	●	●	●
C4	Alarm			●	●	●	●
C4	Steering wheel with fixed central controls			●	●	●	●
C4	Multiplexed diesel additive pump			●	●	●	●
C4	Driver's door module			●	●	●	●
C4	Passenger's door module			●	●	●	●
C4	Hi-Fi amplifier	Audio amplifier		●	●	●	
C4	Rain sensor/ Brightness			●	●	●	
C4	Driving school mode			●	●	●	
C4	Unit Rev counter	Rev counter		●	●	●	●
C4	Driver's seat memorising unit			●	●	●	●
C4	Airbag			●	●	●	●
C4	Multifunction screen	Multifunction screen SAGEM A		●	●	●	●
C4	Multifunction screen	Multifunction screen SAGEM C		●	●	●	●
C4	Telematic	Telematics (RT3)		●	●	●	●
C4	Telematic	Telematic (RT4)		●	●	●	●
C4	Telematic	Telematic (RT5)		●	●	●	●
C4	Telematic	RNEG navigation radio		●	●	●	●
C4	Telematic	RASTREADOR		●	●	●	●
C4	High frequency receiver			●	●	●	●
C4	Trailer relay unit				●	●	●
C4	Engine relay unit				●	●	
C4	Gearbox ECU	Auto gearbox AL4		●	●	●	●
C4	Gearbox ECU	Auto gearbox AM6		●	●	●	●
C4	Gearbox ECU	CFC300P		●	●	●	●
C4	Gearbox ECU	BVA AM6 Euro5		●	●	●	●
C4	Power steering	Electric pump unit (GEP)			●	●	
C4	Directional headlamps			●	●	●	●
C4	Deflation detection			●	●	●	●
C4	Hands Free Kit	Mobile Housing		●	●	●	●
C4	Diesel additive function			●	●	●	●
C4	Injection	Petrol engine	5FT MED17.4	●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data
C4	Injection	Petrol engine	5FX MED17.4	●	●	●	●
C4	Injection	Petrol engine	RFN MM6LP	●	●	●	●
C4	Anti-lock brake system	ESP8.1_BOSCH		●	●	●	●
C4	Anti-lock brake system	ESP8_BOSCH		●	●	●	
C4	Injection	Petrol engine	RFK MM6LP	●	●	●	●
C4	Injection	Petrol engine	KFU MM6LP	●	●	●	●
C4	Injection	Petrol engine	RFJ MM6LPB		●	●	
C4	Injection	Petrol engine	6FY MM6LPB		●	●	
C4	Injection	Petrol engine	MM6KP		●	●	
C4	Injection	Petrol engine	NFU BOSCH ME745	●	●	●	●
C4	Injection	Petrol engine	N6A BOSCH ME745	●	●	●	●
C4	Injection	Petrol engine	NFS BOSCH ME745	●	●	●	●
C4	Injection	Petrol engine	NFR BOSCH ME745	●	●	●	●
C4	Injection	Petrol engine	NFU BOSCH ME749	●	●	●	●
C4	Injection	Petrol engine	N6A BOSCH ME749	●	●	●	●
C4	Injection	Petrol engine	MED17.4	●	●	●	●
C4	Injection	Petrol engine	MEV17.4	●	●	●	●
C4	Anti-lock brake system	ABS8.1_BOSCH		●	●	●	●
C4	Anti-lock brake system	ABS8_BOSCH			●	●	●
C4	Injection	Diesel engine	RHR DELPHI DCM3.4	●	●	●	●
C4	Injection	Diesel engine	RHF DELPHI DCM3.4	●	●	●	●
C4	Injection	Diesel engine	9HV BOSCH EDC16C34 DV6TED4	●	●	●	●
C4	Injection	Diesel engine	9HX BOSCH EDC16C34 DV6ATED4	●	●	●	●
C4	Injection	Diesel engine	9HZ (FAP) BOSCH EDC16C34 DV6TED4	●	●	●	●
C4	Injection	Diesel engine	9HY BOSCH EDC16C34 DV6TED4	●	●	●	●
C4	Injection	Diesel engine	RHR SIEMENS SID803A		●	●	
C4	Injection	Diesel engine	RHR SIEMENS SID803		●	●	
C4 PICASSO	BSI			●	●	●	●
C4 PICASSO	Instrument panel			●	●	●	●
C4 PICASSO	Radio	Radio post-equipment		●	●	●	●
C4 PICASSO	CD player			●	●	●	●
C4 PICASSO	Parking aid			●	●	●	●
C4 PICASSO	Air conditioning			●	●	●	●
C4 PICASSO	Lane departure warning system			●	●	●	●
C4 PICASSO	Steering wheel with fixed central controls			●	●	●	●
C4 PICASSO	Alarm			●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data
C4 PICASS0	Windscreen wiper			●	●	●	
C4 PICASS0	Additive pump	Multiplexed diesel additive pump		●	●	●	●
C4 PICASS0	Additive pump	Additive pump		●	●	●	●
C4 PICASS0	Driver's door module			●	●	●	●
C4 PICASS0	Passenger's door module			●	●	●	●
C4 PICASS0	Hi-Fi amplifier	Audio amplifier		●	●	●	
C4 PICASS0	Rain sensor/ Brightness			●	●	●	
C4 PICASS0	Driver's seat memorising unit			●	●	●	●
C4 PICASS0	Airbag			●	●	●	●
C4 PICASS0	Telematic	Telematics (RT3)		●	●	●	●
C4 PICASS0	Telematic	Telematic (RT4)		●	●	●	●
C4 PICASS0	Telematic	Telematic (RT5)		●	●	●	●
C4 PICASS0	Telematic	RNEG navigation radio		●	●	●	●
C4 PICASS0	High frequency receiver			●	●	●	●
C4 PICASS0	Gearbox ECU	Auto gearbox AL4		●	●	●	●
C4 PICASS0	Gearbox ECU	Auto gearbox AM6		●	●	●	●
C4 PICASS0	Gearbox ECU	CFC300P		●	●	●	●
C4 PICASS0	Gearbox ECU	BVA AM6 Euro5		●	●	●	●
C4 PICASS0	Automatic gearbox electric control			●	●	●	●
C4 PICASS0	Pneumatic suspension	Suspension		●	●	●	●
C4 PICASS0	Power steering	Electric power steering ECU		●	●	●	●
C4 PICASS0	Directional headlamps			●	●	●	●
C4 PICASS0	Trailer relay unit				●	●	●
C4 PICASS0	Engine relay unit				●	●	
C4 PICASS0	Deflation detection			●	●	●	●
C4 PICASS0	Electric secondary brake			●	●	●	●
C4 PICASS0	Hands Free Kit	Mobile Housing		●	●	●	●
C4 PICASS0	Battery charge status unit			●	●	●	●
C4 PICASS0	Ambient interior lighting unit			●	●	●	●
C4 PICASS0	ABS/ Electronic stability program	ESP8.1_BOSCH		●	●	●	●
C4 PICASS0	Injection/ Ignition	Petrol engine	5FT MED17.4	●	●	●	●
C4 PICASS0	Injection/ Ignition	Petrol engine	5FX MED17.4	●	●	●	●
C4 PICASS0	Injection/ Ignition	Petrol engine	MEV17.4	●	●	●	●
C4 PICASS0	Injection/ Ignition	Petrol engine	MEV174	●	●	●	●
C4 PICASS0	Injection/ Ignition	Petrol engine	MED174	●	●	●	●
C4 PICASS0	Injection/ Ignition	Petrol engine	MEV17_4_2	●	●	●	●
C4 PICASS0	Injection/ Ignition	Petrol engine	MED17_4_2	●	●	●	●
C4 PICASS0	Injection/ Ignition	Petrol engine	RFJ MM6LPB	●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data
C4 PICASSO	Injection/ Ignition	Petrol engine	6FY MM6LPB	●	●	●	●
C4 PICASSO	Injection/ Ignition	Diesel engine	9HZ (FAP) BOSCH EDC16C34 DV6TED4	●	●	●	●
C4 PICASSO	Injection/ Ignition	Diesel engine	RHR SIEMENS SID803A		●	●	
C4 PICASSO	Injection/ Ignition	Diesel engine	RHJ SIEMENS SID803A		●	●	
C4 PICASSO	Injection/ Ignition	Diesel engine	RHE DCM3.5	●	●	●	●
C4 PICASSO	Injection/ Ignition	Diesel engine	RHH DCM3.5	●	●	●	●
C4 PICASSO	Injection/ Ignition	Diesel engine	RHD DCM3.5	●	●	●	●
C4 SEDAN	BSI			●	●	●	●
C4 SEDAN	Instrument panel			●	●	●	●
C4 SEDAN	Radio	Radio post-equipment		●	●	●	●
C4 SEDAN	CD player			●	●	●	●
C4 SEDAN	Parking aid			●	●	●	●
C4 SEDAN	Air conditioning			●	●	●	●
C4 SEDAN	Switch module under the steering wheel			●	●	●	●
C4 SEDAN	Alarm			●	●	●	●
C4 SEDAN	Driver's seat memorising unit			●	●	●	●
C4 SEDAN	Driver's door module			●	●	●	●
C4 SEDAN	Passenger's door module			●	●	●	●
C4 SEDAN	Unit Rev counter	Rev counter		●	●	●	●
C4 SEDAN	Rain sensor/ Brightness			●	●	●	
C4 SEDAN	Airbag			●	●	●	●
C4 SEDAN	Multifunction screen	Multifunction screen A		●	●	●	●
C4 SEDAN	Multifunction screen	Multifunction screen C		●	●	●	●
C4 SEDAN	Telematic	Telematics (RT3)		●	●	●	●
C4 SEDAN	Telematic	Telematic (RT4)		●	●	●	●
C4 SEDAN	Telematic	Telematic (RT5)		●	●	●	●
C4 SEDAN	Trailer relay unit				●	●	●
C4 SEDAN	Engine relay unit				●	●	
C4 SEDAN	Multiplexed diesel additive pump			●	●	●	●
C4 SEDAN	Power steering	Electric pump unit (GEP)			●	●	
C4 SEDAN	Directional headlamps			●	●	●	●
C4 SEDAN	Hands Free Kit			●	●	●	●
C4 SEDAN	Injection	Petrol engine	RFJ MM6KP Bio Flex (EW10A FF)	●	●	●	●
C4 SEDAN	Injection	Petrol engine	RFJ MM6KP (EW10A FF)	●	●	●	●
C4 SEDAN	Injection	Petrol engine	RFJ MM6LPB	●	●	●	●
C4 SEDAN	Injection	Petrol engine	NFU BOSCH ME749	●	●	●	●
C4 SEDAN	Injection	Petrol engine	N6A BOSCH ME749	●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data
C4 SEDAN	Injection	Petrol engine	NFS BOSCH ME745	●	●	●	●
C4 SEDAN	Auto gearbox		BVA_AL4_AT8	●	●	●	●
C4 SEDAN	ABS	ESP8.1_BOSCH		●	●	●	●
C4 SEDAN	ABS	ESP8_BOSCH		●	●	●	●
C4 SEDAN	Injection	Petrol engine	NFU BOSCH ME745	●	●	●	●
C4 SEDAN	Injection	Petrol engine	N6A BOSCH ME745	●	●	●	●
C4 SEDAN	Injection	Petrol engine	NFR BOSCH ME745	●	●	●	●
C4 SEDAN	Injection	Diesel engine	RHM BOSCH EDC15C2 DW10A	●	●	●	●
C4 SEDAN	Injection	Diesel engine	RHM BOSCH EDC15C2 DW10A	●	●	●	●
C4 SEDAN	Injection	Diesel engine	RHS BOSCH EDC15C2 DW10A	●	●	●	●
C4 SEDAN	Injection	Diesel engine	RHS BOSCH EDC15C2 DW10A	●	●	●	●
C4 SEDAN	Injection	Diesel engine	RHT BOSCH EDC15C2 DW10A	●	●	●	●
C4 SEDAN	Injection	Diesel engine	RHT BOSCH EDC15C2 DW10A	●	●	●	●
C4 SEDAN	Injection	Diesel engine	RHW BOSCH EDC15C2 DW10A	●	●	●	●
C4 SEDAN	Injection	Diesel engine	RHW BOSCH EDC15C2 DW10A	●	●	●	●
C4 SEDAN	Injection	Diesel engine	RHZ BOSCH EDC15C2 DW10A	●	●	●	●
C4 SEDAN	Injection	Diesel engine	RHZ BOSCH EDC15C2 DW10A	●	●	●	●
C4 SEDAN	Injection	Diesel engine	9HZ (FAP) BOSCH EDC16C34 DV6TED4-110CV	●	●	●	●
C4 SEDAN	Injection	Diesel engine	9HX BOSCH EDC16C34 DV6ATED4- 90CV	●	●	●	●
C4 SEDAN	ABS	ABS8.1_BOSCH		●	●	●	●
C4 SEDAN	ABS	ABS8_BOSCH		●	●	●	●
C4Aircross	Injection/ignition		MIVEC	●	●	●	●
C4Aircross	Injection/ignition		CMM_4A92	●	●	●	●
C4Aircross	Injection/ignition		HDI_4N13	●	●	●	●
C4Aircross	Injection/ignition		HDI_SID807_J3J4	●	●	●	●
C4Aircross	ABS/traction control		ABS_4x4	●	●	●	●
C4Aircross	ABS/traction control		ESP_4x4	●	●	●	●
C4Aircross	Parking aid			●	●	●	●
C4Aircross	Driver and passenger airbags			●	●	●	●
C4Aircross	Driver's door module			●	●	●	●
C4Aircross	Rain and brightness sensor			●	●	●	●
C4Aircross	Anti-theft alarm			●	●	●	●
C4Aircross	Power steering			●	●	●	●
C4Aircross	Instrument panel			●	●	●	●
C4Aircross	Starting authorisation ECU			●	●	●	●
C4Aircross	Radio or radiotelephone(radio part)			●	●	●	●
C4Aircross	Rear final drive piloted clutch			●	●	●	●
C4Aircross	Directional headlamps			●	●	●	●



Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data
C4Aircross	Locking and immobiliser control module		WCM	●	●	●	●
C4Aircross	Locking and immobiliser control module		KOS	●	●	●	●
C4Aircross	Calculateur stop and start			●	●	●	●
C4Aircross	Streeing wheel angle sensor			●	●	●	●
C4Aircross	Heating/ventilation			●	●	●	●
C4Aircross	Gearbox		BV_CVT	●	●	●	●
C4Aircross	Navigation			●	●	●	●
C5	BSI			●	●	●	●
C5	BSI			●	●	●	●
C5	Navigation	Navigation SIEMENS		●	●	●	●
C5	Navigation	Navigation VDO		●			●
C5	Instrument panel			●	●	●	●
C5	Air conditioning			●	●	●	●
C5	Radio post-equipment			●	●	●	●
C5	Car-phone			●	●	●	●
C5	Car-phone			●	●	●	●
C5	CD player			●	●	●	●
C5	Parking aid			●	●	●	●
C5	Sun roof			●	●	●	●
C5	Alarm			●	●	●	●
C5	Switch module at the steering wheel	Top of column			●	●	
C5	Driver's door module			●			●
C5	Passenger's door module			●			●
C5	Airbag			●	●	●	
C5	Display or Autopc or Telematics	Multifunction display SAGEM A		●	●	●	●
C5	Display or Autopc or Telematics	Multifunction display SAGEM B		●	●	●	●
C5	Display or Autopc or Telematics	Multifunction display SIEMENS C		●	●	●	●
C5	Display or Autopc or Telematics	Multifunction display VDO D		●	●	●	●
C5	Display or Autopc or Telematics	Multifunction display AUTOPC		●	●	●	●
C5	Display or Autopc or Telematics	Telematics unit		●	●	●	●
C5	Diesel additive function	ADDITIF_FAP		●	●	●	●
C5	Diesel additive function	ADDG02		●	●	●	●
C5	Injection	Petrol engine	2.0L RFN MM48P	●	●	●	●
C5	Injection	Petrol engine	RFN MM6LP	●	●	●	●
C5	Suspension	Suspension		●	●	●	●
C5	Suspension	ECOTECH SUSPENSION			●	●	
C5	Auto gearbox	Auto gearbox AL4		●			●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data
C5	Auto gearbox	Auto gearbox 4HP20		●	●	●	●
C5	Auto gearbox	Auto gearbox 4HP20		●	●	●	●
C5	Auto gearbox	BVA_ZF		●	●	●	●
C5	additional heating			●	●	●	●
C5	Right-hand headlamp			●	●	●	
C5	Left-hand headlamp			●	●	●	
C5	Injection	Petrol engine	RFN MM6LP	●	●	●	●
C5	Injection	Petrol engine	3.0L XFX BOSCH ME746	●	●	●	●
C5	Injection	Petrol engine	1.8L 6FZ SAGEM S2000P	●			●
C5	Injection	Petrol engine	1.8L 6FZ SAGEM S2000P	●			●
C5	Injection	Petrol engine	6FZ SAGEM S2000PM1		●	●	
C5	Injection	Petrol engine	6FZ SAGEM S2000PM1		●	●	
C5	Anti-lock brake system	ABS		●			●
C5	Anti-lock brake system	ESP		●	●	●	●
C5	Injection	Petrol engine	2.0L RLZ SIEMENS Sirius81	●	●	●	●
C5	Injection	Diesel engine	2.2 L 4HX BOSCH EDC15C2	●	●	●	●
C5	Injection	Diesel engine	2.2 L 4HX BOSCH EDC15C2	●	●	●	●
C5	Injection	Diesel engine	2.0 L RHY BOSCH EDC15C2	●	●	●	●
C5	Injection	Diesel engine	2.0 L RHY BOSCH EDC15C2	●	●	●	●
C5	Injection	Diesel engine	2.0 L RHZ BOSCH EDC15C2	●	●	●	●
C5	Injection	Diesel engine	2.0 L RHZ BOSCH EDC15C2	●	●	●	●
C5	Injection	Diesel engine	2.0 L RHS BOSCH EDC15C2	●	●	●	●
C5	Injection	Diesel engine	2.0 L RHS BOSCH EDC15C2	●	●	●	●
C5	Injection	Diesel engine	RHY SIEMENS SID801	●	●	●	●
C5	Injection	Diesel engine	RHY SIEMENS SID801		●	●	
C5 (X7)	Anti-lock brake system	ESP8.1_BOSCH		●	●	●	●
C5 (X7)	Injection	Petrol engine	MED174	●	●	●	●
C5 (X7)	Injection	Petrol engine	RFJ MM6KP (EW10A)	●	●	●	●
C5 (X7)	Injection	Petrol engine	RFJ MM6KP Bio Flex (EW10A FF)	●	●	●	●
C5 (X7)	Injection	Petrol engine	6FY MM6KP (EW7A)	●	●	●	●
C5 (X7)	Injection	Petrol engine	XFU BOSCH ME747	●	●	●	●
C5 (X7)	Injection	Petrol engine	XFV BOSCH ME747	●	●	●	●
C5 (X7)	Injection	Diesel engine	9HZ (FAP) BOSCH EDC16C34 DV6TED4-110CV	●	●	●	●
C5 (X7)	Injection	Diesel engine	4HP BOSCH EDC16CP39 DW12BTED4	●	●	●	●
C5 (X7)	Injection	Diesel engine	4HR BOSCH EDC16CP39 DW12BTED4	●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data
C5 (X7)	Injection	Diesel engine	4HS BOSCH EDC16CP39 DW12BTED4	●	●	●	●
C5 (X7)	Injection	Diesel engine	4HT BOSCH EDC16CP39 DW12BTED4	●	●	●	●
C5 (X7)	Injection	Diesel engine	UHZ SIEMENS SID201	●	●	●	●
C5 (X7)	Injection	Diesel engine	RHR DELPHI DCM3.4	●	●	●	●
C5 (X7)	Injection	Diesel engine	RHF DELPHI DCM3.4	●	●	●	●
C5 (X7)	Injection	Diesel engine	RHH DCM3.5	●	●	●	●
C5 (X7)	Injection	Diesel engine	RHE DCM3.5	●	●	●	●
C5 (X7)	Injection	Diesel engine	X8Z-DT20C EDC17CP11	●	●	●	●
C5 (X7)	BSI			●	●	●	●
C5 (X7)	Instrument panel			●	●	●	●
C5 (X7)	Seat belt reminder LED			●			
C5 (X7)	Radio	Radio post-equipment		●	●	●	●
C5 (X7)	CD player			●	●	●	●
C5 (X7)	Parking aid			●	●	●	●
C5 (X7)	Air conditioning			●	●	●	●
C5 (X7)	Alarm			●	●	●	●
C5 (X7)	Windscreen wiper	Wiper		●	●	●	
C5 (X7)	Driver's seat memorising unit			●	●	●	●
C5 (X7)	Lane departure warning system			●	●	●	●
C5 (X7)	Steering wheel with fixed central controls			●	●	●	●
C5 (X7)	Hi-Fi amplifier	Audio amplifier		●	●	●	
C5 (X7)	Rain sensor/ Brightness			●	●	●	
C5 (X7)	Airbag			●	●	●	●
C5 (X7)	Multifunction screen	Multifunction screen C		●	●	●	●
C5 (X7)	Telematic	Telematics (RT3)		●	●	●	●
C5 (X7)	Telematic	Telematic (RT4)		●	●	●	●
C5 (X7)	Telematic	Telematic (RT5)		●	●	●	●
C5 (X7)	Telematic	RNEG navigation radio		●	●	●	●
C5 (X7)	Telematic	NG4 navigation radio		●	●	●	●
C5 (X7)	Gearbox ECU	Auto gearbox AL4		●	●	●	●
C5 (X7)	Gearbox ECU	Auto gearbox AM6		●	●	●	●
C5 (X7)	Gearbox ECU	Auto gearbox AM6 Euro5		●	●	●	●
C5 (X7)	Suspension	ECOTECH SUSPENSION			●	●	
C5 (X7)	Suspension System Control ECU				●	●	
C5 (X7)	additional heating			●	●	●	●
C5 (X7)	Trailer relay unit			●	●	●	●
C5 (X7)	Engine relay unit			●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data
C5 (X7)	Power steering	Electric pump unit(GEP)		●	●	●	●
C5 (X7)	Directional headlamps			●	●	●	●
C5 (X7)	Electric secondary brake			●	●	●	●
C5 (X7)	Hands Free Kit	Mobile Housing		●	●	●	●
C5 (X7)	Driver's door control panel			●	●	●	●
C5 (X7)	Battery charge status unit			●	●	●	●
C5 (X7)	Deflation detection			●	●	●	●
C5 (X7)	Motorised Boot ECU			●	●	●	●
C5 (X7)	Services module			●	●	●	●
C5 (X73C)	Anti-lock brake system	ESP8.1		●	●	●	●
C5 (X73C)	Electric secondary brake		FSE				
C5 (X73C)	Deflation detection			●	●	●	●
C5 (X73C)	Auto gearbox		BVA_AL4	●	●	●	●
C5 (X73C)	Injection		MM6KP	●	●	●	●
C5 (X73C)	Injection		ME747	●	●	●	●
C5 R	Anti-lock brake system	ESP	ESP_MK60		●	●	
C5 R	Diesel additive function			●	●	●	●
C5 R	Injection	Petrol engine	RFJ MM6LPB		●	●	
C5 R	Injection	Petrol engine	6FY MM6LPB		●	●	
C5 R	Injection	Petrol engine	XFU BOSCH ME747	●	●	●	●
C5 R	Injection	Petrol engine	XFV BOSCH ME747	●	●	●	●
C5 R	Injection	Petrol engine	6FZ SAGEM S2000PM2		●	●	
C5 R	Injection	Diesel engine	4HP BOSCH EDC16CP39 DW12BTED4	●	●	●	●
C5 R	Injection	Diesel engine	4HR BOSCH EDC16CP39 DW12BTED4	●	●	●	●
C5 R	Injection	Diesel engine	4HS BOSCH EDC16CP39 DW12BTED4	●	●	●	●
C5 R	Injection	Diesel engine	4HT BOSCH EDC16CP39 DW12BTED4	●	●	●	●
C5 R	Injection	Diesel engine	2.2 L 4HX BOSCH EDC15C2	●	●	●	●
C5 R	Injection	Diesel engine	2.2 L 4HX BOSCH EDC15C2	●	●	●	●
C5 R	Injection	Diesel engine	9HY BOSCH EDC16C34 DV6TED4	●	●	●	●
C5 R	Injection	Diesel engine	9HZ (FAP) BOSCH EDC16C34 DV6ATED4	●	●	●	●
C5 R	Injection	Diesel engine	RHR SIEMENS SID803A		●	●	
C5 R	Injection	Diesel engine	RHL SIEMENS SID803A		●	●	
C5 R	Injection	Diesel engine	RHR SIEMENS SID803		●	●	
C5 R	Injection	Diesel engine	RHL SIEMENS SID803		●	●	
C5 R	BSI				●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data
C5 R	Instrument panel				●	●	
C5 R	Radio	Radio post-equipment		●	●	●	●
C5 R	CD player			●	●	●	●
C5 R	Parking aid			●	●	●	●
C5 R	Air conditioning			●	●	●	●
C5 R	Lane departure warning system			●	●	●	●
C5 R	Alarm			●	●	●	●
C5 R	Switch module under the steering wheel	Top of column		●	●	●	●
C5 R	Driver's door module			●	●	●	●
C5 R	Passenger's door module			●	●	●	●
C5 R	Rain sensor/ Brightness			●	●	●	
C5 R	Sun roof		TO_WEBASTO		●	●	
C5 R	Airbag			●	●	●	●
C5 R	Multifunction screen	Multifunction screen SAGEM A		●	●	●	●
C5 R	Multifunction screen	Multifunction screen SAGEM C		●	●	●	●
C5 R	Telematic	Telematics (RT3)		●	●	●	●
C5 R	Telematic	Telematic (RT4)		●	●	●	●
C5 R	Telematic	Telematic (RT5)		●	●	●	●
C5 R	Trailer relay unit				●	●	●
C5 R	Engine relay unit				●	●	
C5 R	Suspension	ECOTECH SUSPENSION			●	●	
C5 R	Gearbox ECU	Auto gearbox AL4		●	●	●	●
C5 R	Gearbox ECU	Auto gearbox 4HP20		●	●	●	●
C5 R	Gearbox ECU	Auto gearbox AM6		●	●	●	●
C5 R	additional heating			●	●	●	●
C5 R	Power steering	Electric pump unit (GEP)		●	●	●	●
C5 R	Directional headlamps			●	●	●	
C5 R	Deflation detection			●	●	●	●
C5 R	Hands Free Kit			●	●	●	●
C6	Anti-lock brake system	ESP8.1_BOSCH		●	●	●	●
C6	Anti-lock brake system	ESP VSC440			●	●	
C6	Anti-lock brake system	ESP VSC440			●	●	
C6	Injection	Petrol engine	XFU BOSCH ME747	●	●	●	●
C6	Injection	Petrol engine	XFV BOSCH ME747	●	●	●	●
C6	Injection	Diesel engine	4HP BOSCH EDC16CP39 DW12BTED4	●	●	●	●
C6	Injection	Diesel engine	4HR BOSCH EDC16CP39 DW12BTED4	●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data
C6	Injection	Diesel engine	4HS BOSCH EDC16CP39 DW12BTED4	●	●	●	●
C6	Injection	Diesel engine	4HT BOSCH EDC16CP39 DW12BTED4	●	●	●	●
C6	Injection	Diesel engine	UHZ SIEMENS SID201	●	●	●	●
C6	Injection	Diesel engine	X8Z-DT20C EDC17CP11	●	●	●	●
C6	BSI			●	●	●	●
C6	Instrument panel				●	●	
C6	Radio	Radio post-equipment		●	●	●	●
C6	CD player			●	●	●	●
C6	Parking aid			●	●	●	●
C6	Air conditioning			●	●	●	●
C6	Rear air conditioning table				●	●	
C6	Lane departure warning system			●	●	●	●
C6	Alarm			●	●	●	●
C6	Windscreen wiper	Wiper		●	●	●	
C6	Switch module under the steering wheel	Top of column		●	●	●	●
C6	LH seat switch panel				●	●	
C6	RH seat switch panel				●	●	
C6	Driver's door module				●	●	
C6	Passenger's door module				●	●	
C6	Rain sensor/ Brightness			●	●	●	
C6	Driver's seat memorising unit			●	●	●	●
C6	Passenger's seat memorizing unit			●	●	●	
C6	Rear seat memorising unit				●	●	
C6	Airbag			●	●	●	●
C6	Multifunction screen	Colour multifunction display		●	●	●	●
C6	Telematic	Telematics (RT3)		●	●	●	●
C6	Telematic	Telematic (RT4)		●	●	●	●
C6	Telematic	Telematic (RT5)		●	●	●	●
C6	Suspension	ECOTECH SUSPENSION			●	●	
C6	Variable damping				●	●	
C6	Gearbox ECU	Auto gearbox AM6		●	●	●	●
C6	Gearbox ECU	BVA AM6 Euro5		●	●	●	●
C6	Pedestrian impact detection			●	●	●	●
C6	Trailer relay unit				●	●	●
C6	Engine relay unit				●	●	
C6	Boot relay unit				●	●	
C6	Boot moving deflector				●	●	

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data
C6	additional heating			●	●	●	●
C6	Power steering	Electric pump unit(GEP)		●	●	●	●
C6	Directional headlamps			●	●	●	●
C6	Headlamp beam corrector	LH headlamp beam corrector		●	●	●	●
C6	Headlamp beam corrector	RH headlamp beam corrector		●	●	●	●
C6	Deflation detection			●	●	●	●
C6	Electric secondary brake			●	●	●	●
C6	Hands Free Kit	Mobile Housing		●	●	●	●
C6	Battery charge status unit			●	●	●	●
C6	High Head Vision			●	●	●	●
C8_CAN	Anti-lock brake system	ESP8.1_BOSCH		●	●	●	●
C8_CAN	Anti-lock brake system	ESP8_BOSCH		●	●	●	
C8_CAN	Diesel additive function			●	●	●	●
C8_CAN	Injection	Petrol engine	RFJ MM6LPB	●	●	●	●
C8_CAN	Injection	Diesel engine	4HP BOSCH EDC16CP39 DW12BTED4	●	●	●	●
C8_CAN	Injection	Diesel engine	4HR BOSCH EDC16CP39 DW12BTED4	●	●	●	●
C8_CAN	Injection	Diesel engine	4HS BOSCH EDC16CP39 DW12BTED4	●	●	●	●
C8_CAN	Injection	Diesel engine	4HT BOSCH EDC16CP39 DW12BTED4	●	●	●	●
C8_CAN	Injection	Diesel engine	2.2 L 4HW BOSCH EDC15C2	●	●	●	●
C8_CAN	Injection	Diesel engine	2.2 L 4HW BOSCH EDC15C2	●	●	●	●
C8_CAN	Injection	Diesel engine	2.0 L RHT BOSCH EDC15C2	●	●	●	●
C8_CAN	Injection	Diesel engine	2.0 L RHT BOSCH EDC15C2	●	●	●	●
C8_CAN	Injection	Diesel engine	2.0 L RHW BOSCH EDC15C2	●	●	●	●
C8_CAN	Injection	Diesel engine	2.0 L RHW BOSCH EDC15C2	●	●	●	●
C8_CAN	Injection	Diesel engine	2.0 L RHZ BOSCH EDC15C2	●	●	●	●
C8_CAN	Injection	Diesel engine	2.0 L RHZ BOSCH EDC15C2	●	●	●	●
C8_CAN	Injection	Diesel engine	2.0 L RHM BOSCH EDC15C2	●	●	●	●
C8_CAN	Injection	Diesel engine	2.0 L RHM BOSCH EDC15C2	●	●	●	●
C8_CAN	Injection	Diesel engine	RHR SIEMENS SID803A		●	●	
C8_CAN	Injection	Diesel engine	RHK SIEMENS SID803A		●	●	
C8_CAN	BSI			●	●	●	●
C8_CAN	Instrument panel			●	●	●	●
C8_CAN	Radio	Radio post-equipment		●	●	●	●
C8_CAN	CD player			●	●	●	●
C8_CAN	Parking aid			●	●	●	●
C8_CAN	Air conditioning			●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data
C8_CAN	LEDs and odometer ECU			●	●	●	●
C8_CAN	Alarm			●	●	●	●
C8_CAN	Switch module under the steering wheel	Top of column		●	●	●	●
C8_CAN	Sliding side doors module			●	●	●	●
C8_CAN	Driver's door module			●	●	●	●
C8_CAN	Passenger's door module			●	●	●	●
C8_CAN	Rain sensor/ Brightness			●	●	●	
C8_CAN	Front sunroof			●	●	●	●
C8_CAN	Rear sunroof			●	●	●	●
C8_CAN	Middle sunroof			●	●	●	●
C8_CAN	Memory unit			●	●	●	●
C8_CAN	Airbag			●	●	●	●
C8_CAN	Telematic receiver command			●			●
C8_CAN	Multifunction screen	Multifunction display SIEMENS C		●	●	●	●
C8_CAN	Telematic	Telematics (RT3)		●	●	●	●
C8_CAN	Telematic	Telematic (RT4)		●	●	●	●
C8_CAN	Telematic	Telematic (RT5)		●	●	●	●
C8_CAN	Telematic	RNEG navigation radio		●	●	●	●
C8_CAN	Trailer relay unit			●	●	●	●
C8_CAN	Engine relay unit			●	●	●	●
C8_CAN	Gearbox ECU	Auto gearbox AL4		●	●	●	●
C8_CAN	Gearbox ECU	Auto gearbox AM6		●	●	●	●
C8_CAN	Gearbox ECU	BVA AM6 Euro5		●	●	●	●
C8_CAN	additional heating			●	●	●	●
C8_CAN	Power steering			●	●	●	●
C8_CAN	Right-hand headlamp			●	●	●	●
C8_CAN	Left-hand headlamp			●	●	●	●
C8_CAN	Deflation detection			●	●	●	●
C8_CAN	Hands Free Kit	Mobile Housing		●	●	●	●
C8_VAN	Anti-lock brake system	ESP	ESP_BOSCH5.7	●			●
C8_VAN	Anti-lock brake system	ESP	ESP8_BOSCH	●			●
C8_VAN	Anti-lock brake system	ESP	ESP8.1	●			●
C8_VAN	Diesel additive function	ADDITIF_FAP		●	●	●	●
C8_VAN	Diesel additive function	ADDG02		●	●	●	●
C8_VAN	Injection	Petrol engine	2.0L RFN MM48P	●	●	●	●
C8_VAN	Injection	Petrol engine	3FZ MM4MP2	●	●	●	●
C8_VAN	Injection	Petrol engine	RFN MM4MP2	●	●	●	●
C8_VAN	Injection	Petrol engine	RFN MM6LP	●	●	●	●



Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data
C8_VAN	Injection	Petrol engine	RFN MM6LP	●	●	●	●
C8_VAN	Injection	Petrol engine	3FZ MM6LP	●	●	●	●
C8_VAN	Injection	Petrol engine	3FZ MM6LP	●	●	●	●
C8_VAN	Injection	Petrol engine	3.0L XFW BOSCH ME746	●	●	●	●
C8_VAN	Injection	Diesel engine	2.2 L 4HW BOSCH EDC15C2	●	●	●	●
C8_VAN	Injection	Diesel engine	2.2 L 4HW BOSCH EDC15C2	●	●	●	●
C8_VAN	Injection	Diesel engine	2.0 L RHT BOSCH EDC15C2	●	●	●	●
C8_VAN	Injection	Diesel engine	2.0 L RHT BOSCH EDC15C2	●	●	●	●
C8_VAN	Injection	Diesel engine	2.0 L RHW BOSCH EDC15C2	●	●	●	●
C8_VAN	Injection	Diesel engine	2.0 L RHW BOSCH EDC15C2	●	●	●	●
C8_VAN	Injection	Diesel engine	2.0 L RHZ BOSCH EDC15C2	●	●	●	●
C8_VAN	Injection	Diesel engine	2.0 L RHZ BOSCH EDC15C2	●	●	●	●
C8_VAN	Injection	Diesel engine	2.0 L RHM BOSCH EDC15C2	●	●	●	●
C8_VAN	BSI			●	●	●	●
C8_VAN	Instrument panel			●	●	●	●
C8_VAN	Radio or telematic receiver command	Radio post-equipment		●	●	●	●
C8_VAN	Radio or telematic receiver command	Telematic receiver command		●			●
C8_VAN	CD player			●	●	●	●
C8_VAN	Parking aid			●	●	●	●
C8_VAN	Air conditioning			●	●	●	
C8_VAN	LEDs and odometer ECU			●	●	●	●
C8_VAN	Memory unit			●			●
C8_VAN	Rear sunroof			●			●
C8_VAN	Front sunroof			●			●
C8_VAN	Middle sunroof			●			●
C8_VAN	Alarm				●	●	
C8_VAN	Switch module at the steering wheel	Top of column			●	●	
C8_VAN	Sliding side doors module			●			●
C8_VAN	Injection	Diesel engine	2.0 L RHM BOSCH EDC15C2	●	●	●	●
C8_VAN	Airbag			●	●	●	●
C8_VAN	Display or Telematics	Multifunction display SAGEM B		●	●	●	●
C8_VAN	Display or Telematics	Telematics unit		●	●	●	●
C8_VAN	Auto gearbox	Auto gearbox AL4		●			●
C8_VAN	Auto gearbox	Auto gearbox AL4		●			●
C8_VAN	Auto gearbox	Auto gearbox AL4		●			●
C8_VAN	Auto gearbox	Auto gearbox 4HP20		●			●
C8_VAN	Auto gearbox	Auto gearbox 4HP20		●			●
C8_VAN	additional heating			●	●	●	●
C8_VAN	Right-hand headlamp			●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data
C8_VAN	Left-hand headlamp			●	●	●	●
C-CROSSER	BSI				●	●	●
C-CROSSER	Rear final drive piloted clutch				●	●	●
C-CROSSER	Gearbox	Gearbox CVT			●	●	●
C-CROSSER	Gearbox	BOITE_GETRAG			●	●	●
C-CROSSER	Steering wheel angle sensor				●	●	
C-CROSSER	Airbag				●	●	●
C-CROSSER	Locking and immobiliser control module				●	●	●
C-CROSSER	Instrument panel				●	●	●
C-CROSSER	Air conditioning				●	●	●
C-CROSSER	Radio	Radio post-equipment			●	●	●
C-CROSSER	Hands Free Kit				●	●	●
C-CROSSER	Navigation				●	●	
C-CROSSER	Driver's door control panel				●	●	
C-CROSSER	Passenger's door switch panel				●	●	
C-CROSSER	Rear LH door switch panel				●	●	
C-CROSSER	Rear RH door switch panel				●	●	
C-CROSSER	Sun roof				●	●	
C-CROSSER	Gear lever (DCT)				●	●	●
C-CROSSER	ABS/ Electronic stability program	ABS anti-lock braking system			●	●	●
C-CROSSER	ABS/ Electronic stability program	Electronic stability program			●	●	●
C-CROSSER	Injection/ Ignition	Petrol engine	SFZ MIVEC 2.4 L		●	●	●
C-CROSSER	Injection/ Ignition	Diesel engine	4HN BOSCH EDC16CP39		●	●	●
C-ELYSEE 4/C-ELYSEE 5	ABS			●	●	●	●
C-ELYSEE 4/C-ELYSEE 5	Gearbox ECU			●			●
C-ELYSEE 4/C-ELYSEE 5	Airbag				●	●	●
C-ELYSEE 4/C-ELYSEE 5	Transponder			●			●
C-ELYSEE 4/C-ELYSEE 5	Central locking control unit			●	●	●	●
C-ELYSEE 4/C-ELYSEE 5	Injection	1.6 L NFU BOSCH ME744		●	●	●	●
C-ELYSEE 4/C-ELYSEE 5	Injection	NFU J35			●	●	
C-QUATRE 4	BSI			●	●	●	●
C-QUATRE 4	Instrument panel			●	●	●	●
C-QUATRE 4	Radio			●	●	●	●
C-QUATRE 4	CD player			●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data
C-QUATRE 4	Parking aid			●	●	●	●
C-QUATRE 4	Air conditioning			●	●	●	●
C-QUATRE 4	Alarm			●	●	●	●
C-QUATRE 4	Steering wheel with fixed central controls			●	●	●	●
C-QUATRE 4	Airbag			●	●	●	●
C-QUATRE 4	Multifunction screen			●	●	●	●
C-QUATRE 4	Gearbox ECU			●	●	●	●
C-QUATRE 4	Trailer relay unit				●	●	●
C-QUATRE 4	Engine relay unit				●	●	●
C-QUATRE 4	Power steering				●	●	
C-QUATRE 4	Hands Free Kit			●	●	●	●
C-QUATRE 4	Driver's door module			●	●	●	●
C-QUATRE 4	Passenger's door module			●	●	●	●
C-QUATRE 4	Telematic	Telematics (RT3)		●	●	●	●
C-QUATRE 4	Telematic	Telematic (RT4)		●	●	●	●
C-QUATRE 4	ABS	ESP8. 1_BOSCH		●	●	●	●
C-QUATRE 4	ABS	ABS8. 1_BOSCH		●	●	●	●
C-QUATRE 4	Injection	RFJ MM6LPB		●	●	●	●
C-QUATRE 4	Injection	N6A BOSCH ME745		●	●	●	●
C-QUATRE 4	Injection	MM6KP		●	●	●	●
C-QUATRE 5	BSI			●	●	●	●
C-QUATRE 5	Instrument panel			●	●	●	●
C-QUATRE 5	Radio			●	●	●	●
C-QUATRE 5	CD player			●	●	●	●
C-QUATRE 5	Parking aid			●	●	●	●
C-QUATRE 5	Air conditioning			●	●	●	●
C-QUATRE 5	Alarm			●	●	●	●
C-QUATRE 5	Steering wheel with fixed central controls			●	●	●	●
C-QUATRE 5	Rain sensor/ Brightness			●	●	●	
C-QUATRE 5	Airbag			●	●	●	●
C-QUATRE 5	Multifunction screen			●	●	●	●
C-QUATRE 5	Gearbox ECU			●	●	●	●
C-QUATRE 5	Trailer relay unit				●	●	●
C-QUATRE 5	Engine relay unit				●	●	
C-QUATRE 5	Power steering				●	●	
C-QUATRE 5	Hands Free Kit			●	●	●	●
C-QUATRE 5	Driver's door module			●	●	●	●
C-QUATRE 5	Passenger's door module			●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data
C-QUATRE 5	Telematic	Telematics (RT3)		●	●	●	●
C-QUATRE 5	Telematic	Telematic (RT4)		●	●	●	●
C-QUATRE 5	ABS	ESP8.1_BOSCH		●	●	●	●
C-QUATRE 5	ABS	ABS8.1_BOSCH		●	●	●	●
C-QUATRE 5	Injection	RFJ MM6LPB		●	●	●	●
C-QUATRE 5	Injection	N6A BOSCH ME745		●	●	●	●
C-TRIOMPHE	BSI			●	●	●	●
C-TRIOMPHE	Instrument panel			●	●	●	●
C-TRIOMPHE	Radio			●	●	●	●
C-TRIOMPHE	CD player			●	●	●	●
C-TRIOMPHE	Parking aid			●	●	●	●
C-TRIOMPHE	Air conditioning			●	●	●	●
C-TRIOMPHE	Alarm			●	●	●	●
C-TRIOMPHE	Steering wheel with fixed central controls			●	●	●	●
C-TRIOMPHE	Rain sensor/ Brightness			●	●	●	
C-TRIOMPHE	Airbag			●	●	●	●
C-TRIOMPHE	Multifunction screen			●	●	●	●
C-TRIOMPHE	Gearbox ECU			●	●	●	●
C-TRIOMPHE	Trailer relay unit				●	●	●
C-TRIOMPHE	Engine relay unit				●	●	
C-TRIOMPHE	Power steering				●	●	
C-TRIOMPHE	Directional headlamps			●	●	●	●
C-TRIOMPHE	Hands Free Kit			●	●	●	●
C-TRIOMPHE	Driver's door module			●	●	●	●
C-TRIOMPHE	Passenger's door module			●	●	●	●
C-TRIOMPHE	Telematic	Telematics (RT3)		●	●	●	●
C-TRIOMPHE	Telematic	Telematic (RT4)		●	●	●	●
C-TRIOMPHE	ABS	ESP8.1_BOSCH		●	●	●	●
C-TRIOMPHE	ABS	ESP8_BOSCH		●	●	●	●
C-TRIOMPHE	ABS	ABS8.1_BOSCH		●	●	●	●
C-TRIOMPHE	ABS	ABS8_BOSCH			●	●	●
C-TRIOMPHE	Injection	Petrol engine	RFJ MM6LPB	●	●	●	●
C-ZERO	Built-in System Interface			●	●	●	●
C-ZERO	Electric motor ECU			●	●	●	●
C-ZERO	Traction battery ECU			●	●	●	●
C-ZERO	Electric vehicle management ECU			●	●	●	●
C-ZERO	Traction battery cell electronics		CMU_01	●	○	○	●
C-ZERO	Traction battery cell electronics		CMU_02	●	○	○	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data
C-ZERO	Traction battery cell electronics		CMU_03	●	○	○	●
C-ZERO	Traction battery cell electronics		CMU_04	●	○	○	●
C-ZERO	Traction battery cell electronics		CMU_05	●	○	○	●
C-ZERO	Traction battery cell electronics		CMU_06	●	○	○	●
C-ZERO	Traction battery cell electronics		CMU_07	●	○	○	●
C-ZERO	Traction battery cell electronics		CMU_08	●	○	○	●
C-ZERO	Traction battery cell electronics		CMU_09	●	○	○	●
C-ZERO	Traction battery cell electronics		CMU_10	●	○	○	●
C-ZERO	Traction battery cell electronics		CMU_11	●	○	○	●
C-ZERO	Traction battery cell electronics		CMU_12	●	○	○	●
C-ZERO	ESP			●	●	●	●
C-ZERO	Power steering			●	●	●	●
C-ZERO	Steering wheel angle sensor			●	●	●	●
C-ZERO	Airbag			●	●	●	●
C-ZERO	Gateway wiring housing			●	●	●	●
C-ZERO	Independent telematic unit			●	●	●	●
C-ZERO	Instrument panel			●	●	●	●
C-ZERO	Radio			●	●	●	●
C-ZERO	Air conditioning			●	●	●	●
C-ZERO	Air conditioning compressor and passeger compartment heating control module			●	●	●	●
DS3	Auto gearbox		BVA_AL4	●	●	●	●
DS3	Injection		MED17.4	●	●	●	●
DS3	Injection		MEV174	●	●	●	●
DS3	Injection		MEV17_4_2	●	●	●	●
DS4/C4(B7)	ABS/traction control		ABS81	●	●	●	●
DS4/C4(B7)	ABS/traction control		81 ESP	●	●	●	●
DS4/C4(B7)	Instrument panel			●	●	●	●
DS4/C4(B7)	Display		EMF_A_UDS	●	●	●	●
DS4/C4(B7)	Display		EMF_C_UDS	●	●	●	●
DS4/C4(B7)	Trailer relay unit			●	●	●	●
DS4/C4(B7)	Driver's seat memorizing unit			●	●	●	●
DS4/C4(B7)	Steering wheel with integral controls(VCI)			●	●	●	●
DS4/C4(B7)	Parking aid			●	●	●	●
DS4/C4(B7)	audio amplifier			●	●	●	○
DS4/C4(B7)	Telematics		RADIONAV_RNEGC	●	●	●	●
DS4/C4(B7)	Telematics		RNEG2010	●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data
DS4/C4 (B7)	Matrix screen integral to the instrument panel		MATT_C_2010	●	●	●	○
DS4/C4 (B7)	Matrix screen integral to the instrument panel		MATT_M_2010	●	●	●	○
DS4/C4 (B7)	Driver's door module			●	●	●	●
DS4/C4 (B7)	Switch module under the steering wheel		HDC	●	●	●	●
DS4/C4 (B7)	Switch module under the steering wheel		COM2008P	●	●	●	●
DS4/C4 (B7)	Lane departure warning system			●	●	●	●
DS4/C4 (B7)	gearbox		BVA_AL4	●	●	●	●
DS4/C4 (B7)	gearbox		BVA_AM6_AT6_EURO5	●	●	●	●
DS4/C4 (B7)	gearbox		CFC300P	●	●	●	●
DS4/C4 (B7)	Electric secondary brake			●	●	●	●
DS4/C4 (B7)	Power steering electric pump unit			●	●	●	●
DS4/C4 (B7)	Anti-theft alarm			●	●	●	●
DS4/C4 (B7)	Under inflation detection			●	●	●	●
DS4/C4 (B7)	Air conditioning ECU			●	●	●	●
DS4/C4 (B7)	Rain sensor			●	●	●	●
DS4/C4 (B7)	Radio			●	●	●	●
DS4/C4 (B7)	Air-bag			●	●	●	●
DS4/C4 (B7)	Seat belts not fastened LED unit			●	○	○	○
DS4/C4 (B7)	Multiplexed control panel			●	●	●	●
DS4/C4 (B7)	Monitoring of the blind spot			●	●	●	●
DS4/C4 (B7)	Engine ECU		DCM35_BR2	●	●	●	●
DS4/C4 (B7)	Engine ECU		EDC17C10_BR2	●	●	●	●
DS4/C4 (B7)	Engine ECU		HDI.SID807_BR2	●	●	●	●
DS4/C4 (B7)	Engine ECU		MEV17.4.2	●	●	●	●
DS4/C4 (B7)	Engine ECU		MED17.4.2	●	●	●	●
DS4/C4 (B7)	Engine ECU		ME745	●	●	●	●
DS4/C4 (B7)	Engine ECU		MEVD17.4.2	●	●	●	●
DS4/C4 (B7)	Discharge bulbs vertical and horizontal adjustment			●	●	●	●
DS4/C4 (B7)	Engine relay unit			●	●	●	●
DS4/C4 (B7)	Independent telematic unit (BTA)			●	●	●	●
DS4/C4 (B7)	Multiplexed additive adding pump			●	●	●	●
DS4/C4 (B7)	Battery charge status unit			●	●	●	●
DS4/C4 (B7)	Driving school module			●	●	●	○
DS4/C4 (B7)	Supply protection and management unit			●	●	●	●
DS4/C4 (B7)	Voltage retaining device			●	○	○	○

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data
DS5	ABS/traction control			●	●	●	●
DS5	Built-in Systems Interface			●	●	●	●
DS5	Engine ECU		HDI_SID807_BR2	●	●	●	●
DS5	Engine ECU		DCM35_HY	●	●	●	●
DS5	Engine ECU		DCM35_BR2	●	●	●	●
DS5	Engine ECU		MED17.4.2	●	●	●	●
DS5	Engine ECU		MEVD17.4.2	●	●	●	●
DS5	Gearbox		CFC300P_HY	●	●	●	●
DS5	gearbox		BVA_AM6_AT6_EUR05	●	●	●	●
DS5	Power steering electric pump unit			●	●	●	●
DS5	Electric steering lock			●	●	●	●
DS5	Multiplexed additive adding pump			●	●	●	●
DS5	Service module		BTA	●	●	●	●
DS5	Service module		BLVV	●	●	●	●
DS5	Supply protection and management unit			●	●	●	●
DS5	Battery charge status unit			●	●	●	●
DS5	Telematic navigator			●	●	●	●
DS5	Electric secondary brake			●	●	●	●
DS5	Trailer relay unit			●	●	●	●
DS5	Electronic key reader			●	●	●	●
DS5	Seat belts not fastened LED unit(TNB)			●	○	○	○
DS5	Instrument panel		COMBINE_UDS	●	●	●	●
DS5	Display		EMF_A	●	●	●	●
DS5	Display		EMF_C	●	●	●	●
DS5	Matrix screen integral to the instrument panel		COLOUR MATRIX SCREEN	●	●	●	●
DS5	Matrix screen integral to the instrument panel		MONOCHROME MATRIX SCREEN	●	●	●	●
DS5	Anti-theft alarm		Alarm with anti-lift module	●	●	●	●
DS5	Vibrators control ECU			●	●	●	●
DS5	Switch module under the steering wheel (top of column)			●	●	●	●
DS5	Hands-free control unit			●	●	●	●
DS5	Rain sensor			●	●	●	●
DS5	Hybrid mode selector			●	●	●	●
DS5	Traction battery ECU			●	●	●	●
DS5	Hybrid control ECU 1			●	●	●	●
DS5	Hybrid control ECU 2			●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data
DS5	Under inflation detection (DSG)			●	●	●	●
DS5	Parking aid			●	●	●	●
DS5	Driver's seat memorizing unit			●	●	●	●
DS5	Voltage retaining device			●	○	○	○
DS5	High head Vision			●	●	●	●
DS5	Multifunction camera or multifunction video camera			●	●	●	●
DS5	Air conditioning			●	●	●	●
DS5	audio amplifier			●	●	●	●
DS5	Discharge bulbs vertical and horizontal adjustment			●	●	●	●
DS5	Air-bag		RBG_UDS	●	●	●	●
DS5	Engine relay unit			●	●	●	●
DS5	Telematics		RADIONAV_RNEGC	●	●	●	●
DS5	Telematics		RNEG_2010	●	●	●	●
DS5	Radio			●	●	●	●
DS5	Steering wheel with integral controls(VCI)			●	●	●	●
DS5	Multiplexed control panel			●	●	●	●
DS5	Clock			●	●	●	●
DS5	Windscreen wiper			●	●	●	●
ELYSEE	Transponder			●			●
ELYSEE	Gearbox ECU	Auto gearbox AL4 TA96		●			●
ELYSEE	Gearbox ECU	Auto gearbox AL4 TA2000		●			●
ELYSEE	Gearbox ECU	Auto gearbox AL4 TA2000		●			●
ELYSEE	Gearbox ECU	Auto gearbox AL4 TA2000		●			●
ELYSEE	Airbag	Airbag		●			
ELYSEE	Airbag	Sac SIEMENS			●	●	●
ELYSEE	Anti-lock brake system			●			●
ELYSEE	Injection	1.6 L NFU BOSCH ME744		●	●	●	●
EVASION	Injection	Diesel engine	2.1 L P8C LUCAS EPIC	●			●
FUKANG/FUKANG 988	Gearbox ECU	Auto gearbox AL4 TA96		●			●
FUKANG/FUKANG 988	Gearbox ECU	Auto gearbox AL4 TA2000		●			●
FUKANG/FUKANG 988	Gearbox ECU	Auto gearbox AL4 TA2000		●			●
FUKANG/FUKANG 988	Gearbox ECU	Auto gearbox AL4 TA2000		●			●
FUKANG/FUKANG 988	Transponder			●			●
FUKANG/FUKANG 988	Injection	1.6 L NFU BOSCH ME744		●	●	●	●
FUKANG/FUKANG 988	Anti-lock brake system	ABS Bosch 5.3		●			●
FUKANG/FUKANG 988	Anti-lock brake system	ABS8.1_BOSCH		●	●	●	●
JUMPER	Injection	Petrol engine	2.0 L RFN MM48P	●	●	●	●



Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data
JUMPER 3	Injection/ ignition	Diesel engine	EDC16C39 SOFIM 3.0 145 CV		●	●	●
JUMPER 3	Injection/ ignition	Diesel engine	EDC16C39 SOFIM 3.0 145 CV FAP		●	●	●
JUMPER 3	Injection/ ignition	Diesel engine	DCU-102 4HU PUMA 120 CV		●	●	●
JUMPER 3	Injection/ ignition	Diesel engine	DCU-102 4HV PUMA 100 CV		●	●	●
JUMPER 3	ABS/ Electronic stability program	ESP8_BOSCH			●	●	●
JUMPER 3	Built-in Systems Interface (BSI)						●
JUMPER 3	Instrument panel			●	●	●	●
JUMPER 3	Parking aid			●	●	●	●
JUMPER 3	Air conditioning			●	●	●	●
JUMPER 3	Telematic	Telematic		●	●	●	●
JUMPER 3	Chrono-tachograph			●	●	●	●
JUMPER 3	ABS/ Electronic stability program	ABS8_BOSCH			●	●	●
JUMPER 3	ABS/ Electronic stability program	ASR8.0			●	●	●
JUMPER 3	Airbags			●			●
JUMPER 3	Power steering				●	●	●
JUMPER 3	Pneumatic suspension	Suspension			●	●	●
JUMPER 3	additional heating				●	●	●
JUMPER 3 Minibus	Injection/ ignition	Diesel engine	EDC16C39 SOFIM 3.0 145 CV		●	●	●
JUMPER 3 Minibus	Injection/ ignition	Diesel engine	EDC16C39 SOFIM 3.0 145 CV FAP		●	●	●
JUMPER 3 Minibus	Injection/ ignition	Diesel engine	DCU-102 4HU PUMA 120 CV		●	●	●
JUMPER 3 Minibus	Injection/ ignition	Diesel engine	DCU-102 4HV PUMA 100 CV		●	●	●
JUMPER 3 Minibus	Built-in Systems Interface (BSI)						●
JUMPER 3 Minibus	Instrument panel			●	●	●	●
JUMPER 3 Minibus	Parking aid			●	●	●	●
JUMPER 3 Minibus	Air conditioning			●	●	●	●
JUMPER 3 Minibus	Telematic	Telematic		●	●	●	●
JUMPER 3 Minibus	Chrono-tachograph			●	●	●	●
JUMPER 3 Minibus	Airbags			●			●
JUMPER 3 Minibus	Power steering				●	●	●
JUMPER 3 Minibus	Pneumatic suspension	Suspension			●	●	●
JUMPER 3 Minibus	additional heating				●	●	●
JUMPY	Auto gearbox			●			●
JUMPY	Auto gearbox			●			●
JUMPY	Auto gearbox			●			●
JUMPY	additional heating			●	●	●	●
JUMPY	Injection	Petrol engine	2.0 L RFN MM48P	●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data
JUMPY	Injection	Diesel engine	2.0 L RHW BOSCH EDC15C2	●	●	●	●
JUMPY	Injection	Diesel engine	2.0 L RHW BOSCH EDC15C2	●	●	●	●
JUMPY	Injection	Diesel engine	2.0 L RHZ BOSCH EDC15C2	●	●	●	●
JUMPY	Injection	Diesel engine	2.0 L RHZ BOSCH EDC15C2	●	●	●	●
JUMPY	Injection	Diesel engine	2.0 L RHX BOSCH EDC15C2	●	●	●	●
JUMPY	Injection	Diesel engine	2.0 L RHX BOSCH EDC15C2	●	●	●	●
JUMPY	Injection	Diesel engine	1.9 L WJY LUCAS DCN2	●	●	●	●
JUMPY 2	Auto gearbox	Auto gearbox AL4		●			●
JUMPY 2	Auto gearbox	Auto gearbox AL4		●			●
JUMPY 2	Auto gearbox	Auto gearbox AL4		●			●
JUMPY 2	additional heating			●	●	●	●
JUMPY 2	Airbag			●	●	●	
JUMPY 2	Injection	Petrol engine	2.0 L RFN MM48P	●	●	●	●
JUMPY 2	Injection	Diesel engine	2.0 L RHW BOSCH EDC15C2	●	●	●	●
JUMPY 2	Injection	Diesel engine	2.0 L RHZ BOSCH EDC15C2	●	●	●	●
JUMPY 2	Injection	Diesel engine	2.0 L RHX BOSCH EDC15C2	●	●	●	●
JUMPY 2	Injection	Diesel engine	1.9 L WJY LUCAS DCN2	●	●	●	●
JUMPY 2	Anti-lock brake system	ABS electronic distribution		●			●
JUMPY 3	BSI			●	●	●	●
JUMPY 3	Instrument panel			●	●	●	●
JUMPY 3	Radio	Radio post-equipment		●	●	●	●
JUMPY 3	CD player			●	●	●	●
JUMPY 3	Parking aid			●	●	●	●
JUMPY 3	Air conditioning			●	●	●	●
JUMPY 3	Rear air conditioning table			●	●	●	●
JUMPY 3	Switch module under the steering wheel	Top of column		●	●	●	●
JUMPY 3	Alarm			●	●	●	●
JUMPY 3	Rain sensor/ Brightness			●	●	●	
JUMPY 3	Airbag			●	●	●	●
JUMPY 3	Multifunction screen	Multifunction screen A		●	●	●	●
JUMPY 3	Multifunction screen	Multifunction screen C		●	●	●	●
JUMPY 3	Telematic	Telematics (RT3)		●	●	●	●
JUMPY 3	Telematic	Telematic (RT4)		●	●	●	●
JUMPY 3	Telematic	Telematic (RT5)		●	●	●	●
JUMPY 3	Telematic	RNEG navigation radio		●	●	●	●
JUMPY 3	Power steering	Electric power steering ECU		●	●	●	●
JUMPY 3	Pneumatic suspension	Suspension		●	●	●	●
JUMPY 3	additional heating			●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data
JUMPY 3	Trailer relay unit			●	●	●	●
JUMPY 3	Engine relay unit			●	●	●	●
JUMPY 3	Hands Free Kit	Mobile Housing		●	●	●	●
JUMPY 3	Bodywork Conversion Unit			●	●	●	●
JUMPY 3	Injection/ Ignition	Petrol engine	RFH MM6KP	●	●	●	●
JUMPY 3	Injection/ Ignition	Diesel engine	9HU BOSCH EDC16C34 DV6UTD4 - 90CV	●	●	●	●
JUMPY 3	Injection/ Ignition	Diesel engine	RHR SIEMENS SID803A		●	●	
JUMPY 3	Injection/ Ignition	Diesel engine	RHK SIEMENS SID803A		●	●	
JUMPY 3	Injection/ Ignition	Diesel engine	RHG SIEMENS SID803A		●	●	
JUMPY 3	ABS/ Electronic stability program	ABS8.1_BOSCH		●	●	●	●
JUMPY 3	ABS/ Electronic stability program	ABS8_BOSCH			●	●	
JUMPY 3	ABS/ Electronic stability program	ESP8_BOSCH		●	●	●	
JUMPY 3	ABS/ Electronic stability program	ESP8.1_BOSCH		●	●	●	●
NEMO	BSI			●			●
NEMO	Gearbox	Gearbox BVMP_MAP		●	●	●	●
NEMO	Driver's and passenger's airbags	Airbag		●	●	●	●
NEMO	Instrument panel			●	●	●	●
NEMO	Parking aid			●	●	●	●
NEMO	Injection/ Ignition	Petrol engine	KFV V34P	●	●	●	●
NEMO	Injection/ Ignition	Petrol engine	V34.2	●	●	●	●
NEMO	Injection/ Ignition	Diesel engine	8HS BOSCH EDC16C34	●	●	●	●
NEMO	Anti-lock Braking System (ABS) / Electronic Stability Program (ESP)	ABS		●	●	●	●
SAXO	Electrical vehicle	Electric motor		●			
SAXO	additional heating			●	●	●	●
SAXO	Transponder	Transponder VALEO		●			●
SAXO	Injection	Petrol engine	1.0 L CDY/CDZ BOSCH MA3.1	●			●
SAXO	Injection	Petrol engine	1.1 L HDY/HDZ BOSCH MA3.1	●			●
SAXO	Injection	Petrol engine	1.1 L HFX BOSCH M7.4.4	●	●	●	●
SAXO	Injection	Petrol engine	1.4 L KFW SAGEM S2000	●			●
SAXO	Injection	Petrol engine	1.4 L KFW SAGEM S2000	●			●
SAXO	Injection	Petrol engine	1.4 L KFX MM1AP	●			●
SAXO	Injection	Petrol engine	1.4 L KFX BOSCH MP7.3	●			●
SAXO	Injection	Petrol engine	1.6 L NFX MM48P	●	●	●	●
SAXO	Injection	Petrol engine	1.6 L NFT BOSCH M7.4.4	●	●	●	●
SAXO	Injection	Petrol engine	1.6 L NFX MM1AP	●			●
SAXO	Injection	Petrol engine	1.6 L NFZ BOSCH MP7.2	●			●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data
SAXO	Injection	Diesel engine	1.5L VJX/VJU BOSCH AS4-VP20	●			●
SAXO	Anti-lock brake system	ABS		●			●
XANTIA 2	Injection	Petrol engine	1.8 L LFX MM1AP				●
XANTIA 2	Injection	Petrol engine	1.8 L LFY SAGEM SL96	●			●
XANTIA 2	Injection	Petrol engine	1.8 L LFY BOSCH MP7.3	●			●
XANTIA 2	Injection	Petrol engine	3.0 L XFZ BOSCH MP7.0	●			●
XANTIA 2	Injection	Diesel engine	2.1 L P8C LUCAS EPIC	●			●
XANTIA 2	Injection	Diesel engine	2.0 L RHZ BOSCH EDC15C2	●			●
XANTIA 2	Injection	Diesel engine	2.0 L RHZ BOSCH EDC15C2	●			●
XANTIA 2	Injection	Diesel engine	2.0 L RHZ BOSCH EDC15C2	●	●	●	●
XANTIA 2	Injection	Diesel engine	2.0 L RHY BOSCH EDC15C2	●			●
XANTIA 2	Injection	Diesel engine	2.0 L RHY BOSCH EDC15C2	●			●
XANTIA 2	Injection	Diesel engine	2.0 L RHY BOSCH EDC15C2	●	●	●	●
XANTIA 2	additional heating			●	●	●	●
XANTIA 2	Right hand side airbag			●			
XANTIA 2	Left hand side airbag			●			
XANTIA 2	Auto gearbox	Auto gearbox ZF 4HP20		●			●
XANTIA 2	Auto gearbox	Auto gearbox AL4		●			●
XM/XM MULTIPLEXEE	Injection	2.1 L P8C LUCAS EPIC		●			●
XSARA	Injection	Petrol engine	1.4 L KFX MM1AP	●			●
XSARA	Injection	Petrol engine	1.4 L KFX BOSCH MP7.3	●			●
XSARA	Injection	Petrol engine	1.4L KFX SAGEM SL96	●			●
XSARA	Injection	Petrol engine	1.6 L NFZ BOSCH MP7.2	●			●
XSARA	Injection	Petrol engine	1.8 L LFX MM1AP	●			●
XSARA	Injection	Petrol engine	1.8L LFY SAGEM SL96	●			●
XSARA	Injection	Petrol engine	2.0 L RFS MM1AP	●			●
XSARA	Injection	Diesel engine	2.0 L RHY BOSCH EDC15C2	●			●
XSARA	Injection	Diesel engine	2.0 L RHY BOSCH EDC15C2	●	●	●	●
XSARA	Injection	Petrol engine	1.4 L KFX BOSCH MP7.3	●			●
XSARA	Injection	Petrol engine	1.4L KFX SAGEM SL96	●			●
XSARA	Injection	Petrol engine	1.6 L NFZ BOSCH MP7.2	●			●
XSARA	Injection	Petrol engine	1.8 L LFX MM1AP	●			●
XSARA	Injection	Petrol engine	1.8L LFY SAGEM SL96	●			●
XSARA	Injection	Petrol engine	2.0 L RFS MM1AP	●			●
XSARA	Injection	Diesel engine	2.0 L RHY BOSCH EDC15C2	●			●
XSARA	Injection	Diesel engine	2.0 L RHY BOSCH EDC15C2	●	●	●	●
XSARA	additional heating			●	●	●	●
XSARA	Anti-lock brake system	ABS mechanical distribution		●			●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data
XSARA	Airbag			●			
XSARA	Airbag			●			
XSARA	Left hand side airbag			●			
XSARA	Right hand side airbag			●			
XSARA	BSI			●			●
XSARA	Radio post-equipment			●			●
XSARA	CD player			●			●
XSARA	Instrument panel			●			
XSARA	additional heating			●	●	●	●
XSARA	Anti-lock brake system	ABS electronic distribution		●			●
XSARA	Anti-lock brake system	ABS mechanical distribution		●			●
XSARA	Airbag			●			
XSARA	Left hand side airbag			●			
XSARA	Right hand side airbag			●			
XSARA	Auto gearbox	Auto gearbox AL4		●			●
XSARA	Anti-lock brake system	ABS electronic distribution		●			●
XSARA 2	BSI			●			●
XSARA 2	Navigation			●	●	●	●
XSARA 2	Instrument panel			●			●
XSARA 2	Air conditioning			●	●	●	●
XSARA 2	Radio post-equipment			●	●	●	●
XSARA 2	CD player			●			●
XSARA 2	Parking aid			●			●
XSARA 2	Top of column				●	●	
XSARA 2	Alarm				●	●	
XSARA 2	Driving school mode			●			●
XSARA 2	Display or Autopc	Multifunction display A		●	●	●	●
XSARA 2	Display or Autopc	Multifunction display B		●	●	●	●
XSARA 2	Display or Autopc	Multifunction display C		●	●	●	●
XSARA 2	Display or Autopc	AUTOPC		●	●	●	
XSARA 2	Auto gearbox	Auto gearbox AL4		●			●
XSARA 2	Airbag			●	●	●	
XSARA 2	BSI			●			●
XSARA 2	Navigation			●	●	●	●
XSARA 2	Instrument panel			●			●
XSARA 2	Air conditioning			●	●	●	●
XSARA 2	Radio post-equipment			●	●	●	●
XSARA 2	Car-phone			●	●	●	●
XSARA 2	CD player			●			●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data
XSARA 2	Parking aid			●			●
XSARA 2	Switch module at the steering wheel	Top of column			●	●	
XSARA 2	Alarm				●	●	
XSARA 2	Driving school mode			●			●
XSARA 2	Rain sensor/ Brightness				●	●	
XSARA 2	Airbag			●	●	●	
XSARA 2	Injection	Petrol engine	2.0L RFN MM48P	●	●	●	●
XSARA 2	Injection	Petrol engine	2.0L RFS MM48P	●	●	●	●
XSARA 2	Injection	Petrol engine	1.6L NFU BOSCH ME744	●	●	●	●
XSARA 2	Injection	Petrol engine	1.4L KFW SAGEM S2000P	●			●
XSARA 2	Injection	Petrol engine	1.4L KFW SAGEM S2000P	●			●
XSARA 2	Injection	Diesel engine	2.0 L RHY BOSCH EDC15C2	●	●	●	●
XSARA 2	Injection	Diesel engine	1.9L WJY LUCAS DCN2	●	●	●	●
XSARA 2	Injection	Diesel engine	RHY SIEMENS SID801	●	●	●	●
XSARA 2	Injection	Diesel engine	8HZ BOSCH EDC16C3 (DV4)		●	●	
XSARA 2	Injection	Petrol engine	RFN MM4MP2	●	●	●	●
XSARA 2	Injection	Petrol engine	RFN MM6LP	●	●	●	●
XSARA 2	Anti-lock brake system	ABS electronic distribution		●			●
XSARA 2	Anti-lock brake system	ESP	ESP_BOSCH5.7	●			●
XSARA PICASSO	Injection	Petrol engine	1.6L NFZ BOSCH MP7.2	●			●
XSARA PICASSO	Injection	Petrol engine	1.6L NFV BOSCH M744	●	●	●	●
XSARA PICASSO	Injection	Petrol engine	2.0L RFM MM48P	●	●	●	●
XSARA PICASSO	Injection	Petrol engine	1.8L 6FZ SAGEM S2000P	●			●
XSARA PICASSO	Injection	Petrol engine	1.8L 6FZ SAGEM S2000P	●			●
XSARA PICASSO	Injection	Petrol engine	6FZ SAGEM S2000PM1		●	●	
XSARA PICASSO	Injection	Petrol engine	6FZ SAGEM S2000PM1		●	●	
XSARA PICASSO	Injection	Petrol engine	6FZ SAGEM S2000PM2		●	●	
XSARA PICASSO	Injection	Petrol engine	NFS BOSCH ME745	●	●	●	●
XSARA PICASSO	BSI ECU			●			●
XSARA PICASSO	Navigation			●	●	●	●
XSARA PICASSO	Multifunction display	Multifunction display VDO B		●	●	●	●
XSARA PICASSO	Multifunction display	Multifunction display VDO C		●	●	●	●
XSARA PICASSO	Air conditioning			●	●	●	●
XSARA PICASSO	Radio post-equipment			●	●	●	●
XSARA PICASSO	CD player			●	●	●	●
XSARA PICASSO	Instrument panel			●	●	●	●
XSARA PICASSO	Injection	Petrol engine	NFU BOSCH ME745	●	●	●	●
XSARA PICASSO	Injection	Petrol engine	N6A BOSCH ME745	●	●	●	●
XSARA PICASSO	Injection	Petrol engine	NFR BOSCH ME745	●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data
XSARA PICASSO	Injection	Diesel engine	2.0 L BOSCH EDC15C2	●	●	●	●
XSARA PICASSO	Injection	Diesel engine	2.0 L BOSCH EDC15C2	●	●	●	●
XSARA PICASSO	Diesel additive function			●	●	●	●
XSARA PICASSO	Additional heating			●	●	●	●
XSARA PICASSO	Airbag			●			
XSARA PICASSO	Left hand side airbag			●			
XSARA PICASSO	Right hand side airbag			●			
XSARA PICASSO	Anti-lock brake system	ABS electronic distribution		●			●
XSARA PICASSO	Anti-lock brake system	ESP		●	●	●	●
XSARA PICASSO CHINE	BSI			●	●	●	●
XSARA PICASSO CHINE	Navigation				●	●	
XSARA PICASSO CHINE	Air conditioning			●	●	●	●
XSARA PICASSO CHINE	Instrument panel			●	●	●	●
XSARA PICASSO CHINE	Radio post-equipment			●	●	●	●
XSARA PICASSO CHINE	CD player			●	●	●	●
XSARA PICASSO CHINE	Parking aid			●	●	●	●
XSARA PICASSO CHINE	Alarm				●	●	
XSARA PICASSO CHINE	Switch module at the steering wheel	Top of column			●	●	
XSARA PICASSO CHINE	Rain sensor/ Brightness				●	●	
XSARA PICASSO CHINE	Airbag			●	●	●	
XSARA PICASSO CHINE	Multifunction display	Multifunction display SAGEM B		●	●	●	●
XSARA PICASSO CHINE	Multifunction display	Multifunction display SIEMENS C		●	●	●	●
XSARA PICASSO CHINE	Telematic	RASTREADOR		●	●	●	●
XSARA PICASSO CHINE	Auto gearbox	Auto gearbox AL4		●			●
XSARA PICASSO CHINE	additional heating			●	●	●	●
XSARA PICASSO CHINE	Diesel additive function			●	●	●	●
XSARA PICASSO CHINE	Injection	Petrol engine	RFN MM6LP	●	●	●	●
XSARA PICASSO CHINE	Injection	Petrol engine	6FZ SAGEM S2000PM1		●	●	
XSARA PICASSO CHINE	Injection	Petrol engine	6FZ SAGEM S2000PM1		●	●	
XSARA PICASSO CHINE	Injection	Petrol engine	6FZ SAGEM S2000PM2		●	●	
XSARA PICASSO CHINE	Injection	Petrol engine	1.6L NFV BOSCH M744	●	●	●	●
XSARA PICASSO CHINE	Injection	Petrol engine	NFS BOSCH ME745	●	●	●	●
XSARA PICASSO CHINE	Injection	Petrol engine	NFU BOSCH ME745	●	●	●	●
XSARA PICASSO CHINE	Injection	Petrol engine	N6A BOSCH ME745	●	●	●	●
XSARA PICASSO CHINE	Injection	Petrol engine	NFR BOSCH ME745	●	●	●	●
XSARA PICASSO CHINE	Injection	Petrol engine	NFS BOSCH ME749	●	●	●	●
XSARA PICASSO CHINE	Injection	Petrol engine	NFU BOSCH ME749	●	●	●	●
XSARA PICASSO CHINE	Anti-lockbrake system	ABS8.1_BOSCH		●	●	●	●

Vehicle	System	EngType	ECU Name	Ecu Info.	Read Codes	Erase Codes	Live Data
XSARA PICASSO CHINE	Anti-lock brake system	ABS8_BOSCH			●	●	
XSARA PICASSO CHINE	Anti-lock brake system	ABR5.3		●			●
XSARA PICASSO CHINE	Injection	Petrol engine	N6A BOSCH ME749	●	●	●	●
XSARA PICASSO CHINE	Injection	Diesel engine	2.0 L BOSCH EDC15C2	●	●	●	●
XSARA PICASSO CHINE	Injection	Diesel engine	9HY BOSCH EDC16C3 DV6TED4	●	●	●	●
XSARA PICASSO CHINE	Injection	Diesel engine	9HZ (FAP) BOSCH EDC16C34 DV6TED4	●	●	●	●
XSARA PICASSO CHINE	Anti-lock brake system	ESP8.1_BOSCH		●	●	●	●
XSARA PICASSO CHINE	Anti-lock brake system	ESP_BOSCH5.7		●	●	●	●
XSARA PICASSO CHINE	Anti-lock brake system	ESP8_BOSCH			●	●	
ZX	Engine	Petrol engine	1.1 L HDY/HDZ BOSCH MA3.1	●			●
ZX	Engine	Petrol engine	1.4 L KFX MM1AP	●			●
ZX	Engine	Petrol engine	1.4 L KFX MM1AP	●			●
ZX	Engine	Petrol engine	1.6 L BFZ SAGEM CCM4GJ	●			●
ZX	Engine	Petrol engine	2.0 L RFS MM1AP	●			●
ZX	Engine	Petrol engine	2.0 L RFS MM1AP	●			●
ZX	Driving assistance	ABS BOSCH 5		●			●
ZX	Auto gearbox	BVA_AL4		●	●	●	●