

MaxiSys_Chrysler_V4.00 Function List (Note:For reference only)

NOTES:

- This function is supported. ✖ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.**

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
1996~2003	All Model	PCM	●	●	●	●	●	●	○	C000 C001 C002 C003 C004 C005 C006 C007 C008 C009 C00A C00B C00C C00D C00E C00F C010 C011 C012 C013 C014 C015 C016 C017 C018 C019
1996~2003	All Model	TCM	○	●	●	●	●	●	○	C02D C02E C02F C030 C031 C032 C033 061F 0391 0625 0626
1996~2003	All Model	ABS	○	●	●	●	○	●	○	002F 0577 0578
1996~2003	All Model	ORC	○	●	●	●	○	○	○	0622 0623
1996~2003	All Model	SKM	○	●	●	●	○	●	○	C01A C01B C01C C01D C01E C01F C020 C021 C022 C023 C024 C025 C026 C027 C028 C029 C02A C02B C02C
1996~2003	All Model	APM	○	●	●	●	○	●	○	0579
1996~2003	All Model	ATC	○	●	●	●	○	●	○	057A 057B 057C
1996~2003	All Model	AUD	○	●	●	●	○	○	○	057D 057E 057F
1996~2003	All Model	BCM	○	●	●	●	○	●	○	0581 008F 003D 0582 0583 0584 0585 057A 0586 0587 0588 0589 058A 008E 058B 058C 058D 058E 058F 0590 0591 0592 049F 0593 0594 0595 0596 0597 0598 0599 059A 059C 059D 059E 059F 0600 0601
1996~2003	All Model	CMT	○	●	●	○	○	○	○	
1996~2003	All Model	DAA	○	●	●	○	○	○	○	0602 0603 0604 0605 0606 0607 01C8 0608 0609
1996~2003	All Model	DDM	○	●	●	●	○	●	○	060A 057A 060B 0592 060C
1996~2003	All Model	DSD	○	●	●	●	○	●	○	060D 057A
1996~2003	All Model	FCM	○	●	●	●	○	●	○	060E 060F 003F 003D 0610 0611 0612
1996~2003	All Model	FDC	○	●	●	●	○	○	○	0613
1996~2003	All Model	HFM	○	●	●	●	○	●	○	057A
1996~2003	All Model	HVA	○	●	●	●	○	●	○	0614 0615 0616 0617 0618
1996~2003	All Model	LSA	○	●	●	○	○	○	○	
1996~2003	All Model	MIC	○	●	●	●	○	●	○	
1996~2003	All Model	MSM	○	●	●	●	○	●	○	
1996~2003	All Model	NAV	○	●	●	○	○	○	○	0619
1996~2003	All Model	OCM	○	○	○	●	○	○	○	057A 0620 0621 0608
1996~2003	All Model	PAM	○	●	●	●	○	○	○	
1996~2003	All Model	PDM	○	●	●	●	○	●	○	0610 060B 057A 0592 060C
1996~2003	All Model	PLM	○	●	●	●	○	●	○	0624 061A 060D 061B 00B4 00B5 057A 061C 061D
1996~2003	All Model	PSD	○	●	●	●	○	●	○	0624 061A 060D 061B 00B4 00B5 057A
1996~2003	All Model	RSA	○	●	●	○	○	○	○	
1996~2003	All Model	RSM	○	●	●	○	○	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
1996~2003	All Model	SAR	○	●	●	○	○	●	○	057F
1996~2003	All Model	SLA	○	○	○	●	○	●	○	
1996~2003	All Model	SRM	○	○	○	●	○	●	○	
1996~2003	All Model	VIC	○	●	●	○	○	○	○	
1996~2003	All Model	VTS	○	○	○	●	○	●	○	0627 0628 008F 0582 0583 0587 0629 062A 062B 062C
1996~2003	All Model	XCM	○	○	○	●	○	●	○	062D
2004	Durango (Pre-2011)	VES	●	●	●	●	●	●	○	
2004	Durango (Pre-2011)	ORC	●	●	●	●	●	○	●	
2004	Durango (Pre-2011)	HFM	●	●	●	●	●	●	○	00E3 0081
2004	Durango (Pre-2011)	AMP	●	●	●	●	●	○	●	0289 028A 006D 006B 006C 0068 006A 0081
2004	Durango (Pre-2011)	MSMD	●	●	●	●	●	○	○	02EE 00BC 0114 0116 0118 0117 0115 0119
2004	Durango (Pre-2011)	FCMCGW	●	●	●	●	●	●	●	0039 003C 003D 0032 003F 003E 0036 0037 0035 0034 0038 003A 0349 0033 0040
2004	Durango (Pre-2011)	TCM	●	●	●	●	○	●	●	0167 0166 01EE 016A 0169 016C 016B 016E 016D 01F0 0172 0177 0170 016F 0175
2004	Durango (Pre-2011)	WCM	●	●	●	●	●	○	●	01D2 0228 0226 0225 0227
2004	Durango (Pre-2011)	PCM	●	●	●	●	●	●	●	0127 0126 0044 0129 026C 026D 0128 012E 012F 012C 012D 0173 012A 0081 012B 013B
2004	Durango (Pre-2011)	EOM	●	●	●	●	●	●	●	00BA
2004	Durango (Pre-2011)	HSM	●	●	●	●	●	●	○	
2004	Durango (Pre-2011)	HVAC	●	●	●	●	●	●	○	00EA 00E8 0378 00E9 0324
2004	Durango (Pre-2011)	PDM	●	●	●	●	●	●	●	0081
2004	Durango (Pre-2011)	RADIO	●	●	●	●	●	○	○	01BB 0081
2004	Durango (Pre-2011)	DDM	●	●	●	●	●	●	●	00AC 0081
2004	Durango (Pre-2011)	OCM	●	●	●	●	●	○	○	011E
2004	Durango (Pre-2011)	CCN	●	●	●	●	●	●	●	008C 008F 008E 0091 008D 0090
2004	Durango (Pre-2011)	ABS	●	●	●	●	●	●	●	0031 002E 0081 002F 0030
2004	Durango (Pre-2011)	SDAR	●	●	●	●	●	○	○	01C8 0081
2005	Durango (Pre-2011)	WCM	●	●	●	●	●	○	●	01D2 0228 0226 0225 0227
2005	Durango (Pre-2011)	HVAC	●	●	●	●	●	●	○	00EA 00E8 0378 00E9 0324
2005	Durango (Pre-2011)	ORC	●	●	●	●	●	○	●	
2005	Durango (Pre-2011)	TCM	●	●	●	●	○	●	●	0167 0166 01EE 016A 0169 016C 016B 016E 016D 01F0 0172 0177 0170 016F 0175
2005	Durango (Pre-2011)	RADIO	●	●	●	●	●	○	○	01BB 0081
2005	Durango (Pre-2011)	OCM	●	●	●	●	●	○	○	011E
2005	Durango (Pre-2011)	SDAR	●	●	●	●	●	○	○	01C8 0081
2005	Durango (Pre-2011)	PDM	●	●	●	●	●	●	●	0081
2005	Durango (Pre-2011)	HSM	●	●	●	●	●	●	○	
2005	Durango (Pre-2011)	VES	●	●	●	●	●	●	○	
2005	Durango (Pre-2011)	FCMCGW	●	●	●	●	●	●	●	0039 003C 003D 0032 003F 003E 0036 0037 0035 0034 0038 003A 0349 0033 0040
2005	Durango (Pre-2011)	HFM	●	●	●	●	●	●	○	00E3 0081
2005	Durango (Pre-2011)	DDM	●	●	●	●	●	●	●	00AC 0081
2005	Durango (Pre-2011)	CCN	●	●	●	●	●	●	●	008C 008F 008E 0091 008D 0090

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2005	300 / Magnum / Charger (Pre-2011)	FCMCGW	●	●	●	●	●	●	●	0039 003C 003D 0032 003F 003E 0036 0037 0035 0034 0038 003A 002E 0349 0033
2005	300 / Magnum / Charger (Pre-2011)	TCM	●	●	●	●	●	●	●	0167 0166 01EE 016A 0169 016C 016B 016E 016D 01F0 0172 01F1 0177 01EF 0175 01F4 0081 01F3 01F2
2005	300 / Magnum / Charger (Pre-2011)	HFM	●	●	●	●	●	●	○	00E3 0081
2005	300 / Magnum / Charger (Pre-2011)	PCM	●	●	●	●	●	●	●	0127 0126 0044 0129 026C 026D 0128 012E 012F 012C 012D 0173 012A 0081 012B 013B 013C
2005	300 / Magnum / Charger (Pre-2011)	PDM	●	●	●	●	●	●	●	0081
2005	300 / Magnum / Charger (Pre-2011)	HIDT	●	●	●	●	●	●	○	00E5
2005	Dakota	EOM	●	●	●	●	●	○	●	00BA
2005	Dakota	RADIO	●	●	●	●	●	○	○	01BB 0081
2005	Dakota	OCM	●	●	●	●	●	○	○	011E
2005	Dakota	CCN	●	●	●	●	●	●	●	008C 008F 008E 0091 008D 0090
2005	Dakota	WCM	●	●	●	●	●	○	●	01D2 0228 0226 0225 0227
2005	Dakota	HVAC	●	●	●	●	●	●	●	00EA 00E8 00E9 0324 02EA 02EB 0081
2005	Dakota	AMP	●	●	●	●	●	○	●	0289 028A 006D 006B 006C 0068 006A 0081
2005	Dakota	TCM	●	●	●	●	○	●	●	0167 0166 01EE 016A 0169 016C 016B 016E 016D 01F0 0172 0177 0170 016F 0175
2005	Dakota	PCM	●	●	●	●	●	●	●	0127 0126 0044 0129 026C 026D 0128 012E 012F 013C 012C 012D 0173 012A 0081 012B 013B
2005	Dakota	ABS	●	●	●	●	●	●	●	005A 0002 005E
2005	Dakota	SDAR	●	●	●	●	●	○	○	01C8 0081
2005	Dakota	ORC	●	●	●	●	●	○	●	
2005	Dakota	HFM	●	●	●	●	●	●	○	00E3 0081
2005	Dakota	FCMCGW	●	●	●	●	●	●	●	003C 003D 0032 00C4 003F 003E 0036 0037 0034 0038 003A 002E 0349 0033
2005	Grand Cherokee	HVAC	●	●	●	●	●	●	○	00EA 00E9
2005	Grand Cherokee	SUNR	●	●	●	●	●	●	○	
2005	Grand Cherokee	RADIO	●	●	●	●	●	○	○	01BB 0081
2005	Grand Cherokee	TCM	●	●	●	●	●	●	●	0167 0166 01EE 016A 0169 016C 016B 016E 016D 01F0 0172 0177 0170 016F 0175 01F4 0081 01F3 01F2
2005	Grand Cherokee	WCM	●	●	●	●	●	○	●	022E 01D2 0228 0226 0225 0232 0230 0231 022F 01DE 022D 0227 0274
2005	Grand Cherokee	SDAR	●	●	●	●	●	○	○	01C8 0081
2005	Grand Cherokee	VES	●	●	●	●	●	●	○	
2005	Grand Cherokee	AHBM	●	●	●	●	●	●	○	0066
2005	Grand Cherokee	FDCM	●	●	●	●	●	●	●	0081
2005	Grand Cherokee	ESM	●	●	●	●	●	●	○	
2005	Grand Cherokee	EOM	●	●	●	●	●	○	●	00BA

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2005	Grand Cherokee	PCM	●	●	●	●	●	●	●	0127 0126 0044 0129 026C 026D 0128 012E 012F 013C 012C 012D 0173 012A 0081 012B 013B 0042 0149 0142 0145 0384 014B 014A 0148 0049 0146 0147
2005	Grand Cherokee	FCMCGW	●	●	●	●	●	●	●	0039 003C 003D 0032 003F 003E 0036 0037 0035 0034 0038 003A 0373 0374 0375 0033 0040
2005	Grand Cherokee	ORC	●	●	●	●	●	○	●	
2005	Grand Cherokee	ITM	●	●	●	●	●	●	●	0104 0105 0107 0385 0106
2005	Grand Cherokee	ABS	●	●	●	●	●	●	●	005A 0058 0059 005E 005C 005D 005F 005B
2005	Grand Cherokee	PTS	●	●	●	●	●	●	○	01B4 01B3 01B5 0081
2005	Grand Cherokee	PDM	●	●	●	●	●	●	●	0081
2005	Grand Cherokee	SCM	●	●	●	●	●	○	●	0081
2005	Grand Cherokee	OCM	●	●	●	●	●	○	○	011E
2005	Grand Cherokee	AMP	●	●	●	●	●	○	●	0289 028A 006D 006B 006C 0068 006A 0081
2005	Grand Cherokee	LRSM	●	●	●	●	●	○	○	010D
2005	Grand Cherokee	DDM	●	●	●	●	●	●	●	00AC 0081
2005	Grand Cherokee	MSMD	●	●	●	●	●	○	○	02EE 00BC 0114 0116 0118 0117 0115 0119
2005	Grand Cherokee	CCN	●	●	●	●	●	●	●	0097 008C 008F 008E 0091 0090
2005	Grand Cherokee	HSM	●	●	●	●	●	●	○	
2005	Grand Cherokee	HFM	●	●	●	●	●	●	○	00E3 0081
2006	Dodge Ram	FDCM	●	●	●	●	●	○	○	02B4 02B7 02B6 02B5 02B3 02B2 02B1 02AF 02B0 0081
2006	Dodge Ram	OCM	●	●	●	●	●	○	○	011E
2006	Dodge Ram	HFM	●	●	●	●	●	●	○	00E3 0081
2006	Dodge Ram	SUNR	●	●	●	●	●	●	○	
2006	Dodge Ram	AMP	●	●	●	●	●	○	●	028A 028D 006D 006C 027F 0068 006A 0081
2006	Dodge Ram	HVAC	●	●	●	●	●	●	●	00EA 00E8 00E9 0324 02EA 02EB 0081 00EB
2006	Dodge Ram	TIPMCGW	●	●	●	●	●	●	●	033E 030D 0039 030E 030C 003C 003D 0214 0032 0210 003F 003E 0036 0037 0035 0034 0038 003A 020E 0213 0215 028F 0211 0387 003B 0316 0033
2006	Dodge Ram	ABS	●	●	●	●	●	●	●	0002 0285 0062
2006	Dodge Ram	PCM	●	●	●	●	●	●	●	0127 0126 0044 0129 026C 026D 0128 012E 012F 013C 012C 012D 013B 0173 012A 0081 012B 0156 0157 0154 0155 0141 0150 0151 0153 015A 0159 037D 0158 014F 0152
2006	Dodge Ram	SDAR	●	●	●	●	●	○	○	01C8 0081
2006	Dodge Ram	TCM	●	●	●	●	○	●	●	0167 0166 01EE 016A 0169 016C 016B 016E 016D 01F0 0172 0177 0170 016F 0175
2006	Dodge Ram	VES	●	●	●	●	●	●	○	
2006	Dodge Ram	CCN	●	●	●	●	●	●	○	008C 008F 008E 0090
2006	Dodge Ram	EOM	●	●	●	●	●	○	●	00BA
2006	Dodge Ram	ORC	●	●	●	●	●	○	●	
2006	Dodge Ram	RADIO	●	●	●	●	●	○	●	01BB 0081
2006	Dodge Ram	WCM	●	●	●	●	●	○	●	0242 01D2 0228 023F 0226 0225 0232 0230 0231 022F 01DE 0244 0233 022D 0241 023D 023E 0271 0270

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2006	Liberty	SKREEM	●	●	●	●	●	○	○	
2006	Liberty	RADIO	●	●	●	●	●	●	●	
2006	Liberty	MIC/CCN	●	●	●	●	○	●	○	
2006	Liberty	ITM	●	○	○	●	○	●	○	
2006	Liberty	HFM	●	●	●	●	○	●	○	
2006	300 / Magnum / Charger (Pre-2011)	PTIM	●	●	●	●	●	●	●	
2006	300 / Magnum / Charger (Pre-2011)	PTS	●	●	●	●	○	●	○	01B4 01B3 01B5 0081
2006	300 / Magnum / Charger (Pre-2011)	SDAR	●	●	●	●	●	○	○	01C8 0081
2006	300 / Magnum / Charger (Pre-2011)	OCM	●	●	●	●	●	○	○	011E
2006	300 / Magnum / Charger (Pre-2011)	AMP	●	●	●	●	●	○	●	0289 028B 028A 006D 006B 0073 006C 0068 006A 0081 0069
2006	300 / Magnum / Charger (Pre-2011)	HIDT	●	●	●	●	●	●	○	00E5
2006	300 / Magnum / Charger (Pre-2011)	WCM	●	●	●	●	●	○	●	022E 01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0244 0233 022D 023D 023E 0271 0270 0227
2006	300 / Magnum / Charger (Pre-2011)	HFM	●	●	●	●	●	●	○	00E3 0081
2006	300 / Magnum / Charger (Pre-2011)	ORC	●	●	●	●	●	●	●	0081 0122
2006	300 / Magnum / Charger (Pre-2011)	VES	●	●	●	●	●	●	○	
2006	300 / Magnum / Charger (Pre-2011)	SUNR	●	●	●	●	●	●	○	
2006	300 / Magnum / Charger (Pre-2011)	RADIO	●	●	●	●	●	○	●	01BB 0081
2006	300 / Magnum / Charger (Pre-2011)	FCMCGW	●	●	●	●	●	●	●	0039 003C 003D 0032 003F 003E 0036 0037 0035 0034 00C8 003A 002E 0320 0033
2006	300 / Magnum / Charger (Pre-2011)	ITM	●	●	●	●	●	●	●	0104 0105 0107 0385 0106 0081
2006	300 / Magnum / Charger (Pre-2011)	EOM	●	●	●	●	●	○	●	00BA
2006	300 / Magnum / Charger (Pre-2011)	MSMD	●	●	●	●	●	○	○	02EE 00BC 0114 0116 0118 0117 0115 0119
2006	300 / Magnum / Charger (Pre-2011)	ESM	●	●	●	●	●	●	○	
2006	300 / Magnum / Charger (Pre-2011)	DDM	●	●	●	●	●	●	●	00AC 0081
2006	300 / Magnum / Charger (Pre-2011)	TCM	●	●	●	●	●	●	●	01F4 0081 01F3 01F2 0167 0166 01EE 016A 0169 016C 016B 016E 016D 01F0 0172 01F1 0177 01EF 0175

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2006	300 / Magnum / Charger (Pre-2011)	LRSM	●	●	●	●	●	○	○	010D
2006	300 / Magnum / Charger (Pre-2011)	PCM	●	●	●	●	●	●	●	0127 0126 0044 0129 026C 026D 0128 012E 012F 013C 012C 012D 0173 012A 0081 012B 013B 0042 0149 0142 0145 0045 0046 0384 014B 014A 0148 0049 014D 0146 0147
2006	300 / Magnum / Charger (Pre-2011)	HSM	●	●	●	●	●	●	○	
2006	300 / Magnum / Charger (Pre-2011)	ABS	●	●	●	●	●	●	●	0002 0285 0062 005A 0058 0059 005E 005C 005D 005F 005B
2006	300 / Magnum / Charger (Pre-2011)	HVAC	●	●	●	●	●	●	○	00EA 00E9
2006	300 / Magnum / Charger (Pre-2011)	CCN	●	●	●	●	●	●	○	008F 008E 0094 038D 0090 0383
2006	300 / Magnum / Charger (Pre-2011)	AHBM	●	●	●	●	●	●	○	0066
2006	300 / Magnum / Charger (Pre-2011)	PDM	●	●	●	●	●	●	●	0081
2006	300 / Magnum / Charger (Pre-2011)	SCM	●	●	●	●	○	●	●	
2006	Dakota	HVAC	●	●	●	●	●	●	●	00EA 00E8 00E9 0324 02EA 02EB 0081
2006	Dakota	FCMCGW	●	●	●	●	●	●	●	0039 003C 003D 0032 00C4 003F 003E 0036 0037 0034 0038 003A 00C9 0320 0033 0040
2006	Dakota	RADIO	●	●	●	●	●	○	●	01BB 0081
2006	Dakota	HFM	●	●	●	●	●	●	○	00E3 0081
2006	Dakota	AMP	●	●	●	●	●	○	●	0069 006D 0079 0068 02F6 0081 0289 028A 006B 006C 006A
2006	Dakota	PCM	●	●	●	●	●	●	●	0127 0126 0044 0129 026C 026D 0128 012E 012F 013C 012C 012D 0173 012A 0081 012B 013B
2006	Dakota	TCM	●	●	●	●	○	●	●	0167 0166 01EE 016A 0169 016C 016B 016E 016D 01F0 0172 0177 0170 016F 0175
2006	Dakota	OCM	●	●	●	●	●	○	○	011E
2006	Dakota	SDAR	●	●	●	●	●	○	○	01C8 0081
2006	Dakota	WCM	●	●	●	●	●	○	●	01D2 0228 0226 0225 0227 0232 0230 0231 022F 01DE 0244 0233 022D 023D 023E 0271 0270
2006	Dakota	ABS	●	●	●	●	●	●	●	0002 0285 0062
2006	Dakota	EOM	●	●	●	●	●	○	●	00BA
2006	Dakota	ORC	●	●	●	●	●	○	●	0081 0122
2006	Dakota	CCN	●	●	●	●	●	●	●	008C 008F 008E 0091 008D 0090
2006	Raider	EOM	●	●	●	●	●	○	●	00BA
2006	Raider	OCM	●	●	●	●	●	○	○	011E
2006	Raider	ORC	●	●	●	●	●	○	●	0081 0122
2006	Raider	RADIO	●	●	●	●	●	○	●	01BB 0081

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2006	Grand Cherokee	PCM	●	●	●	●	●	●	●	0042 0149 0142 0044 0145 012D 0384 014B 0173 014A 0148 0049 0146 0147 0081 013B 0127 0126 0129 026C 026D 0128 012E 012F 013C 012C 012A 012B
2006	Grand Cherokee	FCMCGW	●	●	●	●	●	●	●	0039 003C 003D 0032 003F 003E 0036 0037 0035 0034 0038 003A 002E 0302 0033 0040
2006	Grand Cherokee	ESM	●	●	●	●	●	●	○	
2006	Grand Cherokee	RADIO	●	●	●	●	●	○	●	01BB 0081
2006	Grand Cherokee	WCM	●	●	●	●	●	○	●	022E 01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0244 0233 022D 023D 023E 0271 0270
2006	Grand Cherokee	ORC	●	●	●	●	●	○	●	0122
2006	Grand Cherokee	CCN	●	●	●	●	●	●	●	0097 008C 008F 008E 0091 0094 0099 0098 0090
2006	Grand Cherokee	EOM	●	●	●	●	●	○	●	00BA
2006	Grand Cherokee	DDM	●	●	●	●	●	●	●	00AC 0081
2006	Grand Cherokee	LRSM	●	●	●	●	●	○	○	010D
2006	Grand Cherokee	HVAC	●	●	●	●	●	●	○	00EA 00E9
2006	Grand Cherokee	VES	●	●	●	●	●	●	○	
2006	Grand Cherokee	SCM	●	●	●	●	●	○	●	0081
2006	Grand Cherokee	HFM	●	●	●	●	●	●	○	00E3 0081
2006	Grand Cherokee	AHBM	●	●	●	●	●	●	○	0066
2006	Grand Cherokee	SDAR	●	●	●	●	●	○	○	01C8 0081
2006	Grand Cherokee	AMP	●	●	●	●	●	○	●	0289 028A 006D 006B 006C 0068 006A 0081
2006	Grand Cherokee	PDM	●	●	●	●	●	●	●	00AC 0081
2006	Grand Cherokee	FDCM	●	●	●	●	●	●	●	0081
2006	Grand Cherokee	TCM	●	●	●	●	●	●	●	01F4 0081 01F3 01F2 0167 0166 01EE 016A 0169 016C 016B 016E 016D 01F0 0172 0177 0170 016F 0175
2006	Grand Cherokee	OCM	●	●	●	●	●	○	○	011E
2006	Commander	AMP	●	●	●	●	●	○	●	0289 028A 006D 006B 006C 0068 006A 0081
2006	Commander	DDM	●	●	●	●	●	●	●	00AC 0081
2006	Commander	SCM	●	●	●	●	●	○	●	0081
2006	Commander	FDCM	●	●	●	●	●	●	●	0081
2006	Commander	TM	●	●	●	○	○	○	○	
2006	Commander	PCM	●	●	●	●	●	●	●	0042 0149 0142 0044 0145 012D 0045 0046 0384 014B 0173 014A 0148 0049 014D 0146 0147 0081 013B 0127 0126 0129 026C 026D 0128 012E 012F 013C 012C 012A 012B
2006	Commander	SDAR	●	●	●	●	●	○	○	01C8 0081
2006	Commander	ITM	●	●	●	●	●	●	●	0104 0105 0107 0385 0106 0081
2006	Commander	HVAC	●	●	●	●	●	●	○	00EA 00E9
2006	Commander	PDM	●	●	●	●	●	●	●	0081 00AC
2006	Commander	WCM	●	●	●	●	●	○	●	022E 01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0244 0233 022D 023D 023E 0271 0270
2006	Commander	LRSM	●	●	●	●	●	○	●	010D
2006	Commander	RADIO	●	●	●	●	●	○	●	01BB 0081
2006	Commander	AHBM	●	●	●	●	●	●	○	0066

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2006	Commander	PTS	●	●	●	●	○	●	○	01B4 01B3 01B5 0081
2006	Commander	SUNR	●	●	●	●	●	●	○	
2006	Commander	ABS	●	●	●	●	●	●	●	0002 0285 0062
2006	Commander	CCN	●	●	●	●	●	●	●	0097 008C 008F 008E 0091 0094 0099 0098 0090
2006	Commander	ESM	●	●	●	●	●	●	○	
2006	Commander	VES	●	●	●	●	●	●	○	
2006	Commander	MSMD	●	●	●	●	●	○	○	02EE 00BC 0114 0116 0118 0117 0115 0119
2006	Commander	HSM	●	●	●	●	●	●	○	
2006	Commander	TCM	●	●	●	●	●	●	●	0167 0166 01EE 016A 0169 016C 016B 016E 016D 01F0 0172 0177 0170 016F 0175 01F4 0081 01F3 01F2
2006	Commander	HFM	●	●	●	●	●	●	○	00E3 0081
2006	Commander	FCMCGW	●	●	●	●	●	●	●	0039 003C 003D 0032 003F 003E 0036 0037 0035 0034 0038 003A 002E 0302 0033 0040
2006	Commander	OCM	●	●	●	●	●	○	○	011E
2006	Commander	ORC	●	●	●	●	●	○	●	0122
2007	Pacifica	PLGM	●	●	●	●	●	●	●	038A 038B 00B4 0199 00B5
2007	Pacifica	BCMCGW	●	●	●	●	●	●	●	007E 007D 0081 003B 037B
2007	Pacifica	PCM	●	●	●	●	●	●	●	027B 025F 025E 0260 027C 0262 0261 027D 0264 0263 02F8 0127 0140 0126 0044 026C 026D 0128 027E 0266 0265 0145 02FB 013C 012C 012D 0177 0173 012A 0281 0280 0176 024E 0170 016F 0081 012B 035B 0269 01FC 013B
2007	Pacifica	ORC	●	●	●	●	●	○	●	0081 0122
2007	Pacifica	ABS	●	●	●	●	●	●	●	0002 0285 0062
2007	Pacifica	SAS	●	●	●	●	○	○	○	
2007	Pacifica	AWD	●	●	●	●	●	○	●	
2007	Pacifica	OCM	●	●	●	●	○	○	○	
2007	Pacifica	SKREEM	●	●	●	●	●	○	○	
2007	Pacifica	IPM	●	●	●	●	○	●	○	
2007	Pacifica	PDM	●	●	●	●	○	●	○	
2007	Pacifica	RADIO	●	●	●	○	○	●	○	
2007	Pacifica	MHSM	●	●	●	●	○	●	○	
2007	Pacifica	EOM	●	●	●	○	○	○	○	
2007	Pacifica	PTS	●	●	●	●	●	●	○	
2007	Pacifica	SDAR	●	●	●	●	●	●	○	
2007	Pacifica	DDM	●	●	●	●	○	●	○	
2007	Pacifica	MIC/CCN	●	●	●	●	○	●	○	
2007	Pacifica	AMP	●	●	●	○	○	○	○	
2007	Pacifica	HFM	●	●	●	●	○	●	○	
2007	Pacifica	MTC	●	●	●	●	○	●	○	
2007	Pacifica	NAV	●	●	●	○	○	○	○	
2007	Pacifica	ATC	●	●	●	●	●	●	○	
2007	Dodge Ram	HFM	●	●	●	●	●	●	○	00E3 0081

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2007	Dodge Ram	PCM	●	●	●	●	●	●	●	027B 025F 025E 0260 027C 0262 0261 027D 0264 0263 02F8 0127 0140 0126 0044 026C 026D 0128 027E 0266 0265 0145 02FB 013C 012C 012D 0177 0173 012A 0281 0280 0176 024E 0170 016F 0081 012B 035B 0269 01FC 013B 0398 0399 033D 0397 0156 0157 0154 0155 0141 0150 0151 037D 017B 0292 0049 0276 0277 033B 017A 0178 0179 0278 014F 033A 0152 033C 039A 039B 0153 015A 0159 0158
2007	Dodge Ram	TIPMCGW	●	●	●	●	●	●	●	030F 02F1 02F0 02F3 02EF 0039 003C 003D 0214 0032 0210 003F 003E 0036 0037 0035 0034 0038 003A 020E 0213 0215 028F 0211 0387 038F 003B 02F4 0033 0390
2007	Dodge Ram	CCN	●	●	●	●	●	●	●	008C 008F 008E 0081 0090
2007	Dodge Ram	EOM	●	●	●	●	●	●	●	00BA 0081
2007	Dodge Ram	WCM	●	●	●	●	●	○	●	01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0244 0081 0233 022D 023D 023E 0271 0270
2007	Dodge Ram	ABS	●	●	●	●	●	●	●	0002 0285 0062
2007	Dodge Ram	ORC	●	●	●	●	●	○	●	0081 0122
2007	Dodge Ram	AMP	●	●	●	●	●	○	●	028A 028D 006D 006C 027F 0068 006A 0081
2007	Dodge Ram	HVAC	●	●	●	●	●	●	●	00EA 00E8 00E9 02EA 02EB 0081 00EB
2007	Dodge Ram	RADIO	●	●	●	●	●	○	●	01BB 0081
2007	Dodge Ram	TCM	●	●	●	●	●	●	○	01F6 0391 0081 027B 0167 0166 01EE 027C 016A 0169 027D 0291 016C 016B 02F8 0290 027E 016E 016D 0392 0393 0394 0395 0177 0176 024E 01FB 016F 0396 035B 0175 01FC
2007	Dodge Ram	SUNR	●	●	●	●	●	●	○	
2007	Dodge Ram	SDAR	●	●	●	●	●	○	○	01C8 0081
2007	Dodge Ram	SAS	●	●	●	●	○	○	○	
2007	Dodge Ram	FDCM	●	●	●	●	●	○	○	02B4 02B7 02B6 02B5 02B3 02B2 02B1 02AF 02B0 0081
2007	Dodge Ram	VES	●	●	●	●	●	●	○	
2007	Durango (Pre-2011)	VES	●	●	●	●	●	●	○	
2007	Durango (Pre-2011)	CCN	●	●	●	●	●	●	●	008F 008E 008D 0081 0090
2007	Durango (Pre-2011)	HSM	●	●	●	●	●	●	●	
2007	Durango (Pre-2011)	MSMD	●	●	●	●	●	○	○	02EE 00BC 0114 0116 0118 0117 0081 0115 0119
2007	Durango (Pre-2011)	DDM	●	●	●	●	●	●	●	00AC 0081
2007	Durango (Pre-2011)	ABS	●	●	●	●	●	●	●	0002 0285 0062
2007	Durango (Pre-2011)	PCM	●	●	●	●	●	●	●	027B 025F 025E 0260 027C 0262 0261 027D 0264 0263 02F8 0127 0140 0126 0044 026C 026D 0128 027E 0266 0265 0145 02FB 013C 012C 012D 0177 0173 012A 0281 0280 0176 024E 0170 016F 0081 012B 035B 0269 01FC 013B
2007	Durango (Pre-2011)	HFM	●	●	●	●	●	●	○	00E3
2007	Durango (Pre-2011)	PLGM	●	●	●	●	●	●	●	038A 038B 00B4 0199 00B5
2007	Durango (Pre-2011)	RADIO	●	●	●	●	●	○	●	01BB 0081

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2007	Durango (Pre-2011)	AMP	●	●	●	●	●	○	●	0069 006D 0079 0068 0303 0081
2007	Durango (Pre-2011)	FCMCGW	●	●	●	●	●	●	●	0039 003C 003D 0032 003E 0036 00D5 00D8 0037 0035 0034 0038 00DB 00D6 00D9 003A 0081 003B 0302 0033 00C6 0040 00DA 0272 0273
2007	Durango (Pre-2011)	PDM	●	●	●	●	●	●	●	00AC 0081
2007	Durango (Pre-2011)	HVAC	●	●	●	●	●	●	●	00EA 00E8 00E9 0324 02EA 02EB 0081 0323
2007	Durango (Pre-2011)	ORC	●	●	●	●	●	○	●	0081 0122
2007	Durango (Pre-2011)	EOM	●	●	●	●	●	●	●	00BA 0081
2007	Durango (Pre-2011)	PTS	●	●	●	●	●	●	●	01B4 01B3 01B5 01B8 0081
2007	Durango (Pre-2011)	SAS	●	●	●	●	○	○	○	
2007	Durango (Pre-2011)	PTIM	●	●	●	●	●	●	●	
2007	Durango (Pre-2011)	SDAR	●	●	●	●	●	○	○	01C8 0081
2007	Durango (Pre-2011)	WCM	●	●	●	●	●	○	●	01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0244 0081 0233 022D 023D 023E 0271 0270
2007	Aspen	AMP	●	●	●	●	●	○	●	0069 006D 0079 0068 0303 0081 02F6
2007	Aspen	PDM	●	●	●	●	●	●	●	0081 00AC
2007	Aspen	WCM	●	●	●	●	●	○	●	01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0244 0081 0233 022D 023D 023E 0271 0270
2007	Aspen	FCMCGW	●	●	●	●	●	●	●	0039 003C 003D 0032 003E 0036 00D5 00D8 0037 0035 0034 0038 00DB 00D6 00D9 003A 0081 003B 0302 0033 00C6 0040 00DA 0272 0273
2007	Aspen	ORC	●	●	●	●	●	○	●	0081 0122
2007	Aspen	SAS	●	●	●	●	○	○	○	
2007	Aspen	MSMD	●	●	●	●	●	○	○	02EE 00BC 0114 0116 0118 0117 0081 0115 0119
2007	Aspen	PLGM	●	●	●	●	●	●	●	038A 038B 00B4 0199 00B5
2007	Aspen	DDM	●	●	●	●	●	●	●	0081 00AC
2007	Aspen	PCM	●	●	●	●	●	●	●	027B 025F 025E 0260 027C 0262 0261 027D 0264 0263 02F8 0127 0140 0126 0044 026C 026D 0128 027E 0266 0265 0145 02FB 013C 012C 012D 0177 0173 012A 0281 0280 0176 024E 0170 016F 0081 012B 035B 0269 01FC 013B
2007	Aspen	HSM	●	●	●	●	●	●	●	
2007	Aspen	HFM	●	●	●	●	●	○	○	00E3 0081
2007	Aspen	ABS	●	●	●	●	●	●	●	0002 0285 0062
2007	Aspen	VES	●	●	●	●	●	●	○	
2007	Aspen	CCN	●	●	●	●	●	●	●	008F 008E 008D 0081 0090
2007	Aspen	RADIO	●	●	●	●	●	○	●	01BB 0081
2007	Aspen	SDAR	●	●	●	●	●	○	○	01C8 0081
2007	Aspen	PTS	●	●	●	●	●	●	●	01B4 01B3 01B5 01B8 0081
2007	Aspen	EOM	●	●	●	●	●	●	●	00BA 0081
2007	Aspen	HVAC	●	●	●	●	●	●	●	00EA 00E8 00E9 0324 02EA 02EB 0081 0323
2007	Wrangler	RADIO	●	●	●	●	●	●	●	031C 025D 039E 039F 01BB 03A0 0081
2007	Wrangler	ITM	●	●	●	●	○	●	●	0385 0106 0081
2007	Wrangler	SAS	●	●	●	●	○	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2007	Wrangler	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069
2007	Wrangler	ASBS	●	●	●	●	●	○	○	0081 0317 0318 031A 031B 0319
2007	Wrangler	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 0039 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0035 0038 003A 021E 021F 038F 003B 02F4 0033 0390 021D
2007	Wrangler	PCM	●	●	●	●	●	●	●	027B 025F 025E 0260 027C 0262 0261 027D 0264 0263 02F8 0127 0140 0126 0044 026C 026D 0128 027E 0266 0265 0145 02FB 013C 012C 012D 0177 0173 012A 0281 0280 0176 024E 0170 016F 0081 012B 035B 0269 01FC 013B 0042 0149 0142 02BA 02B9 02BF 02BD 02BE 02BC 014A 0148 0049 0144 02C0 02BB 031D 02C1 02C2
2007	Wrangler	TCM	●	●	●	●	●	●	○	0392 0393 0394 0395 0176 024E 01FB 016F 0081 0396 035B 01FC
2007	Wrangler	ABS	●	●	●	●	●	●	●	0002 0285 0062
2007	Wrangler	CCN	●	●	●	●	●	●	●	00BC 0094 038D 0091
2007	Wrangler	WCM	●	●	●	●	●	○	●	01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0244 0081 0233 022D 0227 0274 031E 031F
2007	Wrangler	ORC	●	●	●	●	●	○	●	0081 0122
2007	Wrangler	OCM	●	●	●	●	●	○	○	011E 0081
2007	Sebring / 200 / Avenger	DDM	●	●	●	●	●	●	○	0306 0081
2007	Sebring / 200 / Avenger	ABS	●	●	●	●	●	●	●	0002 0285 0062
2007	Sebring / 200 / Avenger	SAS	●	●	●	●	○	○	○	
2007	Sebring / 200 / Avenger	ITM	●	●	●	●	●	●	●	0385 0106 0081 0104 0105 0107
2007	Sebring / 200 / Avenger	PCM	●	●	●	●	●	●	●	0042 0142 012D 0310 0173 03A3 0081 03A4 013B 0144 027B 025F 025E 0260 027C 0262 0261 027D 0264 0263 02F8 0127 0140 0126 0044 026C 026D 0128 027E 0266 0265 0145 02FB 013C 012C 0177 012A 0281 0280 0176 024E 0170 016F 012B 035B 0269 01FC 02E7 013E 0141 012E 0314
2007	Sebring / 200 / Avenger	PDM	●	●	●	●	●	●	○	0306 0081
2007	Sebring / 200 / Avenger	TIPMCGW	●	●	●	●	●	●	●	030F 02F1 02F0 02F3 02EF 0039 003C 003D 0214 0032 0210 003F 003E 0036 02C3 0037 0035 0034 0038 003A 020E 0213 0215 028F 0211 038F 003B 02F4 0033 0390
2007	Sebring / 200 / Avenger	HVAC	●	●	●	●	●	●	●	00EA 00E9 03A9 02EB
2007	Sebring / 200 / Avenger	AWD	●	●	●	●	●	○	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2007	Sebring / 200 / Avenger	AMP	●	●	●	●	●	○	●	0069 006D 0079 0068 02F6 0081
2007	Sebring / 200 / Avenger	WCM	●	●	●	●	●	○	●	02A7 022E 01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0244 0081 0233 022D 023D 023E 0271 0270
2007	Sebring / 200 / Avenger	RADIO	●	●	●	●	●	●	●	039F 039E 01BB 03A0 0081 025D
2007	Sebring / 200 / Avenger	CCN	●	●	●	●	●	●	●	008C 008F 008E 0094 0092 0081 0096 0090
2007	Sebring / 200 / Avenger	PTCM	●	●	●	●	●	○	●	0371 025B 0259 026A 0081 025A
2007	Sebring / 200 / Avenger	TCM	●	●	●	●	●	●	●	0167 0166 01EE 016A 0169 016C 016B 016E 016D 01F0 0172 0177 0170 016F 0175 027B 027C 027D 0291 02F8 0290 027E 0392 0393 0394 0395 0176 024E 01FB 0081 0396 035B 01FC
2007	Sebring / 200 / Avenger	VES3	●	●	●	●	●	●	●	
2007	Sebring / 200 / Avenger	ORC	●	●	●	●	●	○	●	0081 0122
2007	Sebring / 200 / Avenger	HFM	●	●	●	●	●	●	○	00E3
2007	Nitro	ITM	●	●	●	●	●	●	●	0104 0105 0107 0385 0106 0081
2007	Nitro	SAS	●	●	●	●	○	○	○	
2007	Nitro	HFM	●	●	●	●	●	●	○	00E3
2007	Nitro	DMFR	●	●	●	●	●	●	●	
2007	Nitro	ORC	●	●	●	●	●	○	●	0122
2007	Nitro	CCN	●	●	●	●	●	●	●	00BC 0094 038D 0091
2007	Nitro	ABS	●	●	●	●	●	●	●	0002 0285 0062
2007	Nitro	WCM	●	●	●	●	●	○	●	01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0244 0081 0233 022D 0227 0274 031E 031F
2007	Nitro	ESM	●	●	●	●	●	●	○	
2007	Nitro	RADIO	●	●	●	●	●	●	●	039F 039E 01BB 03A0 025D 0081
2007	Nitro	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 0039 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0035 0038 003A 021E 021F 038F 003B 02F4 0033 0390 021D
2007	Nitro	HVAC	●	●	●	●	●	●	●	00EA 00E9 03A9 02EB
2007	Nitro	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069
2007	Nitro	OCM	●	●	●	●	●	○	○	011E 0081
2007	Nitro	DMFL	●	●	●	●	●	●	●	
2007	Nitro	PCM	●	●	●	●	●	●	●	#####
2007	Nitro	TCM	●	●	●	●	●	○	○	01F4 0081 01F3 01F2
2007	Nitro	VES3	●	●	●	●	●	●	●	
2007	Nitro	PTS	●	●	●	●	●	●	●	01B4 01B3 01B5 01B8 0081
2007	Liberty	SAS	●	●	●	●	●	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2007	300 / Magnum / Charger (Pre-2011)	VES	●	●	●	●	●	●	○	
2007	300 / Magnum / Charger (Pre-2011)	FCMCGW	●	●	●	●	●	●	●	0039 003C 003D 0032 003F 003E 0036 0037 0035 0034 0038 00C8 003A 002E 0081 003B 0320 0033
2007	300 / Magnum / Charger (Pre-2011)	HSM	●	●	●	●	●	●	●	
2007	300 / Magnum / Charger (Pre-2011)	PTIM	●	●	●	●	●	●	●	
2007	300 / Magnum / Charger (Pre-2011)	SUNR	●	●	●	●	●	●	○	
2007	300 / Magnum / Charger (Pre-2011)	HVAC	●	●	●	●	●	●	○	00EA 00E9 02EA 02EB 0081
2007	300 / Magnum / Charger (Pre-2011)	LRSM	●	●	●	●	●	○	○	010D 0081
2007	300 / Magnum / Charger (Pre-2011)	ESM	●	●	●	●	●	●	○	
2007	300 / Magnum / Charger (Pre-2011)	SCM	●	●	●	●	○	●	●	
2007	300 / Magnum / Charger (Pre-2011)	SDAR	●	●	●	●	●	○	○	01C8 0081
2007	300 / Magnum / Charger (Pre-2011)	RADIO	●	●	●	●	●	○	●	01BB 0081
2007	300 / Magnum / Charger (Pre-2011)	HIDT	●	●	●	●	●	●	○	00E5 0081
2007	300 / Magnum / Charger (Pre-2011)	ORC	●	●	●	●	○	●	○	
2007	300 / Magnum / Charger (Pre-2011)	DDM	●	●	●	●	●	●	●	
2007	300 / Magnum / Charger (Pre-2011)	ABS	●	●	●	●	●	●	●	0002 0285 0062
2007	300 / Magnum / Charger (Pre-2011)	PTS	●	●	●	●	○	●	○	01B4 01B3 01B5 01B8 0081
2007	Compass	ABS	●	●	●	●	●	●	●	0002 0285 0062
2007	Compass	SDAR	●	●	●	●	●	○	○	01C8 0081
2007	Compass	ORC	●	●	●	●	●	○	●	0122
2007	Compass	SAS	●	●	●	●	○	○	○	
2007	Compass	OCM	●	●	●	●	●	○	○	011E 0081
2007	Compass	CCN	●	●	●	●	●	●	●	008C 008F 008E 0094 0092 0081 0096 0090
2007	Compass	RADIO	●	●	●	●	●	○	●	01BB 0081
2007	Compass	AMP	●	●	●	●	●	○	●	0289 028A 006D 006B 006C 0068 006A 0081
2007	Compass	PCM	●	●	●	●	●	●	●	0042 0142 012D 0310 0173 03A3 0144 0081 03A4 013B 02E7 0140 013E 0126 0141 0044 0128 012E 0314 012C 012A 012B

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2007	Compass	TIPMCGW	●	●	●	●	●	●	●	02F3 0039 003C 003D 0214 0032 0210 003F 003E 0036 0037 0035 0034 0038 003A 020E 0213 0215 028F 0211 003B 02F4 0033 0390 030F 02F1 02F0 02EF 038F
2007	Compass	TCM	●	●	●	●	●	●	●	0081 01F5
2007	Compass	HFM	●	●	●	●	●	●	○	00E3 0081
2007	Compass	WCM	●	●	●	●	●	○	●	02A7 01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0244 0081 0233 022D 023D 023E 0271 0270
2007	Compass	AWD	●	●	●	●	●	●	●	
2007	Compass	ITM	●	●	●	●	●	●	●	0104 0105 0107 0385 0106 0081
2007	Dakota	SDAR	●	●	●	●	●	○	○	01C8 0081
2007	Dakota	ORC	●	●	●	●	●	○	●	0081 0122
2007	Dakota	HVAC	●	●	●	●	●	●	●	00EA 00E8 00E9 02EA 02EB 0081
2007	Dakota	EOM	●	●	●	●	●	●	●	00BA 0081
2007	Dakota	AMP	●	●	●	●	●	○	●	0069 006D 0079 0068 02F6 0081 0303
2007	Dakota	FCMCGW	●	●	●	●	●	●	●	0039 003C 003D 0032 003E 0036 00D5 00D8 0037 0035 0034 0038 00DB 00D6 00D9 003A 0081 003B 0302 0033 00C6 0040 00DA 0272 0273
2007	Dakota	OCM	●	●	●	●	●	○	○	011E 0081
2007	Dakota	RADIO	●	●	●	●	●	○	●	01BB 0081
2007	Dakota	CCN	●	●	●	●	●	●	●	008F 008E 008D 0081 0090
2007	Dakota	ABS	●	●	●	●	●	●	●	0002 0285 0062
2007	Dakota	WCM	●	●	●	●	●	○	●	01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0244 0081 0233 022D 023D 023E 0271 0270
2007	Dakota	PCM	●	●	●	●	●	●	●	027B 025F 025E 0260 027C 0262 0261 027D 0264 0263 02F8 0127 0140 0126 0044 026C 026D 0128 027E 0266 0265 0145 02FB 013C 012C 012D 0177 0173 012A 0281 0280 0176 024E 0170 016F 0081 012B 035B 0269 01FC 013B
2007	Raider	CCN	●	●	●	●	●	●	●	008F 008E 008D 0081 0090
2007	Raider	EOM	●	●	●	●	●	●	●	00BA 0081
2007	Raider	FCMCGW	●	●	●	●	●	●	●	0039 003C 003D 0032 003E 0036 00D5 00D8 0037 0035 0034 0038 00DB 00D6 00D9 003A 0081 003B 0302 0033 00C6 0040 00DA 0272 0273
2007	Raider	WCM	●	●	●	●	●	○	●	01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0244 0081 0233 022D 023D 023E 0271 0270
2007	Raider	HVAC	●	●	●	●	●	●	●	00EA 00E8 00E9 02EA 02EB 0081
2007	Raider	SDAR	●	●	●	●	●	○	○	01C8 0081
2007	Raider	PCM	●	●	●	●	●	●	●	027B 025F 025E 0260 027C 0262 0261 027D 0264 0263 02F8 0127 0140 0126 0044 026C 026D 0128 027E 0266 0265 0145 02FB 013C 012C 012D 0177 0173 012A 0281 0280 0176 024E 0170 016F 0081 012B 035B 0269 01FC 013B
2007	Raider	OCM	●	●	●	●	●	○	○	011E 0081

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2007	Raider	ABS	●	●	●	●	●	●	●	0002 0285 0062
2007	Raider	RADIO	●	●	●	●	●	○	●	01BB 0081
2007	Raider	ORC	●	●	●	●	●	○	●	0081 0122
2007	Raider	AMP	●	●	●	●	●	○	●	0069 006D 0079 0068 0303 0081 02F6
2007	Caliber	OCM	●	●	●	●	●	○	○	011E 0081
2007	Caliber	WCM	●	●	●	●	●	○	●	02A7 01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0244 0081 0233 022D 023D 023E 0271 0270
2007	Caliber	HFM	●	●	●	●	●	●	○	00E3 0081
2007	Caliber	PCM	●	●	●	●	●	●	●	0042 0142 012D 0310 0173 03A3 0144 0081 03A4 013B 02E7 0140 013E 0126 0141 0044 0128 012E 0314 012C 012A 012B
2007	Caliber	CCN	●	●	●	●	●	●	●	008C 008F 008E 0094 0092 0081 0096 0090
2007	Caliber	ITM	●	●	●	●	●	●	●	0104 0105 0107 0385 0106 0081
2007	Caliber	SAS	●	●	●	●	○	○	○	
2007	Caliber	RADIO	●	●	●	●	●	○	●	01BB 0081
2007	Caliber	AMP	●	●	●	●	●	○	●	0289 028A 006D 006B 006C 0068 006A 0081
2007	Caliber	SDAR	●	●	●	●	●	○	○	01C8 0081
2007	Caliber	TCM	●	●	●	●	●	●	●	0081 01F5
2007	Caliber	AWD	●	●	●	●	●	●	●	
2007	Caliber	ABS	●	●	●	●	●	●	●	0002 0285 0062
2007	Caliber	ORC	●	●	●	●	●	○	●	0081 0122
2007	Caliber	TIPMCGW	●	●	●	●	●	●	●	030F 02F1 02F0 02F3 02EF 0039 003C 003D 0214 0032 0210 003F 003E 0036 0037 0035 0034 0038 003A 020E 0213 0215 028F 0211 038F 003B 02F4 0033 0390
2007	PT Cruiser	WCM	●	●	●	●	●	○	●	01D2 0228 0240 0226 0225 0232 0230 0231 022F 01DE 0244 0243 0081 0233 022D 0241 023D 023E 0271 0270
2007	PT Cruiser	ITM	●	●	●	●	●	●	●	0385 0106 0081 0104 0105 0107 038E
2007	PT Cruiser	SDAR	●	●	●	●	●	○	○	01C8 0081
2007	PT Cruiser	TCM	●	●	●	●	○	●	●	0167 0166 01EE 016A 0169 016C 016B 016E 016D 01F0 0172 0177 0170 016F 0175
2007	PT Cruiser	RADIO	●	●	●	●	●	○	●	01BB 0081
2007	PT Cruiser	TIPMCGW	●	●	●	●	●	●	●	030D 0039 030E 030C 003C 003D 0214 0032 0210 003F 003E 0036 0037 0035 0034 0038 003A 020E 0213 0215 028F 0212 028E 0211 003B 0316 0033
2007	PT Cruiser	CCN	●	●	●	●	●	●	●	008C 008F 008E 0094 0092 0081 0096 0090
2007	PT Cruiser	DDM	●	●	●	●	●	●	○	
2007	PT Cruiser	OCM	●	●	●	●	●	○	○	011E 0081
2007	PT Cruiser	PCM	●	●	●	●	●	●	●	0042 0149 0142 0044 0145 012D 0173 0148 0049 0081 013B 0127 0126 0129 026C 026D 0128 012E 012F 013C 012C 012A 012B
2007	PT Cruiser	ORC	●	●	●	●	●	○	●	0081 0122
2007	PT Cruiser	ABS	●	●	●	●	●	●	●	0002 005E 0060 005B
2007	PT Cruiser	PDM	●	●	●	●	○	●	○	
2007	PT Cruiser	HFM	●	●	●	●	●	●	○	00E3 0081

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2007	PT Cruiser	AMP	●	●	●	●	●	○	●	0289 028A 006D 006B 006C 0068 006A 0081
2007	PT Cruiser	PCM	●	●	●	●	○	●	○	
2007	PT Cruiser	CAN GW	●	●	●	●	●	○	●	
2007	Sprinter	HVAC	●	●	●	●	●	●	●	0012
2007	Sprinter	BCH	●	●	●	●	●	●	○	
2007	Sprinter	AEHM	●	●	●	●	●	○	○	0004
2007	Sprinter	ECM	●	●	●	●	●	●	●	0025 0329 0024 001E 0335 004A 004C 0023 0022 0020 0021 0042 0142 0127 0044 0337 0045 0046 0043 0049 014D 026E 002E 026F 0336
2007	Sprinter	RCM	●	●	●	●	●	●	○	0249 0016 0017
2007	Sprinter	EISCGW	●	●	●	●	●	○	●	000B 0329 032A 032B 004A 004C 032C 002C 000D 000E 002B 002A 000C
2007	Sprinter	ESM	●	●	●	●	●	●	○	000F
2007	Sprinter	TCM	●	●	●	●	●	○	○	02D6 02D7 02D4 02D5 0329 004A 004C 0328 0018
2007	Sprinter	TM	●	●	●	●	○	○	○	0019
2007	Sprinter	ABS	●	●	●	●	●	○	●	032D 0329 0002 0001 0003 004A 004C
2007	Sprinter	PSM	●	●	●	●	●	●	○	0329 004A 0258 0339 0015
2007	Sprinter	DDM	●	●	●	●	●	●	○	
2007	Sprinter	CCN	●	●	●	●	●	○	○	0007 0008 0005 0334 0006 0329 032F 0330 0331 0332 0333 004A 004C 0009 000A 032E
2007	Sprinter	SBM	●	●	●	●	●	●	○	
2007	Sprinter	ACH	●	●	●	●	●	●	○	
2007	Sprinter	ORC	●	●	●	○	●	○	○	0329 004A 004C 0338 0014 0013 02CF
2007	Sprinter	RADIO	●	●	●	●	●	○	○	0028 0027 0029 024A 004A 0081 004B 0041
2007	Sprinter	PTS	●	●	●	●	●	●	●	02D2 02D3
2007	Sprinter	BCM	●	●	●	●	●	●	○	02E1
2007	Sprinter	TPM	●	●	●	●	●	○	○	02D0 02D1 004A 001A 001B 001C 001D 0247 004E
2007	Sprinter	AHLM	●	●	●	●	●	●	○	0329 029F 004A 004C
2007	Sprinter	SCM	●	●	●	●	●	●	○	
2007	Sprinter	CDC	●	●	●	●	●	○	○	
2007	Sprinter	HFM	●	●	●	●	●	○	○	004A
2007	Grand Cherokee	HVAC	●	●	●	●	●	●	○	00EA 00E9 02EA 02EB 0081
2007	Grand Cherokee	ORC	●	●	●	●	●	○	●	0122
2007	Grand Cherokee	ABS	●	●	●	●	●	●	●	0002 0285 0062
2007	Grand Cherokee	WCM	●	●	●	●	●	○	●	022E 01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0244 0081 0233 022D 023D 023E 0271 0270
2007	Grand Cherokee	VES	●	●	●	●	●	●	○	
2007	Grand Cherokee	HSM	●	●	●	●	●	●	●	
2007	Grand Cherokee	TM	●	●	●	○	○	○	○	
2007	Grand Cherokee	ITM	●	●	●	●	●	●	●	0104 0105 0107 0385 0106 0081
2007	Grand Cherokee	LRSM	●	●	●	●	●	○	○	010D 0081
2007	Grand Cherokee	MSMD	●	●	●	●	●	○	○	02EE 00BC 0114 0116 0118 0117 0081 0115 0119
2007	Grand Cherokee	PDM	●	●	●	●	●	●	●	0081 00AC
2007	Grand Cherokee	SCM	●	●	●	●	●	○	●	0081

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2008	Dodge Ram	WCM	●	●	●	●	●	○	●	01D2 0228 0226 0225 0232 0230 0231 022F 0244 0081 0233 033F 02DE 02DF 023D 023E 03A6 0271 0270
2008	Dodge Ram	AMP	●	●	●	●	●	○	●	028A 028D 006D 006C 027F 0068 006A 0081
2008	Dodge Ram	SDAR	●	●	●	●	●	○	○	01C8 0081
2008	Dodge Ram	RADIO	●	●	●	●	●	○	●	01BB 0081
2008	Dodge Ram	TCM	●	●	●	●	●	●	○	01F6 0391 0081 027B 0167 0166 01EE 027C 016A 0169 027D 0291 016C 016B 02F8 0290 027E 016E 016D 0392 0393 0394 0395 0177 0176 024E 01FB 016F 0396 035B 0175 01FC
2008	Dodge Ram	CCN	●	●	●	●	●	●	●	008C 008F 008E 02D9 02DB 02E0 03A5 0081 0090
2008	Dodge Ram	EOM	●	●	●	●	●	●	●	00BA 0081
2008	Dodge Ram	PCM	●	●	●	●	●	●	●	#####
2008	Dodge Ram	VES	●	●	●	●	●	●	○	
2008	Dodge Ram	TIPMCGW	●	●	●	●	●	●	●	033E 030D 030F 02F1 02F0 02F3 02EF 0039 030E 030C 003C 003D 0214 0032 0210 003F 003E 0036 0037 0035 0034 0038 003A 020E 0213 0215 028F 0211 0387 038F 003B 02F4 0033 0390
2008	Dodge Ram	ABS	●	●	●	●	●	●	●	0002 0285 0062 0081
2008	Dodge Ram	HVAC	●	●	●	●	●	●	●	00EA 00E8 00E9 02EA 02EB 0081 00EB
2008	Dodge Ram	ORC	●	●	●	●	●	○	●	0081 0122
2008	Dodge Ram	FDCM	●	●	●	●	●	○	○	02B4 02B7 02B6 02B5 02B3 02B2 02B1 02AF 02B0 0081
2008	Dodge Ram	SAS	●	●	●	●	○	○	○	
2008	Dodge Ram	HFM	●	●	●	●	●	●	○	00E3
2008	Durango (Pre-2011)	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069
2008	Durango (Pre-2011)	HVAC	●	●	●	●	●	●	●	00EA 00E9 02EA 0323 02EB 0081 00E8 0324
2008	Durango (Pre-2011)	VES3	●	●	●	●	●	●	●	
2008	Durango (Pre-2011)	EOM	●	●	●	●	●	●	●	00BA 0081
2008	Durango (Pre-2011)	WCM	●	●	●	●	●	○	●	01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0244 0081 0233 022D 023E 0271
2008	Durango (Pre-2011)	HFM	●	●	●	●	●	●	○	00E3
2008	Durango (Pre-2011)	PCM	●	●	●	●	●	●	●	027B 025F 025E 0260 027C 0262 0261 027D 0264 0263 02F8 0127 0140 0126 0044 026C 026D 0128 027E 0266 0265 0145 02FB 013C 012C 012D 0177 0173 012A 0281 0280 0176 024E 0170 016F 0081 012B 035B 0269 01FC 013B
2008	Durango (Pre-2011)	CCN	●	●	●	●	●	●	●	008F 008E 008D 0081 0090
2008	Durango (Pre-2011)	ORC	●	●	●	●	●	○	●	0081 0122
2008	Durango (Pre-2011)	PTS	●	●	●	●	●	●	●	01B4 01B3 01B5 01B8 0081
2008	Durango (Pre-2011)	HSM	●	●	●	●	●	●	●	
2008	Durango (Pre-2011)	RADIO	●	●	●	●	●	●	●	039F 039E 01BB 03A0 025D
2008	Durango (Pre-2011)	DDM	●	●	●	●	●	●	●	0081 00AC
2008	Durango (Pre-2011)	PTIM	●	●	●	●	●	●	●	
2008	Durango (Pre-2011)	PDM	●	●	●	●	●	●	●	0081 00AC
2008	Durango (Pre-2011)	ABS	●	●	●	●	●	●	●	0002 0285 0062 0081

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2008	Durango (Pre-2011)	MSMD	●	●	●	●	●	○	○	02EE 00BC 0114 0116 0118 0117 0081 0115 0119
2008	Durango (Pre-2011)	FCMCGW	●	●	●	●	●	●	●	02F1 02F0 02F3 02EF 0039 003C 003D 02A6 02A5 02A4 0032 0257 003E 0036 00D5 00D8 0037 0035 0034 0038 00DB 00D6 00D9 003A 0293 003B 0302 0033 00C6 0040 00DA 0272 0273
2008	Durango (Pre-2011)	SAS	●	●	●	●	○	○	○	
2008	Durango (Pre-2011)	PLGM	●	●	●	●	●	●	●	038A 038B 00B4 0199 00B5
2008	Aspen	HSM	●	●	●	●	●	●	●	
2008	Aspen	PLGM	●	●	●	●	●	●	●	038A 038B 00B4 0199 00B5
2008	Aspen	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069
2008	Aspen	ABS	●	●	●	●	●	●	●	0002 0285 0062 0081
2008	Aspen	DDM	●	●	●	●	●	●	●	00AC 0081
2008	Aspen	HVAC	●	●	●	●	●	●	●	00EA 00E8 00E9 0324 02EA 02EB 0081 0323
2008	Aspen	WCM	●	●	●	●	●	○	●	01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0244 0081 0233 022D 023E 0271
2008	Aspen	SAS	●	●	●	●	○	○	○	
2008	Aspen	EOM	●	●	●	●	●	●	●	00BA 0081
2008	Aspen	PTIM	●	●	●	●	●	●	●	
2008	Aspen	RADIO	●	●	●	●	●	●	●	039F 039E 01BB 03A0 025D
2008	Aspen	FCMCGW	●	●	●	●	●	●	●	02F1 02F0 02F3 02EF 0039 003C 003D 02A6 02A5 02A4 0032 0257 003E 0036 00D5 00D8 0037 0035 0034 0038 00DB 00D6 00D9 003A 0293 003B 0302 0033 00C6 0040 00DA 0272 0273
2008	Aspen	MSMD	●	●	●	●	●	○	○	02EE 00BC 0114 0116 0118 0117 0081 0115 0119
2008	Aspen	VES3	●	●	●	●	●	●	●	
2008	Aspen	PDM	●	●	●	●	●	●	●	0081 00AC
2008	Aspen	CCN	●	●	●	●	●	●	●	008F 008E 008D 0081 0090
2008	Aspen	HFM	●	●	●	●	●	●	○	00E3
2008	Aspen	PCM	●	●	●	●	●	●	●	027B 025F 025E 0260 027C 0262 0261 027D 0264 0263 02F8 0127 0140 0126 0044 026C 026D 0128 027E 0266 0265 0145 02FB 013C 012C 012D 0177 0173 012A 0281 0280 0176 024E 0170 016F 0081 012B 035B 0269 01FC 013B
2008	Aspen	PTS	●	●	●	●	●	●	●	01B4 01B3 01B5 01B8 0081
2008	Aspen	ORC	●	●	●	●	●	○	●	0081 0122
2008	Wrangler (Export)	ABS	●	●	●	●	●	●	●	0002 0285 0062 0081
2008	Wrangler (Export)	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 0039 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0035 0038 003A 021E 021F 038F 003B 02F4 0033 0390 021D
2008	Wrangler (Export)	WCM	●	●	●	●	●	○	●	0233 01D2 03E4 0341 0228 04A2 0232 0230 0231 022F 01DE 0413 022D 0227
2008	Wrangler (Export)	SAS	●	●	●	●	○	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2008	Wrangler (Export)	PCM	●	●	●	●	●	●	○	0145 012D 0042 0149 0142 02BA 02B9 02BF 02BD 02BE 02BC 014A 0148 0044 0049 0144 0081 02C0 02BB 031D 02C1 013B 02C2
2008	Wrangler (Export)	CCN	●	●	●	●	○	●	●	00BC 0094 038D 0091
2008	Wrangler (Export)	RADIO	●	●	●	●	●	●	●	025D 039E 039F 01BB 03A0 01BC 0081
2008	Wrangler (Export)	ORC	●	●	●	●	●	○	●	0081 0122
2008	Wrangler (Export)	TCM	●	●	●	●	●	●	○	0392 0393 0394 0395 0176 024E 01FB 016F 0081 0396 035B 01FC
2008	Journey	WCM	●	●	●	●	●	●	●	02A7 0414 0233 022E 01D2 03E4 0228 03E6 0232 0230 0231 022F 01DE 0413 0300 0245 0225 0244 0081 01DA 02FC
2008	Journey	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 0039 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0035 0038 003A 02E3 021E 021F 038F 003B 02F4 0033 0390 021D 022D
2008	Journey	DMFR	●	●	●	●	●	●	●	
2008	Journey	HVAC	●	●	●	●	●	●	●	00EA 00E9 00EC 02EA 02EB 0081 0288 0287 03A9
2008	Journey	ITM	●	●	●	●	●	●	●	0104 0105 0107 0385 0106 0081
2008	Journey	PCM	●	●	●	●	●	●	●	#####
2008	Journey	DMFL	●	●	●	●	●	●	●	
2008	Journey	SAS	●	●	●	●	○	○	○	
2008	Journey	ORC	●	●	●	●	●	○	●	02A1 0122
2008	Journey	ABS	●	●	●	●	●	●	●	0002 0285 0062
2008	Journey	HFM	●	●	●	●	●	●	○	00E3
2008	Journey	RADIO	●	●	●	●	●	●	●	039F 039E 01BB 03A0 025D
2008	Journey	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069
2008	Journey	VES3	●	●	●	●	●	●	●	
2008	Journey	CCN	●	●	●	●	○	●	●	008C 0091 02D9 02DB 0094 02E0 03A5 037F 037E 0081 0096
2008	Journey	DISP	●	●	●	●	●	○	○	
2008	Journey	AWD	●	●	●	●	●	○	●	
2008	Journey	TCM	●	●	●	●	●	●	●	0391 0081 0167 0166 01EE 016A 0169 016C 016B 016E 016D 01F0 0172 0177 0170 016F 0175
2008	Wrangler	ASBS	●	●	●	●	●	○	○	0081 0317 0318 031A 031B 0319
2008	Wrangler	ABS	●	●	●	●	●	●	●	0002 0285 0062 0081
2008	Wrangler	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 0039 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0035 0038 003A 021E 021F 038F 003B 02F4 0033 0390 021D
2008	Wrangler	ITM	●	●	●	●	○	●	●	0385 0106 0081
2008	Wrangler	SAS	●	●	●	●	○	○	○	
2008	Wrangler	WCM	●	●	●	●	●	○	●	01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0244 0081 0233 022D 0227 0274 031E 031F
2008	Wrangler	CCN	●	●	●	●	○	●	●	00BC 0094 038D 0091
2008	Wrangler	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069
2008	Wrangler	RADIO	●	●	●	●	●	●	●	0081 031C 025D 039E 039F 01BB 03A0

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2008	Liberty	VES3	●	●	●	●	●	●	●	
2008	Liberty	PTS	●	●	●	●	●	●	●	01B4 01B3 01B5 01B8 0081
2008	Liberty	OCM	●	●	●	●	●	○	○	011E 0081
2008	Liberty	PCM	●	●	●	●	●	●	●	#####
2008	Liberty	WCM	●	●	●	●	●	○	●	01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0244 0081 0233 022D 0227 0274 031E 031F
2008	Liberty	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069
2008	Challenger	PCM	●	●	●	●	●	●	●	027B 025F 025E 0260 027C 0262 0261 027D 0264 0263 02F8 0127 0140 0126 0044 026C 026D 0128 027E 0266 0265 0145 02FB 013C 012C 012D 0177 0173 012A 0281 0280 0176 024E 0170 016F 0081 012B 035B 0269 01FC 013B
2008	Challenger	ABS	●	●	●	●	●	●	●	0002 0285 0062
2008	Challenger	ESM	●	●	●	●	●	●	○	
2008	Challenger	WCM	●	●	●	●	●	●	●	02A7 022E 01D2 0228 0225 0081 0300 0245 02FC 02FF 02FD 02FE 0414 0233 03E4 03E6 0232 0230 0231 022F 01DE 0413
2008	Challenger	HSM	●	●	●	●	●	●	●	
2008	Challenger	ORC	●	●	●	●	●	○	●	02A1
2008	Challenger	EOM	●	●	●	●	●	○	●	00BA 0081
2008	Challenger	PEM	●	●	●	●	●	○	●	0315 0308 0307 0081
2008	Challenger	DDM	●	●	●	●	●	●	○	0306 0081
2008	Challenger	TPM	●	●	●	●	○	○	●	02F7 0232 0230 0231 022F 0244 0081
2008	Challenger	RADIO	●	●	●	●	●	●	●	025D 039E 039F 01BB 03A0
2008	Challenger	HVAC	●	●	●	●	●	●	●	0288 0287 00E9 00EC 03A9 02EB
2008	Challenger	SUNR	●	●	●	●	●	●	○	
2008	Challenger	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069
2008	Challenger	HFM	●	●	●	●	●	●	○	00E3
2008	Challenger	TCM	●	●	●	●	●	○	○	01F4 0081 01F3 01F2
2008	Challenger	CCN	●	●	●	●	●	●	●	008F 008E 0094 03A5 038D 0090 0383
2008	Challenger	SCM	●	●	●	●	○	●	●	
2008	Challenger	TIPMCGW	●	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 0219 003D 0032 030B 0036 0037 0389 0034 0038 003A 030A 038F 003B 02F4 0388 0390 022D 03A2
2008	Challenger	PDM	●	●	●	●	●	●	○	0306 0081
2008	300 / Magnum / Charger (Pre-2011)	AHBM	●	●	●	●	●	○	○	0067 0066 0081
2008	300 / Magnum / Charger (Pre-2011)	PCM	●	●	●	●	●	●	●	#####
2008	300 / Magnum / Charger (Pre-2011)	SDARV	●	●	●	●	●	○	○	
2008	300 / Magnum / Charger (Pre-2011)	ITM	●	●	●	●	●	●	●	0104 0105 0107 0385 0106 0081

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2008	300 / Magnum / Charger (Pre-2011)	ESM	●	●	●	●	●	●	○	
2008	300 / Magnum / Charger (Pre-2011)	RADIO	●	●	●	●	●	●	●	025D 039E 039F 01BB 03A0
2008	300 / Magnum / Charger (Pre-2011)	TIPMCGW	●	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 0219 003D 0032 0322 0036 0037 0389 0034 0038 00C8 003A 02E5 038F 003B 02F4 0388 0390 022D 03A2
2008	300 / Magnum / Charger (Pre-2011)	ACC	●	●	●	●	●	○	●	0064 0321 0065 02CE 0081
2008	300 / Magnum / Charger (Pre-2011)	HIDT	●	●	●	●	●	●	○	00E5 0081
2008	300 / Magnum / Charger (Pre-2011)	SUNR	●	●	●	●	●	●	○	
2008	300 / Magnum / Charger (Pre-2011)	HFM	●	●	●	●	●	●	○	00E3
2008	300 / Magnum / Charger (Pre-2011)	VES3	●	●	●	●	●	●	●	
2008	300 / Magnum / Charger (Pre-2011)	MSMD	●	●	●	●	●	○	○	02EE 00BC 0114 0116 0118 0117 0081 0115 0119
2008	300 / Magnum / Charger (Pre-2011)	SCM	●	●	●	●	○	●	●	
2008	300 / Magnum / Charger (Pre-2011)	WCM	●	●	●	●	●	●	●	02A7 0414 0233 022E 01D2 03E4 0228 03E6 0232 0230 0231 022F 01DE 0413 0300 0245 0225 0244 0081 01DA 02FC
2008	300 / Magnum / Charger (Pre-2011)	HSM	●	●	●	●	●	●	●	
2008	300 / Magnum / Charger (Pre-2011)	EOM	●	●	●	●	●	○	●	00BA 0081
2008	300 / Magnum / Charger (Pre-2011)	PTIM	●	●	●	●	●	●	●	
2008	300 / Magnum / Charger (Pre-2011)	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069
2008	300 / Magnum / Charger (Pre-2011)	DDM	●	●	●	●	●	●	●	
2008	300 / Magnum / Charger (Pre-2011)	PDM	●	●	●	●	●	●	●	00AC 0081
2008	300 / Magnum / Charger (Pre-2011)	CCN	●	●	●	●	●	●	●	008F 008E 0094 03A5 038D 0090 0383
2008	300 / Magnum / Charger (Pre-2011)	ABS	●	●	●	●	●	●	●	0002 0285 0062
2008	300 / Magnum / Charger (Pre-2011)	TCM	●	●	●	●	●	○	○	01F4 0081 01F3 01F2

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2008	300 / Magnum / Charger (Pre-2011)	ORC	●	●	●	●	●	○	●	02A1
2008	300 / Magnum / Charger (Pre-2011)	PTS	●	●	●	●	○	●	○	01B4 01B3 01B5 01B8 0081
2008	300 / Magnum / Charger (Pre-2011)	HVAC	●	●	●	●	●	●	●	00EA 00E9 02EA 02EB 0081
2008	300 / Magnum / Charger (Pre-2011)	LRSM	●	●	●	●	●	○	○	010D 0081
2008	Compass	TCM	●	●	●	●	●	●	●	0081 01F5
2008	Compass	ITM	●	●	●	●	●	●	●	0104 0105 0107 0385 0106 0081
2008	Compass	AWD	●	●	●	●	●	●	●	
2008	Compass	AMP	●	●	●	●	●	○	●	0289 028A 006D 006B 006C 0068 006A 0081 0069 0073
2008	Compass	RADIO	●	●	●	●	●	○	●	01BB 0081
2008	Compass	SDAR	●	●	●	●	●	○	○	0081
2008	Compass	PCM	●	●	●	●	●	●	●	02E7 0140 013E 0126 0141 0044 0128 012E 0314 012C 012D 013B 0173 012A 0081 012B 0042 0142 0310 0313 0312 03A3 0311 0144 03A4
2008	Compass	SAS	●	●	●	●	○	○	○	
2008	Compass	WCM	●	●	●	●	●	○	●	02A7 01D2 0228 0226 0225 0232 0230 0231 022F 0244 0081 0233 022D 023D 023E 0271 0270
2008	Compass	HFM	●	●	●	●	●	●	○	00E3
2008	Compass	ABS	●	●	●	●	●	●	●	0002 0285 0062 03AB 0081
2008	Compass	TIPMCGW	●	●	●	●	●	●	●	02F3 0039 003C 003D 0214 0032 0210 003F 003E 0036 0037 0035 0034 0038 003A 020E 0213 0215 028F 0211 003B 02F4 0033 0390 030D 030F 02F1 02F0 02EF 030E 030C 038F
2008	Compass	ORC	●	●	●	●	●	○	●	0081 0122
2008	Compass	CCN	●	●	●	●	●	●	●	008C 008F 008E 0094 0092 0081 0096 0090
2008	Dakota	ORC	●	●	●	●	●	○	●	02A1
2008	Dakota	HFM	●	●	●	●	●	●	○	00E3
2008	Dakota	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069
2008	Dakota	WCM	●	●	●	●	●	○	●	01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0244 0081 0233 022D 023E 0271
2008	Dakota	FCMCGW	●	●	●	●	●	●	●	02F1 02F0 02F3 02EF 0039 003C 003D 02A6 02A5 02A4 0032 0257 003E 0036 00D5 00D8 0037 0035 0034 0038 00DB 00D6 00D9 003A 0293 003B 0302 0033 00C6 0040 00DA 0272 0273
2008	Dakota	CCN	●	●	●	●	●	●	●	008F 008E 008D 0081 0090
2008	Dakota	RADIO	●	●	●	●	●	●	●	039F 039E 01BB 03A0 025D
2008	Dakota	HVAC	●	●	●	●	●	●	●	00EA 00E8 00E9 02EA 02EB 0081
2008	Dakota	EOM	●	●	●	●	●	○	●	00BA

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2008	Dakota	PCM	●	●	●	●	●	●	●	027B 025F 025E 0260 027C 0262 0261 027D 0264 0263 02F8 0127 0140 0126 0044 026C 026D 0128 027E 0266 0265 0145 02FB 013C 012C 012D 0177 0173 012A 0281 0280 0176 024E 0170 016F 0081 012B 035B 0269 01FC 013B
2008	Dakota	ABS	●	●	●	●	●	●	●	0002 0285 0062
2008	Raider	PCM	●	●	●	●	●	●	●	027B 025F 025E 0260 027C 0262 0261 027D 0264 0263 02F8 0127 0140 0126 0044 026C 026D 0128 027E 0266 0265 0145 02FB 013C 012C 012D 0177 0173 012A 0281 0280 0176 024E 0170 016F 0081 012B 035B 0269 01FC 013B
2008	Raider	FCMCGW	●	●	●	●	●	●	●	02F1 02F0 02F3 02EF 0039 003C 003D 02A6 02A5 02A4 0032 003E 0036 00D5 00D8 0037 0035 0034 0038 00DB 00D6 00D9 003A 0293 003B 0302 0033 00C6 0040 00DA 0272 0273
2008	Raider	HVAC	●	●	●	●	●	●	●	00EA 00E8 00E9 02EA 02EB 0081
2008	Raider	ABS	●	●	●	●	●	●	●	0002 0285 0062
2008	Raider	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069
2008	Raider	CCN	●	●	●	●	●	●	●	008F 008E 008D 0081 0090
2008	Raider	ORC	●	●	●	●	●	○	●	02A1
2008	Raider	RADIO	●	●	●	●	●	●	●	025D 039E 039F 01BB 03A0
2008	Raider	HFM	●	●	●	●	●	●	○	00E3
2008	Raider	EOM	●	●	●	●	●	○	●	00BA
2008	Raider	WCM	●	●	●	●	●	○	●	01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0244 0081 0233 022D 023E 0271
2008	Caliber	ITM	●	●	●	●	●	●	●	0104 0105 0107 0385 0106 0081
2008	Caliber	EBG	●	●	●	●	●	○	○	
2008	Caliber	WCM	●	●	●	●	●	○	●	02A7 01D2 0228 0226 0225 0232 0230 0231 022F 0244 0081 0233 022D 023D 023E 0271 0270
2008	Caliber	HFM	●	●	●	●	●	●	○	00E3
2008	Caliber	TCM	●	●	●	●	●	●	●	0081 01F5
2008	Caliber	CCN	●	●	●	●	●	●	●	008C 008F 008E 0094 0092 0081 0096 0090
2008	Caliber	AWD	●	●	●	●	●	●	●	
2008	Caliber	ORC	●	●	●	●	●	○	●	0081 0122
2008	Caliber	ABS	●	●	●	●	●	●	●	0002 0285 0062
2008	Caliber	AMP	●	●	●	●	●	○	●	0289 028A 006D 006B 006C 0068 006A 0081 0079 0069 0073
2008	Caliber	TIPMCGW	●	●	●	●	●	●	●	030D 030F 02F1 02F0 02F3 02EF 0039 030E 030C 003C 003D 0214 0032 0210 003F 003E 0036 0037 0035 0034 0038 003A 020E 0213 0215 028F 0211 038F 003B 02F4 0033 0390
2008	Caliber	RADIO	●	●	●	●	●	●	●	01BB 0081 039F 039E 03A0 025D
2008	Caliber	SAS	●	●	●	●	○	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2008	Town & Country / Caravan	PSDMR	●	●	●	●	●	○	●	0343 0198 019B 0197 0342 0081
2008	Town & Country / Caravan	WCM	●	●	●	●	●	●	●	02A7 0414 0233 022E 01D2 03E4 0228 03E6 0232 0230 0231 022F 01DE 0413 0300 0245 0225 0244 0081 01DA 02FC
2008	Town & Country / Caravan	DMFL	●	●	●	●	●	●	●	
2008	Town & Country / Caravan	HVAC	●	●	●	●	●	●	●	00EA 00E9 00EC 02EA 02EB 0081 0288 0287 03A9
2008	Town & Country / Caravan	DMFR	●	●	●	●	●	●	●	
2008	Town & Country / Caravan	PLGM	●	●	●	●	●	●	●	038A 038B 00B4 0199 00B5 0342
2008	Town & Country / Caravan	PSDML	●	●	●	●	●	○	●	0343 0198 019B 0197 0342 0081
2008	Town & Country / Caravan	ITM	●	●	●	●	●	●	●	0104 0105 0107 0385 0106 0081
2008	Sprinter	ECM	●	●	●	●	●	●	●	0025 0329 0024 001E 0335 004A 004C 0023 0022 0020 0021 0042 0142 0127 0044 0337 0045 0046 0043 0049 014D 026E 002E 026F 0336
2008	Sprinter	TM	●	●	●	●	○	○	○	0019
2008	Sprinter	PSM	●	●	●	●	●	●	○	0329 004A 0258 0339 0015
2008	Sprinter	AEHM	●	●	●	●	●	○	○	0004
2008	Sprinter	ESM	●	●	●	●	●	●	○	000F
2008	Sprinter	PTS	●	●	●	●	●	●	●	02D2 02D3
2008	Sprinter	DDM	●	●	●	●	●	●	○	
2008	Sprinter	BCM	●	●	●	●	●	●	○	02E1
2008	Sprinter	SBM	●	●	●	●	●	●	○	
2008	Sprinter	PSDML	●	●	●	●	○	●	○	0377 0376
2008	Sprinter	EISCGW	●	●	●	●	●	○	●	000B 0329 032A 032B 004A 004C 032C 002C 000D 000E 002B 002A 000C
2008	Sprinter	RADIO	●	●	●	●	●	○	●	0028 0027 0029 024A 004A 0081 0041 004B
2008	Sprinter	SCM	●	●	●	●	●	●	○	
2008	Sprinter	TPM	●	●	●	●	●	○	○	02D0 02D1 004A 001A 001B 001C 001D 0247 004E
2008	Sprinter	PSDMR	●	●	●	●	○	●	○	0376 0377
2008	Sprinter	HVAC	●	●	●	●	●	●	●	0012
2008	Sprinter	AHLM	●	●	●	●	●	●	○	0329 029F 004A 004C
2008	Sprinter	TCM	●	●	●	●	●	○	○	02D6 02D7 02D4 02D5 0329 004A 004C 0328 0018
2008	Sprinter	ORC	●	●	●	○	●	○	○	0329 004A 004C 0338 0014 0013 02CF
2008	Sprinter	ACH	●	●	●	●	●	●	○	
2008	Sprinter	BCH	●	●	●	●	●	●	○	
2008	Sprinter	RCM	●	●	●	●	●	●	○	0249 0016 0017

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2008	Sprinter	CCN	●	●	●	●	●	○	○	0007 0008 0005 0334 0006 0329 032F 0330 0331 0332 0333 004A 004C 0009 000A
2008	Sprinter	ABS	●	●	●	●	●	○	●	032D 0329 0002 0001 0003 004A 004C
2008	Sprinter	HFM	●	●	●	●	●	○	○	004A
2008	Sprinter	CDC	●	●	●	●	●	○	○	
2008	Grand Cherokee	EOM	●	●	●	●	●	○	●	00BA 0081
2008	Grand Cherokee	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069
2008	Grand Cherokee	DDM	●	●	●	●	●	●	●	0081 00AC
2008	Grand Cherokee	TM	●	●	●	○	○	○	○	
2008	Grand Cherokee	SAS	●	●	●	●	○	○	○	
2008	Grand Cherokee	PCM	●	●	●	●	●	●	●	#####
2008	Grand Cherokee	FDCM	●	●	●	●	●	●	●	0081
2008	Grand Cherokee	WCM	●	●	●	●	●	●	●	02A7 022E 01D2 0228 0225 0232 0230 0231 022F 01DE 0244 0081 0300 0233 01DA 0245 02FC 0414 03E4 03E6 0413
2008	Grand Cherokee	PTS	●	●	●	●	●	●	●	01B4 01B3 01B5 01B8 0081 02ED 03B7
2008	Grand Cherokee	ESM	●	●	●	●	●	●	○	
2008	Grand Cherokee	AHLM	●	●	●	●	●	●	○	029F 0081
2008	Grand Cherokee	SDARV	●	●	●	●	●	○	○	
2008	Grand Cherokee	CCN	●	●	●	●	●	●	●	0097 008C 008F 008E 0091 0094 0081 0099 0098 0090
2008	Grand Cherokee	PDM	●	●	●	●	●	●	●	00AC 0081
2008	Grand Cherokee	ITM	●	●	●	●	●	●	●	0104 0105 0107 0385 0106 0081
2008	Grand Cherokee	ABS	●	●	●	●	●	●	●	0002 0285 0062
2008	Grand Cherokee	RADIO	●	●	●	●	●	●	●	039F 039E 01BB 03A0 025D
2008	Grand Cherokee	HSM	●	●	●	●	●	●	●	
2008	Grand Cherokee	VES3	●	●	●	●	●	●	●	
2008	Grand Cherokee	TCM	●	●	●	●	●	○	○	01F4 0081 01F3 01F2
2008	Grand Cherokee	AHBM	●	●	●	●	●	○	○	0067 0066 0081
2008	Grand Cherokee	MSMD	●	●	●	●	●	○	○	02EE 00BC 0114 0116 0118 0117 0081 0115 0119
2008	Grand Cherokee	SUNR	●	●	●	●	●	●	○	
2008	Grand Cherokee	LRSM	●	●	●	●	●	○	○	010D 0081
2008	Grand Cherokee	HFM	●	●	●	●	●	●	○	00E3
2008	Grand Cherokee	HVAC	●	●	●	●	●	●	●	00EA 00E9 02EA 02EB 0081
2008	Grand Cherokee	ORC	●	●	●	●	●	○	●	02A1 0122
2008	Grand Cherokee	FCMCGW	●	●	●	●	●	●	●	02F1 02F0 02F3 02EF 0039 003C 003D 02A6 02A5 02A4 0032 0257 003E 0036 00D5 00D8 0037 0035 0034 0038 00DB 00D6 00D9 003A 0293 0081 003B 0302 0033 00C6 0040 022D 00DA 0272 0273
2008	Commander	MSMD	●	●	●	●	●	○	○	02EE 00BC 0114 0116 0118 0117 0081 0115 0119
2008	Commander	HFM	●	●	●	●	●	●	○	00E3
2008	Commander	RADIO	●	●	●	●	●	●	●	025D 039E 039F 01BB 03A0
2008	Commander	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069
2008	Commander	SUNR	●	●	●	●	●	●	○	
2008	Commander	TCM	●	●	●	●	●	○	○	01F4 0081 01F3 01F2

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2008	Commander	ITM	●	●	●	●	●	●	●	0104 0105 0107 0385 0106 0081
2008	Commander	PLGM	●	●	●	●	●	●	●	038A 038B 00B4 0199 00B5
2008	Commander	HVAC	●	●	●	●	●	●	●	00EA 00E9 02EA 02EB 0081
2008	Commander	VES3	●	●	●	●	●	●	●	
2008	Commander	PDM	●	●	●	●	●	●	●	0081 00AC
2008	Commander	WCM	●	●	●	●	●	●	●	02A7 0414 0233 022E 01D2 03E4 0228 03E6 0232 0230 0231 022F 01DE 0413 0300 0245 0225 0244 0081 01DA 02FC
2008	Commander	ABS	●	●	●	●	●	●	●	0002 0285 0062
2008	Commander	FDCM	●	●	●	●	●	●	●	0081
2008	Commander	LRSM	●	●	●	●	●	○	○	010D 0081
2008	Commander	SDARV	●	●	●	●	●	○	○	
2008	Commander	HSM	●	●	●	●	●	●	●	
2008	Commander	SAS	●	●	●	●	○	○	○	
2008	Commander	FCMCGW	●	●	●	●	●	●	●	02F1 02F0 02F3 02EF 0039 003C 003D 02A6 02A5 02A4 0032 0257 003E 0036 00D5 00D8 0037 0035 0034 0038 00DB 00D6 00D9 003A 0293 0081 003B 0302 0033 00C6 0040 022D 00DA 0272 0273
2008	Commander	ESM	●	●	●	●	●	●	○	
2008	Commander	PTS	●	●	●	●	○	●	○	01B4 01B3 01B5 01B8 0081
2008	Commander	AHBM	●	●	●	●	●	○	○	0067 0066 0081
2008	Commander	DDM	●	●	●	●	●	●	●	0081 00AC
2008	Commander	CCN	●	●	●	●	●	●	●	0097 008C 008F 008E 0091 0094 0081 0099 0098 0090
2008	Commander	ORC	●	●	●	●	●	○	●	02A1 0122
2008	Commander	TM	●	●	●	○	○	○	○	
2008	Commander	PCM	●	●	●	●	●	●	●	#####
2008	Viper (Pre-2011)	OCM	●	●	●	●	●	○	○	02AD 0081
2008	Viper (Pre-2011)	PCM	●	●	●	●	●	●	○	013E 0126 0141 0044 0325 0193 0128 0145 0326 012C 012D 012A 0081 012B
2008	Viper (Pre-2011)	SDAR	●	●	●	●	●	●	○	
2008	Viper (Pre-2011)	HVAC	●	●	●	●	○	●	○	
2008	Viper (Pre-2011)	RADIO	●	●	●	○	○	●	○	
2008	Viper (Pre-2011)	ABS	●	●	●	●	○	●	○	
2008	Viper (Pre-2011)	ORC	●	●	●	●	●	●	●	
2008	Viper (Pre-2011)	BCM	●	●	●	●	○	●	○	
2008	Viper (Pre-2011)	MIC/CCN	●	●	●	●	●	○	○	
2008	Viper (Pre-2011)	PCI to CAN Gateway	●	●	●	●	○	○	○	
2008	Crossfire	OCM	●	●	●	●	○	○	○	
2008	Crossfire	ORC	●	●	●	●	○	○	○	02A1
2008	Crossfire	BCM	●	●	●	●	○	●	○	
2008	Crossfire	TCM	●	●	●	●	●	●	●	
2008	Crossfire	PTCM	●	●	●	●	○	●	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2008	Crossfire	SLA	●	●	●	●	○	●	○	
2008	Crossfire	ESP	●	●	●	●	○	●	○	
2008	Crossfire	IC	●	●	●	●	○	●	○	
2008	Crossfire	PCM	●	●	●	●	○	●	○	
2008	Crossfire	CLP	●	●	●	●	○	●	○	
2008	Crossfire	SKREEM	●	●	●	●	○	●	○	
2008	Crossfire	TPM	●	●	●	●	●	○	●	
2008	Crossfire	HVAC	●	●	●	●	○	●	○	
2009	Dodge Ram	CCN	●	●	●	●	●	●	●	008C 008F 008E 02D9 02DB 02E0 03A5 0081 0090
2009	Dodge Ram	SDAR	●	●	●	●	●	○	○	0081
2009	Dodge Ram	SUNR	●	●	●	●	●	●	○	
2009	Dodge Ram	EOM	●	●	●	●	●	●	●	00BA 0081
2009	Dodge Ram	VES	●	●	●	●	●	●	○	
2009	Dodge Ram	AMP	●	●	●	●	●	○	●	028A 028D 006D 006C 027F 0068 006A 0081
2009	Dodge Ram	SAS	●	●	●	●	○	○	○	
2009	Dodge Ram	TCM	●	●	●	●	●	●	○	027B 0167 0166 01EE 027C 016A 0169 027D 0291 016C 016B 02F8 0290 027E 016E 016D 0392 0393 0394 0395 0177 0176 024E 01FB 016F 0081 0396 035B 0175 01FC 01F6 0391
2009	Dodge Ram	RADIO	●	●	●	●	●	○	●	01BB 0081
2009	Dodge Ram	TIPMCGW	●	●	●	●	●	●	●	033E 030D 030F 02F1 02F0 02F3 02EF 0039 030E 030C 003C 003D 0214 0032 0210 003F 003E 0036 0037 0034 0038 003A 020E 0213 0215 028F 0211 0387 038F 003B 02F4 0033 0390
2009	Dodge Ram	FDCM	●	●	●	●	●	○	○	02B4 02B7 02B6 02B5 02B3 02B2 02B1 02AF 02B0 0081
2009	Dodge Ram	HFM	●	●	●	●	●	●	○	00E3
2009	Dodge Ram	ABS	●	●	●	●	●	●	●	0002 0285 0062 0081
2009	Dodge Ram	HVAC	●	●	●	●	●	●	●	00EB 00E8 00E9 02EA 02EB 0081 00EA
2009	Dodge Ram	PCM	●	●	●	●	●	●	●	#####
2009	Dodge Ram	ORC	●	●	●	●	●	○	●	0081 0122
2009	Dodge Ram	WCM	●	●	●	●	●	○	●	01D2 0228 0226 0225 0232 0230 0231 022F 0244 0081 0233 033F 03A7 03A8 023D 023E 03A6 0271 0270
2009	Ram 1500	SDARV	●	●	●	●	●	○	○	
2009	Ram 1500	RADIO	●	●	●	●	●	●	●	039F 0301 039E 01BB 03A0 025D
2009	Ram 1500	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 0039 008F 008E 003D 0214 0032 003F 0036 0037 0035 0038 002E 0387 038F 003B 02F4 0033 0390 021D 022D
2009	Ram 1500	PCM	●	●	●	●	●	●	●	027B 025F 025E 0260 027C 0262 0261 027D 0264 0263 02F8 0127 0140 0126 0044 026C 026D 0128 027E 0266 0265 0145 02FB 03B8 013C 012C 012D 0177 0173 012A 0281 0280 0176 024E 0170 016F 0081 012B 035B 0269 01FC 013B 02F9 0304 02FA
2009	Ram 1500	DMFR	●	●	●	●	○	●	○	
2009	Ram 1500	CCN	●	●	●	●	●	●	●	00BC 0094 03A5 038D 0091

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2009	Ram 1500	DMFL	●	●	●	●	●	●	○	
2009	Ram 1500	ABS	●	●	●	●	●	●	●	0002 0285 0062 0081
2009	Ram 1500	WCM	●	●	●	●	●	●	●	02A7 0414 0233 01D2 03E4 0228 03E6 0232 0230 0231 022F 01DE 0413 0300 0245 02FF 0225 0244 0081 01DA 02FC 02FD 02FE
2009	Ram 1500	DTCM	●	●	●	●	●	●	○	
2009	Ram 1500	HVAC	●	●	●	●	●	●	●	00EA 00E9 00EC 02EA 02EB 0081 02E9
2009	Ram 1500	PTS	●	●	●	●	●	●	●	02ED 03B7
2009	Ram 1500	HFM	●	●	●	●	●	●	○	00E3
2009	Ram 1500	MSMD	●	●	●	●	●	○	○	02EE 00BC 0114 0116 0118 0117 0081 0115 0119
2009	Ram 1500	HSM	●	●	●	●	●	●	○	
2009	Ram 1500	SAS	●	●	●	●	○	○	○	
2009	Ram 1500	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069
2009	Ram 1500	ORC	●	●	●	●	●	○	●	02A1
2009	Ram 1500	VES3	●	●	●	●	●	●	●	
2009	Durango (Pre-2011)	EOM	●	●	●	●	●	●	●	00BA 0081
2009	Durango (Pre-2011)	EAC	●	●	●	●	●	○	○	
2009	Durango (Pre-2011)	HGM	●	●	●	●	●	●	●	034D
2009	Durango (Pre-2011)	DDM	●	●	●	●	●	●	●	0081 00AC
2009	Durango (Pre-2011)	BPCM	●	○	○	●	○	○	○	02C5 0350 03BF 018D 0351 034F 0359 034E 0354 0352 0353 0356 0355 0358 0357
2009	Durango (Pre-2011)	HVAC	●	●	●	●	●	●	●	00EA 034A 00E9 034B 02EA 02EB 0081 00E8 0324
2009	Durango (Pre-2011)	SDARV	●	●	●	●	●	○	○	
2009	Durango (Pre-2011)	HSM	●	●	●	●	●	●	●	
2009	Durango (Pre-2011)	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069
2009	Durango (Pre-2011)	EPS	●	●	●	●	●	○	○	
2009	Durango (Pre-2011)	MSMD	●	●	●	●	●	○	○	02EE 00BC 0114 0116 0118 0117 0081 0115 0119
2009	Durango (Pre-2011)	SAS	●	●	●	●	○	○	○	
2009	Durango (Pre-2011)	FCMCGW	●	●	●	●	●	●	●	02F1 02F0 02F3 02EF 0039 003C 003D 02A6 02A5 02A4 0032 0257 003E 0036 00D5 00D8 0037 0035 0034 0038 00DB 00D6 00D9 003A 0293 003B 0302 0033 00C6 0040 00DA 0272 0273
2009	Durango (Pre-2011)	MCPA	●	○	○	●	○	○	○	034C
2009	Durango (Pre-2011)	RADIO	●	●	●	●	●	●	●	025D 039E 039F 01BB 0301 03A0
2009	Durango (Pre-2011)	FDCM	●	●	●	●	●	●	○	0081
2009	Durango (Pre-2011)	ABS	●	●	●	●	●	●	●	035A 03BB 0002 0285 0062 0081
2009	Durango (Pre-2011)	ORC	●	●	●	●	●	○	●	0081 0122
2009	Durango (Pre-2011)	CCN	●	●	●	●	●	●	●	008F 008E 02D9 008D 02DB 03BA 02E0 03A5 0090
2009	Durango (Pre-2011)	TCM	●	●	●	●	●	○	○	018D 0360 035B 035C 035D 035E 035F
2009	Durango (Pre-2011)	PDM	●	●	●	●	●	●	●	00AC 0081
2009	Durango (Pre-2011)	PTS	●	●	●	●	●	●	●	01B4 01B3 01B5 01B8 0081
2009	Durango (Pre-2011)	PLGM	●	●	●	●	●	●	●	038A 038B 00B4 0199 00B5
2009	Durango (Pre-2011)	HCP	●	●	●	●	●	○	○	0363 018D 0365 036C 03BD 036A 03BE 0367 036B 0368 035B 0369 036D 0361 0364 036F 0362 036E

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2009	Durango (Pre-2011)	WCM	●	●	●	●	●	○	●	01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0244 0081 0233 022D 023E 0271
2009	Durango (Pre-2011)	APM	●	○	○	○	○	○	○	018D
2009	Durango (Pre-2011)	HFM	●	●	●	●	●	●	○	00E3
2009	Durango (Pre-2011)	VES3	●	●	●	●	●	●	●	
2009	Durango (Pre-2011)	MCPB	●	○	○	●	○	○	○	034C
2009	Durango (Pre-2011)	PCM	●	●	●	●	●	●	●	027B 025F 025E 0260 027C 0262 0261 027D 0264 0263 02F8 0127 0140 0126 0044 026C 026D 0128 027E 0266 0265 0145 02FB 03B8 013C 012C 012D 0177 0173 012A 0281 0280 0176 024E 0170 016F 0081 012B 035B 0269 01FC 013B 02F9 0304 02FA
2009	Aspen	SAS	●	●	●	●	○	○	○	
2009	Aspen	WCM	●	●	●	●	●	○	●	01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0244 0081 0233 022D 023E 0271
2009	Aspen	HSM	●	●	●	●	●	●	●	
2009	Aspen	FCMCGW	●	●	●	●	●	●	●	02F1 02F0 02F3 02EF 0039 003C 003D 02A6 02A5 02A4 0032 0257 003E 0036 00D5 00D8 0037 0035 0034 0038 00DB 00D6 00D9 003A 0293 003B 0302 0033 00C6 0040 00DA 0272 0273
2009	Aspen	PLGM	●	●	●	●	●	●	●	038A 038B 00B4 0199 00B5
2009	Aspen	MCPB	●	○	○	●	○	○	○	034C
2009	Aspen	MSMD	●	●	●	●	●	○	○	02EE 00BC 0114 0116 0118 0117 0081 0115 0119
2009	Aspen	TCM	●	●	●	●	●	○	○	018D 0360 035B 035C 035D 035E 035F
2009	Aspen	HCP	●	●	●	●	●	○	○	0363 018D 0365 036C 03BD 036A 03BE 0367 036B 0368 035B 0369 036D 0361 0364 036F 0362 036E
2009	Aspen	ABS	●	●	●	●	●	●	●	0002 0285 0062 0081 035A 03BB
2009	Aspen	PCM	●	●	●	●	●	●	●	027B 025F 025E 0260 027C 0262 0261 027D 0264 0263 02F8 0127 0140 0126 0044 026C 026D 0128 027E 0266 0265 0145 02FB 03B8 013C 012C 012D 0177 0173 012A 0281 0280 0176 024E 0170 016F 0081 012B 035B 0269 01FC 013B 02F9 0304 02FA
2009	Aspen	HVAC	●	●	●	●	●	●	●	00EA 034A 00E9 034B 02EA 02EB 0081 00E8 0324
2009	Aspen	FDCM	●	●	●	●	●	●	○	0081
2009	Aspen	BPCM	●	○	○	●	○	○	○	02C5 0350 03BF 018D 0351 034F 0359 034E 0354 0352 0353 0356 0355 0358 0357
2009	Aspen	APM	●	○	○	○	○	○	○	018D
2009	Aspen	MCPA	●	○	○	●	○	○	○	034C
2009	Aspen	HFM	●	●	●	●	●	●	○	00E3
2009	Aspen	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069
2009	Aspen	RADIO	●	●	●	●	●	●	●	039F 0301 039E 01BB 03A0 025D
2009	Aspen	VES3	●	●	●	●	●	●	●	
2009	Aspen	EAC	●	●	●	●	●	○	○	
2009	Aspen	CCN	●	●	●	●	●	●	●	008F 008E 02D9 008D 02DB 03BA 02E0 03A5 0090

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2009	Aspen	ORC	●	●	●	●	●	○	●	0081 0122
2009	Aspen	EPS	●	●	●	●	●	○	○	
2009	Aspen	PTS	●	●	●	●	●	●	●	01B4 01B3 01B5 01B8 0081
2009	Aspen	DDM	●	●	●	●	●	●	●	0081 00AC
2009	Aspen	EOM	●	●	●	●	●	●	●	00BA 0081
2009	Aspen	HGM	●	●	●	●	●	●	●	034D
2009	Aspen	SDARV	●	●	●	●	●	○	○	
2009	Aspen	PDM	●	●	●	●	●	●	●	00AC 0081
2009	Wrangler (Export)	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 0039 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0035 0038 003A 021E 021F 038F 003B 02F4 0033 0390 021D
2009	Wrangler (Export)	PCM	●	●	●	●	●	●	○	0145 012D 0042 0149 0142 02BA 02B9 02BF 02BD 02BE 02BC 014A 0148 0044 0049 0144 0081 02C0 02BB 031D 02C1 013B 02C2
2009	Wrangler (Export)	ABS	●	●	●	●	●	●	●	0002 0285 0062 0081
2009	Wrangler (Export)	TCM	●	●	●	●	●	●	○	0392 0393 0394 0395 0176 024E 01FB 016F 0081 0396 035B 01FC
2009	Wrangler (Export)	RADIO	●	●	●	●	●	●	●	025D 039E 039F 01BB 01BC 0081 03A0
2009	Wrangler (Export)	CCN	●	●	●	●	●	●	○	008C 00BC 0382 0091 0094 038D 0096 0383
2009	Wrangler (Export)	WCM	●	●	●	●	●	○	●	0233 01D2 03E4 0341 0228 04A2 0232 0230 0231 022F 01DE 0413 022D 0227
2009	Wrangler (Export)	SAS	●	●	●	●	○	○	○	
2009	Wrangler (Export)	ORC	●	●	●	●	●	○	●	0081 0122
2009	Journey	VES3	●	●	●	●	●	●	●	
2009	Journey	HFM	●	●	●	●	●	●	○	00E3
2009	Journey	SDARV	●	●	●	●	●	○	○	
2009	Journey	DISP	●	●	●	●	●	○	○	
2009	Journey	PCM	●	●	●	●	●	●	●	#####
2009	Journey	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 0039 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0035 0038 003A 02E3 021E 021F 038F 003B 02F4 0033 0390 021D 022D
2009	Journey	ORC	●	●	●	●	●	○	●	02A1 0122
2009	Journey	CCN	●	●	●	●	○	●	●	008C 0091 02D9 02DB 0094 02E0 03A5 037F 037E 0081 0096
2009	Journey	SAS	●	●	●	●	○	○	○	
2009	Journey	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069
2009	Journey	HVAC	●	●	●	●	●	●	●	00EA 03B9 03A9 02EB 00E9 00EC 02EA 0081 0288 0287
2009	Journey	ITM	●	●	●	●	●	●	●	0104 0105 0107 0385 0106 0081
2009	Journey	WCM	●	●	●	●	●	●	●	02A7 022E 01D2 0228 0225 0232 0230 0231 022F 01DE 0244 0081 0300 0233 01DA 0245 02FC 0414 03E4 03E6 0413
2009	Journey	DMFR	●	●	●	●	●	●	●	
2009	Journey	ABS	●	●	●	●	●	●	●	0002 0285 0062
2009	Journey	RADIO	●	●	●	●	●	●	●	039F 0301 039E 01BB 03A0 025D

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2009	Journey	TCM	●	●	●	●	●	●	●	0167 0166 01EE 016A 0169 016C 016B 016E 016D 01F0 0172 0177 0170 016F 0175 0391 0081
2009	Journey	AWD	●	●	●	●	●	○	●	
2009	Journey	DMFL	●	●	●	●	●	●	●	
2009	Wrangler	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 0039 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0035 0038 003A 021E 021F 038F 003B 02F4 0033 0390 021D
2009	Wrangler	PCM	●	●	●	●	●	●	●	#####
2009	Wrangler	CCN	●	●	●	●	●	●	○	008C 00BC 0382 0091 0094 038D 0096 0383
2009	Wrangler	ORC	●	●	●	●	●	○	●	0081 0122
2009	Wrangler	ABS	●	●	●	●	●	●	●	0002 0285 0062 0081
2009	Wrangler	ITM	●	●	●	●	●	●	●	0385 0106 0081
2009	Wrangler	WCM	●	●	●	●	●	○	●	01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0244 0081 0233 022D 0227 0274 031E 031F
2009	Wrangler	SAS	●	●	●	●	○	○	○	
2009	Wrangler	TCM	●	●	●	●	●	●	○	0392 0393 0394 0395 0176 024E 01FB 016F 0081 0396 035B 01FC
2009	Wrangler	HFM	●	●	●	●	●	●	○	00E3
2009	Wrangler	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069
2009	Wrangler	RADIO	●	●	●	●	●	●	●	031C 025D 039E 039F 01BB 0301 03A0 0081
2009	Wrangler	ASBS	●	●	●	●	●	○	○	0081 0317 0318 031A 031B 0319
2009	Sebring / 200 / Avenger	SAS	●	●	●	●	○	○	○	
2009	Sebring / 200 / Avenger	DDM	●	●	●	●	●	●	○	0306 0081
2009	Sebring / 200 / Avenger	WCM	●	●	●	●	●	○	●	02A7 022E 01D2 0228 0226 0225 0232 0230 0231 022F 0244 0081 0233 022D 023D 023E 0271 0270
2009	Sebring / 200 / Avenger	AWD	●	●	●	●	●	○	●	
2009	Sebring / 200 / Avenger	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069
2009	Sebring / 200 / Avenger	PDM	●	●	●	●	●	●	○	0306 0081
2009	Sebring / 200 / Avenger	HFM	●	●	●	●	●	●	○	00E3
2009	Sebring / 200 / Avenger	TCM	●	●	●	●	●	●	●	0391 0081 027B 0167 0166 01EE 027C 016A 0169 027D 0291 016C 016B 02F8 0290 027E 016E 016D 0392 0393 0394 0395 0177 0176 024E 01FB 016F 0396 035B 0175 01FC 01F0 0172 0170
2009	Sebring / 200 / Avenger	VES3	●	●	●	●	●	●	●	
2009	Sebring / 200 / Avenger	ABS	●	●	●	●	●	●	●	0002 0285 0062 0081

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2009	Sebring / 200 / Avenger	PTCM	●	●	●	●	●	○	●	0371 025B 0259 026A 0081 025A
2009	Sebring / 200 / Avenger	HVAC	●	●	●	●	●	●	●	00EA 03B9 03A9 02EB 00E9
2009	Sebring / 200 / Avenger	ITM	●	●	●	●	●	●	●	0104 0105 0107 0385 0106 0081
2009	Sebring / 200 / Avenger	TIPMCGW	●	●	●	●	●	●	●	030D 030F 02F1 02F0 02F3 02EF 0039 030E 030C 003C 003D 0214 0032 0210 003F 003E 0036 02C3 0037 0035 0034 0038 003A 020E 0213 0215 028F 0211 038F 003B 02F4 0033 0390
2009	Sebring / 200 / Avenger	RADIO	●	●	●	●	●	●	●	025D 039E 039F 01BB 0081 0301 03A0
2009	Sebring / 200 / Avenger	CCN	●	●	●	●	●	●	●	008C 008F 008E 0094 0092 0081 0096 0090
2009	Sebring / 200 / Avenger	PCM	●	●	●	●	●	●	●	#####
2009	Sebring / 200 / Avenger	ORC	●	●	●	●	●	○	●	0081 0122
2009	Nitro	HFM	●	●	●	●	●	●	○	00E3
2009	Nitro	SAS	●	●	●	●	○	○	○	
2009	Nitro	PTS	●	●	●	●	●	●	●	01B4 01B3 01B5 01B8 0081
2009	Nitro	ORC	●	●	●	●	●	○	●	0122
2009	Nitro	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 0039 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0035 0038 003A 021E 021F 02E2 038F 003B 02F4 0033 0390 021D
2009	Nitro	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069
2009	Nitro	DMFL	●	●	●	●	●	●	●	
2009	Nitro	ITM	●	●	●	●	●	●	●	0104 0105 0107 0385 0106 0081
2009	Nitro	VES3	●	●	●	●	●	●	●	
2009	Nitro	ABS	●	●	●	●	●	●	●	0002 0285 0062 0081
2009	Nitro	OCM	●	●	●	●	●	○	○	011E 0081
2009	Nitro	WCM	●	●	●	●	●	○	●	01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0244 0081 0233 022D 0227 0274 031E 031F
2009	Nitro	TCM	●	●	●	●	●	○	○	01F4 0081 01F3 01F2
2009	Nitro	DMFR	●	●	●	●	●	●	●	
2009	Nitro	HVAC	●	●	●	●	●	●	●	00EA 03B9 03A9 02EB 00E9
2009	Nitro	RADIO	●	●	●	●	●	●	●	025D 039E 039F 01BB 0301 03A0
2009	Nitro	CCN	●	●	●	●	●	●	○	008C 00BC 0382 0091 0094 038D 0096 0383
2009	Nitro	ESM	●	●	●	●	●	●	○	
2009	Nitro	PCM	●	●	●	●	●	●	●	#####
2009	Liberty	HFM	●	●	●	●	●	●	○	00E3
2009	Liberty	WCM	●	●	●	●	●	○	●	01D2 0341 0228 0226 0225 0232 0230 0231 022F 01DE 0244 0081 0233 022D 0227 0274 031E 031F

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2009	Liberty	FDCM	●	●	●	●	●	●	○	0340 0081
2009	Liberty	TCM	●	●	●	●	●	○	○	01F4 0081 01F3 01F2
2009	Liberty	DMFL	●	●	●	●	●	●	●	
2009	Liberty	CCN	●	●	●	●	●	●	○	008C 00BC 0382 0091 0094 038D 0096 0383
2009	Liberty	MSMD	●	●	●	●	●	○	○	02EE 00BC 0114 0116 0118 0117 0081 0115 0119
2009	Liberty	SUNR	●	●	●	●	●	○	○	02E6 0081
2009	Liberty	VES3	●	●	●	●	●	●	●	
2009	Liberty	PCM	●	●	●	●	●	●	●	#####
2009	Liberty	ABS	●	●	●	●	●	●	●	0002 0285 0062
2009	Liberty	DMFR	●	●	●	●	●	●	●	
2009	Liberty	ITM	●	●	●	●	●	●	●	0104 0105 0107 03AA 0106 0081
2009	Liberty	ORC	●	●	●	●	●	○	●	0122
2009	Liberty	RADIO	●	●	●	●	●	●	●	039F 0301 039E 01BB 03A0 025D
2009	Liberty	OCM	●	●	●	●	●	○	○	011E 0081
2009	Liberty	ESM	●	●	●	●	●	●	○	
2009	Liberty	SAS	●	●	●	●	○	○	○	
2009	Liberty	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069
2009	Liberty	HVAC	●	●	●	●	●	●	●	00EA 00E9 03A9 02EB 03B9
2009	Liberty	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 0039 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0035 0038 003A 021E 021F 02E2 038F 003B 02F4 0033 0390 021D
2009	Liberty	PTS	●	●	●	●	●	●	●	01B4 01B3 01B5 01B8 0081
2009	Challenger	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069
2009	Challenger	TCM	●	●	●	●	●	○	○	01F4 0081 01F3 01F2
2009	Challenger	SCM	●	●	●	●	○	●	●	
2009	Challenger	HVAC	●	●	●	●	●	●	●	00EA 03B9 03A9 02EB 0288 0287 00E9 00EC 02EA
2009	Challenger	CCN	●	●	●	●	●	●	●	008F 008E 0094 03A5 038D 0090 0383
2009	Challenger	DDM	●	●	●	●	●	●	○	0306 0081
2009	Challenger	SUNR	●	●	●	●	●	●	○	
2009	Challenger	ESM	●	●	●	●	●	●	○	
2009	Challenger	TPM	●	●	●	●	○	○	●	02F7 0232 0230 0231 022F 0244 0081
2009	Challenger	HSM	●	●	●	●	●	●	●	
2009	Challenger	TIPMCGW	●	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 0219 003D 0032 030B 0036 0037 0389 0034 0038 003A 030A 038F 003B 02F4 0388 0390 022D 03A2
2009	Challenger	RADIO	●	●	●	●	●	●	●	025D 039E 039F 01BB 0301 03A0
2009	Challenger	PCM	●	●	●	●	●	●	●	027B 025F 025E 0260 027C 0262 0261 027D 0264 0263 02F8 0127 0140 0126 02F9 0044 026C 026D 0128 027E 0266 0265 0145 02FB 03B8 013C 012C 012D 0177 0304 0173 012A 0281 0280 02FA 0176 024E 0170 016F 0081 012B 035B 0269 01FC 013B
2009	Challenger	HFM	●	●	●	●	●	●	○	00E3
2009	Challenger	ABS	●	●	●	●	●	●	●	0002 0285 0062
2009	Challenger	PDM	●	●	●	●	●	●	○	0306 0081

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2009	300 / Magnum / Charger (Pre-2011)	EOM	●	●	●	●	●	○	●	00BA 0081
2009	300 / Magnum / Charger (Pre-2011)	ABS	●	●	●	●	●	●	●	0002 0285 0062
2009	300 / Magnum / Charger (Pre-2011)	SUNR	●	●	●	●	●	●	○	
2009	300 / Magnum / Charger (Pre-2011)	ACC	●	●	●	●	●	○	●	0064 0321 0065 02CE 0081
2009	300 / Magnum / Charger (Pre-2011)	VES3	●	●	●	●	●	●	●	
2009	300 / Magnum / Charger (Pre-2011)	HFM	●	●	●	●	●	●	○	00E3
2009	300 / Magnum / Charger (Pre-2011)	ORC	●	●	●	●	●	○	●	02A1
2009	300 / Magnum / Charger (Pre-2011)	AHBM	●	●	●	●	●	○	○	0067 0066 0081
2009	300 / Magnum / Charger (Pre-2011)	WCM	●	●	●	●	●	●	●	02A7 022E 01D2 0228 0225 0232 0230 0231 022F 0244 0081 0300 0233 01DA 0245 02FC 0414 03E4 03E6 01DE 0413 02FF 02FD 02FE
2009	300 / Magnum / Charger (Pre-2011)	RADIO	●	●	●	●	●	●	●	025D 039E 039F 01BB 0301 03A0
2009	300 / Magnum / Charger (Pre-2011)	ITM	●	●	●	●	●	●	●	0104 0105 0107 0385 0106 0081
2009	300 / Magnum / Charger (Pre-2011)	HVAC	●	●	●	●	●	●	●	00EA 00E9 02EA 02EB 0081
2009	300 / Magnum / Charger (Pre-2011)	ESM	●	●	●	●	●	●	○	
2009	Compass	SAS	●	●	●	●	○	○	○	
2009	Compass	RADIO	●	●	●	●	●	●	●	039F 0301 039E 01BB 03A0 025D
2009	Compass	TCM	●	●	●	●	●	●	●	0081 01F5
2009	Compass	ABS	●	●	●	●	●	●	●	0002 0285 0062
2009	Compass	HFM	●	●	●	●	●	●	○	00E3
2009	Compass	ORC	●	●	●	●	●	○	●	0081 0122
2009	Compass	WCM	●	●	●	●	●	○	●	02A7 01D2 0228 0226 0225 0232 0230 0231 022F 0244 0081 0233 022D 023D 023E 0271 0270
2009	Compass	AWD	●	●	●	●	●	●	●	
2009	Compass	TIPMCGW	●	●	●	●	●	●	●	030D 030F 02F1 02F0 02F3 02EF 0039 030E 030C 003C 003D 0214 0032 0210 003F 003E 0036 0037 0035 0034 0038 003A 020E 0213 0215 028F 0211 038F 003B 02F4 0033 0390
2009	Compass	CCN	●	●	●	●	●	●	●	008C 008F 008E 0094 0092 0081 0096 0090
2009	Compass	ITM	●	●	●	●	●	●	●	0104 0105 0107 0385 0106 0081

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2009	Compass	PCM	●	●	●	●	●	●	●	02E7 0140 013E 0126 0141 0044 0128 012E 0314 012C 012D 013B 0173 012A 0081 012B 0042 0142 0310 03A3 0144 03A4 0313 0312 0311
2009	Compass	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069
2009	Dakota	EOM	●	●	●	●	●	○	●	00BA
2009	Dakota	CCN	●	●	●	●	●	●	●	008F 008E 008D 0090
2009	Dakota	WCM	●	●	●	●	●	○	●	01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0244 0081 0233 022D 023E 0271
2009	Dakota	HVAC	●	●	●	●	●	●	●	00EA 00E8 00E9 02EA 02EB 0081
2009	Dakota	RADIO	●	●	●	●	●	●	●	025D 039E 039F 01BB 0301 03A0
2009	Dakota	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069
2009	Dakota	FCMCGW	●	●	●	●	●	●	●	02F1 02F0 02F3 02EF 0039 003C 003D 02A6 02A5 02A4 0032 0257 003E 0036 00D5 00D8 0037 0035 0034 0038 00DB 00D6 00D9 003A 0293 003B 0302 0033 00C6 0040 00DA 0272 0273
2009	Dakota	HFM	●	●	●	●	●	●	○	00E3
2009	Dakota	ORC	●	●	●	●	●	○	●	02A1
2009	Dakota	PCM	●	●	●	●	●	●	●	027B 025F 025E 0260 027C 0262 0261 027D 0264 0263 02F8 0127 0140 0126 0044 026C 026D 0128 027E 0266 0265 0145 02FB 03B8 013C 012C 012D 0177 0173 012A 0281 0280 0176 024E 0170 016F 0081 012B 035B 0269 01FC 013B 02F9 0304 02FA
2009	Dakota	ABS	●	●	●	●	●	●	●	0002 0285 0062
2009	Raider	FCMCGW	●	●	●	●	●	●	●	02F1 02F0 02F3 02EF 0039 003C 003D 02A6 02A5 02A4 0032 0257 003E 0036 00D5 00D8 0037 0035 0034 0038 00DB 00D6 00D9 003A 0293 003B 0302 0033 00C6 0040 00DA 0272 0273
2009	Raider	RADIO	●	●	●	●	●	●	●	025D 039E 039F 01BB 0301 03A0
2009	Raider	ORC	●	●	●	●	●	○	●	02A1
2009	Raider	CCN	●	●	●	●	●	●	●	008F 008E 008D 0090
2009	Raider	HFM	●	●	●	●	●	●	○	00E3
2009	Raider	WCM	●	●	●	●	●	○	●	01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0244 0081 0233 022D 023E 0271
2009	Raider	HVAC	●	●	●	●	●	●	●	00EA 00E8 00E9 02EA 02EB 0081
2009	Raider	EOM	●	●	●	●	●	○	●	00BA
2009	Raider	ABS	●	●	●	●	●	●	●	0002 0285 0062
2009	Raider	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069
2009	Raider	PCM	●	●	●	●	●	●	●	027B 025F 025E 0260 027C 0262 0261 027D 0264 0263 02F8 0127 0140 0126 02F9 0044 026C 026D 0128 027E 0266 0265 0145 02FB 03B8 013C 012C 012D 0177 0304 0173 012A 0281 0280 02FA 0176 024E 0170 016F 0081 012B 035B 0269 01FC 013B
2009	Caliber	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2009	Caliber	WCM	●	●	●	●	●	○	●	02A7 01D2 0228 0226 0225 0232 0230 0231 022F 0244 0081 0233 022D 023D 023E 0271 0270
2009	Caliber	ABS	●	●	●	●	●	●	●	0002 0285 0062
2009	Caliber	RADIO	●	●	●	●	●	●	●	039F 0301 039E 01BB 03A0 025D
2009	Caliber	AWD	●	●	●	●	●	●	●	
2009	Caliber	PCM	●	●	●	●	●	●	●	02E7 0140 013E 0126 0141 0044 0128 012E 0314 012C 012D 013B 0173 012A 0081 012B 0042 0142 0310 03A3 0144 03A4 0313 0312 0311
2009	Caliber	EBG	●	●	●	●	●	○	○	
2009	Caliber	ORC	●	●	●	●	●	○	●	0081 0122
2009	Caliber	SAS	●	●	●	●	○	○	○	
2009	Caliber	TCM	●	●	●	●	●	●	●	0081 01F5
2009	Caliber	TIPMCGW	●	●	●	●	●	●	●	030D 030F 02F1 02F0 02F3 02EF 0039 030E 030C 003C 003D 0214 0032 0210 003F 003E 0036 0037 0035 0034 0038 003A 020E 0213 0215 028F 0211 038F 003B 02F4 0033 0390
2009	Caliber	CCN	●	●	●	●	●	●	●	008C 008F 008E 0094 0092 0081 0096 0090
2009	Caliber	ITM	●	●	●	●	●	●	●	0104 0105 0107 0385 0106 0081
2009	Caliber	HFM	●	●	●	●	●	●	○	00E3
2009	PT Cruiser	SDAR	●	●	●	●	●	○	○	0081
2009	PT Cruiser	CCN	●	●	●	●	●	●	●	008C 008F 008E 0094 0092 0081 0096 0090
2009	PT Cruiser	RADIO	●	●	●	●	●	○	●	01BB 0081
2009	PT Cruiser	ITM	●	●	●	●	●	●	●	0104 0105 0107 038E 0106 0081 0385
2009	PT Cruiser	ABS	●	●	●	●	●	●	●	0002 005E 0060 005B
2009	PT Cruiser	WCM	●	●	●	●	●	○	●	01D2 0228 0226 0225 0232 0230 0231 022F 0244 0081 0233 022D 023D 023E 0271 0270
2009	PT Cruiser	TIPMCGW	●	●	●	●	●	●	●	030D 0039 030E 030C 003C 003D 0214 0032 0210 003F 003E 0036 0037 0035 0034 0038 003A 020E 0213 0215 028F 0212 028E 0211 003B 02F4 0033
2009	PT Cruiser	HFM	●	●	●	●	●	●	○	00E3
2009	PT Cruiser	TCM	●	●	●	●	○	●	●	0167 0166 01EE 016A 0169 016C 016B 016E 016D 01F0 0172 0177 0170 016F 0175
2009	PT Cruiser	DDM	●	●	●	●	●	●	○	
2009	PT Cruiser	OCM	●	●	●	●	●	○	○	011E 0081
2009	PT Cruiser	ORC	●	●	●	●	●	○	●	0081 0122
2009	PT Cruiser	PDM	●	●	●	●	○	●	○	
2009	PT Cruiser	AMP	●	●	●	●	●	○	●	0289 028A 006D 006B 006C 0068 006A 0081 0069 0073
2009	PT Cruiser	PCM	●	●	●	●	●	●	●	0127 0126 0044 0129 026C 026D 0128 012E 012F 013C 012C 012D 013B 0173 012A 0081 012B 0042 0149 0142 0145 0148 0049
2009	Mini-Van	MHSM	●	●	●	●	○	●	○	
2009	Mini-Van	PCM	●	●	●	●	○	●	○	
2009	Mini-Van	PLGM	●	●	●	●	●	●	●	
2009	Mini-Van	PSD	●	●	●	●	○	●	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2009	Routan	PCM	●	●	●	●	●	●	●	027B 025F 025E 0260 027C 0262 0261 027D 0264 0263 02F8 0127 0140 0126 02F9 0044 026C 026D 0128 027E 0266 0265 0145 02FB 03B8 013C 012C 012D 0177 0304 0173 012A 0281 0280 02FA 0176 024E 0170 016F 0081 012B 035B 0269 01FC 013B
2009	Routan	VES3	●	●	●	●	●	●	●	
2009	Town & Country / Caravan	DMRL	●	●	●	●	●	●	●	00B4 00B5 00B6 0081
2009	Town & Country / Caravan	HIDT	●	●	●	●	●	●	○	02B8 0081
2009	Town & Country / Caravan	FSM	●	●	●	●	●	●	○	03AC 03AD 0346 0347
2009	Town & Country / Caravan	DMFL	●	●	●	●	●	●	●	
2009	Town & Country / Caravan	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 0039 030E 030C 008F 008E 0219 003D 0032 0036 0037 0035 0038 003A 002E 038F 003B 02F4 0033 0390 021D 022D
2009	Town & Country / Caravan	BSM	●	●	●	●	●	○	○	0372
2009	Town & Country / Caravan	HFM	●	●	●	●	●	●	○	00E3
2009	Town & Country / Caravan	TCM	●	●	●	●	●	●	○	027B 027C 027D 02F8 03B6 027E 03B5 01FC 0177 03B4 0081 0175
2009	Town & Country / Caravan	AHBM	●	●	●	●	●	○	○	0067 0066 0081
2009	Town & Country / Caravan	ORC	●	●	●	●	●	○	●	02A1 0122
2009	Town & Country / Caravan	SDARV	●	●	●	●	●	○	○	
2009	Town & Country / Caravan	HVAC	●	●	●	●	●	●	●	00EA 00E9 00EC 02EA 02EB 0081 0288 0287 03B9 03A9
2009	Town & Country / Caravan	VES3	●	●	●	●	●	●	●	
2009	Town & Country / Caravan	PSDMR	●	●	●	●	●	○	●	0343 0198 019B 0197 0342 0081
2009	Town & Country / Caravan	PTS	●	●	●	●	●	●	●	02ED 03B7
2009	Town & Country / Caravan	CCN	●	●	●	●	●	●	○	008C 00BC 0382 0091 0094 038D 0096 0383
2009	Town & Country / Caravan	SAS	●	●	●	●	○	○	○	
2009	Town & Country / Caravan	DMRR	●	●	●	●	●	●	●	00B4 00B5 0199 0081

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2009	Town & Country / Caravan	PLGM	●	●	●	●	●	●	●	038A 038B 00B4 0199 00B5 0342
2009	Town & Country / Caravan	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069
2009	Town & Country / Caravan	WCM	●	●	●	●	●	●	●	02A7 022E 01D2 0228 0225 0232 0230 0231 022F 01DE 0244 0081 0300 0233 01DA 0245 02FC 0414 03E4 03E6 0413 0341
2009	Town & Country / Caravan	VES2	●	●	●	●	●	●	●	03AE
2009	Town & Country / Caravan	DMFR	●	●	●	●	●	●	●	
2009	Town & Country / Caravan	PSDML	●	●	●	●	●	○	●	0343 0198 019B 0197 0342 0081
2009	Town & Country / Caravan	DVD	●	●	●	●	●	○	○	
2009	Town & Country / Caravan	ITM	●	●	●	●	●	●	●	0104 0105 0107 0385 0106 0081
2009	Town & Country / Caravan	ABS	●	●	●	●	●	●	●	0002 0285 0062 0081
2009	Town & Country / Caravan	PCM	●	●	●	●	●	●	●	#####
2009	Town & Country / Caravan	SUNR	●	●	●	●	●	●	○	
2009	Town & Country / Caravan	MSMD	●	●	●	●	●	○	○	02EE 00BC 0114 0116 0118 0117 0081 0115 0119
2009	Town & Country / Caravan	RADIO	●	●	●	●	●	●	●	025D 039E 039F 01BB 0301 03A0
2009	Sprinter	CCN	●	●	●	●	●	○	○	0007 0008 0005 0334 0006 0329 032F 0330 0331 0332 0333 004A 004C 0009 000A
2009	Sprinter	SCM	●	●	●	●	●	●	○	
2009	Sprinter	ABS	●	●	●	●	●	○	●	032D 0329 0002 0001 0003 004A 004C
2009	Sprinter	PTS	●	●	●	●	●	●	●	02D2 02D3
2009	Sprinter	TM	●	●	●	●	○	○	○	0019
2009	Sprinter	BCH	●	●	●	●	●	●	○	
2009	Sprinter	ECM	●	●	●	●	●	●	●	0042 0142 0127 0044 0337 0329 001E 0045 0046 004A 004C 0023 0043 0049 014D 026E 002E 026F 0336 0025 0024 0335 0022 0020 0021
2009	Sprinter	BCM	●	●	●	●	●	●	○	02E1
2009	Sprinter	AHLM	●	●	●	●	●	●	○	0329 029F 004A 004C
2009	Sprinter	PSM	●	●	●	●	●	●	○	0329 004A 0258 0339 0015
2009	Sprinter	PSDMR	●	●	●	●	○	●	○	0377 0376
2009	Sprinter	TPM	●	●	●	●	●	○	○	02D0 02D1 004A 001A 001B 001C 001D 0247 004E
2009	Sprinter	TCM	●	●	●	●	●	○	○	02D6 02D7 02D4 02D5 0329 004A 004C 0328 0018

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2009	Grand Cherokee	FCMCGW	●	●	●	●	●	●	●	02F1 02F0 02F3 02EF 0039 003C 003D 02A6 02A5 02A4 0032 0257 003E 0036 00D5 00D8 0037 0035 0034 0038 00DB 00D6 00D9 003A 002E 0293 0081 003B 0302 0033 00C6 0040 022D 00DA 0272 0273
2009	Commander	AHBM	●	●	●	●	●	○	○	0067 0066 0081
2009	Commander	TCM	●	●	●	●	●	○	○	01F4 0081 01F3 01F2
2009	Commander	HVAC	●	●	●	●	●	●	●	00EA 00E9 02EA 02EB 0081
2009	Commander	SUNR	●	●	●	●	●	●	○	
2009	Commander	TM	●	●	●	○	○	○	○	
2009	Commander	HSM	●	●	●	●	●	●	●	
2009	Commander	PCM	●	●	●	●	●	●	●	#####
2009	Commander	WCM	●	●	●	●	●	●	●	02A7 022E 01D2 0228 0225 0232 0230 0231 022F 01DE 0244 0081 0300 0233 01DA 0245 02FC 0414 03E4 03E6 0413
2009	Commander	PTS	●	●	●	●	●	●	●	02ED 03B7
2009	Commander	FCMCGW	●	●	●	●	●	●	●	02F1 02F0 02F3 02EF 0039 003C 003D 02A6 02A5 02A4 0032 0257 003E 0036 00D5 00D8 0037 0035 0034 0038 00DB 00D6 00D9 003A 002E 0293 0081 003B 0302 0033 00C6 0040 022D 00DA 0272 0273
2009	Commander	ABS	●	●	●	●	●	●	●	0002 0285 0062
2009	Commander	MSMD	●	●	●	●	●	○	○	02EE 00BC 0114 0116 0118 0117 0081 0115 0119
2009	Commander	DDM	●	●	●	●	●	●	●	0081 00AC
2009	Commander	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069
2009	Commander	SDARV	●	●	●	●	●	○	○	
2009	Commander	ORC	●	●	●	●	●	○	●	02A1 0122
2009	Commander	LRSM	●	●	●	●	●	○	○	010D 0081
2009	Commander	HFM	●	●	●	●	●	●	○	00E3
2009	Commander	VES3	●	●	●	●	●	●	●	
2009	Commander	ESM	●	●	●	●	●	●	○	
2009	Commander	RADIO	●	●	●	●	●	●	●	039F 0301 039E 01BB 03A0 025D
2009	Commander	SAS	●	●	●	●	○	○	○	
2009	Commander	FDCM	●	●	●	●	●	●	●	0081
2009	Commander	AHLM	●	●	●	●	●	●	○	029F 0081
2009	Commander	ITM	●	●	●	●	●	●	●	0104 0105 0107 0385 0106 0081
2009	Commander	PDM	●	●	●	●	●	●	●	0081 00AC
2009	Commander	PLGM	●	●	●	●	●	●	●	038A 038B 00B4 0199 00B5
2009	Commander	CCN	●	●	●	●	●	●	●	0097 008C 008F 008E 0091 0094 0081 0099 0098 0090
2009	Viper (Pre-2011)	OCM	●	●	●	●	●	○	○	02AD 0081
2009	Viper (Pre-2011)	PCM	●	●	●	●	●	●	○	013E 0126 0141 0044 0325 0193 0128 0145 0326 012C 012D 012A 0081 012B
2009	Viper (Pre-2011)	ABS	●	●	●	●	○	●	○	
2009	Viper (Pre-2011)	ORC	●	●	●	●	●	●	●	
2009	Viper (Pre-2011)	BCM	●	●	●	●	○	●	○	
2009	Viper (Pre-2011)	MIC/CCN	●	●	●	●	●	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2009	Viper (Pre-2011)	RADIO	●	●	●	○	○	●	○	
2009	Viper (Pre-2011)	PCI to CAN Gateway	●	●	●	●	○	○	○	
2009	Viper (Pre-2011)	SDAR	●	●	●	●	●	●	○	
2009	Viper (Pre-2011)	HVAC	●	●	●	●	○	●	○	
2010	Ram 3500 Pickup	VES3	●	●	●	●	●	●	●	
2010	Ram 3500 Pickup	ITBM	●	●	●	●	○	○	○	
2010	Ram 3500 Pickup	HVAC	●	●	●	●	●	●	●	00EA 00E9 00EC 03A9 02EB 0081 02E9
2010	Ram 3500 Pickup	PTS	●	●	●	●	●	●	●	02ED 03B7
2010	Ram 3500 Pickup	RADIO	●	●	●	●	●	●	●	039F 039E 01BB 03A0 025D 01BC 0081
2010	Ram 3500 Pickup	DMFL	●	●	●	●	●	●	●	
2010	Ram 3500 Pickup	ABS	●	●	●	●	●	●	●	0002 0285 0062
2010	Ram 3500 Pickup	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069
2010	Ram 3500 Pickup	DTCM	●	●	●	●	●	●	○	
2010	Ram 3500 Pickup	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 0039 008F 003D 0214 0032 003F 0036 0037 0035 0038 002E 0387 038F 003B 02F4 0033 0390 021D
2010	Ram 3500 Pickup	HSM	●	●	●	●	●	●	○	
2010	Ram 3500 Pickup	SAS	●	●	●	●	○	○	○	
2010	Ram 3500 Pickup	DMFR	●	●	●	●	●	●	●	
2010	Ram 3500 Pickup	ORC	●	●	●	●	●	○	●	02A1
2010	Ram 3500 Pickup	PCM	●	●	●	●	●	●	●	#####
2010	Ram 3500 Pickup	WCM	●	●	●	●	●	●	●	02A7 01D2 0228 02FF 0225 0081 0300 0245 02FC 02FD 02FE 0414 0233 03E4 03E6 0232 0230 0231 022F 01DE 0413
2010	Ram 3500 Pickup	MSMD	●	●	●	●	●	○	○	02EE 0081
2010	Ram 3500 Pickup	CCN	●	●	●	●	●	●	●	00BC 0094 03A5 038D 0091
2010	Ram 3500 Pickup	HFM	●	●	●	●	●	●	○	00E3
2010	Ram 3500 Pickup	SDARV	●	●	●	●	●	○	○	
2010	Ram 2500	FDCM	●	●	●	●	●	○	○	02B4 02B7 02B6 02B5 02B3 02B2 02B1 02AF 02B0
2010	Ram 2500	ORC	●	●	●	●	●	○	●	02A1
2010	Ram 2500	DMFR	●	●	●	●	●	●	●	
2010	Ram 2500	DMFL	●	●	●	●	●	●	●	
2010	Ram 2500	CCN	●	●	●	●	●	●	●	00BC 0094 03A5 038D 0091
2010	Ram 2500	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069
2010	Ram 2500	SAS	●	●	●	●	○	○	○	
2010	Ram 2500	HFM	●	●	●	●	●	●	○	00E3
2010	Ram 2500	PCM	●	●	●	●	●	●	●	#####
2010	Ram 2500	DTCM	●	●	●	●	●	●	○	
2010	Ram 2500	VES3	●	●	●	●	●	●	●	
2010	Ram 2500	ABS	●	●	●	●	●	●	●	0002 0285 0062
2010	Ram 2500	HSM	●	●	●	●	●	●	○	
2010	Ram 2500	TPM	●	●	●	●	●	○	●	0414 0232 0230 0231 022F 0413

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2010	Ram 2500	SDARV	●	●	●	●	●	○	○	
2010	Ram 2500	RADIO	●	●	●	●	●	●	●	039F 039E 01BB 03A0 025D 01BC 0081
2010	Ram 2500	HVAC	●	●	●	●	●	●	●	00EA 02E9 00EC 02EA 02EB 00E9 0081
2010	Ram 2500	MSMD	●	●	●	●	●	○	○	02EE 00BC 0114 0116 0118 0117 0081 0115 0119
2010	Ram 2500	PTS	●	●	●	●	●	●	●	02ED 03B7
2010	Ram 2500	ITBM	●	●	●	●	○	○	○	
2010	Ram 2500	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 0039 008F 008E 003D 0214 0032 003F 0036 0037 0035 0038 002E 0387 038F 003B 02F4 0033 0390 021D 022D
2010	Ram 2500	WCM	●	●	●	●	●	●	●	02A7 0414 0233 01D2 03E4 0228 03E6 0232 0230 0231 022F 01DE 0413 0300 0245 02FF 0225 0081 02FC 02FD 02FE
2010	Dodge Ram	ABS	●	●	●	●	●	●	●	0002 0285 0062 0081
2010	Dodge Ram	SDAR	●	●	●	●	●	○	○	0081
2010	Dodge Ram	RADIO	●	●	●	●	●	○	●	01BB 0081
2010	Dodge Ram	CCN	●	●	●	●	●	●	●	008C 008F 008E 02D9 02DB 02E0 03A5 0081 0090
2010	Dodge Ram	TIPMCGW	●	●	●	●	●	●	●	033E 030D 030F 02F1 02F0 02F3 02EF 0039 030E 030C 003C 003D 0214 0032 0210 003F 003E 0036 0037 0035 0034 0038 003A 020E 0213 0215 028F 0211 0387 038F 003B 02F4 0033 0390
2010	Dodge Ram	SUNR	●	●	●	●	●	●	○	
2010	Dodge Ram	TCM	●	●	●	●	●	●	○	027B 0167 0166 01EE 027C 016A 0169 027D 0291 016C 016B 02F8 0290 027E 016E 016D 0392 0393 0394 0395 0177 0176 024E 01FB 016F 0396 035B 0175 01FC 01F6 0391
2010	Dodge Ram	EOM	●	●	●	●	●	●	●	00BA 0081
2010	Dodge Ram	WCM	●	●	●	●	●	○	●	01D2 0228 0226 0225 0232 0230 0231 022F 0244 0081 0233 033F 023D 023E 0271 0270
2010	Dodge Ram	HFM	●	●	●	●	●	●	○	00E3
2010	Dodge Ram	PCM	●	●	●	●	●	●	●	#####
2010	Dodge Ram	VES	●	●	●	●	●	●	○	
2010	Dodge Ram	FDCM	●	●	●	●	●	○	○	02B4 02B7 02B6 02B5 02B3 02B2 02B1 02AF 02B0
2010	Dodge Ram	SAS	●	●	●	●	○	○	○	
2010	Dodge Ram	ORC	●	●	●	●	●	○	●	0081 0122
2010	Dodge Ram	HVAC	●	●	●	●	●	●	●	00EA 00E8 00E9 02EA 02EB 0081 00EB
2010	Dodge Ram	AMP	●	●	●	●	●	○	●	028A 028D 006D 006C 027F 0068 006A 0081
2010	Ram 1500	ITBM	●	●	●	●	○	○	○	
2010	Ram 1500	CCN	●	●	●	●	●	●	●	00BC 0094 03A5 038D 0091
2010	Ram 1500	HFM	●	●	●	●	●	●	○	00E3

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2010	Ram 1500	PCM	●	●	●	●	●	●	●	027B 025F 025E 0260 027C 0262 0261 027D 0264 0263 02F8 0127 0140 0126 02F9 0044 026C 026D 0128 027E 0266 0265 0145 02FB 03B8 013C 012C 012D 0177 0304 0173 012A 0281 0280 02FA 0176 024E 0170 016F 012B 035B 0269 01FC 013B
2010	Ram 1500	HSM	●	●	●	●	●	●	○	
2010	Ram 1500	SDARV	●	●	●	●	●	○	○	
2010	Ram 1500	ORC	●	●	●	●	●	○	●	02A1
2010	Ram 1500	VES3	●	●	●	●	●	●	●	
2010	Ram 1500	SAS	●	●	●	●	○	○	○	
2010	Ram 1500	PTS	●	●	●	●	●	●	●	02ED 03B7
2010	Ram 1500	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 0039 008F 008E 003D 0214 0032 003F 0036 0037 0035 0038 002E 0387 038F 003B 02F4 0033 0390 021D 022D
2010	Ram 1500	ABS	●	●	●	●	●	●	●	0002 0285 0062
2010	Ram 1500	MSMD	●	●	●	●	●	○	○	02EE 00BC 0114 0116 0118 0117 0081 0115 0119
2010	Ram 1500	WCM	●	●	●	●	●	●	●	02A7 01D2 0228 02FF 0225 0232 0230 0231 022F 01DE 0244 0081 0300 01DA 0245 02FC 02FD 02FE 0414 0233 03E4 03E6 0413
2010	Ram 1500	DMFL	●	●	●	●	●	●	●	
2010	Ram 1500	DTCM	●	●	●	●	●	●	○	
2010	Ram 1500	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069
2010	Ram 1500	RADIO	●	●	●	●	●	●	●	039F 039E 01BB 03A0 025D 01BC 0081
2010	Ram 1500	HVAC	●	●	●	●	●	●	●	00EA 02E9 00EC 03A9 02EB 00E9 0081
2010	Ram 1500	TPM	●	●	●	●	●	○	●	0414 0232 0230 0231 022F 0413
2010	Ram 1500	DMFR	●	●	●	●	●	●	●	
2010	Ram (Mexico)	HFM	●	●	●	●	●	●	○	00E3
2010	Ram (Mexico)	ABS	●	●	●	●	●	●	●	0002 0285 0062
2010	Ram (Mexico)	WCM	●	●	●	●	●	●	●	02A7 0414 0233 01D2 03E4 0228 03E6 0232 0230 0231 022F 01DE 0413 0300 0245 02FF 0225 0244 0081 01DA 02FC 02FD 02FE
2010	Ram (Mexico)	MSMD	●	●	●	●	●	○	○	02EE 00BC 0114 0116 0118 0117 0081 0115 0119
2010	Ram (Mexico)	PCM	●	●	●	●	●	●	●	#####
2010	Ram (Mexico)	TPM	●	●	●	●	●	○	●	0414 0232 0230 0231 022F 0413
2010	Ram (Mexico)	DMFL	●	●	●	●	●	●	●	
2010	Ram (Mexico)	HVAC	●	●	●	●	●	●	●	00EA 02E9 00EC 02EA 02EB 00E9 0081
2010	Ram (Mexico)	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 0039 008F 008E 003D 0214 0032 003F 0036 0037 0035 0038 002E 0387 038F 003B 02F4 0033 0390 021D 022D
2010	Ram (Mexico)	DMFR	●	●	●	●	●	●	●	
2010	Ram (Mexico)	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069
2010	Ram (Mexico)	ORC	●	●	●	●	●	○	●	02A1
2010	Ram (Mexico)	SAS	●	●	●	●	○	○	○	
2010	Ram (Mexico)	SDARV	●	●	●	●	●	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2010	Ram (Mexico)	HSM	●	●	●	●	●	●	○	
2010	Ram (Mexico)	PTS	●	●	●	●	●	●	●	02ED 03B7
2010	Ram (Mexico)	ITBM	●	●	●	●	○	○	○	
2010	Ram (Mexico)	DTCM	●	●	●	●	●	●	○	
2010	Ram (Mexico)	VES3	●	●	●	●	●	●	●	
2010	Ram (Mexico)	CCN	●	●	●	●	●	●	●	00BC 0094 038D 0091
2010	Ram (Mexico)	RADIO	●	●	●	●	●	●	●	025D 039E 039F 01BB 01BC 0081 03A0
2010	Wrangler (Export)	TCM	●	●	●	●	●	●	○	0392 0393 0394 0395 0176 024E 01FB 016F 0396 035B 01FC
2010	Wrangler (Export)	ORC	●	●	●	●	●	○	●	0081 0122 03CC 02A1 03CD
2010	Wrangler (Export)	RADIO	●	●	●	●	●	●	●	039F 039E 01BB 03A0 025D 01BC 0081
2010	Wrangler (Export)	PCM	●	●	●	●	●	●	○	0145 012D 0042 0149 0142 02BA 02B9 02BF 02BD 02BE 02BC 014A 0148 0044 0049 0144 02C0 02BB 031D 02C1 013B 02C2
2010	Wrangler (Export)	CCN	●	●	●	●	●	●	○	008C 00BC 0382 0091 0094 038D 0096 0383
2010	Wrangler (Export)	SAS	●	●	●	●	○	○	○	
2010	Wrangler (Export)	WCM	●	●	●	●	●	○	●	0233 01D2 03E4 0341 0228 04A2 0232 0230 0231 022F 01DE 0413 022D 0227
2010	Wrangler (Export)	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 0039 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0035 0038 003A 021E 021F 038F 003B 02F4 0033 0390 021D
2010	Wrangler (Export)	ABS	●	●	●	●	●	●	●	0002 0285 0062 0081
2010	Journey	WCM	●	●	●	●	●	●	●	02A7 022E 01D2 0228 0225 0232 0230 0231 022F 01DE 0244 0081 0300 0233 01DA 0245 02FC 02FF 02FD 02FE 0414 03E4 03E6 0413
2010	Journey	HFM	●	●	●	●	●	●	○	00E3
2010	Journey	CCN	●	●	●	●	○	●	●	008C 0091 02D9 02DB 0094 02E0 03A5 037F 037E 0081 0096
2010	Journey	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 0039 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0035 0038 003A 02E3 021E 021F 038F 003B 02F4 0033 0390 021D 022D
2010	Journey	SAS	●	●	●	●	○	○	○	
2010	Journey	DISP	●	●	●	●	●	○	○	
2010	Journey	DMFL	●	●	●	●	●	●	●	
2010	Journey	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069
2010	Journey	SDARV	●	●	●	●	●	○	○	
2010	Journey	ORC	●	●	●	●	●	○	●	03CC 02A1 0122
2010	Journey	TCM	●	●	●	●	●	●	●	0167 0166 01EE 016A 0169 016C 016B 016E 016D 01F0 0172 0177 0170 016F 0175 0391
2010	Journey	VES3	●	●	●	●	●	●	●	
2010	Journey	HVAC	●	●	●	●	●	●	●	00EA 03B9 03A9 02EB 00E9 00EC 02EA 0081 0288 0287
2010	Journey	RADIO	●	●	●	●	●	●	●	025D 039E 039F 01BB 03A0 01BC 0081
2010	Journey	AWD	●	●	●	●	●	○	●	
2010	Journey	ITM	●	●	●	●	●	●	●	03CF 0107 0385 0081 03CE

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2010	Sebring / 200 / Avenger	PTCM	●	●	●	●	●	○	●	0371 025B 0259 026A 0081 025A
2010	Sebring / 200 / Avenger	ABS	●	●	●	●	●	●	●	0002 0285 0062 03AB 0081
2010	Sebring / 200 / Avenger	HFM	●	●	●	●	●	●	○	00E3
2010	Sebring / 200 / Avenger	ITM	●	●	●	●	●	●	●	0385 0106 0081 03CF 0107 03CE
2010	Sebring / 200 / Avenger	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069
2010	Sebring / 200 / Avenger	TIPMCGW	●	●	●	●	●	●	●	030D 030F 02F1 02F0 02F3 02EF 0039 030E 030C 003C 003D 0214 0032 0210 003F 003E 0036 02C3 0037 0035 0034 0038 003A 020E 0213 0215 028F 0211 038F 003B 02F4 0033 0390
2010	Sebring / 200 / Avenger	ORC	●	●	●	●	●	○	●	03CC
2010	Sebring / 200 / Avenger	WCM	●	●	●	●	●	○	●	02A7 022E 01D2 0228 0226 0225 0232 0230 0231 022F 0244 0081 0233 022D 023D 023E 0271 0270
2010	Nitro	HVAC	●	●	●	●	●	●	●	0288 0287 00E9 00EC 02EA 02EB 02E9 00EA 0081 03B9 03A9
2010	Nitro	ITM	●	●	●	●	●	●	●	03CF 0107 0385 0081 03CE
2010	Nitro	ORC	●	●	●	●	●	○	●	03CC 03CD
2010	Nitro	ESM	●	●	●	●	●	●	○	
2010	Nitro	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069
2010	Nitro	HFM	●	●	●	●	●	●	○	00E3
2010	Nitro	PTS	●	●	●	●	●	●	●	02ED 03B7
2010	Nitro	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 0039 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0035 0038 003A 021E 021F 02E2 038F 003B 02F4 0033 0390 021D
2010	Nitro	PCM	●	●	●	●	●	●	●	#####
2010	Nitro	RADIO	●	●	●	●	●	●	●	025D 039E 039F 01BB 01BC 0081 03A0
2010	Nitro	ABS	●	●	●	●	●	●	●	0002 0285 0062 0081
2010	Nitro	DMFR	●	●	●	●	●	●	●	
2010	Nitro	SAS	●	●	●	●	○	○	○	
2010	Nitro	OCM	●	●	●	●	●	○	○	011E
2010	Nitro	WCM	●	●	●	●	●	○	●	01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0244 0081 0233 022D 0227 0274 031E 031F
2010	Nitro	DMFL	●	●	●	●	●	●	●	
2010	Nitro	TCM	●	●	●	●	●	○	○	038C 01F3 01F2
2010	Nitro	CCN	●	●	●	●	●	●	○	008C 00BC 0382 0091 0094 038D 0096 0383
2010	Liberty	ABS	●	●	●	●	●	●	●	0002 0285 0062
2010	Liberty	ESM	●	●	●	●	●	●	○	
2010	Liberty	HVAC	●	●	●	●	●	●	●	00EA 03B9 03A9 0288 0287 00E9 00EC 02EA 02EB

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2010	300 / Magnum / Charger (Pre-2011)	PCM	●	●	●	●	●	●	●	#####
2010	300 / Magnum / Charger (Pre-2011)	HVAC	●	●	●	●	●	●	●	00EA 00E9 02EA 02EB 0081
2010	300 / Magnum / Charger (Pre-2011)	AHBM	●	●	●	●	●	○	○	0067 0066
2010	300 / Magnum / Charger (Pre-2011)	LRSM	●	●	●	●	●	○	○	010D 0081
2010	300 / Magnum / Charger (Pre-2011)	SDARV	●	●	●	●	●	○	○	
2010	300 / Magnum / Charger (Pre-2011)	PEM	●	●	●	●	●	○	●	0309 0370 0308 0307 0081
2010	300 / Magnum / Charger (Pre-2011)	HSM	●	●	●	●	●	●	●	
2010	300 / Magnum / Charger (Pre-2011)	HFM	●	●	●	●	●	●	○	00E3
2010	300 / Magnum / Charger (Pre-2011)	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069
2010	300 / Magnum / Charger (Pre-2011)	TCM	●	●	●	●	●	○	○	038C 01F3 01F2
2010	300 / Magnum / Charger (Pre-2011)	ABS	●	●	●	●	●	●	●	0002 0285 0062
2010	300 / Magnum / Charger (Pre-2011)	WCM	●	●	●	●	●	●	●	02A7 0414 0233 022E 01D2 03E4 0228 03E6 0232 0230 0231 022F 01DE 0413 0300 0245 02FF 0225 0244 0081 01DA 02FC 02FD 02FE
2010	300 / Magnum / Charger (Pre-2011)	ORC	●	●	●	●	○	●	○	02A1
2010	Compass	PCM	●	●	●	●	●	●	●	02E7 0140 013E 0126 0141 0044 0128 012E 0314 012C 012D 013B 0173 012A 012B 03E0 0149 03DD 03E3 03E2 03DE 03E1 03D3 03D0 03DF 03D9 03D1 03DA 0049 03DB 03D4 03DC 03D2 03D6 03D8 03D7 03D5
2010	Compass	AWD	●	●	●	●	●	●	●	
2010	Compass	CCN	●	●	●	●	●	●	○	008C 008F 008E 0094 0092 0081 0096 0090
2010	Compass	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069 0303 0081
2010	Compass	RADIO	●	●	●	●	●	●	●	025D 039E 039F 01BB 01BC 0081 03A0
2010	Compass	ITM	●	●	●	●	●	●	●	03CF 0107 0385 0106 0081 03CE
2010	Compass	ABS	●	●	●	●	●	●	●	0002 0285 0062
2010	Compass	ORC	●	●	●	●	●	○	●	03CC 03CD
2010	Compass	SAS	●	●	●	●	○	○	○	
2010	Compass	TIPMCGW	●	●	●	●	●	●	●	030D 030F 02F1 02F0 02F3 02EF 0039 030E 030C 003C 003D 0214 0032 0210 003F 003E 0036 0037 0035 0034 0038 003A 020E 0213 0215 028F 0211 038F 003B 02F4 0033 0390

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2010	Compass	HFM	●	●	●	●	●	●	○	00E3
2010	Compass	HVAC	●	●	●	●	●	●	●	00EA 03B9 03A9 02EB 02E9 02EA 0081
2010	Compass	TCM	●	●	●	●	●	●	●	01F5
2010	Compass	WCM	●	●	●	●	●	○	●	02A7 01D2 0228 0226 0225 0232 0230 0231 022F 0244 0081 0233 022D 0274 031E 031F 037C
2010	Dakota	PCM	●	●	●	●	●	●	●	027B 025F 025E 0260 027C 0262 0261 027D 0264 0263 02F8 0127 0140 0126 02F9 0044 026C 026D 0128 027E 0266 0265 0145 02FB 03B8 013C 012C 012D 0177 0304 0173 012A 0281 0280 02FA 0176 024E 0170 016F 012B 035B 0269 01FC 013B
2010	Dakota	FCMCGW	●	●	●	●	●	●	●	02F1 02F0 02F3 02EF 0039 003C 003D 02A6 02A5 02A4 0032 0257 003E 0036 00D5 00D8 0037 0035 0034 0038 00DB 00D6 00D9 003A 0293 003B 0302 0033 00C6 0040 00DA 0272 0273
2010	Dakota	WCM	●	●	●	●	●	○	●	01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0244 0081 0233 022D 023E 0271
2010	Dakota	ABS	●	●	●	●	●	●	●	0002 0285 0062
2010	Dakota	ORC	●	●	●	●	○	●	○	02A1
2010	Dakota	RADIO	●	●	●	●	●	●	●	025D 039E 039F 01BB 03A0 01BC 0081
2010	Dakota	EOM	●	●	●	●	●	○	●	00BA
2010	Dakota	HFM	●	●	●	●	●	●	○	00E3
2010	Dakota	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069
2010	Dakota	HVAC	●	●	●	●	●	●	●	00EA 00E8 00E9 02EA 02EB 0081
2010	Dakota	CCN	●	●	●	●	●	●	●	008F 008E 008D 0090
2010	Raider	RADIO	●	●	●	●	●	●	●	025D 039E 039F 01BB 01BC 0081 03A0
2010	Raider	WCM	●	●	●	●	●	○	●	01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0244 0081 0233 022D 023E 0271
2010	Raider	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069
2010	Raider	ABS	●	●	●	●	●	●	●	0002 0285 0062
2010	Raider	HFM	●	●	●	●	●	●	○	00E3
2010	Raider	ORC	●	●	●	●	○	●	○	02A1
2010	Raider	HVAC	●	●	●	●	●	●	●	00EA 00E8 00E9 02EA 02EB 0081
2010	Raider	CCN	●	●	●	●	●	●	●	008F 008E 008D 0090
2010	Raider	FCMCGW	●	●	●	●	●	●	●	02F1 02F0 02F3 02EF 0039 003C 003D 02A6 02A5 02A4 0032 0257 003E 0036 00D5 00D8 0037 0035 0034 0038 00DB 00D6 00D9 003A 0293 003B 0302 0033 00C6 0040 00DA 0272 0273
2010	Raider	EOM	●	●	●	●	●	○	●	00BA
2010	Raider	PCM	●	●	●	●	●	●	●	027B 025F 025E 0260 027C 0262 0261 027D 0264 0263 02F8 0127 0140 0126 02F9 0044 026C 026D 0128 027E 0266 0265 0145 02FB 03B8 013C 012C 0177 0304 0173 012A 0281 0280 02FA 0176 024E 0170 016F 012B 035B 0269 01FC 013B

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2010	Mini-Van	HFM	●	●	●	●	○	●	○	
2010	Mini-Van	DSD	●	●	●	●	○	●	○	
2010	Mini-Van	SKREEM	●	●	●	●	●	○	○	
2010	Mini-Van	PTS	●	●	●	●	●	●	○	
2010	Mini-Van	OCM	●	●	●	●	○	○	○	
2010	Mini-Van	SDAR	●	●	●	●	●	●	○	
2010	Mini-Van	MIC/CCN	●	●	●	●	○	●	○	
2010	Mini-Van	PCM	●	●	●	●	○	●	○	
2010	Mini-Van	BCM	●	●	●	●	○	●	○	
2010	Mini-Van	TCM	●	●	●	●	●	●	●	
2010	Mini-Van	IPM	●	●	●	●	○	●	○	
2010	Mini-Van	MHSM	●	●	●	●	○	●	○	
2010	Mini-Van	EOM	●	●	●	○	○	○	○	
2010	Mini-Van	MTC	●	●	●	●	○	●	○	
2010	Mini-Van	PSD	●	●	●	●	○	●	○	
2010	Mini-Van	ORC	●	●	●	●	○	○	○	
2010	Mini-Van	ABS	●	●	●	●	●	○	○	
2010	Mini-Van	PLGM	●	●	●	●	●	●	●	
2010	Mini-Van	ATC	●	●	●	●	○	●	○	
2010	Routan	VES2	●	●	●	●	●	●	●	03AE
2010	Routan	RADIO	●	●	●	●	●	●	●	01BB 025D 01BC 0081 039F 039E 03A0
2010	Routan	DMFR	●	●	●	●	●	●	●	
2010	Routan	PSDML	●	●	●	●	●	○	●	0343 0198 019B 0197 0342 0081
2010	Routan	HVAC	●	●	●	●	●	●	●	02E9 00EA 02EA 02EB 0081 0288 0287 00E9 00EC
2010	Routan	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 0039 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0035 0038 003A 002E 021E 021F 038F 02F4 0033 0390 021D 022D
2010	Routan	DMRL	●	●	●	●	●	●	●	00B4 00B5 00B6 0081
2010	Routan	ORC	●	●	●	●	●	○	●	03CC 02A1 0122
2010	Routan	SUNR	●	●	●	●	●	●	○	
2010	Routan	HFM	●	●	●	●	●	●	○	00E3
2010	Routan	CCN	●	●	●	●	●	●	○	008C 00BC 0382 0091 0094 038D 0096 0383
2010	Routan	WCM	●	●	●	●	●	●	●	02A7 0414 0233 022E 01D2 03E4 0228 03E6 0232 0230 0231 022F 01DE 0413 0300 0245 0341 02FF 0225 0244 0081 01DA 02FC 02FD 02FE
2010	Routan	PCM	●	●	●	●	●	●	●	027B 025F 025E 0260 027C 0262 0261 027D 0264 0263 02F8 0127 0140 0126 02F9 0044 026C 026D 0128 027E 0266 0265 0145 02FB 03B8 013C 012C 012D 0177 0304 0173 012A 0281 0280 02FA 0176 024E 0170 016F 012B 035B 0269 01FC 013B
2010	Routan	FSM	●	●	●	●	●	●	○	03AC 03AD 0346 0347
2010	Routan	DMFL	●	●	●	●	●	●	●	
2010	Routan	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069
2010	Routan	DVD	●	●	●	●	●	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2010	Routan	PLGM	●	●	●	●	●	●	●	0342
2010	Routan	ABS	●	●	●	●	●	●	●	0002 0285 0062
2010	Routan	PTS	●	●	●	●	●	●	●	02ED 03B7
2010	Routan	DMRR	●	●	●	●	●	●	●	00B4 00B5 0199 0081
2010	Routan	VES3	●	●	●	●	●	●	●	
2010	Routan	PSDMR	●	●	●	●	●	○	●	0343 0198 019B 0197 0342 0081
2010	Routan	SAS	●	●	●	●	○	○	○	
2010	Routan	MSMD	●	●	●	●	●	○	○	02EE 00BC 0114 0116 0118 0117 0081 0115 0119
2010	Town & Country / Caravan	PCM	●	●	●	●	●	●	●	#####
2010	Town & Country / Caravan	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 0039 030E 030C 008F 008E 0219 003D 0032 0036 0037 0035 0038 003A 002E 038F 003B 02F4 0033 0390 021D 022D
2010	Town & Country / Caravan	RADIO	●	●	●	●	●	●	●	039F 039E 01BB 03A0 025D 01BC 0081
2010	Town & Country / Caravan	AHBM	●	●	●	●	●	○	○	0067 0066
2010	Town & Country / Caravan	PSDMR	●	●	●	●	●	○	●	0343 0198 019B 0197 0342 0081
2010	Town & Country / Caravan	DMFL	●	●	●	●	●	●	●	
2010	Town & Country / Caravan	HIDT	●	●	●	●	●	●	○	02B8
2010	Town & Country / Caravan	HVAC	●	●	●	●	●	●	●	0288 0287 00E9 00EC 02EA 02EB 00EA 0081 03B9
2010	Town & Country / Caravan	ABS	●	●	●	●	●	●	●	0002 0285 0062 0081
2010	Town & Country / Caravan	ITM	●	●	●	●	●	●	●	03CF 0107 0385 0081 03CE
2010	Town & Country / Caravan	VES2	●	●	●	●	●	●	●	03AE
2010	Town & Country / Caravan	FSM	●	●	●	●	●	●	○	03AC 03AD 0346 0347
2010	Town & Country / Caravan	DMRR	●	●	●	●	●	●	●	00B4 00B5 0199 0081
2010	Town & Country / Caravan	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069
2010	Town & Country / Caravan	CCN	●	●	●	●	●	●	○	008C 00BC 0382 0091 0094 038D 0096 0383
2010	Town & Country / Caravan	DMFR	●	●	●	●	●	●	●	
2010	Town & Country / Caravan	BSM	●	●	●	●	●	○	○	0372

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2010	Town & Country / Caravan	SDARV	●	●	●	●	●	○	○	
2010	Town & Country / Caravan	ORC	●	●	●	●	●	○	●	03CC 02A1 0122
2010	Town & Country / Caravan	DMRL	●	●	●	●	●	●	●	00B4 00B5 00B6 0081
2010	Town & Country / Caravan	HFM	●	●	●	●	●	●	○	00E3
2010	Town & Country / Caravan	DVD	●	●	●	●	●	○	○	
2010	Town & Country / Caravan	PLGM	●	●	●	●	●	●	●	038A 038B 00B4 0199 00B5 0342
2010	Town & Country / Caravan	SAS	●	●	●	●	○	○	○	
2010	Town & Country / Caravan	MSMD	●	●	●	●	●	○	○	02EE 00BC 0114 0116 0118 0117 0081 0115 0119
2010	Town & Country / Caravan	TCM	●	●	●	●	●	●	○	027B 027C 027D 02F8 03B6 027E 03B5 01FC 0177 03B4 0175
2010	Town & Country / Caravan	VES3	●	●	●	●	●	●	●	
2010	Town & Country / Caravan	WCM	●	●	●	●	●	●	●	02A7 0414 0233 022E 01D2 03E4 0228 03E6 0232 0230 0231 022F 01DE 0413 0300 0245 02FF 0225 0244 0081 01DA 02FC 02FD 02FE
2010	Town & Country / Caravan	SUNR	●	●	●	●	●	●	○	
2010	Town & Country / Caravan	PSDML	●	●	●	●	●	○	●	0343 0198 019B 0197 0342 0081
2010	Town & Country / Caravan	PTS	●	●	●	●	●	●	●	02ED 03B7
2010	Grand Cherokee	TM	●	●	●	○	○	○	○	
2010	Grand Cherokee	LRSM	●	●	●	●	●	○	○	010D 0081
2010	Grand Cherokee	PTS	●	●	●	●	●	●	●	02ED 03B7
2010	Grand Cherokee	ESM	●	●	●	●	●	●	○	
2010	Grand Cherokee	ABS	●	●	●	●	●	●	●	0002 0285 0062
2010	Grand Cherokee	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069
2010	Grand Cherokee	PDM	●	●	●	●	●	●	●	00AC 0081
2010	Grand Cherokee	MSMD	●	●	●	●	●	○	○	02EE 00BC 0114 0116 0118 0117 0081 0115 0119
2010	Grand Cherokee	HVAC	●	●	●	●	●	●	●	00EA 00E9 02EA 02EB 0081
2010	Grand Cherokee	SUNR	●	●	●	●	●	●	○	
2010	Grand Cherokee	SAS	●	●	●	●	○	○	○	
2010	Grand Cherokee	HFM	●	●	●	●	●	●	○	00E3
2010	Grand Cherokee	EOM	●	●	●	●	●	○	●	00BA 0081
2010	Grand Cherokee	TCM	●	●	●	●	●	○	○	038C 01F3 01F2

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2010	Grand Cherokee	DDM	●	●	●	●	●	●	●	0081 00AC
2010	Grand Cherokee	VES3	●	●	●	●	●	●	●	
2010	Grand Cherokee	HSM	●	●	●	●	●	●	●	
2010	Grand Cherokee	SDARV	●	●	●	●	●	○	○	
2010	Grand Cherokee	AHBM	●	●	●	●	●	○	○	0067 0066
2010	Grand Cherokee	CCN	●	●	●	●	●	●	●	0097 008C 008F 008E 0091 0094 0081 0099 0098 0090
2010	Grand Cherokee	ORC	●	●	●	●	○	●	○	02A1 0122
2010	Grand Cherokee	AHLM	●	●	●	●	●	●	○	029F
2010	Grand Cherokee	WCM	●	●	●	●	●	●	●	02A7 0414 0233 022E 01D2 03E4 0228 03E6 0232 0230 0231 022F 01DE 0413 0300 0245 02FF 0225 0244 0081 01DA 02FC 02FD 02FE
2010	Grand Cherokee	FCMCGW	●	●	●	●	●	●	●	02F1 02F0 02F3 02EF 0039 003C 003D 02A6 02A5 02A4 0032 0257 003E 0036 00D5 00D8 0037 0035 0034 0038 00DB 00D6 00D9 003A 002E 0293 0081 003B 0302 0033 00C6 0040 022D 00DA 0272 0273
2010	Grand Cherokee	RADIO	●	●	●	●	●	●	●	01BB 025D 01BC 0081 039F 039E 03A0
2010	Grand Cherokee	ITM	●	●	●	●	●	●	●	03CF 0107 0385 0106 0081 03CE
2010	Grand Cherokee	FDCM	●	●	●	●	●	●	●	00E0 00DF 0081
2010	Grand Cherokee	PCM	●	●	●	●	●	●	●	#####
2010	Commander	HSM	●	●	●	●	●	●	●	
2010	Commander	TCM	●	●	●	●	●	○	○	038C 01F3 01F2
2010	Commander	AHLM	●	●	●	●	●	●	○	029F
2010	Commander	DDM	●	●	●	●	●	●	●	0081 00AC
2010	Commander	HVAC	●	●	●	●	●	●	●	00EA 00E9 02EA 02EB 0081
2010	Commander	CCN	●	●	●	●	●	●	●	0097 008C 008F 008E 0091 0094 0081 0099 0098 0090
2010	Commander	FCMCGW	●	●	●	●	●	●	●	02F1 02F0 02F3 02EF 0039 003C 003D 02A6 02A5 02A4 0032 0257 003E 0036 00D5 00D8 0037 0035 0034 0038 00DB 00D6 00D9 003A 002E 0293 0081 003B 0302 0033 00C6 0040 022D 00DA 0272 0273
2010	Commander	ABS	●	●	●	●	●	●	●	0002 0285 0062
2010	Commander	PCM	●	●	●	●	●	●	●	#####
2010	Commander	PLGM	●	●	●	●	●	●	●	038A 038B 00B4 0199 00B5
2010	Commander	SDARV	●	●	●	●	●	○	○	
2010	Commander	VES3	●	●	●	●	●	●	●	
2010	Commander	ESM	●	●	●	●	●	●	○	
2010	Commander	SAS	●	●	●	●	○	○	○	
2010	Commander	ITM	●	●	●	●	●	●	●	03CF 0107 0385 0106 0081 03CE
2010	Commander	ORC	●	●	●	●	○	●	○	02A1 0122
2010	Commander	LRSM	●	●	●	●	●	○	○	010D 0081
2010	Commander	WCM	●	●	●	●	●	●	●	02A7 022E 01D2 0228 0225 0232 0230 0231 022F 01DE 0244 0081 0300 0233 01DA 0245 02FC 02FF 02FD 02FE 0414 03E4 03E6 0413
2010	Commander	PDM	●	●	●	●	●	●	●	0081 00AC
2010	Commander	RADIO	●	●	●	●	●	●	●	025D 039E 039F 01BB 03A0 01BC 0081

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2010	Commander	FDCM	●	●	●	●	●	●	●	00E0 00DF 0081
2010	Commander	MSMD	●	●	●	●	●	○	○	02EE 00BC 0114 0116 0118 0117 0081 0115 0119
2010	Commander	PTS	●	●	●	●	●	●	●	02ED 03B7
2010	Commander	TM	●	●	●	○	○	○	○	
2010	Commander	HFM	●	●	●	●	●	●	○	00E3
2010	Commander	AHBM	●	●	●	●	●	○	○	0067 0066
2010	Commander	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 0069
2010	Commander	SUNR	●	●	●	●	●	●	○	
2010	Viper (Pre-2011)	PCM	●	●	●	●	●	●	○	013E 0126 0141 0044 0325 0193 0128 0145 0326 012C 012D 012A 0081 012B
2010	Viper (Pre-2011)	OCM	●	●	●	●	●	○	○	02AD
2010	Viper (Pre-2011)	HVAC	●	●	●	●	○	●	○	
2010	Viper (Pre-2011)	MIC/CCN	●	●	●	●	●	○	○	
2010	Viper (Pre-2011)	RADIO	●	●	●	○	○	●	○	
2010	Viper (Pre-2011)	PCI to CAN Gateway	●	●	●	●	○	○	○	
2010	Viper (Pre-2011)	BCM	●	●	●	●	○	●	○	
2010	Viper (Pre-2011)	SDAR	●	●	●	●	●	●	○	
2010	Viper (Pre-2011)	ABS	●	●	●	●	○	●	○	
2010	Viper (Pre-2011)	ORC	●	●	●	●	●	●	●	
2011	Ram 3500 Pickup	SDARV	●	●	●	●	●	○	○	
2011	Ram 3500 Pickup	DTCM	●	●	●	●	●	●	○	
2011	Ram 3500 Pickup	HSM	●	●	●	●	●	●	●	0081
2011	Ram 3500 Pickup	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 039D
2011	Ram 3500 Pickup	MSMD	●	●	●	●	●	○	○	02EE 00BC 0114 0116 0118 0117 0081 0115 0119
2011	Ram 3500 Pickup	CCN	●	●	●	●	●	●	●	00BC 0382 038D 0383
2011	Ram 3500 Pickup	WCM	●	●	●	●	●	●	●	02A7 01D2 0228 03E6 0300 0245 0081
2011	Ram 3500 Pickup	DMFR	●	●	●	●	●	●	●	
2011	Ram 3500 Pickup	ITBM	●	●	●	●	○	○	○	
2011	Ram 3500 Pickup	RADIO	●	●	●	●	●	●	●	025D 039E 039F 01BB 03A0
2011	Ram 3500 Pickup	HVAC	●	●	●	●	●	●	●	00EA 03B9 00EC 03A9 02EB 00E9 0081
2011	Ram 3500 Pickup	ORC	●	●	●	●	●	○	●	02A1
2011	Ram 3500 Pickup	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 003D 0032 03E7 0036 0037 0389 0038 002E 0387 038F 003B 0388 0390 03A1 03A2
2011	Ram 3500 Pickup	SAS	●	●	●	●	○	○	○	
2011	Ram 3500 Pickup	ABS	●	●	●	●	●	●	●	0002 0285 0062
2011	Ram 3500 Pickup	HFM	●	●	●	●	●	●	○	00E3
2011	Ram 3500 Pickup	VES3	●	●	●	●	●	●	●	
2011	Ram 3500 Pickup	PCM	●	●	●	●	●	●	●	025E 0260 0261 0263 03C7 0154 0155 0141 0044 0265 0150 0151 012D 017B 0292 03CB 0049 03E5 0280 03C8 024E 016F 0179 03C1 035B 039A 03C6 03C5 03C2 03C3 03C4 03C9

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2011	Ram 2500	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 003D 0032 03E7 0036 0037 0389 0038 002E 0387 038F 003B 0388 0390 03A1 022D 03A2
2011	Ram 2500	ABS	●	●	●	●	●	●	●	0002 0285 0062
2011	Ram 2500	VES3	●	●	●	●	●	●	●	
2011	Ram 2500	MSMD	●	●	●	●	●	○	○	02EE 00BC 0114 0116 0118 0117 0081 0115 0119
2011	Ram 4500/5500	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 039D
2011	Ram 4500/5500	CCN	●	●	●	●	●	●	●	00BC 0382 038D 0383
2011	Ram 4500/5500	MSMD	●	●	●	●	●	○	○	02EE 00BC 0114 0116 0118 0117 0081 0115 0119
2011	Ram 4500/5500	DCU	●	○	○	○	○	○	○	
2011	Ram 4500/5500	DTCM	●	●	●	●	●	●	○	
2011	Ram 4500/5500	WCM	●	●	●	●	●	●	●	02A7 01D2 0228 03E6 0081 0300 0245
2011	Ram 4500/5500	SAS	●	●	●	●	○	○	○	
2011	Ram 4500/5500	HVAC	●	●	●	●	●	●	●	00EA 03B9 00EC 03A9 02EB 00E9 0081
2011	Ram 4500/5500	ORC	●	●	●	●	●	○	●	02A1
2011	Ram 4500/5500	TCM	●	●	●	●	○	●	○	01F6 0391
2011	Ram 4500/5500	DMFL	●	●	●	●	●	●	●	
2011	Ram 4500/5500	HFM	●	●	●	●	●	●	○	00E3
2011	Ram 4500/5500	PCM	●	●	●	●	●	●	●	025E 0260 0261 0263 03ED 03E8 03E9 03EA 03EB 03EC 03C7 0154 0155 0141 0044 0265 0150 0151 012D 017B 03CB 0049 03E5 0280 03C8 024E 0379 016F 0179 03C1 03EF 035B 039A 03C5 03EE 03C2 03C3 03C4 0411 03F4 0491 04AF
2011	Ram 4500/5500	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 008F 008E 003D 0214 0032 003F 0036 0037 0389 0038 002E 0387 038F 003B 02F4 0388 0390 03A1 03A2
2011	Ram 4500/5500	ITBM	●	●	●	●	○	○	○	
2011	Ram 4500/5500	DMFR	●	●	●	●	●	●	●	
2011	Ram 4500/5500	HSM	●	●	●	●	●	●	●	0412 0081
2011	Ram 4500/5500	RADIO	●	●	●	●	●	●	●	039F 039E 01BB 03A0 025D
2011	Ram 4500/5500	ABS	●	●	●	●	●	●	●	0002 0285 0062
2011	Ram 1500	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 003D 0032 03E7 0036 0037 0389 0038 002E 0387 038F 003B 0388 0390 03A1 022D 03A2
2011	Ram 1500	BTM	●	●	●	●	●	●	○	
2011	Ram 1500	DMFL	●	●	●	●	●	●	●	
2011	Ram 1500	DRM	●	●	●	●	●	○	○	
2011	Ram 1500	WCM	●	●	●	●	●	●	●	02A7 0414 01D2 0228 03E6 0232 0230 0231 022F 0413 0300 0245 0081
2011	Ram 1500	SAS	●	●	●	●	○	○	○	
2011	Ram 1500	DMFR	●	●	●	●	●	●	●	
2011	Ram 1500	PTS	●	●	●	●	●	●	●	02ED 03B7
2011	Ram 1500	MCPB	●	○	○	●	○	○	○	034C
2011	Ram 1500	ABS	●	●	●	●	●	●	●	03BC 0002 03BB 0285 0062

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2011	Ram 1500	MCPA	●	○	○	●	○	○	○	034C
2011	Ram 1500	BPCM	●	●	●	●	●	●	○	0419 041D 041B 041A 012D 0418 041C 0359 034E 0354
2011	Ram 1500	HSM	●	●	●	●	●	●	●	0412 0081
2011	Ram 1500	OBCM	●	●	●	●	●	●	○	
2011	Ram 1500	HCP	●	●	●	●	●	○	○	041E 0420 035B 041F 036A 0368
2011	Ram 1500	ITBM	●	●	●	●	○	○	○	
2011	Ram 1500	APM	●	○	○	○	○	○	○	0422
2011	Ram 1500	MSMD	●	●	●	●	●	○	○	02EE 00BC 0114 0116 0118 0117 0081 0115 0119
2011	Ram 1500	PCM	●	●	●	●	●	●	●	#####
2011	Ram 1500	HFM	●	●	●	●	●	●	○	00E3
2011	Ram 1500	EPS	●	●	●	●	●	○	○	
2011	Ram 1500	DTCM	●	●	●	●	●	●	●	
2011	Ram 1500	TCM	●	●	●	●	●	○	○	035B 0416 0415 0417
2011	Ram 1500	EAC	●	●	●	●	●	○	○	
2011	Ram 1500	CCN	●	●	●	●	●	●	●	00BC 0382 038D 0383
2011	Ram 1500	RADIO	●	●	●	●	●	●	●	039F 039E 01BB 03A0 025D
2011	Ram 1500	SDARV	●	●	●	●	●	○	○	
2011	Ram 1500	PHGM	●	●	●	●	○	●	○	
2011	Ram 1500	HVAC	●	●	●	●	●	●	●	00EA 03B9 00EC 03A9 02EB 02EA 0081 00E9
2011	Ram 1500	ORC	●	●	●	●	●	○	●	02A1
2011	Ram 1500	HGM	●	●	●	●	●	●	●	034D
2011	Ram 1500	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 039D
2011	Ram 1500	TPM	●	●	●	●	●	○	●	0414 0232 0230 0231 022F 0413
2011	Ram 1500	VES3	●	●	●	●	●	●	●	
2011	Ram (Mexico)	DMFR	●	●	●	●	●	●	●	
2011	Ram (Mexico)	WCM	●	●	●	●	●	●	●	02A7 0414 01D2 0228 03E6 0232 0230 0231 022F 0413 0300 0245 01DE 0081
2011	Ram (Mexico)	ABS	●	●	●	●	●	●	●	0002 0285 0062
2011	Ram (Mexico)	DTCM	●	●	●	●	●	●	○	
2011	Ram (Mexico)	PCM	●	●	●	●	●	●	●	#####
2011	Ram (Mexico)	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 003D 0032 03E7 0036 0037 0389 0038 002E 038F 003B 0388 0390 03A1 022D 03A2
2011	Ram (Mexico)	TPM	●	●	●	●	●	○	●	0414 0232 0230 0231 022F 0413
2011	Ram (Mexico)	CCN	●	●	●	●	●	●	●	00BC 0382 038D 0383
2011	Ram (Mexico)	HSM	●	●	●	●	●	●	●	0081
2011	Ram (Mexico)	DMFL	●	●	●	●	●	●	●	
2011	Ram (Mexico)	SAS	●	●	●	●	○	○	○	
2011	Ram (Mexico)	ORC	●	●	●	●	●	○	●	02A1
2011	Ram (Mexico)	RADIO	●	●	●	●	●	●	●	039F 039E 01BB 03A0 025D
2011	Ram (Mexico)	ITBM	●	●	●	●	○	○	○	
2011	Ram (Mexico)	SDARV	●	●	●	●	●	○	○	
2011	Ram (Mexico)	PTS	●	●	●	●	●	●	●	02ED 03B7
2011	Ram (Mexico)	HFM	●	●	●	●	●	●	○	00E3

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2011	Freemont	BCM	●	●	●	●	●	●	●	0439 043C 02F1 0438 02F0 02F3 02EF 02F5 008F 03C0 003D 043B 043A 002E 038F 0390 022D
2011	Freemont	AMP	●	●	●	●	●	○	○	006D 0068
2011	Freemont	RFH	●	●	●	●	●	●	●	0443 0440 0442 0441 0444 043F 0445
2011	Freemont	VES3	●	●	●	●	●	●	○	
2011	Freemont	HSM	●	●	●	●	●	●	●	
2011	Freemont	ABS	●	●	●	●	●	●	●	0433 03AB 0434
2011	Freemont	HFM	●	●	●	●	●	○	○	00E3
2011	Freemont	IPC	●	●	●	●	●	●	○	04B3
2011	Freemont	DTCM	●	●	●	●	●	●	●	
2011	Freemont	ORC	●	●	●	●	●	○	●	03CC 02A1 0122
2011	Freemont	SCCM	●	●	●	●	●	○	○	
2011	Freemont	ICS	●	●	●	●	●	●	○	
2011	Freemont	ITM	●	●	●	●	●	●	●	0107 0437 0104 03CE 0436
2011	Freemont	TPM	●	●	●	●	●	○	●	0435 0232 0230 0231 022F 0413
2011	Freemont	PTS	●	●	●	●	●	●	●	02ED 03B7
2011	Wrangler	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0389 0038 003A 002E 021F 038F 003B 02F4 0388 0390 03A1 03A2
2011	Wrangler	CCN	●	●	●	●	●	●	○	008C 00BC 0382 0091 0094 038D 0096 0383
2011	Wrangler	ASBS	●	●	●	●	●	○	○	0317 0318 031A 031B 0319
2011	Wrangler	PCM	●	●	●	●	●	●	●	#####
2011	Wrangler	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 039D
2011	Wrangler	HFM	●	●	●	●	●	●	○	00E3
2011	Wrangler	ABS	●	●	●	●	●	●	●	0002 0285 0062 0081
2011	Wrangler	ORC	●	●	●	●	●	○	●	03CC 02A1 0081 0122 03CD
2011	Wrangler	HVAC	●	●	●	●	●	●	●	02E9 00EA 02EA 02EB 0081
2011	Wrangler	RADIO	●	●	●	●	●	●	●	031C 025D 039E 039F 01BB 03A0
2011	Wrangler	ITM	●	●	●	●	●	●	●	0437 0448 03CF 0449 0436 0385 0081
2011	Wrangler	SAS	●	●	●	●	○	○	○	
2011	Wrangler	WCM	●	●	●	●	●	○	●	01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0244 0081 0233 022D 0227 0274 031E 031F
2011	Wrangler	TCM	●	●	●	●	●	○	○	038C 01F3 01F2
2011	Wrangler	ESM	●	●	●	●	●	●	○	
2011	Sebring / 200 / Avenger	TIPMCGW	●	●	●	●	●	●	●	030D 030F 02F1 02F0 02F3 02EF 0039 030E 030C 003C 003D 0214 0032 0210 003E 03E7 0036 02C3 0037 0389 0034 0038 003A 0213 038F 003B 02F4 0388 0390 03A2
2011	Sebring / 200 / Avenger	AWD	●	●	●	●	●	○	●	
2011	Sebring / 200 / Avenger	ABS	●	●	●	●	●	●	●	03AB 0002
2011	Sebring / 200 / Avenger	RADIO	●	●	●	●	●	●	●	039F 039E 01BB 03A0 025D

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2011	Sebring / 200 / Avenger	ITM	●	●	●	●	●	●	●	03CF 0107 0385 0106 0081 03CE
2011	Sebring / 200 / Avenger	HVAC	●	●	●	●	●	●	●	0288 0287 00E9 00EC 03A9 02EB 02E9 00EA 02EA 0081
2011	Sebring / 200 / Avenger	HFM	●	●	●	●	●	●	○	00E3
2011	Sebring / 200 / Avenger	VES3	●	●	●	●	●	●	●	
2011	Sebring / 200 / Avenger	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 039D
2011	Sebring / 200 / Avenger	ESM	●	●	●	●	○	●	●	
2011	Sebring / 200 / Avenger	PCM	●	●	●	●	●	●	●	042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0405 0406 0407 040C 040E 040F 03B8 013C 012C 012D 0410 0386 0140 02F9 03F1 03F0 03F2 012A 03E5 02FA 040D 03F5 040B 012B 0408 0409
2011	Sebring / 200 / Avenger	PDM	●	●	●	●	●	●	○	0306 0081
2011	Sebring / 200 / Avenger	SAS	●	●	●	●	○	○	○	
2011	Sebring / 200 / Avenger	WCM	●	●	●	●	●	○	●	02A7 022E 01D2 0228 0226 0225 0232 0230 0231 022F 0244 0081 0233 022D 0274 031E 031F 037C
2011	Sebring / 200 / Avenger	ORC	●	●	●	●	●	○	●	03CC
2011	Sebring / 200 / Avenger	TCM	●	●	●	●	○	●	●	0167 0166 01EE 016A 0169 016C 016B 016E 016D 01F0 0172 0177 0170 016F 0175 044D 044E 044A 044C 01EF 044B
2011	Sebring / 200 / Avenger	CCN	●	●	●	●	●	●	●	008C 008F 008E 0094 0092 0081 0096 0090
2011	Sebring / 200 / Avenger	PTCM	●	●	●	●	●	○	●	0371 025B 0259 026A 0081 025A
2011	Sebring / 200 / Avenger	DDM	●	●	●	●	●	●	○	0306 0081
2011	Nitro	TCM	●	●	●	●	●	○	○	038C 01F3 01F2
2011	Nitro	CCN	●	●	●	●	●	●	○	008C 00BC 0382 0091 0094 038D 0096 0383
2011	Nitro	HFM	●	●	●	●	●	●	○	00E3
2011	Nitro	ORC	●	●	●	●	●	○	●	03CC 03CD
2011	Nitro	DMFR	●	●	●	●	●	●	●	
2011	Nitro	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0389 0038 003A 021F 02E2 038F 003B 02F4 0388 0390 03A1 03A2

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2011	Nitro	ABS	●	●	●	●	●	●	●	0002 0285 0062
2011	Nitro	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 039D
2011	Nitro	PTS	●	●	●	●	●	●	●	02ED 03B7
2011	Nitro	DMFL	●	●	●	●	●	●	●	
2011	Nitro	WCM	●	●	●	●	●	○	●	01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0244 0081 0233 022D 0227 0274 031E 031F
2011	Nitro	ESM	●	●	●	●	●	●	○	
2011	Nitro	OCM	●	●	●	●	●	○	○	011E
2011	Nitro	ITM	●	●	●	●	●	●	●	03CF 0107 0385 0081 03CE
2011	Nitro	SAS	●	●	●	●	○	○	○	
2011	Nitro	PCM	●	●	●	●	●	●	●	03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 0127 03F3 0126 0411 0404 0402 0403 040A 0400 0401 0128 03FB 03FF 03F4 0405 0406 0407 040C 040E 040F 03B8 013C 012C 012D 0410 0386 0140 02F9 03F1 03F0 03F2 012A 03E5 02FA 040D 03F5 040B 012B 0408 0409
2011	Nitro	HVAC	●	●	●	●	●	●	●	02E9 00EA 02EA 02EB 0081 0288 0287 00E9 00EC 03A9
2011	Nitro	RADIO	●	●	●	●	●	●	●	025D 039E 039F 01BB 03A0
2011	Liberty	HFM	●	●	●	●	●	●	○	00E3
2011	Liberty	PCM	●	●	●	●	●	●	●	#####
2011	Liberty	MSMD	●	●	●	●	●	●	●	0455 0451 0450 0454 044F 0452 0453 02EE 00BC 0114 0116 0118 0117 0115 0119
2011	Liberty	DMFL	●	●	●	●	●	●	●	
2011	Liberty	ESM	●	●	●	●	●	●	○	
2011	Liberty	ITM	●	●	●	●	●	●	●	03CF 0107 03AA 0081 03CE
2011	Liberty	SUNR	●	●	●	●	●	○	○	02E6 0081
2011	Liberty	TCM	●	●	●	●	●	○	○	038C 01F3 01F2
2011	Liberty	RADIO	●	●	●	●	●	●	●	039F 039E 01BB 03A0 025D
2011	Liberty	ABS	●	●	●	●	●	●	●	0002 0285 0062 0081
2011	Liberty	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 039D
2011	Liberty	HVAC	●	●	●	●	●	●	●	02E9 00EA 02EA 02EB 0081 0288 0287 00E9 00EC 03A9
2011	Liberty	OCM	●	●	●	●	●	○	○	011E
2011	Liberty	ORC	●	●	●	●	●	○	●	03CC 03CD
2011	Liberty	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0389 0038 003A 021F 02E2 038F 003B 02F4 0388 0390 03A1 03A2
2011	Liberty	CCN	●	●	●	●	●	●	●	00BC 0382 038D 0383
2011	Liberty	FDCM	●	●	●	●	●	●	○	0340
2011	Liberty	PTS	●	●	●	●	●	●	●	02ED 03B7
2011	Liberty	SAS	●	●	●	●	○	○	○	
2011	Liberty	DMFR	●	●	●	●	●	●	●	
2011	Liberty	WCM	●	●	●	●	●	○	●	01D2 0341 0228 0226 0225 0232 0230 0231 022F 01DE 0244 0081 0233 022D 0227 0274 031E 031F
2011	Challenger	WCM	●	●	●	●	●	●	●	02A7 0414 01D2 0228 03E6 0232 0230 0231 022F 0413 0081 0300 0245

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2011	300 / Magnum / Charger (Pre-2011)	PTS	●	●	●	●	●	●	●	02ED 03B7
2011	300 / Magnum / Charger (Pre-2011)	BCM	●	●	●	●	●	●	●	0439 043C 02F1 0438 02F0 02F3 02EF 02F5 008F 03C0 003D 043B 043A 002E 038F 0390 022D
2011	300 / Magnum / Charger (Pre-2011)	HFM	●	●	●	●	●	○	○	00E3
2011	300 / Magnum / Charger (Pre-2011)	EPS	●	●	●	●	●	○	○	
2011	300 / Magnum / Charger (Pre-2011)	MSM	●	●	●	●	●	●	●	0455 0451 0454 044F 0452 0450 0453
2011	300 / Magnum / Charger (Pre-2011)	SCCM	●	●	●	●	●	○	○	
2011	300 / Magnum / Charger (Pre-2011)	ESM	●	●	●	●	●	●	○	
2011	300 / Magnum / Charger (Pre-2011)	BSM	●	●	●	●	●	○	○	0372
2011	300 / Magnum / Charger (Pre-2011)	ACC	●	●	●	●	●	○	●	0457
2011	300 / Magnum / Charger (Pre-2011)	HVAC	●	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2011	300 / Magnum / Charger (Pre-2011)	PCM	●	●	●	●	●	●	●	#####
2011	Compass	CCN	●	●	●	●	●	●	●	008C 008F 008E 0094 0092 0081 0096 0090
2011	Compass	AMP	●	●	●	●	●	○	●	0069 006D 0079 0068 0303 0081 006A 039D
2011	Compass	WCM	●	●	●	●	●	○	●	02A7 01D2 0228 0226 0225 0232 0230 0231 022F 0244 0081 0233 022D 0274 031E 031F 037C
2011	Compass	ORC	●	●	●	●	●	○	●	03CC 03CD
2011	Compass	RADIO	●	●	●	●	●	●	●	025D 039E 039F 01BB 03A0
2011	Compass	PCM	●	●	●	●	●	●	●	#####
2011	Compass	TCM	●	●	●	●	●	●	●	0380
2011	Compass	ITM	●	●	●	●	●	●	●	03CF 0107 0385 0106 0081 03CE
2011	Compass	ABS	●	●	●	●	●	●	●	0002 0285 0062 03AB
2011	Compass	HVAC	●	●	●	●	●	●	●	02E9 00EA 02EA 02EB 0081
2011	Compass	SAS	●	●	●	●	○	○	○	
2011	Compass	TIPMCGW	●	●	●	●	●	●	●	030D 030F 02F1 02F0 02F3 02EF 0039 030E 030C 003C 003D 0214 0032 0210 003F 003E 0036 0037 0389 0034 0038 003A 020E 0213 0215 028F 0211 038F 003B 02F4 0388 0390
2011	Compass	HFM	●	●	●	●	●	●	○	00E3
2011	Compass	AWD	●	●	●	●	●	●	●	
2011	Dakota	EOM	●	●	●	●	●	○	●	00BA
2011	Dakota	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 039D
2011	Dakota	CCN	●	●	●	●	●	●	●	008F 008E 008D 0090

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2011	Routan	VES2	●	●	●	●	●	●	●	03AE
2011	Routan	PSDML	●	●	●	●	●	○	○	0343 0461 0462 0460 0342
2011	Routan	RADIO	●	●	●	●	●	●	●	025D 039E 039F 01BB 03A0
2011	Routan	FSM	●	●	●	●	●	●	○	03AC 03AD 0346 0347
2011	Routan	PTS	●	●	●	●	●	●	●	02ED 03B7
2011	Routan	MSMD	●	●	●	●	●	●	●	0455 0451 0450 0454 044F 0452 0453
2011	Routan	DMRR	●	●	●	●	●	●	●	00B4 00B5 00B6
2011	Routan	ORC	●	●	●	●	●	○	●	03CC 02A1 0122
2011	Town & Country / Caravan	BTM	●	●	●	●	●	●	○	
2011	Town & Country / Caravan	ORC	●	●	●	●	●	○	●	03CC 02A1 0122
2011	Town & Country / Caravan	PCM	●	●	●	●	●	●	●	#####
2011	Town & Country / Caravan	PSDML	●	●	●	●	●	○	○	0343 0461 0462 0460 0342
2011	Town & Country / Caravan	DMRR	●	●	●	●	●	●	●	00B4 00B5 00B6
2011	Town & Country / Caravan	DMFR	●	●	●	●	●	●	●	
2011	Town & Country / Caravan	HVAC	●	●	●	●	●	●	●	045C 00E9 045D 045E 045F 02EB 00EA 03B9 03A9 02EA
2011	Town & Country / Caravan	HSM	●	●	●	●	●	●	●	0412 0081
2011	Town & Country / Caravan	DMFL	●	●	●	●	●	●	●	
2011	Town & Country / Caravan	TCM	●	●	●	●	●	●	○	03AF 03B0 03B1 03B2 03B6 03B3 03B5 01FC 0177 03B4 0175 035B 0416 0415 0417
2011	Town & Country / Caravan	SAS	●	●	●	●	○	○	○	
2011	Town & Country / Caravan	EAC	●	●	●	●	●	○	○	
2011	Town & Country / Caravan	TPM	●	●	●	●	●	○	●	0414 0232 0230 0231 022F 0413 0459
2011	Town & Country / Caravan	HIDT	●	●	●	●	●	●	○	02B8
2011	Town & Country / Caravan	SDARV	●	●	●	●	●	○	○	
2011	Town & Country / Caravan	MSMD	●	●	●	●	●	●	●	0455 0451 0450 0454 044F 0452 0453
2011	Town & Country / Caravan	PSDMR	●	●	●	●	●	○	○	0343 0461 0462 0460 0342

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2011	Town & Country / Caravan	VES3	●	●	●	●	●	●	●	
2011	Town & Country / Caravan	PEM	●	●	●	●	●	○	●	0443 0463 0442 0307
2011	Town & Country / Caravan	DMRL	●	●	●	●	●	●	●	00B4 00B5 00B6
2011	Town & Country / Caravan	ABS	●	●	●	●	●	●	●	03AB 0002 0081 04EB
2011	Town & Country / Caravan	WCM	●	●	●	●	●	●	●	02A7 0414 022E 01D2 03E4 0228 03E6 0232 0230 0231 022F 01DE 0413 0081 0300 0245
2011	Town & Country / Caravan	BSM	●	●	●	●	●	○	○	0372
2011	Town & Country / Caravan	CCN	●	●	●	●	●	●	●	00BC 0382 038D 0383
2011	Town & Country / Caravan	MCPA	●	○	○	●	○	○	○	034C
2011	Town & Country / Caravan	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 039D
2011	Town & Country / Caravan	AHBM	●	●	●	●	●	○	○	0067 0066 03C0 00BC
2011	Town & Country / Caravan	HFM	●	●	●	●	●	●	○	00E3
2011	Town & Country / Caravan	EPS	●	●	●	●	●	○	○	
2011	Town & Country / Caravan	PTS	●	●	●	●	●	●	●	02ED 03B7
2011	Town & Country / Caravan	DRM	●	●	●	●	●	○	○	
2011	Town & Country / Caravan	BPCM	●	●	●	●	●	●	○	041C 0359 034E
2011	Town & Country / Caravan	ITM	●	●	●	●	●	●	●	03CF 0107 0385 0106 0081 03CE
2011	Town & Country / Caravan	OBCM	●	●	●	○	●	○	○	
2011	Town & Country / Caravan	MCPB	●	○	○	●	○	○	○	034C
2011	Town & Country / Caravan	HCP	●	●	●	●	●	○	○	041E 0420 035B 041F 036A 0368
2011	Town & Country / Caravan	RADIO	●	●	●	●	●	●	●	039F 039E 01BB 03A0 025D
2011	Town & Country / Caravan	FSM	●	●	●	●	●	●	○	03AC 03AD 0346 0347

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2011	Town & Country / Caravan	SUNR	●	●	●	●	●	●	○	
2011	Town & Country / Caravan	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 0036 0037 0389 0038 003A 002E 038F 003B 02F4 0388 0390 03A1 022D 03A2
2011	Town & Country / Caravan	DVD	●	●	●	●	●	○	○	
2011	Town & Country / Caravan	PLGM	●	●	●	●	●	●	●	038A 038B 00B4 0199 00B5 0342
2011	Town & Country / Caravan	VES2	●	●	●	●	●	●	●	03AE
2011	Town & Country / Caravan	PHGM	●	●	●	●	○	●	○	
2011	Town & Country / Caravan	HGM	●	●	●	●	●	●	●	034D
2011	Town & Country / Caravan	APM	●	○	○	○	○	○	○	0422
2011	Durango (Post-2011)	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0389 0038 002E 038F 003B 0388 0390 03A1 022D 03A2
2011	Durango (Post-2011)	ORC	●	●	●	●	●	○	●	03CC 02A1 0122
2011	Durango (Post-2011)	HSM	●	●	●	●	●	●	●	0412 0081
2011	Durango (Post-2011)	RADIO	●	●	●	●	●	●	●	039F 039E 01BB 03A0 025D
2011	Durango (Post-2011)	ITM	●	●	●	●	●	●	●	0107 0437 03CF 03CE 0436 0081
2011	Durango (Post-2011)	ACC	●	●	●	●	●	○	○	0457 0081
2011	Durango (Post-2011)	SDARV	●	●	●	●	●	○	○	
2011	Durango (Post-2011)	CCN	●	●	●	●	●	●	●	00BC 0382 038D 0383
2011	Durango (Post-2011)	DTCM	●	●	●	●	●	●	●	0340
2011	Durango (Post-2011)	AHLM	●	●	●	●	●	●	○	0464
2011	Durango (Post-2011)	SAS	●	●	●	●	●	●	○	
2011	Durango (Post-2011)	BSM	●	●	●	●	●	○	○	0372
2011	Durango (Post-2011)	PCM	●	●	●	●	●	●	●	03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 0127 03F3 0126 0411 0404 0402 0403 040A 0400 0401 0128 03FB 03FF 03F4 0405 0406 0407 040C 040E 040F 03B8 013C 012C 012D 0410 0386 0140 02F9 03F1 03F0 03F2 012A 03E5 02FA 040D 03F5 040B 012B 0408 0409
2011	Durango (Post-2011)	MSMD	●	●	●	●	●	●	●	0455 0451 0450 0454 044F 0452 0453
2011	Durango (Post-2011)	PLGM	●	●	●	●	○	●	●	00B4 00B5 038A 038B 0199
2011	Durango (Post-2011)	TCM	●	●	●	●	●	○	○	038C 01F3 01F2
2011	Durango (Post-2011)	HFM	●	●	●	●	●	●	○	00E3
2011	Durango (Post-2011)	DMFL	●	●	●	●	●	●	●	
2011	Durango (Post-2011)	VES3	●	●	●	●	●	●	●	
2011	Durango (Post-2011)	AHBM	●	●	●	●	○	●	○	0066

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2011	Durango (Post-2011)	EPS	●	●	●	●	●	○	○	
2011	Durango (Post-2011)	PEM	●	●	●	●	●	○	●	0443 0463 0442 0307
2011	Durango (Post-2011)	ESM	●	●	●	●	●	●	○	
2011	Durango (Post-2011)	ABS	●	●	●	●	●	●	●	0433 03AB 0081
2011	Durango (Post-2011)	WCM	●	●	●	●	●	●	●	02A7 0414 01D2 03E4 0228 03E6 0232 0230 0231 022F 0413 0300 0245 0081
2011	Durango (Post-2011)	TPM	●	●	●	●	●	○	●	0414 0232 0230 0231 022F 0413
2011	Durango (Post-2011)	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 039D
2011	Durango (Post-2011)	PTS	●	●	●	●	●	●	●	02ED 01B8
2011	Durango (Post-2011)	HVAC	●	●	●	●	●	●	●	045C 00E9 045D 045E 045F 02EB
2011	Durango (Post-2011)	DMFR	●	●	●	●	●	●	●	
2011	Grand Cherokee	EPS	●	●	●	●	●	○	○	
2011	Grand Cherokee	VES3	●	●	●	●	●	●	●	
2011	Grand Cherokee	BSM	●	●	●	●	●	○	○	0372
2011	Grand Cherokee	ASCM	●	●	●	●	●	○	○	046E 0467 046F 0472 046A 0471 0466 0469 046B 0468 046D 046C 0470
2011	Grand Cherokee	PLGM	●	●	●	●	○	●	●	00B4 00B5 038A 038B 0199
2011	Grand Cherokee	AHLM	●	●	●	●	●	●	○	0464
2011	Grand Cherokee	HSM	●	●	●	●	●	●	●	0412 0081
2011	Grand Cherokee	SAS	●	●	●	●	●	●	○	
2011	Grand Cherokee	SDARV	●	●	●	●	●	○	○	
2011	Grand Cherokee	ABS	●	●	●	●	●	●	●	0433 03AB 0081
2011	Grand Cherokee	PEM	●	●	●	●	●	○	●	0443 0463 0442 0307
2011	Grand Cherokee	MSMD	●	●	●	●	●	●	●	0455 0451 0450 0454 044F 0452 0453
2011	Grand Cherokee	HFM	●	●	●	●	●	●	○	00E3
2011	Grand Cherokee	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 039D
2011	Grand Cherokee	AHBM	●	●	●	●	○	●	○	0066
2011	Grand Cherokee	DMFR	●	●	●	●	●	●	●	
2011	Grand Cherokee	DMFL	●	●	●	●	●	●	●	
2011	Grand Cherokee	ORC	●	●	●	●	●	○	●	03CC 02A1 0122
2011	Grand Cherokee	ELSD	●	●	●	●	●	●	○	0474 0473
2011	Grand Cherokee	HVAC	●	●	●	●	●	●	●	045C 00E9 045D 045F 02EB
2011	Grand Cherokee	WCM	●	●	●	●	●	●	●	02A7 0414 01D2 0465 03E4 0228 03E6 0232 0230 0231 022F 0413 0300 0245 0081
2011	Grand Cherokee	DTCM	●	●	●	●	●	●	●	0340
2011	Grand Cherokee	TPM	●	●	●	●	●	○	●	0414 0232 0230 0231 022F 0413
2011	Grand Cherokee	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0389 0038 002E 038F 003B 0388 0390 03A1 022D 03A2
2011	Grand Cherokee	ITM	●	●	●	●	●	●	●	0107 0437 03CF 03CE 0436 0081
2011	Grand Cherokee	PTS	●	●	●	●	●	●	●	02ED 01B8
2011	Grand Cherokee	RADIO	●	●	●	●	●	●	●	039F 039E 01BB 03A0 025D
2011	Grand Cherokee	PCM	●	●	●	●	●	●	●	#####
2011	Grand Cherokee	TCM	●	●	●	●	●	○	○	038C 01F3 01F2

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2012	Ram 3500 Cab Chassis	DMFL	●	●	●	●	●	●	●	
2012	Ram 3500 Cab Chassis	PCM	●	●	●	●	●	●	●	#####
2012	Ram 3500 Cab Chassis	ORC	●	●	●	●	●	○	●	02A1
2012	Ram 3500 Cab Chassis	TCM	●	●	●	●	○	●	○	01F6 0391
2012	Ram 2500	HSM	●	●	●	●	●	●	●	0412 0081
2012	Ram 2500	ITBM	●	●	●	●	○	○	○	
2012	Ram 2500	PTS	●	●	●	●	●	●	●	02ED 03B7
2012	Ram 2500	DMFR	●	●	●	●	●	●	●	
2012	Ram 2500	CCN	●	●	●	●	●	●	●	00BC 0382 038D 0383
2012	Ram 2500	MSMD	●	●	●	●	●	○	○	02EE 00BC 0114 0116 0118 0117 0115 0119
2012	Ram 2500	PCM	●	●	●	●	●	●	●	#####
2012	Ram 2500	DMFL	●	●	●	●	●	●	●	
2012	Ram 2500	VES3	●	●	●	●	●	●	●	
2012	Ram 2500	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 039D
2012	Ram 2500	WCM	●	●	●	●	●	●	●	02A7 0414 01D2 0228 03E6 0232 0230 0231 022F 0413 0081 0300 0245
2012	Ram 2500	FDCM	●	●	●	●	●	○	○	02B4 02B7 02B6 02B5 02B3 02B2 02B1 02AF 02B0
2012	Ram 2500	RADIO	●	●	●	●	●	●	●	039F 0475 01BB 03A0 025D 039E
2012	Ram 2500	DTCM	●	●	●	●	●	●	○	
2012	Ram 2500	HVAC	●	●	●	●	●	●	●	00EA 03B9 00EC 03A9 02EB 00E9 0081
2012	Ram 2500	ABS	●	●	●	●	●	●	●	0002 0285 0062 0081
2012	Ram 2500	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 003D 0032 03E7 0036 0037 0389 0038 0476 0387 038F 003B 0388 0390 03A1 022D 03A2
2012	Ram 2500	TPM	●	●	●	●	●	○	●	0414 0232 0230 0231 022F 0413 0081 03CA
2012	Ram 2500	ORC	●	●	●	●	●	○	●	02A1
2012	Ram 2500	SAS	●	●	●	●	○	○	○	
2012	Ram 2500	HFM	●	●	●	●	●	●	○	00E3
2012	Ram 4500/5500	WCM	●	●	●	●	●	●	●	02A7 01D2 0228 03E6 0300 0245
2012	Ram 4500/5500	DCU	●	○	○	○	○	○	○	
2012	Ram 4500/5500	HSM	●	●	●	●	●	●	●	0412
2012	Ram 4500/5500	DMFL	●	●	●	●	●	●	●	
2012	Ram 4500/5500	DTCM	●	●	●	●	●	●	○	
2012	Ram 4500/5500	HVAC	●	●	●	●	●	●	●	00EA 00E9 00EC 03A9 02EB 03B9
2012	Ram 4500/5500	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 003D 0214 0032 03E7 0036 0037 0389 0038 0476 0387 038F 003B 0388 0390 03A1 022D 03A2
2012	Ram 4500/5500	ABS	●	●	●	●	●	●	●	0002 0285 0062
2012	Ram 4500/5500	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 039D
2012	Ram 4500/5500	RADIO	●	●	●	●	●	●	●	025D 039E 039F 01BB 0475 03A0
2012	Ram 4500/5500	HFM	●	●	●	●	●	●	○	00E3
2012	Ram 4500/5500	TCM	●	●	●	●	○	●	○	01F6 0391
2012	Ram 4500/5500	DMFR	●	●	●	●	●	●	●	
2012	Ram 4500/5500	ORC	●	●	●	●	●	○	●	02A1

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2012	Ram 4500/5500	ITBM	●	●	●	●	○	○	○	
2012	Ram 4500/5500	MSMD	●	●	●	●	●	○	○	02EE 00BC 0114 0116 0118 0117 0115 0119
2012	Ram 4500/5500	SAS	●	●	●	●	○	○	○	
2012	Ram 4500/5500	CCN	●	●	●	●	●	●	●	00BC 0382 038D 0383
2012	Ram 4500/5500	PCM	●	●	●	●	●	●	●	025E 0260 0261 0263 03ED 03E8 03E9 03EA 03EB 03EC 03C7 0154 0155 0141 0044 0265 0150 0151 012D 017B 03CB 0049 03E5 0280 03C8 024E 0379 0179 03C1 03EF 039A 03C5 03EE 03C2 03C4 0478 0477
2012	Ram 1500	ABS	●	●	●	●	●	●	●	0002 0285 0062
2012	Ram 1500	DTCM	●	●	●	●	●	●	●	
2012	Ram 1500	TPM	●	●	●	●	●	○	●	0414 0232 0230 0231 022F 0413
2012	Ram 1500	HVAC	●	●	●	●	●	●	●	00EC 02EA 02EB 00EA 00E9 03A9 03B9
2012	Ram 1500	PCM	●	●	●	●	●	●	●	042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0405 0406 0407 040C 040E 040F 03B8 013C 012C 012D 0410 0386 02F9 03F1 03F0 03F2 012A 03E5 02FA 040D 03F5 040B 012B 0408 0409
2012	Ram 1500	DMFR	●	●	●	●	●	●	●	
2012	Ram 1500	RADIO	●	●	●	●	●	●	●	039F 0475 01BB 03A0 025D 039E
2012	Ram 1500	HFM	●	●	●	●	●	●	○	00E3
2012	Ram 1500	HSM	●	●	●	●	●	●	●	0412
2012	Ram 1500	DMFL	●	●	●	●	●	●	●	
2012	Ram 1500	VES3	●	●	●	●	●	●	●	
2012	Ram 1500	SAS	●	●	●	●	○	○	○	
2012	Ram 1500	ITBM	●	●	●	●	○	○	○	
2012	Ram 1500	WCM	●	●	●	●	●	●	●	02A7 0414 01D2 0228 03E6 0232 0230 0231 022F 0413 0300 0245
2012	Ram 1500	CCN	●	●	●	●	●	●	●	00BC 0382 038D 0383
2012	Ram 1500	ORC	●	●	●	●	●	○	●	02A1
2012	Ram 1500	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 003D 0032 03E7 0036 0037 0389 0038 0476 0387 038F 003B 0388 0390 03A1 022D 03A2
2012	Ram 1500	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 039D
2012	Ram 1500	MSMD	●	●	●	●	●	○	○	02EE 00BC 0114 0116 0118 0117 0115 0119
2012	Ram 1500	PTS	●	●	●	●	●	●	●	02ED 03B7
2012	Ram (Mexico)	PCM	●	●	●	●	●	●	●	#####
2012	Ram (Mexico)	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 039D
2012	Ram (Mexico)	TPM	●	●	●	●	●	○	●	0414 0232 0230 0231 022F 0413
2012	Ram (Mexico)	HFM	●	●	●	●	●	●	○	00E3
2012	Ram (Mexico)	PTS	●	●	●	●	●	●	●	02ED 03B7
2012	Ram (Mexico)	CCN	●	●	●	●	●	●	●	00BC 0382 038D 0383
2012	Ram (Mexico)	DTCM	●	●	●	●	●	●	○	
2012	Ram (Mexico)	RADIO	●	●	●	●	●	●	●	039F 0475 01BB 03A0 025D 039E

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2012	Wrangler	TCM	●	●	●	●	●	○	○	038C 01F3 01F2
2012	Wrangler	WCM	●	●	●	●	●	○	●	01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0244 0233 022D 0227 0274 031E 031F
2012	Wrangler	SAS	●	●	●	●	○	○	○	
2012	Wrangler	RADIO	●	●	●	●	●	●	●	031C 025D 039E 039F 01BB 0475 03A0
2012	Wrangler	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0389 0038 003A 002E 021F 038F 003B 02F4 0388 0390 03A1 03A2
2012	Wrangler	ITM	●	●	●	●	●	●	●	0437 0448 03CF 0449 0436 0385
2012	Wrangler	HFM	●	●	●	●	●	●	○	00E3
2012	Wrangler	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 039D
2012	Wrangler	ORC	●	●	●	●	●	○	●	03CC 02A1 0081 0122 03CD
2012	Wrangler	CCN	●	●	●	●	●	●	○	008C 00BC 0382 0091 0094 038D 0096 0383
2012	Wrangler	PCM	●	●	●	●	●	●	●	#####
2012	Wrangler	ASBS	●	●	●	●	●	○	○	0317 0318 031A 031B 0319
2012	Wrangler	ESM	●	●	●	●	●	●	○	
2012	Wrangler	ABS	●	●	●	●	●	●	●	0002 0285 0062
2012	Wrangler	HVAC	●	●	●	●	●	●	●	02E9 00EA 02EA 02EB
2012	Sebring / 200 / Avenger	RADIO	●	●	●	●	●	●	●	039F 0475 01BB 03A0 025D 039E
2012	Sebring / 200 / Avenger	ABS	●	●	●	●	●	●	●	0002 0285 0062 03AB
2012	Sebring / 200 / Avenger	SAS	●	●	●	●	○	○	○	
2012	Sebring / 200 / Avenger	HFM	●	●	●	●	●	●	○	00E3
2012	Sebring / 200 / Avenger	WCM	●	●	●	●	●	○	●	02A7 022E 01D2 0228 0226 0225 0232 0230 0231 022F 0244 0233 022D 0274 031E 031F 037C
2012	Sebring / 200 / Avenger	TIPMCGW	●	●	●	●	●	●	●	030D 030F 02F1 02F0 02F3 02EF 0039 030E 030C 003C 003D 0214 0032 0210 003E 03E7 0036 02C3 0037 0389 0034 0038 003A 0213 038F 003B 02F4 0388 0390 03A2
2012	Sebring / 200 / Avenger	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 039D
2012	Sebring / 200 / Avenger	PDM	●	●	●	●	●	●	○	0306
2012	Sebring / 200 / Avenger	CCN	●	●	●	●	●	●	●	008C 008F 008E 0094 0092 0096 0090
2012	Sebring / 200 / Avenger	HVAC	●	●	●	●	●	●	●	0288 0287 00E9 00EC 03A9 02EB 02E9 00EA 02EA
2012	Sebring / 200 / Avenger	ORC	●	●	●	●	●	○	●	03CC

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2012	Sebring / 200 / Avenger	PCM	●	●	●	●	●	●	●	042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0405 0406 0407 040C 040E 040F 03B8 013C 012C 012D 0410 0386 02F9 03F1 03F0 03F2 012A 03E5 02FA 040D 03F5 040B 012B 0408 0409
2012	Sebring / 200 / Avenger	DDM	●	●	●	●	●	●	○	0306
2012	Sebring / 200 / Avenger	PTCM	●	●	●	●	●	○	●	0371 025B 0259 026A 025A
2012	Nitro	HFM	●	●	●	●	●	●	○	00E3
2012	Nitro	PTS	●	●	●	●	●	●	●	02ED 03B7
2012	Nitro	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0389 0038 003A 021F 02E2 038F 003B 02F4 0388 0390 03A1 03A2
2012	Nitro	ESM	●	●	●	●	●	●	○	
2012	Nitro	PCM	●	●	●	●	●	●	●	042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0405 0406 0407 040C 040E 040F 03B8 013C 012C 012D 0410 0386 02F9 03F1 03F0 03F2 012A 03E5 02FA 040D 03F5 040B 012B 0408 0409
2012	Nitro	HVAC	●	●	●	●	●	●	●	0288 0287 00E9 00EC 02E9 00EA 02EA 02EB
2012	Nitro	DMFR	●	●	●	●	●	●	●	
2012	Nitro	RADIO	●	●	●	●	●	●	●	025D 039E 039F 01BB 0475 03A0
2012	Nitro	ORC	●	●	●	●	●	○	●	03CC 03CD
2012	Nitro	ITM	●	●	●	●	●	●	●	03CF 0107 0385 0106 03CE
2012	Nitro	OCM	●	●	●	●	●	○	○	011E
2012	Nitro	DMFL	●	●	●	●	●	●	●	
2012	Nitro	ABS	●	●	●	●	●	●	●	0002 0285 0062
2012	Nitro	TCM	●	●	●	●	●	○	○	038C 01F3 01F2
2012	Nitro	WCM	●	●	●	●	●	○	●	01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0244 0233 022D 0227 0274 031E 031F
2012	Nitro	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 039D
2012	Nitro	SAS	●	●	●	●	○	○	○	
2012	Nitro	CCN	●	●	●	●	●	●	○	008C 00BC 0382 0091 0094 038D 0096 0383
2012	Liberty	HFM	●	●	●	●	●	●	○	00E3
2012	Liberty	DMFL	●	●	●	●	●	●	●	
2012	Liberty	ITM	●	●	●	●	●	●	●	03CF 0107 03AA 0106 0081 03CE
2012	Liberty	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 039D
2012	Liberty	MSMD	●	●	●	●	●	●	●	02EE 00BC 0114 044F 0116 0118 0117 0115 0119 0455 0451 0450 0454 0452 0453
2012	Liberty	SUNR	●	●	●	●	●	○	○	02E6 0081

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2012	Liberty	TCM	●	●	●	●	●	○	○	038C 01F3 01F2
2012	Liberty	HVAC	●	●	●	●	●	●	●	02E9 00EA 02EA 02EB 0288 0287 00E9 00EC 03A9
2012	Liberty	SAS	●	●	●	●	○	○	○	
2012	Liberty	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0389 0038 003A 021F 02E2 038F 003B 02F4 0388 0390 03A1 03A2
2012	Liberty	OCM	●	●	●	●	●	○	○	011E
2012	Liberty	DMFR	●	●	●	●	●	●	●	
2012	Liberty	ABS	●	●	●	●	●	●	●	0002 0285 0062 0081
2012	Liberty	ORC	●	●	●	●	●	○	●	03CC 03CD
2012	Liberty	RADIO	●	●	●	●	●	●	●	025D 039E 039F 01BB 0475 03A0
2012	Liberty	CCN	●	●	●	●	●	●	●	00BC 0382 038D 0383
2012	Liberty	ESM	●	●	●	●	●	●	○	
2012	Liberty	FDCM	●	●	●	●	●	●	○	0340
2012	Liberty	PCM	●	●	●	●	●	●	●	#####
2012	Liberty	PTS	●	●	●	●	●	●	●	02ED 03B7
2012	Liberty	WCM	●	●	●	●	●	○	●	01D2 0341 0228 0226 0225 0232 0230 0231 022F 01DE 0244 0081 0233 022D 0227 0274 031E 031F
2012	Challenger	EPS	●	●	●	●	●	○	○	
2012	Challenger	EOM	●	●	●	●	●	○	●	00BA 0081
2012	Challenger	HVAC	●	●	●	●	●	●	●	02E9 00EA 02EA 02EB
2012	Challenger	CCN	●	●	●	●	●	●	●	008F 008E 0382 038D 0090 0383
2012	Challenger	ADCM	●	●	●	●	●	○	○	
2012	Challenger	TPM	●	●	●	●	●	○	●	0414 0232 0230 0231 022F 0413
2012	Challenger	PCM	●	●	●	●	●	●	●	042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0405 0406 0407 040C 040E 040F 03B8 013C 012C 012D 0410 0386 02F9 03F1 03F0 03F2 012A 03E5 02FA 040D 03F5 040B 012B 0408 0409
2012	Challenger	SUNR	●	●	●	●	●	●	○	
2012	Challenger	TCM	●	●	●	●	●	○	○	038C 01F3 01F2
2012	Challenger	RADIO	●	●	●	●	●	●	●	025D 039E 039F 01BB 0475 03A0
2012	Challenger	ABS	●	●	●	●	●	●	●	0433 03AB 0081
2012	Challenger	DDM	●	●	●	●	●	●	○	0306
2012	Challenger	ESM	●	●	●	●	●	●	○	
2012	Challenger	PEM	●	●	●	●	●	○	●	0309 0370 0308 0307
2012	Challenger	SAS	●	●	●	●	●	●	○	
2012	Challenger	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 039D
2012	Challenger	HFM	●	●	●	●	●	●	○	00E3
2012	Challenger	ORC	●	●	●	●	●	○	●	02A1
2012	Challenger	TIPMCGW	●	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 0219 003D 0032 030B 0036 0037 0389 0034 0038 002E 038F 0388 0390 022D 03A2
2012	Challenger	PDM	●	●	●	●	●	●	○	0306

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2012	Challenger	HSM	●	●	●	●	●	●	●	
2012	Challenger	WCM	●	●	●	●	●	●	●	02A7 0414 01D2 0228 03E6 0232 0230 0231 022F 0413 0300 0245
2012	Charger (Post-2011)	BCM	●	●	●	●	●	●	●	0439 043C 02F1 0438 02F0 02F3 02EF 02F5 008F 03C0 003D 043B 043A 002E 038F 0390 022D
2012	Charger (Post-2011)	MSM	●	●	●	●	●	●	●	0455 0451 0454 044F 0452 0450 0453
2012	Charger (Post-2011)	ABS	●	●	●	●	●	●	●	0433 03AB 0434
2012	Charger (Post-2011)	TPM	●	●	●	●	●	○	●	0435 0458 0232 0230 0231 022F 0413 0459
2012	Charger (Post-2011)	HVAC	●	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2012	Charger (Post-2011)	AMP	●	●	●	●	●	○	○	006D 0068
2012	Charger (Post-2011)	ACC	●	●	●	●	●	○	●	0457
2012	Charger (Post-2011)	ICS	●	●	●	●	●	●	○	
2012	Charger (Post-2011)	BSM	●	●	●	●	●	○	○	0372
2012	Charger (Post-2011)	IPC	●	●	●	●	●	●	○	0456
2012	Charger (Post-2011)	HFM	●	●	●	●	●	○	○	00E3
2012	Charger (Post-2011)	PTS	●	●	●	●	●	●	●	02ED 03B7
2012	Charger (Post-2011)	TGW	●	●	●	●	●	○	○	0305 025D 0446
2012	Charger (Post-2011)	DTCM	●	●	●	●	●	●	●	
2012	Charger (Post-2011)	PDM	●	●	●	●	●	●	●	
2012	Charger (Post-2011)	SCCM	●	●	●	●	●	○	○	
2012	Charger (Post-2011)	VSIM	●	●	●	●	●	●	●	
2012	Charger (Post-2011)	DDM	●	●	●	●	●	●	●	
2012	Charger (Post-2011)	ADCM	●	●	●	●	●	○	○	
2012	Charger (Post-2011)	ORC	●	●	●	●	●	○	●	045A 02A1
2012	Charger (Post-2011)	TCM	●	●	●	●	●	○	●	047F 038C 01F3 01F2
2012	Charger (Post-2011)	PCM	●	●	●	●	●	●	●	042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0405 0406 0407 040C 040E 040F 03B8 013C 012C 012D 0410 0429 02F9 03F1 03F0 03F2 012A 03E5 02FA 040D 03F5 040B 012B 0408 0409
2012	Charger (Post-2011)	ESM	●	●	●	●	●	●	○	
2012	Charger (Post-2011)	HSM	●	●	●	●	●	●	●	
2012	Charger (Post-2011)	EPS	●	●	●	●	●	○	○	
2012	Charger (Post-2011)	RFH	●	●	●	●	●	●	●	0443 0440 0442 0444 043F 0445
2012	Charger (Post-2011)	ITM	●	●	●	●	●	●	●	0107 0437 0104 03CE 0436
2012	300 / Magnum / Charger (Pre-2011)	DTCM	●	●	●	●	●	●	●	
2012	300 / Magnum / Charger (Pre-2011)	HSM	●	●	●	●	●	●	●	
2012	300 / Magnum / Charger (Pre-2011)	PDM	●	●	●	●	●	●	●	
2012	300 / Magnum / Charger (Pre-2011)	BCM	●	●	●	●	●	●	●	0439 043C 02F1 0438 02F0 02F3 02EF 02F5 008F 03C0 003D 043B 043A 002E 038F 0390 022D

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2012	300 / Magnum / Charger (Pre-2011)	TPM	●	●	●	●	●	○	●	0435 0458 0232 0230 0231 022F 0413 0459
2012	300 / Magnum / Charger (Pre-2011)	SCCM	●	●	●	●	●	○	○	
2012	300 / Magnum / Charger (Pre-2011)	TCM	●	●	●	●	●	○	●	047F 038C 01F3 01F2
2012	300 / Magnum / Charger (Pre-2011)	HFM	●	●	●	●	●	○	○	00E3
2012	300 / Magnum / Charger (Pre-2011)	MSM	●	●	●	●	●	●	●	0455 0451 0454 044F 0452 0450 0453
2012	300 / Magnum / Charger (Pre-2011)	HVAC	●	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2012	300 / Magnum / Charger (Pre-2011)	ORC	●	●	●	●	●	○	●	045A 02A1
2012	300 / Magnum / Charger (Pre-2011)	RFH	●	●	●	●	●	●	●	0443 0440 0442 0444 0465 043F 0445
2012	300 / Magnum / Charger (Pre-2011)	BSM	●	●	●	●	●	○	○	0372
2012	300 / Magnum / Charger (Pre-2011)	ESM	●	●	●	●	●	●	○	
2012	300 / Magnum / Charger (Pre-2011)	ITM	●	●	●	●	●	●	●	0107 0437 0104 03CE 0436
2012	300 / Magnum / Charger (Pre-2011)	PCM	●	●	●	●	●	●	●	#####
2012	300 / Magnum / Charger (Pre-2011)	PTS	●	●	●	●	●	●	●	02ED 03B7
2012	300 / Magnum / Charger (Pre-2011)	EPS	●	●	●	●	●	○	○	
2012	300 / Magnum / Charger (Pre-2011)	ABS	●	●	●	●	●	●	●	0433 03AB 0434
2012	300 / Magnum / Charger (Pre-2011)	DDM	●	●	●	●	●	●	●	
2012	300 / Magnum / Charger (Pre-2011)	AMP	●	●	●	●	●	○	○	006D 0068
2012	300 / Magnum / Charger (Pre-2011)	TGW	●	●	●	●	●	○	○	0305 025D 0446
2012	300 / Magnum / Charger (Pre-2011)	ICS	●	●	●	●	●	●	○	
2012	300 / Magnum / Charger (Pre-2011)	AFLS	●	●	●	●	●	●	○	045B
2012	300 / Magnum / Charger (Pre-2011)	IPC	●	●	●	●	●	●	○	0456

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2012	300 / Magnum / Charger (Pre-2011)	ACC	●	●	●	●	●	○	●	0457
2012	300 / Magnum / Charger (Pre-2011)	ADCM	●	●	●	●	●	○	○	
2012	Compass	TCM	●	●	●	●	●	●	●	0380
2012	Compass	ITM	●	●	●	●	●	●	●	03CF 0107 0385 0106 03CE
2012	Compass	ABS	●	●	●	●	●	●	●	03AB 0002 0285 0062
2012	Compass	AWD	●	●	●	●	●	●	●	
2012	Compass	TIPMCGW	●	●	●	●	●	●	●	030D 030F 02F1 02F0 02F3 02EF 0039 030E 030C 003C 003D 0214 0032 0210 003F 003E 0036 0037 0389 0034 0038 003A 020E 0213 0215 028F 0211 038F 003B 02F4 0388 0390 03A2
2012	Compass	HVAC	●	●	●	●	●	●	●	02E9 00EA 02EA 02EB
2012	Compass	SAS	●	●	●	●	○	○	○	
2012	Compass	RADIO	●	●	●	●	●	●	●	025D 039E 039F 01BB 0475 03A0
2012	Compass	WCM	●	●	●	●	●	○	●	02A7 01D2 0228 0226 0225 0232 0230 0231 022F 0244 0233 022D 0274 031E 031F 037C
2012	Compass	HFM	●	●	●	●	●	●	○	00E3
2012	Compass	CCN	●	●	●	●	●	●	●	008C 008F 008E 0094 0092 0096 0090
2012	Compass	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 039D 0069 0303 0081
2012	Compass	ORC	●	●	●	●	●	○	●	03CC 03CD
2012	Compass	PCM	●	●	●	●	●	●	●	#####
2012	Dakota	PCM	●	●	●	●	●	●	●	042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0405 0406 0407 040C 040E 040F 03B8 013C 012C 012D 0410 0381 02F9 03F1 03F0 03F2 012A 03E5 02FA 040D 03F5 040B 012B 0408 0409
2012	Dakota	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 039D
2012	Dakota	ABS	●	●	●	●	●	●	●	0002 0285 0062
2012	Dakota	HVAC	●	●	●	●	●	●	●	00EA 00E8 00E9 02EA 02EB 0081
2012	Dakota	HFM	●	●	●	●	●	●	○	00E3
2012	Dakota	CCN	●	●	●	●	●	●	●	008F 008E 008D 0090
2012	Dakota	FCMCGW	●	●	●	●	●	●	●	02F1 02F0 02F3 02EF 0039 003C 003D 02A6 02A5 02A4 0032 0257 003E 0036 00D5 00D8 0037 0035 0034 0038 00DB 00D6 00D9 003A 0293 003B 0302 0033 00C6 0040 00DA 0272 0273
2012	Dakota	RADIO	●	●	●	●	●	●	●	025D 039E 039F 01BB 0475 03A0
2012	Dakota	ORC	●	●	●	●	○	●	○	02A1
2012	Dakota	WCM	●	●	●	●	●	○	●	01D2 0228 0226 0225 0232 0230 0231 022F 01DE 0244 0081 0233 022D 023E 0271
2012	Dakota	EOM	●	●	●	●	●	○	●	00BA
2012	Dart	OCM	●	●	●	●	●	○	●	011E

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2012	Routan	PSDMR	●	●	●	●	●	○	○	0343 0461 0462 0460 0342
2012	Routan	TPM	●	●	●	●	●	○	●	0414 0232 0230 0231 022F 0413
2012	Routan	RADIO	●	●	●	●	●	●	●	039F 0475 01BB 03A0 025D 039E
2012	Routan	PTS	●	●	●	●	●	●	●	02ED 03B7
2012	Routan	PEM	●	●	●	●	●	○	●	0443 0463 0442 0307
2012	Routan	PCM	●	●	●	●	●	●	●	03F4 02F9 03F1
2012	Routan	DVD	●	●	●	●	●	○	○	
2012	Town & Country / Caravan	DMRL	●	●	●	●	●	●	●	00B4 00B5 00B6
2012	Town & Country / Caravan	PSDMR	●	●	●	●	●	○	○	0343 0461 0462 0460 0342
2012	Town & Country / Caravan	MSMD	●	●	●	●	●	●	●	0455 0451 0450 0454 044F 0452 0453
2012	Town & Country / Caravan	CCN	●	●	●	●	●	●	●	00BC 0382 038D 0383
2012	Town & Country / Caravan	PLGM	●	●	●	●	●	●	●	038A 038B 00B4 0199 00B5 0342
2012	Town & Country / Caravan	DMFR	●	●	●	●	●	●	●	
2012	Town & Country / Caravan	TPM	●	●	●	●	●	○	●	0414 0232 0230 0231 022F 0413 0459
2012	Town & Country / Caravan	PTS	●	●	●	●	●	●	●	02ED 03B7
2012	Town & Country / Caravan	HFM	●	●	●	●	●	●	○	00E3
2012	Town & Country / Caravan	SUNR	●	●	●	●	●	●	○	
2012	Town & Country / Caravan	HVAC	●	●	●	●	●	●	●	00EA 03B9 03A9 02EB 045C 00E9 045D 045E 045F 02EA
2012	Town & Country / Caravan	ABS	●	●	●	●	●	●	●	03AB 0002 0081 0285 0062 0433
2012	Town & Country / Caravan	PCM	●	●	●	●	●	●	●	#####
2012	Town & Country / Caravan	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 0036 0037 0389 0038 003A 002E 038F 003B 02F4 0388 0390 03A1 022D 03A2
2012	Town & Country / Caravan	ORC	●	●	●	●	●	○	●	03CC 02A1 0122
2012	Town & Country / Caravan	HSM	●	●	●	●	●	●	●	0412
2012	Town & Country / Caravan	EPPM	●	●	●	●	●	○	●	047E

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2012	Town & Country / Caravan	HIDT	●	●	●	●	●	●	○	0480
2012	Town & Country / Caravan	SAS	●	●	●	●	○	○	○	
2012	Town & Country / Caravan	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 039D
2012	Town & Country / Caravan	DMFL	●	●	●	●	●	●	●	
2012	Town & Country / Caravan	ITM	●	●	●	●	●	●	●	03CF 0107 0385 0106 03CE
2012	Town & Country / Caravan	AHBM	●	●	●	●	●	○	○	03C0 00BC
2012	Town & Country / Caravan	PEM	●	●	●	●	●	○	●	0443 0463 0442 0307
2012	Town & Country / Caravan	PSDML	●	●	●	●	●	○	○	0343 0461 0462 0460 0342
2012	Town & Country / Caravan	BSM	●	●	●	●	●	○	○	0372
2012	Town & Country / Caravan	DMRR	●	●	●	●	●	●	●	00B4 00B5 00B6
2012	Town & Country / Caravan	DVD	●	●	●	●	●	○	○	
2012	Town & Country / Caravan	RADIO	●	●	●	●	●	●	●	039F 0475 01BB 03A0 025D 039E
2012	Town & Country / Caravan	WCM	●	●	●	●	●	●	●	02A7 0414 022E 01D2 03E4 0228 03E6 0232 0230 0231 022F 0413 0300 0245
2012	Town & Country / Caravan	FSM	●	●	●	●	●	●	○	03AC 03AD 0346 0347
2012	Town & Country / Caravan	VES2	●	●	●	●	●	●	●	03AE
2012	Town & Country / Caravan	TCM	●	●	●	●	●	●	●	047C 0479 047A 047B 042C 0410 024E 01FB 016F 0481 0175 01FC
2012	Town & Country / Caravan	VES3	●	●	●	●	●	●	●	
2012	Durango (Post-2011)	DMFR	●	●	●	●	●	●	●	
2012	Durango (Post-2011)	RADIO	●	●	●	●	●	●	●	039F 0475 01BB 03A0 025D 039E
2012	Durango (Post-2011)	WCM	●	●	●	●	●	●	●	02A7 0414 01D2 03E4 0228 03E6 0232 0230 0231 022F 0413 0300 0245
2012	Durango (Post-2011)	PLGM	●	●	●	●	○	●	●	00B4 00B5 038A 038B 0199
2012	Durango (Post-2011)	AHBM	●	●	●	●	○	●	○	0066
2012	Durango (Post-2011)	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 039D

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2012	Durango (Post-2011)	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0389 0038 0476 0387 038F 003B 0388 0390 03A1 022D 03A2
2012	Durango (Post-2011)	PTS	●	●	●	●	●	●	●	02ED 01B8
2012	Durango (Post-2011)	ESM	●	●	●	●	●	●	○	
2012	Durango (Post-2011)	TPM	●	●	●	●	●	○	●	0414 0232 0230 0231 022F 0413
2012	Durango (Post-2011)	ITM	●	●	●	●	●	●	●	0107 0437 03CF 03CE 0436
2012	Durango (Post-2011)	HSM	●	●	●	●	●	●	●	0412
2012	Durango (Post-2011)	HVAC	●	●	●	●	●	●	●	045C 00E9 045D 045E 045F 02EB
2012	Durango (Post-2011)	DTCM	●	●	●	●	●	●	●	0340
2012	Durango (Post-2011)	DMFL	●	●	●	●	●	●	●	
2012	Durango (Post-2011)	EPS	●	●	●	●	●	○	○	
2012	Durango (Post-2011)	MSMD	●	●	●	●	●	●	●	0455 0451 0450 0454 044F 0452 0453
2012	Durango (Post-2011)	TCM	●	●	●	●	●	○	○	038C 01F3 01F2
2012	Durango (Post-2011)	AHLM	●	●	●	●	●	●	○	0464
2012	Durango (Post-2011)	HFM	●	●	●	●	●	●	○	00E3
2012	Durango (Post-2011)	BSM	●	●	●	●	●	○	○	0372
2012	Durango (Post-2011)	ACC	●	●	●	●	●	○	○	0457 0081
2012	Durango (Post-2011)	PCM	●	●	●	●	●	●	●	042A 03F8 03FC 03F6 03F9 03FD 03F7 03FA 03FE 042B 0127 03F3 0140 0126 0411 0404 0402 0403 040A 0400 0401 0128 042C 03FB 03FF 03F4 0405 0406 0407 040C 040E 040F 03B8 013C 012C 012D 0410 0386 02F9 03F1 03F0 03F2 012A 03E5 02FA 040D 03F5 040B 012B 0408 0409
2012	Durango (Post-2011)	CCN	●	●	●	●	●	●	●	00BC 0382 038D 0383
2012	Durango (Post-2011)	ORC	●	●	●	●	●	○	●	03CC 02A1 0122
2012	Durango (Post-2011)	ABS	●	●	●	●	●	●	●	0433 03AB
2012	Durango (Post-2011)	SAS	●	●	●	●	●	●	○	
2012	Durango (Post-2011)	VES3	●	●	●	●	●	●	●	
2012	Durango (Post-2011)	PEM	●	●	●	●	●	○	●	0443 0463 0442 0307
2012	Grand Cherokee	ADCM	●	●	●	●	●	○	○	
2012	Grand Cherokee	MSMD	●	●	●	●	●	●	●	0455 0451 0450 0454 044F 0452 0453
2012	Grand Cherokee	RADIO	●	●	●	●	●	●	●	025D 039E 039F 01BB 0475 03A0
2012	Grand Cherokee	ORC	●	●	●	●	●	○	●	03CC 02A1 0122
2012	Grand Cherokee	ESM	●	●	●	●	●	●	○	
2012	Grand Cherokee	ELSD	●	●	●	●	●	●	○	0474 0473
2012	Grand Cherokee	CCN	●	●	●	●	●	●	●	00BC 0382 038D 0383
2012	Grand Cherokee	TPM	●	●	●	●	●	○	●	0414 0232 0230 0231 022F 0413
2012	Grand Cherokee	BSM	●	●	●	●	●	○	○	0372
2012	Grand Cherokee	PCM	●	●	●	●	●	●	●	#####
2012	Grand Cherokee	HFM	●	●	●	●	●	●	○	00E3
2012	Grand Cherokee	WCM	●	●	●	●	●	●	●	02A7 0414 01D2 0465 03E4 0228 03E6 0232 0230 0231 022F 0413 0081 0300 0245
2012	Grand Cherokee	ACC	●	●	●	●	●	○	○	0457 0081

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2012	Grand Cherokee	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0389 0038 0476 0387 038F 003B 0388 0390 03A1 022D 03A2
2012	Grand Cherokee	PEM	●	●	●	●	●	○	●	0443 0463 0442 0307
2012	Grand Cherokee	VES3	●	●	●	●	●	●	●	
2012	Grand Cherokee	ABS	●	●	●	●	●	●	●	0433 03AB 0081
2012	Grand Cherokee	DTCM	●	●	●	●	●	●	●	0340
2012	Grand Cherokee	AHBM	●	●	●	●	○	●	○	0066
2012	Grand Cherokee	SAS	●	●	●	●	●	●	○	
2012	Grand Cherokee	AHLM	●	●	●	●	●	●	○	0464
2012	Grand Cherokee	TCM	●	●	●	●	●	○	○	038C 01F3 01F2
2012	Grand Cherokee	HVAC	●	●	●	●	●	●	●	045C 00E9 045D 045F 02EB
2012	Grand Cherokee	PLGM	●	●	●	●	○	●	●	00B4 00B5 038A 038B 0199
2012	Grand Cherokee	EPS	●	●	●	●	●	○	○	
2012	Grand Cherokee	PTS	●	●	●	●	●	●	●	02ED 01B8
2012	Grand Cherokee	HSM	●	●	●	●	●	●	●	0412
2012	Grand Cherokee	ITM	●	●	●	●	●	●	●	0107 0437 03CF 03CE 0436 0081
2012	Grand Cherokee	ASCM	●	●	●	●	●	○	○	046E 0467 046F 0472 046A 0471 0466 0469 046B 0468 046D 046C 0470
2012	Grand Cherokee	DMFL	●	●	●	●	●	●	●	
2012	Grand Cherokee	AMP	●	●	●	●	●	○	●	006D 0079 0068 006A 039D
2012	Grand Cherokee	DMFR	●	●	●	●	●	●	●	
2013	Forza	ORC	●	●	●	●	○	●	○	
2013	Forza	IPC	●	●	●	●	○	●	○	0520 04E6
2013	Ram 3500 Pickup	PCM	●	●	●	●	●	●	●	#####
2013	Ram 3500 Pickup	DCU	●	●	●	○	○	○	○	
2013	Ram 3500 Pickup	ORC	●	●	●	●	●	●	●	02A1
2013	Ram 3500 Pickup	ITBM	●	●	●	●	●	○	○	
2013	Ram 3500 Pickup	ABS	●	●	●	●	●	●	●	0433 03AB 0434
2013	Ram 3500 Pickup	BCM	●	●	●	●	●	●	●	043C 02F1 0438 02F0 02F3 02EF 02F5 008F 03C0 003D 043B 0529 043A 002E 038F 003B 022D
2013	Ram 3500 Pickup	HSM	●	●	●	●	●	●	●	
2013	Ram 3500 Pickup	RADIO	●	●	●	●	●	●	●	
2013	Ram 3500 Pickup	EDM	●	●	●	●	●	●	○	
2013	Ram 3500 Pickup	DTCM	●	●	●	●	●	●	●	
2013	Ram 3500 Pickup	VSIM	●	●	●	●	●	●	○	
2013	Ram 3500 Pickup	TCM	●	●	●	●	●	●	●	01EF
2013	Ram 3500 Pickup	RFH	●	●	●	●	●	●	●	0443 0442 051E 0444 0463 043F 051B 052A 0445 052B 052C
2013	Ram 3500 Pickup	HVAC	●	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2013	Ram 3500 Pickup	PTS	●	●	●	●	●	●	●	02ED 03B7
2013	Ram 3500 Pickup	VGT	●	●	●	○	○	○	○	
2013	Ram 3500 Pickup	ASCM	●	●	●	●	●	○	●	052D 0466 0469 0468 046D 0470
2013	Ram 3500 Pickup	SCCM	●	●	●	●	●	○	○	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2013	Ram (Mexico)	ESM	●	●	●	●	●	○	○	
2013	Ram (Mexico)	HVAC	●	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2013	Ram (Mexico)	DCU	●	●	●	○	○	○	○	
2013	Ram (Mexico)	TPM	●	●	●	●	●	○	●	0435 0232 0230 0231 022F 0413
2013	Ram (Mexico)	PTS	●	●	●	●	●	●	●	02ED 03B7
2013	Ram (Mexico)	VGT	●	●	●	○	○	○	○	
2013	Ram (Mexico)	PDM	●	●	●	●	●	●	●	
2013	Ram (Mexico)	HSM	●	●	●	●	●	●	●	
2013	Ram (Mexico)	ORC	●	●	●	●	●	●	●	02A1
2013	Ram (Mexico)	ICS	●	●	●	●	●	●	●	
2013	500	EAC	●	●	●	●	●	○	○	
2013	500	RBC	●	●	●	●	●	○	○	0002 0533 0534 0532 0531
2013	500	BPCM	●	●	●	●	●	●	○	0537 0418 0419 0535 041D 041B 0536 0359 034E 0368 0354
2013	500	PTS	●	●	●	●	●	○	○	
2013	500	VTM	●	●	●	●	●	○	○	0538
2013	500	EPS	●	●	●	●	●	○	○	050B 050C
2013	500	ABS	●	●	●	●	●	●	○	04F5 04F4
2013	500	TPM	●	●	●	●	●	●	●	0414 0232 0230 0231 022F 0413 04F6 04F7
2013	500	ESM	●	●	●	○	●	○	○	
2013	500	EVCU	●	●	●	●	●	●	○	053C 053D 053A 0539 053E 053B
2013	500	HVAC	●	●	●	●	●	●	○	04FE
2013	500	OBCM	●	●	●	●	●	○	○	
2013	500	IPC	●	●	●	●	●	●	○	04FC 04FB 04FD 04DB 04DE
2013	500	CTM	●	●	●	●	○	●	○	04FF 0500
2013	500	RADIO	●	●	●	●	●	○	○	04F3
2013	500	PIM	●	●	●	●	●	○	○	
2013	500	PCM	●	●	●	●	●	●	●	0507 0506 012C 012D 0509 0508 050A 03E5 0504 0081 012B 0505
2013	500	ORC	●	●	●	●	●	○	●	
2013	500	BCM	●	●	●	●	●	●	●	003E 0501 043B 0502 0503
2013	500	TCM	●	●	●	●	●	●	○	04F8 04F9 044D 02BD 044E 044A 04FA 044C 01EF 044B
2013	Wrangler (Export)	CCN	●	●	●	●	●	●	○	008C 00BC 0382 0091 0094 038D 0096 0383
2013	Wrangler (Export)	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0389 0038 003A 002E 021F 038F 003B 02F4 0388 0390 03A1 022D 03A2
2013	Wrangler (Export)	WCM	●	●	●	●	●	○	●	0233 01D2 0228 04A2 0227
2013	Wrangler (Export)	ORC	●	●	●	●	●	○	●	03CC 02A1 0122 03CD
2013	Wrangler (Export)	RADIO	●	●	●	●	●	●	●	039E 01BB 025D 039F 04A1 03A0
2013	Wrangler (Export)	PCM	●	●	●	●	●	●	●	0042 012D 02BA 0428 0424 0049 0423 03E5 0427 03D2 0426 0425 031D 0447 013B
2013	Wrangler (Export)	ABS	●	●	●	●	●	●	●	03AB 0002 0285 0062
2013	Wrangler (Export)	SAS	●	●	●	●	○	○	○	
2013	Wrangler (Export)	TCM	●	●	●	●	●	○	○	038C 01F3 01F2

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2013	Freemont	HVAC	●	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2013	Freemont	PDM	●	●	●	●	●	●	●	
2013	Freemont	TPM	●	●	●	●	●	○	●	0435 0232 0230 0231 022F 0413
2013	Freemont	DTCM	●	●	●	●	●	●	●	
2013	Wrangler	SAS	●	●	●	●	○	○	○	
2013	Wrangler	ITM	●	●	●	●	●	●	●	0437 0448 03CF 0449 0436 0385
2013	Wrangler	ESM	●	●	●	●	●	●	○	
2013	Wrangler	HFM	●	●	●	●	●	●	○	00E3
2013	Wrangler	CCN	●	●	●	●	●	●	○	008C 00BC 0382 0091 0094 038D 0096 0383
2013	Wrangler	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 003F 0036 0037 0389 0038 003A 002E 021F 038F 003B 02F4 0388 0390 03A1 022D 03A2
2013	Wrangler	ASBS	●	●	●	●	●	○	○	0317 0318 031A 031B 0319
2013	Wrangler	HVAC	●	●	●	●	●	●	●	00EA 03B9 03A9 02EB
2013	Wrangler	AMP	●	●	●	●	●	○	●	006D 0068
2013	Wrangler	ORC	●	●	●	●	●	○	●	03CC 02A1 0122 03CD
2013	Wrangler	TCM	●	●	●	●	●	○	○	038C 01F3 01F2
2013	Wrangler	RADIO	●	●	●	●	●	●	●	039E 01BB 025D 04B1 039F 04A1 03A0
2013	Wrangler	ABS	●	●	●	●	●	●	●	03AB 0002 0285 0062
2013	Wrangler	PCM	●	●	●	●	●	●	●	0042 012D 02BA 0428 0424 0049 0423 03E5 0427 03D2 0426 0425 031D 0447 013B 0127 03F3 0140 0126 0411 040A 0128 03F4 03B8 013C 012C 0410 0386 02F9 03F1 03F0 03F2 012A 02FA 012B 04EE 04EF 04ED 04F1 04EC 04F2
2013	Wrangler	WCM	●	●	●	●	●	○	●	0233 01D2 0228 04A2 0227
2013	Wrangler	TPM	●	●	●	●	●	○	●	0414 0232 0230 0231 022F 0413
2013	Sebring / 200 / Avenger	HVAC	●	●	●	●	●	●	●	00EA 03B9 03A9 02EB 00E9
2013	Sebring / 200 / Avenger	CCN	●	●	●	●	●	●	●	00BC 008F 008E 0382 038D 0090 0383
2013	Sebring / 200 / Avenger	WCM	●	●	●	●	●	○	●	02A7 0233 022E 01D2 0228 04A2 0232 0230 0231 022F 0413 022D 0227
2013	Sebring / 200 / Avenger	DDM	●	●	●	●	●	●	○	0306
2013	Sebring / 200 / Avenger	AMP	●	●	●	●	●	○	●	006D 0068
2013	Sebring / 200 / Avenger	PTCM	●	●	●	●	●	○	●	0259 04A4
2013	Sebring / 200 / Avenger	TIPMCGW	●	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 030E 030C 0483 003C 003D 0214 03E7 0484 0036 02C3 0037 0389 0034 0038 003A 002E 038F 003B 02F4 0388 0390 03A2
2013	Sebring / 200 / Avenger	ORC	●	●	●	●	●	○	●	03CC

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2013	Sebring / 200 / Avenger	SAS	●	●	●	●	○	○	○	
2013	Sebring / 200 / Avenger	RADIO	●	●	●	●	●	●	●	04A1 039F 01BB 03A0 039E 025D
2013	Sebring / 200 / Avenger	PDM	●	●	●	●	●	●	○	0306
2013	Sebring / 200 / Avenger	ABS	●	●	●	●	●	●	●	03AB 0002 0485 0285 0062
2013	Sebring / 200 / Avenger	HFM	●	●	●	●	●	●	○	00E3
2013	Sebring / 200 / Avenger	PCM	●	●	●	●	●	●	●	042A 03F8 03F6 03F9 03F7 03FA 042B 0127 03F3 0140 0126 0411 0404 0402 040A 0400 0128 042C 03FB 03F4 0405 0406 040C 040E 03B8 013C 012C 012D 0410 0386 02F9 03F1 03F0 03F2 012A 03E5 02FA 040D 03F5 012B 0408 0409 04EE 04EF 04ED 04F1 04EC 04F2
2013	Liberty	PCM	●	●	●	●	●	●	●	#####
2013	Liberty	RADIO	●	●	●	●	●	●	●	039E 01BB 025D 039F 04A1 03A0
2013	Liberty	HVAC	●	●	●	●	●	●	●	00EA 00E9 03A9 02EB 03B9
2013	Liberty	FDCM	●	●	●	●	●	●	○	0340
2013	Liberty	SAS	●	●	●	●	○	○	○	
2013	Liberty	DMFR	●	●	●	●	●	●	●	
2013	Liberty	HFM	●	●	●	●	●	●	○	00E3
2013	Liberty	SUNR	●	●	●	●	●	○	○	02E6 04A7
2013	Liberty	ORC	●	●	●	●	●	○	●	03CC 03CD
2013	Liberty	PTS	●	●	●	●	●	●	●	02ED 03B7
2013	Liberty	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 003F 0036 0037 0389 0038 003A 002E 021F 038F 003B 0388 0390 03A1 03A2
2013	Liberty	ESM	●	●	●	●	●	●	○	
2013	Liberty	OCM	●	●	●	●	●	○	○	011E
2013	Liberty	TCM	●	●	●	●	●	○	○	038C 01F3 01F2
2013	Liberty	CCN	●	●	●	●	●	●	●	00BC 0382 038D 0383
2013	Liberty	ABS	●	●	●	●	●	●	●	03AB 0002 0285 0062
2013	Liberty	DMFL	●	●	●	●	●	●	●	
2013	Liberty	ITM	●	●	●	●	●	●	●	03CF 010A 0107 03AA 0106 03CE
2013	Liberty	AMP	●	●	●	●	●	○	●	006D 0068
2013	Liberty	WCM	●	●	●	●	●	○	●	0233 01D2 03E4 0341 0228 04A2 0232 0230 0231 022F 01DE 0413 022D 0227
2013	Liberty	MSMD	●	●	●	●	●	●	●	0455 0451 0450 0454 044F 0452 0453 02EE 00BC 0114 0116 0118 0117 0115 0119
2013	Challenger	CCN	●	●	●	●	●	●	●	008F 008E 0382 038D 0090 0383
2013	Challenger	PDM	●	●	●	●	●	●	○	0306

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2013	300 / Magnum / Charger (Pre-2011)	EPS	●	●	●	●	●	○	○	
2013	300 / Magnum / Charger (Pre-2011)	PDM	●	●	●	●	●	●	●	
2013	300 / Magnum / Charger (Pre-2011)	ADCM	●	●	●	●	●	○	○	
2013	300 / Magnum / Charger (Pre-2011)	ICS	●	●	●	●	●	●	○	
2013	300 / Magnum / Charger (Pre-2011)	LBSS	●	●	●	●	●	○	○	
2013	300 / Magnum / Charger (Pre-2011)	BCM	●	●	●	●	●	●	●	043C 02F1 0438 02F0 02F3 02EF 02F5 008F 03C0 003D 043B 043A 002E 038F 003B 022D
2013	300 / Magnum / Charger (Pre-2011)	SCCM	●	●	●	●	●	○	○	
2013	300 / Magnum / Charger (Pre-2011)	RFH	●	●	●	●	●	●	●	0443 0440 0442 050E 0444 0465 043F 0445 050F
2013	300 / Magnum / Charger (Pre-2011)	ABS	●	●	●	●	●	●	●	0433 03AB 0434
2013	300 / Magnum / Charger (Pre-2011)	MSM	●	●	●	●	●	●	●	0455 0451 0454 044F 0452 0450 0453
2013	300 / Magnum / Charger (Pre-2011)	HVAC	●	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2013	300 / Magnum / Charger (Pre-2011)	HSM	●	●	●	●	●	●	●	
2013	300 / Magnum / Charger (Pre-2011)	PCM	●	●	●	●	●	●	●	0431 012D 0042 0430 02BD 0049 042F 03E5 03D2 042E 0432 042D 031D 0127 03F3 0140 0126 0411 040A 0128 03F4 03B8 013C 012C 0410 0429 02F9 03F1 03F0 03F2 012A 02FA 012B 04EE 04EF 04ED 04F1 04EC 04F2
2013	300 / Magnum / Charger (Pre-2011)	AFLS	●	●	●	●	●	●	○	045B
2013	Compass	ORC	●	●	●	●	●	○	●	03CC 03CD
2013	Compass	ITM	●	●	●	●	●	●	●	03CF 0107 0385 0106 03CE
2013	Compass	TIPMCGW	●	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 030E 030C 0483 003C 003D 003F 0484 0036 0037 0389 0034 0038 003A 002E 020E 0215 028F 0211 038F 003B 02F4 0388 0390 03A2
2013	Compass	RADIO	●	●	●	●	●	●	●	04A1 039F 01BB 03A0 039E 025D
2013	Compass	AWD	●	●	●	●	●	●	●	
2013	Compass	SAS	●	●	●	●	○	○	○	
2013	Compass	ABS	●	●	●	●	●	●	●	0002 0485 0285 0062 03AB
2013	Compass	TCM	●	●	●	●	●	●	●	0380
2013	Compass	AMP	●	●	●	●	●	○	●	0069 006D 0079 0068 0303

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2013	Compass	PCM	●	●	●	●	●	●	●	04EE 04EF 0127 03F3 0140 0126 0411 040A 0128 03F4 03B8 04ED 013C 012C 012D 0410 04F1 04EC 0386 02F9 03F1 03F0 03F2 012A 03E5 02FA 012B 04F2 03E0 0149 03D0 04B2 03DD 03E3 03E2 03DE 03E1 03D3 03DF 03D9 03DA 0049 03DB 03D4 03DC 03D2 03D6 03D8 03D5
2013	Compass	CCN	●	●	●	●	●	●	●	00BC 008F 008E 0382 038D 0090 0383
2013	Compass	HFM	●	●	●	●	●	●	○	00E3
2013	Compass	HVAC	●	●	●	●	●	●	●	00EA 03B9 03A9 02EB
2013	Compass	WCM	●	●	●	●	●	○	●	02A7 0233 022E 01D2 0228 04A2 0232 0230 0231 022F 0413 022D 0227
2013	Ypsilon	ECM	●	●	●	●	●	●	●	04B8 04B9 04B6 04B7 04C1 04C2 04C3 04C4 04C5 04C9 04CA 04C7 04CE 04C6 04BF 04C8 04CD 04CB 04CC
2013	Ypsilon	ABS	●	●	●	●	○	●	●	04EA 04E9 04E7 04E8
2013	Ypsilon	EPS	●	●	●	●	○	○	●	04DA
2013	Ypsilon	AHM	●	●	●	●	●	●	○	04E1
2013	Ypsilon	HVAC	●	●	●	●	●	●	●	04CF
2013	Ypsilon	IPC	●	●	●	●	●	●	○	04DF 04E0 04DB 04DD 04DC 04DE
2013	Ypsilon	ORC	●	●	●	●	●	●	●	
2013	Ypsilon	TCM	●	●	●	●	○	●	●	04B9 04D5 04D2 04D3 04D0 04D1 04D6 04D9 04D4 04D8 04D7
2013	Ypsilon	BCM	●	●	●	●	●	●	○	04E3 04E2 04E5 04E6 04E4
2013	Dart	TCM	●	●	●	●	●	●	●	0510 044D 044E 044A 044C 01EF 044B
2013	Dart	SCCM	●	●	●	●	●	○	○	
2013	Dart	IPC	●	●	●	●	●	●	○	04B3
2013	Dart	ICS	●	●	●	●	●	●	○	
2013	Dart	CSWM	●	●	●	●	●	●	●	
2013	Dart	EDM	●	●	●	○	○	●	○	
2013	Dart	RADIO	●	●	●	●	●	●	●	
2013	Dart	AMP	●	●	●	●	●	○	○	
2013	Dart	LBSS	●	●	●	●	●	○	●	
2013	Dart	RFH	●	●	●	●	●	●	●	0443 0440 0463 0442 051F 0414 051E 0444 051B 051C 0413 051D 0445 04F7
2013	Dart	CTM	●	●	●	●	●	○	○	
2013	Dart	OCM	●	●	●	●	●	○	●	011E
2013	Dart	ORC	●	●	●	●	●	●	●	02A1
2013	Dart	BCM	●	●	●	●	●	●	●	02F1 0438 02F0 02F3 02EF 02F5 02DC 008F 008E 0219 0518 0517 0519 03E7 043B 0036 049F 0389 02DD 0503 0515 0388 0516 04A6
2013	Dart	HVAC	●	●	●	●	●	●	●	00EA 03B9 03A9 02EB
2013	Dart	PCM	●	●	●	●	●	●	●	04EE 04F0 04EF 0127 03F3 0140 0126 0411 040A 0128 03F4 03B8 04ED 013C 012C 012D 04F1 04EC 02F9 03F1 03F0 03F2 012A 03E5 02FA 012B 04F2 0511 0506 0509 050A 0504 0512
2013	Dart	RBSS	●	●	●	●	●	○	●	

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2013	Town & Country / Caravan	HFM	●	●	●	●	●	●	○	00E3
2013	Town & Country / Caravan	ABS	●	●	●	●	●	●	●	0433 03AB 0002 0485 0285 0062
2013	Town & Country / Caravan	HSM	●	●	●	●	●	●	●	0412
2013	Town & Country / Caravan	SUNR	●	●	●	●	●	●	○	
2013	Town & Country / Caravan	PCM	●	●	●	●	●	●	●	042A 03F6 03F7 042B 0127 03F3 0140 0126 0411 0404 040A 0128 042C 03F4 0405 040C 03B8 013C 012C 012D 0410 0386 02F9 03F1 03F0 03F2 012A 03E5 02FA 040D 012B 0408 0042 02BA 0428 0424 0049 0423 0427 03D2 0426 0425 031D 013B 04EE 04EF 04ED 04F1 04EC 04F2
2013	Town & Country / Caravan	DMRL	●	●	●	●	●	●	●	00B4 00B5 00B6
2013	Town & Country / Caravan	DMFL	●	●	●	●	●	●	●	
2013	Town & Country / Caravan	EPPM	●	●	●	●	●	○	●	047E
2013	Town & Country / Caravan	HIDT	●	●	●	●	●	●	○	0480
2013	Town & Country / Caravan	RBSS	●	●	●	●	●	○	○	
2013	Town & Country / Caravan	DVD	●	●	●	●	●	○	○	
2013	Town & Country / Caravan	ORC	●	●	●	●	●	○	●	03CC 02A1
2013	Town & Country / Caravan	WCM	●	●	●	●	●	●	●	02A7 0414 022E 01D2 03E4 0228 03E6 0232 0230 0231 022F 0413 0300 0245
2013	Town & Country / Caravan	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 0036 0037 0389 0038 003A 002E 038F 003B 02F4 0388 0390 03A1 022D 03A2
2013	Town & Country / Caravan	HVAC	●	●	●	●	●	●	●	045C 00E9 045D 045E 045F 02EB 00EA 03B9 02EA 03A9
2013	Town & Country / Caravan	AMP	●	●	●	●	●	○	●	006D 0068
2013	Town & Country / Caravan	ITM	●	●	●	●	●	●	●	03CF 0107 0385 0106 03CE
2013	Town & Country / Caravan	PEM	●	●	●	●	●	○	●	0443 0463 0442 0307
2013	Town & Country / Caravan	CCN	●	●	●	●	●	●	●	00BC 0382 038D 0383

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2013	Town & Country / Caravan	PSDML	●	●	●	●	●	○	○	0343 0461 04A9 0460 0342
2013	Town & Country / Caravan	DMRR	●	●	●	●	●	●	●	00B4 00B5 00B6
2013	Town & Country / Caravan	PSDMR	●	●	●	●	●	○	○	0343 0461 04A9 0460 0342
2013	Town & Country / Caravan	DMFR	●	●	●	●	●	●	●	
2013	Town & Country / Caravan	TCM	●	●	●	●	●	●	●	047C 0479 047A 047B 042C 0410 0481 0175
2013	Town & Country / Caravan	PTS	●	●	●	●	●	●	●	02ED 03B7
2013	Town & Country / Caravan	AHBM	●	●	●	●	○	●	○	0066
2013	Town & Country / Caravan	LBSS	●	●	●	●	●	○	○	
2013	Town & Country / Caravan	MSMD	●	●	●	●	●	●	●	0455 0451 0450 0454 044F 0452 0453
2013	Town & Country / Caravan	FSM	●	●	●	●	●	●	○	03AC 03AD 0346 0347
2013	Town & Country / Caravan	SAS	●	●	●	●	○	○	○	
2013	Town & Country / Caravan	PLGM	●	●	●	●	●	●	●	038A 038B 0342
2013	Town & Country / Caravan	VES3	●	●	●	●	●	●	●	
2013	Town & Country / Caravan	RADIO	●	●	●	●	●	●	●	039E 01BB 025D 039F 04A1 03A0
2013	Durango (Post-2011)	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 03E7 0036 0037 0389 0038 002E 0476 0387 038F 003B 0388 0390 03A1 022D 03A2
2013	Durango (Post-2011)	CCN	●	●	●	●	●	●	●	00BC 0382 038D 0383
2013	Durango (Post-2011)	AHBM	●	●	●	●	○	●	○	0066
2013	Durango (Post-2011)	ABS	●	●	●	●	●	●	●	0433 03AB
2013	Durango (Post-2011)	TCM	●	●	●	●	●	○	○	038C 01F3 01F2
2013	Durango (Post-2011)	MSMD	●	●	●	●	●	●	●	0455 0451 0450 0454 044F 0452 0453
2013	Durango (Post-2011)	ITM	●	●	●	●	●	●	●	0107 0437 03CF 03CE 0436
2013	Durango (Post-2011)	AHLM	●	●	●	●	●	●	○	0464
2013	Durango (Post-2011)	ESM	●	●	●	●	●	●	○	
2013	Durango (Post-2011)	DTCM	●	●	●	●	●	●	●	0340
2013	Durango (Post-2011)	DMFR	●	●	●	●	●	●	●	
2013	Durango (Post-2011)	SAS	●	●	●	●	●	●	○	
2013	Durango (Post-2011)	PLGM	●	●	●	●	○	●	●	038A 038B

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2013	Durango (Post-2011)	RADIO	●	●	●	●	●	●	●	039E 01BB 025D 039F 04A1 03A0
2013	Durango (Post-2011)	PTS	●	●	●	●	●	●	●	02ED 03B7
2013	Durango (Post-2011)	HSM	●	●	●	●	●	●	●	0412
2013	Durango (Post-2011)	WCM	●	●	●	●	●	●	●	02A7 0414 01D2 03E4 0228 03E6 0232 0230 0231 022F 0413 0300 0245
2013	Durango (Post-2011)	BSM	●	●	●	●	●	○	○	0372
2013	Durango (Post-2011)	PCM	●	●	●	●	●	●	●	03FC 03FD 03FE 0127 03F3 0140 0126 0411 0403 040A 0128 03FF 03F4 0407 040F 03B8 013C 012C 012D 0410 0386 02F9 03F1 03F0 03F2 012A 03E5 02FA 040B 012B 042A 03F8 03F6 03F9 03F7 03FA 042B 0404 0402 0400 0401 042C 03FB 0405 0406 040C 040E 040D 03F5 0408 0409
2013	Durango (Post-2011)	TPM	●	●	●	●	●	○	●	0414 0232 0230 0231 022F 0413
2013	Durango (Post-2011)	ACC	●	●	●	●	●	○	○	0576
2013	Durango (Post-2011)	DMFL	●	●	●	●	●	●	●	
2013	Durango (Post-2011)	ORC	●	●	●	●	●	○	●	03CC 02A1 0122
2013	Durango (Post-2011)	HVAC	●	●	●	●	●	●	●	045C 00E9 045D 045E 045F 02EB
2013	Durango (Post-2011)	EPS	●	●	●	●	●	○	○	
2013	Durango (Post-2011)	PEM	●	●	●	●	●	○	●	0443 0463 0442 0307
2013	Durango (Post-2011)	HFM	●	●	●	●	●	●	○	00E3
2013	Durango (Post-2011)	VES3	●	●	●	●	●	●	●	
2013	Durango (Post-2011)	AMP	●	●	●	●	●	○	●	006D 0068
2013	Grand Cherokee	AHLM	●	●	●	●	●	●	○	0464
2013	Grand Cherokee	ADCM	●	●	●	●	●	○	○	
2013	Grand Cherokee	ASCM	●	●	●	●	●	○	○	046E 0467 046F 0472 046A 0471 0466 0469 046B 0468 046D 046C 0470
2013	Grand Cherokee	HFM	●	●	●	●	●	●	○	00E3
2013	Grand Cherokee	AMP	●	●	●	●	●	○	●	006D 0068
2013	Grand Cherokee	ITM	●	●	●	●	●	●	●	0107 0437 03CF 03CE 0436
2013	Grand Cherokee	EPS	●	●	●	●	●	○	○	
2013	Grand Cherokee	VES3	●	●	●	●	●	●	●	
2013	Grand Cherokee	ORC	●	●	●	●	●	○	●	03CC 02A1 0122
2013	Grand Cherokee	WCM	●	●	●	●	●	●	●	02A7 0414 01D2 0465 03E4 0228 03E6 0232 0230 0231 022F 0413 0300 0245
2013	Grand Cherokee	DMFL	●	●	●	●	●	●	●	
2013	Grand Cherokee	MSMD	●	●	●	●	●	●	●	0455 0451 0450 0454 044F 0452 0453
2013	Grand Cherokee	ACC	●	●	●	●	●	○	○	0576
2013	Grand Cherokee	ABS	●	●	●	●	●	●	●	0433 03AB
2013	Grand Cherokee	RADIO	●	●	●	●	●	●	●	039E 01BB 025D 039F 04A1 03A0
2013	Grand Cherokee	SAS	●	●	●	●	●	●	○	
2013	Grand Cherokee	BSM	●	●	●	●	●	○	○	0372
2013	Grand Cherokee	HVAC	●	●	●	●	●	●	●	045C 00E9 045D 045F 02EB
2013	Grand Cherokee	PEM	●	●	●	●	●	○	●	0443 0463 0442 0307

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2013	Grand Cherokee	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 03E7 0036 0037 0389 0038 002E 0476 0387 038F 003B 0388 0390 03A1 022D 03A2
2013	Grand Cherokee	DTCM	●	●	●	●	●	●	●	0340
2013	Grand Cherokee	PCM	●	●	●	●	●	●	●	#####
2013	Grand Cherokee	ESM	●	●	●	●	●	●	○	
2013	Grand Cherokee	ELSD	●	●	●	●	●	●	○	0474 0473
2013	Grand Cherokee	PTS	●	●	●	●	●	●	●	02ED 03B7
2013	Grand Cherokee	HSM	●	●	●	●	●	●	●	0412
2013	Grand Cherokee	TCM	●	●	●	●	●	○	○	038C 01F3 01F2
2013	Grand Cherokee	AHBM	●	●	●	●	○	●	○	0066
2013	Grand Cherokee	DMFR	●	●	●	●	●	●	●	
2013	Grand Cherokee	CCN	●	●	●	●	●	●	●	00BC 0382 038D 0383
2013	Grand Cherokee	PLGM	●	●	●	●	○	●	●	038A 038B
2013	Grand Cherokee	TPM	●	●	●	●	●	○	●	0414 0232 0230 0231 022F 0413
2013	Viper (Post-2013)	RFH	●	●	●	●	●	●	●	0440 0442 0444 043F 0445
2013	Viper (Post-2013)	HVAC	●	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2013	Viper (Post-2013)	PDM	●	●	●	●	●	●	●	
2013	Viper (Post-2013)	DDM	●	●	●	●	●	●	●	
2013	Viper (Post-2013)	IPC	●	●	●	●	●	●	●	04B3
2013	Viper (Post-2013)	BCM	●	●	●	●	●	●	●	043C 02F1 0438 02F0 02F3 02EF 02F5 008F 003D 043B 043A 038F 003B 022D
2013	Viper (Post-2013)	OCM	●	●	●	●	●	○	○	011E
2013	Viper (Post-2013)	RADIO	●	●	●	●	●	●	●	
2013	Viper (Post-2013)	ADCM	●	●	●	●	●	○	○	
2013	Viper (Post-2013)	ABS	●	●	●	●	●	●	●	
2013	Viper (Post-2013)	TPM	●	●	●	●	●	○	●	0435 0232 0230 0231 022F 0413
2013	Viper (Post-2013)	ORC	●	●	●	●	●	●	●	02A1
2013	Viper (Post-2013)	AMP	●	●	●	●	●	○	○	006D 0068
2013	Viper (Post-2013)	SCCM	●	●	●	●	●	○	○	
2013	Viper (Post-2013)	ICS	●	●	●	●	●	●	●	
2013	Viper (Post-2013)	PCM	●	●	●	●	●	●	○	013E 0411 0193 04AC 04AB 012C 012D 0429 04AA 012A 0540 03E5 012B 03F4
2014	Fiat 500L	TPM	●	●	●	●	●	●	●	0414 0232 0230 0231 022F 0413 04F6 04F7
2014	Fiat 500L	EPS	●	●	●	●	●	○	○	04DA
2014	Fiat 500L	ESM	●	●	●	●	●	●	●	
2014	Fiat 500L	BCM	●	●	●	●	●	●	●	04E3 0544 0543 04E2 04E5 0541 04E6 04E4 0542
2014	Fiat 500L	IPC	●	●	●	●	○	●	○	04FC 04FB
2014	Fiat 500L	ETM	●	●	●	●	●	○	●	0545
2014	Fiat 500L	PAM	●	●	●	●	●	○	○	0547 0546
2014	Fiat 500L	HVAC	●	●	●	●	●	●	○	04FE
2014	Fiat 500L	ORC	●	●	●	●	●	○	●	
2014	Fiat 500L	TCM	●	●	●	●	●	●	●	04F8 04F9 044D 044E 044A 044C 01EF 044B

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2014	Ram 4500/5500	VGT	●	●	●	○	○	○	○	
2014	Ram 4500/5500	ITBM	●	●	●	●	●	○	○	
2014	Ram 4500/5500	HSM	●	●	●	●	●	●	●	
2014	Ram 4500/5500	PCM	●	●	●	●	●	●	●	#####
2014	Ram 4500/5500	ORC	●	●	●	●	●	●	●	02A1
2014	Ram 4500/5500	DCU	●	●	●	○	○	○	○	
2014	Ram 4500/5500	TCM	●	●	●	●	●	●	●	01EF
2014	Ram 4500/5500	RADIO	●	●	●	●	●	●	●	
2014	Ram 4500/5500	SCCM	●	●	●	●	●	○	○	
2014	Ram 4500/5500	PDM	●	●	●	●	●	●	●	
2014	Ram 4500/5500	ICS	●	●	●	●	●	●	●	
2014	Ram 4500/5500	RFH	●	●	●	●	●	●	●	0443 0442 051E 0444 0463 043F 051B 051D 052A 0445 0414 052B 052C
2014	Ram 4500/5500	ABS	●	●	●	●	●	●	●	0433 03AB 0434
2014	Ram 4500/5500	VSIM	●	●	●	●	●	●	○	
2014	Ram 4500/5500	BCM	●	●	●	●	●	●	●	043C 02F1 0438 02F0 02F3 02EF 02F5 008F 003D 043B 043A 002E 0553 038F 003B 022D 03C0 0529
2014	Ram 4500/5500	DTCM	●	●	●	●	●	●	●	
2014	Ram 4500/5500	HVAC	●	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2014	Ram 4500/5500	IPC	●	●	●	●	●	●	○	04B3 0456 0530
2014	Ram 1500	MSM	●	●	●	●	●	●	●	0455 0451 0454 044F 0452 0450 0453
2014	Ram 1500	EPS	●	●	●	●	●	○	○	050B
2014	Ram 1500	EDM	●	●	●	●	●	●	○	
2014	Ram 1500	SCCM	●	●	●	●	●	○	○	
2014	Ram 1500	HSM	●	●	●	●	●	●	●	
2014	Ram 1500	RADIO	●	●	●	●	●	●	●	
2014	Ram 1500	ICS	●	●	●	●	●	●	●	
2014	Ram 1500	HVAC	●	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2014	Ram 1500	ESM	●	●	●	●	●	○	○	
2014	Ram 1500	PCM	●	●	●	●	●	●	●	#####
2014	Ram 1500	ABS	●	●	●	●	●	●	●	0433 03AB 0434
2014	Ram 1500	ASCM	●	●	●	●	●	○	●	046E 052D 046A 0466 0469 0468 046D 046C 0470
2014	Ram 1500	PDM	●	●	●	●	●	●	●	
2014	Ram 1500	DTCM	●	●	●	●	●	●	●	
2014	Ram 1500	ITBM	●	●	●	●	●	○	○	
2014	Ram 1500	ORC	●	●	●	●	●	●	●	02A1
2014	Ram 1500	AMP	●	●	●	●	●	○	○	006D 0068
2014	Ram 1500	PTS	●	●	●	●	●	●	●	02ED 03B7
2014	Ram 1500	RFH	●	●	●	●	●	●	●	0443 0442 051E 0444 0463 043F 051B 051D 052A 0445 0414 052B 052C
2014	Ram 1500	DDM	●	●	●	●	●	●	●	
2014	Ram 1500	TCM	●	●	●	●	●	○	●	047F
2014	Ram 1500	BCM	●	●	●	●	●	●	●	043C 02F1 0438 02F0 02F3 02EF 02F5 008F 003D 043B 043A 002E 0553 038F 003B 022D 03C0 0529

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2014	Ram 1500	IPC	●	●	●	●	●	●	○	04B3 0456
2014	Ram (Mexico)	ESM	●	●	●	●	●	○	○	
2014	Ram (Mexico)	HSM	●	●	●	●	●	●	●	
2014	Ram (Mexico)	AMP	●	●	●	●	●	○	○	006D 0068
2014	Ram (Mexico)	PCM	●	●	●	●	●	●	●	#####
2014	Ram (Mexico)	IPC	●	●	●	●	●	●	○	04B3 0456
2014	Ram (Mexico)	EDM	●	●	●	●	●	●	○	
2014	Ram (Mexico)	ASCM	●	●	●	●	●	○	●	046E 052D 046A 0466 0469 0468 046D 046C 0470
2014	Ram (Mexico)	VSIM	●	●	●	●	●	●	○	
2014	Ram (Mexico)	ITBM	●	●	●	●	●	○	○	
2014	Ram (Mexico)	BCM	●	●	●	●	●	●	●	043C 02F1 0438 02F0 02F3 02EF 02F5 008F 03C0 003D 043B 0529 043A 002E 038F 003B 022D 0553
2014	Ram (Mexico)	PTS	●	●	●	●	●	●	●	02ED 03B7
2014	Ram (Mexico)	PDM	●	●	●	●	●	●	●	
2014	Ram (Mexico)	DDM	●	●	●	●	●	●	●	
2014	Ram (Mexico)	VGT	●	●	●	○	○	○	○	
2014	Ram (Mexico)	SCCM	●	●	●	●	●	○	○	
2014	Ram (Mexico)	ABS	●	●	●	●	●	●	●	0433 03AB 0434
2014	Ram (Mexico)	TCM	●	●	●	●	●	●	●	047F 01EF
2014	Ram (Mexico)	ORC	●	●	●	●	●	●	●	02A1
2014	Ram (Mexico)	ICS	●	●	●	●	●	●	●	
2014	Ram (Mexico)	HVAC	●	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2014	Ram (Mexico)	DTCM	●	●	●	●	●	●	●	
2014	Ram (Mexico)	RADIO	●	●	●	●	●	●	●	
2014	Ram (Mexico)	DCU	●	●	●	○	○	○	○	
2014	Ram (Mexico)	MSM	●	●	●	●	●	●	●	0455 0451 0454 044F 0452 0450 0453
2014	Ram (Mexico)	EPS	●	●	●	●	●	○	○	050B
2014	Ram (Mexico)	RFH	●	●	●	●	●	●	●	0443 0442 051E 0444 0463 043F 051B 051D 052A 0445 0414 052B 052C
2014	500	PTS	●	●	●	●	●	○	○	
2014	500	ORC	●	●	●	●	●	○	●	
2014	500	BCM	●	●	●	●	●	●	●	003E 0501 043B 0502 0503
2014	500	PIM	●	●	●	●	●	○	○	
2014	500	VTM	●	●	●	●	●	○	○	0538
2014	500	RBC	●	●	●	●	●	○	○	0002 0533 0534 0532 0531
2014	500	ABS	●	●	●	●	●	●	○	04F5 04F4
2014	500	TPM	●	●	●	●	●	●	●	0414 0232 0230 0231 022F 0413 04F6 04F7
2014	500	PCM	●	●	●	●	●	●	●	0507 0506 012C 012D 0509 0508 050A 03E5 0504 0081 012B 0505
2014	500	CTM	●	●	●	●	○	●	○	04FF 0500
2014	500	IPC	●	●	●	●	●	●	○	04FC 04FB 04FD 04DB 04DE
2014	500	RADIO	●	●	●	●	●	○	○	04F3
2014	500	OBCM	●	●	●	●	●	○	○	
2014	500	EVCU	●	●	●	●	●	●	○	053C 053D 053A 0539 053E 053B

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2014	Freemont	BCM	●	●	●	●	●	●	●	043C 02F1 0438 02F0 02F3 02EF 02F5 008F 03C0 003D 043B 043A 002E 038F 003B 022D
2014	Freemont	AMP	●	●	●	●	●	○	○	006D 0068
2014	Freemont	PTS	●	●	●	●	●	●	●	02ED 03B7
2014	Freemont	ITM	●	●	●	●	●	●	●	0107 0437 0104 03CE 0436
2014	Freemont	VTM	●	●	●	●	●	○	○	
2014	Freemont	TCM	●	●	●	●	●	●	●	047C 0479 047A 047B 042C 0410 047D 0175
2014	Freemont	HFM	●	●	●	●	●	○	○	00E3
2014	Freemont	DTCM	●	●	●	●	●	●	●	
2014	Freemont	HVAC	●	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2014	Freemont	SCCM	●	●	●	●	●	○	○	
2014	Freemont	ORC	●	●	●	●	●	○	●	03CC 02A1 0122
2014	Freemont	TPM	●	●	●	●	●	○	●	0435 0232 0230 0231 022F 0413
2014	Freemont	EPPM	●	●	●	●	●	○	●	047E
2014	Freemont	PCM	●	●	●	●	●	●	●	#####
2014	Freemont	ABS	●	●	●	●	●	●	●	0433 03AB 0434
2014	Freemont	TGW	●	●	●	●	●	○	○	0305 025D 050D 0446
2014	Freemont	PDM	●	●	●	●	●	●	●	
2014	Freemont	DDM	●	●	●	●	●	●	●	
2014	Freemont	VES3	●	●	●	●	●	●	○	
2014	Freemont	IPC	●	●	●	●	●	●	○	04B3
2014	Freemont	HSM	●	●	●	●	●	●	●	
2014	Freemont	RFH	●	●	●	●	●	●	●	0443 0440 0442 050E 0441 0444 043F 0445 050F
2014	Wrangler	AMP	●	●	●	●	●	○	●	006D 0068
2014	Wrangler	TPM	●	●	●	●	●	○	●	0414 0232 0230 0231 022F 0413
2014	Wrangler	CCN	●	●	●	●	●	●	○	008C 00BC 0382 0091 0094 038D 0096 0383
2014	Wrangler	PCM	●	●	●	●	●	●	●	04EE 04EF 0127 03F3 0140 0126 0411 040A 0128 03F4 03B8 04ED 013C 012C 012D 04EC 0551 0386 02F9 03F1 03F0 03F2 012A 03E5 02FA 054E 012B 0042 02BA 0428 0424 0049 0423 0427 03D2 0426 0425 031D 0447 013B
2014	Wrangler	WCM	●	●	●	●	●	○	●	0233 01D2 0228 04A2 0227
2014	Wrangler	HVAC	●	●	●	●	●	●	●	00EA 03B9 03A9 02EB
2014	Wrangler	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 0036 0037 0389 0038 002E 038F 003B 0388 0390 03A1 022D 03A2
2014	Wrangler	RADIO	●	●	●	●	●	●	●	04A1 039F 01BB 03A0 039E 025D 04B1
2014	Wrangler	SAS	●	●	●	●	○	○	○	
2014	Wrangler	TCM	●	●	●	●	●	○	○	038C 01F3 01F2
2014	Wrangler	ASBS	●	●	●	●	●	○	○	0317 0318 031A 031B 0319
2014	Wrangler	ABS	●	●	●	●	●	●	●	03AB 0002
2014	Wrangler	HFM	●	●	●	●	●	●	○	00E3
2014	Wrangler	ORC	●	●	●	●	●	○	●	03CC 02A1 0122 03CD
2014	Wrangler	ESM	●	●	●	●	●	●	○	
2014	Wrangler	ITM	●	●	●	●	●	●	●	0437 0448 03CF 0449 0436 0385

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2014	Liberty	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 003F 0036 0037 0389 0038 003A 002E 021F 038F 003B 0388 0390 03A1 03A2
2014	Liberty	ESM	●	●	●	●	●	●	○	
2014	Liberty	AMP	●	●	●	●	●	○	●	006D 0068
2014	Liberty	RADIO	●	●	●	●	●	●	●	039E 01BB 025D 039F 04A1 03A0
2014	Liberty	MSMD	●	●	●	●	●	●	●	0455 0451 0450 0454 044F 0452 0453 02EE 00BC 0114 0116 0118 0117 0115 0119
2014	Liberty	HVAC	●	●	●	●	●	●	●	00EA 03B9 03A9 02EB 00E9
2014	Liberty	DMFR	●	●	●	●	●	●	●	
2014	Liberty	SAS	●	●	●	●	○	○	○	
2014	Liberty	FDCM	●	●	●	●	●	●	○	0340
2014	Liberty	PCM	●	●	●	●	●	●	●	#####
2014	Liberty	OCM	●	●	●	●	●	○	○	011E
2014	Liberty	DMFL	●	●	●	●	●	●	●	
2014	Cherokee	AMP	●	●	●	●	●	○	○	
2014	Cherokee	ICS	●	●	●	●	●	●	●	
2014	Cherokee	ESL	●	●	●	●	●	○	●	
2014	Cherokee	BCM	●	●	●	●	●	●	●	02F1 0438 02F0 02F3 02EF 02F5 02DC 008F 008E 0219 0517 0519 03E7 0561 043B 0036 049F 0389 02DD 0228 0503 0515 0388 0516 04A6
2014	Cherokee	IPC	●	●	●	●	●	●	○	04B3
2014	Cherokee	PLGM	●	●	●	●	●	○	○	0562
2014	Cherokee	PTU	●	●	●	○	○	○	○	
2014	Cherokee	LBSS	●	●	●	●	●	○	●	
2014	Cherokee	TCM	○	○	○	○	○	○	○	0564 0563
2014	Cherokee	OCM	●	●	●	●	●	○	●	011E
2014	Cherokee	PDM	●	●	●	●	●	●	●	
2014	Cherokee	DDM	●	●	●	●	●	●	●	
2014	Cherokee	PCM	●	●	●	●	●	●	●	04EF 0127 03F3 0140 0126 0411 040A 0128 03F4 04ED 013C 012C 012D 04F1 04EC 0551 02F9 03F1 03F0 03F2 012A 03E5 054E 012B 04F2 0550 0430 0565 0567 0049 042F 0566 042E 042D 031D
2014	Cherokee	HVAC	●	●	●	●	●	●	●	00EA 03B9 03A9 02EB
2014	Cherokee	DTCM	●	●	●	●	○	●	●	0568 0569 056A
2014	Cherokee	RDM	●	●	●	○	○	○	○	
2014	Cherokee	EDM	●	●	●	○	○	●	○	
2014	Cherokee	ORC	●	●	●	●	●	●	●	02A1
2014	Cherokee	ABS	●	●	●	●	●	○	●	0433 0513
2014	Cherokee	MSM	●	●	●	●	●	○	○	
2014	Cherokee	ACC	●	●	●	●	●	○	●	056B
2014	Cherokee	SCCM	●	●	●	●	●	●	○	
2014	Cherokee	EPB	●	●	●	●	●	○	●	056C 056D
2014	Cherokee	RFH	●	●	●	●	●	●	●	0443 0463 0442 056E 0444 043F 051D 0445 04F7

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2014	Cherokee	AHLM	●	●	●	●	○	○	○	029F
2014	Cherokee	RADIO	●	●	●	●	●	●	●	
2014	Cherokee	FFCM	●	●	●	●	●	○	●	056F
2014	Cherokee	PAM	●	●	●	●	●	●	●	
2014	Cherokee	RBSS	●	●	●	●	●	○	●	
2014	Cherokee	EPS	●	●	●	●	●	○	○	051A
2014	Cherokee	CSWM	●	●	●	●	●	●	●	
2014	Cherokee	ESM	●	●	●	●	●	○	○	
2014	Challenger	SAS	●	●	●	●	●	●	○	
2014	Challenger	SUNR	●	●	●	●	●	●	○	
2014	Challenger	ADCM	●	●	●	●	●	○	○	
2014	Challenger	DDM	●	●	●	●	●	●	○	0306
2014	Challenger	PDM	●	●	●	●	●	●	○	0306
2014	Challenger	HSM	●	●	●	●	●	●	●	
2014	Challenger	WCM	●	●	●	●	●	●	●	02A7 0414 01D2 03E4 0228 03E6 0232 0230 0231 022F 0413 0300 0245
2014	Challenger	AMP	●	●	●	●	●	○	●	006D 0068
2014	Challenger	ESM	●	●	●	●	●	●	○	
2014	Challenger	PCM	●	●	●	●	●	●	●	04EE 04EF 0127 03F3 0140 0126 0411 040A 0128 03F4 03B8 04ED 013C 012C 012D 04EC 0551 0386 02F9 03F1 03F0 03F2 012A 03E5 02FA 054E 012B
2014	Challenger	TPM	●	●	●	●	●	○	●	0414 0232 0230 0231 022F 0413
2014	Challenger	EPS	●	●	●	●	●	○	○	
2014	Challenger	PTS	●	●	●	●	●	○	●	02ED
2014	Challenger	EOM	●	●	●	●	●	○	●	00BC
2014	Challenger	HVAC	●	●	●	●	●	●	●	00EA 03B9 03A9 02EB
2014	Challenger	ORC	●	●	●	●	●	○	●	02A1
2014	Challenger	CCN	●	●	●	●	●	●	●	008F 008E 0382 038D 0090 0383
2014	Challenger	PEM	●	●	●	●	●	○	●	0443 0463 0442 0307
2014	Challenger	ABS	●	●	●	●	●	●	●	0433 03AB
2014	Challenger	HFM	●	●	●	●	●	●	○	00E3
2014	Challenger	TCM	●	●	●	●	●	○	○	038C 01F3 01F2
2014	Challenger	TIPMCGW	●	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 0219 003D 0032 0036 0037 0389 0038 002E 038F 003B 0388 0390 022D 03A2
2014	Challenger	RADIO	●	●	●	●	●	●	●	039E 01BB 025D 039F 04A1 03A0
2014	Charger (Post-2011)	PDM	●	●	●	●	●	●	●	
2014	Charger (Post-2011)	TCM	●	●	●	●	●	○	●	038C 01F3 01F2 047F
2014	Charger (Post-2011)	ADCM	●	●	●	●	●	○	○	
2014	Charger (Post-2011)	DDM	●	●	●	●	●	●	●	
2014	Charger (Post-2011)	RFH	●	●	●	●	●	●	●	0443 0440 0442 050E 04B4 0444 043F 0445 050F
2014	Charger (Post-2011)	VSIM	●	●	●	●	●	●	●	
2014	Charger (Post-2011)	EPS	●	●	●	●	●	○	○	
2014	Charger (Post-2011)	ABS	●	●	●	●	●	●	●	0433 03AB 0434
2014	Charger (Post-2011)	ITM	●	●	●	●	●	●	●	0107 0437 0104 03CE 0436

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2014	300 / Magnum / Charger (Pre-2011)	SCCM	●	●	●	●	●	○	○	
2014	300 / Magnum / Charger (Pre-2011)	HFM	●	●	●	●	●	○	○	00E3
2014	300 / Magnum / Charger (Pre-2011)	ITM	●	●	●	●	●	●	●	0107 0437 0104 03CE 0436
2014	300 / Magnum / Charger (Pre-2011)	ADCM	●	●	●	●	●	○	○	
2014	300 / Magnum / Charger (Pre-2011)	PTS	●	●	●	●	●	●	●	02ED 03B7
2014	300 / Magnum / Charger (Pre-2011)	DTCM	●	●	●	●	●	●	●	
2014	300 / Magnum / Charger (Pre-2011)	ORC	●	●	●	●	●	○	●	045A 02A1
2014	300 / Magnum / Charger (Pre-2011)	MSM	●	●	●	●	●	●	●	0455 0451 0454 044F 0452 0450 0453
2014	300 / Magnum / Charger (Pre-2011)	IPC	●	●	●	●	●	●	○	04B3 0456
2014	300 / Magnum / Charger (Pre-2011)	ACC	●	●	●	●	●	○	●	0576
2014	300 / Magnum / Charger (Pre-2011)	HVAC	●	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2014	300 / Magnum / Charger (Pre-2011)	DDM	●	●	●	●	●	●	●	
2014	300 / Magnum / Charger (Pre-2011)	RBSS	●	●	●	●	●	○	○	
2014	300 / Magnum / Charger (Pre-2011)	RFH	●	●	●	●	●	●	●	0443 0440 0442 050E 0444 0465 043F 0445 050F
2014	300 / Magnum / Charger (Pre-2011)	HSM	●	●	●	●	●	●	●	
2014	300 / Magnum / Charger (Pre-2011)	AFLS	●	●	●	●	●	●	○	045B
2014	300 / Magnum / Charger (Pre-2011)	PCM	●	●	●	●	●	●	●	04EE 04EF 0127 03F3 0140 0126 0411 040A 0128 03F4 03B8 04ED 013C 012C 012D 04EC 0551 0429 02F9 03F1 03F0 03F2 012A 03E5 02FA 054E 012B 0431 0042 0430 02BD 0049 042F 03D2 042E 0432 042D 031D
2014	300 / Magnum / Charger (Pre-2011)	TGW	●	●	●	●	●	○	○	0305 025D 050D 0446
2014	Compass	TIPMCGW	●	●	●	●	●	●	●	02F1 02F0 02F3 02EF 02DC 030E 030C 0483 003C 003D 0484 0036 0037 0389 0034 0038 003A 002E 038F 003B 0388 0390 03A2
2014	Compass	ABS	●	●	●	●	●	●	●	0002 0485 0285 0062 03AB
2014	Compass	HFM	●	●	●	●	●	●	○	00E3

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2014	Town & Country / Caravan	RBSS	●	●	●	●	●	○	○	
2014	Town & Country / Caravan	HSM	●	●	●	●	●	●	●	0412
2014	Town & Country / Caravan	ORC	●	●	●	●	●	○	●	03CC 02A1
2014	Town & Country / Caravan	PSDML	●	●	●	●	●	○	○	0343 0461 04A9 0460 0342
2014	Town & Country / Caravan	DMRR	●	●	●	●	●	●	●	00B4 00B5 00B6
2014	Town & Country / Caravan	EPPM	●	●	●	●	●	○	●	047E
2014	Town & Country / Caravan	DMFL	●	●	●	●	●	●	●	
2014	Town & Country / Caravan	PTS	●	●	●	●	●	●	●	02ED 03B7
2014	Town & Country / Caravan	DMRL	●	●	●	●	●	●	●	00B4 00B5 00B6
2014	Town & Country / Caravan	VES3	●	●	●	●	●	●	●	
2014	Town & Country / Caravan	PSDMR	●	●	●	●	●	○	○	0343 0461 04A9 0460 0342
2014	Town & Country / Caravan	RADIO	●	●	●	●	●	●	●	04A1 039F 01BB 03A0 039E 025D
2014	Town & Country / Caravan	CCN	●	●	●	●	●	●	●	00BC 0382 038D 0383
2014	Town & Country / Caravan	DMFR	●	●	●	●	●	●	●	
2014	Town & Country / Caravan	SUNR	●	●	●	●	●	●	○	
2014	Town & Country / Caravan	HIDT	●	●	●	●	●	●	○	0480
2014	Town & Country / Caravan	TPM	●	●	●	●	●	○	●	0414 0232 0230 0231 022F 0413 0459
2014	Town & Country / Caravan	DVD	●	●	●	●	●	○	○	
2014	Town & Country / Caravan	HVAC	●	●	●	●	●	●	●	00EA 03B9 03A9 02EB 02EA 045C 00E9 045D 045E 045F
2014	Town & Country / Caravan	TCM	●	●	●	●	●	●	●	047C 0479 047A 047B 042C 0410 0481 0175
2014	Town & Country / Caravan	MSMD	●	●	●	●	●	●	●	0455 0451 0450 0454 044F 0452 0453

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2014	Town & Country / Caravan	PCM	●	●	●	●	●	●	●	0042 012D 02BA 0428 0424 0049 0423 03E5 0427 03D2 0426 0425 031D 013B 042A 03F6 03F7 042B 04EE 04EF 0127 03F3 0140 0126 0411 0404 040A 0128 042C 03F4 0405 040C 03B8 04ED 013C 012C 0410 04EC 0551 0386 02F9 03F1 03F0 03F2 012A 02FA 040D 054E 012B 0408
2014	Town & Country / Caravan	SAS	●	●	●	●	○	○	○	
2014	Town & Country / Caravan	TIPMCGW	●	●	●	●	●	●	●	02F1 02F2 02F0 02F3 02EF 02F5 02DC 030E 030C 008F 008E 0219 003D 0032 0036 0037 0389 0038 003A 002E 038F 003B 0388 0390 03A1 022D 03A2
2014	Town & Country / Caravan	FSM	●	●	●	●	●	●	○	03AC 03AD 0346 0347
2014	Town & Country / Caravan	HFM	●	●	●	●	●	●	○	00E3
2014	Town & Country / Caravan	AMP	●	●	●	●	●	○	●	006D 0068
2014	Town & Country / Caravan	VES2	●	●	●	●	●	●	●	03AE
2014	Town & Country / Caravan	LBSS	●	●	●	●	●	○	○	
2014	Town & Country / Caravan	AHBM	●	●	●	●	○	●	○	0066
2014	Town & Country / Caravan	ITM	●	●	●	●	●	●	●	03CF 0107 0385 0106 03CE
2014	ProMaster	ABS	●	●	●	●	●	○	●	04E7 04E8 04EA 04E9
2014	ProMaster	HVAC	●	●	●	●	●	●	○	04FE 0571
2014	ProMaster	PAM	●	●	●	●	●	○	○	0547 0546
2014	ProMaster	TPM	●	●	●	●	●	●	●	0414 0232 0230 0231 022F 0413 04F6 04F7
2014	ProMaster	BCM	●	●	●	●	●	●	●	0544 0501 04E2 04E4
2014	ProMaster	PCM	●	●	●	●	●	●	●	#####
2014	ProMaster	TCM	●	●	●	●	○	●	●	044D 02BD 044E 044A 044C 01EF 044B
2014	ProMaster	IPC	●	●	●	●	●	●	○	04FC 04FB
2014	ProMaster	ETM	●	●	●	●	●	○	●	0545
2014	ProMaster	ORC	●	●	●	●	●	○	●	
2014	Durango (Post-2011)	PCM	●	●	●	●	●	●	●	055F 0149 055C 055B 0431 012D 0430 0560 0049 03E5 03DC 03D2 055E 055D 0432 0559 042D 055A 0555 0554 0558 0556 0557 031D 04EE 04EF 0127 03F3 0140 0126 0411 040A 0128 03F4 03B8 04ED 013C 012C 04EC 0551 0429 02F9 03F1 03F0 03F2 012A 02FA 054E 012B
2014	Durango (Post-2011)	RFH	●	●	●	●	●	●	●	0443 0440 0442 050E 0444 043F 0445 050F
2014	Durango (Post-2011)	PTS	●	●	●	●	●	●	●	02ED 03B7
2014	Durango (Post-2011)	PLGM	●	●	●	●	●	●	○	0562

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2014	Durango (Post-2011)	BCM	●	●	●	●	●	●	●	043C 02F1 0438 02F0 02F3 02EF 02F5 008F 003D 043B 0529 043A 002E 038F 003B 022D 03C0
2014	Durango (Post-2011)	ITM	●	●	●	●	●	●	●	0107 0437 0104 03CE 0436
2014	Durango (Post-2011)	HVAC	●	●	●	●	●	●	●	00EA
2014	Durango (Post-2011)	ORC	●	●	●	●	●	○	●	03CC 045A 02A1
2014	Durango (Post-2011)	DTCM	●	●	●	●	●	●	●	0340
2014	Durango (Post-2011)	ICS	●	●	●	●	●	●	○	
2014	Durango (Post-2011)	EDM	●	●	●	●	●	●	○	
2014	Durango (Post-2011)	EPS	●	●	●	●	●	○	○	050B
2014	Durango (Post-2011)	ELSD	●	●	●	●	●	●	○	0474 0473
2014	Durango (Post-2011)	AMP	●	●	●	●	●	○	○	006D 0068
2014	Durango (Post-2011)	VES2	●	●	●	●	●	●	○	
2014	Durango (Post-2011)	DDM	●	●	●	●	●	●	●	
2014	Durango (Post-2011)	HVACR	●	●	●	●	●	●	●	00EA
2014	Durango (Post-2011)	HSM	●	●	●	●	●	●	●	
2014	Durango (Post-2011)	LBSS	●	●	●	○	●	○	○	
2014	Durango (Post-2011)	ACC	●	●	●	●	●	○	○	056B
2014	Durango (Post-2011)	VES3	●	●	●	●	●	●	○	
2014	Durango (Post-2011)	PDM	●	●	●	●	●	●	●	
2014	Durango (Post-2011)	ESM	●	●	●	●	●	○	○	
2014	Durango (Post-2011)	MSM	●	●	●	●	●	●	●	0455 0451 0454 044F 0452 0450 0453
2014	Durango (Post-2011)	SCCM	●	●	●	●	●	○	●	
2014	Durango (Post-2011)	IPC	●	●	●	●	●	●	●	04B3 0456
2014	Durango (Post-2011)	AHLM	●	●	●	●	●	○	○	029F
2014	Durango (Post-2011)	TPM	●	●	●	●	●	○	●	0435 0232 0230 0231 022F 0413
2014	Durango (Post-2011)	ABS	●	●	●	●	●	●	●	0433 03AB 0434
2014	Durango (Post-2011)	FFCM	●	●	●	●	●	○	○	056F
2014	Durango (Post-2011)	TCM	●	●	●	●	●	○	●	047F
2014	Durango (Post-2011)	RADIO	●	●	●	●	●	●	●	
2014	Durango (Post-2011)	RBSS	●	●	●	○	●	○	○	
2014	Grand Cherokee	VES3	●	●	●	●	●	●	○	
2014	Grand Cherokee	EDM	●	●	●	●	●	●	○	
2014	Grand Cherokee	ABS	●	●	●	●	●	●	●	0433 03AB 0434
2014	Grand Cherokee	HVAC	●	●	●	●	●	●	●	00EA
2014	Grand Cherokee	AFLS	●	●	●	●	●	●	●	045B
2014	Grand Cherokee	RFH	●	●	●	●	●	●	●	0443 0440 0442 050E 0444 0465 043F 0445 050F
2014	Grand Cherokee	ASCM	●	●	●	●	●	○	●	046E 052D 046A 0466 0469 0468 046D 046C 0470
2014	Grand Cherokee	PDM	●	●	●	●	●	●	●	
2014	Grand Cherokee	LBSS	●	●	●	○	●	○	○	
2014	Grand Cherokee	PCM	●	●	●	●	●	●	●	04EE 04EF 0127 03F3 0140 0126 0411 040A 0128 03F4 03B8 04ED 013C 012C 012D 04EC 0551 0429 02F9 03F1 03F0 03F2 012A 03E5 02FA 054E 012B 0149 055C 055B 0431 0430 0560 0049 03DC 03D2 055D 0432 0559 042D 055A 0555 0554 0558 0556 0557 031D

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2014	Grand Cherokee	ORC	●	●	●	●	●	○	●	03CC 045A 02A1
2014	Grand Cherokee	PLGM	●	●	●	●	●	●	○	0562
2014	Grand Cherokee	TCM	●	●	●	●	●	○	●	047F
2014	Grand Cherokee	ACC	●	●	●	●	●	○	○	056B
2014	Grand Cherokee	SCCM	●	●	●	●	●	○	●	
2014	Grand Cherokee	BCM	●	●	●	●	●	●	●	043C 02F1 0438 02F0 02F3 02EF 02F5 008F 003D 043B 0529 043A 002E 038F 003B 022D 03C0
2014	Grand Cherokee	PTS	●	●	●	●	●	●	●	02ED 03B7
2014	Grand Cherokee	ESM	●	●	●	●	●	○	○	
2014	Grand Cherokee	DTCM	●	●	●	●	●	●	●	0340
2014	Grand Cherokee	HSM	●	●	●	●	●	●	●	
2014	Grand Cherokee	MSM	●	●	●	●	●	●	●	0455 0451 0454 044F 0452 0450 0453
2014	Grand Cherokee	ADCM	●	●	●	●	●	○	○	
2014	Grand Cherokee	DDM	●	●	●	●	●	●	●	
2014	Grand Cherokee	AMP	●	●	●	●	●	○	○	006D 0068
2014	Grand Cherokee	RADIO	●	●	●	●	●	●	●	
2014	Grand Cherokee	ICS	●	●	●	●	●	●	○	
2014	Grand Cherokee	EPS	●	●	●	●	●	○	○	
2014	Grand Cherokee	FFCM	●	●	●	●	●	○	○	056F
2014	Grand Cherokee	RBSS	●	●	●	○	●	○	○	
2014	Grand Cherokee	ELSD	●	●	●	●	●	●	○	0474 0473
2014	Grand Cherokee	IPC	●	●	●	●	●	●	●	04B3 0456
2014	Grand Cherokee	TPM	●	●	●	●	●	○	●	0435 0232 0230 0231 022F 0413
2014	Grand Cherokee	ITM	●	●	●	●	●	●	●	0107 0437 0104 03CE 0436
2014	Grand Cherokee	VES2	●	●	●	●	●	●	○	
2014	Viper (Post-2013)	IPC	●	●	●	●	●	●	●	04B3
2014	Viper (Post-2013)	OCM	●	●	●	●	●	○	○	011E
2014	Viper (Post-2013)	PDM	●	●	●	●	●	●	●	
2014	Viper (Post-2013)	ADCM	●	●	●	●	●	○	○	
2014	Viper (Post-2013)	ABS	●	●	●	●	●	●	●	
2014	Viper (Post-2013)	BCM	●	●	●	●	●	●	●	043C 02F1 0438 02F0 02F3 02EF 02F5 008F 003D 043B 043A 038F 003B 022D
2014	Viper (Post-2013)	RFH	●	●	●	●	●	●	●	0440 0442 0444 043F 0445
2014	Viper (Post-2013)	AMP	●	●	●	●	●	○	○	006D 0068
2014	Viper (Post-2013)	ORC	●	●	●	●	●	●	●	02A1
2014	Viper (Post-2013)	ICS	●	●	●	●	●	●	●	
2014	Viper (Post-2013)	TPM	●	●	●	●	●	○	●	0435 0232 0230 0231 022F 0413
2014	Viper (Post-2013)	PCM	●	●	●	●	●	●	○	013E 0411 0193 04AC 04AB 012C 012D 0429 04AA 012A 0540 03E5 012B 03F4
2014	Viper (Post-2013)	HVAC	●	●	●	●	●	●	●	00EA 03B9 02EA 02EB
2014	Viper (Post-2013)	RADIO	●	●	●	●	●	●	●	
2014	Viper (Post-2013)	DDM	●	●	●	●	●	●	●	
2014	Viper (Post-2013)	SCCM	●	●	●	●	●	○	○	
2015	Cherokee	DTCM	●	●	●	●	○	●	●	0568 0569 056A

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
2015	Cherokee	PTU	●	●	●	○	○	○	○	
2015	Cherokee	RBSS	●	●	●	●	●	○	●	
2015	Cherokee	AHLM	●	●	●	●	○	○	○	029F
2015	Cherokee	BCM	●	●	●	●	●	●	●	02F1 0438 02F0 02F3 02EF 02F5 02DC 008F 008E 0219 0517 0519 03E7 0561 043B 0036 049F 0389 02DD 0228 0503 0515 0388 0516 04A6
2015	Cherokee	ICS	●	●	●	●	●	●	●	
2015	Cherokee	ABS	●	●	●	●	●	○	●	0433 0513
2015	Cherokee	SCCM	●	●	●	●	●	●	○	
2015	Cherokee	EPS	●	●	●	●	●	○	○	051A
2015	Cherokee	PLGM	●	●	●	●	●	○	○	0562
2015	Cherokee	ACC	●	●	●	●	●	○	●	056B
2015	Cherokee	PDM	●	●	●	●	●	●	●	
2015	Cherokee	DDM	●	●	●	●	●	●	●	
2015	Cherokee	AMP	●	●	●	●	●	○	○	
2015	Cherokee	ESM	●	●	●	●	●	○	○	
2015	Cherokee	RADIO	●	●	●	●	●	●	●	
2015	Cherokee	PAM	●	●	●	●	●	●	●	
2015	Cherokee	CSWM	●	●	●	●	●	●	●	
2015	Cherokee	OCM	●	●	●	●	●	○	●	011E
2015	Cherokee	LBSS	●	●	●	●	●	○	●	
2015	Cherokee	MSM	●	●	●	●	●	○	○	
2015	Cherokee	ORC	●	●	●	●	●	●	●	02A1
2015	Cherokee	IPC	●	●	●	●	●	●	○	04B3
2015	Cherokee	HVAC	●	●	●	●	●	●	●	00EA 03B9 03A9 02EB
2015	Cherokee	TCM	○	○	○	○	○	○	○	0564 0563
2015	Cherokee	FFCM	●	●	●	●	●	○	●	056F
2015	Cherokee	PCM	●	●	●	●	●	●	●	04EF 0127 03F3 0140 0126 0411 040A 0128 03F4 04ED 013C 012C 012D 04EC 0551 02F9 03F1 03F0 03F2 012A 03E5 054E 012B 04F2 0430 0565 0567 0049 042F 0566 042E 042D 031D 0550
2015	Cherokee	EDM	●	●	●	○	○	●	○	
2015	Cherokee	RFH	●	●	●	●	●	●	●	0443 0463 0442 056E 0444 043F 051D 0445 04F7
2015	Cherokee	RDM	●	●	●	○	○	○	○	
2015	Cherokee	EPB	●	●	●	●	●	○	●	056C 056D

Specil_Function

Index	Specil Function Name	Index	Specil Function Name
0001	Calibrate G-Sensor	0481	Quicklearn (62TE - PCM Var16)
0002	Bleed Brakes	03DB	Mass Airflow Sensor Replace
0003	Drive Test	0520	Engine Oil Change Lamp Reset
0004	AEHM Actuate Heater Booster	0501	Erase and Program Keys
0005	Gauge Sweep Test	0522	Quicklearn RFE
0006	Speaker Test	0528	Dual Alternator Enable / Disable
0007	CCN Display Dimmer Test	0523	DEF Reductant Doser Prime Override Test
0008	CCN LCD Display Test	0524	DEF Reductant Doser Pump Override Test
0009	Oil Change Reset	052F	Enable / Disable PTO Types
000A	Personalize with Electronic Ignition Switch	052E	PTO Single Speed RPM
000B	Auto Door Re-Lock	0511	Air-Conditioning Self-Learning
000C	Unlock All Doors on 1st Press	0515	Restore BCM Proxi Configuration
000D	Flash Turn Signals with Door Lock	0517	Enable Auto Highbeam
000E	Program EIS CGW VIN	0519	Enable the One Press All Unlock Feature
000F	ESM Shift Lever Test	0516	Sound Horn on Remote Start
0012	Learn Motor	0500	CTM Proxi Configuration
0013	Reset ORC	0532	RBC Sensor Calibration
0014	ORC Initialize ECU	0534	PTS Calibration
0015	PSM Reset ECU	0526	DEF (Reductant) Pressure Line Heater Test
0016	Power Roof Module Normalize Sunroof	047F	Reset Adaptive Values
0017	Power Roof Module Rain Light Sensor Learn	0510	Clear Learned Values
0018	TCM Reset Learned Adaptives	051C	Program Ignition FOBs Keyless Go System
0019	Trailer Module ECU Initialization	051D	Program Tire Sensor Identifications
001A	Left Front Tire Pressure Signal Transmission Test	050D	ROW Map Configuration
001B	Left Rear Tire Pressure Signal Transmission Test	053F	Write Pinion Factor
001C	Right Front Tire Pressure Signal Transmission Test	050E	Clear Multi-Module VIN Handshake Immobilizer Failure
001D	Right Rear Tire Pressure Signal Transmission Test	050F	View Recent Multi-Module VIN Handshake Immobilizer Failures
001E	Check/Write VIN	0506	Brake Switch Learn
0020	Reset Adaptive Memory	050B	Clear Steering Pull Compensation
0021	Throttle Valve Initialization	050C	Initialize EPS
0022	Fuel Pump Activation	0505	Throttle Body Self Learning
0023	Engine ECU Replaced (Drive Authorization)	0504	Reset Accelerator Pedal Adaptives
0024	Camshaft Reference Adaptation	0507	Air-Conditioning Self Learning
0025	O2 Sensor Monitor Test	0502	Initialize Power Top
0027	Radio NCV3 Tone Test	0535	High Voltage Battery Precharge Contactor Test
0028	Radio Most Bus Connectivity	0537	Enable/Disable HV Battery Contactors
0029	Radio Volume Balance Fade Test	0536	Isolation Fault Reset
002A	Replace Steering Column Lock	02DD	Illuminated Approach Time
002B	Program New Ignition Key FOB	049F	Headlamp Delay Time
002C	Erase All Keys and Program New Ignition Key FOB	0518	Compass Calibration
002E	Program Tire Size	04AE	Quicklearn (PCM RFE Transmission)
002F	Bleed Brakes ABS only	03C1	Reset Regen Filter Timers
0030	Bleed Brakes 2WD	03C6	VG Turbocharger Cleaning Procedure
0031	Bleed Brakes 4WD	03C8	Oil Change Monitor Type
0032	Disable Radio Clock Display	03A8	Update Light Load Pressure Thresholds DH
0033	Sound Horn On Lock	0359	Replace BPCM
0034	Horn Chirp Duration	03BF	BPCM Battery Data Report
0035	Headlamps On With Wipers	0350	Hybrid Battery Contactor Test
0036	Flash Hazard Lamps On Lock	034D	TPIM Cooling Fan Actuation
0037	Headlamps Delay Time	02C5	Battery Pack Fan Test
0038	Illuminated Entry Time	018D	Check Vin
0039	Accessory Time Delay	0304	Engine On Odometer
003A	Program Network Configuration	0351	HVIL Operating Status
003B	Restore Vehicle Configuration	041A	Hybrid Battery Precharge Contactor Test
003C	Add Navigation Radio	02FA	New Engine Installed
003D	Change Country Code	03A7	Update Heavy Load Pressure Thresholds DH
003E	Enable Front Fog Lamp Output	02E9	AC Cool Down Test
003F	Enable DRL	0301	SDAR Subscription Verification
0040	Trailer Tow Relay Outputs	034E	Reset Active Discharge Fault
0041	Radio Initialization	053D	Check EVCU VIN

Index	Specil Function Name	Index	Specil Function Name
0042	Compression Test	039D	Channel Output Test
0043	Exhaust Throttle Plate Adaptive Learn	047C	1st Gear Clutch Test 62TE
0044	Injector Kill System Test	036A	Hybrid Trans Start/Stop
0045	Diesel Particulate Filter (New) Initialization	0443	Door Handle Verification Test
0046	Diesel Particulate Filter (Used) Learning	0440	Immobilizer Antenna Test
0049	Injector Quantity Adjustment	03F7	3rd Gear Clutch Test (62TE)
004A	ECU Auto Replacement	0508	Clutch Pedal Learn
004B	Radio Display Test	053C	Accelerator Pedal Learn
004C	ECU Manual Replacement	050A	Emissions Rolls Test Mode
004E	View Electronic TPM ID	04A4	Rear Window Movement
0058	Bleed Brakes:LX	038C	Initialize EGS
0059	Bleed Brakes:WK	0309	Location of the Learned Keys
005A	Cycle Stop Lamp Relay	03CE	Ultrasonic Motion Detection Test
005B	Initialize Steering Angle Sensor	03E2	HPV Electrical Circuit Test
005C	Initialize ESP Module:LX	03E0	Compression Test (Engine NOT Running)
005D	Initialize ESP Module:WK	03DD	Fuel Rail Pressure Control Test
005E	Initialize ABS Module	0370	PEM Door Handle Verification Test
005F	Initialize ESP Module:WK-Non ESP	03E3	High Pressure Fuel Rail Test (Engine Running)
0060	Initialize ESP Module:PT	0447	Stop Start Confirmation
0062	Initialize ESP Sensor	041E	Constrain Battery Power Limits
0064	ACC Cutout Reasons Clear	04FC	IPC Disable Seatbelt Minder Chime
0065	Align ACC Sensor	04FB	IPC Enable Seatbelt Minder Chime
0066	Aim Test	00DF	Bleed DHS
0067	AHBM Self Test	04FE	Self Learning Motor Test
0068	AMP Software Test	02ED	System Wiring Test
0069	AMP Channel Output Channel Test	042C	Reverse Gear Clutch Test (62TE)
006A	AMP Tone Test	03B7	Configure License Plate Size
006B	AMP Mute Channel:6 Channel	0377	Adaptation Reset
006C	AMP Mute Channel:8 Channel	0376	Power Sliding Door Operation
006D	AMP Input Test	0342	Ramp Van Configuration
0073	AMP Mute Channel:7 Channel	0435	Sensor Rolls Test
0079	AMP Multiple Mute Channel	0429	Enable Emissions Rolls Test Mode (PowerNet)
007D	Program Tire Size:CS	0450	Standardization
007E	Enable FCM/IPM Diagnostics	0451	MSMD Self Test
0081	Reset ECU	0198	Close Door
008C	CCN Self Test	03FF	Reverse Gear Clutch Test (RFE)
008D	Disable Seatbelt Minder Chime	04AF	Engine Warm Up
008E	Auto Door Unlock	0407	Shift Lever Position Test (RFE)
008F	Auto Door Lock	03F4	Set Engine RPM
0090	Unlock Driver Door On 1st Press	03CB	Idle Shutdown Timer Adjustment
0091	Change Measurement Units	0491	Enable / Disable Vehicle Features
0092	Measurement Unit	044E	Hydraulic Circuit depressurization
0094	Language Preference	03CC	Activate Driver and Passenger Head Restraint
0096	Seatbelt Alert System	044A	Learn Clutches Contact Point
0097	CCN Gauge Test	040E	Thermistor Test (Non-RFE)
0098	Service Interval - Gas	0455	Actuate Seat Recall
0099	Service Interval - Diesel	044B	Reset of Data group
00AC	Mirror Position Test	0403	Neutral Gate Test (RFE)
00B4	Latch Cinch Test	0432	Reset Oil Change Indicator
00B5	Latch Release Test	0433	ABS Bleed Brakes
00B6	Learn Latch Sector Home	0570	ABS Valve Calibration
00BA	EOM Self Test	03B9	HVAC Cool Down Test
00BC	Self Test	0325	LDP Forced Monitor Test
00C4	Enable Cruise Control	03D4	New DPF Initialize
00C6	Tip Start Override	042B	4th Gear Clutch Test (62TE)
00C8	Police VTA	04B3	IPC Self Test
00C9	Program Tire Size:ND	0444	Erase Ignition FOBIKs
00D5	HB and HG:Enable DRL	04E4	PROXI alignment procedure
00D6	ND:Enable DRL	04EA	Longitudinal and Lateral sensor calibration
00D8	HB and HG:Program Tire Size	04E7	Static Test
00D9	ND:Program Tire Size	04E9	Longitudinal and Lateral sensor decalibration
00DA	WK and XK:Program Tire Size	0461	Sliding Door Close Test
00DB	ND:Enable Cruise Control	04E8	Wheel speed sensor type test
00E3	HFM Self Test	0343	Actuate Drive Clutch Engage
00E5	Calibrate HIFT Module	03D9	Engine ECU Replacement
00E8	Actuator DTC Detection	03FC	1st Gear Clutch Test (RFE)
00E9	Cool Down Test	03FE	3rd Gear Clutch Test (RFE)
00EA	Actuator Calibration Test	0372	Sensor Connectivity and HMI Test

Index	Specil Function Name	Index	Specil Function Name
00EB	Actuator Calibration Test DR	03ED	DEF (Reductant) Doser Prime Override Test
00EC	HVAC Self Test	054C	Engine Idle Shutdown Timer Adjustment
0104	ITM Siren Test	0400	Overdrive Switch Test (Non-RFE)
0105	ITM Ultrasonic Test	03FB	Reverse Gear Clutch Test (Non-RFE)
0106	ITM Initialize Siren	040C	Thermistor Test (62TE)
0107	ITM and Siren Communication Test	0405	Shift Lever Position Test (62TE)
010D	Initialize Optical Paths	03CF	Siren Test
0114	Drive All Motors	0193	Leak detection pump test
0115	Standardization Routine	02F9	Exhaust Phaser 1 Cleaning
0116	Easy Entry/Exit Feature	0326	View Adaptive Numerator Status
0117	Key Fobs Linked to Memory Feature	0379	PTO RPM Adjustment
0118	HB Disable Tilt Mirrors in Reverse	037A	EVR Enable/Disable
0119	Tilt Mirrors in Reverse Feature	03B8	VVT System Test
011E	OCM System Verification Test	0401	Overdrive Switch Test (RFE)
0122	Rollover Detection	0430	DPF Reset Option
0126	ETC Throttle Follower Test	03BD	High Voltage Battery Pack Under Voltage Recovery
0127	EGR System Test	036C	High Voltage Battery Charge
0128	Purge Vapors System Test	0368	Reset High Voltage Impact Event
0129	NVLD Forced Monitor Test	03BE	Regen Brake Control
012A	Learn ETC	0362	View Hybrid Commanded Engine Status
012B	Reset Memory	036E	View Strong Hybrid Limp In Status
012C	Check PCM Odometer	0361	View Battery Pack Information
012D	Check PCM VIN	0364	View ESMR Battery Usage History
012E	Set RPM Test - ETC Equipped	0369	Trans Aux Pump Speed
012F	Set RPM Test - non - ETC Equipped	036D	Transmission Motor Control
013B	TIPM Enable Emissions Rolls Test Mode	0382	Change Language Preference
013C	Cam Crank Relearn	03C3	View/Reset DPF After Treatment Over Temp Events
013E	ETC System Test	04EC	Coolant Three Way Valve Replaced
0140	ESIM Forced Monitor Test	04B8	Self-adaptive parameters reset
0141	GENERATOR FULL FIELD TEST	0416	Check TCM VIN
0142	Cylinder Fuel Quantity Correction Test	03A1	Unlock All Doors First Press
0144	Program Variant Code	0470	Write Suspension Height Values
0145	Set RPM System Test	03E5	Midtronics Warranty Code Validation
0146	NOx Catalyst(New) Initialization	03FA	3rd Gear Clutch Test (Non-RFE)
0147	NOx Catalyst(Used) Learning	03F3	Electric Vacuum Pump Test
0148	IMA Rapid Calibration	03F9	2nd Gear Clutch Test (Non-RFE)
0149	Cylinder Balance Test	03E7	Enable/Disable DRL
014A	Fuel Mean Value Adaptation Initialization	03F6	2nd Gear Clutch Test (62TE)
014B	Exhaust Throttle Plate Adaptive Learn Position	03F8	1st Gear Clutch Test (Non-RFE)
014D	Manual Diesel Particulate Filter Regeneration	0442	Locate Learned Keys
014F	VIEW/RESET DUTY CYCLE ACCUMULATORS	0425	Request Anti-Slugging For Air Condition Compressor
0150	Set RPM System Test - Automatic Transmission	0415	Trans Adapt Reset Trigger
0151	Set RPM System Test - Manual Transmission	0417	Trans Cleaning Procedure
0152	VIEW/RESET TRIP INFORMATION ACCUMULATORS	0305	Anti-Theft Override Test
0153	TORQUE CONVERTER CLUTCH TEST	0428	Fuel Mean Value Adaption Initialization
0154	FUEL PRESSURE OVERRIDE - Automatic Transmission	0422	Check APM VIN
0155	FUEL PRESSURE OVERRIDE - Manual Transmission	0421	Secondary Air Service Test
0156	CYLINDER PERFORMANCE TEST - Automatic Transmission	0420	High Voltage Contactor Circuit
0157	CYLINDER PERFORMANCE TEST - Manual Transmission	041F	Check HCP VIN
0158	IDLE UP FEATURE ENABLE	0426	Rail Pressure Control Switchover
0159	TVA SPAN TEST	0423	Lambda Sensor 1 Initialization
015A	TVA AUTO ZERO TEST	0424	IMA Quick Calibration
0166	1st Gear Clutch Test:RWD	0352	View Battery Monitoring Information
0167	1st Gear Clutch Test:FWD	0354	Reset Weld Check Fault
0169	2nd Gear Clutch Test:RWD	0355	View Isolation Test Results
016A	2nd Gear Clutch Test:FWD	0356	View Hybrid Battery Reasons Contactor Not Closing When Commanded
016B	3rd Gear Clutch Test:RWD	0357	View Stored Reasons Contactor Not Closing When Commanded
016C	3rd Gear Clutch Test:FWD	0358	View Stored Hybrid Battery Reasons Contactors Opened
016D	Reverse Gear Clutch Test:RWD	034B	EVAP Temp Target Speed
016E	Reverse Gear Clutch Test:FWD	034A	Aux Heater Coolant Pump Temp Test
016F	Quick Learn:RFE	0360	Replace TCM
0170	Quick Learn:NOT_RFE	03BA	HEV Telltale Actuators

Index	Specil Function Name	Index	Specil Function Name
0172	Shift Lever Position Test:RFE	035A	Abs System Calibration
0173	FCM Enable Emissions Rolls Test Mode	036F	View HV Charge Mode Status and Amp Hours of Algorithm Charge
0175	TCC Break-In	035C	Trans Adapts Reset Trigger
0176	Overdrive Switch Test	04C0	Oil change
0177	Clear Variable Line Pressure (VLP) Counters	03BB	Vacuum Pump Rezero
0178	Reset NOx Adsorber Counts	04CD	sensor and/or catalytic convertor replacement
0179	Reset Pressure limiting Valve Accumulators	04CB	Supercharging system components replacement
017A	Reset Aftertreatment Trip Information	04C8	Rpm sensor and/or timing chain replacement
017B	Enable / Disable Vehicle Features:cc	04C9	Control unit Replacement / Reprogramming
0199	Latch Home Sector Test	042D	Reset Zero Fuel Quantity Calibration
01B3	Sensor Versions	03C9	View/Reset NAC After Treatment Over Temp Events
01B4	Sensor Functional Test	03C4	View/Reset Duty Cycle Maps
01B5	Sensor Wiring Test	03C5	View Freeze Frame Data
01B8	Configure PTS	045C	Actuator Calibration
01BB	Radio Tone Test	0411	Injector Kill Test
01BC	Radio Dealership Mode	0546	tow hook exclusion
01C8	Tone Test	03C2	View/Reset DOC After Treatment Over Temp Events
01D2	Erase All Ignition Keys	035D	Trans Fast Learn Trigger
01DA	WCM TPM Sensor Test	0551	Cooled EGR H-Bridge Valve System Test
01DE	Program Spare Tire Sensor ID	03D5	VGT Learn
01EE	2 Prime Gear Clutch Test	0353	View Battery Warranty Information
01EF	Quick Learn	03E1	Injector Circuit Test
01F0	Shift Lever Position Test:NON RFE	034C	Resolver Offset Learn Trigger Test
01F1	Clear Variable Line Pressure (VLP)	03DE	IMV Electrical Circuit Test
01F2	Store Learned Adaptives	03DF	Engine Coolant System Air Purge
01F3	Reset Learned Adaptives	03D0	EGR/ECU Self Test
01F4	Initialize EGS-52	03D3	DPF Regeneration
01F5	CVT Initialization	04FF	Audio System Test
01F6	Enable or Disable Mobile PTO	04DF	Disable seat belts reminder
01FB	Quick Learn:Non-RFE	04E2	Exit Logistic Mode
01FC	Thermistor Test	04C1	Reset adaptative parameter
020E	Program Tire Size:DR	03EE	View/Reset DEF (Reductant) Doser Purge Count Reset
0210	DR Restore Customer Preference	03EF	Set PTO Max Vehicle Speed
0211	PT Restore Customer Preference	041D	HV Battery Balance Test
0212	Program Tire Size:PT	043F	Program Ignition FOBIKs
0213	Program Tire Size:JS	03CA	View TPM Light Load Inflation Pressure Data
0214	Combined Rear Lighting	03EC	DEF (Reductant) Tank Heater Test
0215	Program Tire Size:PM or MK	03BC	ABS System Calibration
0219	Auto Wipers	046F	System Pressure Measurement
021D	Unlock All Doors 1st Press	0471	Enable/Disable Air Suspension for ITM
021E	Program Tire Size:JK	0472	Configure Suspension Type
021F	Program Tire Size:KA	046A	Disable Level Control
0225	Program Ignition Keys or Key FOBs:SKIM	0363	Transmission Auxiliary Pump Test
0226	Program Ignition Keys or Key FOBs:RKEONLY	035F	Transmission Cleaning Procedure
0227	WCM Replaced	0365	Enable Jump Assist Mode
0228	PCM Replaced	035E	Trans Line Pressure
022D	Update Pressure Thresholds	037C	WCM Replaced TPM
022E	ELV Replaced	03DC	O2 Sensor Replace
022F	Program Right Rear Tire Sensor ID	03D7	Used DPF Initialize
0230	Program Left Rear Tire Sensor ID	03D6	Swirl Control Learn
0231	Program Right Front Tire Sensor ID	03D8	Throttle Valve Learn
0232	Program Left Front Tire Sensor ID	03D2	Program Variant Coding
0233	TPM Trigger Module Test	0439	Auto High Beam Demo Mode Test
023D	WCM Replaced 1	0438	View Last VTA Trigger Cause Data
023E	WCM Replaced 2	03C0	Auto High Beam Aim Test
023F	PCM Replaced SRT-10 Only	0437	ITM Self Test
0240	PCM Replaced 1.6L Only	0449	Ultrasonic Self Test
0241	WCM Gateway Replaced	043C	Display LIN Part Numbers and Serial Numbers
0242	DR WCM Replaced SCI	0446	TGW Tone Test
0243	PT WCM Replaced SCI	044D	Bleed Hydraulic Circuit
0244	Program Tire Sensor ID w/TPM Tool	0436	Initialize Siren
0245	WIN Replaced	0550	Clear Engine Auto Restart Crank Counter
0247	Tire Pressure ECU Replacement with Manual Initialization	04B1	JK Enable HFM
0249	Power Roof Module Anti-Theft Alarm System Horn	047D	Quicklearn (62TE - PCM Var17)
024A	AGW Initialization	0538	VTM transport mode status

Index	Specil Function Name	Index	Specil Function Name
024E	Overdrive Switch Test:RFE	04BF	Phonic wheel replacement
0257	DVD Player/Video Settings	0544	Collect Immobilizer Data
0258	Load Coding	0525	Alternator(s) Test
0259	Manual Top Movement	04F8	Clear Self Learning Data
025A	Right Rear Window Movment	04FA	Learn long acceleration Signal
025B	Left Rear Window Movment	04F7	Update Front and Rear Axle Nominal Tire Pressure Values
025D	Enable/Disable Front Seat Video	045E	Rear Blower State
025E	1st Gear Clutch Test:RFE	0453	Tilt Mirrors in Reverse
025F	1st Gear Clutch Test:NonRFE	0452	Key Fobs Linked to Memory
0260	2 Prime Gear Clutch Test:RFE	0458	Activate TPM High Gain Mode
0261	2nd Gear Clutch Test:RFE	0456	Disable/Enable Seatbelt Minder Chime
0262	2nd Gear Clutch Test:NonRFE	045A	View Satellite Sensor Information
0263	3rd Gear Clutch Test:RFE	0380	TCM Initialization
0264	3rd Gear Clutch Test:NonRFE	045B	AFLS Calibration
0265	Reverse Gear Clutch Test:RFE	04B7	Startup with CODE CARD
0266	Reverse Gear Clutch Test:NonRFE	04B6	Deactivation of the Power Limitation function
0269	TCC BreakIn	04BA	Replacement of variable geometry turbo and/or turbo position sensor
026A	PTCM Reset ECU	04F9	Neutral Position Self-Learning
026C	O2 Heater System Test:1bank	0367	Regulation of Low Voltage Control
026D	O2 Heater System Test:2bank	036B	Replace HCP
026E	Mass Air Flow Sensor Initialization	0479	2nd Gear Clutch Test 62TE
026F	Rail Pressure Initialization	047A	3rd Gear Clutch Test 62TE
0270	WCM Replaced Var 5 non TPM	043A	Light Rain Sensor Re-Adaption
0271	WCM Replaced Not Var 5 non TPM	043B	Exit Shipping Mode
0272	WK:Enable DRL	0462	Sliding Door Open Test
0273	XK:Enable DRL	0460	Learn Side Identifier
0274	WCM Replaced Non TPM	00E0	DHS Verification Test
0276	Mobile DeSoot - Minimum Required Soot Load	04C7	Intelligent alternator (IAM) replacement
0277	Mobile DeSoot - No Minimum Required Soot Load	04CE	Motorised throttle replacement
0278	Reset Regenerative Filter Timers	04CC	Timing sensor and/or cam replacement
027B	1st Gear Clutch Test:62TE	044F	Easy Entry/Exit
027C	2nd Gear Clutch Test:62TE	0459	TPM Sensor Position Parameter Update
027D	3rd Gear Clutch Test:62TE	0457	ACC Aim Mode \u0096 Auto Alignment
027E	Reverse Gear Clutch Test:62TE	04B9	Self-learnt functions reset
027F	AMP Mute Channel:No Channel 7	0409	TCC Break-In (Non-RFE)
0280	Neutral Gate Test:RFE	04BE	Lambda sensor replacement
0281	Neutral Gate Test:NOT RFE	04BC	Injector codes read
0285	Initialize ABS Non ESP	041C	HV Battery Open Cable Detected Fault Reset
0287	Actuator Calibration w/Rear	054E	Reset Enhanced Automatic Oil Change Indicator
0288	Actuator Calibration Front Only	054A	Max Vehicle Speed Adjustment
0289	AMP Channel Output Channel Test:6 Channel	019B	Learn Side
028A	AMP Channel Output Channel Test:8 Channel	0197	Open Door
028B	AMP Channel Output Channel Test:7 Channel	0434	Brake Pedal Calibration
028D	AMP Channel Output Channel Test:No Channel 7	0408	TCC Break-In (62TE)
028E	Program Tire Size:PT No TCM	0445	RF-HUB Replace
028F	Program Tire Size:PM or MK No TCM	0419	High Voltage Battery Positive Contactor Test
0290	Direct Gear Clutch Test:68RFE	04DD	Last service date
0291	3rd Gear Clutch Test:68RFE	04DB	IPC Replacement
0292	Enable / Disable Vehicle Features:pu	04CA	Intake manifold replacement
0293	Remote Start Override	0543	Configure Door Locks
029F	Calibrate AHLM	0483	Acutate Fuel Pump
02A1	Initialize ORC	0484	Enable/Disable Front Fog Lamp
02A4	Clear Remote Start Inhibit Reasons	0540	Learn Mis-Fire Adaptive Numerator
02A5	Clear Remote Start Abort Reasons	04AA	Leak Detection Pump (LDP) Forced Monitor
02A6	Clear Last Successful Remote Start	04AB	Throttle Follower Test
02A7	Antenna Loop Test	04F4	ABS Static Test
02AF	Actuate TracRite Unlock LED	03F5	QuickLearn (Non-RFE)
02B0	Actuate TracRite Unlock RR LED	040B	Quicklearn (RFE)
02B1	Actuate TracRite Unlock FR/RR LED	040D	Quicklearn (62TE)
02B2	Actuate SmartBar On-Road LED	03F2	Intake Phaser 2 Cleaning
02B3	Actuate SmartBar Off-Road LED	03F0	Intake Phaser 1 Cleaning
02B4	Actuate All LEDs	040F	Thermistor Test (RFE)
02B5	Actuate SmartBar Motor	03F1	Exhaust Phaser 2 Cleaning
02B6	Actuate Rear TracRite Locker	0386	Enable Emissions Rolls Test Mode (TIPM)
02B7	Actuate Front TracRite Locker	0410	Clear Learned Variable Line Pressure (VLP) Counters

Index	Specil Function Name	Index	Specil Function Name
02B8	Calibrate HDT	056C	Service Procedures
02B9	Differential Pressure Sensor Replacement	0469	Height Sensor Check
02BA	Diesel Particulate Filter Replacement	0466	Fill Spring From Reservoir
02BB	Reset Mass Airflow Values	0473	ELSD Quicklearn
02BC	Emission-Relevant Component Replacement	046C	Spring Deflate to Reservoir
02BD	ECU Replacement With Value Transfer	0468	Set Ride Height Level
02BE	ECU Replacement Without Value Transfer	046D	Spring Deflate to Atmosphere
02BF	Display Diesel Particulate Filter Values	046B	Measure System Air Mass
02C0	Reset Inhibiting Timer	0474	System Functionality Test
02C1	Set Oil Dilution Mass Value	0476	Program Tire Size/Pinion Factor
02C2	View Oil Dilution Mass Value	0475	Radio Anti-Theft Override Test
02C3	Hard Top / Soft Top Configuration	04F3	RADIO Proxi Configuration
02CE	Change Cruise Control Mode	04FD	Proxi Configuration
02CF	Sensors:Bussed Inputs:and Bussed Outputs	0531	Swap Line Test
02D0	Verify Front TPM Antenna	053B	Power Electronics Coolant Fill
02D1	Verify Rear TPM Antenna	04A1	Radio Anti-Theft Override Test
02D2	All LED and Sound	053A	High Voltage Battery Coolant Fill
02D3	LED Zebra Display	0539	High Voltage Battery Drain
02D4	TCC Solenoid Test	051F	Read Ignition Module (IGNM) Software Information
02D5	Transmission Shift Solenoids Test	051E	BCM Replaced
02D6	Modulator Solenoid Test	04A6	Temporary Remote Start Disable
02D7	Shift Pressure Solenoid Test	051A	EPS Learn
02D9	Dealer Contact Info Reset	0576	ACC Aim Mode ?Auto Alignment
02DB	Enable / Disable Dealer Contact Info	04B2	Fuel Rail Control Test
02DC	Accessory Delay Time	0562	Calibrate Liftgate
02DE	Update Heavy Load Pressure Thresholds	04A7	Sunroof Initialization
02DF	Update Light Load Pressure Thresholds	010A	Initialize ITM
02E0	Program Dealer Contact Info	04A9	Sliding Door Open Test
02E1	Disable In Plant Mode	053E	Motor Resolver Offset Learn
02E2	Program Tire Size:KK	0560	ECU Replaced With Value Transfer
02E3	Program Tire Size:JC	054B	Engine Idle Shutdown Feature Enable/Disable
02E5	Program Tire Size:LX	0569	Reset PTU Shift Counter
02E6	SUNR Initialization	055D	Reset of O2 Values
02E7	Downstream O2 Response Monitor	04F1	Clear Stored Accumulated Fuel Mass
02EA	First Pass Cool Down Test Results	03D1	High Pressure Fuel Rail Test
02EB	Most Recent Cool Down Test Results	03DA	Injector Accelerated Drift Learn
02EE	Actuate Memory Seat and Pedals	02AD	OCM Rezero Procedure
02EF	View Remote Start Inhibit Data	04D4	Selection and/or engagement clutch electrovalve replacement
02F0	View Remote Start Abort Data	04D6	Hydraulic Kit replacement
02F1	View Last Successful Remote Start Event Data	04D1	Gearbox replacement
02F2	View Last VTA Trigger Cause	046E	Air Spring Circuit Test
02F3	View Remote Start Enable Data	04D9	Pump Relay Replacement
02F4	Restore Vehicle Configuration Without Resets for TIPM	04D7	Tunnel lever replacement
02F5	View VTA Enable Data	0467	Atmosphere Valve Actuator Test
02F6	AMP Tone Test without volume control	0431	Air Flow Meter Replace
02F7	TPM Sensor Test	0561	ESL Replaced
02F8	4th Gear Clutch Test:62TE	0381	Enable Emissions Rolls Test Mode (FCM)
02FB	SRV Test	04BD	Air flow meter sensor replacement
02FC	WIN Replaced SK 3101DFF0	054D	Engine Idle Bump Feature Enable/Disable
02FD	WIN Replaced SK 3112	0555	SCR System After ECU Replacement Procedure
02FE	WIN Replaced SK 31A2	0554	SCR System Dosing Module Replacement
02FF	PCM Replaced Cummins	055A	SCR Extend Mileage W Active Fault
0300	Reset WIN Configuration	054F	Alternator 2 Field Test
0302	Restore Vehicle Configuration Without Resets for FCM	044C	New Actuators
0303	AMP Tone Test with volume control	04E6	Program Keys
0306	Denormalize Window	04EE	Active Grille Shutter Test
0307	PEM Replace	0557	SCR System Wiring Harness Replacement
0308	PEM LF Antennas Verification Test	0556	SCR System Tank Pump Replacement
030A	Program Tire Size:LC	0565	ECU Replaced Without Value Transfer
030B	Enable DRL:LC	0564	TCM VIN Verification
030C	Actuate Transmission Relay	03EB	DEF (Reductant) Suction Line Heater Test
030D	Actuate Fuel Pump	03E9	DEF (Reductant) Pressure Line Heater Tester
030E	Actuate Engine Battery Feed	03EA	DEF (Reductant) Return Line Heater Test
030F	Rear Stop and Turn Lamp System Test	04D0	Gearbox oil accumulator replacement

Index	Specil Function Name	Index	Specil Function Name
0310	Cruise Control Data	04F0	CNG/Gasoline Forced Fuel Type
0311	Manual DPF Regeneration	055F	Active Grill Shutter
0312	ECM Replacement	0553	Rear View Camera Grid Lines
0313	DPF Replacement	0552	Dual Fuel Tank Enable / Disable
0314	Adaptive Numerator Learn	04F2	Reset VCM Adaptives
0315	Location of the Learned Keys by PEM Verification Test	0558	SCR System Pressure Line Replacement
0316	Restore Vehicle Configuration SRT10 and 16L	0418	High Voltage Battery Negative Contactor Test
0317	Smart Bar Motor Self Test	03B1	3rd Gear Clutch Test - 62TE
0318	Sway Bar Telltale Fast Blink Actuator	03B2	4th Gear Clutch Test - 62TE
0319	Sway Bar Telltale Slow Blink Actuator	0464	Record Curb Sensor Values
031A	Sway Bar Telltale Off Actuator	03B3	Reverse Gear Clutch Test - 62TE
031B	Sway Bar Telltale On Actuator	04EB	Brake Sensor Zero Calibration
031C	ENABLE_JK_HFM	045D	Front Blower State
031D	Service Diesel Particulate Filter Regeneration	0465	ESCL Replaced
031E	WCM Replaced SK 3101DFF0 Non TPM	0478	Set Max Cruise Speed
031F	WCM Replaced SK 3101DFF0 TPM	0477	Set Max Vehicle Speed
0320	Restore Vehicle Configuration With Resets for FCM	042A	1st Gear Clutch Test (62TE)
0321	ACC Exit In-Plant Mode	056A	Reset RDM Shift Counter
0322	Enable DRL:LX	0568	Rear Differential Bleed
0323	IR Sensor Data	0463	LF Antenna Verification Test
0324	Rear AC and Rear Wiper Wash Data Display	03C7	Fuel Pressure Override
0328	TCM Automatic Variant Coding (Restore ECU Config)	051B	Program Ignition FOBIKs Baseline System
0329	Automatic Variant Coding (Restore ECU Config)	0503	Proxi Configuration Alignment
032A	Deactivate/Activate Lamp Failure Recognition	0512	Throttle Body Self-Learning
032B	Display Critical ELV/EIS Data	0513	Longitudinal G-Sensor Calibration
032C	ELV Stored Faults Read	0514	Steering Angle Sensor Calibration
032D	Activate/Deactivate Cruise Control	0480	HIDT Calibration
032E	Update Service Interval	0530	Fleet PIN Reset
032F	Customer Programmable- Clock	0529	Light Rain Sensor Calibration
0330	Customer Programmable- Daytime Running Lamps	052A	Remote Start Antenna Test
0331	Customer Programmable- Language	052B	View Ignition (IGNM/KIN) Part Information
0332	Customer Programmable- Speedometer/Odometer Units	052C	View Uconnect Log Data
0333	Customer Programmable- Temperature	052D	Component Air Mass/Pressure/Ride Height Readings
0334	Pushbutton Test	0527	Turbo Actuator Pre-Align / Self Calibrate
0335	ECM Gas Automatic Variant Coding (Restore ECU Config)	0509	Clear Misfire TLC
0336	Set Maximum Vehicle Speed	047B	4th Gear Clutch Test 62TE
0337	Set High Idle Allowed Speeds	047E	Initialize EPPM
0338	ORC Automatic Variant Coding (Restore ECU Config)	0533	Bleed Brakes Verification Test
0339	PSM Automatic Variant Coding (Restore ECU Config)	0521	Catalyst Efficiency Test
033A	VIEW/RESET DUTY CYCLE ACCUMULATORS:03	04CF	Flap actuators learning test
033B	Mobile DeSoot - No Minimum Required Soot Load Var03	04C6	Neutral signal learning
033C	Mobile DeSoot - No Minimum Required Soot Load Var05	04D5	Clutch Replacement
033D	Aisin Trans Data	04C4	Reset vehicle configuration
033E	Actuate Engine ASD	03E8	DEF (Reductant) Doser Pump Override Test
033F	TPM Trigger Module Test DH	0485	Initialize ABS
0340	Non-Volatile Memory Reset	055E	Program Variant Coding.
0341	LRSM Readaption	0542	Rain and Automatic Lights Sensors check
0346	Write Left Rear Seat Position	0573	SCR System Procedure After ECU Replacement
0347	Write Right Rear Seat Position	0575	High Speed Fan Test
0349	Restore Vehicle Configuration With Resets for FCM 2004 and 2005	034F	Hybrid Battery Contactor Status
035B	Shift Lever Position Test	04BB	Rail pressure sensor replacement
0371	Disable Production Mode	04F6	TPM FGA Proxi Configuration
0373	Program Tire Size for EATX	0404	Neutral Gate Test (62TE)
0374	Program Tire Size for EGS 52	0402	Neutral Gate Test (Non-RFE)
0375	Restore Vehicle Configuration Without Resets for FCM 2004 and 2005	040A	O2 System Heater Test
0378	ATC Data Display	03FD	2nd Gear Clutch Test (RFE)

Index	Specil Function Name	Index	Specil Function Name
037B	Restore Vehicle Configuration- CS only	0454	Clear All Learned Seat Parameters
037D	Auxiliary Fuel Filter Enable	0427	Oxidation Catalyst Initialization
037E	Read Original Vehicle Configuration	055B	SCR DEF Tank Fluid Level Reset
037F	Read Current Vehicle Configuration	055C	DEF Dosing Injection Quantity
0383	Update Measurement Unit	03CD	Rollover Detection TRW Only
0384	EDC16 Report	0412	Heated Steering Wheel Configuration
0385	ITM Initialize	0406	Shift Lever Position Test (Non-RFE)
0387	Relearn TIPM VIN	041B	HV Battery Isolation Test
0388	Sound Horn on Lock	0567	Initialize Air Flow Sensor Values
0389	Headlamps on with Wipers	0563	Valve Body Solenoid Learn
038A	Calibrate Liftgate Full Close Position	042F	Lambda Sensor Replace
038B	Calibrate Liftgate Full Open Position	042E	Reset of Lambda values
038D	Seatbelt Alert Minder	0441	ELV Replace
038E	ITM Initialize PT Only	0448	ITM 04 ITM and Siren Communication Test
038F	Remote Start Temporary Disable	04D8	Sensors module replacement
0390	Tip Start Temporary Disable	04DA	Steering Angle Calibration
0391	QuickLearn	04E0	Enable seat belts reminder
0392	1st Gear Clutch Test RFE	04DC	Reset Odometer
0393	2nd Gear Clutch Test RFE	04DE	Reset Service Information
0394	2nd Prime Clutch Test RFE	04E1	Self Learning Working Mode
0395	3rd Gear Clutch Test RFE	04E3	Blinking Lights Configuration
0396	Reverse Gear Clutch Test RFE	04E5	Fire Protection System Activate
0397	P2262 Fault Diagnosis Test (Before Repair)	04C5	Self learning throttle body
0398	Fuel System Run Up Test	04C2	Reset learn flag wheel tooth
0399	High Pressure Fuel System Test	04C3	Reset phases front
039A	Stationary Desoot	04D2	Control unit replacement
039B	VG Turbo Cleaning Procedure	04D3	Electropump replacement
039E	Radio Anti Theft Override Test	045F	First Passed Cooldown Test Results
039F	Radio Hard-drive Back-up	03AF	1st Gear Clutch Test - 62TE
03A0	Radio Enable/Diable Front Video	03B0	2nd Gear Clutch Test - 62TE
03A2	Update Radio Market Select and DVD Region Code	0566	Neutral gear position learning
03A3	Flexible Oil Change Indicator Reset	04EF	Coolant Three Way Valve Test
03A4	Set Oil Type	04ED	Active Grille Shutter Replaced
03A5	Program Dealer Contact Information	04AC	Purge Vapor System Test
03A6	WCM Replaced DH	04B4	Disable Key-Alike
03A9	First Passed Cool Down Test Results	04F5	Longitudinal G-Sensor Calibration Test
03AA	ITM Initialize KK Only	0559	Reset SCR Mileage Counter to 200 Miles
03AB	ABS Initialization	056B	ACC Aim Mode - Auto Alignment
03AC	Calibrate Full Recline	0574	SCR DEF Dosing Injection Quantity
03AD	Calibrate Stow	0572	DPF Pressure Sensor Reset
03AE	Headphone Test	0571	HVAC Proxi Configuration
03B4	Quicklearn - 62TE	056F	FFCM Calibration
03B5	Shift Lever Position Test - 62TE	056E	BCM Immobilizer Replace
03B6	Neutral Gate Test	056D	Take Out of In Plant Mode
03E4	LRSM Re-Adaption	0541	LIN Line Request Check
03E6	Program Ignition Keys or Key FOBs	0549	Pressure Sensor Calibration
0413	Program Tire Sensor ID with TPM Tool	0547	Tow Hook Enable
0414	TPM Sensor Rolls Test	0548	Gear configuration reset
04A2	Program Ignition Keys	0545	Reset Parameters
0577	Clear DTCs	0578	Hydraulic Valve Test
0579	Disable In-Plant Mode	057A	Reset Module
057B	ATC AC Cooldown	057C	Reset ATC Head
057D	Automatic Loudness	057E	Radio Clock Display
057F	Reset Default Parameters	0580	Tone Output Test
0581	Actuate Mode Doors	0582	Program RKE
0583	RKE Horn Chirp	0584	Enable VTSS
0585	Disable EU DRL	0586	Radio EQ Setting
0587	RKE Unlock Sequence	0588	Rolling Door Locks
0589	Calibrate HVAC Door Motors	058A	Key FOB Test
058B	Double Door Unlock	058C	Vehicle Configuration
058D	Fuel Gauge Update	058E	Enable Mopar VTSS
058F	Enable Mopar VTSS Tampr Alert	0590	Enable VTSS Tamper Alert
0591	Headlamps On W/Wipers	0592	Initialize VIN
0593	Primary Fuel Tank Data	0594	Secondary Fuel Tank Data
0595	Optical Horn Chirp	0596	Reset Customer Preferences
0597	Reset Learned Features	0598	Headlamp Delay
0599	Toggle Horn Chirp	059A	Disable Disarm Switches

Index	Specil Function Name	Index	Specil Function Name
059B	Horn Chirp	059C	DRL Enable
059D	Enable Immobilizer	059E	Headlamp Delay Enable
059F	Horn Chirp Enable	0600	Enable Fleet DRL
0601	Init Learned Features	0602	Input Test
0603	Speaker Output Test	0604	Continuous Tone Test
0605	PCI Amplifier Test	0606	Mute Output Test
0607	Reset Amplifier	0608	Vin Verification
0609	Identify EQ	060A	Initialize Learned
060B	Mirror Actuation Test	060C	Initialize Module
060D	Inhibit Monitor	060E	Comb R Stop and Turn Lamps
060F	RG Headlamp Washer Disable	0610	Initialize Learned Features
0611	Configure for Radio Clock	0612	Wiper Actuation Test
0613	Input/Output Test	0614	Reset HVAC Module
0615	Actuator Circuit Test	0616	Disable Ambient Temp Sensor
0617	Enable Ambient Temp Sensor	0618	Reset Rear Blend Sw Span
0619	Navigation Voice Test	0620	Verify OCS
0621	Clear VIN Mismatch	0622	Configure for AOSIM
0623	Configure for Side Airbags	0624	Door Close Test
061A	Door Open Test	061B	Internal Relay Test
061C	Enable Chime	061D	Verify Module Calibration
061E	EATX TCM Has Been Changed	061F	Pinion Factor
0625	TRD Link	0626	EATX DTC Event Data
0627	Enable Illuminated Entry	0628	Check VTSS Mode
0629	Instrusion Sensor Test	062A	RKE FOB & Module Test
062B	Configure ITM	062C	Door Input Test
062D	Configure Module		