



# MaxiSYS\_Infiniti\_V3.00 Function List (Note:For reference only)

**NOTES:**

- This function is supported.                      ✖ This function may be supported, which depends on the actual condition of the vehicle.
  - This function is not supported.              ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

Vehicle Name	Type	YEAR	System Name	Ecu Info.	Read Codes	Erase Codes	Freeze Data	Live Data	Active Test	Special Function
*INFINITI EX35 Camp:P8202	J50	2008	AIRBAG	●	●	●	●	●	○	003, 005, 008
*INFINITI EX35 Camp:P8202	J50	2008	TRANSMISSION	●	●	●	○	●	●	001, 002
INFINITI EX25/EX35	J50	2009-2012	ABS	●	●	●	✖	●	●	001
INFINITI EX25/EX35	J50	2009-2012	ACCELE_PEDAL_ACT	●	●	●	○	●	●	○
INFINITI EX25/EX35	J50	2009-2012	ADAPTIVE_LIGHT	●	●	●	○	●	●	001
INFINITI EX25/EX35	J50	2009-2012	AIRBAG	●	●	●	●	●	○	003, 005, 008
INFINITI EX25/EX35	J50	2009-2012	ALL_MODE_AWD4WD	●	●	●	○	●	●	001
INFINITI EX25/EX35	J50	2009-2012	AUTO_DRIVE_POS	●	●	●	○	●	●	001
INFINITI EX25/EX35	J50	2009-2012	BCM	✖	●	●	○	●	●	001, 002
INFINITI EX25/EX35	J50	2009-2012	ENGINE	●	●	●	✖	●	●	001
INFINITI EX25/EX35	J50	2009-2012	HEAD_LAMP_LEVELIZER	●	●	●	○	●	●	001
INFINITI EX25/EX35	J50	2009-2012	IPDM_ER	○	●	●	○	●	●	002
INFINITI EX25/EX35	J50	2009-2012	METER	✖	●	●	○	●	○	002
INFINITI EX25/EX35	J50	2009-2012	MULTI_AV	✖	●	●	○	●	○	○
INFINITI EX25/EX35	J50	2009-2012	PRECRASH_SEATBELT	●	●	●	○	●	○	001
INFINITI EX25/EX35	J50	2009-2012	SIDE_RADAR_LEFT	●	●	●	○	●	●	001
INFINITI EX25/EX35	J50	2009-2012	SIDE_RADAR_RIGHT	●	●	●	○	●	●	001
INFINITI EX25/EX35	J50	2009-2012	SONAR	●	●	●	○	●	●	○
INFINITI EX25/EX35	J50	2009-2012	ICC	●	●	●	✖	●	●	001, 002
INFINITI EX25/EX35	J50	2009-2012	TRANSMISSION	●	●	●	✖	●	✖	001, 002
INFINITI EX25/EX35	J50	2009-2012	LANE CAMERA	●	●	●	○	●	●	001
INFINITI EX35	J50	2007-2012	ABS	●	●	●	✖	●	●	001
INFINITI EX35	J50	2007-2012	ACCELE_PEDAL_ACT	●	●	●	○	●	●	○
INFINITI EX35	J50	2007-2012	ADAPTIVE_LIGHT	●	●	●	○	●	●	001
INFINITI EX35	J50	2007-2012	AIRBAG	●	●	●	●	●	○	003, 005, 008
INFINITI EX35	J50	2007-2012	ALL_MODE_AWD4WD	●	●	●	○	●	●	001
INFINITI EX35	J50	2007-2012	AUTO_DRIVE_POS	●	●	●	○	●	●	001
INFINITI EX35	J50	2007-2012	BCM	✖	●	●	○	●	●	001, 002
INFINITI EX35	J50	2007-2012	ENGINE	●	●	●	✖	●	●	001
INFINITI EX35	J50	2007-2012	HEAD_LAMP_LEVELIZER	●	●	●	○	●	●	001

INFINITI EX35	J50	2007-2012	HVAC	●	●	●	○	●	●	001
INFINITI EX35	J50	2007-2012	INTELLIGENT_KEY	●	●	●	○	●	●	001, 002
INFINITI EX35	J50	2007-2012	IPDM_ER	○	●	●	○	●	●	002
INFINITI EX35	J50	2007-2012	LANE_CAMERA	●	●	●	○	●	●	001
INFINITI EX35	J50	2007-2012	METER	※	●	●	○	●	○	002
INFINITI EX35	J50	2007-2012	MULTI_AV	※	●	●	○	●	○	○
INFINITI EX35	J50	2007-2012	POP_UP_HOOD	●	●	●	○	●	○	008
INFINITI EX35	J50	2007-2012	REARVIEW_CAMERA	●	○	○	○	●	○	001
INFINITI EX35	J50	2007-2012	SBLIND_CAMERA	●	○	○	○	●	○	001
INFINITI EX35	J50	2007-2012	SONAR	●	●	●	○	●	●	○
INFINITI EX35	J50	2007-2012	ICC	●	●	●	※	●	●	001, 002
INFINITI EX35	J50	2007-2012	TRANSMISSION	●	●	●	※	●	※	001, 002
INFINITI EX35 (DOM)	J50	2009-2011	ABS	●	●	●	※	●	●	001
INFINITI EX35 (DOM)	J50	2009-2011	ACCELE_PEDAL_ACT	●	●	●	○	●	●	○
INFINITI EX35 (DOM)	J50	2009-2011	ADAPTIVE_LIGHT	●	●	●	○	●	●	001
INFINITI EX35 (DOM)	J50	2009-2011	AIRBAG	●	●	●	●	●	○	003, 005, 008
INFINITI EX35 (DOM)	J50	2009-2011	ALL_MODE_AWD4WD	●	●	●	○	●	●	001
INFINITI EX35 (DOM)	J50	2009-2011	AUTO_DRIVE_POS	●	●	●	○	●	●	001
INFINITI EX35 (DOM)	J50	2009-2011	BCM	※	●	●	○	●	●	001, 002
INFINITI EX35 (DOM)	J50	2009-2011	ENGINE	●	●	●	※	●	●	001
INFINITI EX35 (DOM)	J50	2009-2011	HEAD_LAMP_LEVELIZER	●	●	●	○	●	●	001
INFINITI EX35 (DOM)	J50	2009-2011	IPDM_ER	○	●	●	○	●	●	002
INFINITI EX35 (DOM)	J50	2009-2011	LANE_CAMERA	●	●	●	○	●	●	001
INFINITI EX35 (DOM)	J50	2009-2011	METER	※	●	●	○	●	○	002
INFINITI EX35 (DOM)	J50	2009-2011	MULTI_AV	※	●	●	○	●	○	○
INFINITI EX35 (DOM)	J50	2009-2011	PRECRASH_SEATBELT	●	●	●	○	●	○	001
INFINITI EX35 (DOM)	J50	2009-2011	SONAR	●	●	●	○	●	●	○
INFINITI EX35 (DOM)	J50	2009-2011	ICC	●	●	●	※	●	●	001, 002
INFINITI EX35 (DOM)	J50	2009-2011	TRANSMISSION	●	●	●	※	●	※	001, 002
INFINITI EX35/EX30d	J50	2009-2011	ABS	●	●	●	※	●	●	001
INFINITI EX35/EX30d	J50	2009-2011	ACCELE_PEDAL_ACT	●	●	●	○	●	●	○
INFINITI EX35/EX30d	J50	2009-2011	ADAPTIVE_LIGHT	●	●	●	○	●	●	001
INFINITI EX35/EX30d	J50	2009-2011	AIRBAG	●	●	●	●	●	○	003, 005, 008
INFINITI EX35/EX30d	J50	2009-2011	ALL_MODE_AWD4WD	●	●	●	○	●	●	001
INFINITI EX35/EX30d	J50	2009-2011	AUTO_DRIVE_POS	●	●	●	○	●	●	001
INFINITI EX35/EX30d	J50	2009-2011	BCM	※	●	●	○	●	●	001, 002
INFINITI EX35/EX30d	J50	2009-2011	ENGINE	●	●	●	※	●	●	001
INFINITI EX35/EX30d	J50	2009-2011	HEAD_LAMP_LEVELIZER	●	●	●	○	●	●	001
INFINITI EX35/EX30d	J50	2009-2011	IPDM_ER	○	●	●	○	●	●	002

INFINITI EX35/EX30d	J50	2009-2011	LANE CAMERA	●	●	●	○	●	●	001
INFINITI EX35/EX30d	J50	2009-2011	METER	※	●	●	○	●	○	002
INFINITI EX35/EX30d	J50	2009-2011	MULTI_AV	※	●	●	○	●	○	○
INFINITI EX35/EX30d	J50	2009-2011	PRECRASH_SEATBELT	●	●	●	○	●	○	001
INFINITI EX35/EX30d	J50	2009-2011	SIDE_RADAR_LEFT	●	●	●	○	●	●	001
INFINITI EX35/EX30d	J50	2009-2011	SIDE_RADAR_RIGHT	●	●	●	○	●	●	001
INFINITI EX35/EX30d	J50	2009-2011	SONAR	●	●	●	○	●	●	○
INFINITI EX35/EX30d	J50	2009-2011	ICC	●	●	●	※	●	●	001, 002
INFINITI EX35/EX30d	J50	2009-2011	BSW	●	●	●	○	●	●	○
INFINITI EX35/EX30d	J50	2009-2011	TRANSMISSION	●	●	●	※	●	※	001, 002
INFINITI EX35/EX37	J50	2011	ABS	●	●	●	※	●	●	001
INFINITI EX35/EX37	J50	2011	ACCELE_PEDAL_ACT	●	●	●	○	●	●	○
INFINITI EX35/EX37	J50	2011	ADAPTIVE_LIGHT	●	●	●	○	●	●	001
INFINITI EX35/EX37	J50	2011	AIRBAG	●	●	●	●	●	○	003, 005, 008
INFINITI EX35/EX37	J50	2011	ALL_MODE_AWD4WD	●	●	●	○	●	●	001
INFINITI EX35/EX37	J50	2011	AUTO_DRIVE_POS	●	●	●	○	●	●	001
INFINITI EX35/EX37	J50	2011	BCM	※	●	●	○	●	●	001, 002
INFINITI EX35/EX37	J50	2011	ENGINE	●	●	●	※	●	●	001
INFINITI EX35/EX37	J50	2011	HEAD_LAMP_LEVELIZER	●	●	●	○	●	●	001
INFINITI EX35/EX37	J50	2011	IPDM_ER	○	●	●	○	●	●	002
INFINITI EX35/EX37	J50	2011	LANE CAMERA	●	●	●	○	●	●	001
INFINITI EX35/EX37	J50	2011	METER	※	●	●	○	●	○	002
INFINITI EX35/EX37	J50	2011	MULTI_AV	※	●	●	○	●	○	○
INFINITI EX35/EX37	J50	2011	PRECRASH_SEATBELT	●	●	●	○	●	○	001
INFINITI EX35/EX37	J50	2011	SIDE_RADAR_LEFT	●	●	●	○	●	●	001
INFINITI EX35/EX37	J50	2011	SIDE_RADAR_RIGHT	●	●	●	○	●	●	001
INFINITI EX35/EX37	J50	2011	SONAR	●	●	●	○	●	●	○
INFINITI EX35/EX37	J50	2011	ICC	●	●	●	※	●	●	001, 002
INFINITI EX35/EX37	J50	2011	BSW	●	●	●	○	●	●	○
INFINITI EX35/EX37	J50	2011	TRANSMISSION	●	●	●	※	●	※	001, 002
INFINITI EX37	J50	2008-2012	ABS	●	●	●	※	●	●	001
INFINITI EX37	J50	2008-2012	ACCELE_PEDAL_ACT	●	●	●	○	●	●	○
INFINITI EX37	J50	2008-2012	ADAPTIVE_LIGHT	●	●	●	○	●	●	001
INFINITI EX37	J50	2008-2012	AIRBAG	●	●	●	●	●	○	003, 005, 008
INFINITI EX37	J50	2008-2012	ALL_MODE_AWD4WD	●	●	●	○	●	●	001
INFINITI EX37	J50	2008-2012	AUTO_DRIVE_POS	●	●	●	○	●	●	001
INFINITI EX37	J50	2008-2012	BCM	※	●	●	○	●	●	001, 002
INFINITI EX37	J50	2008-2012	ENGINE	●	●	●	※	●	●	001
INFINITI EX37	J50	2008-2012	HEAD_LAMP_LEVELIZER	●	●	●	○	●	●	001

INFINITI EX37	J50	2008-2012	IPDM_ER	○	●	●	○	●	●	002
INFINITI EX37	J50	2008-2012	METER	※	●	●	○	●	○	002
INFINITI EX37	J50	2008-2012	MULTI_AV	※	●	●	○	●	○	○
INFINITI EX37	J50	2008-2012	SONAR	●	●	●	○	●	●	○
INFINITI EX37	J50	2008-2012	TRANSMISSION	●	●	●	※	●	※	001, 002
INFINITI FX35/FX45	S50	2003-2008	ABS	●	●	●	○	●	●	001
INFINITI FX35/FX45	S50	2003-2008	ACM	●	●	●	○	●	○	○
INFINITI FX35/FX45	S50	2003-2008	ACTIVE_SUS	●	●	●	●	●	●	001
INFINITI FX35/FX45	S50	2003-2008	ADAPTIVE_LIGHT	●	●	●	○	●	●	001
INFINITI FX35/FX45	S50	2003-2008	AIRBAG	●	●	●	●	●	○	003, 005, 008
INFINITI FX35/FX45	S50	2003-2008	AIR_LEVELIZER	●	●	●	○	●	●	001
INFINITI FX35/FX45	S50	2003-2008	AIR_PRESSURE_MONITOR	●	●	●	○	●	●	001
INFINITI FX35/FX45	S50	2003-2008	ALL_MODE_AWD4WD	●	●	●	○	●	●	001
INFINITI FX35/FX45	S50	2003-2008	ASCD	○	●	●	○	●	○	○
INFINITI FX35/FX45	S50	2003-2008	AUTO_DRIVE_POS	●	●	●	○	●	●	001
INFINITI FX35/FX45	S50	2003-2008	AUTO_SLIDE_DOOR	●	●	●	○	●	○	○
INFINITI FX35/FX45	S50	2003-2008	BCM	●	●	●	○	●	●	001, 002
INFINITI FX35/FX45	S50	2003-2008	DIFF_LOCK	●	●	●	○	●	○	○
INFINITI FX35/FX45	S50	2003-2008	DISTANCE_CONTROL	●	●	●	○	●	○	○
INFINITI FX35/FX45	S50	2003-2008	DIU	●	●	●	○	●	○	○
INFINITI FX35/FX45	S50	2003-2008	ENGINE	●	●	●	※	●	●	001
INFINITI FX35/FX45	S50	2003-2008	EPS	●	●	●	○	●	○	002
INFINITI FX35/FX45	S50	2003-2008	E_4WD	●	●	●	○	●	●	002
INFINITI FX35/FX45	S50	2003-2008	HEAD_LAMP_LEVELIZER	●	●	●	○	●	●	001
INFINITI FX35/FX45	S50	2003-2008	HVAC	●	●	●	○	●	●	001
INFINITI FX35/FX45	S50	2003-2008	INTELLIGENT_KEY	●	●	●	○	●	●	001, 002
INFINITI FX35/FX45	S50	2003-2008	IPDM_ER	○	●	●	○	●	●	002
INFINITI FX35/FX45	S50	2003-2008	IVMS	●	●	●	○	●	○	○
INFINITI FX35/FX45	S50	2003-2008	LDW	●	●	●	○	●	●	001
INFINITI FX35/FX45	S50	2003-2008	METER	○	●	●	○	●	○	002
INFINITI FX35/FX45	S50	2003-2008	MOTORO_CONTROL_UNIT	●	●	●	○	●	○	001
INFINITI FX35/FX45	S50	2003-2008	MOTOR_ASSIST	○	●	●	○	●	○	001
INFINITI FX35/FX45	S50	2003-2008	MULTI_AV	○	●	●	○	●	○	○
INFINITI FX35/FX45	S50	2003-2008	NATS_IMMU	○	●	●	○	○	○	004, 006
INFINITI FX35/FX45	S50	2003-2008	RASHICAS	●	●	●	○	●	●	○
INFINITI FX35/FX45	S50	2003-2008	REARVIEW_CAMERA	●	○	○	○	●	○	001
INFINITI FX35/FX45	S50	2003-2008	S/BLIND_CAMERA	●	○	○	○	●	○	001
INFINITI FX35/FX45	S50	2003-2008	SMART_ENTRANCE	○	●	●	○	●	●	002
INFINITI FX35/FX45	S50	2003-2008	SONAR	●	●	●	○	●	●	○

INFINITI FX35/FX45	S50	2003-2008	TBDADAS_ICC	●	●	●	○	●	●	001, 002
INFINITI FX35/FX45	S50	2003-2008	TBDADM	●	●	●	○	●	●	001
INFINITI FX35/FX45	S50	2003-2008	TCS	●	●	●	●	●	●	001
INFINITI FX35/FX45	S50	2003-2008	TRANSMISSION	●	●	●	○	●	○	001, 002
INFINITI FX35/FX50	S51	2008-2013	ABS	●	●	●	※	●	●	001
INFINITI FX35/FX50	S51	2008-2013	ACCELE_PEDAL_ACT	●	●	●	○	●	●	○
INFINITI FX35/FX50	S51	2008-2013	ADAPTIVE_LIGHT	●	●	●	○	●	●	001
INFINITI FX35/FX50	S51	2008-2013	AIRBAG	●	●	●	●	●	○	003, 005, 008
INFINITI FX35/FX50	S51	2008-2013	AIR_PRESSURE_MONITOR	●	●	●	○	●	●	001
INFINITI FX35/FX50	S51	2008-2013	ALL_MODE_AWD4WD	●	●	●	○	●	●	001
INFINITI FX35/FX50	S51	2008-2013	AUTO_DRIVE_POS	●	●	●	○	●	●	001
INFINITI FX35/FX50	S51	2008-2013	BCM	※	●	●	○	●	●	001, 002
INFINITI FX35/FX50	S51	2008-2013	ENGINE	●	●	●	※	●	●	001
INFINITI FX35/FX50	S51	2008-2013	E_SUS	●	●	●	○	●	●	001
INFINITI FX35/FX50	S51	2008-2013	HEAD_LAMP_LEVELIZER	●	●	●	○	●	●	001
INFINITI FX35/FX50	S51	2008-2013	IPDM_ER	○	●	●	○	●	●	002
INFINITI FX35/FX50	S51	2008-2013	LANE_CAMERA	●	●	●	○	●	●	001
INFINITI FX35/FX50	S51	2008-2013	METER	※	●	●	○	●	○	002
INFINITI FX35/FX50	S51	2008-2013	MULTI_AV	※	●	●	○	●	○	○
INFINITI FX35/FX50	S51	2008-2013	ODS							
INFINITI FX35/FX50	S51	2008-2013	PRECRASH_SEATBELT	●	●	●	○	●	○	001
INFINITI FX35/FX50	S51	2008-2013	PTC_HEATER	●	●	●	○	●	○	○
INFINITI FX35/FX50	S51	2008-2013	REARVIEW_CAMERA	●	○	○	○	●	○	001
INFINITI FX35/FX50	S51	2008-2013	SONAR	●	●	●	○	●	●	○
INFINITI FX35/FX50	S51	2008-2013	ICC/ADAS	●	●	●	※	●	●	001, 002
INFINITI FX35/FX50	S51	2008-2013	AVM	●	●	●	○	●	●	001
INFINITI FX35/FX50	S51	2008-2013	TOTAL_ILLUM_C/U	●	○	○	○	●	○	001
INFINITI FX35/FX50	S51	2008-2013	TRANSMISSION	●	●	●	※	●	※	001, 002
INFINITI FX35/FX50/FX30d	S51	2011	ABS	●	●	●	※	●	●	001
INFINITI FX35/FX50/FX30d	S51	2011	ACCELE_PEDAL_ACT	●	●	●	○	●	●	○
INFINITI FX35/FX50/FX30d	S51	2011	AIRBAG	●	●	●	○	●	●	001
INFINITI FX35/FX50/FX30d	S51	2011	AIR_PRESSURE_MONITOR	●	●	●	○	●	●	001
INFINITI FX35/FX50/FX30d	S51	2011	ALL_MODE_AWD4WD	●	●	●	○	●	●	001
INFINITI FX35/FX50/FX30d	S51	2011	AUTO_DRIVE_POS	●	●	●	○	●	●	001
INFINITI FX35/FX50/FX30d	S51	2011	BCM	※	●	●	○	●	●	001, 002
INFINITI FX35/FX50/FX30d	S51	2011	ENGINE	●	●	●	※	●	●	001
INFINITI FX35/FX50/FX30d	S51	2011	E_SUS	●	●	●	○	●	●	001
INFINITI FX35/FX50/FX30d	S51	2011	HEAD_LAMP_LEVELIZER	●	●	●	○	●	●	001
INFINITI FX35/FX50/FX30d	S51	2011	IPDM_ER	○	●	●	○	●	●	002

INFINITI FX35/FX50/FX30d	S51	2011	METER	※	●	●	○	●	○	002
INFINITI FX35/FX50/FX30d	S51	2011	MULTI_AV	※	●	●	○	●	○	○
INFINITI FX35/FX50/FX30d	S51	2011	SONAR	●	●	●	○	●	●	○
INFINITI FX35/FX50/FX30d	S51	2011	TOTAL_ILUMM_CU	●	○	○	○	●	○	001
INFINITI FX35/FX50/FX30d	S51	2011	TRANSMISSION	●	●	●	※	●	※	001, 002
INFINITI FX37	S51	2012	ABS	●	●	●	※	●	●	001
INFINITI FX37	S51	2012	ACCELE_PEDAL_ACT	●	●	●	○	●	●	○
INFINITI FX37	S51	2012	ADAPTIVE_LIGHT	●	●	●	○	●	●	001
INFINITI FX37	S51	2012	AIRBAG	●	●	●	●	●	○	003, 005, 008
INFINITI FX37	S51	2012	AIR_PRESSURE_MONITOR	●	●	●	○	●	●	001
INFINITI FX37	S51	2012	ALL_MODE_AWD4WD	●	●	●	○	●	●	001
INFINITI FX37	S51	2012	AUTO_DRIVE_POS	●	●	●	○	●	●	001
INFINITI FX37	S51	2012	BCM	※	●	●	○	●	●	001, 002
INFINITI FX37	S51	2012	ENGINE	●	●	●	※	●	●	001
INFINITI FX37	S51	2012	E_SUS	●	●	●	○	●	●	001
INFINITI FX37	S51	2012	HEAD_LAMP_LEVELIZER	●	●	●	○	●	●	001
INFINITI FX37	S51	2012	IPDM_ER	○	●	●	○	●	●	002
INFINITI FX37	S51	2012	LANE_CAMERA	●	●	●	○	●	●	001
INFINITI FX37	S51	2012	METER	※	●	●	○	●	○	002
INFINITI FX37	S51	2012	MULTI_AV	※	●	●	○	●	○	○
INFINITI FX37	S51	2012	SONAR	●	●	●	○	●	●	○
INFINITI FX37	S51	2012	ICC/ADAS	●	●	●	※	●	●	001, 002
INFINITI FX37	S51	2012	AVM	●	●	●	○	●	●	001
INFINITI FX37	S51	2012	TOTAL_ILLUM_C/U	●	○	○	○	●	○	001
INFINITI FX37	S51	2012	TRANSMISSION	●	●	●	※	●	※	001, 002
INFINITI FX37/FX50	S51	2008-2012	ABS	●	●	●	※	●	●	001
INFINITI FX37/FX50	S51	2008-2012	ACCELE_PEDAL_ACT	●	●	●	○	●	●	○
INFINITI FX37/FX50	S51	2008-2012	ADAPTIVE_LIGHT	●	●	●	○	●	●	001
INFINITI FX37/FX50	S51	2008-2012	AIRBAG	●	●	●	●	●	○	003, 005, 008
INFINITI FX37/FX50	S51	2008-2012	AIR_PRESSURE_MONITOR	●	●	●	○	●	●	001
INFINITI FX37/FX50	S51	2008-2012	ALL_MODE_AWD4WD	●	●	●	○	●	●	001
INFINITI FX37/FX50	S51	2008-2012	AUTO_DRIVE_POS	●	●	●	○	●	●	001
INFINITI FX37/FX50	S51	2008-2012	BCM	※	●	●	○	●	●	001, 002
INFINITI FX37/FX50	S51	2008-2012	ENGINE	●	●	●	※	●	●	001
INFINITI FX37/FX50	S51	2008-2012	E_SUS	●	●	●	○	●	●	001
INFINITI FX37/FX50	S51	2008-2012	HEAD_LAMP_LEVELIZER	●	●	●	○	●	●	001
INFINITI FX37/FX50	S51	2008-2012	IPDM_ER	○	●	●	○	●	●	002
INFINITI FX37/FX50	S51	2008-2012	LANE_CAMERA	●	●	●	○	●	●	001
INFINITI FX37/FX50	S51	2008-2012	METER	※	●	●	○	●	○	002

INFINITI FX37/FX50	S51	2008-2012	MULTI_AV	※	●	●	○	●	○	○
INFINITI FX37/FX50	S51	2008-2012	SONAR	●	●	●	○	●	●	○
INFINITI FX37/FX50	S51	2008-2012	ICC/ADAS	●	●	●	※	●	●	001, 002
INFINITI FX37/FX50	S51	2008-2012	TOTAL ILLUM C/U	●	○	○	○	●	○	001
INFINITI FX37/FX50	S51	2008-2012	TRANSMISSION	●	●	●	※	●	※	001, 002
INFINITI FX37/FX50/FX30d	S51	2009-2012	ABS	●	●	●	※	●	●	001
INFINITI FX37/FX50/FX30d	S51	2009-2012	ACCELE_PEDAL_ACT	●	●	●	○	●	●	○
INFINITI FX37/FX50/FX30d	S51	2009-2012	ADAPTIVE_LIGHT	●	●	●	○	●	●	001
INFINITI FX37/FX50/FX30d	S51	2009-2012	AIRBAG	●	●	●	●	●	○	003, 005, 008
INFINITI FX37/FX50/FX30d	S51	2009-2012	AIR_PRESSURE_MONITOR	●	●	●	○	●	●	001
INFINITI FX37/FX50/FX30d	S51	2009-2012	ALL_MODE_AWD4WD	●	●	●	○	●	●	001
INFINITI FX37/FX50/FX30d	S51	2009-2012	AUTO_DRIVE_POS	●	●	●	○	●	●	001
INFINITI FX37/FX50/FX30d	S51	2009-2012	BCM	※	●	●	○	●	●	001, 002
INFINITI FX37/FX50/FX30d	S51	2009-2012	ENGINE	●	●	●	※	●	●	001
INFINITI FX37/FX50/FX30d	S51	2009-2012	E_SUS	●	●	●	○	●	●	001
INFINITI FX37/FX50/FX30d	S51	2009-2012	HEAD_LAMP_LEVELIZER	●	●	●	○	●	●	001
INFINITI FX37/FX50/FX30d	S51	2009-2012	IPDM_ER	○	●	●	○	●	●	002
INFINITI FX37/FX50/FX30d	S51	2009-2012	LANE CAMERA	●	●	●	○	●	●	001
INFINITI FX37/FX50/FX30d	S51	2009-2012	METER	※	●	●	○	●	○	002
INFINITI FX37/FX50/FX30d	S51	2009-2012	MULTI_AV	※	●	●	○	●	○	○
INFINITI FX37/FX50/FX30d	S51	2009-2012	PRECRASH_SEATBELT	●	●	●	○	●	○	001
INFINITI FX37/FX50/FX30d	S51	2009-2012	REARVIEW_CAMERA	●	○	○	○	●	○	001
INFINITI FX37/FX50/FX30d	S51	2009-2012	SONAR	●	●	●	○	●	●	○
INFINITI FX37/FX50/FX30d	S51	2009-2012	ICC/ADAS	●	●	●	※	●	●	001, 002
INFINITI FX37/FX50/FX30d	S51	2009-2012	AVM	●	●	●	○	●	●	001
INFINITI FX37/FX50/FX30d	S51	2009-2012	TOTAL ILLUM C/U	●	○	○	○	●	○	001
INFINITI FX37/FX50/FX30d	S51	2009-2012	TRANSMISSION	●	●	●	※	●	※	001, 002
INFINITI G20	P11	1999-2002	ABS	●	●	●	○	●	●	001
INFINITI G20	P11	1999-2002	ACM	●	●	●	○	●	○	○
INFINITI G20	P11	1999-2002	ACTIVE_SUS	●	●	●	●	●	●	001
INFINITI G20	P11	1999-2002	ADAPTIVE_LIGHT	●	●	●	○	●	●	001
INFINITI G20	P11	1999-2002	AIRBAG	●	●	●	●	●	○	003, 005, 008
INFINITI G20	P11	1999-2002	AIR_LEVELIZER	●	●	●	○	●	●	001
INFINITI G20	P11	1999-2002	AIR_PRESSURE_MONITOR	●	●	●	○	●	●	001
INFINITI G20	P11	1999-2002	ALL_MODE_AWD4WD	●	●	●	○	●	●	001
INFINITI G20	P11	1999-2002	ASCD	○	●	●	○	●	○	○
INFINITI G20	P11	1999-2002	AUTO_DRIVE_POS	●	●	●	○	●	●	001
INFINITI G20	P11	1999-2002	AUTO_SLIDE_DOOR	●	●	●	○	●	○	○
INFINITI G20	P11	1999-2002	BCM	●	●	●	○	●	●	001, 002

INFINITI G20	P11	1999-2002	DIFF_LOCK	●	●	●	○	●	○	○
INFINITI G20	P11	1999-2002	DISTANCE_CONTROL	●	●	●	○	●	○	○
INFINITI G20	P11	1999-2002	DIU	●	●	●	○	●	○	○
INFINITI G20	P11	1999-2002	ENGINE	●	●	●	※	●	●	001
INFINITI G20	P11	1999-2002	EPS	●	●	●	○	●	○	002
INFINITI G20	P11	1999-2002	E_4WD	●	●	●	○	●	●	002
INFINITI G20	P11	1999-2002	HEAD_LAMP_LEVELIZER	●	●	●	○	●	●	001
INFINITI G20	P11	1999-2002	HVAC	●	●	●	○	●	●	001
INFINITI G20	P11	1999-2002	INTELLIGENT_KEY	●	●	●	○	●	●	001, 002
INFINITI G20	P11	1999-2002	IPDM_ER	○	●	●	○	●	●	002
INFINITI G20	P11	1999-2002	IVMS	●	●	●	○	●	○	○
INFINITI G20	P11	1999-2002	LDW	●	●	●	○	●	●	001
INFINITI G20	P11	1999-2002	METER	○	●	●	○	●	○	002
INFINITI G20	P11	1999-2002	MOTORO_CONTROL_UNIT	●	●	●	○	●	○	001
INFINITI G20	P11	1999-2002	MOTOR_ASSIST	○	●	●	○	●	○	001
INFINITI G20	P11	1999-2002	MULTI_AV	○	●	●	○	●	○	○
INFINITI G20	P11	1999-2002	NATS_IMMU	○	●	●	○	○	○	004, 006
INFINITI G20	P11	1999-2002	RASHICAS	●	●	●	○	●	●	○
INFINITI G20	P11	1999-2002	REARVIEW_CAMERA	●	○	○	○	●	○	001
INFINITI G20	P11	1999-2002	S/BLIND_CAMERA	●	○	○	○	●	○	001
INFINITI G20	P11	1999-2002	SMART_ENTRANCE	○	●	●	○	●	●	002
INFINITI G20	P11	1999-2002	SONAR	●	●	●	○	●	●	○
INFINITI G20	P11	1999-2002	TBDADAS_ICC	●	●	●	○	●	●	001, 002
INFINITI G20	P11	1999-2002	TBDAVM	●	●	●	○	●	●	001
INFINITI G20	P11	1999-2002	TCS	●	●	●	●	●	●	001
INFINITI G20	P11	1999-2002	TRANSMISSION	●	●	●	○	●	○	001, 002
INFINITI G20	CA33	2002-2004	ABS	●	●	●	○	●	●	001
INFINITI G20	CA33	2002-2004	ACM	●	●	●	○	●	○	○
INFINITI G20	CA33	2002-2004	ACTIVE_SUS	●	●	●	●	●	●	001
INFINITI G20	CA33	2002-2004	ADAPTIVE_LIGHT	●	●	●	○	●	●	001
INFINITI G20	CA33	2002-2004	AIRBAG	●	●	●	●	●	○	003, 005, 008
INFINITI G20	CA33	2002-2004	AIR_LEVELIZER	●	●	●	○	●	●	001
INFINITI G20	CA33	2002-2004	AIR_PRESSURE_MONITOR	●	●	●	○	●	●	001
INFINITI G20	CA33	2002-2004	ALL_MODE_AWD4WD	●	●	●	○	●	●	001
INFINITI G20	CA33	2002-2004	ASCD	○	●	●	○	●	○	○
INFINITI G20	CA33	2002-2004	AUTO_DRIVE_POS	●	●	●	○	●	●	001
INFINITI G20	CA33	2002-2004	AUTO_SLIDE_DOOR	●	●	●	○	●	○	○
INFINITI G20	CA33	2002-2004	BCM	●	●	●	○	●	●	001, 002
INFINITI G20	CA33	2002-2004	DIFF_LOCK	●	●	●	○	●	○	○



INFINITI G20	CA33	2002-2004	DISTANCE_CONTROL	●	●	●	○	●	○	○
INFINITI G20	CA33	2002-2004	DIU	●	●	●	○	●	○	○
INFINITI G20	CA33	2002-2004	ENGINE	●	●	●	※	●	●	001
INFINITI G20	CA33	2002-2004	EPS	●	●	●	○	●	○	002
INFINITI G20	CA33	2002-2004	E_4WD	●	●	●	○	●	●	002
INFINITI G20	CA33	2002-2004	HEAD_LAMP_LEVELIZER	●	●	●	○	●	●	001
INFINITI G20	CA33	2002-2004	HVAC	●	●	●	○	●	●	001
INFINITI G20	CA33	2002-2004	INTELLIGENT_KEY	●	●	●	○	●	●	001, 002
INFINITI G20	CA33	2002-2004	IPDM_ER	○	●	●	○	●	●	002
INFINITI G20	CA33	2002-2004	IVMS	●	●	●	○	●	○	○
INFINITI G20	CA33	2002-2004	LDW	●	●	●	○	●	●	001
INFINITI G20	CA33	2002-2004	METER	○	●	●	○	●	○	002
INFINITI G20	CA33	2002-2004	MOTORO_CONTROL_UNIT	●	●	●	○	●	○	001
INFINITI G20	CA33	2002-2004	MOTOR_ASSIST	○	●	●	○	●	○	001
INFINITI G20	CA33	2002-2004	MULTI_AV	○	●	●	○	●	○	○
INFINITI G20	CA33	2002-2004	NATS_IMMU	○	●	●	○	○	○	004, 006
INFINITI G20	CA33	2002-2004	RASHICAS	●	●	●	○	●	●	○
INFINITI G20	CA33	2002-2004	REARVIEW_CAMERA	●	○	○	○	●	○	001
INFINITI G20	CA33	2002-2004	S/BLIND_CAMERA	●	○	○	○	●	○	001
INFINITI G20	CA33	2002-2004	SMART_ENTRANCE	○	●	●	○	●	●	002
INFINITI G20	CA33	2002-2004	SONAR	●	●	●	○	●	●	○
INFINITI G20	CA33	2002-2004	TBDADAS_ICC	●	●	●	○	●	●	001, 002
INFINITI G20	CA33	2002-2004	TBDAVM	●	●	●	○	●	●	001
INFINITI G20	CA33	2002-2004	TCS	●	●	●	●	●	●	001
INFINITI G20	CA33	2002-2004	TRANSMISSION	●	●	●	○	●	○	001, 002
INFINITI G25/G37 Sedan	V36	2009-2012	4WASCAN	●	●	●	○	●	●	○
INFINITI G25/G37 Sedan	V36	2009-2012	ABS	●	●	●	※	●	●	001
INFINITI G25/G37 Sedan	V36	2009-2012	ACCELE_PEDAL_ACT	●	●	●	○	●	●	○
INFINITI G25/G37 Sedan	V36	2009-2012	ADAPTIVE_LIGHT	●	●	●	○	●	●	001
INFINITI G25/G37 Sedan	V36	2009-2012	AIRBAG	●	●	●	●	●	○	003, 005, 008
INFINITI G25/G37 Sedan	V36	2009-2012	ALL_MODE_AWD4WD	●	●	●	○	●	●	001
INFINITI G25/G37 Sedan	V36	2009-2012	AUTO_DRIVE_POS	●	●	●	○	●	●	001
INFINITI G25/G37 Sedan	V36	2009-2012	BCM	※	●	●	○	●	●	001, 002
INFINITI G25/G37 Sedan	V36	2009-2012	CONVERTIBLE_ROOF	●	●	●	○	●	●	001
INFINITI G25/G37 Sedan	V36	2009-2012	ENGINE	●	●	●	※	●	●	001
INFINITI G25/G37 Sedan	V36	2009-2012	HEAD_LAMP_LEVELIZER	●	●	●	○	●	●	001
INFINITI G25/G37 Sedan	V36	2009-2012	IPDM_ER	○	●	●	○	●	●	002
INFINITI G25/G37 Sedan	V36	2009-2012	METER	※	●	●	○	●	○	002
INFINITI G25/G37 Sedan	V36	2009-2012	MULTI_AV	※	●	●	○	●	○	○

INFINITI G25/G37 Sedan	V36	2009-2012	POP_UP_HOOD	●	●	●	○	●	○	008
INFINITI G25/G37 Sedan	V36	2009-2012	PRECRASH_SEATBELT	●	●	●	○	●	○	001
INFINITI G25/G37 Sedan	V36	2009-2012	SONAR	●	●	●	○	●	●	○
INFINITI G25/G37 Sedan	V36	2009-2012	ICC/ADAS	●	●	●	※	●	●	001, 002
INFINITI G25/G37 Sedan	V36	2009-2012	TRANSMISSION	●	●	●	※	●	※	001, 002
INFINITI G35 Coupe	CV35	2003-2007	ABS	●	●	●	○	●	●	001
INFINITI G35 Coupe	CV35	2003-2007	ACM	●	●	●	○	●	○	○
INFINITI G35 Coupe	CV35	2003-2007	ACTIVE_SUS	●	●	●	●	●	●	001
INFINITI G35 Coupe	CV35	2003-2007	ADAPTIVE_LIGHT	●	●	●	○	●	●	001
INFINITI G35 Coupe	CV35	2003-2007	AIRBAG	●	●	●	●	●	○	003, 005, 008
INFINITI G35 Coupe	CV35	2003-2007	AIR_LEVELIZER	●	●	●	○	●	●	001
INFINITI G35 Coupe	CV35	2003-2007	AIR_PRESSURE_MONITOR	●	●	●	○	●	●	001
INFINITI G35 Coupe	CV35	2003-2007	ALL_MODE_AWD4WD	●	●	●	○	●	●	001
INFINITI G35 Coupe	CV35	2003-2007	ASCD	○	●	●	○	●	○	○
INFINITI G35 Coupe	CV35	2003-2007	AUTO_DRIVE_POS	●	●	●	○	●	●	001
INFINITI G35 Coupe	CV35	2003-2007	AUTO_SLIDE_DOOR	●	●	●	○	●	○	○
INFINITI G35 Coupe	CV35	2003-2007	BCM	●	●	●	○	●	●	001, 002
INFINITI G35 Coupe	CV35	2003-2007	DIFF_LOCK	●	●	●	○	●	○	○
INFINITI G35 Coupe	CV35	2003-2007	DISTANCE_CONTROL	●	●	●	○	●	○	○
INFINITI G35 Coupe	CV35	2003-2007	DIU	●	●	●	○	●	○	○
INFINITI G35 Coupe	CV35	2003-2007	ENGINE	●	●	●	※	●	●	001
INFINITI G35 Coupe	CV35	2003-2007	EPS	●	●	●	○	●	○	002
INFINITI G35 Coupe	CV35	2003-2007	E_4WD	●	●	●	○	●	●	002
INFINITI G35 Coupe	CV35	2003-2007	HEAD_LAMP_LEVELIZER	●	●	●	○	●	●	001
INFINITI G35 Coupe	CV35	2003-2007	HVAC	●	●	●	○	●	●	001
INFINITI G35 Coupe	CV35	2003-2007	INTELLIGENT_KEY	●	●	●	○	●	●	001, 002
INFINITI G35 Coupe	CV35	2003-2007	IPDM_ER	○	●	●	○	●	●	002
INFINITI G35 Coupe	CV35	2003-2007	IVMS	●	●	●	○	●	○	○
INFINITI G35 Coupe	CV35	2003-2007	LDW	●	●	●	○	●	●	001
INFINITI G35 Coupe	CV35	2003-2007	METER	○	●	●	○	●	○	002
INFINITI G35 Coupe	CV35	2003-2007	MOTORO_CONTROL_UNIT	●	●	●	○	●	○	001
INFINITI G35 Coupe	CV35	2003-2007	MOTOR_ASSIST	○	●	●	○	●	○	001
INFINITI G35 Coupe	CV35	2003-2007	MULTI_AV	○	●	●	○	●	○	○
INFINITI G35 Coupe	CV35	2003-2007	NATS_IMMU	○	●	●	○	○	○	004, 006
INFINITI G35 Coupe	CV35	2003-2007	RASHICAS	●	●	●	○	●	●	○
INFINITI G35 Coupe	CV35	2003-2007	REARVIEW_CAMERA	●	○	○	○	●	○	001
INFINITI G35 Coupe	CV35	2003-2007	S/BLIND_CAMERA	●	○	○	○	●	○	001
INFINITI G35 Coupe	CV35	2003-2007	SMART_ENTRANCE	○	●	●	○	●	●	002
INFINITI G35 Coupe	CV35	2003-2007	SONAR	●	●	●	○	●	●	○

INFINITI G35 Coupe	CV35	2003-2007	TBDADAS_ICC	●	●	●	○	●	●	001, 002
INFINITI G35 Coupe	CV35	2003-2007	TBDADM	●	●	●	○	●	●	001
INFINITI G35 Coupe	CV35	2003-2007	TCS	●	●	●	●	●	●	001
INFINITI G35 Coupe	CV35	2003-2007	TRANSMISSION	●	●	●	○	●	○	001, 002
INFINITI G35 Sedan	V35	2003-2008	ABS	●	●	●	○	●	●	001
INFINITI G35 Sedan	V35	2003-2008	ACM	●	●	●	○	●	○	○
INFINITI G35 Sedan	V35	2003-2008	ACTIVE_SUS	●	●	●	●	●	●	001
INFINITI G35 Sedan	V35	2003-2008	ADAPTIVE_LIGHT	●	●	●	○	●	●	001
INFINITI G35 Sedan	V35	2003-2008	AIRBAG	●	●	●	●	●	○	003, 005, 008
INFINITI G35 Sedan	V35	2003-2008	AIR_LEVELIZER	●	●	●	○	●	●	001
INFINITI G35 Sedan	V35	2003-2008	AIR_PRESSURE_MONITOR	●	●	●	○	●	●	001
INFINITI G35 Sedan	V35	2003-2008	ALL_MODE_AWD4WD	●	●	●	○	●	●	001
INFINITI G35 Sedan	V35	2003-2008	ASCD	○	●	●	○	●	○	○
INFINITI G35 Sedan	V35	2003-2008	AUTO_DRIVE_POS	●	●	●	○	●	●	001
INFINITI G35 Sedan	V35	2003-2008	AUTO_SLIDE_DOOR	●	●	●	○	●	○	○
INFINITI G35 Sedan	V35	2003-2008	BCM	●	●	●	○	●	●	001, 002
INFINITI G35 Sedan	V35	2003-2008	DIFF_LOCK	●	●	●	○	●	○	○
INFINITI G35 Sedan	V35	2003-2008	DISTANCE_CONTROL	●	●	●	○	●	○	○
INFINITI G35 Sedan	V35	2003-2008	DIU	●	●	●	○	●	○	○
INFINITI G35 Sedan	V35	2003-2008	ENGINE	●	●	●	※	●	●	001
INFINITI G35 Sedan	V35	2003-2008	EPS	●	●	●	○	●	○	002
INFINITI G35 Sedan	V35	2003-2008	E_4WD	●	●	●	○	●	●	002
INFINITI G35 Sedan	V35	2003-2008	HEAD_LAMP_LEVELIZER	●	●	●	○	●	●	001
INFINITI G35 Sedan	V35	2003-2008	HVAC	●	●	●	○	●	●	001
INFINITI G35 Sedan	V35	2003-2008	INTELLIGENT_KEY	●	●	●	○	●	●	001, 002
INFINITI G35 Sedan	V35	2003-2008	IPDM_ER	○	●	●	○	●	●	002
INFINITI G35 Sedan	V35	2003-2008	IVMS	●	●	●	○	●	○	○
INFINITI G35 Sedan	V35	2003-2008	LDW	●	●	●	○	●	●	001
INFINITI G35 Sedan	V35	2003-2008	METER	○	●	●	○	●	○	002
INFINITI G35 Sedan	V35	2003-2008	MOTORO_CONTROL_UNIT	●	●	●	○	●	○	001
INFINITI G35 Sedan	V35	2003-2008	MOTOR_ASSIST	○	●	●	○	●	○	001
INFINITI G35 Sedan	V35	2003-2008	MULTI_AV	○	●	●	○	●	○	○
INFINITI G35 Sedan	V35	2003-2008	NATS_IMMU	○	●	●	○	○	○	004, 006
INFINITI G35 Sedan	V35	2003-2008	RASHICAS	●	●	●	○	●	●	○
INFINITI G35 Sedan	V35	2003-2008	REARVIEW_CAMERA	●	○	○	○	●	○	001
INFINITI G35 Sedan	V35	2003-2008	S/BLIND_CAMERA	●	○	○	○	●	○	001
INFINITI G35 Sedan	V35	2003-2008	SMART_ENTRANCE	○	●	●	○	●	●	002
INFINITI G35 Sedan	V35	2003-2008	SONAR	●	●	●	○	●	●	○
INFINITI G35 Sedan	V35	2003-2008	TBDADAS_ICC	●	●	●	○	●	●	001, 002

INFINITI G35 Sedan	V35	2003-2008	TBDAVM	●	●	●	○	●	●	001
INFINITI G35 Sedan	V35	2003-2008	TCS	●	●	●	●	●	●	001
INFINITI G35 Sedan	V35	2003-2008	TRANSMISSION	●	●	●	○	●	○	001, 002
INFINITI G37 Convertible	HV36	2009-2013	4WASCAN	●	●	●	○	●	●	○
INFINITI G37 Convertible	HV36	2009-2013	ABS	●	●	●	※	●	●	001
INFINITI G37 Convertible	HV36	2009-2013	ACCELE_PEDAL_ACT	●	●	●	○	●	●	○
INFINITI G37 Convertible	HV36	2009-2013	ADAPTIVE_LIGHT	●	●	●	○	●	●	001
INFINITI G37 Convertible	HV36	2009-2013	AIRBAG	●	●	●	●	●	○	003, 005, 008
INFINITI G37 Convertible	HV36	2009-2013	ALL_MODE_AWD4WD	●	●	●	○	●	●	001
INFINITI G37 Convertible	HV36	2009-2013	AUTO_DRIVE_POS	●	●	●	○	●	●	001
INFINITI G37 Convertible	HV36	2009-2013	BCM	※	●	●	○	●	●	001, 002
INFINITI G37 Convertible	HV36	2009-2013	CONVERTIBLE_ROOF	●	●	●	○	●	●	001
INFINITI G37 Convertible	HV36	2009-2013	ENGINE	●	●	●	※	●	●	001
INFINITI G37 Convertible	HV36	2009-2013	HEAD_LAMP_LEVELIZER	●	●	●	○	●	●	001
INFINITI G37 Convertible	HV36	2009-2013	IPDM_ER	○	●	●	○	●	●	002
INFINITI G37 Convertible	HV36	2009-2013	METER	※	●	●	○	●	○	002
INFINITI G37 Convertible	HV36	2009-2013	MULTI_AV	※	●	●	○	●	○	○
INFINITI G37 Convertible	HV36	2009-2013	POP_UP_HOOD	●	●	●	○	●	○	008
INFINITI G37 Convertible	HV36	2009-2013	PRECRASH_SEATBELT	●	●	●	○	●	○	001
INFINITI G37 Convertible	HV36	2009-2013	SONAR	●	●	●	○	●	●	○
INFINITI G37 Convertible	HV36	2009-2013	ICC/ADAS	●	●	●	※	●	●	001, 002
INFINITI G37 Convertible	HV36	2009-2013	TRANSMISSION	●	●	●	※	●	※	001, 002
INFINITI G37 Coupe	CV36	2007-2013	4WASCAN	●	●	●	○	●	●	○
INFINITI G37 Coupe	CV36	2007-2013	ABS	●	●	●	※	●	●	001
INFINITI G37 Coupe	CV36	2007-2013	ACCELE_PEDAL_ACT	●	●	●	○	●	●	○
INFINITI G37 Coupe	CV36	2007-2013	ADAPTIVE_LIGHT	●	●	●	○	●	●	001
INFINITI G37 Coupe	CV36	2007-2013	AIRBAG	●	●	●	●	●	○	003, 005, 008
INFINITI G37 Coupe	CV36	2007-2013	ALL_MODE_AWD4WD	●	●	●	○	●	●	001
INFINITI G37 Coupe	CV36	2007-2013	AUTO_DRIVE_POS	●	●	●	○	●	●	001
INFINITI G37 Coupe	CV36	2007-2013	BCM	※	●	●	○	●	●	001, 002
INFINITI G37 Coupe	CV36	2007-2013	CONVERTIBLE_ROOF	●	●	●	○	●	●	001
INFINITI G37 Coupe	CV36	2007-2013	ENGINE	●	●	●	※	●	●	001
INFINITI G37 Coupe	CV36	2007-2013	HEAD_LAMP_LEVELIZER	●	●	●	○	●	●	001
INFINITI G37 Coupe	CV36	2007-2013	IPDM_ER	○	●	●	○	●	●	002
INFINITI G37 Coupe	CV36	2007-2013	METER	※	●	●	○	●	○	002
INFINITI G37 Coupe	CV36	2007-2013	MULTI_AV	※	●	●	○	●	○	○
INFINITI G37 Coupe	CV36	2007-2013	POP_UP_HOOD	●	●	●	○	●	○	008
INFINITI G37 Coupe	CV36	2007-2013	PRECRASH_SEATBELT	●	●	●	○	●	○	001
INFINITI G37 Coupe	CV36	2007-2013	SONAR	●	●	●	○	●	●	○

INFINITI G37 Coupe	CV36	2007-2013	ICC/ADAS	●	●	●	※	●	●	001, 002
INFINITI G37 Coupe	CV36	2007-2013	TRANSMISSION	●	●	●	※	●	※	001, 002
INFINITI G37 Sedan	V36	2008-2011	4WASCAN	●	●	●	○	●	●	○
INFINITI G37 Sedan	V36	2008-2011	ABS	●	●	●	※	●	●	001
INFINITI G37 Sedan	V36	2008-2011	ACCELE_PEDAL_ACT	●	●	●	○	●	●	○
INFINITI G37 Sedan	V36	2008-2011	ADAPTIVE_LIGHT	●	●	●	○	●	●	001
INFINITI G37 Sedan	V36	2008-2011	AIRBAG	●	●	●	●	●	○	003, 005, 008
INFINITI G37 Sedan	V36	2008-2011	ALL_MODE_AWD4WD	●	●	●	○	●	●	001
INFINITI G37 Sedan	V36	2008-2011	AUTO_DRIVE_POS	●	●	●	○	●	●	001
INFINITI G37 Sedan	V36	2008-2011	BCM	※	●	●	○	●	●	001, 002
INFINITI G37 Sedan	V36	2008-2011	CONVERTIBLE_ROOF	●	●	●	○	●	●	001
INFINITI G37 Sedan	V36	2008-2011	ENGINE	●	●	●	※	●	●	001
INFINITI G37 Sedan	V36	2008-2011	HEAD_LAMP_LEVELIZER	●	●	●	○	●	●	001
INFINITI G37 Sedan	V36	2008-2011	IPDM_ER	○	●	●	○	●	●	002
INFINITI G37 Sedan	V36	2008-2011	METER	※	●	●	○	●	○	002
INFINITI G37 Sedan	V36	2008-2011	MULTI_AV	※	●	●	○	●	○	○
INFINITI G37 Sedan	V36	2008-2011	POP_UP_HOOD	●	●	●	○	●	○	008
INFINITI G37 Sedan	V36	2008-2011	PRECRASH_SEATBELT	●	●	●	○	●	○	001
INFINITI G37 Sedan	V36	2008-2011	SONAR	●	●	●	○	●	●	○
INFINITI G37 Sedan	V36	2008-2011	ICC/ADAS	●	●	●	※	●	●	001, 002
INFINITI G37 Sedan	V36	2008-2011	TRANSMISSION	●	●	●	※	●	※	001, 002
INFINITI I30	CA32	1996-2001	ABS	●	●	●	○	●	●	001
INFINITI I30	CA32	1996-2001	ACM	●	●	●	○	●	○	○
INFINITI I30	CA32	1996-2001	ACTIVE_SUS	●	●	●	●	●	●	001
INFINITI I30	CA32	1996-2001	ADAPTIVE_LIGHT	●	●	●	○	●	●	001
INFINITI I30	CA32	1996-2001	AIRBAG	●	●	●	●	●	○	003, 005, 008
INFINITI I30	CA32	1996-2001	AIR_LEVELIZER	●	●	●	○	●	●	001
INFINITI I30	CA32	1996-2001	AIR_PRESSURE_MONITOR	●	●	●	○	●	●	001
INFINITI I30	CA32	1996-2001	ALL_MODE_AWD4WD	●	●	●	○	●	●	001
INFINITI I30	CA32	1996-2001	ASCD	○	●	●	○	●	○	○
INFINITI I30	CA32	1996-2001	AUTO_DRIVE_POS	●	●	●	○	●	●	001
INFINITI I30	CA32	1996-2001	AUTO_SLIDE_DOOR	●	●	●	○	●	○	○
INFINITI I30	CA32	1996-2001	BCM	●	●	●	○	●	●	001, 002
INFINITI I30	CA32	1996-2001	DIFF_LOCK	●	●	●	○	●	○	○
INFINITI I30	CA32	1996-2001	DISTANCE_CONTROL	●	●	●	○	●	○	○
INFINITI I30	CA32	1996-2001	DIU	●	●	●	○	●	○	○
INFINITI I30	CA32	1996-2001	ENGINE	●	●	●	※	●	●	001
INFINITI I30	CA32	1996-2001	EPS	●	●	●	○	●	○	002
INFINITI I30	CA32	1996-2001	E_4WD	●	●	●	○	●	●	002

INFINITI I30	CA32	1996-2001	HEAD_LAMP_LEVELIZER	●	●	●	○	●	●	001
INFINITI I30	CA32	1996-2001	HVAC	●	●	●	○	●	●	001
INFINITI I30	CA32	1996-2001	INTELLIGENT_KEY	●	●	●	○	●	●	001, 002
INFINITI I30	CA32	1996-2001	IPDM_ER	○	●	●	○	●	●	002
INFINITI I30	CA32	1996-2001	IVMS	●	●	●	○	●	○	○
INFINITI I30	CA32	1996-2001	LDW	●	●	●	○	●	●	001
INFINITI I30	CA32	1996-2001	METER	○	●	●	○	●	○	002
INFINITI I30	CA32	1996-2001	MOTORO_CONTROL_UNIT	●	●	●	○	●	○	001
INFINITI I30	CA32	1996-2001	MOTOR_ASSIST	○	●	●	○	●	○	001
INFINITI I30	CA32	1996-2001	MULTI_AV	○	●	●	○	●	○	○
INFINITI I30	CA32	1996-2001	NATS_IMMU	○	●	●	○	○	○	004, 006
INFINITI I30	CA32	1996-2001	RASHICAS	●	●	●	○	●	●	○
INFINITI I30	CA32	1996-2001	REARVIEW_CAMERA	●	○	○	○	●	○	001
INFINITI I30	CA32	1996-2001	S/BLIND_CAMERA	●	○	○	○	●	○	001
INFINITI I30	CA32	1996-2001	SMART_ENTRANCE	○	●	●	○	●	●	002
INFINITI I30	CA32	1996-2001	SONAR	●	●	●	○	●	●	○
INFINITI I30	CA32	1996-2001	TBDADAS_ICC	●	●	●	○	●	●	001, 002
INFINITI I30	CA32	1996-2001	TBDAVM	●	●	●	○	●	●	001
INFINITI I30	CA32	1996-2001	TCS	●	●	●	●	●	●	001
INFINITI I30	CA32	1996-2001	TRANSMISSION	●	●	●	○	●	○	001, 002
INFINITI I35	CA33	2002-2004	ABS	●	●	●	○	●	●	001
INFINITI I35	CA33	2002-2004	ACM	●	●	●	○	●	○	○
INFINITI I35	CA33	2002-2004	ACTIVE_SUS	●	●	●	●	●	●	001
INFINITI I35	CA33	2002-2004	ADAPTIVE_LIGHT	●	●	●	○	●	●	001
INFINITI I35	CA33	2002-2004	AIRBAG	●	●	●	●	●	○	003, 005, 008
INFINITI I35	CA33	2002-2004	AIR_LEVELIZER	●	●	●	○	●	●	001
INFINITI I35	CA33	2002-2004	AIR_PRESSURE_MONITOR	●	●	●	○	●	●	001
INFINITI I35	CA33	2002-2004	ALL_MODE_AWD4WD	●	●	●	○	●	●	001
INFINITI I35	CA33	2002-2004	ASCD	○	●	●	○	●	○	○
INFINITI I35	CA33	2002-2004	AUTO_DRIVE_POS	●	●	●	○	●	●	001
INFINITI I35	CA33	2002-2004	AUTO_SLIDE_DOOR	●	●	●	○	●	○	○
INFINITI I35	CA33	2002-2004	BCM	●	●	●	○	●	●	001, 002
INFINITI I35	CA33	2002-2004	DIFF_LOCK	●	●	●	○	●	○	○
INFINITI I35	CA33	2002-2004	DISTANCE_CONTROL	●	●	●	○	●	○	○
INFINITI I35	CA33	2002-2004	DIU	●	●	●	○	●	○	○
INFINITI I35	CA33	2002-2004	ENGINE	●	●	●	※	●	●	001
INFINITI I35	CA33	2002-2004	EPS	●	●	●	○	●	○	002
INFINITI I35	CA33	2002-2004	E_4WD	●	●	●	○	●	●	002
INFINITI I35	CA33	2002-2004	HEAD_LAMP_LEVELIZER	●	●	●	○	●	●	001

INFINITI I35	CA33	2002-2004	HVAC	●	●	●	○	●	●	001
INFINITI I35	CA33	2002-2004	INTELLIGENT_KEY	●	●	●	○	●	●	001, 002
INFINITI I35	CA33	2002-2004	IPDM_ER	○	●	●	○	●	●	002
INFINITI I35	CA33	2002-2004	IVMS	●	●	●	○	●	○	○
INFINITI I35	CA33	2002-2004	LDW	●	●	●	○	●	●	001
INFINITI I35	CA33	2002-2004	METER	○	●	●	○	●	○	002
INFINITI I35	CA33	2002-2004	MOTORO_CONTROL_UNIT	●	●	●	○	●	○	001
INFINITI I35	CA33	2002-2004	MOTOR_ASSIST	○	●	●	○	●	○	001
INFINITI I35	CA33	2002-2004	MULTI_AV	○	●	●	○	●	○	○
INFINITI I35	CA33	2002-2004	NATS_IMMU	○	●	●	○	○	○	004, 006
INFINITI I35	CA33	2002-2004	RASHICAS	●	●	●	○	●	●	○
INFINITI I35	CA33	2002-2004	REARVIEW_CAMERA	●	○	○	○	●	○	001
INFINITI I35	CA33	2002-2004	S/BLIND_CAMERA	●	○	○	○	●	○	001
INFINITI I35	CA33	2002-2004	SMART_ENTRANCE	○	●	●	○	●	●	002
INFINITI I35	CA33	2002-2004	SONAR	●	●	●	○	●	●	○
INFINITI I35	CA33	2002-2004	TBDADAS_ICC	●	●	●	○	●	●	001, 002
INFINITI I35	CA33	2002-2004	TBDAVM	●	●	●	○	●	●	001
INFINITI I35	CA33	2002-2004	TCS	●	●	●	●	●	●	001
INFINITI I35	CA33	2002-2004	TRANSMISSION	●	●	●	○	●	○	001, 002
INFINITI JX35	L50	2012-2013	ABS	●	●	●	※	●	●	001
INFINITI JX35	L50	2012-2013	ACCELE_PEDAL_ACT	●	●	●	○	●	●	○
INFINITI JX35	L50	2012-2013	AIRBAG	●	●	●	●	●	○	003, 005, 008
INFINITI JX35	L50	2012-2013	ALL_MODE_AWD4WD	●	●	●	○	●	●	001
INFINITI JX35	L50	2012-2013	AUTO_DRIVE_POS	●	●	●	○	●	●	001
INFINITI JX35	L50	2012-2013	BCM	※	●	●	○	●	●	001, 002
INFINITI JX35	L50	2012-2013	ENGINE	●	●	●	※	●	●	001
INFINITI JX35	L50	2012-2013	EPS	●	●	●	○	●	○	002
INFINITI JX35	L50	2012-2013	HEAD_LAMP_LEVELIZER	●	●	●	○	●	●	001
INFINITI JX35	L50	2012-2013	HVAC	●	●	●	○	●	●	001
INFINITI JX35	L50	2012-2013	IPDM E/R	○	●	●	○	●	●	002
INFINITI JX35	L50	2012-2013	LANE_CAMERA	●	●	●	○	●	●	001
INFINITI JX35	L50	2012-2013	LASER/RADAR	●	●	●	○	●	○	001
INFINITI JX35	L50	2012-2013	METER	※	●	●	○	●	○	002
INFINITI JX35	L50	2012-2013	MULTI_AV	※	●	●	○	●	○	○
INFINITI JX35	L50	2012-2013	PRECRASH_SEATBELT	●	●	●	○	●	○	001
INFINITI JX35	L50	2012-2013	SIDE_RADAR_LEFT	●	●	●	○	●	●	001
INFINITI JX35	L50	2012-2013	SIDE_RADAR_RIGHT	●	●	●	○	●	●	001
INFINITI JX35	L50	2012-2013	SONAR	●	●	●	○	●	●	○
INFINITI JX35	L50	2012-2013	ICC/ADAS	●	●	●	※	●	●	001, 002

INFINITI JX35	L50	2012-2013	AVM	●	●	●	○	●	●	001
INFINITI JX35	L50	2012-2013	TRANSMISSION	●	●	●	※	●	※	001, 002
INFINITI M25/M37	Y51	2010-2012	4WASCAN	●	●	●	○	●	●	○
INFINITI M25/M37	Y51	2010-2012	ABS	●	●	●	※	●	●	001
INFINITI M25/M37	Y51	2010-2012	ACCELE_PEDAL_ACT	●	●	●	○	●	●	○
INFINITI M25/M37	Y51	2010-2012	ADAPTIVE_LIGHT	●	●	●	○	●	●	001
INFINITI M25/M37	Y51	2010-2012	AIRBAG	●	●	●	●	●	○	003, 005, 008
INFINITI M25/M37	Y51	2010-2012	AIR_PRESSURE_MONITOR	●	●	●	○	●	●	001
INFINITI M25/M37	Y51	2010-2012	ALL_MODE_AWD4WD	●	●	●	○	●	●	001
INFINITI M25/M37	Y51	2010-2012	AUTO_DRIVE_POS	●	●	●	○	●	●	001
INFINITI M25/M37	Y51	2010-2012	BCM	※	●	●	○	●	●	001, 002
INFINITI M25/M37	Y51	2010-2012	CONVERTIBLE_ROOF	●	●	●	○	●	●	001
INFINITI M25/M37	Y51	2010-2012	ENGINE	●	●	●	※	●	●	001
INFINITI M25/M37	Y51	2010-2012	E_SUS	●	●	●	○	●	●	001
INFINITI M25/M37	Y51	2010-2012	HEAD_LAMP_LEVELIZER	●	●	●	○	●	●	001
INFINITI M25/M37	Y51	2010-2012	HVAC	●	●	●	○	●	●	001
INFINITI M25/M37	Y51	2010-2012	IPDM E/R	○	●	●	○	●	●	002
INFINITI M25/M37	Y51	2010-2012	LANE_CAMERA	●	●	●	○	●	●	001
INFINITI M25/M37	Y51	2010-2012	LASER/RADAR	●	●	●	○	●	○	001
INFINITI M25/M37	Y51	2010-2012	METER	※	●	●	○	●	○	002
INFINITI M25/M37	Y51	2010-2012	MULTI_AV	※	●	●	○	●	○	○
INFINITI M25/M37	Y51	2010-2012	POP_UP_HOOD	●	●	●	○	●	○	008
INFINITI M25/M37	Y51	2010-2012	PRECRASH_SEATBELT	●	●	●	○	●	○	001
INFINITI M25/M37	Y51	2010-2012	SIDE_RADAR_LEFT	●	●	●	○	●	●	001
INFINITI M25/M37	Y51	2010-2012	SIDE_RADAR_RIGHT	●	●	●	○	●	●	001
INFINITI M25/M37	Y51	2010-2012	SONAR	●	●	●	○	●	●	○
INFINITI M25/M37	Y51	2010-2012	ICC/ADAS	●	●	●	※	●	●	001, 002
INFINITI M25/M37	Y51	2010-2012	TRANSMISSION	●	●	●	※	●	※	001, 002
INFINITI M35/M45	Y50	2006-2010	ABS	●	●	●	※	●	●	001
INFINITI M35/M45	Y50	2006-2010	ADAPTIVE_LIGHT	●	●	●	○	●	●	001
INFINITI M35/M45	Y50	2006-2010	AIRBAG	●	●	●	●	●	○	003, 005, 008
INFINITI M35/M45	Y50	2006-2010	AIR_PRESSURE_MONITOR	●	●	●	○	●	●	001
INFINITI M35/M45	Y50	2006-2010	ALL_MODE_AWD4WD	●	●	●	○	●	●	001
INFINITI M35/M45	Y50	2006-2010	AUTO_DRIVE_POS	●	●	●	○	●	●	001
INFINITI M35/M45	Y50	2006-2010	BCM	※	●	●	○	●	●	001, 002
INFINITI M35/M45	Y50	2006-2010	ENGINE	●	●	●	※	●	●	001
INFINITI M35/M45	Y50	2006-2010	INTELLIGENT_KEY	●	●	●	○	●	●	001, 002
INFINITI M35/M45	Y50	2006-2010	IPDM E/R	○	●	●	○	●	●	002
INFINITI M35/M45	Y50	2006-2010	LASER/RADAR	●	●	●	○	●	○	001



INFINITI M35/M45	Y50	2006-2010	METER	※	●	●	○	●	○	002
INFINITI M35/M45	Y50	2006-2010	MULTI_AV	※	●	●	○	●	○	○
INFINITI M35/M45	Y50	2006-2010	PRECRASH_SEATBELT	●	●	●	○	●	○	001
INFINITI M35/M45	Y50	2006-2010	REARVIEW_CAMERA	●	○	○	○	●	○	001
INFINITI M35/M45	Y50	2006-2010	SONAR	●	●	●	○	●	●	○
INFINITI M35/M45	Y50	2006-2010	ICC/ADAS	●	●	●	※	●	●	001, 002
INFINITI M35/M45	Y50	2006-2010	TRANSMISSION	●	●	●	※	●	※	001, 002
INFINITI M37	Y51	2012	4WASCAN	●	●	●	○	●	●	○
INFINITI M37	Y51	2012	ABS	●	●	●	※	●	●	001
INFINITI M37	Y51	2012	ACCELE_PEDAL_ACT	●	●	●	○	●	●	○
INFINITI M37	Y51	2012	ADAPTIVE_LIGHT	●	●	●	○	●	●	001
INFINITI M37	Y51	2012	AIRBAG	●	●	●	●	●	○	003, 005, 008
INFINITI M37	Y51	2012	AIR_PRESSURE_MONITOR	●	●	●	○	●	●	001
INFINITI M37	Y51	2012	ALL_MODE_AWD4WD	●	●	●	○	●	●	001
INFINITI M37	Y51	2012	AUTO_DRIVE_POS	●	●	●	○	●	●	001
INFINITI M37	Y51	2012	BCM	※	●	●	○	●	●	001, 002
INFINITI M37	Y51	2012	ENGINE	●	●	●	※	●	●	001
INFINITI M37	Y51	2012	HEAD_LAMP_LEVELIZER	●	●	●	○	●	●	001
INFINITI M37	Y51	2012	HVAC	●	●	●	○	●	●	001
INFINITI M37	Y51	2012	IPDM_E/R	○	●	●	○	●	●	002
INFINITI M37	Y51	2012	LANE_CAMERA	●	●	●	○	●	●	001
INFINITI M37	Y51	2012	LASER/RADAR	●	●	●	○	●	○	001
INFINITI M37	Y51	2012	METER	※	●	●	○	●	○	002
INFINITI M37	Y51	2012	MULTI_AV	※	●	●	○	●	○	○
INFINITI M37	Y51	2012	SIDE_RADAR_LEFT	●	●	●	○	●	●	001
INFINITI M37	Y51	2012	SIDE_RADAR_RIGHT	●	●	●	○	●	●	001
INFINITI M37	Y51	2012	SONAR	●	●	●	○	●	●	○
INFINITI M37	Y51	2012	ICC	●	●	●	※	●	●	001, 002
INFINITI M37	Y51	2012	TRANSMISSION	●	●	●	※	●	※	001, 002
INFINITI M37/M56	Y51	2010-2013	4WASCAN	●	●	●	○	●	●	○
INFINITI M37/M56	Y51	2010-2013	ABS	●	●	●	※	●	●	001
INFINITI M37/M56	Y51	2010-2013	ACCELE_PEDAL_ACT	●	●	●	○	●	●	○
INFINITI M37/M56	Y51	2010-2013	ADAPTIVE_LIGHT	●	●	●	○	●	●	001
INFINITI M37/M56	Y51	2010-2013	AIRBAG	●	●	●	●	●	○	003, 005, 008
INFINITI M37/M56	Y51	2010-2013	AIR_PRESSURE_MONITOR	●	●	●	○	●	●	001
INFINITI M37/M56	Y51	2010-2013	ALL_MODE_AWD4WD	●	●	●	○	●	●	001
INFINITI M37/M56	Y51	2010-2013	AUTO_DRIVE_POS	●	●	●	○	●	●	001
INFINITI M37/M56	Y51	2010-2013	BCM	※	●	●	○	●	●	001, 002
INFINITI M37/M56	Y51	2010-2013	ENGINE	●	●	●	※	●	●	001

INFINITI M37/M56	Y51	2010-2013	HEAD LAMP LEVELIZER	●	●	●	○	●	●	001
INFINITI M37/M56	Y51	2010-2013	HVAC	●	●	●	○	●	●	001
INFINITI M37/M56	Y51	2010-2013	IPDM E/R	○	●	●	○	●	●	002
INFINITI M37/M56	Y51	2010-2013	LANE CAMERA	●	●	●	○	●	●	001
INFINITI M37/M56	Y51	2010-2013	LASER/RADAR	●	●	●	○	●	○	001
INFINITI M37/M56	Y51	2010-2013	METER	※	●	●	○	●	○	002
INFINITI M37/M56	Y51	2010-2013	MULTI_AV	※	●	●	○	●	○	○
INFINITI M37/M56	Y51	2010-2013	SIDE_RADAR_LEFT	●	●	●	○	●	●	001
INFINITI M37/M56	Y51	2010-2013	SIDE_RADAR_RIGHT	●	●	●	○	●	●	001
INFINITI M37/M56	Y51	2010-2013	SONAR	●	●	●	○	●	●	○
INFINITI M37/M56	Y51	2010-2013	ICC	●	●	●	※	●	●	001, 002
INFINITI M37/M56	Y51	2010-2013	TRANSMISSION	●	●	●	※	●	※	001, 002
INFINITI M37/M56/M30d	Y51	2010-2012	4WASCAN	●	●	●	○	●	●	○
INFINITI M37/M56/M30d	Y51	2010-2012	ABS	●	●	●	※	●	●	001
INFINITI M37/M56/M30d	Y51	2010-2012	ACCELE_PEDAL_ACT	●	●	●	○	●	●	○
INFINITI M37/M56/M30d	Y51	2010-2012	ADAPTIVE_LIGHT	●	●	●	○	●	●	001
INFINITI M37/M56/M30d	Y51	2010-2012	AIRBAG	●	●	●	●	●	○	003, 005, 008
INFINITI M37/M56/M30d	Y51	2010-2012	AIR_PRESSURE_MONITOR	●	●	●	○	●	●	001
INFINITI M37/M56/M30d	Y51	2010-2012	ALL_MODE_AWD4WD	●	●	●	○	●	●	001
INFINITI M37/M56/M30d	Y51	2010-2012	AUTO_DRIVE_POS	●	●	●	○	●	●	001
INFINITI M37/M56/M30d	Y51	2010-2012	BCM	※	●	●	○	●	●	001, 002
INFINITI M37/M56/M30d	Y51	2010-2012	CONVERTIBLE_ROOF	●	●	●	○	●	●	001
INFINITI M37/M56/M30d	Y51	2010-2012	DIGITAL_SOUND_CONTROLLER	●	●	●	○	●	○	○
INFINITI M37/M56/M30d	Y51	2010-2012	ENGINE	●	●	●	※	●	●	001
INFINITI M37/M56/M30d	Y51	2010-2012	E_SUS	●	●	●	○	●	●	001
INFINITI M37/M56/M30d	Y51	2010-2012	EV/HEV	●	●	●	●	●	●	001
INFINITI M37/M56/M30d	Y51	2010-2012	HEAD LAMP LEVELIZER	●	●	●	○	●	●	001
INFINITI M37/M56/M30d	Y51	2010-2012	HVAC	●	●	●	○	●	●	001
INFINITI M37/M56/M30d	Y51	2010-2012	IPDM E/R	○	●	●	○	●	●	002
INFINITI M37/M56/M30d	Y51	2010-2012	LANE CAMERA	●	●	●	○	●	●	001
INFINITI M37/M56/M30d	Y51	2010-2012	LASER/RADAR	●	●	●	○	●	○	001
INFINITI M37/M56/M30d	Y51	2010-2012	HV BATTERY	●	●	●	●	●	●	001
INFINITI M37/M56/M30d	Y51	2010-2012	METER	※	●	●	○	●	○	002
INFINITI M37/M56/M30d	Y51	2010-2012	MOTORO_CONTROL_UNIT	●	●	●	※	●	○	001
INFINITI M37/M56/M30d	Y51	2010-2012	MULTI_AV	※	●	●	○	●	○	○
INFINITI M37/M56/M30d	Y51	2010-2012	POP_UP_HOOD	●	●	●	○	●	○	008
INFINITI M37/M56/M30d	Y51	2010-2012	PRECRASH_SEATBELT	●	●	●	○	●	○	001
INFINITI M37/M56/M30d	Y51	2010-2012	SIDE_RADAR_LEFT	●	●	●	○	●	●	001
INFINITI M37/M56/M30d	Y51	2010-2012	SIDE_RADAR_RIGHT	●	●	●	○	●	●	001

INFINITI M37/M56/M30d	Y51	2010-2012	SONAR	●	●	●	○	●	●	○
INFINITI M37/M56/M30d	Y51	2010-2012	ICC	●	●	●	※	●	●	001, 002
INFINITI M37/M56/M30d	Y51	2010-2012	TRANSMISSION	●	●	●	※	●	※	001, 002
INFINITI M45	Y34	2003-2005	ABS	●	●	●	○	●	●	001
INFINITI M45	Y34	2003-2005	ACM	●	●	●	○	●	○	○
INFINITI M45	Y34	2003-2005	ACTIVE_SUS	●	●	●	●	●	●	001
INFINITI M45	Y34	2003-2005	ADAPTIVE_LIGHT	●	●	●	○	●	●	001
INFINITI M45	Y34	2003-2005	AIRBAG	●	●	●	●	●	○	003, 005, 008
INFINITI M45	Y34	2003-2005	AIR_LEVELIZER	●	●	●	○	●	●	001
INFINITI M45	Y34	2003-2005	AIR_PRESSURE_MONITOR	●	●	●	○	●	●	001
INFINITI M45	Y34	2003-2005	ALL_MODE_AWD4WD	●	●	●	○	●	●	001
INFINITI M45	Y34	2003-2005	ASCD	○	●	●	○	●	○	○
INFINITI M45	Y34	2003-2005	AUTO_DRIVE_POS	●	●	●	○	●	●	001
INFINITI M45	Y34	2003-2005	AUTO_SLIDE_DOOR	●	●	●	○	●	○	○
INFINITI M45	Y34	2003-2005	BCM	●	●	●	○	●	●	001, 002
INFINITI M45	Y34	2003-2005	DIFF_LOCK	●	●	●	○	●	○	○
INFINITI M45	Y34	2003-2005	DISTANCE_CONTROL	●	●	●	○	●	○	○
INFINITI M45	Y34	2003-2005	DIU	●	●	●	○	●	○	○
INFINITI M45	Y34	2003-2005	ENGINE	●	●	●	※	●	●	001
INFINITI M45	Y34	2003-2005	EPS	●	●	●	○	●	○	002
INFINITI M45	Y34	2003-2005	E_4WD	●	●	●	○	●	●	002
INFINITI M45	Y34	2003-2005	HEAD_LAMP_LEVELIZER	●	●	●	○	●	●	001
INFINITI M45	Y34	2003-2005	HVAC	●	●	●	○	●	●	001
INFINITI M45	Y34	2003-2005	INTELLIGENT_KEY	●	●	●	○	●	●	001, 002
INFINITI M45	Y34	2003-2005	IPDM_ER	○	●	●	○	●	●	002
INFINITI M45	Y34	2003-2005	IVMS	●	●	●	○	●	○	○
INFINITI M45	Y34	2003-2005	LDW	●	●	●	○	●	●	001
INFINITI M45	Y34	2003-2005	METER	○	●	●	○	●	○	002
INFINITI M45	Y34	2003-2005	MOTORO_CONTROL_UNIT	●	●	●	○	●	○	001
INFINITI M45	Y34	2003-2005	MOTOR_ASSIST	○	●	●	○	●	○	001
INFINITI M45	Y34	2003-2005	MULTI_AV	○	●	●	○	●	○	○
INFINITI M45	Y34	2003-2005	NATS_IMMU	○	●	●	○	○	○	004, 006
INFINITI M45	Y34	2003-2005	RASHICAS	●	●	●	○	●	●	○
INFINITI M45	Y34	2003-2005	REARVIEW_CAMERA	●	○	○	○	●	○	001
INFINITI M45	Y34	2003-2005	S/BLIND_CAMERA	●	○	○	○	●	○	001
INFINITI M45	Y34	2003-2005	SMART_ENTRANCE	○	●	●	○	●	●	002
INFINITI M45	Y34	2003-2005	SONAR	●	●	●	○	●	●	○
INFINITI M45	Y34	2003-2005	TBDADAS_ICC	●	●	●	○	●	●	001, 002
INFINITI M45	Y34	2003-2005	TBDAVM	●	●	●	○	●	●	001

INFINITI M45	Y34	2003-2005	TCS	●	●	●	●	●	●	001
INFINITI M45	Y34	2003-2005	TRANSMISSION	●	●	●	○	●	○	001, 002
INFINITI Q45	F50	ALL	ABS	●	●	●	○	●	●	001
INFINITI Q45	F50	ALL	ACM	●	●	●	○	●	○	○
INFINITI Q45	F50	ALL	ACTIVE_SUS	●	●	●	●	●	●	001
INFINITI Q45	F50	ALL	ADAPTIVE_LIGHT	●	●	●	○	●	●	001
INFINITI Q45	F50	ALL	AIRBAG	●	●	●	●	●	○	003, 005, 008
INFINITI Q45	F50	ALL	AIR_LEVELIZER	●	●	●	○	●	●	001
INFINITI Q45	F50	ALL	AIR_PRESSURE_MONITOR	●	●	●	○	●	●	001
INFINITI Q45	F50	ALL	ALL_MODE_AWD4WD	●	●	●	○	●	●	001
INFINITI Q45	F50	ALL	ASCD	○	●	●	○	●	○	○
INFINITI Q45	F50	ALL	AUTO_DRIVE_POS	●	●	●	○	●	●	001
INFINITI Q45	F50	ALL	AUTO_SLIDE_DOOR	●	●	●	○	●	○	○
INFINITI Q45	F50	ALL	BCM	●	●	●	○	●	●	001, 002
INFINITI Q45	F50	ALL	DIFF_LOCK	●	●	●	○	●	○	○
INFINITI Q45	F50	ALL	DISTANCE_CONTROL	●	●	●	○	●	○	○
INFINITI Q45	F50	ALL	DIU	●	●	●	○	●	○	○
INFINITI Q45	F50	ALL	ENGINE	●	●	●	※	●	●	001
INFINITI Q45	F50	ALL	EPS	●	●	●	○	●	○	002
INFINITI Q45	F50	ALL	E_4WD	●	●	●	○	●	●	002
INFINITI Q45	F50	ALL	HEAD_LAMP_LEVELIZER	●	●	●	○	●	●	001
INFINITI Q45	F50	ALL	HVAC	●	●	●	○	●	●	001
INFINITI Q45	F50	ALL	INTELLIGENT_KEY	●	●	●	○	●	●	001, 002
INFINITI Q45	F50	ALL	IPDM_ER	○	●	●	○	●	●	002
INFINITI Q45	F50	ALL	IVMS	●	●	●	○	●	○	○
INFINITI Q45	F50	ALL	LDW	●	●	●	○	●	●	001
INFINITI Q45	F50	ALL	METER	○	●	●	○	●	○	002
INFINITI Q45	F50	ALL	MOTORO_CONTROL_UNIT	●	●	●	○	●	○	001
INFINITI Q45	F50	ALL	MOTOR_ASSIST	○	●	●	○	●	○	001
INFINITI Q45	F50	ALL	MULTI_AV	○	●	●	○	●	○	○
INFINITI Q45	F50	ALL	NATS_IMMU	○	●	●	○	○	○	004, 006
INFINITI Q45	F50	ALL	RASHICAS	●	●	●	○	●	●	○
INFINITI Q45	F50	ALL	REARVIEW_CAMERA	●	○	○	○	●	○	001
INFINITI Q45	F50	ALL	S/BLIND_CAMERA	●	○	○	○	●	○	001
INFINITI Q45	F50	ALL	SMART_ENTRANCE	○	●	●	○	●	●	002
INFINITI Q45	F50	ALL	SONAR	●	●	●	○	●	●	○
INFINITI Q45	F50	ALL	TBDADAS_ICC	●	●	●	○	●	●	001, 002
INFINITI Q45	F50	ALL	TBDAVM	●	●	●	○	●	●	001
INFINITI Q45	F50	ALL	TCS	●	●	●	●	●	●	001

INFINITI Q45	F50	ALL	TRANSMISSION	●	●	●	○	●	○	001, 002
INFINITI QX4	F50	1997-2003	ABS	●	●	●	○	●	●	001
INFINITI QX4	F50	1997-2003	ACM	●	●	●	○	●	○	○
INFINITI QX4	F50	1997-2003	ACTIVE_SUS	●	●	●	●	●	●	001
INFINITI QX4	F50	1997-2003	ADAPTIVE_LIGHT	●	●	●	○	●	●	001
INFINITI QX4	F50	1997-2003	AIRBAG	●	●	●	●	●	○	003, 005, 008
INFINITI QX4	F50	1997-2003	AIR_LEVELIZER	●	●	●	○	●	●	001
INFINITI QX4	F50	1997-2003	AIR_PRESSURE_MONITOR	●	●	●	○	●	●	001
INFINITI QX4	F50	1997-2003	ALL_MODE_AWD4WD	●	●	●	○	●	●	001
INFINITI QX4	F50	1997-2003	ASCD	○	●	●	○	●	○	○
INFINITI QX4	F50	1997-2003	AUTO_DRIVE_POS	●	●	●	○	●	●	001
INFINITI QX4	F50	1997-2003	AUTO_SLIDE_DOOR	●	●	●	○	●	○	○
INFINITI QX4	F50	1997-2003	BCM	●	●	●	○	●	●	001, 002
INFINITI QX4	F50	1997-2003	DIFF_LOCK	●	●	●	○	●	○	○
INFINITI QX4	F50	1997-2003	DISTANCE_CONTROL	●	●	●	○	●	○	○
INFINITI QX4	F50	1997-2003	DIU	●	●	●	○	●	○	○
INFINITI QX4	F50	1997-2003	ENGINE	●	●	●	※	●	●	001
INFINITI QX4	F50	1997-2003	EPS	●	●	●	○	●	○	002
INFINITI QX4	F50	1997-2003	E_4WD	●	●	●	○	●	●	002
INFINITI QX4	F50	1997-2003	HEAD_LAMP_LEVELIZER	●	●	●	○	●	●	001
INFINITI QX4	F50	1997-2003	HVAC	●	●	●	○	●	●	001
INFINITI QX4	F50	1997-2003	INTELLIGENT_KEY	●	●	●	○	●	●	001, 002
INFINITI QX4	F50	1997-2003	IPDM_ER	○	●	●	○	●	●	002
INFINITI QX4	F50	1997-2003	IVMS	●	●	●	○	●	○	○
INFINITI QX4	F50	1997-2003	LDW	●	●	●	○	●	●	001
INFINITI QX4	F50	1997-2003	METER	○	●	●	○	●	○	002
INFINITI QX4	F50	1997-2003	MOTORO_CONTROL_UNIT	●	●	●	○	●	○	001
INFINITI QX4	F50	1997-2003	MOTOR_ASSIST	○	●	●	○	●	○	001
INFINITI QX4	F50	1997-2003	MULTI_AV	○	●	●	○	●	○	○
INFINITI QX4	F50	1997-2003	NATS_IMMU	○	●	●	○	○	○	004, 006
INFINITI QX4	F50	1997-2003	RASHICAS	●	●	●	○	●	●	○
INFINITI QX4	F50	1997-2003	REARVIEW_CAMERA	●	○	○	○	●	○	001
INFINITI QX4	F50	1997-2003	S/BLIND_CAMERA	●	○	○	○	●	○	001
INFINITI QX4	F50	1997-2003	SMART_ENTRANCE	○	●	●	○	●	●	002
INFINITI QX4	F50	1997-2003	SONAR	●	●	●	○	●	●	○
INFINITI QX4	F50	1997-2003	TBDADAS_ICC	●	●	●	○	●	●	001, 002
INFINITI QX4	F50	1997-2003	TBDAVM	●	●	●	○	●	●	001
INFINITI QX4	F50	1997-2003	TCS	●	●	●	●	●	●	001
INFINITI QX4	F50	1997-2003	TRANSMISSION	●	●	●	○	●	○	001, 002

INFINITI QX56	JA60	2004-2010	ABS	●	●	●	○	●	●	001
INFINITI QX56	JA60	2004-2010	ACM	●	●	●	○	●	○	○
INFINITI QX56	JA60	2004-2010	ACTIVE_SUS	●	●	●	●	●	●	001
INFINITI QX56	JA60	2004-2010	ADAPTIVE_LIGHT	●	●	●	○	●	●	001
INFINITI QX56	JA60	2004-2010	AIRBAG	●	●	●	●	●	○	003, 005, 008
INFINITI QX56	JA60	2004-2010	AIR_LEVELIZER	●	●	●	○	●	●	001
INFINITI QX56	JA60	2004-2010	AIR_PRESSURE_MONITOR	●	●	●	○	●	●	001
INFINITI QX56	JA60	2004-2010	ALL_MODE_AWD4WD	●	●	●	○	●	●	001
INFINITI QX56	JA60	2004-2010	ASCD	○	●	●	○	●	○	○
INFINITI QX56	JA60	2004-2010	AUTO_DRIVE_POS	●	●	●	○	●	●	001
INFINITI QX56	JA60	2004-2010	AUTO_SLIDE_DOOR	●	●	●	○	●	○	○
INFINITI QX56	JA60	2004-2010	BCM	●	●	●	○	●	●	001, 002
INFINITI QX56	JA60	2004-2010	DIFF_LOCK	●	●	●	○	●	○	○
INFINITI QX56	JA60	2004-2010	DISTANCE_CONTROL	●	●	●	○	●	○	○
INFINITI QX56	JA60	2004-2010	DIU	●	●	●	○	●	○	○
INFINITI QX56	JA60	2004-2010	ENGINE	●	●	●	※	●	●	001
INFINITI QX56	JA60	2004-2010	EPS	●	●	●	○	●	○	002
INFINITI QX56	JA60	2004-2010	E_4WD	●	●	●	○	●	●	002
INFINITI QX56	JA60	2004-2010	HEAD_LAMP_LEVELIZER	●	●	●	○	●	●	001
INFINITI QX56	JA60	2004-2010	HVAC	●	●	●	○	●	●	001
INFINITI QX56	JA60	2004-2010	INTELLIGENT_KEY	●	●	●	○	●	●	001, 002
INFINITI QX56	JA60	2004-2010	IPDM_ER	○	●	●	○	●	●	002
INFINITI QX56	JA60	2004-2010	IVMS	●	●	●	○	●	○	○
INFINITI QX56	JA60	2004-2010	LDW	●	●	●	○	●	●	001
INFINITI QX56	JA60	2004-2010	METER	○	●	●	○	●	○	002
INFINITI QX56	JA60	2004-2010	MOTORO_CONTROL_UNIT	●	●	●	○	●	○	001
INFINITI QX56	JA60	2004-2010	MOTOR_ASSIST	○	●	●	○	●	○	001
INFINITI QX56	JA60	2004-2010	MULTI_AV	○	●	●	○	●	○	○
INFINITI QX56	JA60	2004-2010	NATS_IMMU	○	●	●	○	○	○	004, 006
INFINITI QX56	JA60	2004-2010	RASHICAS	●	●	●	○	●	●	○
INFINITI QX56	JA60	2004-2010	REARVIEW_CAMERA	●	○	○	○	●	○	001
INFINITI QX56	JA60	2004-2010	S/BLIND_CAMERA	●	○	○	○	●	○	001
INFINITI QX56	JA60	2004-2010	SMART_ENTRANCE	○	●	●	○	●	●	002
INFINITI QX56	JA60	2004-2010	SONAR	●	●	●	○	●	●	○
INFINITI QX56	JA60	2004-2010	TBDADAS_ICC	●	●	●	○	●	●	001, 002
INFINITI QX56	JA60	2004-2010	TBDAVM	●	●	●	○	●	●	001
INFINITI QX56	JA60	2004-2010	TCS	●	●	●	●	●	●	001
INFINITI QX56	JA60	2004-2010	TRANSMISSION	●	●	●	○	●	○	001, 002
INFINITI QX56	Z62	2010-2012	ABS	●	●	●	※	●	●	001

INFINITI QX56	Z62	2010-2012	ACCELE_PEDAL_ACT	●	●	●	○	●	●	○
INFINITI QX56	Z62	2010-2012	ADAPTIVE_LIGHT	●	●	●	○	●	●	001
INFINITI QX56	Z62	2010-2012	AIRBAG	●	●	●	●	●	○	003, 005, 008
INFINITI QX56	Z62	2010-2012	AIR_PRESSURE_MONITOR	●	●	●	○	●	●	001
INFINITI QX56	Z62	2010-2012	ALL_MODE_AWD4WD	●	●	●	○	●	●	001
INFINITI QX56	Z62	2010-2012	AUTO_DRIVE_POS	●	●	●	○	●	●	001
INFINITI QX56	Z62	2010-2012	BCM	※	●	●	○	●	●	001, 002
INFINITI QX56	Z62	2010-2012	ENGINE	●	●	●	※	●	●	001
INFINITI QX56	Z62	2010-2012	E_SUS	●	●	●	○	●	●	001
INFINITI QX56	Z62	2010-2012	HEAD_LAMP_LEVELIZER	●	●	●	○	●	●	001
INFINITI QX56	Z62	2010-2012	HVAC	●	●	●	○	●	●	001
INFINITI QX56	Z62	2010-2012	IPDM E/R	○	●	●	○	●	●	002
INFINITI QX56	Z62	2010-2012	LANE_CAMERA	●	●	●	○	●	●	001
INFINITI QX56	Z62	2010-2012	LASER/RADAR	●	●	●	○	●	○	001
INFINITI QX56	Z62	2010-2012	METER	※	●	●	○	●	○	002
INFINITI QX56	Z62	2010-2012	MULTI_AV	※	●	●	○	●	○	○
INFINITI QX56	Z62	2010-2012	PRECRASH_SEATBELT	●	●	●	○	●	○	001
INFINITI QX56	Z62	2010-2012	REARVIEW_CAMERA	●	○	○	○	●	○	001
INFINITI QX56	Z62	2010-2012	SIDE_RADAR_LEFT	●	●	●	○	●	●	001
INFINITI QX56	Z62	2010-2012	SIDE_RADAR_RIGHT	●	●	●	○	●	●	001
INFINITI QX56	Z62	2010-2012	SONAR	●	●	●	○	●	●	○
INFINITI QX56	Z62	2010-2012	ICC	●	●	●	※	●	●	001, 002
INFINITI QX56	Z62	2010-2012	TRANSMISSION	●	●	●	※	●	※	001, 002

## Special\_Function

Index	Special Function Name	Index	Special Function Name
0001	work support	0002	CAN DIAG SUPPORT MNTR
0003	ECU DISCRIMINATED NO	0004	C/U INITIALIZATION
0005	READ CODES [PAST]	0006	SELF FOUNCTION CHECK
0007	CALIBRATION DATA	0008	TROUBLE DIAG RECORD