

# MaxiDas\_BENTLEY\_V6.50 Function List

NOTES:

- This function is supported.                      ✖ This function may be supported, which depends on the actual condition of the vehicle.
  - This function is not supported.                ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

| Control Unit       | ECU Info. | Read Codes | Erase Codes | Live Data | Freeze Frame | Active Test | Special Function (●)               | Special Function (✖)         |
|--------------------|-----------|------------|-------------|-----------|--------------|-------------|------------------------------------|------------------------------|
| ABS Brakes         | ●         | ●          | ●           | ●         | ✖            | ●           | 0001, 0002, 0003, 0004, 0005       | 0006, 0007, 0008, 0009, 000C |
| Auto Dist. Reg     | ●         | ●          | ●           | ●         | ✖            | ●           | 0001, 0002, 0003, 0004, 0005       | 0006, 0007, 0009             |
| Engine             | ●         | ●          | ●           | ●         | ✖            | ●           | 0001, 0002, 0003, 0004, 0005, 0008 | 0006, 0007, 0009             |
| Auto Trans         | ●         | ●          | ●           | ●         | ✖            | ●           | 0001, 0002, 0003, 0004, 0005       | 0006, 0007, 0009             |
| Auto HVAC          | ●         | ●          | ●           | ●         | ✖            | ●           | 0001, 0002, 0003, 0004, 0005       | 0006, 0007, 0009             |
| Cent. Elect.       | ●         | ●          | ●           | ●         | ✖            | ●           | 0001, 0002, 0003, 0004, 0005       | 0006, 0007, 0009             |
| Park/Steer Assist  | ●         | ●          | ●           | ●         | ✖            | ●           | 0001, 0002, 0003, 0004, 0005       | 0006, 0007, 0009             |
| Airbags            | ●         | ●          | ●           | ●         | ✖            | ●           | 0001, 0002, 0003, 0004, 0005       | 0006, 0007, 0009             |
| Steering wheel     | ●         | ●          | ●           | ●         | ✖            | ●           | 0001, 0002, 0003, 0004, 0005       | 0006, 0007, 0009             |
| Instruments        | ●         | ●          | ●           | ●         | ✖            | ●           | 0001, 0002, 0003, 0004, 0005       | 0006, 0007, 0009, 000A       |
| Aux. Heat          | ●         | ●          | ●           | ●         | ✖            | ●           | 0001, 0002, 0003, 0004, 0005       | 0006, 0007, 0009             |
| CAN Gateway        | ●         | ●          | ●           | ●         | ✖            | ●           | 0001, 0002, 0003, 0004, 0005       | 0006, 0007, 0009             |
| Engine II          | ●         | ●          | ●           | ●         | ✖            | ●           | 0001, 0002, 0003, 0004, 0005       | 0006, 0007, 0009             |
| Engine III         | ●         | ●          | ●           | ●         | ✖            | ●           | 0001, 0002, 0003, 0004, 0005       | 0006, 0007, 0009             |
| AWD                | ●         | ●          | ●           | ●         | ✖            | ●           | 0001, 0002, 0003, 0004, 0005       | 0006, 0007, 0009             |
| Immobilizer        | ●         | ●          | ●           | ●         | ✖            | ●           | 0001, 0002, 0003, 0004, 0005       | 0006, 0007, 0009             |
| Centr. Locks       | ●         | ●          | ●           | ●         | ✖            | ●           | 0001, 0002, 0003, 0004, 0005       | 0006, 0007, 0009             |
| Navigation         | ●         | ●          | ●           | ●         | ✖            | ●           | 0001, 0002, 0003, 0004, 0005       | 0006, 0007, 0009             |
| Inter. Monitor     | ●         | ●          | ●           | ●         | ✖            | ●           | 0001, 0002, 0003, 0004, 0005       | 0006, 0007, 0009             |
| Central Conv.      | ●         | ●          | ●           | ●         | ✖            | ●           | 0001, 0002, 0003, 0004, 0005       | 0006, 0007, 0009             |
| Xenon Range        | ●         | ●          | ●           | ●         | ✖            | ●           | 0001, 0002, 0003, 0004, 0005       | 0006, 0007, 0009             |
| Radio              | ●         | ●          | ●           | ●         | ✖            | ●           | 0001, 0002, 0003, 0004, 0005       | 0006, 0007, 0009             |
| Engine Conjunct.   | ●         | ●          | ●           | ●         | ✖            | ●           | 0001, 0002, 0003, 0004, 0005       | 0006, 0007, 0009             |
| Diesel pump        | ●         | ●          | ●           | ●         | ✖            | ●           | 0001, 0002, 0003, 0004, 0005       | 0006, 0007, 0009             |
| Electric drive     | ●         | ●          | ●           | ●         | ✖            | ●           | 0001, 0002, 0003, 0004, 0005       | 0006, 0007, 0009             |
| Battery Regul.     | ●         | ●          | ●           | ●         | ✖            | ●           | 0001, 0002, 0003, 0004, 0005       | 0006, 0007, 0009             |
| Battery charger    | ●         | ●          | ●           | ●         | ✖            | ●           | 0001, 0002, 0003, 0004, 0005       | 0006, 0007, 0009             |
| Clutch             | ●         | ●          | ●           | ●         | ✖            | ●           | 0001, 0002, 0003, 0004, 0005       | 0006, 0007, 0009             |
| Differential Locks | ●         | ●          | ●           | ●         | ✖            | ●           | 0001, 0002, 0003, 0004, 0005       | 0006, 0007, 0009             |
| Door Elect, Driver | ●         | ●          | ●           | ●         | ✖            | ●           | 0001, 0002, 0003, 0004, 0005       | 0006, 0007, 0009             |



# MaxiDas\_BENTLEY\_V6.50 Function List

**NOTES:**

- This function is supported.                     ※ This function may be supported, which depends on the actual condition of the vehicle.
  - This function is not supported.             ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.**

| Control Unit          | ECU Info. | Read Codes | Erase Codes | Live Data | Freeze Frame | Active Test | Special Function (●)         | Special Function (※)   |
|-----------------------|-----------|------------|-------------|-----------|--------------|-------------|------------------------------|------------------------|
| Voice Control         | ●         | ●          | ●           | ●         | ※            | ●           | 0001, 0002, 0003, 0004, 0005 | 0006, 0007, 0009       |
| Telephone             | ●         | ●          | ●           | ●         | ※            | ●           | 0001, 0002, 0003, 0004, 0005 | 0006, 0007, 0009       |
| HVAC, Rear            | ●         | ●          | ●           | ●         | ※            | ●           | 0001, 0002, 0003, 0004, 0005 | 0006, 0007, 0009       |
| Roof Electronics      | ●         | ●          | ●           | ●         | ※            | ●           | 0001, 0002, 0003, 0004, 0005 | 0006, 0007, 0009       |
| Seat, Rear, DS        | ●         | ●          | ●           | ●         | ※            | ●           | 0001, 0002, 0003, 0004, 0005 | 0006, 0007, 0009       |
| Auxiliary Fuel Tank   | ●         | ●          | ●           | ●         | ※            | ●           | 0001, 0002, 0003, 0004, 0005 | 0006, 0007, 0009       |
| Wiper Electr.         | ●         | ●          | ●           | ●         | ※            | ●           | 0001, 0002, 0003, 0004, 0005 | 0006, 0007, 0009       |
| Left light control    | ●         | ●          | ●           | ●         | ※            | ●           | 0001, 0002, 0003, 0004, 0005 | 0006, 0007, 0009       |
| Right light control   | ●         | ●          | ●           | ●         | ※            | ●           | 0001, 0002, 0003, 0004, 0005 | 0006, 0007, 0009       |
| Auto. Lighting switch | ●         | ●          | ●           | ●         | ※            | ●           | 0001, 0002, 0003, 0004, 0005 | 0006, 0007, 0009       |
| Towing Protection     | ●         | ●          | ●           | ●         | ※            | ●           | 0001, 0002, 0003, 0004, 0005 | 0006, 0007, 0009       |
| Trailer Function      | ●         | ●          | ●           | ●         | ※            | ●           | 0001, 0002, 0003, 0004, 0005 | 0006, 0007, 0009       |
| Sec. Air Heating      | ●         | ●          | ●           | ●         | ※            | ●           | 0001, 0002, 0003, 0004, 0005 | 0006, 0007, 0009       |
| Active Steering       | ●         | ●          | ●           | ●         | ※            | ●           | 0001, 0002, 0003, 0004, 0005 | 0006, 0007, 0008, 0009 |
| Position Sensing      | ●         | ●          | ●           | ●         | ※            | ●           | 0001, 0002, 0003, 0004, 0005 | 0006, 0007, 0009       |
| Lane Change           | ●         | ●          | ●           | ●         | ※            | ●           | 0001, 0002, 0003, 0004, 0005 | 0006, 0007, 0009       |
| Tire Pressure II      | ●         | ●          | ●           | ●         | ※            | ●           | 0001, 0002, 0003, 0004, 0005 | 0006, 0007, 0009       |
| Lane Maintain         | ●         | ●          | ●           | ●         | ※            | ●           | 0001, 0002, 0003, 0004, 0005 | 0006, 0007, 0009       |
| Back-up Cam.          | ●         | ●          | ●           | ●         | ※            | ●           | 0001, 0002, 0003, 0004, 0005 | 0006, 0007, 0009       |
| Sliding Door Left     | ●         | ●          | ●           | ●         | ※            | ●           | 0001, 0002, 0003, 0004, 0005 | 0006, 0007, 0009       |
| Driver Ident.         | ●         | ●          | ●           | ●         | ※            | ●           | 0001, 0002, 0003, 0004, 0005 | 0006, 0007, 0009       |
| Intercom              | ●         | ●          | ●           | ●         | ※            | ●           | 0001, 0002, 0003, 0004, 0005 | 0006, 0007, 0009       |
| Special Function      | ●         | ●          | ●           | ●         | ※            | ●           | 0001, 0002, 0003, 0004, 0005 | 0006, 0007, 0009       |
| Data Transfer         | ●         | ●          | ●           | ●         | ※            | ●           | 0001, 0002, 0003, 0004, 0005 | 0006, 0007, 0009       |
| Operations            | ●         | ●          | ●           | ●         | ※            | ●           | 0001, 0002, 0003, 0004, 0005 | 0006, 0007, 0009       |
| Trunk Elect.          | ●         | ●          | ●           | ●         | ※            | ●           | 0001, 0002, 0003, 0004, 0005 | 0006, 0007, 0009       |
| Auxiliary Heater      | ●         | ●          | ●           | ●         | ※            | ●           | 0001, 0002, 0003, 0004, 0005 | 0006, 0007, 0009       |
| Media Player 1        | ●         | ●          | ●           | ●         | ※            | ●           | 0001, 0002, 0003, 0004, 0005 | 0006, 0007, 0009       |

## MaxiDas\_BENTLEY\_V6.50 Function List

## NOTES:

- This function is supported.      ※ This function may be supported, which depends on the actual condition of the vehicle.  
 ○ This function is not supported.    ▲ This function is the new feature in this version.  
 As for special function please refer to the special function table.

| Control Unit        | ECU Info. | Read Codes | Erase Codes | Live Data | Freeze Frame | Active Test | Special Function (●)         | Special Function (※) |
|---------------------|-----------|------------|-------------|-----------|--------------|-------------|------------------------------|----------------------|
| Media Player 2      | ●         | ●          | ●           | ●         | ※            | ●           | 0001, 0002, 0003, 0004, 0005 | 0006, 0007, 0009     |
| Media Player 3      | ●         | ●          | ●           | ●         | ※            | ●           | 0001, 0002, 0003, 0004, 0005 | 0006, 0007, 0009     |
| Media Player 4      | ●         | ●          | ●           | ●         | ※            | ●           | 0001, 0002, 0003, 0004, 0005 | 0006, 0007, 0009     |
| Ctrl Head RR        | ●         | ●          | ●           | ●         | ※            | ●           | 0001, 0002, 0003, 0004, 0005 | 0006, 0007, 0009     |
| Ctrl Head LR        | ●         | ●          | ●           | ●         | ※            | ●           | 0001, 0002, 0003, 0004, 0005 | 0006, 0007, 0009     |
| Ctrl Head Roof      | ●         | ●          | ●           | ●         | ※            | ●           | 0001, 0002, 0003, 0004, 0005 | 0006, 0007, 0009     |
| Ctrl Head Dash      | ●         | ●          | ●           | ●         | ※            | ●           | 0001, 0002, 0003, 0004, 0005 | 0006, 0007, 0009     |
| Digital Radio       | ●         | ●          | ●           | ●         | ※            | ●           | 0001, 0002, 0003, 0004, 0005 | 0006, 0007, 0009     |
| Digital TV          | ●         | ●          | ●           | ●         | ※            | ●           | 0001, 0002, 0003, 0004, 0005 | 0006, 0007, 0009     |
| Centr. Electr. II   | ●         | ●          | ●           | ●         | ※            | ●           | 0001, 0002, 0003, 0004, 0005 | 0006, 0007, 0009     |
| Information Electr. | ●         | ●          | ●           | ●         | ※            | ●           | 0001, 0002, 0003, 0004, 0005 | 0006, 0007, 0009     |
| Centr. Conv. II     | ●         | ●          | ●           | ●         | ※            | ●           | 0001, 0002, 0003, 0004, 0005 | 0006, 0007, 0009     |
| Inform. Electr. II  | ●         | ●          | ●           | ●         | ※            | ●           | 0001, 0002, 0003, 0004, 0005 | 0006, 0007, 0009     |



## Special Function

| index | Specil Function Name |
|-------|----------------------|
| 0001  | Coding               |
| 0002  | Basic Settings       |
| 0003  | Adaptation           |
| 0004  | Security Access      |
| 0005  | AdvancedDataStream   |
| 0006  | Single Reading       |
| 0007  | Login CodingII       |
| 0008  | Readiness            |
| 0009  | Advanced ID          |
| 000A  | OilReset             |
| 000B  | EPB                  |
| 000C  | Steering             |
| 000D  | Read login password  |