

MaxiDas_Subaru_V3.20 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

| System Name | Read Codes | Erase Codes | Live Data | Special Function |
|-----------------------------|------------|-------------|-----------|------------------------------|
| Engine Control System | ● | ● | ● | 0001, 0002, 0003, 0004, 0005 |
| Transmission Control System | ● | ● | ● | 0005 |
| Brake Control System | ● | ● | ● | 0006, 0007 |
| Integ. unit mode | ● | ● | ● | 0008, 0009 |
| Airbag System | ● | ● | ○ | 0010 |
| CAN SYSTEM | ● | ○ | ○ | 0011 |
| Cruise Control System | ● | ○ | ● | 0003 |
| Keyless access system | ● | ● | ● | |
| Power Steering System | ● | ● | ● | 0007 |
| Tire Pressure Monitor | ● | ● | ● | 0013 |
| Occupant Detection System | ○ | ○ | ○ | 0012 |
| Parking Brake System | ● | ● | ● | 0007, 0014 |
| Air Condition System | ● | ● | ● | 0007, 0015, 0016 |



Special_Function

| index | Specil Function Name | index2 | Specil Function Name3 |
|-------|-----------------------------|--------|-------------------------------|
| 0001 | System Operation Check Mode | 0008 | Integ.Unit customizing |
| 0002 | Dealer Check Mode Procedure | 0009 | Function Check |
| 0003 | Cancel code(s) Display | 0010 | Status data |
| 0004 | Diagnosis Results | 0011 | Fault Location |
| 0005 | OBD SYSTEM | 0012 | Re-zeroing |
| 0006 | Function Check Sequence | 0013 | Transmitter ID regist confirm |
| 0007 | Freeze Frame | | |