Autel

MaxiDas_LandRover_V4.50 Fuction List

NOTES:

● This function is supported. ▲ This function is the new feature in this version.

○ This function is not supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

VehicleType	ModelYear	Engine Type	Capacity	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test
Defender	~2007			Engine	●	●	●	●	●
Defender	~2007			ABS	●	●	●	●	●
Defender	~2007			BCU	●			●	
Defender	2007	Diesel I4	2.4L	IPC	●	●	●	●	
Defender	2007	Diesel I4	2.4L	PCM	●	●	●	●	
Defender	2007	Diesel I4	2.4L	ABS	●	●	●		
Discovery	1994~1998			Engine	●	●	●	●	
Discovery	1998~2004			Engine	●	●	●	●	●
Discovery	1998~2004			AT	●	●	●	●	
Discovery	1998~2004			ABS	●	●	●	●	●
Discovery	1998~2004			SRS		●	●		
Discovery	1998~2004			Cruise Control	●	●	●	●	
Discovery	1998~2004			Active Cornering Enhancement	●	●	●	●	
Discovery	1998~2004			BCU	●			●	
Discovery	1998~2004			GAUGES	●			●	
Discovery	1998~2004			Heated Screen	●			●	
Discovery	1998~2004			Lighting	●			●	
Discovery	1998~2004			Power Distribution	●			●	
Discovery	1998~2004			Security	●			●	
Discovery	1998~2004			Warnings& Sounders	●			●	
Discovery	1998~2004			Washers& Wipers	●			●	
Discovery	1998~2004			Windows& Sunroof	●			●	
Discovery	2005-2009	Normal aspirated V6		ATCM	●	●	●	●	
Discovery	2005-2009	Normal aspirated V6		CCM	●	●	●	●	
Discovery	2005-2009	Normal aspirated V6		FLM	●	●	●	●	
Discovery	2005-2009	Normal aspirated V6		IPC	●	●	●	●	
Discovery	2005-2009	Normal aspirated V6		PBM	●	●	●	●	
Discovery	2005-2009	Normal aspirated V6		PCM	●	●	●	●	
Discovery	2005-2009	Normal aspirated V6		RCM	●	●	●	●	
Discovery	2005-2009	Normal aspirated V6		RDCM	●	●	●	●	

Autel

MaxiDas_LandRover_V4.50 Fuction List

NOTES:

● This function is supported. ▲ This function is the new feature in this version.

○ This function is not supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

VehicleType	ModelYear	Engine Type	Capacity	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test
Discovery	2005-2009	Normal aspirated V6		RLM	●	●	●	●	
Discovery	2005-2009	Normal aspirated V6		SASM	●	●	●	●	
Discovery	2005-2009	Normal aspirated V6		TCCM	●	●	●	●	
Discovery	2005-2009	Normal aspirated V6		TCM	●	●	●	●	
Discovery	2005-2009	Normal aspirated V6		VDM	●	●	●	●	
Discovery	2005-2009	Normal aspirated V6		ACM	●	●	●	●	
Discovery	2005-2009	Normal aspirated V6		BCM	●	●	●	●	
Discovery	2005-2009	Normal aspirated V6		HVAC	●	●	●	●	
Discovery	2005-2009	Normal aspirated V6		PAM	●	●	●	●	
Discovery	2005-2009	Normal aspirated V6		TPM	●	●	●	●	
Discovery	2005-2009	Normal aspirated V6		AAM	●	●	●	●	
Discovery	2005-2009	Normal aspirated V6		DACMC	●	●	●	●	
Discovery	2005-2009	Normal aspirated V6		FEM	●	●	●	●	
Discovery	2005-2009	Normal aspirated V6		REM	●	●	●	●	
Discovery	2005-2009	Normal aspirated V6		SRM	●	●	●	●	
Discovery	2005-2009	Normal aspirated V6		TEL	●	●	●	●	
Discovery	2005-2009	Normal aspirated V6		TMC	●	●	●	●	
Discovery	2005-2009	Normal aspirated V6		TVM	●	●	●	●	
Discovery	2005-2009	Normal aspirated V8		ATCM	●	●	●	●	
Discovery	2005-2009	Normal aspirated V8		CCM	●	●	●	●	
Discovery	2005-2009	Normal aspirated V8		FLM	●	●	●	●	
Discovery	2005-2009	Normal aspirated V8		IPC	●	●	●	●	
Discovery	2005-2009	Normal aspirated V8		PBM	●	●	●	●	
Discovery	2005-2009	Normal aspirated V8		PCM	●	●	●	●	
Discovery	2005-2009	Normal aspirated V8		RCM	●	●	●	●	
Discovery	2005-2009	Normal aspirated V8		RDCM	●	●	●	●	
Discovery	2005-2009	Normal aspirated V8		RLM	●	●	●	●	
Discovery	2005-2009	Normal aspirated V8		SASM	●	●	●	●	
Discovery	2005-2009	Normal aspirated V8		TCCM	●	●	●	●	
Discovery	2005-2009	Normal aspirated V8		TCM	●	●	●	●	

Autel

MaxiDas_LandRover_V4.50 Fuction List

NOTES:

● This function is supported. ▲ This function is the new feature in this version.

○ This function is not supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

VehicleType	ModelYear	Engine Type	Capacity	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test
Discovery	2005-2009	Normal aspirated V8		VDM	●	●	●	●	
Discovery	2005-2009	Normal aspirated V8		ACM	●	●	●	●	
Discovery	2005-2009	Normal aspirated V8		BCM	●	●	●	●	
Discovery	2005-2009	Normal aspirated V8		HVAC	●	●	●	●	
Discovery	2005-2009	Normal aspirated V8		PAM	●	●	●	●	
Discovery	2005-2009	Normal aspirated V8		TPM	●	●	●	●	
Discovery	2005-2009	Normal aspirated V8		AAM	●	●	●	●	
Discovery	2005-2009	Normal aspirated V8		DACMC	●	●	●	●	
Discovery	2005-2009	Normal aspirated V8		FEM	●	●	●	●	
Discovery	2005-2009	Normal aspirated V8		REM	●	●	●	●	
Discovery	2005-2009	Normal aspirated V8		SRM	●	●	●	●	
Discovery	2005-2009	Normal aspirated V8		TEL	●	●	●	●	
Discovery	2005-2009	Normal aspirated V8		TMC	●	●	●	●	
Discovery	2005-2009	Normal aspirated V8		TVM	●	●	●	●	
Discovery	2005-2009	Diesel V6		ATCM	●	●	●	●	
Discovery	2005-2009	Diesel V6		CCM	●	●	●	●	
Discovery	2005-2009	Diesel V6		FLM	●	●	●	●	
Discovery	2005-2009	Diesel V6		IPC	●	●	●	●	
Discovery	2005-2009	Diesel V6		PBM	●	●	●	●	
Discovery	2005-2009	Diesel V6		PCM	●	●	●	●	
Discovery	2005-2009	Diesel V6		RCM	●	●	●	●	
Discovery	2005-2009	Diesel V6		RDCM	●	●	●	●	
Discovery	2005-2009	Diesel V6		RLM	●	●	●	●	
Discovery	2005-2009	Diesel V6		SASM	●	●	●	●	
Discovery	2005-2009	Diesel V6		TCCM	●	●	●	●	
Discovery	2005-2009	Diesel V6		TCM	●	●	●	●	
Discovery	2005-2009	Diesel V6		VDM	●	●	●	●	
Discovery	2005-2009	Diesel V6		ACM	●	●	●	●	
Discovery	2005-2009	Diesel V6		BCM	●	●	●	●	
Discovery	2005-2009	Diesel V6		HVAC	●	●	●	●	

Autel

MaxiDas_LandRover_V4.50 Fuction List

NOTES:

● This function is supported. ▲ This function is the new feature in this version.

○ This function is not supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

VehicleType	ModelYear	Engine Type	Capacity	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test
Discovery	2005-2009	Diesel V6		PAM	●	●	●	●	
Discovery	2005-2009	Diesel V6		TPM	●	●	●	●	
Discovery	2005-2009	Diesel V6		AAM	●	●	●	●	
Discovery	2005-2009	Diesel V6		DACMC	●	●	●	●	
Discovery	2005-2009	Diesel V6		FEM	●	●	●	●	
Discovery	2005-2009	Diesel V6		REM	●	●	●	●	
Discovery	2005-2009	Diesel V6		SRM	●	●	●	●	
Discovery	2005-2009	Diesel V6		TEL	●	●	●	●	
Discovery	2005-2009	Diesel V6		TMC	●	●	●	●	
Discovery	2005-2009	Diesel V6		TVM	●	●	●	●	
Discovery	2005-2009	Diesel V6		AHCM	●	●	●	●	
Discovery	2010	Normal aspirated V6		ABS	●	●	●	●	
Discovery	2010	Normal aspirated V6		ATCM	●	●	●	●	
Discovery	2010	Normal aspirated V6		BCM	●	●	●	●	
Discovery	2010	Normal aspirated V6		CCM	●	●	●	●	
Discovery	2010	Normal aspirated V6		HCM	●	●	●	●	
Discovery	2010	Normal aspirated V6		IPC	●	●	●	●	
Discovery	2010	Normal aspirated V6		OCS	●	●	●	●	
Discovery	2010	Normal aspirated V6		PBM	●	●	●	●	
Discovery	2010	Normal aspirated V6		PCM	●	●	●	●	
Discovery	2010	Normal aspirated V6		RCM	●	●	●	●	
Discovery	2010	Normal aspirated V6		RDCM	●	●	●	●	
Discovery	2010	Normal aspirated V6		RLM	●	●	●	●	
Discovery	2010	Normal aspirated V6		SASM	●	●	●	●	
Discovery	2010	Normal aspirated V6		TCCM	●	●	●	●	
Discovery	2010	Normal aspirated V6		TCM	●	●	●	●	
Discovery	2010	Normal aspirated V6		VIM	●	●	●	●	
Discovery	2010	Normal aspirated V6		ACM	●	●	●	●	
Discovery	2010	Normal aspirated V6		AHCM	●	●	●	●	
Discovery	2010	Normal aspirated V6		DDM	●	●	●	●	

Autel

MaxiDas_LandRover_V4.50 Fuction List

NOTES:

● This function is supported. ▲ This function is the new feature in this version.

○ This function is not supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

VehicleType	ModelYear	Engine Type	Capacity	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test
Discovery	2010	Normal aspirated V6		DSM	●	●	●	●	
Discovery	2010	Normal aspirated V6		FCDIM	●	●	●	●	
Discovery	2010	Normal aspirated V6		FCIM	●	●	●	●	
Discovery	2010	Normal aspirated V6		FCIMB	●	●	●	●	
Discovery	2010	Normal aspirated V6		HCMB	●	●	●	●	
Discovery	2010	Normal aspirated V6		HVAC	●	●	●	●	
Discovery	2010	Normal aspirated V6		IPMB	●	●	●	●	
Discovery	2010	Normal aspirated V6		KVM	●	●	●	●	
Discovery	2010	Normal aspirated V6		PAM	●	●	●	●	
Discovery	2010	Normal aspirated V6		PDM	●	●	●	●	
Discovery	2010	Normal aspirated V6		SPRM	●	●	●	●	
Discovery	2010	Normal aspirated V6		AAM	●	●	●	●	
Discovery	2010	Normal aspirated V6		APIM	●	●	●	●	
Discovery	2010	Normal aspirated V6		DABM	●	●	●	●	
Discovery	2010	Normal aspirated V6		DACMC	●	●	●	●	
Discovery	2010	Normal aspirated V6		FEM	●	●	●	●	
Discovery	2010	Normal aspirated V6		REM	●	●	●	●	
Discovery	2010	Normal aspirated V6		SRM	●	●	●	●	
Discovery	2010	Normal aspirated V6		TEL	●	●	●	●	
Discovery	2010	Normal aspirated V6		TVM	●	●	●	●	
Discovery	2010	Normal aspirated V8		ABS	●	●	●	●	
Discovery	2010	Normal aspirated V8		ATCM	●	●	●	●	
Discovery	2010	Normal aspirated V8		BCM	●	●	●	●	
Discovery	2010	Normal aspirated V8		CCM	●	●	●	●	
Discovery	2010	Normal aspirated V8		HCM	●	●	●	●	
Discovery	2010	Normal aspirated V8		IPC	●	●	●	●	
Discovery	2010	Normal aspirated V8		OCS	●	●	●	●	
Discovery	2010	Normal aspirated V8		PBM	●	●	●	●	
Discovery	2010	Normal aspirated V8		PCM	●	●	●	●	
Discovery	2010	Normal aspirated V8		RCM	●	●	●	●	

Autel

MaxiDas_LandRover_V4.50 Fuction List

NOTES:

● This function is supported. ▲ This function is the new feature in this version.

○ This function is not supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

VehicleType	ModelYear	Engine Type	Capacity	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test
Discovery	2010	Normal aspirated V8		RDCM	●	●	●	●	
Discovery	2010	Normal aspirated V8		RLM	●	●	●	●	
Discovery	2010	Normal aspirated V8		SASM	●	●	●	●	
Discovery	2010	Normal aspirated V8		TCCM	●	●	●	●	
Discovery	2010	Normal aspirated V8		TCM	●	●	●	●	
Discovery	2010	Normal aspirated V8		VIM	●	●	●	●	
Discovery	2010	Normal aspirated V8		ACM	●	●	●	●	
Discovery	2010	Normal aspirated V8		AHCM	●	●	●	●	
Discovery	2010	Normal aspirated V8		DDM	●	●	●	●	
Discovery	2010	Normal aspirated V8		DSM	●	●	●	●	
Discovery	2010	Normal aspirated V8		FCDIM	●	●	●	●	
Discovery	2010	Normal aspirated V8		FCIM	●	●	●	●	
Discovery	2010	Normal aspirated V8		FCIMB	●	●	●	●	
Discovery	2010	Normal aspirated V8		HCMB	●	●	●	●	
Discovery	2010	Normal aspirated V8		HVAC	●	●	●	●	
Discovery	2010	Normal aspirated V8		IPMB	●	●	●	●	
Discovery	2010	Normal aspirated V8		KVM	●	●	●	●	
Discovery	2010	Normal aspirated V8		PAM	●	●	●	●	
Discovery	2010	Normal aspirated V8		PDM	●	●	●	●	
Discovery	2010	Normal aspirated V8		SPRM	●	●	●	●	
Discovery	2010	Normal aspirated V8		AAM	●	●	●	●	
Discovery	2010	Normal aspirated V8		APIM	●	●	●	●	
Discovery	2010	Normal aspirated V8		DABM	●	●	●	●	
Discovery	2010	Normal aspirated V8		DACMC	●	●	●	●	
Discovery	2010	Normal aspirated V8		FEM	●	●	●	●	
Discovery	2010	Normal aspirated V8		REM	●	●	●	●	
Discovery	2010	Normal aspirated V8		SRM	●	●	●	●	
Discovery	2010	Normal aspirated V8		TEL	●	●	●	●	
Discovery	2010	Normal aspirated V8		TVM	●	●	●	●	
Discovery	2010	Diesel V6	2.7L	ABS	●	●	●	●	

Autel

MaxiDas_LandRover_V4.50 Fuction List

NOTES:

● This function is supported. ▲ This function is the new feature in this version.

○ This function is not supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

VehicleType	ModelYear	Engine Type	Capacity	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test
Discovery	2010	Diesel V6	2.7L	ATCM	●	●	●	●	
Discovery	2010	Diesel V6	2.7L	BCM	●	●	●	●	
Discovery	2010	Diesel V6	2.7L	CCM	●	●	●	●	
Discovery	2010	Diesel V6	2.7L	HCM	●	●	●	●	
Discovery	2010	Diesel V6	2.7L	IPC	●	●	●	●	
Discovery	2010	Diesel V6	2.7L	OCS	●	●	●	●	
Discovery	2010	Diesel V6	2.7L	PBM	●	●	●	●	
Discovery	2010	Diesel V6	2.7L	PCM	●	●	●	●	
Discovery	2010	Diesel V6	2.7L	RCM	●	●	●	●	
Discovery	2010	Diesel V6	2.7L	RDCM	●	●	●	●	
Discovery	2010	Diesel V6	2.7L	RLM	●	●	●	●	
Discovery	2010	Diesel V6	2.7L	SASM	●	●	●	●	
Discovery	2010	Diesel V6	2.7L	TCCM	●	●	●	●	
Discovery	2010	Diesel V6	2.7L	TCM	●	●	●	●	
Discovery	2010	Diesel V6	2.7L	VIM	●	●	●	●	
Discovery	2010	Diesel V6	2.7L	ACM	●	●	●	●	
Discovery	2010	Diesel V6	2.7L	AHCM	●	●	●	●	
Discovery	2010	Diesel V6	2.7L	DDM	●	●	●	●	
Discovery	2010	Diesel V6	2.7L	DSM	●	●	●	●	
Discovery	2010	Diesel V6	2.7L	FCDIM	●	●	●	●	
Discovery	2010	Diesel V6	2.7L	FCIM	●	●	●	●	
Discovery	2010	Diesel V6	2.7L	FCIMB	●	●	●	●	
Discovery	2010	Diesel V6	2.7L	HCMB	●	●	●	●	
Discovery	2010	Diesel V6	2.7L	HVAC	●	●	●	●	
Discovery	2010	Diesel V6	2.7L	IPMB	●	●	●	●	
Discovery	2010	Diesel V6	2.7L	KVM	●	●	●	●	
Discovery	2010	Diesel V6	2.7L	PAM	●	●	●	●	
Discovery	2010	Diesel V6	2.7L	PDM	●	●	●	●	
Discovery	2010	Diesel V6	2.7L	SPRM	●	●	●	●	
Discovery	2010	Diesel V6	2.7L	AAM	●	●	●	●	

Autel

MaxiDas_LandRover_V4.50 Fuction List

NOTES:

● This function is supported. ▲ This function is the new feature in this version.

○ This function is not supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

VehicleType	ModelYear	Engine Type	Capacity	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test
Discovery	2010	Diesel V6	2.7L	APIM	●	●	●	●	
Discovery	2010	Diesel V6	2.7L	DABM	●	●	●	●	
Discovery	2010	Diesel V6	2.7L	DACMC	●	●	●	●	
Discovery	2010	Diesel V6	2.7L	FEM	●	●	●	●	
Discovery	2010	Diesel V6	2.7L	REM	●	●	●	●	
Discovery	2010	Diesel V6	2.7L	SRM	●	●	●	●	
Discovery	2010	Diesel V6	2.7L	TEL	●	●	●	●	
Discovery	2010	Diesel V6	2.7L	TVM	●	●	●	●	
Discovery	2010	Diesel V6	3.0L	ABS	●	●	●	●	
Discovery	2010	Diesel V6	3.0L	ATCM	●	●	●	●	
Discovery	2010	Diesel V6	3.0L	BCM	●	●	●	●	
Discovery	2010	Diesel V6	3.0L	CCM	●	●	●	●	
Discovery	2010	Diesel V6	3.0L	HCM	●	●	●	●	
Discovery	2010	Diesel V6	3.0L	IPC	●	●	●	●	
Discovery	2010	Diesel V6	3.0L	OCS	●	●	●	●	
Discovery	2010	Diesel V6	3.0L	PBM	●	●	●	●	
Discovery	2010	Diesel V6	3.0L	PCM	●	●	●	●	
Discovery	2010	Diesel V6	3.0L	RCM	●	●	●	●	
Discovery	2010	Diesel V6	3.0L	RDCM	●	●	●	●	
Discovery	2010	Diesel V6	3.0L	RLM	●	●	●	●	
Discovery	2010	Diesel V6	3.0L	SASM	●	●	●	●	
Discovery	2010	Diesel V6	3.0L	TCCM	●	●	●	●	
Discovery	2010	Diesel V6	3.0L	TCM	●	●	●	●	
Discovery	2010	Diesel V6	3.0L	VIM	●	●	●	●	
Discovery	2010	Diesel V6	3.0L	ACM	●	●	●	●	
Discovery	2010	Diesel V6	3.0L	AHCM	●	●	●	●	
Discovery	2010	Diesel V6	3.0L	DDM	●	●	●	●	
Discovery	2010	Diesel V6	3.0L	DSM	●	●	●	●	
Discovery	2010	Diesel V6	3.0L	FCDIM	●	●	●	●	
Discovery	2010	Diesel V6	3.0L	FCIM	●	●	●	●	

Autel

MaxiDas_LandRover_V4.50 Fuction List

NOTES:

● This function is supported. ▲ This function is the new feature in this version.

○ This function is not supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

VehicleType	ModelYear	Engine Type	Capacity	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test
Discovery	2010	Diesel V6	3.0L	FCIMB	●	●	●	●	
Discovery	2010	Diesel V6	3.0L	HCMB	●	●	●	●	
Discovery	2010	Diesel V6	3.0L	HVAC	●	●	●	●	
Discovery	2010	Diesel V6	3.0L	IPMB	●	●	●	●	
Discovery	2010	Diesel V6	3.0L	KVM	●	●	●	●	
Discovery	2010	Diesel V6	3.0L	PAM	●	●	●	●	
Discovery	2010	Diesel V6	3.0L	PDM	●	●	●	●	
Discovery	2010	Diesel V6	3.0L	SPRM	●	●	●	●	
Discovery	2010	Diesel V6	3.0L	AAM	●	●	●	●	
Discovery	2010	Diesel V6	3.0L	APIM	●	●	●	●	
Discovery	2010	Diesel V6	3.0L	DABM	●	●	●	●	
Discovery	2010	Diesel V6	3.0L	DACMC	●	●	●	●	
Discovery	2010	Diesel V6	3.0L	FEM	●	●	●	●	
Discovery	2010	Diesel V6	3.0L	REM	●	●	●	●	
Discovery	2010	Diesel V6	3.0L	SRM	●	●	●	●	
Discovery	2010	Diesel V6	3.0L	TEL	●	●	●	●	
Discovery	2010	Diesel V6	3.0L	TVM	●	●	●	●	
Range Rover Sport	2005-2009	Normal aspirated V8		ARCM	●	●	●	●	
Range Rover Sport	2005-2009	Normal aspirated V8		ATCM	●	●	●	●	
Range Rover Sport	2005-2009	Normal aspirated V8		CCM	●	●	●	●	
Range Rover Sport	2005-2009	Normal aspirated V8		FLM	●	●	●	●	
Range Rover Sport	2005-2009	Normal aspirated V8		IPC	●	●	●	●	
Range Rover Sport	2005-2009	Normal aspirated V8		PBM	●	●	●	●	
Range Rover Sport	2005-2009	Normal aspirated V8		PCM	●	●	●	●	
Range Rover Sport	2005-2009	Normal aspirated V8		RCM	●	●	●	●	
Range Rover Sport	2005-2009	Normal aspirated V8		RDCM	●	●	●	●	
Range Rover Sport	2005-2009	Normal aspirated V8		RLM	●	●	●	●	
Range Rover Sport	2005-2009	Normal aspirated V8		SASM	●	●	●	●	
Range Rover Sport	2005-2009	Normal aspirated V8		TCCM	●	●	●	●	
Range Rover Sport	2005-2009	Normal aspirated V8		TCM	●	●	●	●	

Autel

MaxiDas_LandRover_V4.50 Fuction List

NOTES:

● This function is supported. ▲ This function is the new feature in this version.

○ This function is not supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

VehicleType	ModelYear	Engine Type	Capacity	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test
Range Rover Sport	2005-2009	Normal aspirated V8		VDM	●	●	●	●	
Range Rover Sport	2005-2009	Normal aspirated V8		ACM	●	●	●	●	
Range Rover Sport	2005-2009	Normal aspirated V8		BCM	●	●	●	●	
Range Rover Sport	2005-2009	Normal aspirated V8		HVAC	●	●	●	●	
Range Rover Sport	2005-2009	Normal aspirated V8		PAM	●	●	●	●	
Range Rover Sport	2005-2009	Normal aspirated V8		TPM	●	●	●	●	
Range Rover Sport	2005-2009	Normal aspirated V8		AAM	●	●	●	●	
Range Rover Sport	2005-2009	Normal aspirated V8		DACMC	●	●	●	●	
Range Rover Sport	2005-2009	Normal aspirated V8		FEM	●	●	●	●	
Range Rover Sport	2005-2009	Normal aspirated V8		REM	●	●	●	●	
Range Rover Sport	2005-2009	Normal aspirated V8		SRM	●	●	●	●	
Range Rover Sport	2005-2009	Normal aspirated V8		TEL	●	●	●	●	
Range Rover Sport	2005-2009	Normal aspirated V8		TMC	●	●	●	●	
Range Rover Sport	2005-2009	Normal aspirated V8		TVM	●	●	●	●	
Range Rover Sport	2005-2009	Supercharged V8		ARCM	●	●	●	●	
Range Rover Sport	2005-2009	Supercharged V8		ATCM	●	●	●	●	
Range Rover Sport	2005-2009	Supercharged V8		CCM	●	●	●	●	
Range Rover Sport	2005-2009	Supercharged V8		FLM	●	●	●	●	
Range Rover Sport	2005-2009	Supercharged V8		IPC	●	●	●	●	
Range Rover Sport	2005-2009	Supercharged V8		PBM	●	●	●	●	
Range Rover Sport	2005-2009	Supercharged V8		PCM	●	●	●	●	
Range Rover Sport	2005-2009	Supercharged V8		RCM	●	●	●	●	
Range Rover Sport	2005-2009	Supercharged V8		RDCM	●	●	●	●	
Range Rover Sport	2005-2009	Supercharged V8		RLM	●	●	●	●	
Range Rover Sport	2005-2009	Supercharged V8		SASM	●	●	●	●	
Range Rover Sport	2005-2009	Supercharged V8		TCCM	●	●	●	●	
Range Rover Sport	2005-2009	Supercharged V8		TCM	●	●	●	●	
Range Rover Sport	2005-2009	Supercharged V8		VDM	●	●	●	●	
Range Rover Sport	2005-2009	Supercharged V8		ACM	●	●	●	●	
Range Rover Sport	2005-2009	Supercharged V8		BCM	●	●	●	●	

Autel

MaxiDas_LandRover_V4.50 Fuction List

NOTES:

● This function is supported. ▲ This function is the new feature in this version.

○ This function is not supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

VehicleType	ModelYear	Engine Type	Capacity	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test
Range Rover Sport	2005-2009	Supercharged V8		HVAC	●	●	●	●	
Range Rover Sport	2005-2009	Supercharged V8		PAM	●	●	●	●	
Range Rover Sport	2005-2009	Supercharged V8		TPM	●	●	●	●	
Range Rover Sport	2005-2009	Supercharged V8		AAM	●	●	●	●	
Range Rover Sport	2005-2009	Supercharged V8		DACMC	●	●	●	●	
Range Rover Sport	2005-2009	Supercharged V8		FEM	●	●	●	●	
Range Rover Sport	2005-2009	Supercharged V8		REM	●	●	●	●	
Range Rover Sport	2005-2009	Supercharged V8		SRM	●	●	●	●	
Range Rover Sport	2005-2009	Supercharged V8		TEL	●	●	●	●	
Range Rover Sport	2005-2009	Supercharged V8		TMC	●	●	●	●	
Range Rover Sport	2005-2009	Supercharged V8		TVM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V8		ARCM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V8		ATCM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V8		CCM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V8		FLM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V8		IPC	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V8		PBM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V8		PCM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V8		RCM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V8		RDCM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V8		RLM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V8		SASM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V8		TCCM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V8		TCM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V8		VDM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V8		ACM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V8		AHCM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V8		BCM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V8		HVAC	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V8		PAM	●	●	●	●	

Autel

MaxiDas_LandRover_V4.50 Fuction List

NOTES:

● This function is supported. ▲ This function is the new feature in this version.

○ This function is not supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

VehicleType	ModelYear	Engine Type	Capacity	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test
Range Rover Sport	2005-2009	Diesel V8		TPM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V8		AAM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V8		DACMC	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V8		FEM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V8		REM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V8		SRM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V8		TEL	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V8		TMC	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V8		TVM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V6		ARCM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V6		ATCM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V6		CCM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V6		FLM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V6		IPC	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V6		PBM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V6		PCM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V6		RCM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V6		RDCM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V6		RLM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V6		SASM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V6		TCCM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V6		TCM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V6		VDM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V6		ACM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V6		AHCM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V6		BCM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V6		HVAC	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V6		PAM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V6		TPM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V6		AAM	●	●	●	●	

Autel

MaxiDas_LandRover_V4.50 Fuction List

NOTES:

● This function is supported. ▲ This function is the new feature in this version.

○ This function is not supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

VehicleType	ModelYear	Engine Type	Capacity	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test
Range Rover Sport	2005-2009	Diesel V6		DACMC	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V6		FEM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V6		REM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V6		SRM	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V6		TEL	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V6		TMC	●	●	●	●	
Range Rover Sport	2005-2009	Diesel V6		TVM	●	●	●	●	
Range Rover Sport	2010	Normal aspirated V8		ABS	●	●	●	●	
Range Rover Sport	2010	Normal aspirated V8		ADCM	●	●	●	●	
Range Rover Sport	2010	Normal aspirated V8		ARCM	●	●	●	●	
Range Rover Sport	2010	Normal aspirated V8		ATCM	●	●	●	●	
Range Rover Sport	2010	Normal aspirated V8		BCM	●	●	●	●	
Range Rover Sport	2010	Normal aspirated V8		CCM	●	●	●	●	
Range Rover Sport	2010	Normal aspirated V8		HCM	●	●	●	●	
Range Rover Sport	2010	Normal aspirated V8		IPC	●	●	●	●	
Range Rover Sport	2010	Normal aspirated V8		OCS	●	●	●	●	
Range Rover Sport	2010	Normal aspirated V8		PBM	●	●	●	●	
Range Rover Sport	2010	Normal aspirated V8		PCM	●	●	●	●	
Range Rover Sport	2010	Normal aspirated V8		RCM	●	●	●	●	
Range Rover Sport	2010	Normal aspirated V8		RDCM	●	●	●	●	
Range Rover Sport	2010	Normal aspirated V8		RLM	●	●	●	●	
Range Rover Sport	2010	Normal aspirated V8		SASM	●	●	●	●	
Range Rover Sport	2010	Normal aspirated V8		TCCM	●	●	●	●	
Range Rover Sport	2010	Normal aspirated V8		TCM	●	●	●	●	
Range Rover Sport	2010	Normal aspirated V8		VIM	●	●	●	●	
Range Rover Sport	2010	Normal aspirated V8		ACM	●	●	●	●	
Range Rover Sport	2010	Normal aspirated V8		AHCM	●	●	●	●	
Range Rover Sport	2010	Normal aspirated V8		DDM	●	●	●	●	
Range Rover Sport	2010	Normal aspirated V8		DSM	●	●	●	●	
Range Rover Sport	2010	Normal aspirated V8		FCIM	●	●	●	●	

Autel

MaxiDas_LandRover_V4.50 Fuction List

NOTES:

● This function is supported. ▲ This function is the new feature in this version.

○ This function is not supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

VehicleType	ModelYear	Engine Type	Capacity	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test
Range Rover Sport	2010	Normal aspirated V8		FCIMB	●	●	●	●	
Range Rover Sport	2010	Normal aspirated V8		HCMB	●	●	●	●	
Range Rover Sport	2010	Normal aspirated V8		HVAC	●	●	●	●	
Range Rover Sport	2010	Normal aspirated V8		IPMB	●	●	●	●	
Range Rover Sport	2010	Normal aspirated V8		KVM	●	●	●	●	
Range Rover Sport	2010	Normal aspirated V8		PAM	●	●	●	●	
Range Rover Sport	2010	Normal aspirated V8		PDM	●	●	●	●	
Range Rover Sport	2010	Normal aspirated V8		AAM	●	●	●	●	
Range Rover Sport	2010	Normal aspirated V8		APIM	●	●	●	●	
Range Rover Sport	2010	Normal aspirated V8		DABM	●	●	●	●	
Range Rover Sport	2010	Normal aspirated V8		DACMC	●	●	●	●	
Range Rover Sport	2010	Normal aspirated V8		FEM	●	●	●	●	
Range Rover Sport	2010	Normal aspirated V8		REM	●	●	●	●	
Range Rover Sport	2010	Normal aspirated V8		SRM	●	●	●	●	
Range Rover Sport	2010	Normal aspirated V8		TEL	●	●	●	●	
Range Rover Sport	2010	Normal aspirated V8		TVM	●	●	●	●	
Range Rover Sport	2010	Supercharged V8		ABS	●	●	●	●	
Range Rover Sport	2010	Supercharged V8		ADCM	●	●	●	●	
Range Rover Sport	2010	Supercharged V8		ARCM	●	●	●	●	
Range Rover Sport	2010	Supercharged V8		ATCM	●	●	●	●	
Range Rover Sport	2010	Supercharged V8		BCM	●	●	●	●	
Range Rover Sport	2010	Supercharged V8		CCM	●	●	●	●	
Range Rover Sport	2010	Supercharged V8		HCM	●	●	●	●	
Range Rover Sport	2010	Supercharged V8		IPC	●	●	●	●	
Range Rover Sport	2010	Supercharged V8		OCS	●	●	●	●	
Range Rover Sport	2010	Supercharged V8		PBM	●	●	●	●	
Range Rover Sport	2010	Supercharged V8		PCM	●	●	●	●	
Range Rover Sport	2010	Supercharged V8		RCM	●	●	●	●	
Range Rover Sport	2010	Supercharged V8		RDCM	●	●	●	●	
Range Rover Sport	2010	Supercharged V8		RLM	●	●	●	●	

Autel

MaxiDas_LandRover_V4.50 Fuction List

NOTES:

● This function is supported. ▲ This function is the new feature in this version.

○ This function is not supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

VehicleType	ModelYear	Engine Type	Capacity	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test
Range Rover Sport	2010	Supercharged V8		SASM	●	●	●	●	
Range Rover Sport	2010	Supercharged V8		TCCM	●	●	●	●	
Range Rover Sport	2010	Supercharged V8		TCM	●	●	●	●	
Range Rover Sport	2010	Supercharged V8		VIM	●	●	●	●	
Range Rover Sport	2010	Supercharged V8		ACM	●	●	●	●	
Range Rover Sport	2010	Supercharged V8		AHCM	●	●	●	●	
Range Rover Sport	2010	Supercharged V8		DDM	●	●	●	●	
Range Rover Sport	2010	Supercharged V8		DSM	●	●	●	●	
Range Rover Sport	2010	Supercharged V8		FCIM	●	●	●	●	
Range Rover Sport	2010	Supercharged V8		FCIMB	●	●	●	●	
Range Rover Sport	2010	Supercharged V8		HCMB	●	●	●	●	
Range Rover Sport	2010	Supercharged V8		HVAC	●	●	●	●	
Range Rover Sport	2010	Supercharged V8		IPMB	●	●	●	●	
Range Rover Sport	2010	Supercharged V8		KVM	●	●	●	●	
Range Rover Sport	2010	Supercharged V8		PAM	●	●	●	●	
Range Rover Sport	2010	Supercharged V8		PDM	●	●	●	●	
Range Rover Sport	2010	Supercharged V8		AAM	●	●	●	●	
Range Rover Sport	2010	Supercharged V8		APIM	●	●	●	●	
Range Rover Sport	2010	Supercharged V8		DABM	●	●	●	●	
Range Rover Sport	2010	Supercharged V8		DACMC	●	●	●	●	
Range Rover Sport	2010	Supercharged V8		FEM	●	●	●	●	
Range Rover Sport	2010	Supercharged V8		REM	●	●	●	●	
Range Rover Sport	2010	Supercharged V8		SRM	●	●	●	●	
Range Rover Sport	2010	Supercharged V8		TEL	●	●	●	●	
Range Rover Sport	2010	Supercharged V8		TVM	●	●	●	●	
Range Rover Sport	2010	Diesel V8		ABS	●	●	●	●	
Range Rover Sport	2010	Diesel V8		ADCM	●	●	●	●	
Range Rover Sport	2010	Diesel V8		ARCM	●	●	●	●	
Range Rover Sport	2010	Diesel V8		ATCM	●	●	●	●	
Range Rover Sport	2010	Diesel V8		BCM	●	●	●	●	

Autel

MaxiDas_LandRover_V4.50 Fuction List

NOTES:

● This function is supported. ▲ This function is the new feature in this version.

○ This function is not supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

VehicleType	ModelYear	Engine Type	Capacity	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test
Range Rover Sport	2010	Diesel V8		CCM	●	●	●	●	
Range Rover Sport	2010	Diesel V8		HCM	●	●	●	●	
Range Rover Sport	2010	Diesel V8		IPC	●	●	●	●	
Range Rover Sport	2010	Diesel V8		OCS	●	●	●	●	
Range Rover Sport	2010	Diesel V8		PBM	●	●	●	●	
Range Rover Sport	2010	Diesel V8		PCM	●	●	●	●	
Range Rover Sport	2010	Diesel V8		RCM	●	●	●	●	
Range Rover Sport	2010	Diesel V8		RDCM	●	●	●	●	
Range Rover Sport	2010	Diesel V8		RLM	●	●	●	●	
Range Rover Sport	2010	Diesel V8		SASM	●	●	●	●	
Range Rover Sport	2010	Diesel V8		TCCM	●	●	●	●	
Range Rover Sport	2010	Diesel V8		TCM	●	●	●	●	
Range Rover Sport	2010	Diesel V8		VIM	●	●	●	●	
Range Rover Sport	2010	Diesel V8		ACM	●	●	●	●	
Range Rover Sport	2010	Diesel V8		AHCM	●	●	●	●	
Range Rover Sport	2010	Diesel V8		DDM	●	●	●	●	
Range Rover Sport	2010	Diesel V8		DSM	●	●	●	●	
Range Rover Sport	2010	Diesel V8		FCIM	●	●	●	●	
Range Rover Sport	2010	Diesel V8		FCIMB	●	●	●	●	
Range Rover Sport	2010	Diesel V8		HCMB	●	●	●	●	
Range Rover Sport	2010	Diesel V8		HVAC	●	●	●	●	
Range Rover Sport	2010	Diesel V8		IPMB	●	●	●	●	
Range Rover Sport	2010	Diesel V8		KVM	●	●	●	●	
Range Rover Sport	2010	Diesel V8		PAM	●	●	●	●	
Range Rover Sport	2010	Diesel V8		PDM	●	●	●	●	
Range Rover Sport	2010	Diesel V8		AAM	●	●	●	●	
Range Rover Sport	2010	Diesel V8		APIM	●	●	●	●	
Range Rover Sport	2010	Diesel V8		DABM	●	●	●	●	
Range Rover Sport	2010	Diesel V8		DACMC	●	●	●	●	
Range Rover Sport	2010	Diesel V8		FEM	●	●	●	●	

Autel

MaxiDas_LandRover_V4.50 Fuction List

NOTES:

● This function is supported. ▲ This function is the new feature in this version.

○ This function is not supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

VehicleType	ModelYear	Engine Type	Capacity	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test
Range Rover Sport	2010	Diesel V8		REM	●	●	●	●	
Range Rover Sport	2010	Diesel V8		SRM	●	●	●	●	
Range Rover Sport	2010	Diesel V8		TEL	●	●	●	●	
Range Rover Sport	2010	Diesel V8		TVM	●	●	●	●	
Range Rover Sport	2010	Diesel V6		ABS	●	●	●	●	
Range Rover Sport	2010	Diesel V6		ADCM	●	●	●	●	
Range Rover Sport	2010	Diesel V6		ARCM	●	●	●	●	
Range Rover Sport	2010	Diesel V6		ATCM	●	●	●	●	
Range Rover Sport	2010	Diesel V6		BCM	●	●	●	●	
Range Rover Sport	2010	Diesel V6		CCM	●	●	●	●	
Range Rover Sport	2010	Diesel V6		HCM	●	●	●	●	
Range Rover Sport	2010	Diesel V6		IPC	●	●	●	●	
Range Rover Sport	2010	Diesel V6		OCS	●	●	●	●	
Range Rover Sport	2010	Diesel V6		PBM	●	●	●	●	
Range Rover Sport	2010	Diesel V6		PCM	●	●	●	●	
Range Rover Sport	2010	Diesel V6		RCM	●	●	●	●	
Range Rover Sport	2010	Diesel V6		RDCM	●	●	●	●	
Range Rover Sport	2010	Diesel V6		RLM	●	●	●	●	
Range Rover Sport	2010	Diesel V6		SASM	●	●	●	●	
Range Rover Sport	2010	Diesel V6		TCCM	●	●	●	●	
Range Rover Sport	2010	Diesel V6		TCM	●	●	●	●	
Range Rover Sport	2010	Diesel V6		VIM	●	●	●	●	
Range Rover Sport	2010	Diesel V6		ACM	●	●	●	●	
Range Rover Sport	2010	Diesel V6		AHCM	●	●	●	●	
Range Rover Sport	2010	Diesel V6		DDM	●	●	●	●	
Range Rover Sport	2010	Diesel V6		DSM	●	●	●	●	
Range Rover Sport	2010	Diesel V6		FCIM	●	●	●	●	
Range Rover Sport	2010	Diesel V6		FCIMB	●	●	●	●	
Range Rover Sport	2010	Diesel V6		HCMB	●	●	●	●	
Range Rover Sport	2010	Diesel V6		HVAC	●	●	●	●	

Autel

MaxiDas_LandRover_V4.50 Fuction List

NOTES:

● This function is supported. ▲ This function is the new feature in this version.

○ This function is not supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

VehicleType	ModelYear	Engine Type	Capacity	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test
Range Rover Sport	2010	Diesel V6		IPMB	●	●	●	●	
Range Rover Sport	2010	Diesel V6		KVM	●	●	●	●	
Range Rover Sport	2010	Diesel V6		PAM	●	●	●	●	
Range Rover Sport	2010	Diesel V6		PDM	●	●	●	●	
Range Rover Sport	2010	Diesel V6		AAM	●	●	●	●	
Range Rover Sport	2010	Diesel V6		APIM	●	●	●	●	
Range Rover Sport	2010	Diesel V6		DABM	●	●	●	●	
Range Rover Sport	2010	Diesel V6		DACMC	●	●	●	●	
Range Rover Sport	2010	Diesel V6		FEM	●	●	●	●	
Range Rover Sport	2010	Diesel V6		REM	●	●	●	●	
Range Rover Sport	2010	Diesel V6		SRM	●	●	●	●	
Range Rover Sport	2010	Diesel V6		TEL	●	●	●	●	
Range Rover Sport	2010	Diesel V6		TVM	●	●	●	●	
Range Rover	1995-1999			Engine	●	●	●	●	
Range Rover	1995-1999			AT	●	●	●		
Range Rover	1995-1999			AC		●	●	●	
Range Rover	1999-2002			Engine	●	●	●	●	●
Range Rover	1999-2002			AT	●	●	●	●	
Range Rover	1999-2002			ABS	●	●	●	●	●
Range Rover	1999-2002			SRS		•	•		
Range Rover	1999-2002			AC		•	•	•	
Range Rover	1999-2002			Cruise Control		•	•	•	
Range Rover	2002-2004			Engine	●	●	●	●	●
Range Rover	2002-2004			AT	●	●	●	●	●
Range Rover	2002-2004			ABS	●	●	●	●	●
Range Rover	2002-2004			SRS	●	●	●	●	
Range Rover	2002-2004			Air Suspension	●	●	●	●	●
Range Rover	2002-2004			Instrument Park	●	●	●	●	
Range Rover	2002-2004			AC	●	●	●	●	
Range Rover	2002-2004			Parking Aid	●	●	●	●	

Autel

MaxiDas_LandRover_V4.50 Fuction List

NOTES:

● This function is supported. ▲ This function is the new feature in this version.

○ This function is not supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

VehicleType	ModelYear	Engine Type	Capacity	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test
Range Rover	2002-2004			Security	●	●	●	●	
Range Rover	2002-2004			immobilisation	●	●	●	●	
Range Rover	2002-2004			Power steering	●	●	●	●	
Range Rover	2002-2004			Wash Wipe	●	●	●	●	
Range Rover	2002-2004			Window& Sunroof	●	●	●	●	
Range Rover	2002-2004			Fuel Burning Heater	●	●	●	●	
Range Rover	2002-2004			Automatic Headlight	●	●	●	●	
Range Rover	2002-2004			Interior Lights	●	●	●	●	
Range Rover	2002-2004			Transfer Box	●	●	●	●	
Range Rover	2002-2004			Lightting Check Module	●	●	●	●	
Range Rover	2002-2004			Xenon Headlight	●	●	●		
Range Rover	2002-2004			Multi Function Display	●	●	●		
Range Rover	2002-2004			Radio	●	●	●	●	
Range Rover	2002-2004			Video Module	●	●	●	●	
Range Rover	2002-2004			Body Control Unit	●	●	●	●	
Range Rover	2002-2004			Seat Memory ECU	●	●	●	●	
Range Rover	2005			AAM	●	●	●	●	
Range Rover	2005			CDP	●	●	●		
Range Rover	2005			FEM	●	●	●	●	
Range Rover	2005			REM	●	●	●	●	
Range Rover	2005			SRM	●	●	●	●	
Range Rover	2005			TEL	●	●	●	●	
Range Rover	2005			TMC	●	●	●	●	
Range Rover	2005			TVM	●	●	●	●	
Range Rover	2005			ACM	●	●	●	●	
Range Rover	2005			GWM	●				
Range Rover	2006	Normal aspirated V8		IPC	●	●	●	●	
Range Rover	2006	Normal aspirated V8		FLM	●	●	●	●	
Range Rover	2006	Normal aspirated V8		PCM	●	●	●	●	
Range Rover	2006	Normal aspirated V8		RLM	●	●	●	●	

Autel

MaxiDas_LandRover_V4.50 Fuction List

NOTES:

● This function is supported. ▲ This function is the new feature in this version.

○ This function is not supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

VehicleType	ModelYear	Engine Type	Capacity	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test
Range Rover	2006	Normal aspirated V8		SASM	●	●	●	●	
Range Rover	2006	Normal aspirated V8		TCCM	●	●	●	●	
Range Rover	2006	Normal aspirated V8		TCM	●	●	●	●	
Range Rover	2006	Normal aspirated V8		VDM	●	●	●	●	
Range Rover	2006	Normal aspirated V8		ACM	●	●	●	●	
Range Rover	2006	Normal aspirated V8		RDUM	●	●	●	●	
Range Rover	2006	Normal aspirated V8		VIM	●	●	●	●	
Range Rover	2006	Normal aspirated V8		TPM	●	●	●	●	
Range Rover	2006	Normal aspirated V8		AAM	●	●	●	●	
Range Rover	2006	Normal aspirated V8		CDP	●	●	●		
Range Rover	2006	Normal aspirated V8		FEM	●	●	●	●	
Range Rover	2006	Normal aspirated V8		REM	●	●	●	●	
Range Rover	2006	Normal aspirated V8		SRM	●	●	●	●	
Range Rover	2006	Normal aspirated V8		TEL	●	●	●	●	
Range Rover	2006	Normal aspirated V8		TMC	●	●	●	●	
Range Rover	2006	Normal aspirated V8		TVM	●	●	●	●	
Range Rover	2006	Normal aspirated V8		BPM	●	●	●	●	
Range Rover	2006	Normal aspirated V8		DSM	●	●	●	●	
Range Rover	2006	Normal aspirated V8		AHCM	●	●	●		
Range Rover	2006	Normal aspirated V8		HVAC	●	●	●	●	
Range Rover	2006	Normal aspirated V8		LCM	●	●	●	●	
Range Rover	2006	Normal aspirated V8		MFSW	●			●	
Range Rover	2006	Normal aspirated V8		PAM	●	●	●	●	
Range Rover	2006	Normal aspirated V8		RAIN	●	●	●		
Range Rover	2006	Normal aspirated V8		SCLM	●	●	●	●	
Range Rover	2006	Normal aspirated V8		RCM	●	●	●	●	
Range Rover	2006	Supercharged V8		IPC	●	●	●	●	
Range Rover	2006	Supercharged V8		FLM	●	●	●	●	
Range Rover	2006	Supercharged V8		PCM	●	●	●	●	
Range Rover	2006	Supercharged V8		RLM	●	●	●	●	

Autel

MaxiDas_LandRover_V4.50 Fuction List

NOTES:

● This function is supported. ▲ This function is the new feature in this version.

○ This function is not supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

VehicleType	ModelYear	Engine Type	Capacity	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test
Range Rover	2006	Supercharged V8		SASM	●	●	●	●	
Range Rover	2006	Supercharged V8		TCCM	●	●	●	●	
Range Rover	2006	Supercharged V8		TCM	●	●	●	●	
Range Rover	2006	Supercharged V8		VDM	●	●	●	●	
Range Rover	2006	Supercharged V8		ACM	●	●	●	●	
Range Rover	2006	Supercharged V8		RDUM	●	●	●	●	
Range Rover	2006	Supercharged V8		VIM	●	●	●	●	
Range Rover	2006	Supercharged V8		TPM	●	●	●	●	
Range Rover	2006	Supercharged V8		AAM	●	●	●	●	
Range Rover	2006	Supercharged V8		CDP	●	●	●		
Range Rover	2006	Supercharged V8		FEM	●	●	●	●	
Range Rover	2006	Supercharged V8		REM	●	●	●	●	
Range Rover	2006	Supercharged V8		SRM	●	●	●	●	
Range Rover	2006	Supercharged V8		TEL	●	●	●	●	
Range Rover	2006	Supercharged V8		TMC	●	●	●	●	
Range Rover	2006	Supercharged V8		TVM	●	●	●	●	
Range Rover	2006	Supercharged V8		BPM	●	●	●	●	
Range Rover	2006	Supercharged V8		DSM	●	●	●	●	
Range Rover	2006	Supercharged V8		AHCM	●	●	●		
Range Rover	2006	Supercharged V8		HVAC	●	●	●	●	
Range Rover	2006	Supercharged V8		LCM	●	●	●	●	
Range Rover	2006	Supercharged V8		MFSW	●	●	●	●	
Range Rover	2006	Supercharged V8		PAM	●	●	●	●	
Range Rover	2006	Supercharged V8		RAIN	●	●	●		
Range Rover	2006	Supercharged V8		SCLM	●	●	●	●	
Range Rover	2006	Supercharged V8		RCM	●	●	●	●	
Range Rover	2006	Diesel straight six		IPC	●	●	●	●	
Range Rover	2006	Diesel straight six		FLM	●	●	●	●	
Range Rover	2006	Diesel straight six		RLM	●	●	●	●	
Range Rover	2006	Diesel straight six		ACM	●	●	●	●	

Autel

MaxiDas_LandRover_V4.50 Fuction List

NOTES:

● This function is supported. ▲ This function is the new feature in this version.

○ This function is not supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

VehicleType	ModelYear	Engine Type	Capacity	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test
Range Rover	2006	Diesel straight six		RDUM	●	●	●	●	
Range Rover	2006	Diesel straight six		VIM	●	●	●	●	
Range Rover	2006	Diesel straight six		TPM	●	●	●	●	
Range Rover	2006	Diesel straight six		AAM	●	●	●	●	
Range Rover	2006	Diesel straight six		CDP	●	●	●		
Range Rover	2006	Diesel straight six		FEM	●	●	●	●	
Range Rover	2006	Diesel straight six		REM	●	●	●	●	
Range Rover	2006	Diesel straight six		SRM	●	●	●	●	
Range Rover	2006	Diesel straight six		TEL	●	●	●	●	
Range Rover	2006	Diesel straight six		TMC	●	●	●	●	
Range Rover	2006	Diesel straight six		TVM	●	●	●	●	
Range Rover	2006	Diesel straight six		BPM	●	●	●	●	
Range Rover	2006	Diesel straight six		DSM	●	●	●	●	
Range Rover	2006	Diesel straight six		AHCM	●	●	●	●	
Range Rover	2006	Diesel straight six		HVAC	●	●	●	●	
Range Rover	2006	Diesel straight six		LCM	●	●	●	●	
Range Rover	2006	Diesel straight six		MFSW	●	●	●	●	
Range Rover	2006	Diesel straight six		PAM	●	●	●	●	
Range Rover	2006	Diesel straight six		RAIN	●	●	●		
Range Rover	2006	Diesel straight six		SASM	●	●	●	●	
Range Rover	2006	Diesel straight six		SCLM	●	●	●	●	
Range Rover	2006	Diesel straight six		VDM	●	●	●	●	
Range Rover	2006	Diesel straight six		RCM	●	●	●	●	
Range Rover	2006	Diesel straight six		TCM	●	●	●	●	
Range Rover	2006	Diesel straight six		PCM	●	●	●	●	
Range Rover	2006	Diesel straight six		TCCM	●	●	●	●	
Range Rover	2007	Supercharged V8		ATCM	●	●	●	●	
Range Rover	2007	Supercharged V8		FLM	●	●	●	●	
Range Rover	2007	Supercharged V8		IPC	●	●	●	●	
Range Rover	2007	Supercharged V8		OCS	●	●	●	●	

Autel

MaxiDas_LandRover_V4.50 Fuction List

NOTES:

● This function is supported. ▲ This function is the new feature in this version.

○ This function is not supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

VehicleType	ModelYear	Engine Type	Capacity	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test
Range Rover	2007	Supercharged V8		PBM	●	●	●	●	
Range Rover	2007	Supercharged V8		PCM	●	●	●	●	
Range Rover	2007	Supercharged V8		RCM	●	●	●	●	
Range Rover	2007	Supercharged V8		RDCM	●	●	●	●	
Range Rover	2007	Supercharged V8		RLM	●	●	●	●	
Range Rover	2007	Supercharged V8		SASM	●	●	●	●	
Range Rover	2007	Supercharged V8		TCCM	●	●	●	●	
Range Rover	2007	Supercharged V8		TCM	●	●	●	●	
Range Rover	2007	Supercharged V8		VDM	●	●	●	●	
Range Rover	2007	Supercharged V8		ACM	●	●	●	●	
Range Rover	2007	Supercharged V8		DCSM	●	●	●	●	
Range Rover	2007	Supercharged V8		RBM	●	●	●	●	
Range Rover	2007	Supercharged V8		RDUM	●	●	●	●	
Range Rover	2007	Supercharged V8		RHVAC	●	●	●	●	
Range Rover	2007	Supercharged V8		TPM	●	●	●	●	
Range Rover	2007	Supercharged V8		VIM	●	●	●	●	
Range Rover	2007	Supercharged V8		AAM	●	●	●	●	
Range Rover	2007	Supercharged V8		CDP	●	●	●		
Range Rover	2007	Supercharged V8		FEM	●	●	●	●	
Range Rover	2007	Supercharged V8		REM	●	●	●	●	
Range Rover	2007	Supercharged V8		SRM	●	●	●	●	
Range Rover	2007	Supercharged V8		TEL	●	●	●	●	
Range Rover	2007	Supercharged V8		TMC	●	●	●	●	
Range Rover	2007	Supercharged V8		TVM	●	●	●	●	
Range Rover	2007	Supercharged V8		BPM	●	●	●	●	
Range Rover	2007	Supercharged V8		DSM	●	●	●	●	
Range Rover	2007	Supercharged V8		HVAC	●	●	●	●	
Range Rover	2007	Supercharged V8		LCM	●	●	●	●	
Range Rover	2007	Supercharged V8		PAM	●	●	●	●	
Range Rover	2007	Supercharged V8		RAIN	●	●	●		

Autel

MaxiDas_LandRover_V4.50 Fuction List

NOTES:

● This function is supported. ▲ This function is the new feature in this version.

○ This function is not supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

VehicleType	ModelYear	Engine Type	Capacity	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test
Range Rover	2007	Supercharged V8		SCLM	●	●	●	●	
Range Rover	2007	Normal aspirated V8		ATCM	●	●	●	●	
Range Rover	2007	Normal aspirated V8		FLM	●	●	●	●	
Range Rover	2007	Normal aspirated V8		IPC	●	●	●	●	
Range Rover	2007	Normal aspirated V8		OCS	●	●	●	●	
Range Rover	2007	Normal aspirated V8		PBM	●	●	●	●	
Range Rover	2007	Normal aspirated V8		PCM	●	●	●	●	
Range Rover	2007	Normal aspirated V8		RCM	●	●	●	●	
Range Rover	2007	Normal aspirated V8		RDCM	●	●	●	●	
Range Rover	2007	Normal aspirated V8		RLM	●	●	●	●	
Range Rover	2007	Normal aspirated V8		SASM	●	●	●	●	
Range Rover	2007	Normal aspirated V8		TCCM	●	●	●	●	
Range Rover	2007	Normal aspirated V8		TCM	●	●	●	●	
Range Rover	2007	Normal aspirated V8		VDM	●	●	●	●	
Range Rover	2007	Normal aspirated V8		ACM	●	●	●	●	
Range Rover	2007	Normal aspirated V8		DCSM	●	●	●	●	
Range Rover	2007	Normal aspirated V8		RBM	●	●	●	●	
Range Rover	2007	Normal aspirated V8		RDUM	●	●	●	●	
Range Rover	2007	Normal aspirated V8		RHVAC	●	●	●	●	
Range Rover	2007	Normal aspirated V8		TPM	●	●	●	●	
Range Rover	2007	Normal aspirated V8		VIM	●	●	●	●	
Range Rover	2007	Normal aspirated V8		AAM	●	●	●	●	
Range Rover	2007	Normal aspirated V8		CDP	●	●	●		
Range Rover	2007	Normal aspirated V8		FEM	●	●	●	●	
Range Rover	2007	Normal aspirated V8		REM	●	●	●	●	
Range Rover	2007	Normal aspirated V8		SRM	●	●	●	●	
Range Rover	2007	Normal aspirated V8		TEL	●	●	●	●	
Range Rover	2007	Normal aspirated V8		TMC	●	●	●	●	
Range Rover	2007	Normal aspirated V8		TVM	●	●	●	●	
Range Rover	2007	Normal aspirated V8		BPM	●	●	●	●	

Autel

MaxiDas_LandRover_V4.50 Fuction List

NOTES:

● This function is supported. ▲ This function is the new feature in this version.

○ This function is not supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

VehicleType	ModelYear	Engine Type	Capacity	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test
Range Rover	2007	Normal aspirated V8		DSM	●	●	●	●	
Range Rover	2007	Normal aspirated V8		HVAC	●	●	●	●	
Range Rover	2007	Normal aspirated V8		LCM	●	●	●	●	
Range Rover	2007	Normal aspirated V8		PAM	●	●	●	●	
Range Rover	2007	Normal aspirated V8		RAIN	●	●	●		
Range Rover	2007	Normal aspirated V8		SCLM	●	●	●	●	
Range Rover	2007	Diesel V8		ATCM	●	●	●	●	
Range Rover	2007	Diesel V8		FLM	●	●	●	●	
Range Rover	2007	Diesel V8		IPC	●	●	●	●	
Range Rover	2007	Diesel V8		OCS	●	●	●	●	
Range Rover	2007	Diesel V8		PBM	●	●	●	●	
Range Rover	2007	Diesel V8		PCM	●	●	●	●	
Range Rover	2007	Diesel V8		RCM	●	●	●	●	
Range Rover	2007	Diesel V8		RDCM	●	●	●	●	
Range Rover	2007	Diesel V8		RLM	●	●	●	●	
Range Rover	2007	Diesel V8		SASM	●	●	●	●	
Range Rover	2007	Diesel V8		TCCM	●	●	●	●	
Range Rover	2007	Diesel V8		TCM	●	●	●	●	
Range Rover	2007	Diesel V8		VDM	●	●	●	●	
Range Rover	2007	Diesel V8		ACM	●	●	●	●	
Range Rover	2007	Diesel V8		DCSM	●	●	●	●	
Range Rover	2007	Diesel V8		RBM	●	●	●	●	
Range Rover	2007	Diesel V8		RDUM	●	●	●	●	
Range Rover	2007	Diesel V8		RHVAC	●	●	●	●	
Range Rover	2007	Diesel V8		TPM	●	●	●	●	
Range Rover	2007	Diesel V8		VIM	●	●	●	●	
Range Rover	2007	Diesel V8		AAM	●	●	●	●	
Range Rover	2007	Diesel V8		CDP	●	●	●		
Range Rover	2007	Diesel V8		FEM	●	●	●	●	
Range Rover	2007	Diesel V8		REM	●	●	●	●	

Autel

MaxiDas_LandRover_V4.50 Fuction List

NOTES:

● This function is supported. ▲ This function is the new feature in this version.

○ This function is not supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

VehicleType	ModelYear	Engine Type	Capacity	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test
Range Rover	2007	Diesel V8		SRM	●	●	●	●	
Range Rover	2007	Diesel V8		TEL	●	●	●	●	
Range Rover	2007	Diesel V8		TMC	●	●	●	●	
Range Rover	2007	Diesel V8		TVM	●	●	●	●	
Range Rover	2007	Diesel V8		BPM	●	●	●	●	
Range Rover	2007	Diesel V8		DSM	●	●	●	●	
Range Rover	2007	Diesel V8		AHCM	●	●	●	●	
Range Rover	2007	Diesel V8		HVAC	●	●	●	●	
Range Rover	2007	Diesel V8		LCM	●	●	●	●	
Range Rover	2007	Diesel V8		PAM	●	●	●	●	
Range Rover	2007	Diesel V8		RAIN	●	●	●		
Range Rover	2007	Diesel V8		SCLM	●	●	●	●	
Range Rover	2010	Normal aspirated V8		ABS	●	●	●	●	
Range Rover	2010	Normal aspirated V8		ADCM	●	●	●	●	
Range Rover	2010	Normal aspirated V8		ATCM	●	●	●	●	
Range Rover	2010	Normal aspirated V8		BCM	●	●	●	●	
Range Rover	2010	Normal aspirated V8		CCM	●	●	●	●	
Range Rover	2010	Normal aspirated V8		HCM	●	●	●	●	
Range Rover	2010	Normal aspirated V8		IPC	●	●	●	●	
Range Rover	2010	Normal aspirated V8		OCS	●	●	●	●	
Range Rover	2010	Normal aspirated V8		PBM	●	●	●	●	
Range Rover	2010	Normal aspirated V8		PCM	●	●	●	●	
Range Rover	2010	Normal aspirated V8		RCM	●	●	●	●	
Range Rover	2010	Normal aspirated V8		RDCM	●	●	●	●	
Range Rover	2010	Normal aspirated V8		RLM	●	●	●	●	
Range Rover	2010	Normal aspirated V8		SASM	●	●	●	●	
Range Rover	2010	Normal aspirated V8		TCCM	●	●	●	●	
Range Rover	2010	Normal aspirated V8		TCM	●	●	●	●	
Range Rover	2010	Normal aspirated V8		VIM	●	●	●	●	
Range Rover	2010	Normal aspirated V8		ACM	●	●	●	●	

Autel

MaxiDas_LandRover_V4.50 Fuction List

NOTES:

● This function is supported. ▲ This function is the new feature in this version.

○ This function is not supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

VehicleType	ModelYear	Engine Type	Capacity	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test
Range Rover	2010	Normal aspirated V8		DCSM	●	●	●	●	
Range Rover	2010	Normal aspirated V8		DDM	●	●	●	●	
Range Rover	2010	Normal aspirated V8		DSM	●	●	●	●	
Range Rover	2010	Normal aspirated V8		HCMB	●	●	●	●	
Range Rover	2010	Normal aspirated V8		HVAC	●	●	●	●	
Range Rover	2010	Normal aspirated V8		IPMB	●	●	●	●	
Range Rover	2010	Normal aspirated V8		KVM	●	●	●	●	
Range Rover	2010	Normal aspirated V8		PAM	●	●	●	●	
Range Rover	2010	Normal aspirated V8		PDM	●	●	●	●	
Range Rover	2010	Normal aspirated V8		PSM	●	●	●	●	
Range Rover	2010	Normal aspirated V8		RBM	●	●	●	●	
Range Rover	2010	Normal aspirated V8		RDCSM	●	●	●	●	
Range Rover	2010	Normal aspirated V8		RDUM	●	●	●	●	
Range Rover	2010	Normal aspirated V8		RHVAC	●	●	●	●	
Range Rover	2010	Normal aspirated V8		SODL	●	●	●	●	
Range Rover	2010	Normal aspirated V8		SODR	●	●	●	●	
Range Rover	2010	Normal aspirated V8		AAM	●	●	●	●	
Range Rover	2010	Normal aspirated V8		APIM	●	●	●	●	
Range Rover	2010	Normal aspirated V8		CDP	●	●	●	●	
Range Rover	2010	Normal aspirated V8		DABM	●	●	●	●	
Range Rover	2010	Normal aspirated V8		DACMC	●	●	●	●	
Range Rover	2010	Normal aspirated V8		FEM	●	●	●	●	
Range Rover	2010	Normal aspirated V8		REM	●	●	●	●	
Range Rover	2010	Normal aspirated V8		SRM	●	●	●	●	
Range Rover	2010	Normal aspirated V8		TEL	●	●	●	●	
Range Rover	2010	Normal aspirated V8		TVM	●	●	●	●	
Range Rover	2010	Supercharged V8		ABS	●	●	●	●	
Range Rover	2010	Supercharged V8		ADCM	●	●	●	●	
Range Rover	2010	Supercharged V8		ATCM	●	●	●	●	
Range Rover	2010	Supercharged V8		BCM	●	●	●	●	

Autel

MaxiDas_LandRover_V4.50 Fuction List

NOTES:

● This function is supported. ▲ This function is the new feature in this version.

○ This function is not supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

VehicleType	ModelYear	Engine Type	Capacity	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test
Range Rover	2010	Supercharged V8		CCM	●	●	●	●	
Range Rover	2010	Supercharged V8		HCM	●	●	●	●	
Range Rover	2010	Supercharged V8		IPC	●	●	●	●	
Range Rover	2010	Supercharged V8		OCS	●	●	●	●	
Range Rover	2010	Supercharged V8		PBM	●	●	●	●	
Range Rover	2010	Supercharged V8		PCM	●	●	●	●	
Range Rover	2010	Supercharged V8		RCM	●	●	●	●	
Range Rover	2010	Supercharged V8		RDCM	●	●	●	●	
Range Rover	2010	Supercharged V8		RLM	●	●	●	●	
Range Rover	2010	Supercharged V8		SASM	●	●	●	●	
Range Rover	2010	Supercharged V8		TCCM	●	●	●	●	
Range Rover	2010	Supercharged V8		TCM	●	●	●	●	
Range Rover	2010	Supercharged V8		VIM	●	●	●	●	
Range Rover	2010	Supercharged V8		ACM	●	●	●	●	
Range Rover	2010	Supercharged V8		DCSM	●	●	●	●	
Range Rover	2010	Supercharged V8		DDM	●	●	●	●	
Range Rover	2010	Supercharged V8		DSM	●	●	●	●	
Range Rover	2010	Supercharged V8		HCMB	●	●	●	●	
Range Rover	2010	Supercharged V8		HVAC	●	●	●	●	
Range Rover	2010	Supercharged V8		IPMB	●	●	●	●	
Range Rover	2010	Supercharged V8		KVM	●	●	●	●	
Range Rover	2010	Supercharged V8		PAM	●	●	●	●	
Range Rover	2010	Supercharged V8		PDM	●	●	●	●	
Range Rover	2010	Supercharged V8		PSM	●	●	●	●	
Range Rover	2010	Supercharged V8		RBM	●	●	●	●	
Range Rover	2010	Supercharged V8		RDCSM	●	●	●	●	
Range Rover	2010	Supercharged V8		RDUM	●	●	●	●	
Range Rover	2010	Supercharged V8		RHVAC	●	●	●	●	
Range Rover	2010	Supercharged V8		SODL	●	●	●	●	
Range Rover	2010	Supercharged V8		SODR	●	●	●	●	

Autel

MaxiDas_LandRover_V4.50 Fuction List

NOTES:

● This function is supported. ▲ This function is the new feature in this version.

○ This function is not supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

VehicleType	ModelYear	Engine Type	Capacity	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test
Range Rover	2010	Supercharged V8		AAM	●	●	●	●	
Range Rover	2010	Supercharged V8		APIM	●	●	●	●	
Range Rover	2010	Supercharged V8		CDP	●	●	●	●	
Range Rover	2010	Supercharged V8		DABM	●	●	●	●	
Range Rover	2010	Supercharged V8		DACMC	●	●	●	●	
Range Rover	2010	Supercharged V8		FEM	●	●	●	●	
Range Rover	2010	Supercharged V8		REM	●	●	●	●	
Range Rover	2010	Supercharged V8		SRM	●	●	●	●	
Range Rover	2010	Supercharged V8		TEL	●	●	●	●	
Range Rover	2010	Supercharged V8		TVM	●	●	●	●	
Range Rover	2010	Diesel V8		ABS	●	●	●	●	
Range Rover	2010	Diesel V8		ADCM	●	●	●	●	
Range Rover	2010	Diesel V8		ATCM	●	●	●	●	
Range Rover	2010	Diesel V8		BCM	●	●	●	●	
Range Rover	2010	Diesel V8		CCM	●	●	●	●	
Range Rover	2010	Diesel V8		HCM	●	●	●	●	
Range Rover	2010	Diesel V8		IPC	●	●	●	●	
Range Rover	2010	Diesel V8		OCS	●	●	●	●	
Range Rover	2010	Diesel V8		PBM	●	●	●	●	
Range Rover	2010	Diesel V8		PCM	●	●	●	●	
Range Rover	2010	Diesel V8		RCM	●	●	●	●	
Range Rover	2010	Diesel V8		RDCM	●	●	●	●	
Range Rover	2010	Diesel V8		RLM	●	●	●	●	
Range Rover	2010	Diesel V8		SASM	●	●	●	●	
Range Rover	2010	Diesel V8		TCCM	●	●	●	●	
Range Rover	2010	Diesel V8		TCM	●	●	●	●	
Range Rover	2010	Diesel V8		VIM	●	●	●	●	
Range Rover	2010	Diesel V8		ACM	●	●	●	●	
Range Rover	2010	Diesel V8		DCSM	●	●	●	●	
Range Rover	2010	Diesel V8		DDM	●	●	●	●	

Autel

MaxiDas_LandRover_V4.50 Fuction List

NOTES:

● This function is supported. ▲ This function is the new feature in this version.

○ This function is not supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

VehicleType	ModelYear	Engine Type	Capacity	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test
Range Rover	2010	Diesel V8		DSM	●	●	●	●	
Range Rover	2010	Diesel V8		HCMB	●	●	●	●	
Range Rover	2010	Diesel V8		HVAC	●	●	●	●	
Range Rover	2010	Diesel V8		IPMB	●	●	●	●	
Range Rover	2010	Diesel V8		KVM	●	●	●	●	
Range Rover	2010	Diesel V8		PAM	●	●	●	●	
Range Rover	2010	Diesel V8		PDM	●	●	●	●	
Range Rover	2010	Diesel V8		PSM	●	●	●	●	
Range Rover	2010	Diesel V8		RBM	●	●	●	●	
Range Rover	2010	Diesel V8		RDCSM	●	●	●	●	
Range Rover	2010	Diesel V8		RDUM	●	●	●	●	
Range Rover	2010	Diesel V8		RHVAC	●	●	●	●	
Range Rover	2010	Diesel V8		SODL	●	●	●	●	
Range Rover	2010	Diesel V8		SODR	●	●	●	●	
Range Rover	2010	Diesel V8		AAM	●	●	●	●	
Range Rover	2010	Diesel V8		APIM	●	●	●	●	
Range Rover	2010	Diesel V8		CDP	●	●	●	●	
Range Rover	2010	Diesel V8		DABM	●	●	●	●	
Range Rover	2010	Diesel V8		DACMC	●	●	●	●	
Range Rover	2010	Diesel V8		FEM	●	●	●	●	
Range Rover	2010	Diesel V8		REM	●	●	●	●	
Range Rover	2010	Diesel V8		SRM	●	●	●	●	
Range Rover	2010	Diesel V8		TEL	●	●	●	●	
Range Rover	2010	Diesel V8		TVM	●	●	●	●	
Freelander 1	~2007			Engine	●	●	●	●	●
Freelander 1	~2007			AT	●	●	●	●	●
Freelander 1	~2007			ABS	●	●	●	●	●
Freelander 1	~2007			SRS	●	●	●		
Freelander 1	~2007			Instrument pack	●	●	●	●	
Freelander 1	~2007			Security	●			●	

Autel

MaxiDas_LandRover_V4.50 Fuction List

NOTES:

● This function is supported. ▲ This function is the new feature in this version.

○ This function is not supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

VehicleType	ModelYear	Engine Type	Capacity	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test
Freelander 1	~2007			Tail door	●			●	
Freelander 1	~2007			Exterior Lighting	●			●	
Freelander 1	~2007			Warning and Sounders	●			●	
Freelander 1	~2007			Wash Wipe	●			●	
Freelander 1	~2007			Electric Windows	●			●	
Freelander 1	~2007			Heated Rear Window	●			●	
Freelander 1	~2007			Heated Front Screen	●			●	
Freelander 2		Diesel I4		ABS	●	●	●	●	
Freelander 2		Diesel I4		ATCM	●	●	●	●	
Freelander 2		Diesel I4		BCM	●	●	●	●	
Freelander 2		Diesel I4		HCM	●	●	●	●	
Freelander 2		Diesel I4		OCS	●	●	●	●	
Freelander 2		Diesel I4		PCM	●	●	●	●	
Freelander 2		Diesel I4		RCM	●	●	●	●	
Freelander 2		Diesel I4		RDCM	●	●	●	●	
Freelander 2		Diesel I4		SASM	●	●	●	●	
Freelander 2		Diesel I4		TCM	●	●	●	●	
Freelander 2		Diesel I6		AHCM	●	●	●	●	
Freelander 2		Diesel I4		DDM	●	●	●	●	
Freelander 2		Diesel I4		DSM	●	●	●	●	
Freelander 2		Diesel I4		HVAC	●	●	●	●	
Freelander 2		Diesel I4		ICM	●	●	●	●	
Freelander 2		Diesel I4		IPC	●	●	●	●	
Freelander 2		Diesel I4		PAM	●	●	●	●	
Freelander 2		Diesel I4		PDM	●	●	●	●	
Freelander 2		Diesel I4		TRM	●	●	●	●	
Freelander 2		Diesel I4		AAM	●	●	●	●	
Freelander 2		Diesel I4		ACM	●	●	●	●	
Freelander 2		Diesel I4		BPM	●	●	●	●	
Freelander 2		Diesel I4		DABM	●	●	●	●	

Autel

MaxiDas_LandRover_V4.50 Fuction List

NOTES:

● This function is supported. ▲ This function is the new feature in this version.

○ This function is not supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

VehicleType	ModelYear	Engine Type	Capacity	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test
Freelander 2		Diesel I4		DACMC	●	●	●	●	
Freelander 2		Diesel I4		FCDIM	●	●	●	●	
Freelander 2		Diesel I4		NCM	●	●	●	●	
Freelander 2		Diesel I4		SRM	●	●	●	●	
Freelander 2		Diesel I6		ABS	●	●	●	●	
Freelander 2		Diesel I6		ATCM	●	●	●	●	
Freelander 2		Diesel I6		BCM	●	●	●	●	
Freelander 2		Diesel I6		HCM	●	●	●	●	
Freelander 2		Diesel I6		OCS	●	●	●	●	
Freelander 2		Diesel I6		PCM	●	●	●	●	
Freelander 2		Diesel I6		RCM	●	●	●	●	
Freelander 2		Diesel I6		RDCM	●	●	●	●	
Freelander 2		Diesel I6		SASM	●	●	●	●	
Freelander 2		Diesel I6		TCM	●	●	●	●	
Freelander 2		Diesel I6		AHCM	●	●	●		
Freelander 2		Diesel I6		DDM	●	●	●	●	
Freelander 2		Diesel I6		DSM	●	●	●	●	
Freelander 2		Diesel I6		HVAC	●	●	●	●	
Freelander 2		Diesel I6		ICM	●	●	●	●	
Freelander 2		Diesel I6		IPC	●	●	●	●	
Freelander 2		Diesel I6		PAM	●	●	●	●	
Freelander 2		Diesel I6		PDM	●	●	●	●	
Freelander 2		Diesel I6		TRM	●	●	●	●	
Freelander 2		Diesel I6		AAM	●	●	●	●	
Freelander 2		Diesel I6		ACM	●	●	●	●	
Freelander 2		Diesel I6		BPM	●	●	●	●	
Freelander 2		Diesel I6		DABM	●	●	●	●	
Freelander 2		Diesel I6		DACMC	●	●	●	●	
Freelander 2		Diesel I6		FCDIM	●	●	●	●	
Freelander 2		Diesel I6		NCM	●	●	●	●	

MaxiDas_LandRover_V4.50 Fuction List

NOTES:

● This function is supported. ▲ This function is the new feature in this version.

○ This function is not supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

VehicleType	ModelYear	Engine Type	Capacity	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test
Freelander 2		Diesel I6		SRM	●	●	●	●	

Autel®

Fuction List

VehicleType	ModelYear	System Name	Function Name
Defender	2007~2011		Injector replacement
Discovery	1998~2004	Engine	Reset Adaptions
Discovery	1998~2004	Engine	Read/Set Injector Grades
Discovery	1998~2004	Engine	Throttle track
Discovery	1998~2004	Engine	Security
Discovery	1998~2004	Engine	Testfire injectors
Discovery	1998~2004	AT	Reset Adaptions
Discovery	1998~2004	ABS	SLS Calibration
Discovery	1998~2004	ABS	SLS Transportation
Discovery	1998~2004	ABS	Suspension configuration
Discovery	1998~2004	ABS	Brake bleeding
Discovery	1998~2004	ABS	Settings
Discovery	1998~2004	BCU	Suspension PLIP
Discovery	1998~2004	BCU	Key programming
Discovery	1998~2004	BCU	EKA
Discovery	1998~2004	BCU	VIN
Discovery	2005-2009		Air suspension deflation.
Discovery	2005-2009		Air suspension enable.
Discovery	2005-2009		Air suspension height calibration.
Discovery	2005-2009		Brake bleed.
Discovery	2005-2009		Diesel particulate filter dynamic regeneration
Discovery	2005-2009		Diesel particulate filter replacement
Discovery	2005-2009		Drive the parking brake to the latching position.
Discovery	2005-2009		Drive the parking brake to the mounting position.
Discovery	2005-2009		Headlamp calibration suspension set-up
Discovery	2005-2009		Longitudinal accelerometer calibration.
Discovery	2005-2009		Parking brake unjam procedure.
Discovery	2005-2009		Program keys.
Discovery	2005-2009		Rain sensor initialisation.
Discovery	2005-2009		Reset the oil service counter.
Discovery	2005-2009		Seat cushion replacement
Discovery	2005-2009		Service interval reset.
Discovery	2005-2009		Sliding roof module initialisation.
Discovery	2005-2009		Steering angle sensor calibration
Discovery	2005-2009		Steering column calibration
Discovery	2005-2009		Suspension geometry set-up
Discovery	2005-2009		Suspension tight tolerance control
Discovery	2005-2009		Third button configuration.
Discovery	2005-2009		Tire pressure monitor confirmation application.
Discovery	2005-2009		Tire pressure sensor replacement.
Discovery	2010		Add additional keys
Discovery	2010		Air suspension deflation.
Discovery	2010		Air suspension enable.
Discovery	2010		Battery replacement
Discovery	2010		Brake bleed.
Discovery	2010		Build mode
Discovery	2010		Check Passive Keys Enabled
Discovery	2010		Diesel particulate filter dynamic regeneration
Discovery	2010		Diesel particulate filter replacement
Discovery	2010		Drive the parking brake to the latching position.
Discovery	2010		Drive the parking brake to the mounting position.
Discovery	2010		Driver's side - Door glass window calibration

Autel®

Fuction List

VehicleType	ModelYear	System Name	Function Name
Defender	2007~2011		Injector replacement
Discovery	2010		Exhaust gas recirculation valve
Discovery	2010		Headlamp calibration suspension set-up
Discovery	2010		Headlamp control module system calibration
Discovery	2010		Height calibration
Discovery	2010		Immobilization
Discovery	2010		Injector replacement
Discovery	2010		Longitudinal accelerometer calibration.
Discovery	2010		Oil service counter reset
Discovery	2010		Parking brake unjam procedure.
Discovery	2010		Passenger's side - Door glass window calibration
Discovery	2010		Petrol powertrain idle speed control test
Discovery	2010		Recover Programmed keys
Discovery	2010		Replace faulty/lost keys
Discovery	2010		Restraints build mode
Discovery	2010		Seat cushion replacement
Discovery	2010		Service interval reset.
Discovery	2010		Steering angle sensor calibration
Discovery	2010		Steering column calibration
Discovery	2010		Sunroof calibration
Discovery	2010		Suspension geometry set-up
Discovery	2010		Suspension tight tolerance control
Discovery	2010		Throttle valve actuator
Discovery	2010		Tire pressure monitor sensor identification display
Discovery	2010		Tire pressure sensor replacement.
Discovery	2010		Verify keys
Range Rover Spor	2005-2009		Air suspension deflation.
Range Rover Spor	2005-2009		Air suspension enable.
Range Rover Spor	2005-2009		Air suspension height calibration.
Range Rover Spor	2005-2009		Brake bleed.
Range Rover Spor	2005-2009		Clear adaptive data.
Range Rover Spor	2005-2009		Diesel particulate filter dynamic regeneration
Range Rover Spor	2005-2009		Diesel particulate filter replacement
Range Rover Spor	2005-2009		Drive the parking brake to the latching position.
Range Rover Spor	2005-2009		Drive the parking brake to the mounting position.
Range Rover Spor	2005-2009		Headlamp calibration suspension set-up
Range Rover Spor	2005-2009		Lateral accelerometer calibration.
Range Rover Spor	2005-2009		Longitudinal accelerometer calibration.
Range Rover Spor	2005-2009		Parking brake unjam procedure.
Range Rover Spor	2005-2009		Petrol powertrain idle speed control test
Range Rover Spor	2005-2009		Program keys.
Range Rover Spor	2005-2009		Rain sensor initialisation.
Range Rover Spor	2005-2009		Reset the oil service counter.
Range Rover Spor	2005-2009		Seat cushion replacement
Range Rover Spor	2005-2009		Service interval reset.
Range Rover Spor	2005-2009		Sliding roof module initialisation.
Range Rover Spor	2005-2009		Steering angle sensor calibration
Range Rover Spor	2005-2009		Steering column calibration
Range Rover Spor	2005-2009		Suspension geometry set-up
Range Rover Spor	2005-2009		Suspension tight tolerance control
Range Rover Spor	2005-2009		Third button configuration.
Range Rover Spor	2005-2009		Tire pressure monitor confirmation application.

Autel®

Fuction List

VehicleType	ModelYear	System Name	Function Name
Defender	2007~2011		Injector replacement
Range Rover Spor	2005-2009		Tire pressure sensor replacement.
Range Rover Spor	2010		Add additional keys
Range Rover Spor	2010		Air suspension deflation.
Range Rover Spor	2010		Air suspension enable.
Range Rover Spor	2010		Battery replacement
Range Rover Spor	2010		Brake bleed.
Range Rover Spor	2010		Build mode
Range Rover Spor	2010		Calibration learn
Range Rover Spor	2010		Check Passive Keys Enabled
Range Rover Spor	2010		Clear adaptive data.
Range Rover Spor	2010		Diesel particulate filter dynamic regeneration
Range Rover Spor	2010		Diesel particulate filter replacement
Range Rover Spor	2010		Drive the parking brake to the latching position.
Range Rover Spor	2010		Drive the parking brake to the mounting position.
Range Rover Spor	2010		Driver's side - Door glass window calibration
Range Rover Spor	2010		Exhaust gas recirculation valve
Range Rover Spor	2010		Headlamp calibration suspension set-up
Range Rover Spor	2010		Headlamp control module system calibration
Range Rover Spor	2010		Height calibration
Range Rover Spor	2010		Immobilization
Range Rover Spor	2010		Injector replacement
Range Rover Spor	2010		Lateral accelerometer calibration.
Range Rover Spor	2010		Longitudinal accelerometer calibration.
Range Rover Spor	2010		Oil service counter reset
Range Rover Spor	2010		Parking brake unjam procedure.
Range Rover Spor	2010		Passenger's side - Door glass window calibration
Range Rover Spor	2010		Petrol powertrain idle speed control test
Range Rover Spor	2010		Recover Programmed keys
Range Rover Spor	2010		Replace faulty/lost keys
Range Rover Spor	2010		Restraints build mode
Range Rover Spor	2010		Seat cushion replacement
Range Rover Spor	2010		Service interval reset.
Range Rover Spor	2010		Steering angle sensor calibration
Range Rover Spor	2010		Steering column calibration
Range Rover Spor	2010		Sunroof calibration
Range Rover Spor	2010		Suspension geometry set-up
Range Rover Spor	2010		Suspension tight tolerance control
Range Rover Spor	2010		Throttle valve actuator
Range Rover Spor	2010		Tire pressure monitor sensor identification display
Range Rover Spor	2010		Tire pressure sensor replacement.
Range Rover Spor	2010		Verify keys
Range Rover	1999-2002	Engine	Reset Adaptions
Range Rover	1999-2002	AT	Reset Adaptions
Range Rover	2002-2004	Engine	Idle speed adjustment
Range Rover	2002-2004	Engine	Reset Adaptions
Range Rover	2002-2004	Engine	Erase driver demand fault
Range Rover	2002-2004	AT	Reset Adaptions
Range Rover	2002-2004	ABS	Steering Angle Calibration
Range Rover	2002-2004	Air Suspension	Transport Mode
Range Rover	2002-2004	Air Suspension	Production Mode
Range Rover	2002-2004	Air Suspension	System Deflate
Range Rover	2002-2004	Air Suspension	System Inflation
Range Rover	2002-2004	Air Suspension	Height Calibration
Range Rover	2002-2004	Wash Wipe	Rain sensor reset
Range Rover	2006		Air suspension deflation.

Autel®

Fuction List

VehicleType	ModelYear	System Name	Function Name
Defender	2007~2011		Injector replacement
Range Rover	2006		Air suspension enable.
Range Rover	2006		Brake bleed.
Range Rover	2006		Headlamp calibration suspension set-up
Range Rover	2006		Idle speed control valve test
Range Rover	2006		Program keys.
Range Rover	2006		Rain sensor initialisation.
Range Rover	2006		Service interval reset.
Range Rover	2006		Sliding roof module initialisation.
Range Rover	2006		Steering angle sensor calibration
Range Rover	2006		Suspension geometry set-up
Range Rover	2006		Suspension tight tolerance control
Range Rover	2006		Tire pressure monitor confirmation application.
Range Rover	2006		Tire pressure sensor replacement.
Range Rover	2007		Air suspension deflation.
Range Rover	2007		Air suspension enable.
Range Rover	2007		Air suspension height calibration.
Range Rover	2007		Brake bleed.
Range Rover	2007		Diesel particulate filter dynamic regeneration
Range Rover	2007		Diesel particulate filter replacement
Range Rover	2007		Drive the parking brake to the latching position.
Range Rover	2007		Drive the parking brake to the mounting position.
Range Rover	2007		Headlamp calibration suspension set-up
Range Rover	2007		Idle speed control valve test
Range Rover	2007		Longitudinal accelerometer calibration.
Range Rover	2007		Parking brake unjam procedure.
Range Rover	2007		Program keys.
Range Rover	2007		Rain sensor initialisation.
Range Rover	2007		Rain sensor windshield setup
Range Rover	2007		Reset the oil service counter.
Range Rover	2007		Seat cushion replacement
Range Rover	2007		Service interval reset.
Range Rover	2007		Sliding roof module initialisation.
Range Rover	2007		Steering angle sensor calibration
Range Rover	2007		Suspension geometry set-up
Range Rover	2007		Suspension tight tolerance control
Range Rover	2007		Tire pressure monitor confirmation application.
Range Rover	2007		Tire pressure sensor replacement.
Range Rover	2010		Add additional keys
Range Rover	2010		Air suspension deflation.
Range Rover	2010		Air suspension enable.
Range Rover	2010		Battery replacement
Range Rover	2010		Brake bleed.
Range Rover	2010		Build mode
Range Rover	2010		Calibration learn
Range Rover	2010		Check Passive Keys Enabled
Range Rover	2010		Diesel particulate filter dynamic regeneration
Range Rover	2010		Diesel particulate filter replacement
Range Rover	2010		Drive the parking brake to the latching position.

Autel®

Fuction List

VehicleType	ModelYear	System Name	Function Name
Defender	2007~2011		Injector replacement
Range Rover	2010		Drive the parking brake to the mounting position.
Range Rover	2010		Driver's side - Door glass window calibration
Range Rover	2010		Headlamp calibration suspension set-up
Range Rover	2010		Headlamp control module system calibration
Range Rover	2010		Height calibration
Range Rover	2010		Idle speed test.
Range Rover	2010		Immobilization
Range Rover	2010		Longitudinal accelerometer calibration.
Range Rover	2010		Parking brake unjam procedure.
Range Rover	2010		Passenger's side - Door glass window calibration
Range Rover	2010		Recover Programmed keys
Range Rover	2010		Replace faulty/lost keys
Range Rover	2010		Reset the oil service counter.
Range Rover	2010		Restraints build mode
Range Rover	2010		Seat cushion replacement
Range Rover	2010		Service interval reset.
Range Rover	2010		Steering angle sensor calibration
Range Rover	2010		Steering column calibration
Range Rover	2010		Sunroof calibration
Range Rover	2010		Suspension geometry set-up
Range Rover	2010		Suspension tight tolerance control
Range Rover	2010		Tire pressure monitor sensor identification display
Range Rover	2010		Tire pressure sensor replacement.
Range Rover	2010		Verify keys
Freelander 1	~2007	Engine	Adjust throttle stop
Freelander 1	~2007	Engine	CO adjustment
Freelander 1	~2007	Engine	ECM Options
Freelander 1	~2007	Engine	Idle speed adjustment
Freelander 1	~2007	Engine	Reset Adaptions
Freelander 1	~2007	Engine	Reset closed throttle position
Freelander 1	~2007	Engine	Service Idle Speed Offset
Freelander 1	~2007	Engine	Service Ignition Offset
Freelander 1	~2007	Engine	Set service ignition off set
Freelander 1	~2007	ABS	Calibrate 'G' Sensor
Freelander 1	~2007	ABS	VAC Fill Valve Sequence
Freelander 1	~2007	Security	EKA Programming
Freelander 1	~2007	Security	PLIP Programming
Freelander 2	2007~		Battery replacement
Freelander 2	2007~		Boost pressure actuator replacement
Freelander 2	2007~		Crash status reset
Freelander 2	2007~		Diesel fueling adaption re-initialization
Freelander 2	2007~		Diesel lambda sensor replacement
Freelander 2	2007~		Diesel particulate filter air temperature sensor
Freelander 2	2007~		Diesel particulate filter differential pressure sensor replacement
Freelander 2	2007~		Diesel particulate filter dynamic regeneration
Freelander 2	2007~		Diesel particulate filter replacement
Freelander 2	2007~		Driver's door window glass
Freelander 2	2007~		Exhaust gas recirculation replacement

Autel®

Fuction List

VehicleType	ModelYear	System Name	Function Name
Defender	2007~2011		Injector replacement
Freelander 2	2007~		Headlamp control module system calibration
Freelander 2	2007~		Idle speed - Adjustment
Freelander 2	2007~		Injector replacement
Freelander 2	2007~		Lateral accelerometer calibration.
Freelander 2	2007~		Longitudinal accelerometer sensor calibration
Freelander 2	2007~		Oil change reset
Freelander 2	2007~		Passenger's door window glass
Freelander 2	2007~		Pressure sensor calibration.
Freelander 2	2007~		Program keys.
Freelander 2	2007~		Restraints build mode
Freelander 2	2007~		Roll Rate sensor calibration
Freelander 2	2007~		Seat cushion replacement
Freelander 2	2007~		Service interval reset.
Freelander 2	2007~		Sunroof calibration
Freelander 2	2007~		Throttle valve actuator replacement
Freelander 2	2007~		Tire pressure sensor replacement.
Freelander 2	2007~		Yaw rate sensor calibration.